

## Industrial Automation Headquarters

**Taiwan: Delta Electronics, Inc.**  
 Taoyuan Technology Center  
 No.18, Xinglong Rd., Taoyuan District,  
 Taoyuan City 33068, Taiwan  
 TEL: +886-3-362-6301 / FAX: +886-3-371-6301

## Asia

**China: Delta Electronics (Shanghai) Co., Ltd.**  
 No.182 Minyu Rd., Pudong Shanghai, P.R.C.  
 Post code : 201209  
 TEL: +86-21-6872-3988 / FAX: +86-21-6872-3996  
 Customer Service: 400-820-9595

**Japan: Delta Electronics (Japan), Inc.**  
 Industrial Automation Sales Department  
 2-1-14 Shibadaimon, Minato-ku  
 Tokyo, Japan 105-0012  
 TEL: +81-3-5733-1155 / FAX: +81-3-5733-1255

**Korea: Delta Electronics (Korea), Inc.**  
 1511, 219, Gasan Digital 1-Ro., Geumcheon-gu,  
 Seoul, 08501 South Korea  
 TEL: +82-2-515-5305 / FAX: +82-2-515-5302

**Singapore: Delta Energy Systems (Singapore) Pte Ltd.**  
 4 Kaki Bukit Avenue 1, #05-04, Singapore 417939  
 TEL: +65-6747-5155 / FAX: +65-6744-9228

**India: Delta Electronics (India) Pvt. Ltd.**  
 Plot No.43, Sector 35, HSIIDC Gurgaon,  
 PIN 122001, Haryana, India  
 TEL: +91-124-4874900 / FAX: +91-124-4874945

**Thailand: Delta Electronics (Thailand) PCL.**  
 909 Soi 9, Moo 4, Bangpoo Industrial Estate (E.P.Z),  
 Pattana 1 Rd., T.Phraksa, A.Muang,  
 Samutprakarn 10280, Thailand  
 TEL: +66-2709-2800 / FAX: +66-2709-2827

**Australia: Delta Electronics (Australia) Pty Ltd.**  
 Unit 2, Building A, 18-24 Ricketts Road,  
 Mount Waverley, Victoria 3149 Australia  
 Mail: IA.au@deltaww.com  
 TEL: +61-1300-335-823 / +61-3-9543-3720

## Americas

**USA: Delta Electronics (Americas) Ltd.**  
 5101 Davis Drive, Research Triangle Park, NC 27709, U.S.A.  
 TEL: +1-919-767-3813 / FAX: +1-919-767-3969

**Brazil: Delta Electronics Brazil Ltd.**  
 Estrada Velha Rio-São Paulo, 5300 Eugênio de  
 Melo - São José dos Campos CEP: 12247-004 - SP - Brazil  
 TEL: +55-12-3932-2300 / FAX: +55-12-3932-237

**Mexico: Delta Electronics International Mexico S.A. de C.V.**  
 Gustavo Baz No. 309 Edificio E PB 103  
 Colonia La Loma, CP 54060  
 Tlalnepantla, Estado de México  
 TEL: +52-55-3603-9200

## EMEA

**EMEA Headquarters: Delta Electronics (Netherlands) B.V.**  
 Sales: Sales.IA.EMEA@deltaww.com  
 Marketing: Marketing.IA.EMEA@deltaww.com  
 Technical Support: iatechnicalsupport@deltaww.com  
 Customer Support: Customer-Support@deltaww.com  
 Service: Service.IA.emea@deltaww.com  
 TEL: +31(0)40 800 3900

**BENELUX: Delta Electronics (Netherlands) B.V.**  
 Automotive Campus 260, 5708 JZ Helmond, The Netherlands  
 Mail: Sales.IA.Benelux@deltaww.com  
 TEL: +31(0)40 800 3900

**DACH: Delta Electronics (Netherlands) B.V.**  
 Coesterweg 45, D-59494 Soest, Germany  
 Mail: Sales.IA.DACH@deltaww.com  
 TEL: +49(0)2921 987 0

**France: Delta Electronics (France) S.A.**  
 ZI du bois Challand 2, 15 rue des Pyrénées,  
 Lisses, 91090 Evry Cedex, France  
 Mail: Sales.IA.FR@deltaww.com  
 TEL: +33(0)1 69 77 82 60

**Iberia: Delta Electronics Solutions (Spain) S.L.U**  
 Ctra. De Villaverde a Vallecas, 265 1º Dcha Ed.  
 Hormigueras - P.I. de Vallecas 28031 Madrid  
 TEL: +34(0)91 223 74 20  
 Carrer Llacuna 166, 08018 Barcelona, Spain  
 Mail: Sales.IA.Iberia@deltaww.com

**Italy: Delta Electronics (Italy) S.r.l.**  
 Via Meda 2-22060 Novedrate(CO)  
 Piazza Grazioli 18 00186 Roma Italy  
 Mail: Sales.IA.Italy@deltaww.com  
 TEL: +39 039 8900365

**Russia: Delta Energy System LLC**  
 Vereyskaya Plaza II, office 112 Vereyskaya str.  
 17 121357 Moscow Russia  
 Mail: Sales.IA.RU@deltaww.com  
 TEL: +7 495 644 3240

**Turkey: Delta Greentech Elektronik San. Ltd. Sti. (Turkey)**  
 Şerifali Mah. Hendem Cad. Kule Sok. No:16-A  
 34775 Ümraniye - İstanbul  
 Mail: Sales.IA.Turkey@deltaww.com  
 TEL: + 90 216 499 9910

**MEA: Eltek Dubai (Eltek MEA DMCC)**  
 OFFICE 2504, 25th Floor, Saba Tower 1,  
 Jumeirah Lakes Towers, Dubai, UAE  
 Mail: Sales.IA.MEA@deltaww.com  
 TEL: +971(0)4 2690148

# AS Series Programming Manual



Digitized Automation for a Changing World

# AS Series Programming Manual

# AS Series Programming Manual

## Revision History

Version	Revision	Date
1 <sup>st</sup>	The first version was published.	2016/11/30
2 <sup>nd</sup>	<ol style="list-style-type: none"> <li>Updated information in section 2.1.1, 2.2.7, 2.2.8, 2.2.14, 2.2.16.</li> <li>Added new instructions in Chapter 3.</li> <li>Updated and added new instructions in Chapter 6.</li> <li>Updated information in Chapter 7.</li> </ol>	2018/05/07
3 <sup>rd</sup>	<ol style="list-style-type: none"> <li>Updated SM information in section 2.1.1.</li> <li>Updated SM information including SM784-815, SM896-927, SM1440-1447 and added SM478-479, SM498-499, SM518-519, SM538-539, SM558-559, SM578-579, SM1581-1608, SM1611-1618, SM1621-1628, SM1683-1684, and SM1691-1698SM in sections 2.2.7.</li> <li>Updated the table of SM refresh time and added new SM refresh time in the table in section 2.2.8.</li> <li>Updated SR182-183, SR217-218, SR424, SR825-893, SR1336, and SR1376 in section 2.2.14.</li> <li>Added SR187-188, SR478-479, SR498-499, SR518-519, SR538-539, SR558-559, SR578-579, SR640-651, SR751-758, and SR761-768 in section 2.2.14.</li> <li>Updated descriptions in point 4 Communication functions, point 14 S curve mode and point 18 Flags and registers concerning data exchange. Added point 15 Backlash compensation function in section 2.2.16.</li> <li>Added new instructions on the lists in Chapter 3.</li> <li>Added new instructions in Chapter 6: API0222, API0601, API0711, API1012, API1013, API1226, API1402, API1403, API1404, API1405, API1406, API1407, API08, API1409, API1410, API1415, API1416, API1818, API1819, API1820, API1906, API2122, API2123, API2211, API2212, API2808, API2809, API2810, and API2811.</li> <li>Updated instructions in Chapter 6: API0222, API0600, API0702, API0708, API0709, API0710, API1004, API1601, API1607, API1808, API1812, API1814, API1815, API1816, API1817, API2200, API2200-2203, API2208, API2210, API2300, API2301, API2302, API2303, API2401, API2500, API2700, API2701, API2702, API2703, API2704, API2705, API2706, API2707, API2708, API2709, API2710, API2711, API2712, API2713, API2714, API2715, API2716, API2717, API2718, API2721, API2723, API2800, API2801, API2802, API2803, API2804, API2805, API2806, API2807 and API2808.</li> <li>Updated solutions for errors including codes 7203, 8105, 8106 and 8107.</li> </ol>	2018/05/22
4 <sup>th</sup>	<ol style="list-style-type: none"> <li>Manual corrections on the unit used in SR182, 183, 185, 210, 213, 421, 422, 423, and 424.</li> </ol>	2018/06/12
5 <sup>th</sup>	<ol style="list-style-type: none"> <li>Added AS300/AS200 Series CPU module descriptions</li> </ol>	2019/5/10

Version	Revision	Date
	<p>in section 1.1.2 Model Description.</p> <ol style="list-style-type: none"> <li>2. Added and updated SM and SR in Chapter 2: SM230-SM261, SM585-SM587, SM1110, SM1685, SR652-SR655, SR791-SR806, SR811-SR818, SR823-SR824, SR1015, SR1520-SR1540, SR1559-SR1592, SM76-SM91, SM168-SM171, SM455, SM1006-SM1031, SM1184-SM1199, SM1216-SM1231, SM1248-SM1263, SM1271-SM1299, SM1424-SM1439, SM1681, SM1709-SM1919, SR166-SR179, SR182-SR183, SR187-SR188, SR215-SR216, SR1000-SR1014, and SR1435-SR1511.</li> <li>3. Added and updated instructions in Chapter 3: API0602, API1417, API2304, API2724, API2812-API2816, API0711, API1110, API1111, API1402, API1407, API1408, and API1416.</li> <li>4. Added information of using index registers in interrupt instructions in section 4.4.</li> <li>5. Updated instructions in Chapter 5: PED, APED, OPED, NED, ANED, ONED, PLS and PLF.</li> <li>6. Updated instructions in Chapter 6: API0602, API1417, API2304, API2724, API2812-API2816, API0018-API0023, API0708-API0711, API1004-API1007, API1110, API1111, API1226, API1402-API1410, API1415-API1416, API1816, API2200, API2201, API2203, API2208, API2210-API2212, API2300-API2302, API2704, API2706-API2709, API2712-API2716, API2719, API2800, API2803, API2805 and API2807.</li> <li>7. Updated emergency information in section 7.3.1 and 7.3.2. Added error codes 2030 and 2031.</li> </ol>	
6 <sup>th</sup>	<ol style="list-style-type: none"> <li>1. Manual corrections on the descriptions of function codes K5566 and K5577 of SR36 and SR412 and SR415 in Chapter 2.</li> <li>2. Updated the descriptions in SM1375~SM1447 in Chapter 2.</li> <li>3. Updated the descriptions in SR1000~SR1006 in Chapter 2.</li> <li>4. Updated the descriptions in the error code 16#00xx in Chapter 2.</li> <li>5. Added a maximum input frequency table in DCNT instruction (API1004) in Chapter 6.</li> <li>6. Updated the acceptable input range for S<sub>1</sub> in PWD instruction (API1009) in Chapter 6.</li> <li>7. Updated the alignment mark function charts in DDRVM instruction (API2709) in Chapter 6.</li> <li>8. Added an example of using abort symbols and completion flags in TPO instruction (API2718) in Chapter 6.</li> </ol>	2019/6/21

7 <sup>th</sup>	<ol style="list-style-type: none"> <li>1. Updated description on AS300, AS200, AS02, 04PU-A in Section 1.1.2.</li> <li>2. Added new product information AS100, AS02HC-A, AS04SIL-A, AS-FPFN02 and AS-FOPC02 in Chapter 1.</li> <li>3. Updated Relation Between the PLC Action and Device Type in Section 2.1.3. Added AS100 information updated SM1375~SM1477 and added SM1448~1455, SM1686 in Section 2.2.7 Special Auxiliary Relays (SM) and Section 2.2.14 Special Data Registers (SR). Added CNT instruction information in Section 2.2.11 Counters. Added DCNT instruction information in Section 2.2.12 32-bit counters (HC). Added frequently mapped registers information in Section 2.2.13. Added new Special Data Registers (SR): SR42, SR48, SR54, SR60, SR66, SR72, SR78, SR84, SR90, SR96, SR102, SR108, SR114, SR120, SR126, SR132, SR138, SR144, SR150, SR156, SR405, SR406 and delete SR1540 in Section 2.2.14. Added #2 error codes in SM27/SR27, updated #22 information in Flags SM230~261, updated #7 PLC error log information, added #24 Auto-reset flags for pulse output in Section 2.2.16.</li> <li>4. Added and updated instructions in Chapter 3: API1014, API1015, API1227, API1418-API1423, API1821, API2817, API2818, API1102-API1108, API1114, API1115, API2806, API1415.</li> <li>5. Added a section explaining which instruction should be used in Ladder Programming Language in section 4.3.</li> <li>6. All the instructions in this manual does NOT support the data type UINT. Remove UINT from the supporting list in Chapter 6. Updated instructions in Chapter 6: API0202, API0216, API0501, API0600, API0708, API0709, API0710, API0801, API1002, API1003, API1004, API1005, API1006, API1007, API1009, API1102-API1108, API1114, API1115, API1210, API1212, API1213, API1226, API1401, API1402, API1404, API1405, API1407, API1408, API1415, API1416, API1417, API1501-API1504, API1808, API2106, API2116, API2117, API2119, API2200, API2204, API2208, API2209, API2212, API2301, API2704, API2706, API2708, API2709, API2718, API2800, API2803, API2806, API2812-API2815. Added new instructions in Chapter 6: API1014, API1015, API1227, API1418-API1423, API1426, API1427, API1821, API2817 and API2818.</li> <li>7. Added an explanation about Step Position in Section 7.1.4.</li> <li>8. Updated error codes 2001-2027 in Section 7.2.8 and 7.2.9. Updated the ERROR LED indicators blinking time to every 0.2 seconds for AIO modules and AS02LC in Section 7.3.1. Added error codes 16#1500 and 16#1505 for AS00SCM in Section 7.3.4.</li> </ol>	2020/12/08
-----------------	--	------------

8 <sup>th</sup>	<ol style="list-style-type: none"> <li>1. Added new product information AS-PS03C, AS-ATXB and updated product information AS-FEN02, AS-FPFN02, AS-FOPC02 in Chapter 1.</li> <li>2. Added and updated SM and SR in Chapter 2: SM27, SM120-151, SM360-391, SM603, SM1160-1161, SM1700-1705, SR27, SR29-31, SR1016-1019, SR1600-1605, SR1700, SR1702, SR1704, SR1706, SR1708, SR1710. Removed the following SM and SR from Chapter 2: SM468, SM488, SM508, SM528, SM548, SM568, SR604-609. Added and updated the following information in section 2.2.16: SR227 information, backlash compensation information, Ethernet IP related flags, SM230-261, auto-reset flags for pulse output, auto-reset flags for Delta CAN communication, how to use DPLSY in high-speed comparison interrupt (I2xx) and how to use backlash compensation in CSFO.</li> <li>3. Added and updated instructions in Chapter 3: API1229, API1424, API1425, API1426, API1427 and API1228.</li> <li>4. Updated instructions in Chapter 6: API0501, API0708, API0709, API1004, API1228, API1400, API1401, API1402, API1403, API1404, API1405, API1406, API1407, API1408, API1409, API1410, API1417, API1418, API1419, API1420, API1421, API1422, API1423, API2300, API2301, API2302, API2304, API2703, API2706, API2710, API2712, API2714, API2810, API2817, and API2818. Added new instructions in Chapter 6: API1229, PI1424, API1425, API1426, and API1427.</li> <li>5. Added error codes 16#19B0-16#19FC in Section 7.2.9. Added and updated information for AS02/04PU, AS02HC, AS04SIL, AS01DNET and AS00SCM in sections 7.3 and 7.4.</li> </ol>	2021/06/24
9 <sup>th</sup>	<ol style="list-style-type: none"> <li>1. Added new instructions API1016-API1018, API1430, API2214, API2215, API2216, API2305, API2820, API2821, API2822, API2823 and updated instructions API1226, API1228 in Chapter 3.</li> <li>2. Added CANRS instruction for CANopen Communication instruction while using with the Ladder Programming language in section 4.3.</li> <li>3. Updated the supported version of ISPSOft for PLF instruction in Chapter 5.</li> <li>4. Added new instructions API1016-API1018, API1430, API2214, API2215, API2216, API2305, API2214, API2215, API2216, API2305, API2820, API2821, API2822, API2823 and updated the following instructions API0222, API0600, API1100, API1101, API1226, API1228, API1421, API1422, API1424, API1425, API1516, API1819, API1821, API1901, API2704, API2717, API2718, API2719, API2720, API2721,</li> </ol>	2022/08/01

	<p>API2724, API2800, API2801, API2802, API2803, API2804, API2805, API2806, API2807, API2809, API2810, API2811, API2812, API2817 and API2818 in Chapter 6.</p> <p>5. Added new error codes 16#000D, 16#0020, 16#0021, 16#0028, 16#0040-16#0047, 16#1000-16#10FF, 16#140C and updated error codes 16#1900-16#191C in section 7.2.2.</p>	
--	---	--

# AS Series Programming Manual

## Table of Contents

### Chapter 1 Introduction

<b>1.1 Overview</b> .....	<b>1-2</b>
1.1.1 Related Manuals .....	1-2
1.1.2 Model Description .....	1-2
<b>1.2 Software</b> .....	<b>1-10</b>
1.2.1 Program Editor .....	1-10
1.2.2 Program Organization Units and Tasks.....	1-12

### Chapter 2 Devices

<b>2.1 Introduction to Devices</b> .....	<b>2-2</b>
2.1.1 Device Table.....	2-2
2.1.2 Basic Structure of I/O Storage .....	2-3
2.1.3 Relation Between the PLC Action and the Device Type .....	2-3
2.1.4 Latched Areas in the Device Range .....	2-4
<b>2.2. Device Functions</b> .....	<b>2-5</b>
2.2.1 Values and Constants .....	2-5
2.2.2 Floating-point Numbers.....	2-7
2.2.3 Strings .....	2-8
2.2.4 Input Relays (X) .....	2-9
2.2.5 Output Relays (Y) .....	2-10
2.2.6 Auxiliary Relays (M) .....	2-10
2.2.7 Special Auxiliary Relays (SM) .....	2-11
2.2.8 Refresh Time for Special Auxiliary Relays.....	2-71
2.2.9 Relays (S).....	2-79
2.2.10 Timers (T) .....	2-79
2.2.11 Counters.....	2-81
2.2.12 32-bit Counters (HC) .....	2-83
2.2.13 Data Registers (D) .....	2-85
2.2.14 Special Data Registers (SR) .....	2-86
2.2.15 Special Data Registers Refresh Conditions .....	2-133
2.2.16 Additional Remarks on Special Auxiliary Relays and Special Data Registers .....	2-137
2.2.17 Index Registers (E) .....	2-171
2.2.18 File Registers (FR).....	2-171

## Chapter 3 Instruction Tables

<b>3.1</b>	<b>Types of Instructions</b> .....	<b>3-2</b>
3.1.1	Basic Instructions .....	3-2
3.1.2	Applied Instructions .....	3-2
<b>3.2</b>	<b>Understanding Instruction Tables</b> .....	<b>3-3</b>
3.2.1	Basic Instructions .....	3-3
3.2.2	Applied Instructions (Sorted numerically) .....	3-4
3.2.3	Applied Instructions (Sorted Alphabetically).....	3-5
3.2.4	Device Tables .....	3-6
<b>3.3</b>	<b>Lists of Basic Instructions</b> .....	<b>3-8</b>
<b>3.4</b>	<b>Lists of Applied Instructions</b> .....	<b>3-11</b>
3.4.1	Applied Instructions (Sorted numerically by API number) .....	3-11
3.4.2	Applied Instructions (Sorted Alphabetically).....	3-48

## Chapter 4 Instruction Structure

<b>4.1</b>	<b>Applied Instructions - API Description</b> .....	<b>4-2</b>
<b>4.2</b>	<b>Operand Usage Description</b> .....	<b>4-4</b>
<b>4.3</b>	<b>Restrictions on the Use of Instructions</b> .....	<b>4-7</b>
<b>4.4</b>	<b>Index Registers</b> .....	<b>4-9</b>
<b>4.5</b>	<b>Pointer Registers</b> .....	<b>4-12</b>
<b>4.6</b>	<b>Pointer Registers of Timers</b> .....	<b>4-14</b>
<b>4.7</b>	<b>Pointer Registers for 16-bit Counters</b> .....	<b>4-16</b>
<b>4.8</b>	<b>Pointer Registers for 32-bit Counters</b> .....	<b>4-18</b>
<b>4.9</b>	<b>File Register</b> .....	<b>4-20</b>

## Chapter 5 Basic Instructions

<b>5.1</b>	<b>List of Basic Instructions</b> .....	<b>5-2</b>
<b>5.2</b>	<b>Basic Instructions</b> .....	<b>5-3</b>

## Chapter 6 Applied Instructions

<b>6.1 Comparison Instructions</b> .....	<b>6-4</b>
6.1.1 List of Comparison Instructions .....	6-4
6.1.2 Explanation of Comparison Instructions.....	6-7
<b>6.2 Arithmetic Instructions</b> .....	<b>6-46</b>
6.2.1 List of Arithmetic Instructions .....	6-46
6.2.2 Explanation of Arithmetic Instructions.....	6-47
<b>6.3 Data Conversion Instructions</b> .....	<b>6-78</b>
6.3.1 List of Data Conversion Instructions.....	6-78
6.3.2 Explanation of Data Conversion Instructions .....	6-79
<b>6.4 Data Transfer Instructions</b> .....	<b>6-122</b>
6.4.1 List of Data Transfer Instructions.....	6-122
6.4.2 Explanation of Data Transfer Instructions.....	6-123
<b>6.5 Jump Instructions</b> .....	<b>6-150</b>
6.5.1 List of Jump Instructions .....	6-150
6.5.2 Explanation of Jump Instructions.....	6-151
<b>6.6 Program Execution Instructions</b> .....	<b>6-159</b>
6.6.1 List of Program Execution Instructions .....	6-159
6.6.2 Explanation of Program Execution Instructions .....	6-160
<b>6.7 IO Refreshing Instructions</b> .....	<b>6-172</b>
6.7.1 List of IO Refreshing Instructions .....	6-172
6.7.2 Explanation of IO Refreshing Instructions .....	6-173
<b>6.8 Miscellaneous Instructions</b> .....	<b>6-181</b>
6.8.1 List of Convenience Instructions .....	6-181
6.8.2 Explanation of Convenience Instructions.....	6-182
<b>6.9 Logic Instructions</b> .....	<b>6-235</b>
6.9.1 List of Logic Instructions .....	6-235
6.9.2 Explanation of Logic Instructions.....	6-236
<b>6.10 Rotation Instructions</b> .....	<b>6-257</b>
6.10.1 List of Rotation Instructions .....	6-257
6.10.2 Explanation of Rotation Instructions.....	6-258
<b>6.11 Timer and Counter Instructions</b> .....	<b>6-269</b>
6.11.1 List of Timer and Counter Instructions.....	6-269
6.11.2 Explanation of Timer and Counter Instructions.....	6-270
<b>6.12 Shift Instructions</b> .....	<b>6-317</b>
6.12.1 List of Shift Instructions .....	6-317

6.12.2 Explanation of Shift Instructions.....	6-318
<b>6.13 Data Processing Instructions.....</b>	<b>6-359</b>
6.13.1 List of Data Processing Instructions .....	6-359
6.13.2 Explanation of Data Processing Instructions .....	6-360
<b>6.14 Structure Creation Instructions .....</b>	<b>6-425</b>
6.14.1 List of Structure Creation Instructions.....	6-425
6.14.2 Explanation of Structure Creation Instructions.....	6-426
<b>6.15 Module Instructions .....</b>	<b>6-434</b>
6.15.1 List of Module Instructions .....	6-434
6.15.2 Explanation of Module Instructions .....	6-435
<b>6.16 Floating-point Number Instructions .....</b>	<b>6-560</b>
6.16.1 List of Floating-point Number Instructions .....	6-560
6.16.2 Explanation of Floating-point Number Instructions .....	6-561
<b>6.17 Real-time Clock Instructions .....</b>	<b>6-596</b>
6.17.1 List of Real-time Clock Instructions.....	6-596
6.17.2 Explanation of Real-time Clock Instructions .....	6-597
<b>6.18 Peripheral Instructions.....</b>	<b>6-628</b>
6.18.1 List of Peripheral Instructions .....	6-628
6.18.2 Explanation of Peripheral Instructions .....	6-629
<b>6.19 Communication Instructions .....</b>	<b>6-645</b>
6.19.1 List of Communication Instructions.....	6-645
6.19.2 Explanation of Communication Instructions.....	6-646
6.19.3 Descriptions on the Communication-related Flags and Registers .....	6-733
<b>6.20 Other Instructions .....</b>	<b>6-737</b>
6.20.1 List of Other Instructions .....	6-737
6.20.2 Explanation of Other Instructions .....	6-738
<b>6.21 String Processing Instructions .....</b>	<b>6-750</b>
6.21.1 List of String Processing Instructions .....	6-750
6.21.2 Explanation of String Processing Instructions .....	6-751
<b>6.22 Ethernet Instructions .....</b>	<b>6-814</b>
6.22.1 List of Ethernet Instructions .....	6-814
6.22.2 Explanation of Ethernet Instructions .....	6-815
<b>6.23 Memory Card Instructions .....</b>	<b>6-878</b>
6.23.1 List of Memory Card Instructions.....	6-878
6.23.2 Explanation of Memory Card Instructions .....	6-879
<b>6.24 Task Control Instructions .....</b>	<b>6-904</b>
6.24.1 List of Task Control Instructions .....	6-904

6.24.2 Explanation of Task Control Instructions .....	6-905
<b>6.25 SFC Instructions .....</b>	<b>6-909</b>
6.25.1 List of SFC Instructions .....	6-909
6.25.2 Explanation of SFC Instructions .....	6-910
<b>6.26 High-speed Output Instructions .....</b>	<b>6-917</b>
6.26.1 List of High-speed Output Instructions.....	6-917
6.26.2 Explanation of High-speed Output Instructions .....	6-918
<b>6.27 Delta CANopen Communication Instructions .....</b>	<b>6-1032</b>
6.27.1 List of Delta CANopen Communication Instructions.....	6-1032
6.27.2 Explanation of Delta CANopen Communication Instructions .....	6-1033
6.27.3 Frequently asked questions in Delta special CANopen communication and Troubleshooting.....	6-1116

## Chapter 7 Troubleshooting

<b>7.1 Troubleshooting .....</b>	<b>7-3</b>
7.1.1 Basic troubleshooting steps .....	7-3
7.1.2 Clear the Error States.....	7-3
7.1.3 Troubleshooting SOP .....	7-4
7.1.4 System Log and Positions of the Error Step.....	7-5
<b>7.2 Troubleshooting for CPU Modules.....</b>	<b>7-7</b>
7.2.1 ERROR LED Indicators Are ON.....	7-7
7.2.2 ERROR LED Indicators Blinking Every 0.5 Seconds.....	7-7
7.2.3 ERROR LED Indicators Blinking Rapidly Every 0.2 Seconds .....	7-9
7.2.4 ERROR LED Indicators Slow Blinking Every 3 Seconds and Lighting up for 1 Second .....	7-9
7.2.5 BAT. LOW LED Indicators Are ON.....	7-10
7.2.6 BAT. LOW LED Indicators Blinking Every 0.5 Seconds .....	7-10
7.2.7 The LED RUN and ERROR Indicators are Blinking Simultaneously Every 0.5 Seconds.....	7-11
7.2.8 The RUN and LED Indicators are Blinking One After Another Every 0.5 Seconds. ....	7-11
7.2.9 Other Errors (Without LED Indicators).....	7-11
<b>7.3 Troubleshooting for Other I/O Modules.....</b>	<b>7-19</b>
7.3.1 Troubleshooting for Analog Modules (AD/DA/XA) and Temperature Modules (RTD/TC) .....	7-19
7.3.2 Troubleshooting for the Positioning Module AS02/04PU .....	7-20
7.3.3 Troubleshooting for the High-Speed Counter Module AS02HC .....	7-20
7.3.4 Troubleshooting for the Load Cell Module AS02LC .....	7-21
7.3.5 Troubleshooting for the Module AS04SIL IO-Link as a Communication	

	Module.....	7-22
7.3.6	Troubleshooting for the Module AS00SCM as a Communication Module	7-25
7.3.7	Troubleshooting for the Module AS00SCM as a Remote Module.....	7-26
7.3.8	Troubleshooting for AS01DNET Modules .....	7-27
<b>7.4</b>	<b>Error Codes and LED Indicators for Modules .....</b>	<b>7-28</b>
7.4.1	Error Codes and LED Indicators for CPU Modules .....	7-28
7.4.2	Error Codes and LED Indicators for Analog/Temperature Modules.....	7-35
7.4.3	Error Codes and LED Indicators for Positioning Module AS02 / 04PU....	7-36
7.4.4	Error Codes and LED Indicators for High Speed Counter Module AS02HC .....	7-36
7.4.5	Error Codes and LED Indicators for Load Cell Module AS02LC .....	7-37
7.4.6	Error Codes and LED Indicators for Module AS04SIL IO-Link as a Communication Module .....	7-37
7.4.7	Error Codes and LED Indicators for Module AS00SCM as a Communication Module.....	7-38
7.4.8	Error Codes and LED Indicators for Module AS00SCM as a Remote Module.....	7-38
7.4.9	Error Codes and LED Indicators for Module AS01DNET (Master/Slave Mode).....	7-39
7.4.10	Error Codes and LED Indicators for Module AS01DNET (RTU Mode) .....	7-40

---

# Chapter 1 Introduction

## Table of Contents

- 1.1 Overview ..... 1-2**
  - 1.1.1 Related Manuals ..... 1-2
  - 1.1.2 Model Description ..... 1-2
  
- 1.2 Software ..... 1-10**
  - 1.2.1 Program Editor ..... 1-10
  - 1.2.2 Program Organization Units and Tasks ..... 1-12

## 1.1 Overview

This manual introduces you how to program the AS Series programmable logic controllers, the basic instructions, and the applied instructions. For software operation, ISPSOft, DIADesigner or DIADesigner-AX is what you need. If you are using AS Series PLC CPU, refer to ISPSOft User Manual or DIADesigner Manual for more information.

### 1.1.1 Related Manuals

The related manuals for the AS Series programmable logic controllers are listed below.

- AS Series Quick Start
 

This guides you in getting started with the system before you read the other related manuals.
- AS Series Programming Manual (this manual)
 

This introduces you to programming the AS Series programmable logic controllers, the basic instructions, and the applied instructions.
- ISPSOft / DIADesigner User Manual
 

This introduces the ISPSOft / DIADesigner software that you use to program the AS Series programmable logic controllers. It describes the programming languages (ladder diagrams, instruction lists, sequential function charts, function block diagrams, and structured texts), the concept of POU's, and the concept of tasks.
- AS Series Hardware and Operation Manual
 

This introduces electrical specifications, appearances, dimensions, CPU functions, devices, module tables, troubleshooting, and so forth.
- AS Series Module Manual
 

This introduces the use of the special I/O modules; for example: network modules, analog I/O modules, temperature measurement modules, and others.

### 1.1.2 Model Description

Classification	Model Name	Description
Power supply module	AS-PS02	Input: 100-240 VAC, 50/60 Hz Output: 24VDC/2A, 48W (for PLC internal use)
	AS-PS02A	Input: 100-240 VAC, 50/60 Hz Output: 24VDC/1.5A, 36W (for PLC internal use) Output: 24VDC/0.5A, 12W (for external use)
Power module adaptor	AS-ATXB	Used with external power supplies for PLC racks which require more than 2A. For easier wiring, this adaptor allows wiring on the bottom of the module instead of on the left-side of the module.
AS300 Series CPU module	AS332P-A	CPU module, 24VDC power input, PNP output, 1x Ethernet port, 2x RS-485 ports, 1x USB port, 1x Micro SD interface, 2x function cards (optional), supporting 32 I/Os (16DI+16DO) and up to 1024 I/Os. Program capacity:128K steps, high-density terminal blocks
	AS332T-A	CPU module, 24VDC power input, NPN output, 1x Ethernet port, 2x RS-485 ports, 1x USB port, 1x Micro SD interface, 2x function cards (optional), supporting 32 I/Os (16DI+16DO) and up to 1024 I/Os. Program capacity:128K steps, high-density terminal blocks

Classification	Model Name	Description
	AS324MT-A	CPU module, 24VDC power input, NPN differential output, 1x Ethernet port, 2x RS-485 ports, 1x USB port, 1x Micro SD interface, 2x function cards (optional), supporting 24 I/Os (12DI+12DO) and up to 1016 I/Os. Program capacity:128K steps, high-density terminal blocks
	AS320P-B	CPU module, 24VDC power input, PNP output, 1x Ethernet port , 2x RS-485 ports, 1x USB port, 1x Micro SD interface, 2x function cards (optional), supporting 20 I/Os (8DI+12DO) and up to 1024 I/Os. Program capacity:128K steps, removable terminal blocks
	AS320T-B	CPU module, 24VDC power input, NPN output, 1x Ethernet port, 2x RS-485 ports, 1x USB port, 1x Micro SD interface, 2x function cards (optional), supporting 20 I/Os (8DI+12DO) and up to 1024 I/Os. Program capacity:128K steps, removable terminal blocks
	AS300N-A	CPU module, 24VDC power input, no I/Os, 1x Ethernet port, 2x RS-485 ports, 1x USB port, 1x Micro SD interface, 2x function cards (optional), and supporting up to 1024 I/Os. Program capacity:128K steps
AS200 Series CPU module	AS228P-A	CPU module, 24VDC power input, PNP output, 1x Ethernet port , 2x RS-485 ports, 1x USB port, 1x Micro SD interface, CAN communication port, supporting 28 I/Os (16DI+12DO) and up to 1024 I/Os. Program capacity: 64K steps, removable terminal blocks
	AS228T-A	CPU module, 24VDC power input, NPN output, 1x Ethernet port , 2x RS-485 ports, 1x USB port, 1x Micro SD interface, CAN communication port, supporting 28 I/Os (16DI+12DO) and up to 1024 I/Os. Program capacity: 64K steps, removable terminal blocks
	AS228R-A	CPU module, 24VDC power input, Relay output, 1x Ethernet port , 2x RS-485 ports, 1x USB port, 1x Micro SD interface, CAN communication port, supporting 28 I/Os (16DI+12DO) and up to 1024 I/Os. Program capacity: 64K steps, removable terminal blocks
	AS218PX-A	CPU module, 24VDC power input, PNP output, 1x Ethernet port , 2x RS-485 ports, 1x USB port, 1x Micro SD interface, CAN communication port, supporting 18 I/Os (8DI+6DO+2AI+2AO) and up to 1024 I/Os. Program capacity: 64K steps, removable terminal blocks
	AS218TX-A	CPU module, 24VDC power input, NPN output, 1x Ethernet port , 2x RS-485 ports, 1x USB port, 1x Micro SD interface, CAN communication port, supporting 18 I/Os (8DI+6DO+2AI+2AO) and up to 1024 I/Os. Program capacity: 64K steps, removable terminal blocks
	AS218RX-A	CPU module, 24VDC power input, Relay output, 1x Ethernet port , 2x RS-485 ports, 1x USB port, 1x Micro SD interface, CAN communication port, supporting 18 I/Os (8DI+6DO+2AI+2AO) and up to 1024 I/Os. Program capacity: 64K steps, removable terminal blocks
AS100 Series CPU module	AS132P-A	CPU module, 100-240 VAC power input, PNP output, 1x Ethernet port, 2x RS-485 ports, 1x USB port, 1x Micro SD interface, CAN communication port, supporting 32 I/Os (16DI+16DO) and up to 1024 I/Os. Program capacity:64K steps, removable terminal blocks
	AS132T-A	CPU module, 100-240 VAC power input, NPN output, 1x Ethernet port , 2x RS-485 ports, 1x USB port, 1x Micro SD interface, CAN

1

Classification	Model Name	Description
		communication port, supporting 32 I/Os (16DI+16DO) and up to 1024 I/Os. Program capacity: 64K steps, removable terminal blocks
	AS132R-A	CPU module, 100-240 VAC power input, Relay output, 1x Ethernet port, 2x RS-485 ports, 1x USB port, 1x Micro SD interface, CAN communication port, supporting 32 I/Os (16DI+16DO) and up to 1024 I/Os. Program capacity: 64K steps, removable terminal blocks
	AS148P-A	CPU module, 100-240 VAC power input, PNP output, 1x Ethernet port, 2x RS-485 ports, 1x USB port, 1x Micro SD interface, CAN communication port, supporting 48 I/Os (24DI+24DO) and up to 1024 I/Os. Program capacity: 64K steps, removable terminal blocks
	AS148T-A	CPU module, 100-240 VAC power input, NPN output, 1x Ethernet port, 2x RS-485 ports, 1x USB port, 1x Micro SD interface, CAN communication port, supporting 48 I/Os (24DI+24DO) and up to 1024 I/Os. Program capacity: 64K steps, removable terminal blocks
	AS148R-A	CPU module, 100-240 VAC power input, Relay output, 1x Ethernet port, 2x RS-485 ports, 1x USB port, 1x Micro SD interface, CAN communication port, supporting 48 I/Os (24DI+24DO) and up to 1024 I/Os. Program capacity: 64K steps, removable terminal blocks
	AS164P-A	CPU module, 100-240 VAC power input, PNP output, 1x Ethernet port, 2x RS-485 ports, 1x USB port, 1x Micro SD interface, CAN communication port, supporting 64 I/Os (32DI+32DO) and up to 1024 I/Os. Program capacity: 64K steps, removable terminal blocks
	AS164T-A	CPU module, 100-240 VAC power input, NPN output, 1x Ethernet port, 2x RS-485 ports, 1x USB port, 1x Micro SD interface, CAN communication port, supporting 64 I/Os (32DI+32DO) and up to 1024 I/Os. Program capacity: 64K steps, removable terminal blocks
	AS164R-A	CPU module, 100-240 VAC power input, Relay output, 1x Ethernet port, 2x RS-485 ports, 1x USB port, 1x Micro SD interface, CAN communication port, supporting 64 I/Os (32DI+32DO) and up to 1024 I/Os. Program capacity: 64K steps, removable terminal blocks
Digital input/output module	AS08AM10N-A	24VDC 5mA 8 inputs Spring-clamp terminal block
	AS08AN01P-A	5 - 30VDC 0.5A/output, 4A/COM 8 outputs Sourcing output Spring-clamp terminal block
	AS08AN01R-A	240VAC/24VDC 2A/output, 8A/COM 8 outputs Relay Spring-clamp terminal block
	AS08AN01T-A	5 - 30VDC 0.5A/output, 4A/COM 8 outputs

Classification	Model Name	Description
		Sinking output Spring-clamp terminal block
	AS16AM10N-A	24VDC 5mA 16 inputs Spring-clamp terminal block
	AS16AN01P-A	5 - 30VDC 0.5A/output, 4A/COM 16 outputs Sourcing output Spring-clamp terminal block
	AS16AN01R-A	240VAC/24VDC 2A/output, 8A/COM 16 outputs Relay Spring-clamp terminal block
	AS16AN01T-A	5 - 30VDC 0.5A/output, 4A/COM 16 outputs Sinking output Spring-clamp terminal block
	AS16AP11P-A	24VDC 5mA 8 inputs 5 - 30VDC 0.5A/output, 4A/COM 8 outputs Sourcing output Spring-clamp terminal block
	AS16AP11R-A	24VDC 5mA 8 inputs 240VAC/24VDC 2A/output, 8A/COM 8 outputs Relay Spring-clamp terminal block
	AS16AP11T-A	24VDC 5mA 8 inputs 5 - 30VDC 0.5A/output, 4A/COM 8 outputs Sinking output Spring-clamp terminal block
	AS32AM10N-A	24VDC 3.2mA

1

Classification	Model Name	Description
		32 inputs MIL connector
	AS32AN02T-A	5 - 30VDC 0.1A/output, 3.2A/COM 32 outputs Sinking output MIL connector
	AS64AM10N-A	24VDC 3.2mA 64 inputs MIL connector
	AS64AN02T-A	5 - 30VDC 0.1A/output, 3.2A/COM 64 outputs Sinking output MIL connector
Analog input/output module	AS04AD-A	4-channel analog input module Hardware resolution: 16 bits 0–10V, 0/1–5V, -5 to +5V, -10 to +10V, 0/4–20mA, -20–+20mA Conversion time: 2 ms/channel
	AS08AD-B	8-channel analog input module Hardware resolution: 16 bits 0 to +10V, 0/1–5V, -5V to +5V, -10V to +10V Conversion time: 2 ms/channel
	AS08AD-C	8-channel analog input module Hardware resolution: 16 bits 0/4–20mA, -20mA–+20mA Conversion time: 2 ms/channel
	AS04DA-A	4-channel analog output module Hardware resolution: 12 bits -10 to +10V, 0–20mA, 4–20mA Conversion time: 2 ms/channel
	AS06XA-A	4-channel analog input Hardware resolution: 16 bits 0–10V, 0/1–5V, -5 to +5V, -10 to +10V, 0/4–20mA, -20 to +20mA Conversion time: 2 ms/channel 2-channel analog output Hardware resolution: 12 bits -10 to +10V, 0–20mA, 4–20mA Conversion time: 2 ms/channel
	AS02ADH-A	2-channel analog input module Hardware resolution: 16 bits 0–10 V, 0/1–5 V, -5 to +5 V, -10 to +10 V, 0/4–20 mA, -20 to +20 mA High-speed conversion time: 2 μs Full isolation (the analog channels are isolated from one another.) Logging function enable/disable: 2000 data per channel, peak records Filtering: Low-pass filter, band-pass filter

Classification	Model Name	Description
Temperature measurement module	AS04RTD-A	4-channel, 2-wire/3-wire RTD Sensor type: Pt100 / Ni100 / Pt1000 / Ni1000 / JPt100 / LG-Ni1000 / Cu50 / Cu100 / 0-300Ω / 0-3000Ω input impedance Resolution: 0.1°C/0.1°F (16 bits) Conversion time: 200ms/channel
	AS06RTD-A	6-channel, 2-wire/3-wire RTD Sensor type: Pt100 / Ni100 / Pt1000 / Ni1000 / JPt100 / LG-Ni1000 / Cu50 / Cu100 / 0-300Ω / 0-3000Ω input impedance, Resolution: 0.1°C/0.1°F (16 bits) Conversion time: 200ms/channel
	AS04TC-A	4-channel thermocouple Sensor type: J, K, R, S, T, E, N, B and -100 to +100 mV Resolution: 0.1°C/0.1°F (24 bits) Conversion time: 200ms/channel
	AS08TC-A	8-channel thermocouple Sensor type: J, K, R, S, T, E, N, B and -100 to +100 mV Resolution: 0.1°C/0.1°F (24 bits) Conversion time: 200ms/channel
Load cell module	AS02LC-A	2-channel, 4-wire/6-wire load cell sensor Eigenvalues for a load cell: 1, 2, 4, 6, 20, 40, 80 mV/V Highest precision 1/10000 @ 50ms of conversion time ADC Resolution : 4 bits Conversion time: 2.5–400ms (nine options to choose from)
Positioning module	AS02PU-A	2-axis motion control, 5-24 VDC, 1 differential input (A/B/Z phase ), maximum hardware input bandwidth at 200 k Hz 24 VDC, 5 mA, 5 inputs, maximum hardware input bandwidth at 1 k Hz 5 VDC, 2-axis, 4 differential outputs, high-speed output frequency at 200 k Hz
	AS04PU-A	4-axis motion control 24 VDC, 5mA, 6 outputs, maximum hardware input bandwidth at 1 k Hz 5-30 VDC, 0.1A, 4-axis, 8 NPN outputs, maximum high-speed frequency at 100 kHz
Counter module	AS02HC-A	2-channel high-speed counters Input methods for the 2-channel are pulse-input (max. at 200 kHz) and SSI communication interface input (max. at 1.25 MHz) Incrementing / decrementing encoder input 4-point high-speed open collector output, 5-30 VDC, 0.1A, work with high speed differential output
Network module	AS00SCM-A	Serial communication module, 2x communication ports for communication cards, supporting MODBUS protocols
	AS01DNET-A	DeviceNet communication port, functioning as master or slave
	AS04SIL-A	IO-Link module, built-in with 4 IO-Link communication ports
Remote I/O module	AS00SCM-A +	For AS-FCOPM function cards



Classification	Model Name	Description
	AS-FCOPM	
	AS00SCM-A + AS-FEN02	For AS-FEN02 function cards
	AS01DNET-A (RTU)	DeviceNet remote IO slave, its right side connects with AS Series extension modules, including digital modules, analog modules, temperature modules, etc.
Function cards	AS-F232	Serial communication port, RS232, functioning as master or slave
	AS-F422	Serial communication port, RS422, functioning as master or slave
	AS-F485	Serial communication port, RS485, functioning as master or slave
	AS-FCOPM	CANopen communication port, supporting DS301, AS series remote modules and Delta servo systems
	AS-F2AD	2-channel analog input 0-10V (12 bits), 4-20mA (11 bits) Conversion time: 3ms/channel
	AS-F2DA	2-channel analog output 0-10V, 4-20mA (12 bits) Conversion time: 2ms/channel
	AS-FEN02	Only available for AS300 Series PLC CPU, 2x Ethernet ports, supporting switch function, Modbus TCP, EtherNet/IP Adapter and AS Series remote control
	AS-FPFN02	Only available for AS300 Series PLC CPU, 2x Ethernet ports, supporting switch function, PROFINET Device (Slave)
	AS-FOPC02	Only available for AS300 Series PLC CPU, 2x Ethernet ports, supporting switch function, OPC-UA Server, Modbus TCP
	AS-FFTP01	Only available for AS300 Series PLC CPU, 1x Ethernet ports, supporting FTP Server, OPC UA Server, MQTT Client, Web Server, Data log
	AS-FECAT	Only available for AS300 Series PLC CPU, 2x Ethernet ports, supporting data exchange (before EtherCAT Master enabled), MODBUS TCP Server (1 connection), EtherCAT Master 16-axes point-to-point positioning control (only available for Delta drive)
Programming cable	UC-PRG015-01A (1.5M)	Used for the connection between a PLC and a PC via a mini USB port, use for AS332T-A, AS332P-A and AS324MT-A
	UC-PRG030-01A (3M)	Use for the connection between a PLC and a PC with a mini USB port, use for AS332T-A, AS332P-A and AS324MT-A
	UC-PRG030-20A (3M)	Use for the connection between a PLC and a PC with a RJ45 port, use for AS332T-A, AS332P-A, AS324MT-A, AS-FEN02, AS-FPFN02 and AS-FECAT.
I/O extension cable	UC-ET010-24B (1M) UC-ET020-24B (2M) UC-ET030-24B (3M)	MIL connector, 40Pin ↔ 40Pin, shielded, use for AS32AM10N-A, AS32AN02T-A, AS64AM10N-A and AS64AN02T-A
	UC-ET010-24D (1M) UC-ET020-24D (2M) UC-ET030-24D (3M)	MIL connector, 40Pin ↔ 2x 20Pin, shielded, use for AS332T-A, AS332P-A, AS324MT-A, AS32AM10N-A, AS32AN02T-A, AS64AM10N-A, and AS64AN02T-A
	External	UB-10-ID16A

Classification	Model Name	Description
terminal module		A, AS324MT-A, AS32AM10N-A, AS32AN02T-A, AS64AM10N-A and AS64AN02T-A
	UB-10-ID32A	32 inputs, 40-Pin MIL connector, use for AS32AM10N-A and AS64AM10N-A
	UB-10-IO32D	Terminal block (spring clamp/MIL connector), MIL connector to 40-Pin spring clamp terminal block, use for AS332T-A, AS332P-A, AS324MT-A, AS32AM10N-A, AS32AN02T-A
	UB-10-OR16A	16 relay outputs, 20-Pin MIL connector, NPN, use for AS332T-A, AS32AN02T-A and AS64AN02T-A
	UB-10-OR16B	16 relay outputs, 20-Pin MIL connector, PNP, use for AS332P-A
	UB-10-OT32A	32 transistor outputs, 40-Pin MIL connector, NPN, use for AS32AN02T-A and AS64AN02T-A
Network cables	UC-CMC003-01A (0.3M)	CANopen communication cable, use for AS-FCOPM series
	UC-CMC005-01A (0.5M)	CANopen communication cable, use for AS-FCOPM series
	UC-CMC010-01A (1M)	CANopen communication cable, use for AS-FCOPM series
	UC-CMC015-01A (1.5M)	CANopen communication cable, use for AS-FCOPM series
	UC-CMC020-01A (2M)	CANopen communication cable, use for AS-FCOPM series
	UC-CMC030-01A (3M)	CANopen communication cable, use for AS-FCOPM series
	UC-CMC050-01A (5M)	CANopen communication cable, use for AS-FCOPM series
	UC-CMC100-01A (10M)	CANopen communication cable, use for AS-FCOPM series
	UC-CMC200-01A (20M)	CANopen communication cable, use for AS-FCOPM series
	UC-EMC003-02A (0.3M)	Ethernet communication cable, use for AS Series CPU modules, AS-FEN02, AS-FPFN02 and AS-FECAT function cards.
	UC-EMC005-02A (0.5M)	Ethernet communication cable, use for AS Series CPU modules, AS-FEN02, AS-FPFN02 and AS-FECAT function cards.
	UC-EMC010-02A (1M)	Ethernet communication cable, use for AS Series CPU modules, AS-FEN02, AS-FPFN02 and AS-FECAT function cards.
	UC-EMC020-02A (2M)	Ethernet communication cable, use for AS Series CPU modules, AS-FEN02, AS-FPFN02 and AS-FECAT function cards.
	UC-EMC050-02A (5M)	Ethernet communication cable, use for AS Series CPU modules, AS-FEN02, AS-FPFN02 and AS-FECAT function cards.
	UC-EMC100-02A (10M)	Ethernet communication cable, use for AS Series CPU modules, AS-FEN02, AS-FPFN02 and AS-FECAT function cards.
	UC-EMC200-02A (20M)	Ethernet communication cable, use for AS Series CPU modules, AS-FEN02, AS-FPFN02 and AS-FECAT function cards.

## 1.2 Software

### 1.2.1 Program Editor


The section describes the program editor ISPSOft.




- Supported the following programming languages: structure text (ST), ladder diagram (LD), sequential function chart (SFC), continuous function chart (CFC) and language C.

NOTE: CFC programming is only available in ISPSOft version 3.01 or higher.


NOTE: Language C is only available in ISPSOft version 3.08 or higher.




- User-defined variables allow you to define a variable to replace a PLC device name. This enhances the readability of the program, and saves time when addressing the device.



- The Program Organization Unit (POU) framework divides the main program into several program units, and also replaces the traditional subroutines with functions and function blocks. This makes the framework of the program modular and easier to manage.



- Tasks manage the execution order of the programs. Tasks help you manage large-scale program development.



## 1.2.2 Program Organization Units and Tasks

1

The Program Organization Units (POUs) are the basic elements that constitute the PLC program. Unlike the traditional PLC program, the program framework introduced by IEC 61131-3 allows you to divide a large program into several small units. These small units are called POUs. The POUs can be classified into three types.

1. Program (PROG): The program POU is the main program in the PLC. You can define the execution of this POU to be cyclic scan or interrupt driven, and arrange the scan order in the task list for program POUs.
2. Function block (FB): The function block (FB) POU is similar to a subroutine. The instructions in the function block are executed after a program POU calls the function block with the related parameters.
3. Function (FC): The function (FC) POU is similar to a macro instruction. That is, you can write many operation instructions or functions into a function-type POU, and then use them in a program POU or a function block POU.

Tasks are functions that control the order of program execution or according to certain interrupt conditions. The task provides each program POU with a specific execution task, and specifies the execution order for the program POUs or the way to enable them.

Normally, only some of the program POUs in a project take part in the actual execution. The task controls whether to execute the program POU or not, and how to execute it. If the POU of the program type is not assigned in the task, the program POU is saved as ordinary source code with the project instead of being compiled into the execution code for the PLC. In addition, only the program POU needs to be assigned to the task. Function block POUs or function POUs are automatically called by the program POU. There are three types of tasks.

1. Cyclic task: The program POUs assigned to cyclic tasks are scanned cyclically, and executed in order.
2. Timed interrupt task: If the interrupt time is reached, all program POUs assigned to the timed interrupt task are executed in order.
3. Conditional interrupt task: Conditional Interrupts can be divided into several types, such as external interrupts, and I/O interrupts. You must make sure that the PLC supports the interrupts before you use conditional interrupts in a project. If you assign a program POU to a conditional interrupt task, the program POU is similar to an interrupt subroutine. When the interrupt condition is satisfied (for example, the contact of the external interrupt is triggered) then all program POUs assigned to the conditional interrupt task are executed in order.

---

## Chapter 2 Devices

### Table of Contents

<b>2.1 Introduction to Devices .....</b>	<b>2-2</b>
2.1.1 Device Table .....	2-2
2.1.2 Basic Structure of I/O Storage .....	2-3
2.1.3 Relation Between the PLC Action and the Device Type .....	2-3
2.1.4 Latched Areas in the Device Range .....	2-4
<b>2.2. Device Functions .....</b>	<b>2-5</b>
2.2.1 Values and Constants .....	2-5
2.2.2 Floating-point Numbers .....	2-7
2.2.3 Strings .....	2-8
2.2.4 Input Relays (X) .....	2-9
2.2.5 Output Relays (Y) .....	2-10
2.2.6 Auxiliary Relays (M) .....	2-10
2.2.7 Special Auxiliary Relays (SM) .....	2-11
2.2.8 Refresh Time for Special Auxiliary Relays .....	2-71
2.2.9 Relays (S) .....	2-79
2.2.10 Timers (T) .....	2-79
2.2.11 Counters .....	2-81
2.2.12 32-bit Counters (HC) .....	2-83
2.2.13 Data Registers (D) .....	2-85
2.2.14 Special Data Registers (SR) .....	2-86
2.2.15 Special Data Registers Refresh Conditions .....	2-133
2.2.16 Additional Remarks on Special Auxiliary Relays and Special Data Registers .....	2-137
2.2.17 Index Registers (E) .....	2-171
2.2.18 File Registers (FR) .....	2-171

## 2.1 Introduction to Devices

This section describes the values and strings processed by the PLC. It also describes the functions of devices, including input, output and auxiliary relays, as well as timers, counters, and data registers. The PLC simulates external devices in the PLC's internal memory, so the word "device" is a generic name that refers to all the internal memory locations in the PLC. A device can be a bit device or a word device. Bit devices simulate coils, contacts and flags, while word devices simulate registers.

### 2.1.1 Device Table

Type	Device name		Number of devices	Range
Bit device	Input relay	X	1024	X0.0–X63.15
	Output relay	Y	1024	Y0.0–Y63.15
	Data register	D	48,0000	D0.0–D29999.15
		W	48,0000	W0.0–W29999.15 *4
	Auxiliary relay	M	8192	M0–M8191
	Special auxiliary relay	SM	2048	SM0–SM4095
	Relay	S	2048	S0–S2047
	Timer	T	512	T0–T511
	Counter	C	512	C0–C511
32-bit counter	HC	256	HC0–HC255	
Word device	Input relay	X	64	X0–X63
	Output relay	Y	64	Y0–Y63
	Data register	D	30000	D0–D29999
		W	30000	W0–W29999 *4
	Special auxiliary relay	SR	2048	SR0–SR2047
	File register	FR	65536	FR0–FR65535
	Timer	T	512	T0–T511
	Counter	C	512	C0–C511
	32-bit counter	HC	256(512 words)	HC0–HC255
Index register	E	10	E0–E9	
		5	E10–E14 *4	
Constant*1	Decimal system	K	16 bits: -32768 to 32767	
			32 bits: -2147483648 to 2147483647	
Constant*2	Hexadecimal system	16#	16 bits: 16#0–16#FFFF	
			32 bits: 16#0–16#FFFFFFFF	
Constant*2	Single-precision floating-point number	F	32 bits: ±1.17549435 <sup>-38</sup> to ±3.40282347 <sup>+38</sup>	
String*3	String	"\$"	1–31 characters	

\*1: Constants are indicated by K in the device lists in Chapter 5 and Chapter 6 in the AS Series Programming Manual. For example, when "K50" appears in the AS programming manual, enter only the number 50 in ISPSOft.

\*2: Floating-point numbers are indicated by F/DF in the device lists in Chapter 5 and Chapter 6 in the AS Series Programming Manual, but they are represented by decimal points in ISPSOft. For example, for the floating-point number F500, enter 500.0 in ISPSOft.

\*3: Strings are indicated by \$ in Chapter 5 and Chapter 6 in the AS Series Programming Manual, but they are represented by quotes (" ") in ISPSOft. For example, for the string of 1234, enter "1234" in ISPSOft.

\*4: Used for editing in ISPSOft only.

## 2.1.2 Basic Structure of I/O Storage

Device	Function	Access by bits	Access by words	Modify by ISPSOft	Force the bit ON/OFF
X	Input relay	OK	OK	OK	OK
Y	Output relay	OK	OK	OK	OK
M	Auxiliary relay	OK	-	OK	-
SM	Special auxiliary relay	OK	-	OK	-
S	Relay	OK	-	OK	-
T	Timer	OK	OK	OK	-
C	Counter	OK	OK	OK	-
HC	32-bit counter	OK	OK	OK	-
D	Data register	OK	OK	OK	OK
SR	Special data register	-	OK	OK	-
FR	File register	-	OK*1	-	-
E	Index register	-	OK	OK	-

\*1: Use an instruction for writing to an FR.

## 2.1.3 Relation Between the PLC Action and the Device Type

PLC action		Device type		Non-latched area		Latched area	
		Device Y	Other devices	File register	Other devices		
Power: OFF→ON		Cleared	Cleared	Retained	Retained	Retained	Retained
Restore to defaults		Cleared	Cleared	Cleared	Cleared	Cleared	Cleared
STOP ↓ RUN*1	The non-latched area is cleared.	Cleared	Cleared	Retained	Retained	Retained	Retained
	The state of the non-latched area is retained.	Retained	Retained	Retained	Retained	Retained	Retained
RUN ↓ STOP*1	The state of device Y is cleared.	SM203 is OFF. (The state of other devices are retained.)	Cleared	Retained	Retained	Retained	Retained
	The state of device Y is retained.	SM203 is OFF. (The state of other devices are retained.)	Retained	Retained	Retained	Retained	Retained
	The state of device Y is cleared.	SM203 is ON. *3 (The state of other devices are cleared.)	Cleared	Cleared	Retained	Retained	Retained
	The state of device Y is retained.	SM203 is ON. (The state of other devices are cleared.)	Retained	Cleared	Retained	Retained	Retained
SM204 is ON.*2		Cleared	Cleared	Retained	Retained	Retained	Retained

PLC action	Device type	Non-latched area		Latched area	
		Device Y	Other devices	File register	Other devices
<b>(All non-latched areas are cleared.)</b>					
<b>SM205 is ON.*2</b> <b>(All latched areas are cleared.)</b>					
		Retained	Retained	Retained	Cleared

\*1: For more on setting the states, see HWCONFIG in ISPSOft. The default for PLC STOP->RUN is “clear not-latched area”. The default for PLC RUN->STOP is “clear the state of device Y”.

\*2: PLC clears the areas when SM switches from OFF to ON. After clearing the areas, PLC switches the SM back to OFF.

\*3: When SM203 is ON, it clears the non-latched area once when PLC RUN->STOP. This function should work with AS PLC CPU with FW V1.08.30 or later.

## 2.1.4 Latched Areas in the Device Range


Device	Function	Device range	Latched area
<b>X</b>	Input relay	X0–X63	All devices are non-latched.
<b>Y</b>	Output relay	Y0–Y63	All devices are non-latched.
<b>M*1</b>	Auxiliary relay	M0–M8191	The default range is M6000–M8191.
<b>SM</b>	Special auxiliary relay	SM0–SM2047	Some devices are latched, and cannot be changed. Refer to the list of special auxiliary relays for more information.
<b>S*1</b>	Relay	S0–S1023	The default range is S512–S1023
<b>T</b>	Timer	T0–T511	All devices are non-latched.
<b>C*1</b>	Counter	C0–C511	The default range is C448–C511
<b>HC*1</b>	32-bit counter	HC0–HC255	The default range is HC128–HC255
<b>D*1</b>	Data register	D0–D29999	The default range is D20000–D23999
		W0–W29999	*2
<b>FR</b>	File register	FR0–FR65535	All devices are latched.
<b>SR</b>	Special data register	SR0–SR2047	Some are latched, and cannot be changed. Refer to the list of special data registers for more information.
<b>E</b>	Index register	E0–E9	All devices are non-latched.
		E10–E14	*2

\*1: For more information on setting the latched area, see HWCONFIG in ISPSOft. Setting the latched area means the other areas are seen as non-latched areas. The range of latched areas cannot exceed the device range. For example, setting M600–M7000 as latched areas makes M0–M5999 and M7001–M8191 non-latched areas.

\*2: Used for editing in ISPSOft only.

## 2.2. Device Functions

The following flow chart shows the procedure for processing a program in the PLC.



- Regenerating the input signal
  1. Before the program is executed, the state of the external input signal is read into the memory location for the input signal.
  2. When program is executed, the state in the memory location for the input signal does not change even if the input signal changes from ON to OFF or from OFF to ON. The input signal is not refreshed until the next scan begins.
- Processing the program
 


After the input signal is refreshed, the instructions in the program are executed in order from the start address of the program. The results are stored in the device memory.
- Regenerating the state of the output
 

After the instruction END is executed, the state in the device memory is sent to the specified output terminal.

### 2.2.1 Values and Constants

Name	Description
Bit	A bit is the basic unit in the binary system. Its state is either 1 or 0.
Nibble	A nibble is composed of four consecutive bits (for example b3–b0). Nibbles can represent 0–9 in the decimal system, or 0–F in the hexadecimal system.
Byte	A byte is composed of two consecutive nibbles ( 8 bits, b7–b0). Bytes can represent 00–FF in the hexadecimal system.
Word	A word is composed of two consecutive bytes (16 bits, b15–b0). Words can represent 0000–FFFF in the hexadecimal system.
Double word	A double word is composed of two consecutive words (i.e. 32 bits, b31–b0). Double words represent 00000000–FFFFFFFF in the hexadecimal system.

The relation among bits, nibbles, bytes, words, and double words in the binary system is shown in the picture below.



The PLC uses four types of values to execute the operation according to different control purposes.

1. Binary number (BIN)

The PLC uses the binary system to operate on the values.

2. Decimal number (DEC)

The PLC uses decimal numbers for:

- The setting value of a timer (T) or the setting value of a counter (C/HC); for example, TMR C0 50 (**constant K**).
- The device number; for example, M10 and T30 (device number)
- The number before or after the decimal point; for example, X0.0, Y0.11, and D10.0 (device number).
- **The constant K**, used as the operand in an applied instruction. For example, MOV 123 D0 (**constant K**).

3. Binary-coded decimal (BCD)

A decimal value that is represented by a nibble or four bits so that sixteen consecutive bits represent a four-digit decimal value.

4. Hexadecimal number (HEX)

The PLC uses hexadecimal numbers for:

- **The constant 16#**, used as the operand in an applied instruction; for example, MOV 16#1A2B D0 (hexadecimal constant).

The following table shows the corresponding values.


Binary Number (BIN)	Decimal Number (DEC)	Binary Code Decimal (BCD)	Hexadecimal Number (HEX)
PLC internal execution	Constant K, Device number	BCD related instruction	Constant 16#, Device number
0000	0	0000	0
0001	1	0001	1
0010	2	0010	2
0011	3	0011	3
0100	4	0100	4
0101	5	0101	5
0110	6	0110	6
0111	7	0111	7
1000	8	1000	8
1001	9	1001	9
1010	10	-	A
1011	11	-	B
1100	12	-	C
1101	13	-	D
1110	14	-	E
1111	15	-	F
10000	16	0001 0000	10
10001	17	0001 0001	11

## 2.2.2 Floating-point Numbers

Floating-point numbers are represented by decimal points in ISPSoft. For example, the floating-point number 500 is represented as 500.0.

### 2.2.2.1 Single-precision Floating-point Numbers


Floating-point numbers are represented by a 32-bit register. The representation adopts the IEEE754 standard, and the format shown in the following picture.



Equation:  $(-1)^S \times 2^{E-B} \times 1.M; B = 127$

The single-precision floating-point numbers range between  $\pm 2^{-126}$  to  $\pm 2^{+128}$ , and correspond to the range between  $\pm 1.1755 \times 10^{-38}$  to  $\pm 3.4028 \times 10^{+38}$ .

The AS Series PLC uses two consecutive registers for a 32-bit floating-point number. Take (D1, D0) for example.



#### Example 1:

**23 is represented by a single-precision floating-point number.**

Step 1: Convert 23 into the binary number, 23.0=10111.

Step 2: Normalize the binary number, 10111=1.0111 x24 (0111 is the mantissa, and 4 is the exponent.).

Step 3: Get the value of the exponent.

$$\because E-B=4 \rightarrow E-127=4 \therefore E=131=100000112$$

Step 4: Combine the sign bit, the exponent, and the mantissa to form the floating-point number.

$$0\ 10000011\ 011100000000000000000000_2=41B80000_{16}$$

**Example 2:**

**-23 is represented by a single-precision floating-point number.**

Converting -23.0 into the floating-point number uses the same steps as converting 23.0 into the floating-point number, except that the sign bit is 1.

1 10000011 011100000000000000000000<sub>2</sub>=C1B80000<sub>16</sub>

2

**2.2.2.2 Decimal Floating-point Numbers**

- Single-precision floating-point numbers and double-precision floating-point numbers can be converted into decimal floating-point numbers so people can read them. However, internally the PLC uses single-precision floating-point numbers and double-precision floating-point numbers.
- A 32-bit decimal floating-point number is represented by two consecutive registers. The constant is stored in the first register whose number is smaller while the exponent is stored in the register whose number is bigger. Take (D1, D0) for example.

$$\text{Decimal floating-point number} = [\text{Constant } D0] * 10^{[\text{Exponent } D1]}$$

Base number D0=±1,000 to ±9,999


Exponent D1=-41 to +35

The base number 100 does not exist in D0 because 100 is represented by 1,000×10<sup>-1</sup>. 32-bit decimal floating-point numbers range between ±1175×10<sup>-41</sup> to ±402×10<sup>+35</sup>.

**2.2.3 Strings**


The PLC can process strings composed of ASCII codes (\*1). A complete string begins with a start character, and ends with an ending character (NULL code). Strings can have maximum length of 31 characters, and ISPSOft automatically adds the ending character (16#00).

1. No string (NULL code) is moved.




D0=0 (NULL)

2. The string has an even number of characters.



D0	16#62 (b)	16#61 (a)
D1	16#64 (d)	16#63 (b)
D2	0 (NULL)	

3. The string has an odd number of characters.



D0	16#62 (b)	16#61 (a)
D1	16#64 (d)	16#63 (b)
D2	0 (NULL)	16#65 (e)

\*1: ASCII code chart

Hex	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F
ASCII	☒	☒	☒	☒	☒	☒	☒	☒	☒	☒	☒	☒	☒	☒	☒	☒
Hex	10	11	12	13	14	15	16	17	18	19	1A	1B	1C	1D	1E	1F
ASCII	☒	☒	☒	☒	☒	☒	☒	☒	☒	☒	☒	☒	☒	☒	☒	☒
Hex	20	21	22	23	24	25	26	27	28	29	2A	2B	2C	2D	2E	2F
ASCII	SP	!	"	#	\$	%	&	'	(	)	*	+	,	-	.	/
Hex	30	31	32	33	34	35	36	37	38	39	3A	3B	3C	3D	3E	3F
ASCII	0	1	2	3	4	5	6	7	8	9	:	;	<	=	>	?
Hex	40	41	42	43	44	45	46	47	48	49	4A	4B	4C	4D	4E	4F
ASCII	@	A	B	C	D	E	F	G	H	I	J	K	L	M	N	O
Hex	50	51	52	53	54	55	56	57	58	59	5A	5B	5C	5D	5E	5F
ASCII	P	Q	R	S	T	U	V	W	X	Y	Z	☒	☒	☒	☒	☒
Hex	60	61	62	63	64	65	66	67	68	69	6A	6B	6C	6D	6E	6F
ASCII	`	a	b	c	d	e	f	g	h	i	j	k	l	M	n	o
Hex	70	71	72	73	74	75	76	77	78	79	7A	7B	7C	7D	7E	7F
ASCII	p	q	r	s	t	u	v	w	x	y	z	{		}	-	☒

Note: ☒ represents an invisible character. Do not use it in strings.

### 2.2.4 Input Relays (X)

- Input function

The input is connected to the input device (external devices such as button switches, rotary switches, and number switches), and the PLC reads the input signal. You can use input contact A or contact B several times in the program, and the ON/OFF state of the input varies with the ON/OFF state of the input device.

- Input number (the decimal number)

For the PLC, the input numbers start from X0.0. The number of inputs varies with the number of inputs on the digital input/output modules. The inputs are numbered according to the order in which the digital input/output modules are connected to the CPU module. The maximum number of inputs for the PLC is 8192, and the input number range is between X0.0 to X511.15.

- Input type

Inputs are classified into two types.

1. Regenerated inputs: The PLC reads the state of a regenerated input before the program is executed; for example, LD X0.0.
2. Direct input: The state of a direct input is read by the PLC during the execution of the instructions; for example, LD DX0.0.

## 2.2.5 Output Relays (Y)

- Output function

The output sends the ON/OFF signal to drive the load connected to the output, such as an external signal lamp, a digital display, or an electromagnetic valve. There are four types of outputs. They are relays, transistors (NPN and PNP), and TRIACs (thyristors). You can use the output contact A or contact B several times in the program. Use output Y only once in the program; otherwise, according to the PLC's program-scanning function, the state of the output depends on the circuit connected to the last output Y in the program.

- Output number (the decimal number)

For the PLC, the output numbers start from Y0.0. The number of outputs varies with the number of outputs on the digital input/output modules. The outputs are numbered according to the order in which the digital input/output modules are connected to the PLC. The maximum number of outputs on the PLC is 1024, and the range is between Y0.0 and Y63.15.

An output that is not used as an output device can be used as a general device.

- Output types

Outputs are classified into two types.

1. Regenerated output: The state of a regenerated output is not written until the program executes the END instruction, according to the states of the outputs; for example, OUT Y0.0.
2. Direct output: The state of a direct output is written by the PLC during the execution of the instructions, according to the states of the outputs; for example, OUT DY0.0.

## 2.2.6 Auxiliary Relays (M)

The auxiliary relay has contact A and contact B. It can be used several times in the program. You can combine the control loops by using the auxiliary relay, but you cannot drive the external load using the auxiliary relay. You can use the auxiliary relays in either of the following two ways.

1. For general use: In general use, if an electric power failure occurs when the PLC is running, the auxiliary relay resets to the OFF state. When the power is restored, the auxiliary relay remains in the OFF state.
2. For latched use: In latched use, if an electric power failure occurs when the PLC is running, the state of the auxiliary relay is retained. When the power is restored, the relay state remains the same as before the power failure.

## 2.2.7 Special Auxiliary Relays (SM)

Every special auxiliary relay has its specific function. Do not use the special auxiliary relays which are not defined.

The special auxiliary relays and their functions are listed as follows. As to the SM numbers marked “\*”, users can refer to the additional remarks on special auxiliary relays/special data registers. “R” in the attribute column indicates that the special auxiliary relay can read the data, whereas “R/W” in the attribute column indicates that it can read and write the data. In addition, the mark “–” indicates that the status of the special auxiliary relay does not make any change. The mark “#” indicates that the system will be set according to the status of the PLC, and users can read the setting value and refer to the related manual for more information.

SM	Function			OFF ↓ ON	STOP ↓ RUN	RUN ↓ STOP	Latched	Attribute	Default
		AS300 Series	AS100/200 Series						
SM0	Error: the operation or operand exceeds the allowed range	○	○	OFF	OFF	–	N	R	OFF
SM1	Error: the operation or operand exceeds the allowed range is locked.	○	○	OFF	OFF	–	N	R	OFF
SM5	Instruction inspection error	○	○	OFF	OFF	–	N	R	OFF
SM6	Data lost in the latched area	○	○	OFF	–	–	N	R/W	OFF
SM7	Insufficient power supply (24 V)	○	○	OFF	–	–	N	R	OFF
*SM8	Watchdog timer error	○	○	OFF	–	–	N	R	OFF
SM9	System error	○	○	OFF	–	–	N	R	OFF
SM10	I/O bus error	○	○	OFF	–	–	N	R	OFF
*SM22	Clearing the error log	○	○	OFF	OFF	OFF	N	R/W	OFF
SM23	Clearing the download log	○	○	OFF	OFF	OFF	N	R/W	OFF
SM24	Clearing the state-changing log of the PLC	○	○	OFF	OFF	OFF	N	R/W	OFF
SM25	The online-editing processing flag is on when the online-editing mode starts.	○	○	OFF	–	–	N	R	OFF
SM26	The debugging mode processing flag is on when the debugging mode starts.	○	○	OFF	–	–	N	R	OFF
SM27	AS-F2AD: flags for built-in AD errors	○	○	OFF	–	–	N	R	OFF
SM28	Error: the output point is the same as the output that the high speed instruction used	○	○	OFF	OFF	OFF	N	R/W	OFF
SM29	During the execution of CSFO instruction, either when the output frequency exceeding the limit or when there is no input but an error shows output is underway.	○	○	OFF	OFF	–	N	R/W	OFF
SM30	Error occurs in the remote module	○	○	OFF	–	–	N	R	OFF
SM34	Incorrect password	○	○	OFF	–	–	N	R/W	OFF
*SM36	Enable saving data to the memory card. When ON, the PLC runs according to the value in SR36.	○	○	OFF	–	–	N	R/W	OFF
SM38	Error flag for AS-FEN02, FPFN02, FOPC02, and FFTP01.	○	○	OFF	–	–	N	R/W	OFF
SM76	The data is sent through Function Card 1.	○	–	OFF	OFF	–	N	R/W	OFF
SM77	The data is sent through Function Card 2.	○	–	OFF	OFF	–	N	R/W	OFF
SM78	Waiting to receive the reply through Function Card 1	○	–	OFF	OFF	–	N	R	OFF

SM	Function			OFF ↓ ON	STOP ↓ RUN	RUN ↓ STOP	Latched	Attribute	Default
		AS300 Series	AS100/200 Series						
SM79	Waiting to receive the reply through Function Card 2	○	-	OFF	OFF	-	N	R	OFF
SM80	Reception through Function Card 1 is complete.	○	-	OFF	OFF	-	N	R/W	OFF
SM81	Reception through Function Card 2 is complete.	○	-	OFF	OFF	-	N	R/W	OFF
SM82	Error occurs during receiving data through Function Card 1 when using the MODRW instruction or the RS instruction.	○	-	OFF	OFF	-	N	R	OFF
SM83	Error occurs during receiving data through Function Card 2 when using the MODRW instruction or the RS instruction.	○	-	OFF	OFF	-	N	R	OFF
SM84	No data received through Function Card 1 after a specified period of time.	○	-	OFF	OFF	-	N	R/W	OFF
SM85	No data received through Function Card 2 after a specified period of time.	○	-	OFF	OFF	-	N	R/W	OFF
SM86	Choice made by Function Card 1 between the 8-bit processing mode and the 16-bit processing mode ON: 8-bit processing mode OFF: 16-bit processing mode	○	-	OFF	-	-	N	R/W	OFF
SM87	Choice made by Function Card 2 between the 8-bit processing mode and the 16-bit processing mode ON: 8-bit processing mode OFF: 16-bit processing mode	○	-	OFF	-	-	N	R/W	OFF
SM90	The communication protocol of Function Card 1 changes	○	-	OFF	-	-	N	R/W	OFF
SM91	The communication protocol of Function Card 2 changes	○	-	OFF	-	-	N	R/W	OFF
SM94	Change in the LED lighting control in COM1	○	○	-	-	-	H	R/W	OFF
SM95	Change in the LED lighting control in COM2	○	○	-	-	-	H	R/W	OFF
*SM96	Data is sent through COM1.	○	○	OFF	OFF	-	N	R/W	OFF
*SM97	Data is sent through COM2.	○	○	OFF	OFF	-	N	R/W	OFF
*SM98	Waiting to receive the reply through COM1	○	○	OFF	OFF	-	N	R	OFF
*SM99	Waiting to receive the reply through COM2	○	○	OFF	OFF	-	N	R	OFF
*SM100	Reception through COM1 is complete.	○	○	OFF	OFF	-	N	R/W	OFF
*SM101	Reception through COM2 is complete.	○	○	OFF	OFF	-	N	R/W	OFF
*SM102	Error occurs during receiving data through COM1 when using the MODRW instruction or the RS instruction.	○	○	OFF	OFF	-	N	R/W	OFF
*SM103	Error occurs during receiving data through COM2 when using the MODRW instruction or the RS instruction.	○	○	OFF	OFF	-	N	R/W	OFF
*SM104	No data received through COM1 after a specified period of time.	○	○	OFF	OFF	-	N	R/W	OFF
*SM105	No data received through COM2 after a specified period of time.	○	○	OFF	OFF	-	N	R/W	OFF

SM	Function	AS100/200 Series		OFF ↓ ON	STOP ↓ RUN	RUN ↓ STOP	Latched	Attribute	Default
		AS300 Series	AS100/200 Series						
*SM106	Choice made by COM1 between the 8-bit processing mode and the 16-bit processing mode ON: 8-bit processing mode OFF: 16-bit processing mode	○	○	OFF	–	–	N	R/W	OFF
*SM107	Choice made by COM2 between the 8-bit processing mode and the 16-bit processing mode ON: 8-bit processing mode OFF: 16-bit processing mode	○	○	OFF	–	–	N	R/W	OFF
*SM120	I200 high-speed comparison interrupt for DPLSY to temporarily store output parameters	○	○	OFF	OFF	–	N	R/W	OFF
*SM121	I201 high-speed comparison interrupt for DPLSY to temporarily store output parameters	○	○	OFF	OFF	–	N	R/W	OFF
*SM122	I202 high-speed comparison interrupt for DPLSY to temporarily store output parameters	○	○	OFF	OFF	–	N	R/W	OFF
*SM123	I203 high-speed comparison interrupt for DPLSY to temporarily store output parameters	○	○	OFF	OFF	–	N	R/W	OFF
*SM124	I210 high-speed comparison interrupt for DPLSY to temporarily store output parameters	○	○	OFF	OFF	–	N	R/W	OFF
*SM125	I211 high-speed comparison interrupt for DPLSY to temporarily store output parameters	○	○	OFF	OFF	–	N	R/W	OFF
*SM126	I212 high-speed comparison interrupt for DPLSY to temporarily store output parameters	○	○	OFF	OFF	–	N	R/W	OFF
*SM127	I213 high-speed comparison interrupt for DPLSY to temporarily store output parameters	○	○	OFF	OFF	–	N	R/W	OFF
*SM128	I220 high-speed comparison interrupt for DPLSY to temporarily store output parameters	○	○	OFF	OFF	–	N	R/W	OFF
*SM129	I221 high-speed comparison interrupt for DPLSY to temporarily store output parameters	○	○	OFF	OFF	–	N	R/W	OFF
*SM130	I222 high-speed comparison interrupt for DPLSY to temporarily store output parameters	○	○	OFF	OFF	–	N	R/W	OFF
*SM131	I223 high-speed comparison interrupt for DPLSY to temporarily store output parameters	○	○	OFF	OFF	–	N	R/W	OFF
*SM132	I230 high-speed comparison interrupt for DPLSY to temporarily store output parameters	○	○	OFF	OFF	–	N	R/W	OFF
*SM133	I231 high-speed comparison interrupt for DPLSY to temporarily store output parameters	○	○	OFF	OFF	–	N	R/W	OFF
*SM134	I232 high-speed comparison interrupt for DPLSY to temporarily store output parameters	○	○	OFF	OFF	–	N	R/W	OFF
*SM135	I233 high-speed comparison interrupt for DPLSY to temporarily store output parameters	○	○	OFF	OFF	–	N	R/W	OFF
*SM136	I240 high-speed comparison interrupt for DPLSY to temporarily store output parameters	○	○	OFF	OFF	–	N	R/W	OFF
*SM137	I241 high-speed comparison interrupt for DPLSY to temporarily store output parameters	○	○	OFF	OFF	–	N	R/W	OFF

SM	Function			OFF ↓ ON	STOP ↓ RUN	RUN ↓ STOP	Latched	Attribute	Default
		AS300 Series	AS100/200 Series						
*SM138	I242 high-speed comparison interrupt for DPLSY to temporarily store output parameters	○	○	OFF	OFF	–	N	R/W	OFF
*SM139	I243 high-speed comparison interrupt for DPLSY to temporarily store output parameters	○	○	OFF	OFF	–	N	R/W	OFF
*SM140	I250 high-speed comparison interrupt for DPLSY to temporarily store output parameters	○	○	OFF	OFF	–	N	R/W	OFF
*SM141	I251 high-speed comparison interrupt for DPLSY to temporarily store output parameters	○	○	OFF	OFF	–	N	R/W	OFF
*SM142	I252 high-speed comparison interrupt for DPLSY to temporarily store output parameters	○	○	OFF	OFF	–	N	R/W	OFF
*SM143	I253 high-speed comparison interrupt for DPLSY to temporarily store output parameters	○	○	OFF	OFF	–	N	R/W	OFF
*SM144	I260 high-speed comparison interrupt for DPLSY to temporarily store output parameters	○	○	OFF	OFF	–	N	R/W	OFF
*SM145	I261 high-speed comparison interrupt for DPLSY to temporarily store output parameters	○	○	OFF	OFF	–	N	R/W	OFF
*SM146	I262 high-speed comparison interrupt for DPLSY to temporarily store output parameters	○	○	OFF	OFF	–	N	R/W	OFF
*SM147	I263 high-speed comparison interrupt for DPLSY to temporarily store output parameters	○	○	OFF	OFF	–	N	R/W	OFF
*SM148	I264 high-speed comparison interrupt for DPLSY to temporarily store output parameters	○	○	OFF	OFF	–	N	R/W	OFF
*SM149	I265 high-speed comparison interrupt for DPLSY to temporarily store output parameters	○	○	OFF	OFF	–	N	R/W	OFF
*SM150	I266 high-speed comparison interrupt for DPLSY to temporarily store output parameters	○	○	OFF	OFF	–	N	R/W	OFF
*SM151	I267 high-speed comparison interrupt for DPLSY to temporarily store output parameters	○	○	OFF	OFF	–	N	R/W	OFF
SM166	VR0 started (works with SR166)	○	○	OFF	–	–	N	R/W	OFF
SM167	VR1 started (works with SR167)	○	○	OFF	–	–	N	R/W	OFF
SM168	The connection for Function Card 1 established.	○	–	–	–	–	N	R	OFF
SM169	Function Card 1 is in operation.	○	–	OFF	–	–	N	R	OFF
SM170	The connection for Function Card 2 established.	○	–	–	–	–	N	R	OFF
SM171	Function Card 12 is in operation.	○	–	OFF	–	–	N	R	OFF
SM172	AS-FFTP01 function card is ready.	○	–	OFF	–	–	N	R	OFF
*SM203	When PLC RUN->STOP, it clears the non-latched area once.	○	○	OFF	–	–	N	R/W	OFF
*SM204	All non-latched areas are cleared.	○	○	OFF	OFF	OFF	N	R/W	OFF
*SM205	All latched areas are cleared.	○	○	OFF	OFF	OFF	N	R/W	OFF
SM206	All output is inhibited	○	○	OFF	–	–	N	R/W	OFF
*SM209	The communication protocol of COM1 changes	○	○	OFF	OFF	OFF	N	R/W	OFF
*SM210	Choice made by COM1 between the ASCII mode and the RTU mode	○	○	–	–	–	H	R/W	OFF

SM	Function			OFF ↓ ON	STOP ↓ RUN	RUN ↓ STOP	Latched	Attribute	Default
		AS300 Series	AS100/200 Series						
	ON: RTU mode OFF: ASCII mode								
*SM211	The communication protocol of COM1 changes	○	○	OFF	OFF	OFF	N	R/W	OFF
*SM212	Choice made by COM2 between the ASCII mode and the RTU mode ON: RTU mode OFF: ASCII mode	○	○	–	–	–	H	R/W	OFF
SM215	Running state of the PLC	○	○	OFF	ON	OFF	N	R/W	OFF
SM217	No response from RTC	○	○	OFF	–	–	N	R	OFF
SM218	Error: real-time clock malfunction	○	○	OFF	–	–	N	R	OFF
SM219	Error: battery power for the real-time clock is low	○	○	OFF	–	–	N	R	OFF
*SM220	Calibrating the real-time clock within ±30 seconds	○	○	OFF	OFF	–	N	R/W	OFF
SM221	Enable daylight saving time (D.S.T.)	○	○	–	–	–	H	R	OFF
SM222	Calibrate system clock using NTP (ON: successful calibration ; OFF: unsuccessful calibration or no calibration)	○	○	OFF	–	–	N	R	OFF
*SM230	When selecting “Manual + Flags” in “I/O allocation setting when Power On”, use this flag to activate the 1 <sup>st</sup> module on the right-side of the CPU module.	○	○	–	–	–	Y	R/W	OFF
*SM231	When selecting “Manual + Flags” in “I/O allocation setting when Power On”, use this flag to activate the 2 <sup>nd</sup> module on the right-side of the CPU module.	○	○	–	–	–	Y	R/W	OFF
*SM232	When selecting “Manual + Flags” in “I/O allocation setting when Power On”, use this flag to activate the 3 <sup>rd</sup> module on the right-side of the CPU module.	○	○	–	–	–	Y	R/W	OFF
*SM233	When selecting “Manual + Flags” in “I/O allocation setting when Power On”, use this flag to activate the 4 <sup>th</sup> module on the right-side of the CPU module.	○	○	–	–	–	Y	R/W	OFF
*SM234	When selecting “Manual + Flags” in “I/O allocation setting when Power On”, use this flag to activate the 5 <sup>th</sup> module on the right-side of the CPU module.	○	○	–	–	–	Y	R/W	OFF
*SM235	When selecting “Manual + Flags” in “I/O allocation setting when Power On”, use this flag to activate the 6 <sup>th</sup> module on the right-side of the CPU module.	○	○	–	–	–	Y	R/W	OFF
*SM236	When selecting “Manual + Flags” in “I/O allocation setting when Power On”, use this flag to activate the 7 <sup>th</sup> module on the right-side of the CPU module.	○	○	–	–	–	Y	R/W	OFF
*SM237	When selecting “Manual + Flags” in “I/O allocation setting when Power On”, use this flag to activate the 8 <sup>th</sup> module on the right-side of the CPU module.	○	○	–	–	–	Y	R/W	OFF
*SM238	When selecting “Manual + Flags” in “I/O allocation setting when Power On”, use this flag to activate the 9 <sup>th</sup> module on the right-side of the CPU module.	○	○	–	–	–	Y	R/W	OFF
*SM239	When selecting “Manual + Flags” in “I/O allocation setting when Power On”, use this flag to activate the 10 <sup>th</sup> module on the right-side of the CPU module.	○	○	–	–	–	Y	R/W	OFF

SM	Function	AS100/200 Series		OFF ↓ ON	STOP ↓ RUN	RUN ↓ STOP	Latched	Attribute	Default
		AS300 Series							
*SM240	When selecting "Manual + Flags" in "I/O allocation setting when Power On", use this flag to activate the 11 <sup>th</sup> module on the right-side of the CPU module.	○	○	—	—	—	Y	R/W	OFF
*SM241	When selecting "Manual + Flags" in "I/O allocation setting when Power On", use this flag to activate the 12 <sup>th</sup> module on the right-side of the CPU module.	○	○	—	—	—	Y	R/W	OFF
*SM242	When selecting "Manual + Flags" in "I/O allocation setting when Power On", use this flag to activate the 13 <sup>th</sup> module on the right-side of the CPU module.	○	○	—	—	—	Y	R/W	OFF
*SM243	When selecting "Manual + Flags" in "I/O allocation setting when Power On", use this flag to activate the 14 <sup>th</sup> module on the right-side of the CPU module.	○	○	—	—	—	Y	R/W	OFF
*SM244	When selecting "Manual + Flags" in "I/O allocation setting when Power On", use this flag to activate the 15 <sup>th</sup> module on the right-side of the CPU module.	○	○	—	—	—	Y	R/W	OFF
*SM245	When selecting "Manual + Flags" in "I/O allocation setting when Power On", use this flag to activate the 16 <sup>th</sup> module on the right-side of the CPU module.	○	○	—	—	—	Y	R/W	OFF
*SM246	When selecting "Manual + Flags" in "I/O allocation setting when Power On", use this flag to activate the 17 <sup>th</sup> module on the right-side of the CPU module.	○	○	—	—	—	Y	R/W	OFF
*SM247	When selecting "Manual + Flags" in "I/O allocation setting when Power On", use this flag to activate the 18 <sup>th</sup> module on the right-side of the CPU module.	○	○	—	—	—	Y	R/W	OFF
*SM248	When selecting "Manual + Flags" in "I/O allocation setting when Power On", use this flag to activate the 19 <sup>th</sup> module on the right-side of the CPU module.	○	○	—	—	—	Y	R/W	OFF
*SM249	When selecting "Manual + Flags" in "I/O allocation setting when Power On", use this flag to activate the 20 <sup>th</sup> module on the right-side of the CPU module.	○	○	—	—	—	Y	R/W	OFF
*SM250	When selecting "Manual + Flags" in "I/O allocation setting when Power On", use this flag to activate the 21 <sup>st</sup> module on the right-side of the CPU module.	○	○	—	—	—	Y	R/W	OFF
*SM251	When selecting "Manual + Flags" in "I/O allocation setting when Power On", use this flag to activate the 22 <sup>nd</sup> module on the right-side of the CPU module.	○	○	—	—	—	Y	R/W	OFF
*SM252	When selecting "Manual + Flags" in "I/O allocation setting when Power On", use this flag to activate the 23 <sup>rd</sup> module on the right-side of the CPU module.	○	○	—	—	—	Y	R/W	OFF
*SM253	When selecting "Manual + Flags" in "I/O allocation setting when Power On", use this flag to activate the 24 <sup>th</sup> module on the right-side of the CPU module.	○	○	—	—	—	Y	R/W	OFF
*SM254	When selecting "Manual + Flags" in "I/O allocation setting when Power On", use this flag to activate the 25 <sup>th</sup> module on the right-side of the CPU module.	○	○	—	—	—	Y	R/W	OFF
*SM255	When selecting "Manual + Flags" in "I/O allocation setting when Power On", use this flag to activate the	○	○	—	—	—	Y	R/W	OFF

SM	Function	AS300 Series	AS100/200 Series	OFF	STOP	RUN	Latched	Attribute	Default
				↓ ON	↓ RUN	↓ STOP			
	26 <sup>th</sup> module on the right-side of the CPU module.								
*SM256	When selecting “Manual + Flags” in “I/O allocation setting when Power On”, use this flag to activate the 27 <sup>th</sup> module on the right-side of the CPU module.	○	○	–	–	–	Y	R/W	OFF
*SM257	When selecting “Manual + Flags” in “I/O allocation setting when Power On”, use this flag to activate the 28 <sup>th</sup> module on the right-side of the CPU module.	○	○	–	–	–	Y	R/W	OFF
*SM258	When selecting “Manual + Flags” in “I/O allocation setting when Power On”, use this flag to activate the 29 <sup>th</sup> module on the right-side of the CPU module.	○	○	–	–	–	Y	R/W	OFF
*SM259	When selecting “Manual + Flags” in “I/O allocation setting when Power On”, use this flag to activate the 30 <sup>th</sup> module on the right-side of the CPU module.	○	○	–	–	–	Y	R/W	OFF
*SM260	When selecting “Manual + Flags” in “I/O allocation setting when Power On”, use this flag to activate the 31 <sup>st</sup> module on the right-side of the CPU module.	○	○	–	–	–	Y	R/W	OFF
*SM261	When selecting “Manual + Flags” in “I/O allocation setting when Power On”, use this flag to activate the 32 <sup>nd</sup> module on the right-side of the CPU module.	○	○	–	–	–	Y	R/W	OFF
SM270	Reversing the input direction for MPG 1 flag (X0.0/X0.1)	○	○	OFF	OFF	–	N	R/W	OFF
SM271	Reversing the input direction for MPG 2 flag (X0.2/X0.3)	○	○	OFF	OFF	–	N	R/W	OFF
SM272	Reversing the input direction for MPG 3 flag (X0.4/X0.5)	○	○	OFF	OFF	–	N	R/W	OFF
SM273	Reversing the input direction for MPG 4 flag (X0.6/X0.7)	○	○	OFF	OFF	–	N	R/W	OFF
SM274	Reversing the input direction for MPG 5 flag (X0.8/X0.9)	○	○	OFF	OFF	–	N	R/W	OFF
SM275	Reversing the input direction for MPG 6 flag (X0.10/X0.11)	○	○	OFF	OFF	–	N	R/W	OFF
SM281	Reversing the input direction for high-speed counter 1 flag	○	○	OFF	OFF	–	N	R/W	OFF
SM282	Reversing the input direction for high-speed counter 2 flag	○	○	OFF	OFF	–	N	R/W	OFF
SM283	Reversing the input direction for high-speed counter 3 flag	○	○	OFF	OFF	–	N	R/W	OFF
SM284	Reversing the input direction for high-speed counter 4 flag	○	○	OFF	OFF	–	N	R/W	OFF
SM285	Reversing the input direction for high-speed counter 5 flag	○	○	OFF	OFF	–	N	R/W	OFF
SM286	Reversing the input direction for high-speed counter 6 flag	○	○	OFF	OFF	–	N	R/W	OFF
SM287	Reversing the input direction for high-speed counter 7 flag	○	○	OFF	OFF	–	N	R/W	OFF
SM288	Reversing the input direction for high-speed counter	○	○	OFF	OFF	–	N	R/W	OFF

SM	Function	AS100/200 Series		OFF ↓ ON	STOP ↓ RUN	RUN ↓ STOP	Latched	Attribute	Default
		AS300 Series							
	8 flag								
SM291	Clearing the input point for high-speed counter 1 flag	○	○	OFF	OFF	–	N	R/W	OFF
SM292	Clearing the input point for high-speed counter 2 flag	○	○	OFF	OFF	–	N	R/W	OFF
SM293	Clearing the input point for high-speed counter 3 flag	○	○	OFF	OFF	–	N	R/W	OFF
SM294	Clearing the input point for high-speed counter 4 flag	○	○	OFF	OFF	–	N	R/W	OFF
SM295	Clearing the input point for high-speed counter 5 flag	○	○	OFF	OFF	–	N	R/W	OFF
SM296	Clearing the input point for high-speed counter 6 flag	○	○	OFF	OFF	–	N	R/W	OFF
SM300	Setting counting mode for HC200. HC200 counts down when SM300 is ON.	○	○	OFF	OFF	–	N	R/W	OFF
SM301	Setting counting mode for HC201. HC201 counts down when SM301 is ON.	○	○	OFF	–	–	N	R	OFF
SM302	Setting counting mode for HC202. HC202 counts down when SM302 is ON.	○	○	OFF	–	–	N	R	OFF
SM303	Setting counting mode for HC203. HC203 counts down when SM303 is ON.	○	○	OFF	–	–	N	R	OFF
SM304	Setting counting mode for HC204. HC204 counts down when SM304 is ON.	○	○	OFF	OFF	–	N	R/W	OFF
SM305	Setting counting mode for HC205. HC205 counts down when SM305 is ON.	○	○	OFF	–	–	N	R	OFF
SM306	Setting counting mode for HC206. HC206 counts down when SM306 is ON.	○	○	OFF	–	–	N	R	OFF
SM307	Setting counting mode for HC207. HC207 counts down when SM307 is ON.	○	○	OFF	–	–	N	R	OFF
SM308	Setting counting mode for HC208. HC208 counts down when SM308 is ON.	○	○	OFF	OFF	–	N	R/W	OFF
SM309	Setting counting mode for HC209. HC209 counts down when SM309 is ON.	○	○	OFF	–	–	N	R	OFF
SM310	Setting counting mode for HC210. HC210 counts down when SM310 is ON.	○	○	OFF	–	–	N	R	OFF
SM311	Setting counting mode for HC211. HC211 counts down when SM311 is ON.	○	○	OFF	–	–	N	R	OFF
SM312	Setting counting mode for HC212. HC212 counts down when SM312 is ON.	○	○	OFF	OFF	–	N	R/W	OFF
SM313	Setting counting mode for HC213. HC213 counts down when SM313 is ON.	○	○	OFF	–	–	N	R	OFF
SM314	Setting counting mode for HC214. HC214 counts down when SM314 is ON.	○	○	OFF	–	–	N	R	OFF
SM315	Setting counting mode for HC215. HC215 counts down when SM315 is ON.	○	○	OFF	–	–	N	R	OFF
SM316	Setting counting mode for HC216. HC216 counts down when SM316 is ON.	○	○	OFF	OFF	–	N	R/W	OFF

SM	Function	AS300 Series	AS100/200 Series	OFF	STOP	RUN	Latched	Attribute	Default
				↓ ON	↓ RUN	↓ STOP			
SM317	Setting counting mode for HC217. HC217 counts down when SM317 is ON.	○	○	OFF	–	–	N	R	OFF
SM318	Setting counting mode for HC218. HC218 counts down when SM318 is ON.	○	○	OFF	–	–	N	R	OFF
SM319	Setting counting mode for HC219. HC219 counts down when SM319 is ON.	○	○	OFF	–	–	N	R	OFF
SM320	Setting counting mode for HC220. HC220 counts down when SM320 is ON.	○	○	OFF	OFF	–	N	R/W	OFF
SM321	Setting counting mode for HC221. HC221 counts down when SM321 is ON.	○	○	OFF	–	–	N	R	OFF
SM322	Setting counting mode for HC222. HC222 counts down when SM322 is ON.	○	○	OFF	–	–	N	R	OFF
SM323	Setting counting mode for HC223. HC223 counts down when SM323 is ON.	○	○	OFF	–	–	N	R	OFF
SM332	Setting counting mode for HC232. HC232 counts down when SM332 is ON.	○	○	OFF	OFF	–	N	R/W	OFF
SM333	Setting counting mode for HC233. HC233 counts down when SM333 is ON.	○	○	OFF	–	–	N	R	OFF
SM334	Setting counting mode for HC234. HC234 counts down when SM334 is ON.	○	○	OFF	–	–	N	R	OFF
SM335	Setting counting mode for HC235. HC235 counts down when SM335 is ON.	○	○	OFF	–	–	N	R	OFF
SM336	Setting counting mode for HC236. HC236 counts down when SM336 is ON.	○	○	OFF	OFF	–	N	R/W	OFF
SM337	Setting counting mode for HC237. HC237 counts down when SM337 is ON.	○	○	OFF	–	–	N	R	OFF
SM338	Setting counting mode for HC238. HC238 counts down when SM338 is ON.	○	○	OFF	–	–	N	R	OFF
SM339	Setting counting mode for HC239. HC239 counts down when SM339 is ON.	○	○	OFF	–	–	N	R	OFF
SM340	Setting counting mode for HC240. HC240 counts down when SM340 is ON.	○	○	OFF	OFF	–	N	R/W	OFF
SM341	Setting counting mode for HC241. HC241 counts down when SM341 is ON.	○	○	OFF	–	–	N	R	OFF
SM342	Setting counting mode for HC242. HC242 counts down when SM342 is ON.	○	○	OFF	OFF	–	N	R/W	OFF
SM343	Setting counting mode for HC243. HC243 counts down when SM343 is ON.	○	○	OFF	–	–	N	R	OFF
SM344	Setting counting mode for HC244. HC244 counts down when SM344 is ON.	○	○	OFF	OFF	–	N	R/W	OFF
SM345	Setting counting mode for HC245. HC245 counts down when SM345 is ON.	○	○	OFF	–	–	N	R	OFF
SM346	Setting counting mode for HC246.	○	○	OFF	OFF	–	N	R/W	OFF

SM	Function			OFF ↓ ON	STOP ↓ RUN	RUN ↓ STOP	Latched	Attribute	Default
		AS300 Series	AS100/200 Series						
	HC246 counts down when SM346 is ON.								
SM347	Setting counting mode for HC247. HC247 counts down when SM347 is ON.	○	○	OFF	–	–	N	R	OFF
SM348	Setting counting mode for HC248. HC248 counts down when SM348 is ON.	○	○	OFF	OFF	–	N	R/W	OFF
SM349	Setting counting mode for HC249. HC249 counts down when SM349 is ON.	○	○	OFF	–	–	N	R	OFF
SM350	Setting counting mode for HC250. HC250 counts down when SM350 is ON.	○	○	OFF	OFF	–	N	R/W	OFF
SM351	Setting counting mode for HC251. HC251 counts down when SM351 is ON.	○	○	OFF	–	–	N	R	OFF
SM352	Setting counting mode for HC252. HC252 counts down when SM352 is ON.	○	○	OFF	OFF	–	N	R/W	OFF
SM353	Setting counting mode for HC253. HC253 counts down when SM353 is ON.	○	○	OFF	OFF	–	N	R/W	OFF
*SM360	I200 high-speed comparison interrupt for DPLSY to activate output	○	○	OFF	OFF	–	N	R/W	OFF
*SM361	I201 high-speed comparison interrupt for DPLSY to activate output	○	○	OFF	OFF	–	N	R/W	OFF
*SM362	I202 high-speed comparison interrupt for DPLSY to activate output	○	○	OFF	OFF	–	N	R/W	OFF
*SM363	I203 high-speed comparison interrupt for DPLSY to activate output	○	○	OFF	OFF	–	N	R/W	OFF
*SM364	I210 high-speed comparison interrupt for DPLSY to activate output	○	○	OFF	OFF	–	N	R/W	OFF
*SM365	I211 high-speed comparison interrupt for DPLSY to activate output	○	○	OFF	OFF	–	N	R/W	OFF
*SM366	I212 high-speed comparison interrupt for DPLSY to activate output	○	○	OFF	OFF	–	N	R/W	OFF
*SM367	I213 high-speed comparison interrupt for DPLSY to activate output	○	○	OFF	OFF	–	N	R/W	OFF
*SM368	I220 high-speed comparison interrupt for DPLSY to activate output	○	○	OFF	OFF	–	N	R/W	OFF
*SM369	I221 high-speed comparison interrupt for DPLSY to activate output	○	○	OFF	OFF	–	N	R/W	OFF
*SM370	I222 high-speed comparison interrupt for DPLSY to activate output	○	○	OFF	OFF	–	N	R/W	OFF
*SM371	I223 high-speed comparison interrupt for DPLSY to activate output	○	○	OFF	OFF	–	N	R/W	OFF
*SM372	I230 high-speed comparison interrupt for DPLSY to activate output	○	○	OFF	OFF	–	N	R/W	OFF
*SM373	I231 high-speed comparison interrupt for DPLSY to activate output	○	○	OFF	OFF	–	N	R/W	OFF

SM	Function	AS100/200 Series		OFF ↓ ON	STOP ↓ RUN	RUN ↓ STOP	Latched	Attribute	Default
		AS300 Series	AS100/200 Series						
*SM374	I232 high-speed comparison interrupt for DPLSY to activate output	○	○	OFF	OFF	–	N	R/W	OFF
*SM375	I233 high-speed comparison interrupt for DPLSY to activate output	○	○	OFF	OFF	–	N	R/W	OFF
*SM376	I240 high-speed comparison interrupt for DPLSY to activate output	○	○	OFF	OFF	–	N	R/W	OFF
*SM377	I241 high-speed comparison interrupt for DPLSY to activate output	○	○	OFF	OFF	–	N	R/W	OFF
*SM378	I242 high-speed comparison interrupt for DPLSY to activate output	○	○	OFF	OFF	–	N	R/W	OFF
*SM379	I243 high-speed comparison interrupt for DPLSY to activate output	○	○	OFF	OFF	–	N	R/W	OFF
*SM380	I250 high-speed comparison interrupt for DPLSY to activate output	○	○	OFF	OFF	–	N	R/W	OFF
*SM381	I251 high-speed comparison interrupt for DPLSY to activate output	○	○	OFF	OFF	–	N	R/W	OFF
*SM382	I252 high-speed comparison interrupt for DPLSY to activate output	○	○	OFF	OFF	–	N	R/W	OFF
*SM383	I253 high-speed comparison interrupt for DPLSY to activate output	○	○	OFF	OFF	–	N	R/W	OFF
*SM384	I260 high-speed comparison interrupt for DPLSY to activate output	○	○	OFF	OFF	–	N	R/W	OFF
*SM385	I261 high-speed comparison interrupt for DPLSY to activate output	○	○	OFF	OFF	–	N	R/W	OFF
*SM386	I262 high-speed comparison interrupt for DPLSY to activate output	○	○	OFF	OFF	–	N	R/W	OFF
*SM387	I263 high-speed comparison interrupt for DPLSY to activate output	○	○	OFF	OFF	–	N	R/W	OFF
*SM388	I264 high-speed comparison interrupt for DPLSY to activate output	○	○	OFF	OFF	–	N	R/W	OFF
*SM389	I265 high-speed comparison interrupt for DPLSY to activate output	○	○	OFF	OFF	–	N	R/W	OFF
*SM390	I266 high-speed comparison interrupt for DPLSY to activate output	○	○	OFF	OFF	–	N	R/W	OFF
*SM391	I267 high-speed comparison interrupt for DPLSY to activate output	○	○	OFF	OFF	–	N	R/W	OFF
*SM400	The flag is always ON (normally open) when the CPU runs.	○	○	OFF	ON	OFF	N	R	OFF
*SM401	The flag is always OFF (normally closed) when the CPU runs.	○	○	OFF	OFF	ON	N	R	OFF
*SM402	The flag is ON only at the first scan.	○	○	OFF	ON	OFF	N	R	OFF
*SM403	The flag is OFF only at the first scan.	○	○	OFF	OFF	ON	N	R	OFF
*SM404	10 millisecond clock pulse during which the pulse is ON for 5 milliseconds and then OFF for 5	○	○	OFF	–	–	N	R	OFF

SM	Function			OFF ↓ ON	STOP ↓ RUN	RUN ↓ STOP	Latched	Attribute	Default
		AS300 Series	AS100/200 Series						
	milliseconds								
*SM405	100 millisecond clock pulse during which the pulse is ON for 50 milliseconds and then OFF for 50 milliseconds	○	○	OFF	–	–	N	R	OFF
*SM406	200 millisecond clock pulse during which the pulse is ON for 100 milliseconds and then OFF for 100 milliseconds	○	○	OFF	–	–	N	R	OFF
*SM407	One second clock pulse during which the pulse is ON for 500 milliseconds and then OFF for 500 milliseconds	○	○	OFF	–	–	N	R	OFF
*SM450	Memory card is present ON: the memory card is present. OFF: the memory card is not present.	○	○	–	–	–	N	R	OFF
*SM452	The data in the memory card is being accessed. ON: the data in the memory card is being accessed. OFF: the data in the memory card is not accessed.	○	○	OFF	–	–	N	R	OFF
*SM453	Error occurs during the operation of the memory card. ON: an error occurs. OFF: no error.	○	○	OFF	–	–	N	R	OFF
SM454	Enabling/disabling the data logger. ON: enable OFF: disable	○	○	OFF	–	–	N	R/W	OFF
SM455	The data logger is currently taking samples. ON: number of records has reached its sampling limit	○	○	OFF	–	–	N	R	OFF
*SM456	Execution of data logger and the memory card. ON: execution by the values in SR902.	○	○	OFF	–	–	N	R/W	OFF
SM457	State of the sample parameters in data logger ON: the sample parameter is set.	○	○	–	–	–	N	R	OFF
SM460	Outputting Y0.0/axis 1 (Y0.0/Y0.1).	○	○	OFF	OFF	–	N	R	OFF
SM461	Y0.0/axis 1 (Y0.0/Y0.1) output is complete.	○	○	OFF	OFF	–	N	R/W	OFF
SM462	Reversing the output direction of axis 1 (Y0.1)	○	○	OFF	OFF	–	N	R/W	OFF
*SM463	Stopping the output of Y0.0/axis 1 (Y0.0/Y0.1)	○	○	OFF	OFF	–	N	R/W	OFF
SM464	Enabling the hardware positive limit on axis 1 (Y0.0/Y0.1)	○	○	–	–	–	Y	R/W	OFF
SM465	Alarm: exceeding the positive limit on axis 1 (Y0.0/Y0.1) or while performing zero return and the positive limit is reached.	○	○	OFF	OFF	–	N	R/W	OFF
SM466	Enabling the hardware negative limit on axis 1 (Y0.0/Y0.1)	○	○	–	–	–	Y	R/W	OFF
SM467	Alarm: exceeding the negative limit on axis 1 (Y0.0/Y0.1) or while performing zero return and the negative limit is reached.	○	○	OFF	OFF	–	N	R/W	OFF

SM	Function			OFF ↓ ON	STOP ↓ RUN	RUN ↓ STOP	Latched	Attribute	Default
		AS300 Series	AS100/200 Series						
SM469	Enabling fixed slope ramp-up/down on axis 1 (Y0.0/Y0.1)	○	○	OFF	OFF	–	N	R/W	OFF
SM470	Auto-reset when Y0.0/axis 1 (Y0.0/Y0.1) output is complete.	○	○	OFF	OFF	–	N	R/W	OFF
SM471	Executing an interrupt I500 when pulse output ends on axis 1 (Y0.0/Y0.1)	○	○	OFF	OFF	–	N	R/W	OFF
SM472	Outputting Y0.1.	○	○	OFF	OFF	–	N	R	OFF
SM473	Y0.1 output is complete.	○	○	OFF	OFF	–	N	R/W	OFF
*SM474	Stopping the output of Y0.1.	○	○	OFF	OFF	–	N	R/W	OFF
SM475	Auto-reset when Y0.1 output is complete.	○	○	OFF	OFF	–	N	R/W	OFF
*SM476	Output immediately stops when the instruction is disabled or stops for Y0.0/axis 1 (Y0.0/Y0.1)	○	○	OFF	OFF	–	N	R/W	OFF
*SM477	Output immediately stops when the instruction is disabled or stops for Y0.1	○	○	OFF	OFF	–	N	R/W	OFF
SM478	Change the target position while outputting Y0.0/axis 1 (Y0.0/Y0.1)	○	○	OFF	OFF	–	N	R/W	OFF
SM479	Change the target position while outputting Y0.1	○	○	OFF	OFF	–	N	R/W	OFF
SM480	Outputting Y0.2/axis 2 (Y0.2/Y0.3).	○	○	OFF	OFF	–	N	R	OFF
SM481	Y0.2/axis 2 (Y0.2/Y0.3) output is complete.	○	○	OFF	OFF	–	N	R/W	OFF
SM482	Reversing the output direction of axis 2 (Y0.3)	○	○	OFF	OFF	–	N	R/W	OFF
*SM483	Stopping the output of Y0.2/axis 2 (Y0.2/Y0.3)	○	○	OFF	OFF	–	N	R/W	OFF
SM484	Enabling the hardware positive limit on axis 2 (Y0.2/Y0.3)	○	○	–	–	–	Y	R/W	OFF
SM485	Alarm: exceeding the positive limit on axis 2 (Y0.2/Y0.3) or while performing zero return and the positive limit is reached.	○	○	OFF	OFF	–	N	R/W	OFF
SM486	Enabling the hardware negative limit on axis 2 (Y0.2/Y0.3)	○	○	–	–	–	Y	R/W	OFF
SM487	Alarm: exceeding the negative limit on axis 2 (Y0.2/Y0.3) or while performing zero return and the negative limit is reached.	○	○	OFF	OFF	–	N	R/W	OFF
SM489	Enabling fixed slope ramp-up/down on axis 2 (Y0.2/Y0.3).	○	○	OFF	OFF	–	N	R/W	OFF
SM490	Auto-reset when Y0.2/axis 2 (Y0.2/Y0.3) output is complete.	○	○	OFF	OFF	–	N	R/W	OFF
SM491	Executing an interrupt I501 when pulse output ends on axis 2 (Y0.2/Y0.3).	○	○	OFF	OFF	–	N	R/W	OFF
SM492	Outputting Y0.3.	○	○	OFF	OFF	–	N	R	OFF
SM493	Y0.3 output is complete.	○	○	OFF	OFF	–	N	R/W	OFF
*SM494	Stopping the output of Y0.3.	○	○	OFF	OFF	–	N	R/W	OFF
SM495	Auto-reset when Y0.3 output is complete.	○	○	OFF	OFF	–	N	R/W	OFF
*SM496	The output immediately stops when the instruction is disabled or stops for Y0.2/axis 2 (Y0.2/Y0.3).	○	○	OFF	OFF	–	N	R/W	OFF

SM	Function			OFF ↓ ON	STOP ↓ RUN	RUN ↓ STOP	Latched	Attribute	Default
		AS300 Series	AS100/200 Series						
*SM497	The output immediately stops when the instruction is disabled or stops for Y0.3.	○	○	OFF	OFF	–	N	R/W	OFF
SM498	Change the target position while outputting Y0.2/axis 2 (Y0.2/Y0.3)	○	○	OFF	OFF	–	N	R/W	OFF
SM499	Change the target position while outputting Y0.3	○	○	OFF	OFF	–	N	R/W	OFF
SM500	Outputting Y0.4/axis 3 (Y0.4/Y0.5).	○	○	OFF	OFF	–	N	R	OFF
SM501	Y0.4/axis 3 (Y0.4/Y0.5) output is complete.	○	○	OFF	OFF	–	N	R/W	OFF
SM502	Reversing the output direction of axis 3 (Y0.5).	○	○	OFF	OFF	–	N	R/W	OFF
*SM503	Stopping the output of Y0.4/axis 3 (Y0.4/Y0.5).	○	○	OFF	OFF	–	N	R/W	OFF
SM504	Enabling the hardware positive limit on axis 3 (Y0.4/Y0.5)	○	○	–	–	–	Y	R/W	OFF
SM505	Alarm: exceeding the positive limit on axis 3 (Y0.4/Y0.5) or while performing zero return and the positive limit is reached.	○	○	OFF	OFF	–	N	R/W	OFF
SM506	Enabling the hardware negative limit on axis 3 (Y0.4/Y0.5)	○	○	–	–	–	Y	R/W	OFF
SM507	Alarm: exceeding the negative limit on axis 3 (Y0.4/Y0.5) or while performing zero return and the negative limit is reached.	○	○	OFF	OFF	–	N	R/W	OFF
SM509	Enabling fixed slope ramp-up/down on axis 3 (Y0.4/Y0.5)	○	○	OFF	OFF	–	N	R/W	OFF
SM510	Auto-reset when Y0.4/axis 3 (Y0.4/Y0.5) output is complete.	○	○	OFF	OFF	–	N	R/W	OFF
SM511	Executing an interrupt I502 when pulse output ends for axis 3 (Y0.4/Y0.5).	○	○	OFF	OFF	–	N	R/W	OFF
SM512	Outputting Y0.5.	○	○	OFF	OFF	–	N	R	OFF
SM513	Y0.5 output is complete.	○	○	OFF	OFF	–	N	R/W	OFF
*SM514	Stopping the output of Y0.5.	○	○	OFF	OFF	–	N	R/W	OFF
SM515	Auto-reset when Y0.5 output is complete.	○	○	OFF	OFF	–	N	R/W	OFF
*SM516	Output immediately stops when the instruction is disabled or stops on Y0.4/axis 3 (Y0.4/Y0.5).	○	○	OFF	OFF	–	N	R/W	OFF
*SM517	Output immediately stops when the instruction is disabled or stops on Y0.5.	○	○	OFF	OFF	–	N	R/W	OFF
SM518	Change the target position while outputting Y0.4/axis 3 (Y0.4/Y0.5)	○	○	OFF	OFF	–	N	R/W	OFF
SM519	Change the target position while outputting Y0.5	○	○	OFF	OFF	–	N	R/W	OFF
SM520	Outputting Y0.6/axis 4 (Y0.6/Y0.7).	○	○	OFF	OFF	–	N	R	OFF
SM521	Y0.6/axis 4 (Y0.6/Y0.7) output is complete.	○	○	OFF	OFF	–	N	R/W	OFF
SM522	Reversing the output direction of axis 4 (Y0.7) .	○	○	OFF	OFF	–	N	R/W	OFF
*SM523	Stopping the output of Y0.6/axis 4 (Y0.6/Y0.7).	○	○	OFF	OFF	–	N	R/W	OFF
SM524	Enabling the hardware positive limit on axis 4 (Y0.6/Y0.7).	○	○	–	–	–	Y	R/W	OFF

SM	Function	AS100/200 Series		OFF ↓ ON	STOP ↓ RUN	RUN ↓ STOP	Latched	Attribute	Default
		AS300 Series	AS100/200 Series						
SM525	Alarm: exceeding the positive limit on axis 4 (Y0.6/Y0.7) or while performing zero return and the positive limit is reached.	○	○	OFF	OFF	–	N	R/W	OFF
SM526	Enabling the hardware negative limit on axis 4 (Y0.6/Y0.7).	○	○	–	–	–	Y	R/W	OFF
SM527	Alarm: exceeding the negative limit on axis 4 (Y0.6/Y0.7) or while performing zero return and the negative limit is reached.	○	○	OFF	OFF	–	N	R/W	OFF
SM529	Enabling fixed slope ramp-up/down on axis 4 (Y0.6/Y0.7).	○	○	OFF	OFF	–	N	R/W	OFF
SM530	Auto-reset when Y0.6/axis 4 (Y0.6/Y0.7) output is complete.	○	○	OFF	OFF	–	N	R/W	OFF
SM531	Executing an interrupt I503 when pulse output ends on axis 4 (Y0.6/Y0.7).	○	○	OFF	OFF	–	N	R/W	OFF
SM532	Outputting Y0.7.	○	○	OFF	OFF	–	N	R	OFF
SM533	Y0.7 output is complete.	○	○	OFF	OFF	–	N	R/W	OFF
*SM534	Stopping the output of Y0.7.	○	○	OFF	OFF	–	N	R/W	OFF
SM535	Auto-reset when Y0.7 output is complete.	○	○	OFF	OFF	–	N	R/W	OFF
*SM536	Output immediately stops when the instruction is disabled or stops for Y0.6/axis 4 (Y0.6/Y0.7).	○	○	OFF	OFF	–	N	R/W	OFF
*SM537	Output immediately stops when the instruction is disabled or stops for Y0.7.	○	○	OFF	OFF	–	N	R/W	OFF
SM538	Change the target position while outputting Y0.6/axis 4 (Y0.6/Y0.7)	○	○	OFF	OFF	–	N	R/W	OFF
SM539	Change the target position while outputting Y0.7	○	○	OFF	OFF	–	N	R/W	OFF
SM540	Outputting Y0.8/axis 5 (Y0.8/Y0.9).	○	○	OFF	OFF	–	N	R	OFF
SM541	Y0.8/axis 5 (Y0.8/Y0.9) output is complete.	○	○	OFF	OFF	–	N	R/W	OFF
SM542	Reversing the output direction of axis 5 (Y0.9).	○	○	OFF	OFF	–	N	R/W	OFF
*SM543	Stopping the output of Y0.8/axis 5 (Y0.8/Y0.9).	○	○	OFF	OFF	–	N	R/W	OFF
SM544	Enabling the hardware positive limit on axis 5 (Y0.8/Y0.9).	○	○	–	–	–	Y	R/W	OFF
SM545	Alarm: exceeding the positive limit on axis 5 (Y0.8/Y0.9) or while performing zero return and the positive limit is reached.	○	○	OFF	OFF	–	N	R/W	OFF
SM546	Enabling the hardware negative limit on axis 5 (Y0.8/Y0.9).	○	○	–	–	–	Y	R/W	OFF
SM547	Alarm: exceeding the negative limit on axis 5 (Y0.8/Y0.9) or while performing zero return and the positive limit is reached.	○	○	OFF	OFF	–	N	R/W	OFF
SM549	Enabling fixed slope ramp-up/down on axis 5 (Y0.8/Y0.9).	○	○	OFF	OFF	–	N	R/W	OFF
SM550	Auto-reset when Y0.8/axis 5 (Y0.8/Y0.9) output is complete.	○	○	OFF	OFF	–	N	R/W	OFF

SM	Function			OFF ↓ ON	STOP ↓ RUN	RUN ↓ STOP	Latched	Attribute	Default
		AS300 Series	AS100/200 Series						
SM551	Executing an interrupt I504 when pulse output ends on axis 5 (Y0.8/Y0.9).	○	○	OFF	OFF	–	N	R/W	OFF
SM552	Outputting Y0.9.	○	○	OFF	OFF	–	N	R	OFF
SM553	Y0.9 output is complete.	○	○	OFF	OFF	–	N	R/W	OFF
*SM554	Stopping the output of Y0.9.	○	○	OFF	OFF	–	N	R/W	OFF
SM555	Auto-reset when Y0.9 output is complete.	○	○	OFF	OFF	–	N	R/W	OFF
*SM556	Output immediately stops when the instruction is disabled or stops for Y0.8/axis 5 (Y0.8/Y0.9).	○	○	OFF	OFF	–	N	R/W	OFF
*SM557	The output immediately stops when the instruction is disabled or stops for Y0.9.	○	○	OFF	OFF	–	N	R/W	OFF
SM558	Change the target position while outputting Y0.8/axis 5 (Y0.8/Y0.9)	○	○	OFF	OFF	–	N	R/W	OFF
SM559	Change the target position while outputting Y0.9	○	○	OFF	OFF	–	N	R/W	OFF
SM560	Outputting Y0.10/axis 6 (Y0.10/Y0.11).	○	○	OFF	OFF	–	N	R	OFF
SM561	Y0.10/axis 6 (Y0.10/Y0.11) output is complete.	○	○	OFF	OFF	–	N	R/W	OFF
SM562	Reversing the output direction of axis 6 (Y0.11).	○	○	OFF	OFF	–	N	R/W	OFF
*SM563	Stopping the output of Y0.10/axis 6 (Y0.10/Y0.11).	○	○	OFF	OFF	–	N	R/W	OFF
SM564	Enabling the hardware positive limit on axis 6 (Y0.10/Y0.11).	○	○	–	–	–	Y	R/W	OFF
SM565	Alarm: exceeding the positive limit on axis 6 (Y0.10/Y0.11) or while performing zero return and the positive limit is reached.	○	○	OFF	OFF	–	N	R/W	OFF
SM566	Enabling the hardware negative limit on axis 6 (Y0.10/Y0.11).	○	○	–	–	–	Y	R/W	OFF
SM567	Alarm: exceeding the negative limit on axis 6 (Y0.10/Y0.11) or while performing zero return and the negative limit is reached.	○	○	OFF	OFF	–	N	R/W	OFF
SM569	Enabling fixed slope ramp-up/down on axis 6 (Y0.10/Y0.11).	○	○	OFF	OFF	–	N	R/W	OFF
SM570	Auto-reset when Y0.10/axis 6 (Y0.10/Y0.11) output is complete.	○	○	OFF	OFF	–	N	R/W	OFF
SM571	Executing an interrupt I505 when pulse output ends on axis 6 (Y0.10/Y0.11).	○	○	OFF	OFF	–	N	R/W	OFF
SM572	Outputting Y0.11.	○	○	OFF	OFF	–	N	R	OFF
SM573	Y0.11 output is complete.	○	○	OFF	OFF	–	N	R/W	OFF
*SM574	Stopping Y0.11 output.	○	○	OFF	OFF	–	N	R/W	OFF
SM575	Auto-reset when Y0.11 output is complete.	○	○	OFF	OFF	–	N	R/W	OFF
*SM576	Output immediately stops when the instruction is disabled or stops for Y0.10/axis 6 (Y0.10/Y0.11).	○	○	OFF	OFF	–	N	R/W	OFF
*SM577	Output immediately stops when the instruction is disabled or stops for Y0.11.	○	○	OFF	OFF	–	N	R/W	OFF
SM578	Change the target position while outputting Y0.10/axis 6 (Y0.10/Y0.11)	○	○	OFF	OFF	–	N	R/W	OFF

SM	Function			OFF ↓ ON	STOP ↓ RUN	RUN ↓ STOP	Latched	Attribute	Default
		AS300 Series	AS100/200 Series						
SM579	Change the target position while outputting Y0.11	○	○	OFF	OFF	–	N	R/W	OFF
SM580	All outputs immediately stop when the instruction is disabled or stops.	○	○	OFF	OFF	–	N	R/W	OFF
SM581	You can change the flag of acceleration / deceleration time during the execution of JOG instruction.	○	○	OFF	OFF	–	N	R/W	OFF
SM585	When executing DTPWS / DTPWL, set SM585 flag to ON, if you need to modify the time for acceleration or deceleration. And then modify the acceleration and deceleration time set in SR to change the acceleration time in single-axis point-to-point motion and single-axis multisegment motion or the deceleration time in single-axis point-to-point motion.	○	○	OFF	OFF	–	N	R/W	OFF
*SM586	Used to calculate the interval frequency of acceleration and deceleration (for axis 1-6)	○	○	OFF	OFF	–	N	R/W	OFF
*SM587	When TPO instruction uses position planning table to control the output, if the output is stopped during execution, the axis should refer to its relevant flags (e.g. SM476, SM496--SM576) for the action to stop.	○	○	OFF	OFF	–	N	R/W	OFF
SM591	Set this flag to ON during the execution of TPO instruction, if you need to stop the ongoing output and start a new one for axis 1, the PLC will act according to the setting in SR1291 to output the next segment or a specific number of segment.	○	○	OFF	OFF	–	N	R/W	OFF
SM592	Set this flag to ON during the execution of TPO instruction, if you need to stop the ongoing output and start a new one for axis 2, the PLC will act according to the setting in SR1292 to output the next segment or a specific number of segment.	○	○	OFF	OFF	–	N	R/W	OFF
SM593	Set this flag to ON during the execution of TPO instruction, if you need to stop the ongoing output and start a new one for axis 3, the PLC will act according to the setting in SR1293 to output the next segment or a specific number of segment.	○	○	OFF	OFF	–	N	R/W	OFF
SM594	Set this flag to ON during the execution of TPO instruction, if you need to stop the ongoing output and start a new one for axis 4, the PLC will act according to the setting in SR1294 to output the next segment or a specific number of segment.	○	○	OFF	OFF	–	N	R/W	OFF
SM595	Set this flag to ON during the execution of TPO instruction, if you need to stop the ongoing output and start a new one for axis 5, the PLC will act according to the setting in SR1295 to output the next segment or a specific number of segment.	○	○	OFF	OFF	–	N	R/W	OFF
SM596	Set this flag to ON during the execution of TPO instruction, if you need to stop the ongoing output and start a new one for axis 6, the PLC will act	○	○	OFF	OFF	–	N	R/W	OFF

SM	Function			OFF ↓ ON	STOP ↓ RUN	RUN ↓ STOP	Latched	Attribute	Default
		AS300 Series	AS100/200 Series						
	according to the setting in SR1296 to output the next segment or a specific number of segment.								
SM600	Zero flag	○	○	OFF	–	–	N	R	OFF
SM601	Borrow flag	○	○	OFF	–	–	N	R	OFF
SM602	Carry flag	○	○	OFF	–	–	N	R	OFF
SM603	Error flag for the number of tasks to do has exceeded the number of tasks the work station can manage for XCMP instruction.	○	○	OFF	OFF	–	N	R/W	OFF
SM604	Setting the working mode of the SORT instruction. ON: descending order OFF: ascending order	○	○	OFF	–	–	N	R/W	OFF
SM605	Designating the working mode of the SMOV instruction.	○	○	OFF	–	–	N	R/W	OFF
SM606	8-bit or 16-bit working mode. ON: 8-bit OFF: 16-bit	○	○	OFF	–	–	N	R/W	OFF
SM607	Matrix comparison flag. ON: Comparing equivalent values. OFF: Comparing different values.	○	○	OFF	–	–	N	R/W	OFF
SM608	Matrix comparison complete. When the last bits are compared, SM608 is ON.	○	○	OFF	–	–	N	R	OFF
SM609	When SM609 is ON, the comparison starts from bit 0.	○	○	OFF	–	–	N	R	OFF
SM610	Matrix bit search flag. When the matrix search finds the matching bits or completes the search, the search stops immediately and SM610 is ON.	○	○	OFF	–	–	N	R	OFF
SM611	Matrix pointer error flag. When the value of the pointer exceeds the comparison range, SM611 is ON.	○	○	OFF	–	–	N	R	OFF
SM612	Matrix pointer increasing flag. The current value of the pointer increases by one.	○	○	OFF	–	–	N	R/W	OFF
SM613	Matrix pointer clearing flag. The current value of the pointer is cleared to zero.	○	○	OFF	–	–	N	R/W	OFF
SM614	Carry flag for the matrix rotation/shift/output.	○	○	OFF	–	–	N	R	OFF
SM615	Borrow flag for the matrix shift/output.	○	○	OFF	–	–	N	R/W	OFF
SM616	Direction flag for the matrix rotation/shift. OFF: the bits are shifted leftward. ON: The bits are shifted rightward.	○	○	OFF	–	–	N	R/W	OFF
SM617	The bits with the value 0 or 1 are counted.	○	○	OFF	–	–	N	R/W	OFF
SM618	ON when the matrix counting result is 0.	○	○	OFF	–	–	N	R/W	OFF
SM619	ON when the instruction EI is executed.	○	○	OFF	OFF	–	N	R	OFF
SM620	When the results from the comparison using the instruction CMPT# are that all devices are ON, SM620 is ON.	○	○	OFF	–	–	N	R	OFF

SM	Function	AS300 Series	AS100/200 Series	OFF	STOP	RUN	Latched	Attribute	Default
				↓ ON	↓ RUN	↓ STOP			
SM621	Setting counting mode for HC0. HC0 counts down when SM621 is ON.	○	○	OFF	–	–	N	R/W	OFF
SM622	Setting counting mode for HC. HC1 counts down when SM622 is ON.	○	○	OFF	–	–	N	R/W	OFF
SM623	Setting counting mode for HC2. HC2 counts down when SM623 is ON.	○	○	OFF	–	–	N	R/W	OFF
SM624	Setting counting mode for HC3. HC3 counts down when SM624 is ON.	○	○	OFF	–	–	N	R/W	OFF
SM625	Setting counting mode for HC4. HC4 counts down when SM625 is ON.	○	○	OFF	–	–	N	R/W	OFF
SM626	Setting counting mode for HC5. HC5 counts down when SM626 is ON.	○	○	OFF	–	–	N	R/W	OFF
SM627	Setting counting mode for HC6. HC6 counts down when SM627 is ON.	○	○	OFF	–	–	N	R/W	OFF
SM628	Setting counting mode for HC7. HC7 counts down when SM628 is ON.	○	○	OFF	–	–	N	R/W	OFF
SM629	Setting counting mode for HC8. HC8 counts down when SM629 is ON.	○	○	OFF	–	–	N	R/W	OFF
SM630	Setting counting mode for HC9. HC9 counts down when SM630 is ON.	○	○	OFF	–	–	N	R/W	OFF
SM631	Setting counting mode for HC10. HC10 counts down when SM631 is ON.	○	○	OFF	–	–	N	R/W	OFF
SM632	Setting counting mode for HC11. HC11 counts down when SM632 is ON.	○	○	OFF	–	–	N	R/W	OFF
SM633	Setting counting mode for HC12. HC12 counts down when SM633 is ON.	○	○	OFF	–	–	N	R/W	OFF
SM634	Setting counting mode for HC13. HC13 counts down when SM634 is ON.	○	○	OFF	–	–	N	R/W	OFF
SM635	Setting counting mode for HC14. HC14 counts down when SM635 is ON.	○	○	OFF	–	–	N	R/W	OFF
SM636	Setting counting mode for HC15. HC15 counts down when SM636 is ON.	○	○	OFF	–	–	N	R/W	OFF
SM637	Setting counting mode for HC16. HC16 counts down when SM637 is ON.	○	○	OFF	–	–	N	R/W	OFF
SM638	Setting counting mode for HC17. HC17 counts down when SM638 is ON.	○	○	OFF	–	–	N	R/W	OFF
SM639	Setting counting mode for HC18. HC18 counts down when SM639 is ON.	○	○	OFF	–	–	N	R/W	OFF
SM640	Setting counting mode for HC19. HC19 counts down when SM640 is ON.	○	○	OFF	–	–	N	R/W	OFF
SM641	Setting counting mode for HC20. HC20 counts down when SM641 is ON.	○	○	OFF	–	–	N	R/W	OFF
SM642	Setting counting mode for HC21.	○	○	OFF	–	–	N	R/W	OFF

SM	Function			OFF ↓ ON	STOP ↓ RUN	RUN ↓ STOP	Latched	Attribute	Default
		AS300 Series	AS100/200 Series						
	HC21 counts down when SM642 is ON.								
SM643	Setting counting mode for HC22. HC22 counts down when SM643 is ON.	○	○	OFF	–	–	N	R/W	OFF
SM644	Setting counting mode for HC23. HC23 counts down when SM644 is ON.	○	○	OFF	–	–	N	R/W	OFF
SM645	Setting counting mode for HC24. HC24 counts down when SM645 is ON.	○	○	OFF	–	–	N	R/W	OFF
SM646	Setting counting mode for HC25. HC25 counts down when SM646 is ON.	○	○	OFF	–	–	N	R/W	OFF
SM647	Setting counting mode for HC26. HC26 counts down when SM647 is ON.	○	○	OFF	–	–	N	R/W	OFF
SM648	Setting counting mode for HC27. HC27 counts down when SM648 is ON.	○	○	OFF	–	–	N	R/W	OFF
SM649	Setting counting mode for HC28. HC28 counts down when SM649 is ON.	○	○	OFF	–	–	N	R/W	OFF
SM650	Setting counting mode for HC29. HC29 counts down when SM650 is ON.	○	○	OFF	–	–	N	R/W	OFF
SM651	Setting counting mode for HC30. HC30 counts down when SM651 is ON.	○	○	OFF	–	–	N	R/W	OFF
SM652	Setting counting mode for HC31. HC31 counts down when SM652 is ON.	○	○	OFF	–	–	N	R/W	OFF
SM653	Setting counting mode for HC32. HC32 counts down when SM653 is ON.	○	○	OFF	–	–	N	R/W	OFF
SM654	Setting counting mode for HC33. HC33 counts down when SM653 is ON.	○	○	OFF	–	–	N	R/W	OFF
SM655	Setting counting mode for HC34. HC34 counts down when SM655 is ON.	○	○	OFF	–	–	N	R/W	OFF
SM656	Setting counting mode for HC35. HC35 counts down when SM656 is ON.	○	○	OFF	–	–	N	R/W	OFF
SM657	Setting counting mode for HC36. HC36 counts down when SM657 is ON.	○	○	OFF	–	–	N	R/W	OFF
SM658	Setting counting mode for HC37. HC37 counts down when SM658 is ON.	○	○	OFF	–	–	N	R/W	OFF
SM659	Setting counting mode for HC38. HC38 counts down when SM659 is ON.	○	○	OFF	–	–	N	R/W	OFF
SM660	Setting counting mode for HC39. HC39 counts down when SM660 is ON.	○	○	OFF	–	–	N	R/W	OFF
SM661	Setting counting mode for HC40. HC40 counts down when SM661 is ON.	○	○	OFF	–	–	N	R/W	OFF
SM662	Setting counting mode for HC41. HC41 counts down when SM662 is ON.	○	○	OFF	–	–	N	R/W	OFF
SM663	Setting counting mode for HC42. HC42 counts down when SM663 is ON.	○	○	OFF	–	–	N	R/W	OFF

SM	Function	AS300 Series	AS100/200 Series	OFF	STOP	RUN	Latched	Attribute	Default
				↓ ON	↓ RUN	↓ STOP			
SM664	Setting counting mode for HC43. HC43 counts down when SM664 is ON.	○	○	OFF	–	–	N	R/W	OFF
SM665	Setting counting mode for HC44. HC44 counts down when SM665 is ON.	○	○	OFF	–	–	N	R/W	OFF
SM666	Setting counting mode for HC45. HC45 counts down when SM666 is ON.	○	○	OFF	–	–	N	R/W	OFF
SM667	Setting counting mode for HC46. HC46 counts down when SM667 is ON.	○	○	OFF	–	–	N	R/W	OFF
SM668	Setting counting mode for HC47. HC47 counts down when SM668 is ON.	○	○	OFF	–	–	N	R/W	OFF
SM669	Setting counting mode for HC48. HC48 counts down when SM669 is ON.	○	○	OFF	–	–	N	R/W	OFF
SM670	Setting counting mode for HC49. HC49 counts down when SM670 is ON.	○	○	OFF	–	–	N	R/W	OFF
SM671	Setting counting mode for HC50. HC50 counts down when SM671 is ON.	○	○	OFF	–	–	N	R/W	OFF
SM672	Setting counting mode for HC51. HC51 counts down when SM672 is ON.	○	○	OFF	–	–	N	R/W	OFF
SM673	Setting counting mode for HC52. HC52 counts down when SM673 is ON.	○	○	OFF	–	–	N	R/W	OFF
SM674	Setting counting mode for HC53. HC53 counts down when SM674 is ON.	○	○	OFF	–	–	N	R/W	OFF
SM675	Setting counting mode for HC54. HC54 counts down when SM675 is ON.	○	○	OFF	–	–	N	R/W	OFF
SM676	Setting counting mode for HC55. HC55 counts down when SM676 is ON.	○	○	OFF	–	–	N	R/W	OFF
SM677	Setting counting mode for HC56. HC56 counts down when SM677 is ON.	○	○	OFF	–	–	N	R/W	OFF
SM678	Setting counting mode for HC57. HC57 counts down when SM678 is ON.	○	○	OFF	–	–	N	R/W	OFF
SM679	Setting counting mode for HC58. HC58 counts down when SM679 is ON.	○	○	OFF	–	–	N	R/W	OFF
SM680	Setting counting mode for HC59. HC59 counts down when SM680 is ON.	○	○	OFF	–	–	N	R/W	OFF
SM681	Setting counting mode for HC60. HC60 counts down when SM681 is ON.	○	○	OFF	–	–	N	R/W	OFF
SM682	Setting counting mode for HC61. HC61 counts down when SM682 is ON.	○	○	OFF	–	–	N	R/W	OFF
SM683	Setting counting mode for HC62. HC62 counts down when SM683 is ON.	○	○	OFF	–	–	N	R/W	OFF
SM684	Setting counting mode for HC63. HC63 counts down when SM684 is ON.	○	○	OFF	–	–	N	R/W	OFF
SM685	The DSCLP instruction uses floating-point	○	○	OFF	–	–	N	R/W	OFF

SM	Function			OFF ↓ ON	STOP ↓ RUN	RUN ↓ STOP	Latched	Attribute	Default
		AS300 Series	AS100/200 Series						
	operations.								
SM686	RAMP instruction mode	○	○	OFF	–	–	N	R/W	OFF
SM687	RAMP instruction execution is complete.	○	○	OFF	–	–	N	R/W	OFF
SM688	INCD instruction execution is complete.	○	○	OFF	–	–	N	R/W	OFF
SM690	String control mode.	○	○	OFF	–	–	N	R/W	OFF
SM691	HKY instruction input mode is 16-bit. ON: the input is the hexadecimal input OFF: A–F are function keys.	○	○	OFF	–	–	N	R/W	OFF
SM692	After the execution of the HKY instruction is complete, SM692 is ON for a scan cycle.	○	○	OFF	–	–	N	R/W	OFF
SM693	After the execution of the SEGL instruction is complete, SM693 is ON for a scan cycle.	○	○	OFF	–	–	N	R/W	OFF
SM694	After the execution of the DSW instruction is complete, SM694 is ON for a scan cycle.	○	○	OFF	–	–	N	R/W	OFF
SM695	Radian/degree flag. ON: degrees OFF: Radians	○	○	OFF	–	–	N	R/W	OFF
SM749	Error occurs in the initialization of the data exchange through COM1.	○	○	OFF	–	–	N	R/W	OFF
*SM750	Data exchange through COM1 enabled by ISPSOft.	○	○	OFF	–	–	H	R/W	OFF
*SM752	Connection 1 for data exchange through COM1 started	○	○	OFF	–	–	H	R/W	OFF
*SM753	Connection 2 for data exchange through COM1 started	○	○	OFF	–	–	H	R/W	OFF
*SM754	Connection 3 for data exchange through COM1 started	○	○	OFF	–	–	H	R/W	OFF
*SM755	Connection 4 for data exchange through COM1 started	○	○	OFF	–	–	H	R/W	OFF
*SM756	Connection 5 for data exchange through COM1 started	○	○	OFF	–	–	H	R/W	OFF
*SM757	Connection 6 for data exchange through COM1 started	○	○	OFF	–	–	H	R/W	OFF
*SM758	Connection 7 for data exchange through COM1 started	○	○	OFF	–	–	H	R/W	OFF
*SM759	Connection 8 for data exchange through COM1 started	○	○	OFF	–	–	H	R/W	OFF
*SM760	Connection 9 for data exchange through COM1 started	○	○	OFF	–	–	H	R/W	OFF
*SM761	Connection 10 for data exchange through COM1 started	○	○	OFF	–	–	H	R/W	OFF
*SM762	Connection 11 for data exchange through COM1 started	○	○	OFF	–	–	H	R/W	OFF
*SM763	Connection 12 for data exchange through COM1 started	○	○	OFF	–	–	H	R/W	OFF

SM	Function	AS300 Series	AS100/200 Series	OFF	STOP	RUN	Latched	Attribute	Default
				↓ ON	↓ RUN	↓ STOP			
*SM764	Connection 13 for data exchange through COM1 started	○	○	OFF	–	–	H	R/W	OFF
*SM765	Connection 14 for data exchange through COM1 started	○	○	OFF	–	–	H	R/W	OFF
*SM766	Connection 15 for data exchange through COM1 started	○	○	OFF	–	–	H	R/W	OFF
*SM767	Connection 16 for data exchange through COM1 started	○	○	OFF	–	–	H	R/W	OFF
*SM768	Connection 17 for data exchange through COM1 started	○	○	OFF	–	–	H	R/W	OFF
*SM769	Connection 18 for data exchange through COM1 started	○	○	OFF	–	–	H	R/W	OFF
*SM770	Connection 19 for data exchange through COM1 started	○	○	OFF	–	–	H	R/W	OFF
*SM771	Connection 20 for data exchange through COM1 started	○	○	OFF	–	–	H	R/W	OFF
*SM772	Connection 21 for data exchange through COM1 started	○	○	OFF	–	–	H	R/W	OFF
*SM773	Connection 22 for data exchange through COM1 started	○	○	OFF	–	–	H	R/W	OFF
*SM774	Connection 23 for data exchange through COM1 started	○	○	OFF	–	–	H	R/W	OFF
*SM775	Connection 24 for data exchange through COM1 started	○	○	OFF	–	–	H	R/W	OFF
*SM776	Connection 25 for data exchange through COM1 started	○	○	OFF	–	–	H	R/W	OFF
*SM777	Connection 26 for data exchange through COM1 started	○	○	OFF	–	–	H	R/W	OFF
*SM778	Connection 27 for data exchange through COM1 started	○	○	OFF	–	–	H	R/W	OFF
*SM779	Connection 28 for data exchange through COM1 started	○	○	OFF	–	–	H	R/W	OFF
*SM780	Connection 29 for data exchange through COM1 started	○	○	OFF	–	–	H	R/W	OFF
*SM781	Connection 30 for data exchange through COM1 started	○	○	OFF	–	–	H	R/W	OFF
*SM782	Connection 31 for data exchange through COM1 started	○	○	OFF	–	–	H	R/W	OFF
*SM783	Connection 32 for data exchange through COM1 started	○	○	OFF	–	–	H	R/W	OFF
*SM784	Successful data exchange connection 1 through COM1	○	○	OFF	–	–	N	R	OFF
*SM785	Successful data exchange connection 2 through COM1	○	○	OFF	–	–	N	R	OFF
*SM786	Successful data exchange connection 3 through COM1	○	○	OFF	–	–	N	R	OFF

SM	Function			OFF ↓ ON	STOP ↓ RUN	RUN ↓ STOP	Latched	Attribute	Default
		AS300 Series	AS100/200 Series						
*SM787	Successful data exchange connection 4 through COM1	○	○	OFF	–	–	N	R	OFF
*SM788	Successful data exchange connection 5 through COM1	○	○	OFF	–	–	N	R	OFF
*SM789	Successful data exchange connection 6 through COM1	○	○	OFF	–	–	N	R	OFF
*SM790	Successful data exchange connection 7 through COM1	○	○	OFF	–	–	N	R	OFF
*SM791	Successful data exchange connection 8 through COM1	○	○	OFF	–	–	N	R	OFF
*SM792	Successful data exchange connection 9 through COM1	○	○	OFF	–	–	N	R	OFF
*SM793	Successful data exchange connection 10 through COM1	○	○	OFF	–	–	N	R	OFF
*SM794	Successful data exchange connection 11 through COM1	○	○	OFF	–	–	N	R	OFF
*SM795	Successful data exchange connection 12 through COM1	○	○	OFF	–	–	N	R	OFF
*SM796	Successful data exchange connection 13 through COM1	○	○	OFF	–	–	N	R	OFF
*SM797	Successful data exchange connection 14 through COM1	○	○	OFF	–	–	N	R	OFF
*SM798	Successful data exchange connection 15 through COM1	○	○	OFF	–	–	N	R	OFF
*SM799	Successful data exchange connection 16 through COM1	○	○	OFF	–	–	N	R	OFF
*SM800	Successful data exchange connection 17 through COM1	○	○	OFF	–	–	N	R	OFF
*SM801	Successful data exchange connection 18 through COM1	○	○	OFF	–	–	N	R	OFF
*SM802	Successful data exchange connection 19 through COM1	○	○	OFF	–	–	N	R	OFF
*SM803	Successful data exchange connection 20 through COM1	○	○	OFF	–	–	N	R	OFF
*SM804	Successful data exchange connection 21 through COM1	○	○	OFF	–	–	N	R	OFF
*SM805	Successful data exchange connection 22 through COM1	○	○	OFF	–	–	N	R	OFF
*SM806	Successful data exchange connection 23 through COM1	○	○	OFF	–	–	N	R	OFF
*SM807	Successful data exchange connection 24 through COM1	○	○	OFF	–	–	N	R	OFF
*SM808	Successful data exchange connection 25 through COM1	○	○	OFF	–	–	N	R	OFF
*SM809	Successful data exchange connection 26 through COM1	○	○	OFF	–	–	N	R	OFF

SM	Function	AS100/200 Series		OFF ↓ ON	STOP ↓ RUN	RUN ↓ STOP	Latched	Attribute	Default
		AS300 Series							
*SM810	Successful data exchange connection 27 through COM1	○	○	OFF	–	–	N	R	OFF
*SM811	Successful data exchange connection 28 through COM1	○	○	OFF	–	–	N	R	OFF
*SM812	Successful data exchange connection 29 through COM1	○	○	OFF	–	–	N	R	OFF
*SM813	Successful data exchange connection 30 through COM1	○	○	OFF	–	–	N	R	OFF
*SM814	Successful data exchange connection 31 through COM1	○	○	OFF	–	–	N	R	OFF
*SM815	Successful data exchange connection 32 through COM1	○	○	OFF	–	–	N	R	OFF
*SM816	Error in data exchange connection 1 through COM1	○	○	OFF	–	–	N	R	OFF
*SM817	Error in data exchange connection 2 through COM1	○	○	OFF	–	–	N	R	OFF
*SM818	Error in data exchange connection 3 through COM1	○	○	OFF	–	–	N	R	OFF
*SM819	Error in data exchange connection 4 through COM1	○	○	OFF	–	–	N	R	OFF
*SM820	Error in data exchange connection 5 through COM1	○	○	OFF	–	–	N	R	OFF
*SM821	Error in data exchange connection 6 through COM1	○	○	OFF	–	–	N	R	OFF
*SM822	Error in data exchange connection 7 through COM1	○	○	OFF	–	–	N	R	OFF
*SM823	Error in data exchange connection 8 through COM1	○	○	OFF	–	–	N	R	OFF
*SM824	Error in data exchange connection 9 through COM1	○	○	OFF	–	–	N	R	OFF
*SM825	Error in data exchange connection 10 through COM1	○	○	OFF	–	–	N	R	OFF
*SM826	Error in data exchange connection 11 through COM1	○	○	OFF	–	–	N	R	OFF
*SM827	Error in data exchange connection 12 through COM1	○	○	OFF	–	–	N	R	OFF
*SM828	Error in data exchange connection 13 through COM1	○	○	OFF	–	–	N	R	OFF
*SM829	Error in data exchange connection 14 through COM1	○	○	OFF	–	–	N	R	OFF
*SM830	Error in data exchange connection 15 through COM1	○	○	OFF	–	–	N	R	OFF
*SM831	Error in data exchange connection 16 through COM1	○	○	OFF	–	–	N	R	OFF
*SM832	Error in data exchange connection 17 through COM1	○	○	OFF	–	–	N	R	OFF
*SM833	Error in data exchange connection 18 through COM1	○	○	OFF	–	–	N	R	OFF
*SM834	Error in data exchange connection 19 through COM1	○	○	OFF	–	–	N	R	OFF
*SM835	Error in data exchange connection 20 through COM1	○	○	OFF	–	–	N	R	OFF
*SM836	Error in data exchange connection 21 through COM1	○	○	OFF	–	–	N	R	OFF

SM	Function	AS100/200 Series		OFF ↓ ON	STOP ↓ RUN	RUN ↓ STOP	Latched	Attribute	Default
		AS300 Series							
*SM837	Error in data exchange connection 22 through COM1	○	○	OFF	–	–	N	R	OFF
*SM838	Error in data exchange connection 23 through COM1	○	○	OFF	–	–	N	R	OFF
*SM839	Error in data exchange connection 24 through COM1	○	○	OFF	–	–	N	R	OFF
*SM840	Error in data exchange connection 25 through COM1	○	○	OFF	–	–	N	R	OFF
*SM841	Error in data exchange connection 26 through COM1	○	○	OFF	–	–	N	R	OFF
*SM842	Error in data exchange connection 27 through COM1	○	○	OFF	–	–	N	R	OFF
*SM843	Error in data exchange connection 28 through COM1	○	○	OFF	–	–	N	R	OFF
*SM844	Error in data exchange connection 29 through COM1	○	○	OFF	–	–	N	R	OFF
*SM845	Error in data exchange connection 30 through COM1	○	○	OFF	–	–	N	R	OFF
*SM846	Error in data exchange connection 31 through COM1	○	○	OFF	–	–	N	R	OFF
*SM847	Error in data exchange connection 32 through COM1	○	○	OFF	–	–	N	R	OFF
SM861	Error in the initialization of the data exchange through COM2.	○	○	OFF	–	–	N	R/W	OFF
*SM862	Data exchange through COM2 enabled by ISPSOft.	○	○	OFF	–	OFF	H	R/W	OFF
*SM864	Connection 1 for data exchange through COM2 started	○	○	OFF	–	–	H	R/W	OFF
*SM865	Connection 2 for data exchange through COM2 started	○	○	OFF	–	–	H	R/W	OFF
*SM866	Connection 3 for data exchange through COM2 started	○	○	OFF	–	–	H	R/W	OFF
*SM867	Connection 4 for data exchange through COM2 started	○	○	OFF	–	–	H	R/W	OFF
*SM868	Connection 5 for data exchange through COM2 started	○	○	OFF	–	–	H	R/W	OFF
*SM869	Connection 6 for data exchange through COM2 started	○	○	OFF	–	–	H	R/W	OFF
*SM870	Connection 7 for data exchange through COM2 started	○	○	OFF	–	–	H	R/W	OFF
*SM871	Connection 8 for data exchange through COM2 started	○	○	OFF	–	–	H	R/W	OFF
*SM872	Connection 9 for data exchange through COM2 started	○	○	OFF	–	–	H	R/W	OFF
*SM873	Connection 10 for data exchange through COM2 started	○	○	OFF	–	–	H	R/W	OFF
*SM874	Connection 11 for data exchange through COM2	○	○	OFF	–	–	H	R/W	OFF

SM	Function	AS300 Series	AS100/200 Series	OFF	STOP	RUN	Latched	Attribute	Default
				↓ ON	↓ RUN	↓ STOP			
	started								
*SM875	Connection 12 for data exchange through COM2 started	○	○	OFF	–	–	H	R/W	OFF
*SM876	Connection 13 for data exchange through COM2 started	○	○	OFF	–	–	H	R/W	OFF
*SM877	Connection 14 for data exchange through COM2 started	○	○	OFF	–	–	H	R/W	OFF
*SM878	Connection 15 for data exchange through COM2 started	○	○	OFF	–	–	H	R/W	OFF
*SM879	Connection 16 for data exchange through COM2 started	○	○	OFF	–	–	H	R/W	OFF
*SM880	Connection 17 for data exchange through COM2 started	○	○	OFF	–	–	H	R/W	OFF
*SM881	Connection 18 for data exchange through COM2 started	○	○	OFF	–	–	H	R/W	OFF
*SM882	Connection 19 for data exchange through COM2 started	○	○	OFF	–	–	H	R/W	OFF
*SM883	Connection 20 for data exchange through COM2 started	○	○	OFF	–	–	H	R/W	OFF
*SM884	Connection 21 for data exchange through COM2 started	○	○	OFF	–	–	H	R/W	OFF
*SM885	Connection 22 for data exchange through COM2 started	○	○	OFF	–	–	H	R/W	OFF
*SM886	Connection 23 for data exchange through COM2 started	○	○	OFF	–	–	H	R/W	OFF
*SM887	Connection 24 for data exchange through COM2 started	○	○	OFF	–	–	H	R/W	OFF
*SM888	Connection 25 for data exchange through COM2 started	○	○	OFF	–	–	H	R/W	OFF
*SM889	Connection 26 for data exchange through COM2 started	○	○	OFF	–	–	H	R/W	OFF
*SM890	Connection 27 for data exchange through COM2 started	○	○	OFF	–	–	H	R/W	OFF
*SM891	Connection 28 for data exchange through COM2 started	○	○	OFF	–	–	H	R/W	OFF
*SM892	Connection 29 for data exchange through COM2 started	○	○	OFF	–	–	H	R/W	OFF
*SM893	Connection 30 for data exchange through COM2 started	○	○	OFF	–	–	H	R/W	OFF
*SM894	Connection 31 for data exchange through COM2 started	○	○	OFF	–	–	H	R/W	OFF
*SM895	Connection 32 for data exchange through COM2 started	○	○	OFF	–	–	H	R/W	OFF
*SM896	Successful data exchange connection 1 through COM2	○	○	OFF	–	–	N	R	OFF
*SM897	Successful data exchange connection 2 through	○	○	OFF	–	–	N	R	OFF

SM	Function			OFF ↓ ON	STOP ↓ RUN	RUN ↓ STOP	Latched	Attribute	Default
		AS300 Series	AS100/200 Series						
	COM2								
*SM898	Successful data exchange connection 3 through COM2	○	○	OFF	–	–	N	R	OFF
*SM899	Successful data exchange connection 4 through COM2	○	○	OFF	–	–	N	R	OFF
*SM900	Successful data exchange connection 5 through COM2	○	○	OFF	–	–	N	R	OFF
*SM901	Successful data exchange connection 6 through COM2	○	○	OFF	–	–	N	R	OFF
*SM902	Successful data exchange connection 7 through COM2	○	○	OFF	–	–	N	R	OFF
*SM903	Successful data exchange connection 8 through COM2	○	○	OFF	–	–	N	R	OFF
*SM904	Successful data exchange connection 9 through COM2	○	○	OFF	–	–	N	R	OFF
*SM905	Successful data exchange connection 10 through COM2	○	○	OFF	–	–	N	R	OFF
*SM906	Successful data exchange connection 11 through COM2	○	○	OFF	–	–	N	R	OFF
*SM907	Successful data exchange connection 12 through COM2	○	○	OFF	–	–	N	R	OFF
*SM908	Successful data exchange connection 13 through COM2	○	○	OFF	–	–	N	R	OFF
*SM909	Successful data exchange connection 14 through COM2	○	○	OFF	–	–	N	R	OFF
*SM910	Successful data exchange connection 15 through COM2	○	○	OFF	–	–	N	R	OFF
*SM911	Successful data exchange connection 16 through COM2	○	○	OFF	–	–	N	R	OFF
*SM912	Successful data exchange connection 17 through COM2	○	○	OFF	–	–	N	R	OFF
*SM913	Successful data exchange connection 18 through COM2	○	○	OFF	–	–	N	R	OFF
*SM914	Successful data exchange connection 19 through COM2	○	○	OFF	–	–	N	R	OFF
*SM915	Successful data exchange connection 20 through COM2	○	○	OFF	–	–	N	R	OFF
*SM916	Successful data exchange connection 21 through COM2	○	○	OFF	–	–	N	R	OFF
*SM917	Successful data exchange connection 22 through COM2	○	○	OFF	–	–	N	R	OFF
*SM918	Successful data exchange connection 23 through COM2	○	○	OFF	–	–	N	R	OFF
*SM919	Successful data exchange connection 24 through COM2	○	○	OFF	–	–	N	R	OFF
*SM920	Successful data exchange connection 25 through	○	○	OFF	–	–	N	R	OFF

SM	Function	AS300 Series	AS100/200 Series	OFF	STOP	RUN	Latched	Attribute	Default
				↓ ON	↓ RUN	↓ STOP			
	COM2								
*SM921	Successful data exchange connection 26 through COM2	○	○	OFF	–	–	N	R	OFF
*SM922	Successful data exchange connection 27 through COM2	○	○	OFF	–	–	N	R	OFF
*SM923	Successful data exchange connection 28 through COM2	○	○	OFF	–	–	N	R	OFF
*SM924	Successful data exchange connection 29 through COM2	○	○	OFF	–	–	N	R	OFF
*SM925	Successful data exchange connection 30 through COM2	○	○	OFF	–	–	N	R	OFF
*SM926	Successful data exchange connection 31 through COM2	○	○	OFF	–	–	N	R	OFF
*SM927	Successful data exchange connection 32 through COM2	○	○	OFF	–	–	N	R	OFF
*SM928	Error in data exchange connection 1 through COM2	○	○	OFF	–	–	N	R	OFF
*SM929	Error in data exchange connection 2 through COM2	○	○	OFF	–	–	N	R	OFF
*SM930	Error in data exchange connection 3 through COM2	○	○	OFF	–	–	N	R	OFF
*SM931	Error in data exchange connection 4 through COM2	○	○	OFF	–	–	N	R	OFF
*SM932	Error in data exchange connection 5 through COM2	○	○	OFF	–	–	N	R	OFF
*SM933	Error in data exchange connection 6 through COM2	○	○	OFF	–	–	N	R	OFF
*SM934	Error in data exchange connection 7 through COM2	○	○	OFF	–	–	N	R	OFF
*SM935	Error in data exchange connection 8 through COM2	○	○	OFF	–	–	N	R	OFF
*SM936	Error in data exchange connection 9 through COM2	○	○	OFF	–	–	N	R	OFF
*SM937	Error in data exchange connection 10 through COM2	○	○	OFF	–	–	N	R	OFF
*SM938	Error in data exchange connection 11 through COM2	○	○	OFF	–	–	N	R	OFF
*SM939	Error in data exchange connection 12 through COM2	○	○	OFF	–	–	N	R	OFF
*SM940	Error in data exchange connection 13 through COM2	○	○	OFF	–	–	N	R	OFF
*SM941	Error in data exchange connection 14 through COM2	○	○	OFF	–	–	N	R	OFF
*SM942	Error in data exchange connection 15 through COM2	○	○	OFF	–	–	N	R	OFF
*SM943	Error in data exchange connection 16 through COM2	○	○	OFF	–	–	N	R	OFF
*SM944	Error in data exchange connection 17 through COM2	○	○	OFF	–	–	N	R	OFF
*SM945	Error in data exchange connection 18 through COM2	○	○	OFF	–	–	N	R	OFF
*SM946	Error in data exchange connection 19 through COM2	○	○	OFF	–	–	N	R	OFF

SM	Function			OFF ↓ ON	STOP ↓ RUN	RUN ↓ STOP	Latched	Attribute	Default
		AS300 Series	AS100/200 Series						
*SM947	Error in data exchange connection 20 through COM2	○	○	OFF	–	–	N	R	OFF
*SM948	Error in data exchange connection 21 through COM2	○	○	OFF	–	–	N	R	OFF
*SM949	Error in data exchange connection 22 through COM2	○	○	OFF	–	–	N	R	OFF
*SM950	Error in data exchange connection 23 through COM2	○	○	OFF	–	–	N	R	OFF
*SM951	Error in data exchange connection 24 through COM2	○	○	OFF	–	–	N	R	OFF
*SM952	Error in data exchange connection 25 through COM2	○	○	OFF	–	–	N	R	OFF
*SM953	Error in data exchange connection 26 through COM2	○	○	OFF	–	–	N	R	OFF
*SM954	Error in data exchange connection 27 through COM2	○	○	OFF	–	–	N	R	OFF
*SM955	Error in data exchange connection 28 through COM2	○	○	OFF	–	–	N	R	OFF
*SM956	Error in data exchange connection 29 through COM2	○	○	OFF	–	–	N	R	OFF
*SM957	Error in data exchange connection 30 through COM2	○	○	OFF	–	–	N	R	OFF
*SM958	Error in data exchange connection 31 through COM2	○	○	OFF	–	–	N	R	OFF
*SM959	Error in data exchange connection 32 through COM2	○	○	OFF	–	–	N	R	OFF
SM976	AS remote module #1 connection status (ON: connected; OFF: disconnected or not connected)	○	○	OFF	–	–	N	R	OFF
SM977	AS remote module #2 connection status	○	○	OFF	–	–	N	R	OFF
SM978	AS remote module #3 connection status	○	○	OFF	–	–	N	R	OFF
SM979	AS remote module #4 connection status	○	○	OFF	–	–	N	R	OFF
SM980	AS remote module #5 connection status	○	○	OFF	–	–	N	R	OFF
SM981	AS remote module #6 connection status	○	○	OFF	–	–	N	R	OFF
SM982	AS remote module #7 connection status	○	○	OFF	–	–	N	R	OFF
SM983	AS remote module #8 connection status	○	○	OFF	–	–	N	R	OFF
SM984	AS remote module #9 connection status	○	○	OFF	–	–	N	R	OFF
SM985	AS remote module #10 connection status	○	○	OFF	–	–	N	R	OFF
SM986	AS remote module #11 connection status	○	○	OFF	–	–	N	R	OFF
SM987	AS remote module #12 connection status	○	○	OFF	–	–	N	R	OFF
SM988	AS remote module #13 connection status	○	○	OFF	–	–	N	R	OFF
SM989	AS remote module #14 connection status	○	○	OFF	–	–	N	R	OFF
SM990	AS remote module #15 connection status	○	○	OFF	–	–	N	R	OFF

SM	Function	AS300 Series	AS100/200 Series	OFF ↓ ON	STOP ↓ RUN	RUN ↓ STOP	Latched	Attribute	Default
SM1000	Ethernet setting flag; ON: the data in SR1000–SR1006 is written into the flash memory.	○	○	OFF	–	–	N	R/W	OFF
SM1001	State of the Ethernet connectivity	○	○	OFF	–	–	N	R	OFF
*SM1006	Data exchange through AS-FEN02 enabled by ISPSOft.	○	–	OFF	–	–	N	R/W	OFF
*SM1008	Connection 1 for data exchange through AS-FEN02 started	○	–	OFF	–	–	N	R/W	OFF
*SM1009	Connection 2 for data exchange through AS-FEN02 started	○	–	OFF	–	–	N	R/W	OFF
*SM1010	Connection 3 for data exchange through AS-FEN02 started	○	–	OFF	–	–	N	R/W	OFF
*SM1011	Connection 4 for data exchange through AS-FEN02 started	○	–	OFF	–	–	N	R/W	OFF
*SM1012	Connection 5 for data exchange through AS-FEN02 started	○	–	OFF	–	–	N	R/W	OFF
*SM1013	Connection 6 for data exchange through AS-FEN02 started	○	–	OFF	–	–	N	R/W	OFF
*SM1014	Connection 7 for data exchange through AS-FEN02 started	○	–	OFF	–	–	N	R/W	OFF
*SM1015	Connection 8 for data exchange through AS-FEN02 started	○	–	OFF	–	–	N	R/W	OFF
*SM1016	Successful data exchange connection 1 through AS-FEN02	○	–	OFF	–	–	N	R	OFF
*SM1017	Successful data exchange connection 2 through AS-FEN02	○	–	OFF	–	–	N	R	OFF
*SM1018	Successful data exchange connection 3 through AS-FEN02	○	–	OFF	–	–	N	R	OFF
*SM1019	Successful data exchange connection 4 through AS-FEN02	○	–	OFF	–	–	N	R	OFF
*SM1020	Successful data exchange connection 5 through AS-FEN02	○	–	OFF	–	–	N	R	OFF
*SM1021	Successful data exchange connection 6 through AS-FEN02	○	–	OFF	–	–	N	R	OFF
*SM1022	Successful data exchange connection 7 through AS-FEN02	○	–	OFF	–	–	N	R	OFF
*SM1023	Successful data exchange connection 8 through AS-FEN02	○	–	OFF	–	–	N	R	OFF
*SM1024	Error in data exchange connection 1 through AS-FEN02	○	–	OFF	–	–	N	R	OFF
*SM1025	Error in data exchange connection 2 through AS-FEN02	○	–	OFF	–	–	N	R	OFF
*SM1026	Error in data exchange connection 3 through AS-FEN02	○	–	OFF	–	–	N	R	OFF
*SM1027	Error in data exchange connection 4 through AS-FEN02	○	–	OFF	–	–	N	R	OFF

SM	Function			OFF ↓ ON	STOP ↓ RUN	RUN ↓ STOP	Latched	Attribute	Default
		AS300 Series	AS100/200 Series						
*SM1028	Error in data exchange connection 5 through AS-FEN02	○	–	OFF	–	–	N	R	OFF
*SM1029	Error in data exchange connection 6 through AS-FEN02	○	–	OFF	–	–	N	R	OFF
*SM1030	Error in data exchange connection 7 through AS-FEN02	○	–	OFF	–	–	N	R	OFF
*SM1031	Error in data exchange connection 8 through AS-FEN02	○	–	OFF	–	–	N	R	OFF
*SM1090	TCP connection busy.	○	○	OFF	–	–	N	R	OFF
*SM1091	UDP connection busy.	○	○	OFF	–	–	N	R	OFF
SM1092	Incorrect Modbus TCP server port (available for FW V1.10.20 or later)	○	○	OFF	–	–	N	R/W	OFF
SM1100	Ethernet connection error	○	○	OFF	–	–	N	R	OFF
*SM1106	Basic Ethernet management: connection error	○	○	OFF	–	–	N	R	OFF
*SM1107	Basic Ethernet management: Basic setting error	○	○	OFF	–	–	N	R	OFF
*SM1109	Basic TCP/UDP socket management: the local port is already used.	○	○	OFF	–	–	N	R	OFF
SM1111	EtherNet/IP data exchange flag	○	○	OFF	–	–	N	R	OFF
*SM1113	Email service error	○	○	OFF	–	–	N	R	OFF
*SM1116	Trigger 1 switch for the email.	○	○	OFF	–	–	N	R	OFF
*SM1117	Trigger 1 for the email	○	○	OFF	–	–	N	R	OFF
*SM1119	ON: Trigger 1 is triggered and the email has been sent successfully.	○	○	OFF	–	–	N	R	OFF
*SM1120	ON: Trigger 1 is triggered but the email cannot be sent due to email content error.	○	○	OFF	–	–	N	R	OFF
*SM1122	ON: Trigger 1 is triggered and there is an SMTP server response timeout.	○	○	OFF	–	–	N	R	OFF
*SM1123	ON: Trigger 1 is triggered and there is an SMTP server response error.	○	○	OFF	–	–	N	R	OFF
*SM1124	ON: Trigger 1 is triggered and the size of the attachment exceeds the limit.	○	○	OFF	–	–	N	R	OFF
*SM1125	Trigger 1 is triggered and the attachment is not found.	○	○	OFF	–	–	N	R	OFF
*SM1126	Trigger 2 switch for the email.	○	○	OFF	–	–	N	R	OFF
*SM1127	Trigger 2 for the email	○	○	OFF	–	–	N	R	OFF
*SM1129	ON: Trigger 2 is triggered and the email has been sent successfully.	○	○	OFF	–	–	N	R	OFF
*SM1130	ON: Trigger 2 is triggered but the email cannot be sent due to email content error.	○	○	OFF	–	–	N	R	OFF
*SM1132	ON: Trigger 2 is triggered and there is an SMTP server response timeout.	○	○	OFF	–	–	N	R	OFF
*SM1133	ON: Trigger 2 is triggered and there is an SMTP server response error.	○	○	OFF	–	–	N	R	OFF

SM	Function	AS300 Series	AS100/200 Series	OFF	STOP	RUN	Latched	Attribute	Default
				↓ ON	↓ RUN	↓ STOP			
*SM1134	ON: Trigger 2 is triggered and the size of the attachment exceeds the limit.	○	○	OFF	–	–	N	R	OFF
*SM1135	ON: Trigger 2 is triggered and the attachment is not found.	○	○	OFF	–	–	N	R	OFF
*SM1136	Trigger 3 switch for the email.	○	○	OFF	–	–	N	R	OFF
*SM1137	Trigger 3 for the email	○	○	OFF	–	–	N	R	OFF
*SM1139	ON: Trigger 3 is triggered and the email has been sent successfully.	○	○	OFF	–	–	N	R	OFF
*SM1140	ON: Trigger 3 is triggered but the email cannot be sent due to email content error.	○	○	OFF	–	–	N	R	OFF
*SM1142	ON: Trigger 3 is triggered and there is an SMTP server response timeout.	○	○	OFF	–	–	N	R	OFF
*SM1143	ON: Trigger 3 is triggered and there is an SMTP server response error.	○	○	OFF	–	–	N	R	OFF
*SM1144	ON: Trigger 3 is triggered and the size of the attachment exceeds the limit.	○	○	OFF	–	–	N	R	OFF
*SM1145	ON: Trigger 3 is triggered and the attachment is not found.	○	○	OFF	–	–	N	R	OFF
*SM1146	Trigger 4 switch for the email.	○	○	OFF	–	–	N	R	OFF
*SM1147	Trigger 4 for the email	○	○	OFF	–	–	N	R	OFF
*SM1149	ON: Trigger 4 is triggered and the email has been sent successfully.	○	○	OFF	–	–	N	R	OFF
*SM1150	ON: Trigger 4 is triggered but the email cannot be sent due to email content error.	○	○	OFF	–	–	N	R	OFF
*SM1152	ON: Trigger 4 is triggered and there is an SMTP server response timeout.	○	○	OFF	–	–	N	R	OFF
*SM1153	ON: Trigger 4 is triggered and there is an SMTP server response error.	○	○	OFF	–	–	N	R	OFF
*SM1154	ON: Trigger 4 is triggered and the size of the attachment exceeds the limit.	○	○	OFF	–	–	N	R	OFF
*SM1155	ON: Trigger 4 is triggered and the attachment is not found.	○	○	OFF	–	–	N	R	OFF
SM1160	The process to restore drive parameters has been complete. OFF: When the value in SR1600 switches from 1 to 0, this flag is cleared to OFF. ON: When the process to restore parameters has been complete and without any error, this flag is ON.	○	○	OFF	–	–	N	R	OFF
SM1161	Error occurred during the process to restore drive parameters. OFF: When the value in SR1600 switches from 1 to 0, this flag is cleared to OFF. ON: When an error occurred during the process to restore parameter, this flag is ON.	○	○	OFF	–	–	N	R	OFF

SM	Function			OFF ↓ ON	STOP ↓ RUN	RUN ↓ STOP	Latched	Attribute	Default
		AS300 Series	AS100/200 Series						
*SM1166	Error in data exchange through Ethernet	○	○	–	–	–	N	R	OFF
*SM1167	Data exchange through Ethernet started	○	○	OFF	–	–	H	R/W	OFF
*SM1168	Connection 1 for data exchange through Ethernet started	○	○	OFF	–	–	H	R/W	OFF
*SM1169	Connection 2 for data exchange through Ethernet started	○	○	OFF	–	–	H	R/W	OFF
*SM1170	Connection 3 for data exchange through Ethernet started	○	○	OFF	–	–	H	R/W	OFF
*SM1171	Connection 4 for data exchange through Ethernet started	○	○	OFF	–	–	H	R/W	OFF
*SM1172	Connection 5 for data exchange through Ethernet started	○	○	OFF	–	–	H	R/W	OFF
*SM1173	Connection 6 for data exchange through Ethernet started	○	○	OFF	–	–	H	R/W	OFF
*SM1174	Connection 7 for data exchange through Ethernet started	○	○	OFF	–	–	H	R/W	OFF
*SM1175	Connection 8 for data exchange through Ethernet started	○	○	OFF	–	–	H	R/W	OFF
*SM1176	Connection 9 for data exchange through Ethernet started	○	○	OFF	–	–	H	R/W	OFF
*SM1177	Connection 10 for data exchange through Ethernet started	○	○	OFF	–	–	H	R/W	OFF
*SM1178	Connection 11 for data exchange through Ethernet started	○	○	OFF	–	–	H	R/W	OFF
*SM1179	Connection 12 for data exchange through Ethernet started	○	○	OFF	–	–	H	R/W	OFF
*SM1180	Connection 13 for data exchange through Ethernet started	○	○	OFF	–	–	H	R/W	OFF
*SM1181	Connection 14 for data exchange through Ethernet started	○	○	OFF	–	–	H	R/W	OFF
*SM1182	Connection 15 for data exchange through Ethernet started	○	○	OFF	–	–	H	R/W	OFF
*SM1183	Connection 16 for data exchange through Ethernet started	○	○	OFF	–	–	H	R/W	OFF
*SM1184	Connection 17 for data exchange through Ethernet started	○	–	OFF	–	–	H	R/W	OFF
*SM1185	Connection 18 for data exchange through Ethernet started	○	–	OFF	–	–	H	R/W	OFF
*SM1186	Connection 19 for data exchange through Ethernet started	○	–	OFF	–	–	H	R/W	OFF
*SM1187	Connection 20 for data exchange through Ethernet started	○	–	OFF	–	–	H	R/W	OFF
*SM1188	Connection 21 for data exchange through Ethernet started	○	–	OFF	–	–	H	R/W	OFF
*SM1189	Connection 22 for data exchange through Ethernet started	○	–	OFF	–	–	H	R/W	OFF

SM	Function	AS300 Series	AS100/200 Series	OFF ↓ ON	STOP ↓ RUN	RUN ↓ STOP	Latched	Attribute	Default
*SM1190	Connection 23 for data exchange through Ethernet started	○	–	OFF	–	–	H	R/W	OFF
*SM1191	Connection 24 for data exchange through Ethernet started	○	–	OFF	–	–	H	R/W	OFF
*SM1192	Connection 25 for data exchange through Ethernet started	○	–	OFF	–	–	H	R/W	OFF
*SM1193	Connection 26 for data exchange through Ethernet started	○	–	OFF	–	–	H	R/W	OFF
*SM1194	Connection 27 for data exchange through Ethernet started	○	–	OFF	–	–	H	R/W	OFF
*SM1195	Connection 28 for data exchange through Ethernet started	○	–	OFF	–	–	H	R/W	OFF
*SM1196	Connection 29 for data exchange through Ethernet started	○	–	OFF	–	–	H	R/W	OFF
*SM1197	Connection 30 for data exchange through Ethernet started	○	–	OFF	–	–	H	R/W	OFF
*SM1198	Connection 31 for data exchange through Ethernet started	○	–	OFF	–	–	H	R/W	OFF
*SM1199	Connection 32 for data exchange through Ethernet started	○	–	OFF	–	–	H	R/W	OFF
*SM1200	Successful data exchange connection 1 through Ethernet	○	○	OFF	–	–	N	R	OFF
*SM1201	Successful data exchange connection 2 through Ethernet	○	○	OFF	–	–	N	R	OFF
*SM1202	Successful data exchange connection 3 through Ethernet	○	○	OFF	–	–	N	R	OFF
*SM1203	Successful data exchange connection 4 through Ethernet	○	○	OFF	–	–	N	R	OFF
*SM1204	Successful data exchange connection 5 through Ethernet	○	○	OFF	–	–	N	R	OFF
*SM1205	Successful data exchange connection 6 through Ethernet	○	○	OFF	–	–	N	R	OFF
*SM1206	Successful data exchange connection 7 through Ethernet	○	○	OFF	–	–	N	R	OFF
*SM1207	Successful data exchange connection 8 through Ethernet	○	○	OFF	–	–	N	R	OFF
*SM1208	Successful data exchange connection 9 through Ethernet	○	○	OFF	–	–	N	R	OFF
*SM1209	Successful data exchange connection 10 through Ethernet	○	○	OFF	–	–	N	R	OFF
*SM1210	Successful data exchange connection 11 through Ethernet	○	○	OFF	–	–	N	R	OFF
*SM1211	Successful data exchange connection 12 through Ethernet	○	○	OFF	–	–	N	R	OFF
*SM1212	Successful data exchange connection 13 through Ethernet	○	○	OFF	–	–	N	R	OFF

SM	Function			OFF ↓ ON	STOP ↓ RUN	RUN ↓ STOP	Latched	Attribute	Default
		AS300 Series	AS100/200 Series						
*SM1213	Successful data exchange connection 14 through Ethernet	○	○	OFF	–	–	N	R	OFF
*SM1214	Successful data exchange connection 15 through Ethernet	○	○	OFF	–	–	N	R	OFF
*SM1215	Successful data exchange connection 16 through Ethernet	○	○	OFF	–	–	N	R	OFF
*SM1216	Successful data exchange connection 17 through Ethernet	○	–	OFF	–	–	N	R	OFF
*SM1217	Successful data exchange connection 18 through Ethernet	○	–	OFF	–	–	N	R	OFF
*SM1218	Successful data exchange connection 19 through Ethernet	○	–	OFF	–	–	N	R	OFF
*SM1219	Successful data exchange connection 20 through Ethernet	○	–	OFF	–	–	N	R	OFF
*SM1220	Successful data exchange connection 21 through Ethernet	○	–	OFF	–	–	N	R	OFF
*SM1221	Successful data exchange connection 22 through Ethernet	○	–	OFF	–	–	N	R	OFF
*SM1222	Successful data exchange connection 23 through Ethernet	○	–	OFF	–	–	N	R	OFF
*SM1223	Successful data exchange connection 24 through Ethernet	○	–	OFF	–	–	N	R	OFF
*SM1224	Successful data exchange connection 25 through Ethernet	○	–	OFF	–	–	N	R	OFF
*SM1225	Successful data exchange connection 26 through Ethernet	○	–	OFF	–	–	N	R	OFF
*SM1226	Successful data exchange connection 27 through Ethernet	○	–	OFF	–	–	N	R	OFF
*SM1227	Successful data exchange connection 28 through Ethernet	○	–	OFF	–	–	N	R	OFF
*SM1228	Successful data exchange connection 29 through Ethernet	○	–	OFF	–	–	N	R	OFF
*SM1229	Successful data exchange connection 30 through Ethernet	○	–	OFF	–	–	N	R	OFF
*SM1230	Successful data exchange connection 31 through Ethernet	○	–	OFF	–	–	N	R	OFF
*SM1231	Successful data exchange connection 32 through Ethernet	○	–	OFF	–	–	N	R	OFF
*SM1232	Error in data exchange connection 1 through Ethernet	○	○	OFF	–	–	N	R	OFF
*SM1233	Error in data exchange connection 2 through Ethernet	○	○	OFF	–	–	N	R	OFF
*SM1234	Error in data exchange connection 3 through Ethernet	○	○	OFF	–	–	N	R	OFF
*SM1235	Error in data exchange connection 4 through Ethernet	○	○	OFF	–	–	N	R	OFF

SM	Function	AS300 Series	AS100/200 Series	OFF	STOP	RUN	Latched	Attribute	Default
				↓ ON	↓ RUN	↓ STOP			
*SM1236	Error in data exchange connection 5 through Ethernet	○	○	OFF	–	–	N	R	OFF
*SM1237	Error in data exchange connection 6 through Ethernet	○	○	OFF	–	–	N	R	OFF
*SM1238	Error in data exchange connection 7 through Ethernet	○	○	OFF	–	–	N	R	OFF
*SM1239	Error in data exchange connection 8 through Ethernet	○	○	OFF	–	–	N	R	OFF
*SM1240	Error in data exchange connection 9 through Ethernet	○	○	OFF	–	–	N	R	OFF
*SM1241	Error in data exchange connection 10 through Ethernet	○	○	OFF	–	–	N	R	OFF
*SM1242	Error in data exchange connection 11 through Ethernet	○	○	OFF	–	–	N	R	OFF
*SM1243	Error in data exchange connection 12 through Ethernet	○	○	OFF	–	–	N	R	OFF
*SM1244	Error in data exchange connection 13 through Ethernet	○	○	OFF	–	–	N	R	OFF
*SM1245	Error in data exchange connection 14 through Ethernet	○	○	OFF	–	–	N	R	OFF
*SM1246	Error in data exchange connection 15 through Ethernet	○	○	OFF	–	–	N	R	OFF
*SM1247	Error in data exchange connection 16 through Ethernet	○	○	OFF	–	–	N	R	OFF
*SM1248	Error in data exchange connection 17 through Ethernet	○	–	OFF	–	–	N	R	OFF
*SM1249	Error in data exchange connection 18 through Ethernet	○	–	OFF	–	–	N	R	OFF
*SM1250	Error in data exchange connection 19 through Ethernet	○	–	OFF	–	–	N	R	OFF
*SM1251	Error in data exchange connection 20 through Ethernet	○	–	OFF	–	–	N	R	OFF
*SM1252	Error in data exchange connection 21 through Ethernet	○	–	OFF	–	–	N	R	OFF
*SM1253	Error in data exchange connection 22 through Ethernet	○	–	OFF	–	–	N	R	OFF
*SM1254	Error in data exchange connection 23 through Ethernet	○	–	OFF	–	–	N	R	OFF
*SM1255	Error in data exchange connection 24 through Ethernet	○	–	OFF	–	–	N	R	OFF
*SM1256	Error in data exchange connection 25 through Ethernet	○	–	OFF	–	–	N	R	OFF
*SM1257	Error in data exchange connection 26 through Ethernet	○	–	OFF	–	–	N	R	OFF
*SM1258	Error in data exchange connection 27 through Ethernet	○	–	OFF	–	–	N	R	OFF

SM	Function			OFF ↓ ON	STOP ↓ RUN	RUN ↓ STOP	Latched	Attribute	Default
		AS300 Series	AS100/200 Series						
*SM1259	Error in data exchange connection 28 through Ethernet	○	—	OFF	—	—	N	R	OFF
*SM1260	Error in data exchange connection 29 through Ethernet	○	—	OFF	—	—	N	R	OFF
*SM1261	Error in data exchange connection 30 through Ethernet	○	—	OFF	—	—	N	R	OFF
*SM1262	Error in data exchange connection 31 through Ethernet	○	—	OFF	—	—	N	R	OFF
*SM1263	Error in data exchange connection 32 through Ethernet	○	—	OFF	—	—	N	R	OFF
SM1269	Socket configuration error	○	○	OFF	—	—	N	R/W	OFF
SM1270	Successful TCP socket 1 connection	○	○	OFF	—	—	N	R	OFF
SM1271	TCP socket 1 data received	○	○	OFF	—	—	N	R	OFF
SM1272	TCP socket 1 data sent	○	○	OFF	—	—	N	R	OFF
SM1273	TCP socket 1 connection starting	○	○	OFF	—	—	N	R	OFF
SM1274	TCP socket 1 connection closing	○	○	ON	—	—	Y	R	ON
SM1275	TCP socket 1 data is being sent	○	○	OFF	—	—	N	R	OFF
SM1277	TCP socket 1—Error flag	○	○	OFF	—	—	N	R	OFF
SM1278	Successful TCP socket 2 connection	○	○	OFF	—	—	N	R	OFF
SM1279	TCP socket 2 data received	○	○	OFF	—	—	N	R	OFF
SM1280	TCP socket 2 data sent	○	○	OFF	—	—	N	R	OFF
SM1281	TCP socket 2 connection starting	○	○	OFF	—	—	N	R	OFF
SM1282	TCP socket 2 connection closing	○	○	ON	—	—	Y	R	ON
SM1283	TCP socket 2 data is being sent	○	○	OFF	—	—	N	R	OFF
SM1285	TCP socket 2—Error flag	○	○	OFF	—	—	N	R	OFF
SM1286	Successful TCP socket 3 connection	○	○	OFF	—	—	N	R	OFF
SM1287	TCP socket 3 data received	○	○	OFF	—	—	N	R	OFF
SM1288	TCP socket 3 data sent	○	○	OFF	—	—	N	R	OFF
SM1289	TCP socket 3 connection starting	○	○	OFF	—	—	N	R	OFF
SM1290	TCP socket 3 connection closing	○	○	ON	—	—	Y	R	ON
SM1291	TCP socket 3 data is being sent.	○	○	OFF	—	—	N	R	OFF
SM1293	TCP socket 3—Error flag	○	○	OFF	—	—	N	R	OFF
SM1294	Successful TCP socket 4 connection	○	○	OFF	—	—	N	R	OFF
SM1295	TCP socket 4 data received	○	○	OFF	—	—	N	R	OFF
SM1296	TCP socket 4 data sent	○	○	OFF	—	—	N	R	OFF
SM1297	TCP socket 4 connection starting	○	○	OFF	—	—	N	R	OFF
SM1298	TCP socket 4 connection closing	○	○	ON	—	—	Y	R	ON
SM1299	TCP socket 4 data is being sent.	○	○	OFF	—	—	N	R	OFF
SM1301	TCP socket 4—Error flag	○	○	OFF	—	—	N	R	OFF
SM1312	RTU-EN01 connection 1 status (ON: connected; OFF: disconnected or not)	○	○	OFF	—	—	N	R	OFF

SM	Function	AS300 Series	AS100/200 Series	OFF	STOP	RUN	Latched	Attribute	Default
				↓ ON	↓ RUN	↓ STOP			
	connected)								
SM1313	RTU-EN01 connection 2 status	○	○	OFF	–	–	N	R	OFF
SM1314	RTU-EN01 connection 3 status	○	○	OFF	–	–	N	R	OFF
SM1315	RTU-EN01 connection 4 status	○	○	OFF	–	–	N	R	OFF
SM1334	UDP socket 1 connection started	○	○	OFF	–	–	N	R	OFF
SM1335	UDP socket 1 data receiving	○	○	OFF	–	–	N	R	OFF
SM1336	UDP socket 1 data sending	○	○	OFF	–	–	N	R	OFF
SM1337	UDP socket 1 connection closed	○	○	ON	–	–	Y	R	ON
SM1338	UDP socket 1—Error flag	○	○	OFF	–	–	N	R	OFF
SM1339	UDP socket 2 connection started	○	○	OFF	–	–	N	R	OFF
SM1340	UDP socket 2 data receiving	○	○	OFF	–	–	N	R	OFF
SM1341	UDP socket 2 data sending	○	○	OFF	–	–	N	R	OFF
SM1342	UDP socket 2 connection closed	○	○	ON	–	–	Y	R	ON
SM1343	UDP socket 2—Error flag	○	○	OFF	–	–	N	R	OFF
SM1344	UDP socket 3 connection started	○	○	OFF	–	–	N	R	OFF
SM1345	UDP socket 3 data receiving	○	○	OFF	–	–	N	R	OFF
SM1346	UDP socket 3 data sending	○	○	OFF	–	–	N	R	OFF
SM1347	UDP socket 3 connection closed	○	○	ON	–	–	Y	R	ON
SM1348	UDP socket 3—Error flag	○	○	OFF	–	–	N	R	OFF
SM1349	UDP socket 4 connection started	○	○	OFF	–	–	N	R	OFF
SM1350	UDP socket 4 data receiving	○	○	OFF	–	–	N	R	OFF
SM1351	UDP socket 4 data sending	○	○	OFF	–	–	N	R	OFF
SM1352	UDP socket 4 connection closed	○	○	ON	–	–	Y	R	ON
SM1353	UDP socket 4—Error flag	○	○	OFF	–	–	N	R	OFF
*SM1375	Data exchange through EtherNet/IP (Scanner) started.	○	○	OFF	–	–	H	R/W	OFF
*SM1376	Connection 1 for data exchange through EtherNet/IP (Scanner) started	○	○	OFF	–	–	H	R/W	OFF
*SM1377	Connection 2 for data exchange through EtherNet/IP (Scanner) started	○	○	OFF	–	–	H	R/W	OFF
*SM1378	Connection 3 for data exchange through EtherNet/IP (Scanner) started	○	○	OFF	–	–	H	R/W	OFF
*SM1379	Connection 4 for data exchange through EtherNet/IP (Scanner) started	○	○	OFF	–	–	H	R/W	OFF
*SM1380	Connection 5 for data exchange through EtherNet/IP (Scanner) started	○	○	OFF	–	–	H	R/W	OFF
*SM1381	Connection 6 for data exchange through EtherNet/IP (Scanner) started	○	○	OFF	–	–	H	R/W	OFF
*SM1382	Connection 7 for data exchange through EtherNet/IP (Scanner) started	○	○	OFF	–	–	H	R/W	OFF
*SM1383	Connection 8 for data exchange through EtherNet/IP (Scanner) started	○	○	OFF	–	–	H	R/W	OFF

SM	Function			OFF ↓ ON	STOP ↓ RUN	RUN ↓ STOP	Latched	Attribute	Default
		AS300 Series	AS100/200 Series						
*SM1384	Connection 9 for data exchange through EtherNet/IP (Scanner) started	○	○	OFF	–	–	H	R/W	OFF
*SM1385	Connection 10 for data exchange through EtherNet/IP (Scanner) started	○	○	OFF	–	–	H	R/W	OFF
*SM1386	Connection 11 for data exchange through EtherNet/IP (Scanner) started	○	○	OFF	–	–	H	R/W	OFF
*SM1387	Connection 12 for data exchange through EtherNet/IP (Scanner) started	○	○	OFF	–	–	H	R/W	OFF
*SM1388	Connection 13 for data exchange through EtherNet/IP (Scanner) started	○	○	OFF	–	–	H	R/W	OFF
*SM1389	Connection 14 for data exchange through EtherNet/IP (Scanner) started	○	○	OFF	–	–	H	R/W	OFF
*SM1390	Connection 15 for data exchange through EtherNet/IP (Scanner) started	○	○	OFF	–	–	H	R/W	OFF
*SM1391	Connection 16 for data exchange through EtherNet/IP (Scanner) started	○	○	OFF	–	–	H	R/W	OFF
*SM1392	Connection 17 for data exchange through EtherNet/IP (Scanner) started	○	–	OFF	–	–	H	R/W	OFF
*SM1393	Connection 18 for data exchange through EtherNet/IP (Scanner) started	○	–	OFF	–	–	H	R/W	OFF
*SM1394	Connection 19 for data exchange through EtherNet/IP (Scanner) started	○	–	OFF	–	–	H	R/W	OFF
*SM1395	Connection 20 for data exchange through EtherNet/IP (Scanner) started	○	–	OFF	–	–	H	R/W	OFF
*SM1396	Connection 21 for data exchange through EtherNet/IP (Scanner) started	○	–	OFF	–	–	H	R/W	OFF
*SM1397	Connection 22 for data exchange through EtherNet/IP (Scanner) started	○	–	OFF	–	–	H	R/W	OFF
*SM1398	Connection 23 for data exchange through EtherNet/IP (Scanner) started	○	–	OFF	–	–	H	R/W	OFF
*SM1399	Connection 24 for data exchange through EtherNet/IP (Scanner) started	○	–	OFF	–	–	H	R/W	OFF
*SM1400	Connection 25 for data exchange through EtherNet/IP (Scanner) started	○	–	OFF	–	–	H	R/W	OFF
*SM1401	Connection 26 for data exchange through EtherNet/IP (Scanner) started	○	–	OFF	–	–	H	R/W	OFF
*SM1402	Connection 27 for data exchange through EtherNet/IP (Scanner) started	○	–	OFF	–	–	H	R/W	OFF
*SM1403	Connection 28 for data exchange through EtherNet/IP (Scanner) started	○	–	OFF	–	–	H	R/W	OFF
*SM1404	Connection 29 for data exchange through EtherNet/IP (Scanner) started	○	–	OFF	–	–	H	R/W	OFF
*SM1405	Connection 30 for data exchange through EtherNet/IP (Scanner) started	○	–	OFF	–	–	H	R/W	OFF
*SM1406	Connection 31 for data exchange through EtherNet/IP (Scanner) started	○	–	OFF	–	–	H	R/W	OFF

SM	Function	AS300 Series	AS100/200 Series	OFF	STOP	RUN	Latched	Attribute	Default
				↓ ON	↓ RUN	↓ STOP			
*SM1407	Connection 32 for data exchange through EtherNet/IP (Scanner) started	○	–	OFF	–	–	H	R/W	OFF
*SM1408	Error in data exchange connection 1 through EtherNet/IP (Scanner)	○	○	OFF	–	–	N	R	OFF
*SM1409	Error in data exchange connection 2 through EtherNet/IP (Scanner)	○	○	OFF	–	–	N	R	OFF
*SM1410	Error in data exchange connection 3 through EtherNet/IP (Scanner)	○	○	OFF	–	–	N	R	OFF
*SM1411	Error in data exchange connection 4 through EtherNet/IP (Scanner)	○	○	OFF	–	–	N	R	OFF
*SM1412	Error in data exchange connection 5 through EtherNet/IP (Scanner)	○	○	OFF	–	–	N	R	OFF
*SM1413	Error in data exchange connection 6 through EtherNet/IP (Scanner)	○	○	OFF	–	–	N	R	OFF
*SM1414	Error in data exchange connection 7 through EtherNet/IP (Scanner)	○	○	OFF	–	–	N	R	OFF
*SM1415	Error in data exchange connection 8 through EtherNet/IP (Scanner)	○	○	OFF	–	–	N	R	OFF
*SM1416	Error in data exchange connection 9 through EtherNet/IP (Scanner)	○	○	OFF	–	–	N	R	OFF
*SM1417	Error in data exchange connection 10 through EtherNet/IP (Scanner)	○	○	OFF	–	–	N	R	OFF
*SM1418	Error in data exchange connection 11 through EtherNet/IP (Scanner)	○	○	OFF	–	–	N	R	OFF
*SM1419	Error in data exchange connection 12 through EtherNet/IP (Scanner)	○	○	OFF	–	–	N	R	OFF
*SM1420	Error in data exchange connection 13 through EtherNet/IP (Scanner)	○	○	OFF	–	–	N	R	OFF
*SM1421	Error in data exchange connection 14 through EtherNet/IP (Scanner)	○	○	OFF	–	–	N	R	OFF
*SM1422	Error in data exchange connection 15 through EtherNet/IP (Scanner)	○	○	OFF	–	–	N	R	OFF
*SM1423	Error in data exchange connection 16 through EtherNet/IP (Scanner)	○	○	OFF	–	–	N	R	OFF
*SM1424	Error in data exchange connection 17 through EtherNet/IP (Scanner)	○	–	OFF	–	–	N	R	OFF
*SM1425	Error in data exchange connection 18 through EtherNet/IP (Scanner)	○	–	OFF	–	–	N	R	OFF
*SM1426	Error in data exchange connection 19 through EtherNet/IP (Scanner)	○	–	OFF	–	–	N	R	OFF
*SM1427	Error in data exchange connection 20 through EtherNet/IP (Scanner)	○	–	OFF	–	–	N	R	OFF
*SM1428	Error in data exchange connection 21 through EtherNet/IP (Scanner)	○	–	OFF	–	–	N	R	OFF
*SM1429	Error in data exchange connection 22 through EtherNet/IP (Scanner)	○	–	OFF	–	–	N	R	OFF

SM	Function			OFF ↓ ON	STOP ↓ RUN	RUN ↓ STOP	Latched	Attribute	Default
		AS300 Series	AS100/200 Series						
*SM1430	Error in data exchange connection 23 through EtherNet/IP (Scanner)	○	–	OFF	–	–	N	R	OFF
*SM1431	Error in data exchange connection 24 through EtherNet/IP (Scanner)	○	–	OFF	–	–	N	R	OFF
*SM1432	Error in data exchange connection 25 through EtherNet/IP (Scanner)	○	–	OFF	–	–	N	R	OFF
*SM1433	Error in data exchange connection 26 through EtherNet/IP (Scanner)	○	–	OFF	–	–	N	R	OFF
*SM1434	Error in data exchange connection 27 through EtherNet/IP (Scanner)	○	–	OFF	–	–	N	R	OFF
*SM1435	Error in data exchange connection 28 through EtherNet/IP (Scanner)	○	–	OFF	–	–	N	R	OFF
*SM1436	Error in data exchange connection 29 through EtherNet/IP (Scanner)	○	–	OFF	–	–	N	R	OFF
*SM1437	Error in data exchange connection 30 through EtherNet/IP (Scanner)	○	–	OFF	–	–	N	R	OFF
*SM1438	Error in data exchange connection 31 through EtherNet/IP (Scanner)	○	–	OFF	–	–	N	R	OFF
*SM1439	Error in data exchange connection 32 through EtherNet/IP (Scanner)	○	–	OFF	–	–	N	R	OFF
*SM1440	Error in I/O connection 1 through EtherNet/IP (Adapter)	○	○	OFF	–	–	N	R	OFF
*SM1441	Error in I/O connection 2 through EtherNet/IP (Adapter)	○	○	OFF	–	–	N	R	OFF
*SM1442	Error in I/O connection 3 through EtherNet/IP (Adapter)	○	○	OFF	–	–	N	R	OFF
*SM1443	Error in I/O connection 4 through EtherNet/IP (Adapter)	○	○	OFF	–	–	N	R	OFF
*SM1444	Error in I/O connection 5 through EtherNet/IP (Adapter)	○	○	OFF	–	–	N	R	OFF
*SM1445	Error in I/O connection 6 through EtherNet/IP (Adapter)	○	○	OFF	–	–	N	R	OFF
*SM1446	Error in I/O connection 7 through EtherNet/IP (Adapter)	○	○	OFF	–	–	N	R	OFF
*SM1447	Error in I/O connection 8 through EtherNet/IP (Adapter)	○	○	OFF	–	–	N	R	OFF
*SM1448	I/O connection 1 is established through EtherNet/IP (Adapter)	○	○	OFF	–	–	N	R	OFF
*SM1449	I/O connection 2 is established through EtherNet/IP (Adapter)	○	○	OFF	–	–	N	R	OFF
*SM1450	I/O connection 3 is established through EtherNet/IP (Adapter)	○	○	OFF	–	–	N	R	OFF
*SM1451	I/O connection 4 is established through EtherNet/IP (Adapter)	○	○	OFF	–	–	N	R	OFF

SM	Function	AS300 Series	AS100/200 Series	OFF	STOP	RUN	Latched	Attribute	Default
				↓ ON	↓ RUN	↓ STOP			
*SM1452	I/O connection 5 is established through EtherNet/IP (Adapter)	○	○	OFF	–	–	N	R	OFF
*SM1453	I/O connection 6 is established through EtherNet/IP (Adapter)	○	○	OFF	–	–	N	R	OFF
*SM1454	I/O connection 7 is established through EtherNet/IP (Adapter)	○	○	OFF	–	–	N	R	OFF
*SM1455	I/O connection 8 is established through EtherNet/IP (Adapter)	○	○	OFF	–	–	N	R	OFF
SM1581	Auto-reset the control over CAN communication ID 1 of Delta servo	○	○	OFF	OFF	–	N	R/W	OFF
	Auto-reset the control over ECAT communication ID 1 of Delta servo/inverter	○	–	OFF	OFF	–	N	R/W	OFF
SM1582	Auto-reset the control over CAN communication ID 2 of Delta servo	○	○	OFF	OFF	–	N	R/W	OFF
	Auto-reset the control over ECAT communication ID 2 of Delta servo/inverter	○	–	OFF	OFF	–	N	R/W	OFF
SM1583	Auto-reset the control over CAN communication ID 3 of Delta servo	○	○	OFF	OFF	–	N	R/W	OFF
	Auto-reset the control over ECAT communication ID 3 of Delta servo/inverter	○	–	OFF	OFF	–	N	R/W	OFF
SM1584	Auto-reset the control over CAN communication ID 4 of Delta servo	○	○	OFF	OFF	–	N	R/W	OFF
	Auto-reset the control over ECAT communication ID 4 of Delta servo/inverter	○	–	OFF	OFF	–	N	R/W	OFF
SM1585	Auto-reset the control over CAN communication ID 5 of Delta servo	○	○	OFF	OFF	–	N	R/W	OFF
	Auto-reset the control over ECAT communication ID 5 of Delta servo/inverter	○	–	OFF	OFF	–	N	R/W	OFF
SM1586	Auto-reset the control over CAN communication ID 6 of Delta servo	○	○	OFF	OFF	–	N	R/W	OFF
	Auto-reset the control over ECAT communication ID 6 of Delta servo/inverter	○	–	OFF	OFF	–	N	R/W	OFF
SM1587	Auto-reset the control over CAN communication ID 7 of Delta servo	○	○	OFF	OFF	–	N	R/W	OFF
	Auto-reset the control over ECAT communication ID 7 of Delta servo/inverter	○	–	OFF	OFF	–	N	R/W	OFF
SM1588	Auto-reset the control over CAN communication ID 8 of Delta servo	○	○	OFF	OFF	–	N	R/W	OFF
	Auto-reset the control over ECAT communication ID 8 of Delta servo/inverter	○	–	OFF	OFF	–	N	R/W	OFF
SM1601	Auto-reset the control over CAN communication ID 21 of Delta servo	○	○	OFF	OFF	–	N	R/W	OFF
	Auto-reset the control over ECAT communication ID 9 of Delta servo/inverter	○	–	OFF	OFF	–	N	R/W	OFF

SM	Function			OFF ↓ ON	STOP ↓ RUN	RUN ↓ STOP	Latched	Attribute	Default
		AS300 Series	AS100/200 Series						
SM1602	Auto-reset the control over CAN communication ID 22 of Delta servo	○	○	OFF	OFF	–	N	R/W	OFF
	Auto-reset the control over ECAT communication ID 10 of Delta servo/inverter	○	–	OFF	OFF	–	N	R/W	OFF
SM1603	Auto-reset the control over CAN communication ID 23 of Delta servo	○	○	OFF	OFF	–	N	R/W	OFF
	Auto-reset the control over ECAT communication ID 11 of Delta servo/inverter	○	–	OFF	OFF	–	N	R/W	OFF
SM1604	Auto-reset the control over CAN communication ID 24 of Delta servo	○	○	OFF	OFF	–	N	R/W	OFF
	Auto-reset the control over ECAT communication ID 12 of Delta servo/inverter	○	–	OFF	OFF	–	N	R/W	OFF
SM1605	Auto-reset the control over CAN communication ID 25 of Delta servo	○	○	OFF	OFF	–	N	R/W	OFF
	Auto-reset the control over ECAT communication ID 13 of Delta servo/inverter	○	–	OFF	OFF	–	N	R/W	OFF
SM1606	Auto-reset the control over CAN communication ID 26 of Delta servo	○	○	OFF	OFF	–	N	R/W	OFF
	Auto-reset the control over ECAT communication ID 14 of Delta servo/inverter	○	–	OFF	OFF	–	N	R/W	OFF
SM1607	Auto-reset the control over CAN communication ID 27 of Delta servo	○	○	OFF	OFF	–	N	R/W	OFF
	Auto-reset the control over ECAT communication ID 15 of Delta servo/inverter	○	–	OFF	OFF	–	N	R/W	OFF
SM1608	Auto-reset the control over CAN communication ID 28 of Delta servo.	○	○	OFF	OFF	–	N	R/W	OFF
	Auto-reset the control over ECAT communication ID 16 of Delta servo/inverter	○	–	OFF	OFF	–	N	R/W	OFF
SM1611	Heartbeat error on CAN communication ID 21 of Delta inverter	○	○	OFF	OFF	–	N	R	OFF
	Connection lost on ECAT communication ID 9 of Delta servo/inverter	○	–	OFF	OFF	–	N	R	OFF
SM1612	Heartbeat error on CAN communication ID 22 of Delta inverter	○	○	OFF	OFF	–	N	R	OFF
	Connection lost on ECAT communication ID 10 of Delta servo/inverter	○	–	OFF	OFF	–	N	R	OFF
SM1613	Heartbeat error on CAN communication ID 23 of Delta inverter	○	○	OFF	OFF	–	N	R	OFF
	Connection lost on ECAT communication ID 11 of Delta servo/inverter	○	–	OFF	OFF	–	N	R	OFF
SM1614	Heartbeat error on CAN communication ID 24 of Delta inverter	○	○	OFF	OFF	–	N	R	OFF
	Connection lost on ECAT communication ID 12 of Delta servo/inverter	○	–	OFF	OFF	–	N	R	OFF

SM	Function	AS300 Series	AS100/200 Series	OFF	STOP	RUN	Latched	Attribute	Default
				↓ ON	↓ RUN	↓ STOP			
SM1615	Heartbeat error on CAN communication ID 25 of Delta inverter	○	○	OFF	OFF	–	N	R	OFF
	Connection lost on ECAT communication ID 13 of Delta servo/inverter	○	–	OFF	OFF	–	N	R	OFF
SM1616	Heartbeat error on CAN communication ID 26 of Delta inverter	○	○	OFF	OFF	–	N	R	OFF
	Connection lost on ECAT communication ID 14 of Delta servo/inverter	○	–	OFF	OFF	–	N	R	OFF
SM1617	Heartbeat error on CAN communication ID 27 of Delta inverter	○	○	OFF	OFF	–	N	R	OFF
	Connection lost on ECAT communication ID 15 of Delta servo/inverter	○	–	OFF	OFF	–	N	R	OFF
SM1618	Heartbeat error on CAN communication ID 28 of Delta inverter	○	○	OFF	OFF	–	N	R	OFF
	Connection lost on ECAT communication ID 16 of Delta servo/inverter	○	–	OFF	OFF	–	N	R	OFF
SM1621	CAN communication ID 21 of Delta inverter is starting.	○	○	OFF	OFF	–	N	R	OFF
	ECAT communication ID 9 of Delta servo/inverter inverter is starting.	○	–	OFF	OFF	–	N	R	OFF
SM1622	CAN communication ID 22 of Delta inverter is starting.	○	○	OFF	OFF	–	N	R	OFF
	ECAT communication ID 10 of Delta servo/inverter inverter is starting.	○	–	OFF	OFF	–	N	R	OFF
SM1623	CAN communication ID 23 of Delta inverter is starting.	○	○	OFF	OFF	–	N	R	OFF
	ECAT communication ID 11 of Delta servo/inverter inverter is starting.	○	–	OFF	OFF	–	N	R	OFF
SM1624	CAN communication ID 24 of Delta inverter is starting.	○	○	OFF	OFF	–	N	R	OFF
	ECAT communication ID 12 of Delta servo/inverter inverter is starting.	○	–	OFF	OFF	–	N	R	OFF
SM1625	CAN communication ID 25 of Delta inverter is starting.	○	○	OFF	OFF	–	N	R	OFF
	ECAT communication ID 13 of Delta servo/inverter inverter is starting.	○	–	OFF	OFF	–	N	R	OFF
SM1626	CAN communication ID 26 of Delta inverter is starting.	○	○	OFF	OFF	–	N	R	OFF
	ECAT communication ID 14 of Delta servo/inverter inverter is starting.	○	–	OFF	OFF	–	N	R	OFF
SM1627	CAN communication ID 27 of Delta inverter is starting.	○	○	OFF	OFF	–	N	R	OFF
	ECAT communication ID 15 of Delta servo/inverter inverter is starting.	○	–	OFF	OFF	–	N	R	OFF

SM	Function			OFF ↓ ON	STOP ↓ RUN	RUN ↓ STOP	Latched	Attribute	Default
		AS300 Series	AS100/200 Series						
SM1628	CAN communication ID 28 of Delta inverter is starting.	○	○	OFF	OFF	–	N	R	OFF
	ECAT communication ID 16 of Delta servo/inverter inverter is starting.	○	–	OFF	OFF	–	N	R	OFF
SM1631	Positioning completed on CAN communication ID 1 of Delta servo	○	○	OFF	OFF	–	N	R/W	OFF
	Positioning completed on ECAT communication ID 1 of Delta servo	○	–	OFF	OFF	–	N	R	OFF
SM1632	Positioning completed on CAN communication ID 2 of Delta servo	○	○	OFF	OFF	–	N	R/W	OFF
	Positioning completed on ECAT communication ID 2 of Delta servo	○	–	OFF	OFF	–	N	R/W	OFF
SM1633	Positioning completed on CAN communication ID 3 of Delta servo	○	○	OFF	OFF	–	N	R/W	OFF
	Positioning completed on ECAT communication ID 3 of Delta servo	○	–	OFF	OFF	–	N	R/W	OFF
SM1634	Positioning completed on CAN communication ID 4 of Delta servo	○	○	OFF	OFF	–	N	R/W	OFF
	Positioning completed on ECAT communication ID 4 of Delta servo	○	–	OFF	OFF	–	N	R/W	OFF
SM1635	Positioning completed on CAN communication ID 5 of Delta servo	○	○	OFF	OFF	–	N	R/W	OFF
	Positioning completed on ECAT communication ID 5 of Delta servo	○	–	OFF	OFF	–	N	R/W	OFF
SM1636	Positioning completed on CAN communication ID 5 of Delta servo	○	○	OFF	OFF	–	N	R/W	OFF
	Positioning completed on ECAT communication ID 6 of Delta servo	○	–	OFF	OFF	–	N	R/W	OFF
SM1637	Positioning completed on CAN communication ID 7 of Delta servo	○	○	OFF	OFF	–	N	R/W	OFF
	Positioning completed on ECAT communication ID 7 of Delta servo	○	–	OFF	OFF	–	N	R/W	OFF
SM1638	Positioning completed on CAN communication ID 8 of Delta servo	○	○	OFF	OFF	–	N	R/W	OFF
	Positioning completed on ECAT communication ID 8 of Delta servo	○	–	OFF	OFF	–	N	R/W	OFF
SM1641	Communication stops on CAN communication ID 1 of Delta servo	○	○	OFF	OFF	–	N	R/W	OFF
	Communication stops on ECAT communication ID 1 of Delta servo	○	–	OFF	OFF	–	N	R/W	OFF
SM1642	Communication stops on CAN communication ID 2 of Delta servo	○	○	OFF	OFF	–	N	R/W	OFF
	Communication stops on ECAT communication ID 2 of Delta servo	○	–	OFF	OFF	–	N	R/W	OFF
SM1643	Communication stops on CAN communication ID 3 of Delta servo	○	○	OFF	OFF	–	N	R/W	OFF

SM	Function	AS300 Series	AS100/200 Series	OFF ↓ ON	STOP ↓ RUN	RUN ↓ STOP	Latched	Attribute	Default
	Communication stops on ECAT communication ID 3 of Delta servo	○	–	OFF	OFF	–	N	R/W	OFF
SM1644	Communication stops on CAN communication ID 4 of Delta servo	○	○	OFF	OFF	–	N	R/W	OFF
	Communication stops on ECAT communication ID 4 of Delta servo	○	–	OFF	OFF	–	N	R/W	OFF
SM1645	Communication stops on CAN communication ID 5 of Delta servo	○	○	OFF	OFF	–	N	R/W	OFF
	Communication stops on ECAT communication ID 5 of Delta servo	○	–	OFF	OFF	–	N	R/W	OFF
SM1646	Communication stops on CAN communication ID 6 of Delta servo	○	○	OFF	OFF	–	N	R/W	OFF
	Communication stops on ECAT communication ID 6 of Delta servo	○	–	OFF	OFF	–	N	R/W	OFF
SM1647	Communication stops on CAN communication ID 7 of Delta servo	○	○	OFF	OFF	–	N	R/W	OFF
	Communication stops on ECAT communication ID 7 of Delta servo	○	–	OFF	OFF	–	N	R/W	OFF
SM1648	Communication stops on CAN communication ID 8 of Delta servo	○	○	OFF	OFF	–	N	R/W	OFF
	Communication stops on ECAT communication ID 8 of Delta servo	○	–	OFF	OFF	–	N	R/W	OFF
SM1651	CAN communication ID 1 of Delta servo is starting.	○	○	OFF	OFF	–	N	R	OFF
	ECAT communication ID 1 of Delta servo/inverter is starting.	○	–	OFF	OFF	–	N	R	OFF
SM1652	CAN communication ID 2 of Delta servo is starting.	○	○	OFF	OFF	–	N	R	OFF
	ECAT communication ID 2 of Delta servo/inverter is starting.	○	–	OFF	OFF	–	N	R	OFF
SM1653	CAN communication ID 3 of Delta servo is starting.	○	○	OFF	OFF	–	N	R	OFF
	ECAT communication ID 3 of Delta servo/inverter is starting.	○	–	OFF	OFF	–	N	R	OFF
SM1654	CAN communication ID 4 of Delta servo is starting.	○	○	OFF	OFF	–	N	R	OFF
	ECAT communication ID 4 of Delta servo/inverter is starting.	○	–	OFF	OFF	–	N	R	OFF
SM1655	CAN communication ID 5 of Delta servo is starting.	○	○	OFF	OFF	–	N	R	OFF
	ECAT communication ID 5 of Delta servo/inverter is starting.	○	–	OFF	OFF	–	N	R	OFF
SM1656	CAN communication ID 6 of Delta servo is starting.	○	○	OFF	OFF	–	N	R	OFF
	ECAT communication ID 6 of Delta servo/inverter inverter is starting.	○	–	OFF	OFF	–	N	R	OFF
SM1657	CAN communication ID 7 of Delta servo is starting.	○	○	OFF	OFF	–	N	R	OFF
	ECAT communication ID 7 of Delta servo/inverter is starting.	○	–	OFF	OFF	–	N	R	OFF
SM1658	CAN communication ID 8 of Delta servo is starting.	○	○	OFF	OFF	–	N	R	OFF

SM	Function			OFF ↓ ON	STOP ↓ RUN	RUN ↓ STOP	Latched	Attribute	Default
		AS300 Series	AS100/200 Series						
	ECAT communication ID 8 of Delta servo/inverter is starting.	○	–	OFF	OFF	–	N	R	OFF
SM1661	The function of going back and forth is enabled on CAN communication ID 1 of Delta servo.	○	○	OFF	OFF	–	N	R/W	OFF
	The function of going back and forth is enabled on ECAT communication ID 1 of Delta servo.	○	–	OFF	OFF	–	N	R/W	OFF
SM1662	The function of going back and forth is enabled on CAN communication ID 2 of Delta servo.	○	○	OFF	OFF	–	N	R/W	OFF
	The function of going back and forth is enabled on ECAT communication ID 2 of Delta servo.	○	–	OFF	OFF	–	N	R/W	OFF
SM1663	The function of going back and forth is enabled on CAN communication ID 3 of Delta servo.	○	○	OFF	OFF	–	N	R/W	OFF
	The function of going back and forth is enabled on ECAT communication ID 3 of Delta servo.	○	–	OFF	OFF	–	N	R/W	OFF
SM1664	The function of going back and forth is enabled on CAN communication ID 4 of Delta servo.	○	○	OFF	OFF	–	N	R/W	OFF
	The function of going back and forth is enabled on ECAT communication ID 4 of Delta servo.	○	–	OFF	OFF	–	N	R/W	OFF
SM1665	The function of going back and forth is enabled on CAN communication ID 5 of Delta servo.	○	○	OFF	OFF	–	N	R/W	OFF
	The function of going back and forth is enabled on ECAT communication ID 5 of Delta servo.	○	–	OFF	OFF	–	N	R/W	OFF
SM1666	The function of going back and forth is enabled on CAN communication ID 6 of Delta servo.	○	○	OFF	OFF	–	N	R/W	OFF
	The function of going back and forth is enabled on ECAT communication ID 6 of Delta servo.	○	–	OFF	OFF	–	N	R/W	OFF
SM1667	The function of going back and forth is enabled on CAN communication ID 7 of Delta servo.	○	○	OFF	OFF	–	N	R/W	OFF
	The function of going back and forth is enabled on ECAT communication ID 7 of Delta servo.	○	–	OFF	OFF	–	N	R/W	OFF
SM1668	The function of going back and forth is enabled on CAN communication ID 8 of Delta servo.	○	○	OFF	OFF	–	N	R/W	OFF
	The function of going back and forth is enabled on ECAT communication ID 8 of Delta servo.	○	–	OFF	OFF	–	N	R/W	OFF
SM1671	The go-back/go-forth direction indication flag on CAN communication ID 1 of Delta servo.	○	○	OFF	OFF	–	N	R	OFF
	The go-back/go-forth direction indication flag on ECAT communication ID 1 of Delta servo.	○	–	OFF	OFF	–	N	R	OFF
SM1672	The go-back/go-forth direction indication flag on CAN communication ID 2 of Delta servo.	○	○	OFF	OFF	–	N	R	OFF
	The go-back/go-forth direction indication flag on ECAT communication ID 2 of Delta servo.	○	–	OFF	OFF	–	N	R	OFF
SM1673	The go-back/go-forth direction indication flag on CAN communication ID 3 of Delta servo.	○	○	OFF	OFF	–	N	R	OFF
	The go-back/go-forth direction indication flag on ECAT communication ID 3 of Delta servo.	○	–	OFF	OFF	–	N	R	OFF

SM	Function	AS300 Series	AS100/200 Series	OFF	STOP	RUN	Latched	Attribute	Default
				↓ ON	↓ RUN	↓ STOP			
SM1674	The go-back/go-forth direction indication flag on CAN communication ID 4 of Delta servo.	○	○	OFF	OFF	–	N	R	OFF
	The go-back/go-forth direction indication flag on ECAT communication ID 4 of Delta servo.	○	–	OFF	OFF	–	N	R	OFF
SM1675	The go-back/go-forth direction indication flag on CAN communication ID 5 of Delta servo.	○	○	OFF	OFF	–	N	R	OFF
	The go-back/go-forth direction indication flag on ECAT communication ID 5 of Delta servo.	○	–	OFF	OFF	–	N	R	OFF
SM1676	The go-back/go-forth direction indication flag on CAN communication ID 6 of Delta servo.	○	○	OFF	OFF	–	N	R	OFF
	The go-back/go-forth direction indication flag on ECAT communication ID 6 of Delta servo.	○	–	OFF	OFF	–	N	R	OFF
SM1677	The go-back/go-forth direction indication flag on CAN communication ID 7 of Delta servo.	○	○	OFF	OFF	–	N	R	OFF
	The go-back/go-forth direction indication flag on ECAT communication ID 7 of Delta servo.	○	–	OFF	OFF	–	N	R	OFF
SM1678	The go-back/go-forth direction indication flag on CAN communication ID 8 of Delta servo.	○	○	OFF	OFF	–	N	R	OFF
	The go-back/go-forth direction indication flag on ECAT communication ID 8 of Delta servo.	○	–	OFF	OFF	–	N	R	OFF
SM1681	Instrucion INITC/CASD completion flag on CAN communication of Delta servo	○	○	OFF	OFF	–	N	R/W	OFF
	Instrucion CASD completion flag on ECAT communication of Delta servo/inverter	○	–	OFF	OFF	–	N	R/W	OFF
SM1682	The CAN communication error flag for Delta servo/inverter	○	○	OFF	OFF	–	N	R/W	OFF
	The ECAT communication error flag for Delta servo/inverter	○	–	OFF	OFF	–	N	R/W	OFF
SM1683	Instrucion INITC/CASD completion flag on CAN communication of Delta inverter	○	○	OFF	OFF	–	N	R/W	OFF
SM1684	To set the action for CAN communication of Delta servo/inverter, when a connection is lost: OFF: stops all the communications ON: stops only the lost-connection one	○	○	OFF	OFF	–	N	R/W	OFF
	To set the action for ECAT communication of Delta servo/inverter, when a connection is lost: OFF: stops all the communications ON: stops only the lost-connection one	○	–	OFF	OFF	–	N	R/W	OFF
SM1685	To read the self-defined Delta servo parameters P0-12	○	○	OFF	OFF	–	N	R/W	OFF
SM1686	OFF: initialize a consecutive number of modules ON: initialize a specific module	○	○	OFF	OFF	–	N	R/W	OFF
SM1691	Heartbeat error on CAN communication ID 1 of Delta servo	○	○	OFF	OFF	–	N	R/W	OFF

SM	Function			OFF ↓ ON	STOP ↓ RUN	RUN ↓ STOP	Latched	Attribute	Default
		AS300 Series	AS100/200 Series						
	Connection lost on ECAT communication ID 1 of Delta servo/inverter	○	–	OFF	OFF	–	N	R/W	OFF
SM1692	Heartbeat error on CAN communication ID 2 of Delta servo	○	○	OFF	OFF	–	N	R/W	OFF
	Connection lost on ECAT communication ID 2 of Delta servo/inverter	○	–	OFF	OFF	–	N	R/W	OFF
SM1693	Heartbeat error on CAN communication ID 3 of Delta servo	○	○	OFF	OFF	–	N	R/W	OFF
	Connection lost on ECAT communication ID 3 of Delta servo/inverter	○	–	OFF	OFF	–	N	R/W	OFF
SM1694	Heartbeat error on CAN communication ID 4 of Delta servo	○	○	OFF	OFF	–	N	R/W	OFF
	Connection lost on ECAT communication ID 4 of Delta servo/inverter	○	–	OFF	OFF	–	N	R/W	OFF
SM1695	Heartbeat error on CAN communication ID 5 of Delta servo	○	○	OFF	OFF	–	N	R/W	OFF
	Connection lost on ECAT communication ID 5 of Delta servo/inverter	○	–	OFF	OFF	–	N	R/W	OFF
SM1696	Heartbeat error on CAN communication ID 6 of Delta servo	○	○	OFF	OFF	–	N	R/W	OFF
	Connection lost on ECAT communication ID 6 of Delta servo/inverter	○	–	OFF	OFF	–	N	R/W	OFF
SM1697	Heartbeat error on CAN communication ID 7 of Delta servo	○	○	OFF	OFF	–	N	R/W	OFF
	Connection lost on ECAT communication ID 7 of Delta servo/inverter	○	–	OFF	OFF	–	N	R/W	OFF
SM1698	Heartbeat error on CAN communication ID 8 of Delta servo	○	○	OFF	OFF	–	N	R/W	OFF
	Connection lost on ECAT communication ID 8 of Delta servo/inverter	○	–	OFF	OFF	–	N	R/W	OFF
*SM1700	Flag to activate the backlash compensation at Y0.0/Y0.1 for CSFO instruction	○	○	OFF	OFF	–	N	R/W	OFF
*SM1701	Flag to activate the backlash compensation at Y0.2/Y0.3 for CSFO instruction	○	○	OFF	OFF	–	N	R/W	OFF
*SM1702	Flag to activate the backlash compensation at Y0.4/Y0.5 for CSFO instruction	○	○	OFF	OFF	–	N	R/W	OFF
*SM1703	Flag to activate the backlash compensation at Y0.6/Y0.7 for CSFO instruction	○	○	OFF	OFF	–	N	R/W	OFF
*SM1704	Flag to activate the backlash compensation at Y0.8/Y0.9 for CSFO instruction	○	○	OFF	OFF	–	N	R/W	OFF
*SM1705	Flag to activate the backlash compensation at Y0.10/Y0.11 for CSFO instruction	○	○	OFF	OFF	–	N	R/W	OFF
* SM1709	Error in the initialization of the data exchange through Function Card 1	○	–	OFF	–	–	N	R/W	OFF

SM	Function	AS300 Series	AS100/200 Series	OFF	STOP	RUN	Latched	Attribute	Default
				↓ ON	↓ RUN	↓ STOP			
* SM1710	Data exchange through Function Card 1 enabled by ISPSOft	○	–	OFF	–	OFF	N	R/W	OFF
* SM1712	Connection 1 for data exchange through Function Card 1 started	○	–	OFF	–	–	N	R/W	OFF
* SM1713	Connection 2 for data exchange through Function Card 1 started	○	–	OFF	–	–	N	R/W	OFF
* SM1714	Connection 3 for data exchange through Function Card 1 started	○	–	OFF	–	–	N	R/W	OFF
* SM1715	Connection 4 for data exchange through Function Card 1 started	○	–	OFF	–	–	N	R/W	OFF
* SM1716	Connection 5 for data exchange through Function Card 1 started	○	–	OFF	–	–	N	R/W	OFF
* SM1717	Connection 6 for data exchange through Function Card 1 started	○	–	OFF	–	–	N	R/W	OFF
* SM1718	Connection 7 for data exchange through Function Card 1 started	○	–	OFF	–	–	N	R/W	OFF
* SM1719	Connection 8 for data exchange through Function Card 1 started	○	–	OFF	–	–	N	R/W	OFF
* SM1720	Connection 9 for data exchange through Function Card 1 started	○	–	OFF	–	–	N	R/W	OFF
* SM1721	Connection 10 for data exchange through Function Card 1 started	○	–	OFF	–	–	N	R/W	OFF
* SM1722	Connection 11 for data exchange through Function Card 1 started	○	–	OFF	–	–	N	R/W	OFF
* SM1723	Connection 12 for data exchange through Function Card 1 started	○	–	OFF	–	–	N	R/W	OFF
* SM1724	Connection 13 for data exchange through Function Card 1 started	○	–	OFF	–	–	N	R/W	OFF
* SM1725	Connection 14 for data exchange through Function Card 1 started	○	–	OFF	–	–	N	R/W	OFF
* SM1726	Connection 15 for data exchange through Function Card 1 started	○	–	OFF	–	–	N	R/W	OFF
* SM1727	Connection 16 for data exchange through Function Card 1 started	○	–	OFF	–	–	N	R/W	OFF
* SM1728	Connection 17 for data exchange through Function Card 1 started	○	–	OFF	–	–	N	R/W	OFF
* SM1729	Connection 18 for data exchange through Function Card 1 started	○	–	OFF	–	–	N	R/W	OFF
* SM1730	Connection 19 for data exchange through Function Card 1 started	○	–	OFF	–	–	N	R/W	OFF
* SM1731	Connection 20 for data exchange through Function Card 1 started	○	–	OFF	–	–	N	R/W	OFF
* SM1732	Connection 21 for data exchange through Function Card 1 started	○	–	OFF	–	–	N	R/W	OFF
* SM1733	Connection 22 for data exchange through Function Card 1 started	○	–	OFF	–	–	N	R/W	OFF

SM	Function			OFF ↓ ON	STOP ↓ RUN	RUN ↓ STOP	Latched	Attribute	Default
		AS300 Series	AS100/200 Series						
* SM1734	Connection 23 for data exchange through Function Card 1 started	○	–	OFF	–	–	N	R/W	OFF
* SM1735	Connection 24 for data exchange through Function Card 1 started	○	–	OFF	–	–	N	R/W	OFF
* SM1736	Connection 25 for data exchange through Function Card 1 started	○	–	OFF	–	–	N	R/W	OFF
* SM1737	Connection 26 for data exchange through Function Card 1 started	○	–	OFF	–	–	N	R/W	OFF
* SM1738	Connection 27 for data exchange through Function Card 1 started	○	–	OFF	–	–	N	R/W	OFF
* SM1739	Connection 28 for data exchange through Function Card 1 started	○	–	OFF	–	–	N	R/W	OFF
* SM1740	Connection 29 for data exchange through Function Card 1 started	○	–	OFF	–	–	N	R/W	OFF
* SM1741	Connection 30 for data exchange through Function Card 1 started	○	–	OFF	–	–	N	R/W	OFF
* SM1742	Connection 31 for data exchange through Function Card 1 started	○	–	OFF	–	–	N	R/W	OFF
* SM1743	Connection 32 for data exchange through Function Card 1 started	○	–	OFF	–	–	N	R/W	OFF
* SM1744	Successful data exchange connection 1 through Function Card 1	○	–	OFF	–	–	N	R	OFF
* SM1745	Successful data exchange connection 2 through Function Card 1	○	–	OFF	–	–	N	R	OFF
* SM1746	Successful data exchange connection 3 through Function Card 1	○	–	OFF	–	–	N	R	OFF
* SM1747	Successful data exchange connection 4 through Function Card 1	○	–	OFF	–	–	N	R	OFF
* SM1748	Successful data exchange connection 5 through Function Card 1	○	–	OFF	–	–	N	R	OFF
* SM1749	Successful data exchange connection 6 through Function Card 1	○	–	OFF	–	–	N	R	OFF
* SM1750	Successful data exchange connection 7 through Function Card 1	○	–	OFF	–	–	N	R	OFF
* SM1751	Successful data exchange connection 8 through Function Card 1	○	–	OFF	–	–	N	R	OFF
* SM1752	Successful data exchange connection 9 through Function Card 1	○	–	OFF	–	–	N	R	OFF
* SM1753	Successful data exchange connection 10 through Function Card 1	○	–	OFF	–	–	N	R	OFF
* SM1754	Successful data exchange connection 11 through Function Card 1	○	–	OFF	–	–	N	R	OFF
* SM1755	Successful data exchange connection 12 through Function Card 1	○	–	OFF	–	–	N	R	OFF
* SM1756	Successful data exchange connection 13 through Function Card 1	○	–	OFF	–	–	N	R	OFF

SM	Function	AS300 Series	AS100/200 Series	OFF ↓ ON	STOP ↓ RUN	RUN ↓ STOP	Latched	Attribute	Default
* SM1757	Successful data exchange connection 14 through Function Card 1	○	–	OFF	–	–	N	R	OFF
* SM1758	Successful data exchange connection 15 through Function Card 1	○	–	OFF	–	–	N	R	OFF
* SM1759	Successful data exchange connection 16 through Function Card 1	○	–	OFF	–	–	N	R	OFF
* SM1760	Successful data exchange connection 17 through Function Card 1	○	–	OFF	–	–	N	R	OFF
* SM1761	Successful data exchange connection 18 through Function Card 1	○	–	OFF	–	–	N	R	OFF
* SM1762	Successful data exchange connection 19 through Function Card 1	○	–	OFF	–	–	N	R	OFF
* SM1763	Successful data exchange connection 20 through Function Card 1	○	–	OFF	–	–	N	R	OFF
* SM1764	Successful data exchange connection 21 through Function Card 1	○	–	OFF	–	–	N	R	OFF
* SM1765	Successful data exchange connection 22 through Function Card 1	○	–	OFF	–	–	N	R	OFF
* SM1766	Successful data exchange connection 23 through Function Card 1	○	–	OFF	–	–	N	R	OFF
* SM1767	Successful data exchange connection 24 through Function Card 1	○	–	OFF	–	–	N	R	OFF
* SM1768	Successful data exchange connection 25 through Function Card 1	○	–	OFF	–	–	N	R	OFF
* SM1769	Successful data exchange connection 26 through Function Card 1	○	–	OFF	–	–	N	R	OFF
* SM1770	Successful data exchange connection 27 through Function Card 1	○	–	OFF	–	–	N	R	OFF
* SM1771	Successful data exchange connection 28 through Function Card 1	○	–	OFF	–	–	N	R	OFF
* SM1772	Successful data exchange connection 29 through Function Card 1	○	–	OFF	–	–	N	R	OFF
* SM1773	Successful data exchange connection 30 through Function Card 1	○	–	OFF	–	–	N	R	OFF
* SM1774	Successful data exchange connection 31 through Function Card 1	○	–	OFF	–	–	N	R	OFF
* SM1775	Successful data exchange connection 32 through Function Card 1	○	–	OFF	–	–	N	R	OFF
* SM1776	Error in data exchange connection 1 through Function Card 1	○	–	OFF	–	–	N	R	OFF
* SM1777	Error in data exchange connection 2 through Function Card 1	○	–	OFF	–	–	N	R	OFF
* SM1778	Error in data exchange connection 3 through Function Card 1	○	–	OFF	–	–	N	R	OFF
* SM1779	Error in data exchange connection 4 through Function Card 1	○	–	OFF	–	–	N	R	OFF

SM	Function			OFF ↓ ON	STOP ↓ RUN	RUN ↓ STOP	Latched	Attribute	Default
		AS300 Series	AS100/200 Series						
* SM1780	Error in data exchange connection 5 through Function Card 1	○	–	OFF	–	–	N	R	OFF
* SM1781	Error in data exchange connection 6 through Function Card 1	○	–	OFF	–	–	N	R	OFF
* SM1782	Error in data exchange connection 7 through Function Card 1	○	–	OFF	–	–	N	R	OFF
* SM1783	Error in data exchange connection 8 through Function Card 1	○	–	OFF	–	–	N	R	OFF
* SM1784	Error in data exchange connection 9 through Function Card 1	○	–	OFF	–	–	N	R	OFF
* SM1785	Error in data exchange connection 10 through Function Card 1	○	–	OFF	–	–	N	R	OFF
* SM1786	Error in data exchange connection 11 through Function Card 1	○	–	OFF	–	–	N	R	OFF
* SM1787	Error in data exchange connection 12 through Function Card 1	○	–	OFF	–	–	N	R	OFF
* SM1788	Error in data exchange connection 13 through Function Card 1	○	–	OFF	–	–	N	R	OFF
* SM1789	Error in data exchange connection 14 through Function Card 1	○	–	OFF	–	–	N	R	OFF
* SM1790	Error in data exchange connection 15 through Function Card 1	○	–	OFF	–	–	N	R	OFF
* SM1791	Error in data exchange connection 16 through Function Card 1	○	–	OFF	–	–	N	R	OFF
* SM1792	Error in data exchange connection 17 through Function Card 1	○	–	OFF	–	–	N	R	OFF
* SM1793	Error in data exchange connection 18 through Function Card 1	○	–	OFF	–	–	N	R	OFF
* SM1794	Error in data exchange connection 19 through Function Card 1	○	–	OFF	–	–	N	R	OFF
* SM1795	Error in data exchange connection 20 through Function Card 1	○	–	OFF	–	–	N	R	OFF
* SM1796	Error in data exchange connection 21 through Function Card 1	○	–	OFF	–	–	N	R	OFF
* SM1797	Error in data exchange connection 22 through Function Card 1	○	–	OFF	–	–	N	R	OFF
* SM1798	Error in data exchange connection 23 through Function Card 1	○	–	OFF	–	–	N	R	OFF
* SM1799	Error in data exchange connection 24 through Function Card 1	○	–	OFF	–	–	N	R	OFF
* SM1800	Error in data exchange connection 25 through Function Card 1	○	–	OFF	–	–	N	R	OFF
* SM1801	Error in data exchange connection 26 through Function Card 1	○	–	OFF	–	–	N	R	OFF
* SM1802	Error in data exchange connection 27 through Function Card 1	○	–	OFF	–	–	N	R	OFF

SM	Function	AS300 Series	AS100/200 Series	OFF	STOP	RUN	Latched	Attribute	Default
				↓ ON	↓ RUN	↓ STOP			
* SM1803	Error in data exchange connection 28 through Function Card 1	○	–	OFF	–	–	N	R	OFF
* SM1804	Error in data exchange connection 29 through Function Card 1	○	–	OFF	–	–	N	R	OFF
* SM1805	Error in data exchange connection 30 through Function Card 1	○	–	OFF	–	–	N	R	OFF
* SM1806	Error in data exchange connection 31 through Function Card 1	○	–	OFF	–	–	N	R	OFF
* SM1807	Error in data exchange connection 32 through Function Card 1	○	–	OFF	–	–	N	R	OFF
* SM1821	Error in the initialization of the data exchange through Function Card 2	○	–	OFF	–	–	N	R/W	OFF
* SM1822	Data exchange through Function Card 2 enabled by ISPSOft	○	–	OFF	–	OFF	N	R/W	OFF
* SM1824	Connection 1 for data exchange through Function Card 2 started	○	–	OFF	–	–	N	R/W	OFF
* SM1825	Connection 2 for data exchange through Function Card 2 started	○	–	OFF	–	–	N	R/W	OFF
* SM1826	Connection 3 for data exchange through Function Card 2 started	○	–	OFF	–	–	N	R/W	OFF
* SM1827	Connection 4 for data exchange through Function Card 2 started	○	–	OFF	–	–	N	R/W	OFF
* SM1828	Connection 5 for data exchange through Function Card 2 started	○	–	OFF	–	–	N	R/W	OFF
* SM1829	Connection 6 for data exchange through Function Card 2 started	○	–	OFF	–	–	N	R/W	OFF
* SM1830	Connection 7 for data exchange through Function Card 2 started	○	–	OFF	–	–	N	R/W	OFF
* SM1831	Connection 8 for data exchange through Function Card 2 started	○	–	OFF	–	–	N	R/W	OFF
* SM1832	Connection 9 for data exchange through Function Card 2 started	○	–	OFF	–	–	N	R/W	OFF
* SM1833	Connection 10 for data exchange through Function Card 2 started	○	–	OFF	–	–	N	R/W	OFF
* SM1834	Connection 11 for data exchange through Function Card 2 started	○	–	OFF	–	–	N	R/W	OFF
* SM1835	Connection 12 for data exchange through Function Card 2 started	○	–	OFF	–	–	N	R/W	OFF
* SM1836	Connection 13 for data exchange through Function Card 2 started	○	–	OFF	–	–	N	R/W	OFF
* SM1837	Connection 14 for data exchange through Function Card 2 started	○	–	OFF	–	–	N	R/W	OFF
* SM1838	Connection 15 for data exchange through Function Card 2 started	○	–	OFF	–	–	N	R/W	OFF
* SM1839	Connection 16 for data exchange through Function Card 2 started	○	–	OFF	–	–	N	R/W	OFF

SM	Function			OFF ↓ ON	STOP ↓ RUN	RUN ↓ STOP	Latched	Attribute	Default
		AS300 Series	AS100/200 Series						
* SM1840	Connection 17 for data exchange through Function Card 2 started	○	–	OFF	–	–	N	R/W	OFF
* SM1841	Connection 18 for data exchange through Function Card 2 started	○	–	OFF	–	–	N	R/W	OFF
* SM1842	Connection 19 for data exchange through Function Card 2 started	○	–	OFF	–	–	N	R/W	OFF
* SM1843	Connection 20 for data exchange through Function Card 2 started	○	–	OFF	–	–	N	R/W	OFF
* SM1844	Connection 21 for data exchange through Function Card 2 started	○	–	OFF	–	–	N	R/W	OFF
* SM1845	Connection 22 for data exchange through Function Card 2 started	○	–	OFF	–	–	N	R/W	OFF
* SM1846	Connection 23 for data exchange through Function Card 2 started	○	–	OFF	–	–	N	R/W	OFF
* SM1847	Connection 24 for data exchange through Function Card 2 started	○	–	OFF	–	–	N	R/W	OFF
* SM1848	Connection 25 for data exchange through Function Card 2 started	○	–	OFF	–	–	N	R/W	OFF
* SM1849	Connection 26 for data exchange through Function Card 2 started	○	–	OFF	–	–	N	R/W	OFF
* SM1850	Connection 27 for data exchange through Function Card 2 started	○	–	OFF	–	–	N	R/W	OFF
* SM1851	Connection 28 for data exchange through Function Card 2 started	○	–	OFF	–	–	N	R/W	OFF
* SM1852	Connection 29 for data exchange through Function Card 2 started	○	–	OFF	–	–	N	R/W	OFF
* SM1853	Connection 30 for data exchange through Function Card 2 started	○	–	OFF	–	–	N	R/W	OFF
* SM1854	Connection 31 for data exchange through Function Card 2 started	○	–	OFF	–	–	N	R/W	OFF
* SM1855	Connection 32 for data exchange through Function Card 2 started	○	–	OFF	–	–	N	R/W	OFF
* SM1856	Successful data exchange connection 1 through Function Card 2	○	–	OFF	–	–	N	R	OFF
* SM1857	Successful data exchange connection 2 through Function Card 2	○	–	OFF	–	–	N	R	OFF
* SM1858	Successful data exchange connection 3 through Function Card 2	○	–	OFF	–	–	N	R	OFF
* SM1859	Successful data exchange connection 4 through Function Card 2	○	–	OFF	–	–	N	R	OFF
* SM1860	Successful data exchange connection 5 through Function Card 2	○	–	OFF	–	–	N	R	OFF
* SM1861	Successful data exchange connection 6 through Function Card 2	○	–	OFF	–	–	N	R	OFF
* SM1862	Successful data exchange connection 7 through Function Card 2	○	–	OFF	–	–	N	R	OFF

SM	Function	AS300 Series	AS100/200 Series	OFF ↓ ON	STOP ↓ RUN	RUN ↓ STOP	Latched	Attribute	Default
* SM1863	Successful data exchange connection 8 through Function Card 2	○	—	OFF	—	—	N	R	OFF
* SM1864	Successful data exchange connection 9 through Function Card 2	○	—	OFF	—	—	N	R	OFF
* SM1865	Successful data exchange connection 10 through Function Card 2	○	—	OFF	—	—	N	R	OFF
* SM1866	Successful data exchange connection 11 through Function Card 2	○	—	OFF	—	—	N	R	OFF
* SM1867	Successful data exchange connection 12 through Function Card 2	○	—	OFF	—	—	N	R	OFF
* SM1868	Successful data exchange connection 13 through Function Card 2	○	—	OFF	—	—	N	R	OFF
* SM1869	Successful data exchange connection 14 through Function Card 2	○	—	OFF	—	—	N	R	OFF
* SM1870	Successful data exchange connection 15 through Function Card 2	○	—	OFF	—	—	N	R	OFF
* SM1871	Successful data exchange connection 16 through Function Card 2	○	—	OFF	—	—	N	R	OFF
* SM1872	Successful data exchange connection 17 through Function Card 2	○	—	OFF	—	—	N	R	OFF
* SM1873	Successful data exchange connection 18 through Function Card 2	○	—	OFF	—	—	N	R	OFF
* SM1874	Successful data exchange connection 19 through Function Card 2	○	—	OFF	—	—	N	R	OFF
* SM1875	Successful data exchange connection 20 through Function Card 2	○	—	OFF	—	—	N	R	OFF
* SM1876	Successful data exchange connection 21 through Function Card 2	○	—	OFF	—	—	N	R	OFF
* SM1877	Successful data exchange connection 22 through Function Card 2	○	—	OFF	—	—	N	R	OFF
* SM1878	Successful data exchange connection 23 through Function Card 2	○	—	OFF	—	—	N	R	OFF
* SM1879	Successful data exchange connection 24 through Function Card 2	○	—	OFF	—	—	N	R	OFF
* SM1880	Successful data exchange connection 25 through Function Card 2	○	—	OFF	—	—	N	R	OFF
* SM1881	Successful data exchange connection 26 through Function Card 2	○	—	OFF	—	—	N	R	OFF
* SM1882	Successful data exchange connection 27 through Function Card 2	○	—	OFF	—	—	N	R	OFF
* SM1883	Successful data exchange connection 28 through Function Card 2	○	—	OFF	—	—	N	R	OFF
* SM1884	Successful data exchange connection 29 through Function Card 2	○	—	OFF	—	—	N	R	OFF
* SM1885	Successful data exchange connection 30 through Function Card 2	○	—	OFF	—	—	N	R	OFF

SM	Function			OFF ↓ ON	STOP ↓ RUN	RUN ↓ STOP	Latched	Attribute	Default
		AS300 Series	AS100/200 Series						
* SM1886	Successful data exchange connection 31 through Function Card 2	○	–	OFF	–	–	N	R	OFF
* SM1887	Successful data exchange connection 32 through Function Card 2	○	–	OFF	–	–	N	R	OFF
* SM1888	Error in data exchange connection 1 through Function Card 2	○	–	OFF	–	–	N	R	OFF
* SM1889	Error in data exchange connection 2 through Function Card 2	○	–	OFF	–	–	N	R	OFF
* SM1890	Error in data exchange connection 3 through Function Card 2	○	–	OFF	–	–	N	R	OFF
* SM1891	Error in data exchange connection 4 through Function Card 2	○	–	OFF	–	–	N	R	OFF
* SM1892	Error in data exchange connection 5 through Function Card 2	○	–	OFF	–	–	N	R	OFF
* SM1893	Error in data exchange connection 6 through Function Card 2	○	–	OFF	–	–	N	R	OFF
* SM1894	Error in data exchange connection 7 through Function Card 2	○	–	OFF	–	–	N	R	OFF
* SM1895	Error in data exchange connection 8 through Function Card 2	○	–	OFF	–	–	N	R	OFF
* SM1896	Error in data exchange connection 9 through Function Card 2	○	–	OFF	–	–	N	R	OFF
* SM1897	Error in data exchange connection 10 through Function Card 2	○	–	OFF	–	–	N	R	OFF
* SM1898	Error in data exchange connection 11 through Function Card 2	○	–	OFF	–	–	N	R	OFF
* SM1899	Error in data exchange connection 12 through Function Card 2	○	–	OFF	–	–	N	R	OFF
* SM1900	Error in data exchange connection 13 through Function Card 2	○	–	OFF	–	–	N	R	OFF
* SM1901	Error in data exchange connection 14 through Function Card 2	○	–	OFF	–	–	N	R	OFF
* SM1902	Error in data exchange connection 15 through Function Card 2	○	–	OFF	–	–	N	R	OFF
* SM1903	Error in data exchange connection 16 through Function Card 2	○	–	OFF	–	–	N	R	OFF
* SM1904	Error in data exchange connection 17 through Function Card 2	○	–	OFF	–	–	N	R	OFF
* SM1905	Error in data exchange connection 18 through Function Card 2	○	–	OFF	–	–	N	R	OFF
* SM1906	Error in data exchange connection 19 through Function Card 2	○	–	OFF	–	–	N	R	OFF
* SM1907	Error in data exchange connection 20 through Function Card 2	○	–	OFF	–	–	N	R	OFF
* SM1908	Error in data exchange connection 21 through Function Card 2	○	–	OFF	–	–	N	R	OFF

SM	Function	AS300 Series	AS100/200 Series	OFF	STOP	RUN	Latched	Attribute	Default
				↓ ON	↓ RUN	↓ STOP			
* SM1909	Error in data exchange connection 22 through Function Card 2	○	–	OFF	–	–	N	R	OFF
* SM1910	Error in data exchange connection 23 through Function Card 2	○	–	OFF	–	–	N	R	OFF
* SM1911	Error in data exchange connection 24 through Function Card 2	○	–	OFF	–	–	N	R	OFF
* SM1912	Error in data exchange connection 25 through Function Card 2	○	–	OFF	–	–	N	R	OFF
* SM1913	Error in data exchange connection 26 through Function Card 2	○	–	OFF	–	–	N	R	OFF
* SM1914	Error in data exchange connection 27 through Function Card 2	○	–	OFF	–	–	N	R	OFF
* SM1915	Error in data exchange connection 28 through Function Card 2	○	–	OFF	–	–	N	R	OFF
* SM1916	Error in data exchange connection 29 through Function Card 2	○	–	OFF	–	–	N	R	OFF
* SM1917	Error in data exchange connection 30 through Function Card 2	○	–	OFF	–	–	N	R	OFF
* SM1918	Error in data exchange connection 31 through Function Card 2	○	–	OFF	–	–	N	R	OFF
* SM1919	Error in data exchange connection 32 through Function Card 2	○	–	OFF	–	–	N	R	OFF
SM1921	Positioning completed on ECAT communication ID 9 of Delta servo	○	–	OFF	OFF	–	N	R/W	OFF
SM1922	Positioning completed on ECAT communication ID 10 of Delta servo	○	–	OFF	OFF	–	N	R/W	OFF
SM1923	Positioning completed on ECAT communication ID 11 of Delta servo	○	–	OFF	OFF	–	N	R/W	OFF
SM1924	Positioning completed on ECAT communication ID 12 of Delta servo	○	–	OFF	OFF	–	N	R/W	OFF
SM1925	Positioning completed on ECAT communication ID 13 of Delta servo	○	–	OFF	OFF	–	N	R/W	OFF
SM1926	Positioning completed on ECAT communication ID 14 of Delta servo	○	–	OFF	OFF	–	N	R/W	OFF
SM1927	Positioning completed on ECAT communication ID 15 of Delta servo	○	–	OFF	OFF	–	N	R/W	OFF
SM1928	Positioning completed on ECAT communication ID 16 of Delta servo	○	–	OFF	OFF	–	N	R/W	OFF
SM1931	Communication stops on ECAT communication ID 9 of Delta servo	○	–	OFF	OFF	–	N	R/W	OFF
SM1932	Communication stops on ECAT communication ID 10 of Delta servo	○	–	OFF	OFF	–	N	R/W	OFF
SM1933	Communication stops on ECAT communication ID 11 of Delta servo	○	–	OFF	OFF	–	N	R/W	OFF
SM1934	Communication stops on ECAT communication ID 12 of Delta servo	○	–	OFF	OFF	–	N	R/W	OFF

SM	Function	AS100/200 Series		OFF ↓ ON	STOP ↓ RUN	RUN ↓ STOP	Latched	Attribute	Default
		AS300 Series							
SM1935	Communication stops on ECAT communication ID 13 of Delta servo	○	–	OFF	OFF	–	N	R/W	OFF
SM1936	Communication stops on ECAT communication ID 14 of Delta servo	○	–	OFF	OFF	–	N	R/W	OFF
SM1937	Communication stops on ECAT communication ID 15 of Delta servo	○	–	OFF	OFF	–	N	R/W	OFF
SM1938	Communication stops on ECAT communication ID 16 of Delta servo	○	–	OFF	OFF	–	N	R/W	OFF
SM1941	The function of going back and forth is enabled on ECAT communication ID 9 of Delta servo.	○	–	OFF	OFF	–	N	R/W	OFF
SM1942	The function of going back and forth is enabled on ECAT communication ID 10 of Delta servo.	○	–	OFF	OFF	–	N	R/W	OFF
SM1943	The function of going back and forth is enabled on ECAT communication ID 11 of Delta servo.	○	–	OFF	OFF	–	N	R/W	OFF
SM1944	The function of going back and forth is enabled on ECAT communication ID 12 of Delta servo.	○	–	OFF	OFF	–	N	R/W	OFF
SM1945	The function of going back and forth is enabled on ECAT communication ID 13 of Delta servo.	○	–	OFF	OFF	–	N	R/W	OFF
SM1946	The function of going back and forth is enabled on ECAT communication ID 14 of Delta servo.	○	–	OFF	OFF	–	N	R/W	OFF
SM1947	The function of going back and forth is enabled on ECAT communication ID 15 of Delta servo.	○	–	OFF	OFF	–	N	R/W	OFF
SM1948	The function of going back and forth is enabled on ECAT communication ID 16 of Delta servo.	○	–	OFF	OFF	–	N	R/W	OFF
SM1951	The go-back/go-forth direction indication flag on ECAT communication ID 9 of Delta servo.	○	–	OFF	OFF	–	N	R	OFF
SM1952	The go-back/go-forth direction indication flag on ECAT communication ID 10 of Delta servo.	○	–	OFF	OFF	–	N	R	OFF
SM1953	The go-back/go-forth direction indication flag on ECAT communication ID 11 of Delta servo.	○	–	OFF	OFF	–	N	R	OFF
SM1954	The go-back/go-forth direction indication flag on ECAT communication ID 12 of Delta servo.	○	–	OFF	OFF	–	N	R	OFF
SM1955	The go-back/go-forth direction indication flag on ECAT communication ID 13 of Delta servo.	○	–	OFF	OFF	–	N	R	OFF
SM1956	The go-back/go-forth direction indication flag on ECAT communication ID 14 of Delta servo.	○	–	OFF	OFF	–	N	R	OFF
SM1957	The go-back/go-forth direction indication flag on ECAT communication ID 15 of Delta servo.	○	–	OFF	OFF	–	N	R	OFF
SM1958	The go-back/go-forth direction indication flag on ECAT communication ID 16 of Delta servo.	○	–	OFF	OFF	–	N	R	OFF

\*1: For items with a \* mark, Refer to Section 2.2.1.6 for Additional Remarks on Special Auxiliary Relays and Special Data Registers for details.

\*2: The system executes according to the parameters set in HWCONFIG. When the SM power changes from OFF to ON, the state is -, and the latched area is marked as N.

\*3: The function card here means AS-F232, AS-F422 and AS-F485.

### 2.2.8 Refresh Time for Special Auxiliary Relays

Special auxiliary relay	Refresh time
SM0–SM1	The system automatically sets the flag to ON and resets it to OFF. ON: operation error.
SM5	The system automatically sets the flag to ON and resets it to OFF. ON: an error occurs when the program is written in the PLC.
SM6	During power-on, the system checks whether the data in the latched area has been lost. ON: data in the latched area has been lost. You reset it to OFF.
SM7	ON: power supply (24 V) is not sufficient. You reset it to OFF.
SM8	The system automatically sets SM8 to ON and resets it to OFF. ON: there is a watchdog timer error.
SM9	The system automatically sets SM9 to ON and resets it to OFF. ON: there is a system error.
SM10	The system automatically sets SM10 to ON and resets it to OFF. ON: there is an I/O bus error.
SM22–SM24	You set the flag to ON, and the system automatically resets it to OFF. ON: the log is cleared.
SM25–SM26	ON: users are editing with ISPSOft. OFF: users have logged out of ISPSOft.
SM27	Update the value in the built-in AD for AS-F2AD. The system resets it to OFF.
SM28	The system checks for anything wrong. ON: something is wrong. You reset it to OFF.
SM29	The system automatically sets the flag to ON. You reset it to OFF.
SM30	ON: an error occurs in the remote module. The system resets it to OFF.
SM34	ON: the wrong password is entered. The system resets it to OFF.
SM36	ON: the system saves the data to the memory card. After saving is complete, the system resets it to OFF automatically. You set it to ON to enable saving.
SM38	The system automatically sets the flag to ON. You reset it to OFF.
SM76–SM77	ON: the system executes the communication task. After the communication task is complete, the system resets it to OFF automatically. You set it to ON to enable execution.
SM78–SM79	ON: communication is in progress. After the communication is complete, the system resets it to OFF automatically.
SM80–SM81	ON: reception is complete. You reset it to OFF.
SM82–SM83	ON: an error occurs in the response. You reset it to OFF.
SM84–SM85	ON: a timeout occurs. You reset it to OFF.
SM86–SM87	You set the flag to ON and reset it to OFF. ON: 8-bit mode OFF: 16-bit mode
SM90–SM91	You set the flag to ON. After the communication protocol is changed, the system resets it to OFF.
SM94–SM95	After power-on, the flag is ON or OFF according to the settings in HWCONFIG. You can change this setting.
SM96–SM97	You set the flag to ON. After the data is sent, the system automatically resets the flag to OFF.
SM98–SM99	ON: communication is in process. After the communication is complete, the system resets it to OFF automatically.
SM100–SM101	The system automatically sets the flag to ON, and you reset it to OFF. ON: the command is received.
SM102–SM103	The system automatically sets the flag to ON, and you reset it to OFF.

Special auxiliary relay	Refresh time
	ON: the command received is wrong.
SM104–SM105	The system automatically sets the flag to ON, and you reset it to OFF. ON: there is a receive timeout.
SM106–SM107	You set the flag to ON and reset it to OFF. ON: 8-bit mode OFF: 16-bit mode
SM120–SM151	You set the flag to ON and while executing DPLSY instruction, the system resets it to OFF.
SM166–SM167	You set the flag to ON and reset it to OFF.
SM168–SM171	The system automatically sets the flag to ON, and resets it to OFF.
SM172	The system automatically sets the flag to ON, and resets it to OFF.
SM203	You set the flag to ON and after PLC RUN->STOP, it clears the non-latched area. The system automatically resets the flag to OFF.
SM204–SM205	You set the flag to ON, and the system automatically resets it to OFF. ON: clear the non-latched/latched areas.
SM206	You set SM206 to ON and reset it to OFF. ON: inhibit all output.
SM209	You set SM209 to ON, and the system automatically resets it to OFF. ON: the communication protocol of COM1 changes.
SM210	You set SM210 to ON and reset it to OFF for COM1. ON: RTU mode OFF: ASCII mode
SM211	You set SM211 to ON, and the system automatically resets it to OFF. ON: the communication protocol of COM2 changes.
SM212	You set SM210 to ON and reset it to OFF for COM2. ON: RTU mode OFF: ASCII mode
SM215	You set SM215 to ON and reset it to OFF. ON: the PLC runs. OFF: the PLC stops.
SM217	The system automatically sets the flag to ON.
SM218	The system checks the real-time clock at power-on. ON: real-time clock error You reset it to OFF.
SM219	The system monitors the battery power of the real-time clock. ON: real-time clock power is low. The system resets it to OFF.
SM220	You set SM220 to ON and reset it to OFF. ON: calibrating the real-time clock within $\pm 30$ seconds
SM221	The flag is refreshed according to the settings in HWCONFIG or when the DST instruction (API 1607) is executed. ON: the DST instruction is executed.
SM222	The system automatically sets the flag to ON, and resets it to OFF.
SM230–SM261	The flag is refreshed according to the settings in HWCONFIG; you can redefine this setting.
SM270–SM275	The flag is ON when the CSFO instruction is executed. ON: enable reversing the input direction OFF: disable reversing the input direction
SM281–SM288	You set the flag to ON and reset it to OFF.

Special auxiliary relay	Refresh time
	ON: counting down OFF: counting up
SM291–SM296	You set the flag to ON and reset it to OFF. ON: enable clearing the input points OFF: disable clearing the input points
SM300	You set the flag to ON and reset it to OFF. ON: counting down OFF: counting up
SM301–SM303	The system sets the flag to ON and reset it to OFF. ON: counting down OFF: counting up
SM304	You set the flag to ON and reset it to OFF. ON: counting down OFF: counting up
SM305–SM307	You set the flag to ON and reset it to OFF. ON: counting down OFF: counting up
SM308	You set the flag to ON and reset it to OFF. ON: counting down OFF: counting up
SM309–SM311	You set the flag to ON and reset it to OFF. ON: counting down OFF: counting up
SM312	You set the flag to ON and reset it to OFF. ON: counting down OFF: counting up
SM313–SM315	You set the flag to ON and reset it to OFF. ON: counting down OFF: counting up
SM316	You set the flag to ON and reset it to OFF. ON: counting down OFF: counting up
SM317–SM319	You set the flag to ON and reset it to OFF. ON: counting down OFF: counting up
SM320	You set the flag to ON and reset it to OFF. ON: counting down OFF: counting up
SM321–SM323	You set the flag to ON and reset it to OFF. ON: counting down OFF: counting up
SM332	You set the flag to ON and reset it to OFF. ON: counting down OFF: counting up
SM333–SM335	You set the flag to ON and reset it to OFF. ON: counting down OFF: counting up
SM336	You set the flag to ON and reset it to OFF.

Special auxiliary relay	Refresh time
	ON: counting down OFF: counting up
SM337–SM339	You set the flag to ON and reset it to OFF. ON: counting down OFF: counting up
SM340	You set the flag to ON and reset it to OFF. ON: counting down OFF: counting up
SM341	You set the flag to ON and reset it to OFF. ON: counting down OFF: counting up
SM342	You set the flag to ON and reset it to OFF. ON: counting down OFF: counting up
SM343	You set the flag to ON and reset it to OFF. ON: counting down OFF: counting up
SM344	You set the flag to ON and reset it to OFF. ON: counting down OFF: counting up
SM345	You set the flag to ON and reset it to OFF. ON: counting down OFF: counting up
SM346	You set the flag to ON and reset it to OFF. ON: counting down OFF: counting up
SM347	You set the flag to ON and reset it to OFF. ON: counting down OFF: counting up
SM348	You set the flag to ON and reset it to OFF. ON: counting down OFF: counting up
SM349	You set the flag to ON and reset it to OFF. ON: counting down OFF: counting up
SM350	You set the flag to ON and reset it to OFF. ON: counting down OFF: counting up
SM351	You set the flag to ON and reset it to OFF. ON: counting down OFF: counting up
SM352–SM353	You set the flag to ON and reset it to OFF. ON: counting down OFF: counting up
SM360–SM391	The system sets the flag to ON or OFF.
SM400–SM403	The system automatically sets the flag to ON and resets it to OFF. The flag is refreshed every scan cycle.
SM404	The system automatically sets the flag to ON and resets it to OFF.

Special auxiliary relay	Refresh time
	SM404 is refreshed every 5 milliseconds.
SM405	The system automatically sets SM405 to ON and resets it to OFF. SM405 is refreshed every 50 milliseconds.
SM406	The system automatically sets SM406 to ON and resets it to OFF. SM406 is refreshed every 100 milliseconds.
SM407	The system automatically sets SM407 to ON and resets it to OFF. SM407 is refreshed every 0.5 seconds.
SM450	The system automatically sets SM450 to ON and resets it to OFF. ON: memory card is inserted into the PLC. OFF: memory card is removed out of the PLC.
SM452–SM453	The system sets the flag to ON or OFF.
SM454	You set the flag to ON or OFF.
SM455	The system sets the flag to ON or OFF.
SM456	You set the flag to ON to save. After the saving is complete, the system resets it to OFF.
SM457	The system sets the flag to ON or OFF.
SM460	The system sets the flag to ON or OFF.
SM461	The system sets the flag to ON and you reset it to OFF.
SM462–SM464	You set the flag to ON or OFF.
SM465	The system sets the flag to ON and you reset it to OFF.
SM466	You set the flag to ON or OFF.
SM467	The system sets the flag to ON and you reset it to OFF.
SM469–SM471	You set the flag to ON or OFF.
SM472	The system sets the flag to ON or OFF.
SM473	The system sets the flag to ON and you reset it to OFF.
SM474–SM477	You set the flag to ON or OFF.
SM478–SM479	You set the flag to ON or OFF and the system sets the flag to OFF.
SM480	The system sets the flag to ON or OFF.
SM481	The system sets the flag to ON and you reset it to OFF.
SM482–SM484	You set the flag to ON or OFF.
SM485	The system sets the flag to ON and you reset it to OFF.
SM486	You set the flag to ON or OFF.
SM487	The system sets the flag to ON and you reset it to OFF.
SM489–SM491	You set the flag to ON or OFF.
SM492	The system sets the flag to ON or OFF.
SM493	The system sets the flag to ON and you reset it to OFF.
SM494–SM497	You set the flag to ON or OFF.
SM498–SM499	You set the flag to ON or OFF and the system sets the flag to OFF.
SM500	The system sets the flag to ON or OFF.
SM501	The system sets the flag to ON and you reset it to OFF.
SM502–SM504	You set the flag to ON or OFF.
SM505	The system sets the flag to ON and you reset it to OFF.
SM506	You set the flag to ON or OFF.
SM507	The system sets the flag to ON and you reset it to OFF.
SM509–SM511	You set the flag to ON or OFF.
SM512	The system sets the flag to ON or OFF.
SM513	The system sets the flag to ON and you reset it to OFF.

Special auxiliary relay	Refresh time
SM514–SM517	You set the flag to ON or OFF.
SM518–SM519	You set the flag to ON or OFF and the system sets the flag to OFF.
SM520	The system sets the flag to ON or OFF.
SM521	The system sets the flag to ON and you reset it to OFF.
SM522–SM524	You set the flag to ON or OFF.
SM525	The system sets the flag to ON and you reset it to OFF.
SM526	You set the flag to ON or OFF.
SM527	The system sets the flag to ON and you reset it to OFF.
SM529–SM531	You set the flag to ON or OFF.
SM532	The system sets the flag to ON or OFF.
SM533	The system sets the flag to ON and you reset it to OFF.
SM534–SM537	You set the flag to ON or OFF.
SM538–SM539	You set the flag to ON or OFF and the system sets the flag to OFF.
SM540	The system sets the flag to ON or OFF.
SM541	The system sets the flag to ON and you reset it to OFF.
SM542–SM544	You set the flag to ON or OFF.
SM545	The system sets the flag to ON and you reset it to OFF.
SM546	You set the flag to ON or OFF.
SM547	The system sets the flag to ON and you reset it to OFF.
SM549–SM551	You set the flag to ON or OFF.
SM552	The system sets the flag to ON or OFF.
SM553	The system sets the flag to ON and you reset it to OFF.
SM554–SM557	You set the flag to ON or OFF.
SM558–SM559	You set the flag to ON or OFF and the system sets the flag to OFF.
SM560	The system sets the flag to ON or OFF.
SM561	The system sets the flag to ON and you reset it to OFF.
SM562–SM564	You set the flag to ON or OFF.
SM565	The system sets the flag to ON and you reset it to OFF.
SM566	You set the flag to ON or OFF.
SM567	The system sets the flag to ON and you reset it to OFF.
SM569–SM569	You set the flag to ON or OFF.
SM572	The system sets the flag to ON or OFF.
SM573	The system sets the flag to ON and you reset it to OFF.
SM574	You set the flag to ON or OFF.
SM578–SM579	You set the flag to ON or OFF and the system sets the flag to OFF.
SM580	You set the flag to ON and the system resets it to OFF. ON: disable high-speed output
SM581	You set the flag to ON and reset it to OFF.
SM585	You set the flag to ON or OFF and the system sets the flag to OFF.
SM586--SM587	You set the flag to ON or OFF.
SM591—SM596	You set the flag to ON and the system resets it to OFF or you reset it to OFF.
SM600–SM602	The system automatically sets the flag to ON and resets it to OFF. The flag is refreshed when the instruction is executed.
SM603	Execute XCMP instruction.
SM604	You set SM604 to ON and reset it to OFF. ON: sort in descending order

Special auxiliary relay	Refresh time
	OFF: sort in ascending order
SM605	You set SM605 to ON and reset it to OFF.
SM606	You set SM606 to ON and reset it to OFF. ON: 8-bit mode OFF: 16-bit mode
SM607	You set the flag to ON or OFF.
SM608	The flag is refreshed when the instruction is executed.
SM609	You set the flag to ON or OFF.
SM610–SM611	The flag is refreshed when the instruction is executed.
SM612–SM613	You set the flag to ON or OFF.
SM614	The flag is refreshed when the instruction is executed.
SM615–SM617	You set the flag to ON or OFF.
SM618	The flag is refreshed when the instruction is executed.
SM619	The flag is refreshed when the EI or DI instruction is executed.
SM620	The flag is refreshed when the CMPT instruction is executed.
SM621–SM686	You set the flag to ON or OFF.
SM687	The flag is refreshed when the RAMP instruction is executed.
SM688	The flag is refreshed when the INCD instruction is executed.
SM690–SM691	You set the flag to ON or OFF.
SM692	The flag is refreshed when the HKY instruction is executed.
SM693	The flag is refreshed when the SEGL instruction is executed.
SM694	The flag is refreshed when the DSW instruction is executed.
SM695	You set the flag to ON or OFF.
SM749	The system is refreshed at power-on after the data exchange parameters are downloaded.
SM750–SM783	After the data exchange parameters are downloaded, you set the flag to ON or OFF.
SM784–SM847	The flag is ON when the system is refreshed.
SM861	The system is refreshed at power-on after the data exchange parameters are downloaded.
SM862–SM895	After the parameters of data exchange are downloaded, you set the flag to ON or OFF.
SM896–SM959	The flag is ON, when the system is refreshed automatically.
SM976–SM990	The flag is ON, when the system is refreshed automatically.
SM1000	You set the flag to ON and after saving, the system sets the flag to OFF.
SM1006	You set the flag to ON or OFF.
SM1008–SM1015	You set the flag to ON or OFF.
SM1016–SM1031	The flag is ON, when the system is refreshed automatically.
SM1001	ON: the Ethernet connection is active. OFF: the Ethernet connection is not active.
SM1006	After the parameters of data exchange are downloaded, you set the flag to ON or OFF.
SM1008–SM1015	After the parameters of data exchange are downloaded, you set the flag to ON or OFF.
SM1016–SM1031	The flag is ON, when the system is refreshed automatically.
SM1090	ON: the TCP connection is busy.
SM1091	ON: the UDP connection is busy.
SM1092	System updates.
SM1100	The flag is refreshed when API 2200-API 2210 is executed or the network cable is reconnected.
SM1106	ON: the PHY initialization fails.
SM1107	ON: the IP address, the netmask address, and the gateway address are set incorrectly.
SM1109	ON: the socket function is enabled and the same port is used.

Special auxiliary relay	Refresh time
SM1111	You set the flag to ON or OFF.
SM1113	ON: there is a server error.
SM1116	ON: the trigger of the PLC parameter is enabled.
SM1117	ON: the trigger of the PLC parameter is triggered.
SM1119	ON: the trigger is enabled and the last mail has been sent successfully.
SM1120	ON: the trigger is enabled and the last mail has been sent with an error.
SM1122–SM1123	ON: the trigger is enabled and there is an SMTP server response timeout.
SM1124	ON: the trigger is enabled and the size of the attachment exceeds the limit.
SM1125	ON: the trigger is enabled and the attachment is not found.
SM1126–SM1127	ON: the trigger of the PLC parameter is enabled.
SM1129	ON: the trigger is enabled and the last mail has been sent successfully.
SM1130	ON: the trigger is enabled and the last mail has been sent with an error.
SM1132	ON: the trigger is enabled and there is an SMTP server response timeout.
SM1133	ON: the trigger is enabled and there is an SMTP server response error.
SM1134	ON: the trigger is enabled and the size of the attachment exceeds the limit.
SM1135	ON: the trigger is enabled and the attachment is not found.
SM1136	ON: the trigger for the PLC parameter is enabled.
SM1137	ON: the trigger for the PLC parameter is triggered.
SM1139	ON: the trigger is enabled and the last mail has been sent successfully.
SM1140	ON: the trigger is enabled and the last mail has been sent with an error.
SM1142	ON: the trigger is enabled and there is an SMTP server response timeout.
SM1143	ON: the trigger is enabled and there is an SMTP server response error.
SM1144	ON: the trigger is enabled and the size of the attachment exceeds the limit.
SM1145	ON: the trigger is enabled and the attachment is not found.
SM1146	ON: the trigger for the PLC parameter is enabled.
SM1147	ON: the trigger for the PLC parameter is triggered.
SM1149	ON: the trigger is enabled and the last mail has been sent successfully.
SM1150	ON: the trigger is enabled and the last mail has been sent with an error.
SM1152	ON: the trigger is enabled and there is an SMTP server response timeout.
SM1153	ON: the trigger is enabled and there is an SMTP server response error.
SM1154	ON: the trigger is enabled and the size of the attachment exceeds the limit.
SM1155	ON: the trigger is enabled and the attachment is not found.
SM1160-SM1161	Restore parameters on Delta devices
SM1166	After the data exchange parameters are downloaded, the system is refreshed.
SM1167–SM1199	After the data exchange parameters are downloaded, you set the flag to ON or OFF.
SM1200–SM1263	ON: when the system is refreshed.
SM1269	ON: there is a socket configuration error.
SM1270–SM1353	The flag is refreshed when the socket function is executed.
SM1312–SM1315	The flag is ON, when the system is refreshed automatically.
SM1375–SM1407	After the data exchange parameters are downloaded through EtherNet/IP, you set the flag to ON or OFF.
SM1408–SM1439	ON: an error occurred in data exchange through EtherNet/IP.
SM1440–SM1447	ON: a timeout occurred in the adapter of the I/O connection through EtherNet/IP.
SM1448–SM1455	ON: I/O connection is established through EtherNet/IP (Adapter).

Special auxiliary relay	Refresh time
	OFF: I/O connection is NOT established through EtherNet/IP (Adapter) or the communication is disconnected.
SM1581–SM1588	You set the flag to ON or OFF.
SM1601–SM1608	You set the flag to ON or OFF.
SM1611–SM1618	The system sets the flag to ON or OFF.
SM1621–SM1628	The system sets the flag to ON or OFF.
SM1631–SM1638	The system sets the flag to ON and you set it to OFF.
SM1641–SM1648	You set the flag to ON or OFF.
SM1651–SM1658	The system sets the flag to ON or OFF.
SM1661–SM1668	You set the flag to ON or OFF.
SM1671–SM1682	The system sets the flag to ON or OFF.
SM1683	The system sets the flag to ON or OFF.
SM1684–SM1685	You set the flag to ON or OFF.
SM1691–SM1698	The system sets the flag to ON or OFF.
SM1700–SM1705	The system sets the flag to ON or OFF.
SM1709–SM1710	You set the flag to ON or OFF.
SM1712–SM1743	You set the flag to ON or OFF.
SM1744–SM1807	The system sets the flag to ON or OFF.
SM1821–SM1822	You set the flag to ON or OFF.
SM1824–SM1855	You set the flag to ON or OFF.
SM1856–SM1919	The system sets the flag to ON or OFF.
SM1921--SM1928	The system sets the flag to ON or OFF.
SM1931--SM1938	You set the flag to ON or OFF.
SM1941--SM1948	You set the flag to ON or OFF.
SM1951--SM1958	The system sets the flag to ON or OFF.

### 2.2.9 Relays (S)

You can easily use the relay in industrial automation to set a procedure. It is the most basic device in sequential function chart (SFC) programming.

There are 2048 relays, (S0–S2047). Every stepping relay is like an output relay in that it has an output coil, contact A, and contact B. You can use a relay for several times in a program, but the relay cannot directly drive the external load. In addition, you can use the relay as a general auxiliary relay when it is not used in a sequential function chart.

### 2.2.10 Timers (T)

This topic describes the timers available in ISPSOft. Refer to the ISPSOft User Manual for more information on timers.


- 100 millisecond timer: The timer specified by the TMR instruction takes 100 milliseconds as the timing unit.
- 1 millisecond timer: The timer specified by the TMRH instruction takes 1 millisecond as the timing unit.
- The accumulative timers are ST0–ST511. If you want to use the device-monitoring function, these timers can monitor T0–T511.
- If you use the same timer repeatedly in a program, including in different TMR and TMRH instructions, the timer setting value is the one that the timer matches first.
- If you use the same timer repeatedly in a program, the timer is OFF when one of the conditional contacts is OFF.

- If you use the same timer in a program as the timer for a subroutine's exclusive use and an accumulative timer in the program, it is OFF when one of the conditional contacts is OFF.
- When the timer switches from ON to OFF and the conditional contact is ON, the timer is reset and counts again.
- When the TMR instruction is executed, the specified timer coil is ON and the timer begins to count. When the value of the timer matches the timer setting value (value of the timer  $\geq$  setting value), the state of the contact is ON.

**A. General-purpose timers**

When the TMR instruction is executed, the general-purpose timer begins to count. When the value of the timer matches the timer setting value, the output coil is ON.


- When X0.0=ON and the timer takes 100 ms as the timing unit, the output coil T0 is ON when the value of the timer = timer setting value 100.
- When X0.0=OFF or the power is off, the value of the timer is 0 and the output coil T0 is OFF.



**B. Accumulative timers**

When the TMR instruction is executed, the accumulative timer begins to count. When the value of the timer matches the timer setting value, the output coil is ON. As long as you add the letter S in front of the letter T, the timer becomes an accumulative timer. When the conditional contact is OFF, the value of the accumulative timer is not reset. When the conditional contact is ON, the accumulative timer counts from the current value.

- When X0.0=ON and the timer T250 takes 100 ms as the timing unit, the output coil T250 is ON when the value of the timer = timer setting value 100.
- When X0.0=OFF or the power is off, the accumulative timer ST250 stops counting, and the value of the timer stays the same. When X0.0=ON, the value of the timer is the accumulating value. When the accumulated value = timer setting value 100, the output coil T250 is ON.



### C. Timers used in function blocks

T412–T511 are the timers that you can use in the function block or in interrupts.

When the TMR or END instruction is executed, the timer in the functional block begins to count. When the value of the timer matches the timer setting value, the output coil is ON.

If you use a general-purpose timer in a function block or an interrupt, and the function or interrupt is not executed, the timer cannot count correctly.

## 2.2.11 Counters

- Characteristics of the 16-bit counter


Item	16-bit counter
Type	General type
Number	C0–C511
Direction	Counting up
Setting value	0–32,767
Specifying the counter setting value	The setting value can be either the constant or the value in the data register.
Change of the current value	The counter stops counting when the value of the counter matches the counter setting value.
Output contact	The contact is ON when the value of the counter matches the counter setting value.
Reset	When the instruction RST is executed, the current value is cleared to zero, and the contact is reset of OFF.
Action of the contact	After the scan is complete, the contact acts.

- Function of the counter


Each time the input switches from OFF to ON, the value of the counter is the same as the output coil. You can use either the decimal constant or the value in the data register as the counter setting value.

**16-bit counter:**

1. Setting range: 0–32,767. The setting values 0 and 1 mean the same thing in that the output contact is ON when the counter counts for the first time.
2. For the general-purpose counter, the current value of the counter is cleared when power is lost. If the counter is latching, the current value of the counter and the state of the contact before power was lost power are retained. The latched counter counts from the current value when the power supply is restored.
3. If you use the MOV instruction or ISPSOft to transmit a value larger than the counter setting value to the current value register C0, the contact of the counter C0 is ON and the current value becomes the same as the counter setting value the next time X0.1 switches from OFF to ON.
4. You can use either the constant or the value in the data register as the counter setting value.
5. The counter setting value can be positive or negative. If the counter counts up from 32,767, the next value is 0.
6. Use the counters here with CNT instruction. The example used here is a common one. Refer to API 1003 CNT instruction for more advanced applicaiotns.



1. When X0.0=ON, the RST instruction is executed, the current value of C0 is reset to zero, and the output contact of the counter C0 is FF.
2. When X0.1 changes from OFF to ON, the value of the counter increments by one.
3. When the value of the counter C0 reaches the counter setting value of 5, the contact of the counter C0 is ON (the current value of C0 = the counter setting value = 5). After that the trigger from X0.1 is not accepted by C0 and the current value of C0 stays at the value 5.



## 2.2.12 32-bit Counters (HC)

- Characteristics of the 32-bit counter


Item	32-bit counter		
	Up/down counter	Up counter	High-speed counter
Type	Up/down counter	Up counter	High-speed counter
Number	HC0–HC63	HC64–HC199	HC200–HC255
Direction	Counts up/down	Counts up	Counts up/down
Setting value	-2,147,483,648 to +2,147,483,647		
Specification of the counter setting value	The counter setting value can be either the constant or the value occupying two data registers (32-bit).		
Change of the current value	The counter keeps counting even after the value of the counter matches the counter setting value.		
Output contact	The contact is ON when the value of the addition counter matches the counter setting value. The contact is reset to OFF when the value of the subtraction counter matches the counter setting value.		
Reset	When the RST instruction is executed, the current value is cleared to zero, and the contact is reset to OFF.		
Action of the contact	After the DCNT instruction scan is complete, the contact acts.		

- 32-bit general-purpose addition/subtraction counter
  1. The difference between the 32-bit general-purpose addition counters and the 32-bit general-purpose subtraction counters depends on the states of the special auxiliary relays SM621–SM684. For example, the counter HC0 is an addition counter when SM621 is OFF, whereas HC0 is a subtraction counter when SM621 is ON.
  2. You can use either the constant or the value in the data registers as the counter setting value, and this setting value can be positive or negative. If you use the value in the data registers as the counter setting value, this setting value occupies two consecutive registers.
  3. For the general-purpose counter, the current value of the counter is cleared when power is lost. If the counter is latching, the current value of the counter and the state of the contact before loss of power is retained. The latched counter counts from the current value when power is restored.
  4. If the counter counts up from 2,147,483,647, the next incremental value is -2,147,483,648. If the counter counts down from -2,147,483,648, the next incremental value is 2,147,483,647.
  5. Use the high-speed counters here with DCNT instruction. The example used here is a common one. Refer to API 1004 DCNT instruction for more advanced applicaiotns.


- 32-bit high speed addition/subtraction counter

Refer to the instruction description of API1004 DCNT in AS Series Programming Manual for more details.

Example:



1. X10.0 drives SM621 to determine the counting direction (up/down) for HC0.
2. When X11.0 changes from OFF to ON, the RST instruction is executed and the PV in HC0 is cleared to 0 and its contact is OFF.
3. When X12.0 changes from OFF to ON, PV for HC0 will count up (plus 1) or count down (minus 1).
4. When PV in HC0 changes from -6 to -5, the contact HC0 changes from OFF to ON. When PV in HC0 changes from -5 to -6, the contact HC0 changes from ON to OFF.



### 2.2.13 Data Registers (D)

The data register stores 16-bit data. The highest bit represents either a positive sign or a negative sign, and the values that the data registers can store range between -32,768 to +32,767.

Two 16-bit registers can be combined into a 32-bit register; for example, (D+1, D) in which the lower number register represents the low 16 bits. The highest bit represents either a positive sign or a negative sign, and the values that the data registers can store range between -2,147,483,648 to +2,147,483,647.

- Four 16-bit registers can be combined into a 64-bit register; for example, (D+3, D+2, D+1, D) in which the lower number register represents the lower 16 bits. The highest bit represents either a positive sign or a negative sign, and the values that the data registers can store range between -9,223,372,036,854,776 to +9,223,372,036,854,775,807.
- You can also use the data registers to refresh the values in the control registers in the modules other than digital I/O modules. Refer to the ISPSOft User Manual for more information on refreshing the values in the control registers.

There are three types of registers.

- General-purpose registers: When the PLC changes to RUN, or is disconnected, the value in the register is cleared to zero. If you want to retain the data when the PLC changes to RUN, Refer to the ISPSOft User Manual for more information. Note that the value is still cleared to zero when the PLC is disconnected.
- Latched register: If the PLC is disconnected, the data in the latched register is not cleared. In other words, the value before the disconnection is retained. If you want to clear the data in the latched area, you can use the RST or ZRST instructions.
- Frequently mapped registers: If the PLC program contains a module, after each scan cycle, the PLC performs data mapping with the module. And the mapped data is stored between D26000~D29999. Refer to Chapter 8 of AS Operation Manual for more details on the automatically assigned addresses of the devices. You can also check the assigned addresses of the device while configuring in HWCONFIG of ISPSOft.

## 2.2.14 Special Data Registers (SR)

Every special data register has its own definition and specific function. System status and the error messages are stored in the special data registers. You can also use special data registers to monitor the system statuses. The special data registers and their functions are listed in the table below.

- For SR numbers marked “\*”, Refer to the additional remarks in Section 2.2.1.6 on special auxiliary relays/special data registers.
- The “R” in the attribute column indicates that the special data register can read the data; “R/W” in the attribute column indicates that it can read and write the data.
- The “-” indicates that the status of the special data register does not make any change.
- The “#” indicates that the system is set according to the status of the PLC, and you can read the setting. Refer to the related manual for more information.
- The “Y” in the column latched means it is latched, the “N” means it is non-latched; and “H” means it follows the settings in HWCONFIG.

During execution, you can edit programs in the PLC, but the settings in the HWCONFIG do not change.

SR	Function	AS300 Series	AS100/200 Series	OFF ↓ ON	STOP ↓ RUN	RUN ↓ STOP	Latched	Attribute	Default
SR0	PLC operation/operand error	○	○	0	0	-	N	R	0
SR1	The address of the operation error (32-bit)	○	○	0	0	-	N	R	0
SR2									
SR4	Grammar check error	○	○	0	0	-	N	R	0
SR5	The address of the grammar check error (32-bit)	○	○	0	0	-	N	R	0
SR6									
*SR8	Step address at which the watchdog timer is ON (32-bit)	○	○	0	-	-	N	R	0
SR9									
SM27	AS-F2AD: error flags for built-in AD	○	○	0	-	-	N	R/W	0
SR28	Last output number when the high speed output instruction is used repeatedly	○	○	-1	-1	-1	N	R	-1
SR29	The output point where the latest error occurred while executing CSFO instruction.	○	○	-1	-1	-1	N	R	-1
SR30	Record the number of the step at which frequency was outputted repeatedly from the most recent high speed output point	○	○	0	0	-	N	R	0
SR31									
SR32	The last instruction address that exceeded the allowed range	○	○	-1	-1	-	N	R	-1
SR33									
*SR36	System saves data to the memory card. This function works with SM36	○	○	0	-	-	N	R/W	0
SR38	Error flag for AS-FEN02, FPFN02, FOPC02, and FFTP01.	○	-	0	-	-	N	R/W	0
*SR40	Number of error logs	○	○	-	-	-	Y	R	0
*SR41	Error log pointer	○	○	-	-	-	Y	R	0
*SR42	Error log 1: CPU or remote number	○	○	-	-	-	Y	R	0
*SR43	Error log 1: module ID	○	○	-	-	-	Y	R	0

SR	Function			OFF ↓ ON	STOP ↓ RUN	RUN ↓ STOP	Latched	Attribute	Default
		AS300 Series	AS100/200 Series						
*SR44	Error log 1: error code	○	○	-	-	-	Y	R	0
*SR45	Error log 1: year and the month	○	○	-	-	-	Y	R	0
*SR46	Error log 1: day and the hour	○	○	-	-	-	Y	R	0
*SR47	Error log 1: minute and the second	○	○	-	-	-	Y	R	0
*SR48	Error log 2: CPU or remote number	○	○	-	-	-	Y	R	0
*SR49	Error log 2: module ID	○	○	-	-	-	Y	R	0
*SR50	Error log 2: error code	○	○	-	-	-	Y	R	0
*SR51	Error log 2: year and the month	○	○	-	-	-	Y	R	0
*SR52	Error log 2: day and the hour	○	○	-	-	-	Y	R	0
*SR53	Error log 2: minute and the second	○	○	-	-	-	Y	R	0
*SR54	Error log 3: CPU or remote number	○	○	-	-	-	Y	R	0
*SR55	Error log 3: module ID	○	○	-	-	-	Y	R	0
*SR56	Error log 3: error code	○	○	-	-	-	Y	R	0
*SR57	Error log 3: year and the month	○	○	-	-	-	Y	R	0
*SR58	Error log 3: day and the hour	○	○	-	-	-	Y	R	0
*SR59	Error log 3: minute and the second	○	○	-	-	-	Y	R	0
*SR60	Error log 4: CPU or remote number	○	○	-	-	-	Y	R	0
*SR61	Error log 4: module ID	○	○	-	-	-	Y	R	0
*SR62	Error log 4: error code	○	○	-	-	-	Y	R	0
*SR63	Error log 4: year and the month	○	○	-	-	-	Y	R	0
*SR64	Error log 4: day and the hour	○	○	-	-	-	Y	R	0
*SR65	Error log 4: minute and the second	○	○	-	-	-	Y	R	0
*SR66	Error log 5: CPU or remote number	○	○	-	-	-	Y	R	0
*SR67	Error log 5: module ID	○	○	-	-	-	Y	R	0
*SR68	Error log 5: error code	○	○	-	-	-	Y	R	0
*SR69	Error log 5: year and the month	○	○	-	-	-	Y	R	0
*SR70	Error log 5: day and the hour	○	○	-	-	-	Y	R	0
*SR71	Error log 5: minute and the second	○	○	-	-	-	Y	R	0
*SR72	Error log 6: CPU or remote number	○	○	-	-	-	Y	R	0
*SR73	Error log 6: module ID	○	○	-	-	-	Y	R	0
*SR74	Error log 6: error code	○	○	-	-	-	Y	R	0
*SR75	Error log 6: year and the month	○	○	-	-	-	Y	R	0
*SR76	Error log 6: day and the hour	○	○	-	-	-	Y	R	0
*SR77	Error log 6: minute and the second	○	○	-	-	-	Y	R	0
*SR78	Error log 7: CPU or remote number	○	○	-	-	-	Y	R	0
*SR79	Error log 7: module ID	○	○	-	-	-	Y	R	0
*SR80	Error log 7: error code	○	○	-	-	-	Y	R	0
*SR81	Error log 7: year and the month	○	○	-	-	-	Y	R	0
*SR82	Error log 7: day and the hour	○	○	-	-	-	Y	R	0

2

SR	Function	AS300 Series	AS100/200 Series	OFF ↓ ON	STOP ↓ RUN	RUN ↓ STOP	Latched	Attribute	Default
*SR83	Error log 7: minute and the second	○	○	-	-	-	Y	R	0
*SR84	Error log 8: CPU or remote number	○	○	-	-	-	Y	R	0
*SR85	Error log 8: module ID	○	○	-	-	-	Y	R	0
*SR86	Error log 8: error code	○	○	-	-	-	Y	R	0
*SR87	Error log 8: year and the month	○	○	-	-	-	Y	R	0
*SR88	Error log 8: day and the hour	○	○	-	-	-	Y	R	0
*SR89	Error log 8: minute and the second	○	○	-	-	-	Y	R	0
*SR90	Error log 9: CPU or remote number	○	○	-	-	-	Y	R	0
*SR91	Error log 9: module ID	○	○	-	-	-	Y	R	0
*SR92	Error log 9: error code	○	○	-	-	-	Y	R	0
*SR93	Error log 9: year and the month	○	○	-	-	-	Y	R	0
*SR94	Error log 9: day and the hour	○	○	-	-	-	Y	R	0
*SR95	Error log 9: minute and the second	○	○	-	-	-	Y	R	0
*SR96	Error log 10: CPU or remote number	○	○	-	-	-	Y	R	0
*SR97	Error log 10: module ID	○	○	-	-	-	Y	R	0
*SR98	Error log 10: error code	○	○	-	-	-	Y	R	0
*SR99	Error log 10: year and the month	○	○	-	-	-	Y	R	0
*SR100	Error log 10: day and the hour	○	○	-	-	-	Y	R	0
*SR101	Error log 10: minute and the second	○	○	-	-	-	Y	R	0
*SR102	Error log 11: CPU or remote number	○	○	-	-	-	Y	R	0
*SR103	Error log 11: module ID	○	○	-	-	-	Y	R	0
*SR104	Error log 11: error code	○	○	-	-	-	Y	R	0
*SR105	Error log 11: year and the month	○	○	-	-	-	Y	R	0
*SR106	Error log 11: day and the hour	○	○	-	-	-	Y	R	0
*SR107	Error log 11: minute and the second	○	○	-	-	-	Y	R	0
*SR108	Error log 12: CPU or remote number	○	○	-	-	-	Y	R	0
*SR109	Error log 12: module ID	○	○	-	-	-	Y	R	0
*SR110	Error log 12: error code	○	○	-	-	-	Y	R	0
*SR111	Error log 12: year and the month	○	○	-	-	-	Y	R	0
*SR112	Error log 12: day and the hour	○	○	-	-	-	Y	R	0
*SR113	Error log 12: minute and the second	○	○	-	-	-	Y	R	0
*SR114	Error log 13: CPU or remote number	○	○	-	-	-	Y	R	0
*SR115	Error log 13: module ID	○	○	-	-	-	Y	R	0
*SR116	Error log 13: error code	○	○	-	-	-	Y	R	0
*SR117	Error log 13: year and the month	○	○	-	-	-	Y	R	0
*SR118	Error log 13: day and the hour	○	○	-	-	-	Y	R	0
*SR119	Error log 13: minute and the second	○	○	-	-	-	Y	R	0
*SR120	Error log 14: CPU or remote number	○	○	-	-	-	Y	R	0
*SR121	Error log 14: module ID	○	○	-	-	-	Y	R	0

SR	Function	AS300 Series	AS100/200 Series	OFF	STOP	RUN	Latched	Attribute	Default
				↓ ON	↓ RUN	↓ STOP			
*SR122	Error log 14: error code	○	○	-	-	-	Y	R	0
*SR123	Error log 14: year and the month	○	○	-	-	-	Y	R	0
*SR124	Error log 14: day and the hour	○	○	-	-	-	Y	R	0
*SR125	Error log 14: minute and the second	○	○	-	-	-	Y	R	0
*SR126	Error log 15: CPU or remote number	○	○	-	-	-	Y	R	0
*SR127	Error log 15: module ID	○	○	-	-	-	Y	R	0
*SR128	Error log 15: error code	○	○	-	-	-	Y	R	0
*SR129	Error log 15: year and the month	○	○	-	-	-	Y	R	0
*SR130	Error log 15: day and the hour	○	○	-	-	-	Y	R	0
*SR131	Error log 15: minute and the second	○	○	-	-	-	Y	R	0
*SR132	Error log 16: CPU or remote number	○	○	-	-	-	Y	R	0
*SR133	Error log 16: module ID	○	○	-	-	-	Y	R	0
*SR134	Error log 16: error code	○	○	-	-	-	Y	R	0
*SR135	Error log 16: year and the month	○	○	-	-	-	Y	R	0
*SR136	Error log 16: day and the hour	○	○	-	-	-	Y	R	0
*SR137	Error log 16: minute and the second	○	○	-	-	-	Y	R	0
*SR138	Error log 17: CPU or remote number	○	○	-	-	-	Y	R	0
*SR139	Error log 17: module ID	○	○	-	-	-	Y	R	0
*SR140	Error log 17: error code	○	○	-	-	-	Y	R	0
*SR141	Error log 17: year and the month	○	○	-	-	-	Y	R	0
SR142	Error log 17: day and the hour	○	○	-	-	-	Y	R	0
*SR143	Error log 17: minute and the second	○	○	-	-	-	Y	R	0
*SR144	Error log 18: CPU or remote number	○	○	-	-	-	Y	R	0
*SR145	Error log 18: module ID	○	○	-	-	-	Y	R	0
*SR146	Error log 18: error code	○	○	-	-	-	Y	R	0
*SR147	Error log 18: year and the month	○	○	-	-	-	Y	R	0
*SR148	Error log 18: day and the hour	○	○	-	-	-	Y	R	0
*SR149	Error log 18: minute and the second	○	○	-	-	-	Y	R	0
*SR150	Error log 19: CPU or remote number	○	○	-	-	-	Y	R	0
*SR151	Error log 19: module ID	○	○	-	-	-	Y	R	0
*SR152	Error log 19: error code	○	○	-	-	-	Y	R	0
*SR153	Error log 19: year and the month	○	○	-	-	-	Y	R	0
*SR154	Error log 19: day and the hour	○	○	-	-	-	Y	R	0
*SR155	Error log 19: minute and the second	○	○	-	-	-	Y	R	0
*SR156	Error log 20: CPU or remote number	○	○	-	-	-	Y	R	0
*SR157	Error log 20: module ID	○	○	-	-	-	Y	R	0
*SR158	Error log 20: error code	○	○	-	-	-	Y	R	0
*SR159	Error log 20: year and the month	○	○	-	-	-	Y	R	0
*SR160	Error log 20: day and the hour	○	○	-	-	-	Y	R	0

SR	Function	AS300 Series	AS100/200 Series	OFF ↓ ON	STOP ↓ RUN	RUN ↓ STOP	Latched	Attribute	Default
*SR161	Error log 20: minute and the second	○	○	-	-	-	Y	R	0
SR162	Length of time that the PLC is powered on (unit: minutes) (32-bit)	○	○	-	-	-	Y	R	-
SR163									
SR166	VR0 value (works with SM166)	○	-	0	-	-	N	R	0
SR167	VR1 value (works with SM167)	○	-	0	-	-	N	R	0
*SR168	AS300 Series: Input value in the channel 1 of the Function Card 1 F2AD AS218 Series: Input value in the AD channel 1	○	○	0	-	-	N	R	0
*SR169	AS300 Series: Input value in the channel 2 of the Function Card 1 F2AD AS218 Series: Input value in the AD channel 2	○	○	0	-	-	N	R	0
*SR170	Input value in the channel 1 of the Function Card 2 F2AD	○	-	0	-	-	N	R	0
*SR171	Input value in the channel 2 of the Function Card 2 F2AD	○	-	0	-	-	N	R	0
*SR172	AS300 Series: Output value in the channel 1 of the Function Card 1 F2DA AS218 Series: Input value in the DA channel 1	○	○	0	-	0	N	R/W	0
*SR173	AS300 Series: Output value in the channel 2 of the Function Card 1 F2DA AS218 Series: Output value in the DA channel 2	○	○	0	-	0	N	R/W	0
*SR174	Output value in the channel 1 of the Function Card 2 F2DA	○	-	0	-	0	N	R/W	0
*SR175	Output value in the channel 2 of the Function Card 2 F2DA	○	-	0	-	0	N	R/W	0
SR176	Communication ID (COM11) of serial communication card 1	○	-	-	-	-	N	R	1
SR177	Communication protocol code (COM11) of serial communication card 1	○	-	-	-	-	N	R	0x24
SR178	Communication ID (COM12) of serial communication card 1	○	-	-	-	-	N	R	1
SR179	Communication protocol code (COM12) of serial communication card 1	○	-	-	-	-	N	R	0x24
SR180	The last warning error code	○	○	0	-	-	N	R	0
SR182	Communication Card 1 (COM11) timeout duration (unit: millisecond). 0: no timeout	○	-	-	-	-	N	R/W	200
SR183	Communication Card 2 (COM12) timeout duration (unit: millisecond). 0: no timeout	○	-	-	-	-	N	R/W	200
SR185	The communication cycle time for all the remote modules (unit: millisecond)	○	○	0	-	-	N	R	0
SR190	Frequency multiplication of the high speed counter group 1 (default: 1-time frequency)	○	○	1	-	-	N	R/W	1
SR191	Frequency multiplication of the high speed counter group 2 (default: 1-time frequency)	○	○	1	-	-	N	R/W	1

SR	Function			OFF ↓ ON	STOP ↓ RUN	RUN ↓ STOP	Latched	Attribute	Default
		AS300 Series	AS100/200 Series						
SR192	Frequency multiplication of the high speed counter group 3 (default: 1-time frequency)	○	○	1	-	-	N	R/W	1
SR193	Frequency multiplication of the high speed counter group 4 (default: 1-time frequency)	○	○	1	-	-	N	R/W	1
SR194	Frequency multiplication of the high speed counter group 5 (default: 1-time frequency)	○	○	1	-	-	N	R/W	1
SR195	Frequency multiplication of the high speed counter group 6 (default: 1-time frequency)	○	○	1	-	-	N	R/W	1
SR196	Frequency multiplication of the high speed counter group 7 (default: 1-time frequency)	○	○	1	-	-	N	R/W	1
SR197	Frequency multiplication of the high speed counter group 8 (default: 1-time frequency)	○	○	1	-	-	N	R/W	1
SR198	Pi ( $\pi$ ), floating-point number (32-bit)	○	○	16# 0FDB	16# 0FDB	16# 0FDB	N	R	16# 0FDB
SR199				16# 4049	16# 4049	16# 4049	N		16# 4049
*SR201	COM1 communication address	○	○	-	-	-	H	R/W	1
*SR202	COM2 communication address	○	○	-	-	-	H	R/W	1
*SR209	COM1 communication protocol	○	○	-	-	-	H	R/W	16# 0024
*SR210	COM1 communication timeout (unit: millisecond) 0: no timeout	○	○	-	-	-	H	R/W	0
*SR212	COM2 communication protocol	○	○	-	-	-	H	R/W	16# 0024
*SR213	COM2 communication timeout (unit: millisecond) 0: no timeout	○	○	-	-	-	H	R/W	0
*SR215	Function Card 1 name	○	-	-	-	-	N	R	0
*SR216	Function Card 2 Name	○	-	-	-	-	N	R	0
SR217	COM1 baudrate value (unit:100 bps)	○	○	96	-	-	H	R/W	96
SR218	COM2 baudrate value (unit:100 bps)	○	○	96	-	-	H	R/W	96
*SR220	Real-time clock (RTC) year value: 00–99 (BCD)	○	○	-	-	-	Y	R	0
*SR221	Real-time clock (RTC) month value : 01–12 (BCD)	○	○	-	-	-	Y	R	1
*SR222	Real-time clock (RTC) day value : 1–31 (BCD)	○	○	-	-	-	Y	R	1
*SR223	Real-time clock (RTC) hour value: 00–23 (BCD)	○	○	-	-	-	Y	R	0
*SR224	Real-time clock (RTC) minute value: 00–59 (BCD)	○	○	-	-	-	Y	R	0
*SR225	Real-time clock (RTC) second value: 00–59 (BCD)	○	○	-	-	-	Y	R	0
*SR226	Real-time clock (RTC) week value: 1–7 (BCD)	○	○	-	-	-	Y	R	1
*SR227	Number of download logs (maximum is 20)	○	○	-	-	-	Y	R	0
*SR228	Download log pointer	○	○	-	-	-	Y	R	0
*SR229	Download log 1: action number	○	○	-	-	-	Y	R	0
*SR230	Download log 1: year and the month	○	○	-	-	-	Y	R	0

SR	Function	AS100/200 Series		OFF	STOP	RUN	Latched	Attribute	Default
		AS300 Series		↓ ON	↓ RUN	↓ STOP			
*SR231	Download log 1: day and the hour	○	○	-	-	-	Y	R	0
*SR232	Download log 1: minute and the second	○	○	-	-	-	Y	R	0
*SR233	Download log 2: action number	○	○	-	-	-	Y	R	0
*SR234	Download log 2: year and the month	○	○	-	-	-	Y	R	0
*SR235	Download log 2: day and the hour	○	○	-	-	-	Y	R	0
*SR236	Download log 2: minute and the second	○	○	-	-	-	Y	R	0
*SR237	Download log 3: action number	○	○	-	-	-	Y	R	0
*SR238	Download log 3: year and the month	○	○	-	-	-	Y	R	0
*SR239	Download log 3: day and the hour	○	○	-	-	-	Y	R	0
*SR240	Download log 3: minute and the second	○	○	-	-	-	Y	R	0
*SR241	Download log 4: action number	○	○	-	-	-	Y	R	0
*SR242	Download log 4: year and the month	○	○	-	-	-	Y	R	0
*SR243	Download log 4: day and the hour	○	○	-	-	-	Y	R	0
*SR244	Download log 4: minute and the second	○	○	-	-	-	Y	R	0
*SR245	Download log 5: action number	○	○	-	-	-	Y	R	0
*SR246	Download log 5: year and the month	○	○	-	-	-	Y	R	0
*SR247	Download log 5: day and the hour	○	○	-	-	-	Y	R	0
*SR248	Download log 5: minute and the second	○	○	-	-	-	Y	R	0
*SR249	Download log 6: action number	○	○	-	-	-	Y	R	0
*SR250	Download log 6: year and the month	○	○	-	-	-	Y	R	0
*SR251	Download log 6: day and the hour	○	○	-	-	-	Y	R	0
*SR252	Download log 6: minute and the second	○	○	-	-	-	Y	R	0
*SR253	Download log 7: action number	○	○	-	-	-	Y	R	0
*SR254	Download log 7: year and the month	○	○	-	-	-	Y	R	0
*SR255	Download log 7: day and the hour	○	○	-	-	-	Y	R	0
*SR256	Download log 7: minute and the second	○	○	-	-	-	Y	R	0
*SR257	Download log 8: action number	○	○	-	-	-	Y	R	0
*SR258	Download log 8: year and the month	○	○	-	-	-	Y	R	0
*SR259	Download log 8: day and the hour	○	○	-	-	-	Y	R	0
*SR260	Download log 8: minute and the second	○	○	-	-	-	Y	R	0
*SR261	Download log 9: action number	○	○	-	-	-	Y	R	0
*SR262	Download log 9: year and the month	○	○	-	-	-	Y	R	0
*SR263	Download log 9: day and the hour	○	○	-	-	-	Y	R	0
*SR264	Download log 9: minute and the second	○	○	-	-	-	Y	R	0
*SR265	Download log 10: action number	○	○	-	-	-	Y	R	0
*SR266	Download log 10: year and the month	○	○	-	-	-	Y	R	0
*SR267	Download log 10: day and the hour	○	○	-	-	-	Y	R	0
*SR268	Download log 10: minute and the second	○	○	-	-	-	Y	R	0
*SR269	Download log 11: action number	○	○	-	-	-	Y	R	0

SR	Function			OFF ↓ ON	STOP ↓ RUN	RUN ↓ STOP	Latched	Attribute	Default
		AS300 Series	AS100/200 Series						
*SR270	Download log 11: year and the month	○	○	-	-	-	Y	R	0
*SR271	Download log 11: day and the hour	○	○	-	-	-	Y	R	0
*SR272	Download log 11: minute and the second	○	○	-	-	-	Y	R	0
*SR273	Download log 12: action number	○	○	-	-	-	Y	R	0
*SR274	Download log 12: year and the month	○	○	-	-	-	Y	R	0
*SR275	Download log 12: day and the hour	○	○	-	-	-	Y	R	0
*SR276	Download log 12: minute and the second	○	○	-	-	-	Y	R	0
*SR277	Download log 13: action number	○	○	-	-	-	Y	R	0
*SR278	Download log 13: year and the month	○	○	-	-	-	Y	R	0
*SR279	Download log 13: day and the hour	○	○	-	-	-	Y	R	0
*SR280	Download log 13: minute and the second	○	○	-	-	-	Y	R	0
*SR281	Download log 14: action number	○	○	-	-	-	Y	R	0
*SR282	Download log 14: year and the month	○	○	-	-	-	Y	R	0
*SR283	Download log 14: day and the hour	○	○	-	-	-	Y	R	0
*SR284	Download log 14: minute and the second	○	○	-	-	-	Y	R	0
*SR285	Download log 15: action number	○	○	-	-	-	Y	R	0
*SR286	Download log 15: year and the month	○	○	-	-	-	Y	R	0
*SR287	Download log 15: day and the hour	○	○	-	-	-	Y	R	0
*SR288	Download log 15: minute and the second	○	○	-	-	-	Y	R	0
*SR289	Download log 16: action number	○	○	-	-	-	Y	R	0
*SR290	Download log 16: year and the month	○	○	-	-	-	Y	R	0
*SR291	Download log 16: day and the hour	○	○	-	-	-	Y	R	0
*SR292	Download log 16: minute and the second	○	○	-	-	-	Y	R	0
*SR293	Download log 17: action number	○	○	-	-	-	Y	R	0
*SR294	Download log 17: year and the month	○	○	-	-	-	Y	R	0
*SR295	Download log 17: day and the hour	○	○	-	-	-	Y	R	0
*SR296	Download log 17: minute and the second	○	○	-	-	-	Y	R	0
*SR297	Download log 18: action number	○	○	-	-	-	Y	R	0
*SR298	Download log 18: year and the month	○	○	-	-	-	Y	R	0
*SR299	Download log 18: day and the hour	○	○	-	-	-	Y	R	0
*SR300	Download log 18: minute and the second	○	○	-	-	-	Y	R	0
*SR301	Download log 19: action number	○	○	-	-	-	Y	R	0
*SR302	Download log 19: year and the month	○	○	-	-	-	Y	R	0
*SR303	Download log 19: day and the hour	○	○	-	-	-	Y	R	0
*SR304	Download log 19: minute and the second	○	○	-	-	-	Y	R	0
*SR305	Download log 20: action number	○	○	-	-	-	Y	R	0
*SR306	Download log 20: year and the month	○	○	-	-	-	Y	R	0
*SR307	Download log 20: day and the hour	○	○	-	-	-	Y	R	0
*SR308	Download log 20: minute and the second	○	○	-	-	-	Y	R	0

SR	Function	AS100/200 Series		OFF	STOP	RUN	Latched	Attribute	Default
		AS300 Series	AS100/200 Series	↓ ON	↓ RUN	↓ STOP			
*SR309	Number of PLC status change logs (maximum is 20)	○	○	-	-	-	Y	R	0
*SR310	PLC status change log pointer	○	○	-	-	-	Y	R	0
*SR311	PLC status change log 1: action number	○	○	-	-	-	Y	R	0
*SR312	PLC status change log 1: year and the month	○	○	-	-	-	Y	R	0
*SR313	PLC status change log 1: day and the hour	○	○	-	-	-	Y	R	0
*SR314	PLC status change log 1: minute and the second	○	○	-	-	-	Y	R	0
*SR315	PLC status change log 2: action number	○	○	-	-	-	Y	R	0
*SR316	PLC status change log 2: year and the month	○	○	-	-	-	Y	R	0
*SR317	PLC status change log 2: day and the hour	○	○	-	-	-	Y	R	0
*SR318	PLC status change log 2: minute and the second	○	○	-	-	-	Y	R	0
*SR319	PLC status change log 3: action number	○	○	-	-	-	Y	R	0
*SR320	PLC status change log 3: year and the month	○	○	-	-	-	Y	R	0
*SR321	PLC status change log 3: day and the hour	○	○	-	-	-	Y	R	0
*SR322	PLC status change log 3: minute and the second	○	○	-	-	-	Y	R	0
*SR323	PLC status change log 4: action number	○	○	-	-	-	Y	R	0
*SR324	PLC status change log 4: year and the month	○	○	-	-	-	Y	R	0
*SR325	PLC status change log 4: day and the hour	○	○	-	-	-	Y	R	0
*SR326	PLC status change log 4: minute and the second	○	○	-	-	-	Y	R	0
*SR327	PLC status change log 5: action number	○	○	-	-	-	Y	R	0
*SR328	PLC status change log 5: year and the month	○	○	-	-	-	Y	R	0
*SR329	PLC status change log 5: day and the hour	○	○	-	-	-	Y	R	0
*SR330	PLC status change log 5: minute and the second	○	○	-	-	-	Y	R	0
*SR331	PLC status change log 6: action number	○	○	-	-	-	Y	R	0
*SR332	PLC status change log 6: year and the month	○	○	-	-	-	Y	R	0
*SR333	PLC status change log 6: day and the hour	○	○	-	-	-	Y	R	0
*SR334	PLC status change log 6: minute and the second	○	○	-	-	-	Y	R	0
*SR335	PLC status change log 7: action number	○	○	-	-	-	Y	R	0
*SR336	PLC status change log 7: year and the month	○	○	-	-	-	Y	R	0
*SR337	PLC status change log 7: day and the hour	○	○	-	-	-	Y	R	0
*SR338	PLC status change log 7: minute and the second	○	○	-	-	-	Y	R	0
*SR339	PLC status change log 8: action number	○	○	-	-	-	Y	R	0
*SR340	PLC status change log 8: year and the month	○	○	-	-	-	Y	R	0
*SR341	PLC status change log 8: day and the hour	○	○	-	-	-	Y	R	0
*SR342	PLC status change log 8: minute and the second	○	○	-	-	-	Y	R	0
*SR343	PLC status change log 9: action number	○	○	-	-	-	Y	R	0
*SR344	PLC status change log 9: year and the month	○	○	-	-	-	Y	R	0
*SR345	PLC status change log 9: day and the hour	○	○	-	-	-	Y	R	0
*SR346	PLC status change log 9: minute and the second	○	○	-	-	-	Y	R	0
*SR347	PLC status change log 10: action number	○	○	-	-	-	Y	R	0

SR	Function	AS300 Series	AS100/200 Series	OFF	STOP	RUN	Latched	Attribute	Default
				↓ ON	↓ RUN	↓ STOP			
*SR348	PLC status change log 10: year and the month	○	○	-	-	-	Y	R	0
*SR349	PLC status change log 10: day and the hour	○	○	-	-	-	Y	R	0
*SR350	PLC status change log 10: minute and the second	○	○	-	-	-	Y	R	0
*SR351	PLC status change log 11: action number	○	○	-	-	-	Y	R	0
*SR352	PLC status change log 11: year and the month	○	○	-	-	-	Y	R	0
*SR353	PLC status change log 11: day and the hour	○	○	-	-	-	Y	R	0
*SR354	PLC status change log 11: minute and the second	○	○	-	-	-	Y	R	0
*SR355	PLC status change log 12: action number	○	○	-	-	-	Y	R	0
*SR356	PLC status change log 12: year and the month	○	○	-	-	-	Y	R	0
*SR357	PLC status change log 12: day and the hour	○	○	-	-	-	Y	R	0
*SR358	PLC status change log 12: minute and the second	○	○	-	-	-	Y	R	0
*SR359	PLC status change log 13: action number	○	○	-	-	-	Y	R	0
*SR360	PLC status change log 13: year and the month	○	○	-	-	-	Y	R	0
*SR361	PLC status change log 13: day and the hour	○	○	-	-	-	Y	R	0
*SR362	PLC status change log 13: minute and the second	○	○	-	-	-	Y	R	0
*SR363	PLC status change log 14: action number	○	○	-	-	-	Y	R	0
*SR364	PLC status change log 14: year and the month	○	○	-	-	-	Y	R	0
*SR365	PLC status change log 14: day and the hour	○	○	-	-	-	Y	R	0
*SR366	PLC status change log 14: minute and the second	○	○	-	-	-	Y	R	0
*SR367	PLC status change log 15: action number	○	○	-	-	-	Y	R	0
*SR368	PLC status change log 15: year and the month	○	○	-	-	-	Y	R	0
*SR369	PLC status change log 15: day and the hour	○	○	-	-	-	Y	R	0
*SR370	PLC status change log 15: minute and the second	○	○	-	-	-	Y	R	0
*SR371	PLC status change log 16: action number	○	○	-	-	-	Y	R	0
*SR372	PLC status change log 16: year and the month	○	○	-	-	-	Y	R	0
*SR373	PLC status change log 16: day and the hour	○	○	-	-	-	Y	R	0
*SR374	PLC status change log 16: minute and the second	○	○	-	-	-	Y	R	0
*SR375	PLC status change log 17: action number	○	○	-	-	-	Y	R	0
*SR376	PLC status change log 17: year and the month	○	○	-	-	-	Y	R	0
*SR377	PLC status change log 17: day and the hour	○	○	-	-	-	Y	R	0
*SR378	PLC status change log 17: minute and the second	○	○	-	-	-	Y	R	0
*SR379	PLC status change log 18: action number	○	○	-	-	-	Y	R	0
*SR380	PLC status change log 18: year and the month	○	○	-	-	-	Y	R	0
*SR381	PLC status change log 18: day and the hour	○	○	-	-	-	Y	R	0
*SR382	PLC status change log 18: minute and the second	○	○	-	-	-	Y	R	0
*SR383	PLC status change log 19: action number	○	○	-	-	-	Y	R	0
*SR384	PLC status change log 19: year and the month	○	○	-	-	-	Y	R	0
*SR385	PLC status change log 19: day and the hour	○	○	-	-	-	Y	R	0
*SR386	PLC status change log 19: minute and the second	○	○	-	-	-	Y	R	0

SR	Function	AS100/200 Series		OFF	STOP	RUN	Latched	Attribute	Default
		AS300 Series	AS100/200 Series	↓ ON	↓ RUN	↓ STOP			
*SR387	PLC status change log 20: action number	○	○	-	-	-	Y	R	0
*SR388	PLC status change log 20: year and the month	○	○	-	-	-	Y	R	0
*SR389	PLC status change log 20: day and the hour	○	○	-	-	-	Y	R	0
*SR390	PLC status change log 20: minute and the second	○	○	-	-	-	Y	R	0
*SR391	Real-time clock (RTC) year value: 00–99 (BCD)	○	○	-	-	-	Y	R	0
*SR392	Real-time clock (RTC) month value: 01–12 (BCD)	○	○	-	-	-	Y	R	1
*SR393	Real-time clock (RTC) day value: 1–31 (BCD)	○	○	-	-	-	Y	R	1
*SR394	Real-time clock (RTC) hour value: 00–23 (BCD)	○	○	-	-	-	Y	R	0
*SR395	Real-time clock (RTC) minute value: 00–59 (BCD)	○	○	-	-	-	Y	R	0
*SR396	Real-time clock (RTC) second value: 00–59 (BCD)	○	○	-	-	-	Y	R	0
*SR397	Real-time clock (RTC) week value: 1–7 (BCD)	○	○	-	-	-	Y	R	1
SR403	Funciton card 1 firmware version (e.g. 10670 = V1.06.70; 0 = no firmware)	○	○	-	-	-	N	R	0
SR404	Funciton card 2 firmware version (e.g. 10670 = V1.06.70; 0 = no firmware)	○	○	-	-	-	N	R	0
SR405	PLC main processor firmware version (e.g. 10670 = V1.06.70; 0 = no firmware)	○	○	-	-	-	Y	R	-
SR406	PLC sub-processor firmware version (e.g. 0 = no sub-processor)	○	○	-	-	-	Y	R	-
SR407	When the PLC runs, the value in SR407 increases by one every second. SR407 counts from 0 to 32767, and then from -32768 to 0.	○	○	0	0	-	N	R/W	0
SR408	When the PLC runs, the value in SR408 increases by one every scan cycle. SR408 counts from 0 to 32767, and then from -32768 to 0.	○	○	0	0	-	N	R/W	0
SR411	The current scan time is stored in SR411 and SR412 (unit of measurement is 100 microseconds).	○	○	0	-	-	N	R	0
SR412	Milliseconds are stored in SR411 (range is 0–65535). Microseconds are stored in SR412 (the range is 0–900). For example, if SR411=12 and SR412=300, then the current scan time is 12.3 milliseconds.	○	○	0	-	-	N	R	0
SR413	The maximum scan time is stored in SR413 and SR414 (unit of measurement is 100 microseconds). The value of the millisecond is stored in SR413.	○	○	0	-	-	N	R	0
SR414									
SR415	The minimum scan time is stored in SR415 and SR416 (unit of measurement is 100 microseconds). The value of the millisecond is stored in SR415.	○	○	0	-	-	N	R	0
SR416									
SR421	Duration of the timer interrupt I601 (unit: millisecond). The default is 0, meaning the system uses the settings in HWCONFIG.	○	○	0	0	-	N	R/W	0
SR422	Duration of the timer interrupt I602 (unit: millisecond). The default is 0, meaning the system uses the settings in HWCONFIG.	○	○	0	0	-	N	R/W	0

SR	Function	AS300 Series	AS100/200 Series	OFF ↓ ON	STOP ↓ RUN	RUN ↓ STOP	Latched	Attribute	Default
SR423	Duration of the timer interrupt I603 (unit: millisecond). The default is 0, meaning the system uses the settings in HWCONFIG.	○	○	0	0	-	N	R/W	0
SR424	Duration of the timer interrupt I604 (unit: 0.1 millisecond). The default is 0, meaning the system uses the settings in HWCONFIG.	○	○	0	0	-	N	R/W	0
SR440	MAC address	○	○	-	-	-	Y	R	-
SR441	(Example: 12:34:56:78:9A:BC => SR440=16#1234, SR441=16#5678, SR442=16#9ABC)	○	○	-	-	-	Y	R	-
SR442	(Updates once, when the PLC is supplied with power)	○	○	-	-	-	Y	R	-
SR443	PLC serial number	○	○	-	-	-	Y	R	-
SR444	(Updates once, when the PLC is supplied with power)	○	○	-	-	-	Y	R	-
SR445	EX : AS324MTAW15500012	○	○	-	-	-	Y	R	-
SR446	AS → SR443 = 16#5341	○	○	-	-	-	Y	R	-
SR447	32 → SR444 = 16#3233	○	○	-	-	-	Y	R	-
SR448	4M → SR445 = 16#4D34	○	○	-	-	-	Y	R	-
SR449	TA → SR446 = 16#4154	○	○	-	-	-	Y	R	-
SR450	W1 → SR447 = 16#3157	○	○	-	-	-	Y	R	-
SR451	55 → SR448 = 16#3535 00 → SR449 = 16#3030 01 → SR450 = 16#3130 2 → SR451 = 16#0032 (Updates once, when the PLC is supplied with power)	○	○	-	-	-	Y	R	-
*SR453	If an error occurs during the operation of the memory card, the error code is recorded.	○	○	-	-	-	Y	R	0
SR460	Y0.0/axis 1 (Y0.0/Y0.1) position (unit: number of pulse)	○	○	-	-	-	Y	R/W	0
SR461									
SR462	Axis 1 (Y0.0/Y0.1) output mode	○	○	-	-	-	Y	R/W	0
SR463	Axis 1 (Y0.0/Y0.1) starting/ending frequency	○	○	-	-	-	Y	R/W	200
SR464	Axis 1 (Y0.0/Y0.1) accelerating time	○	○	-	-	-	Y	R/W	200
SR465	Axis 1 (Y0.0/Y0.1) decelerating time	○	○	-	-	-	Y	R/W	200
SR466	Axis 1 (Y0.0/Y0.1) JOG frequency	○	○	-	-	-	Y	R/W	200
SR467	Axis 1 (Y0.0/Y0.1) number in the current position planning table	○	○	0	0	-	N	R	0
SR468	Axis 1 (Y0.0/Y0.1) numerator value transferred from the machine unit	○	○	-	-	-	H	R/W	0
SR469	Axis 1 (Y0.0/Y0.1) denominator value transferred from the machine unit	○	○	-	-	-	H	R/W	0
SR470	Axis 1 (Y0.0/Y0.1) position of the machine unit (single-precision floating-point values)	○	○	-	-	-	Y	R	0
SR471									
SR472	Axis 1 (Y0.0/Y0.1) target frequency for fixed slope	○	○	-	-	-	Y	R	0

SR	Function	AS100/200 Series		OFF	STOP	RUN	Latched	Attribute	Default
		AS300 Series		↓ ON	↓ RUN	↓ STOP			
SR473									
SR474	Y0.1 position (unit: number of pulse)	○	○	-	-	-	Y	R/W	0
SR475									
SR476	Y0.1 starting/ending frequency	○	○	-	-	-	Y	R/W	200
SR477	Y0.1 accelerating/decelerating time	○	○	-	-	-	Y	R/W	200
SR478	Axis 1 (Y0.0) backlash compensation pulse	○	○	-	-	-	Y	R/W	0
SR479	Y0.1 backlash compensation pulse	○	○	-	-	-	Y	R/W	0
SR480	Y0.2/axis 2 (Y0.2/Y0.3) position (unit: number of pulse)	○	○	-	-	-	Y	R/W	0
SR481									
SR482	Y0.2/axis 2 (Y0.2/Y0.3) output mode	○	○	-	-	-	Y	R/W	0
SR483	Y0.2/axis 2 (Y0.2/Y0.3) starting/ending frequency	○	○	-	-	-	Y	R/W	200
SR484	Y0.2/axis 2 (Y0.2/Y0.3) accelerating time	○	○	-	-	-	Y	R/W	200
SR485	Y0.2/axis 2 (Y0.2/Y0.3) decelerating time	○	○	-	-	-	Y	R/W	200
SR486	Y0.2/axis 2 (Y0.2/Y0.3) JOG frequency	○	○	-	-	-	Y	R/W	200
SR487	Y0.2/axis 2 (Y0.2/Y0.3) number in the current position planning table	○	○	0	0	-	N	R	0
SR488	Y0.2/axis 2 (Y0.2/Y0.3) numerator value transferred from the machine unit	○	○	-	-	-	H	R/W	0
SR489	Y0.2/axis 2 (Y0.2/Y0.3) denominator value transferred from the machine unit	○	○	-	-	-	H	R/W	0
SR490	Y0.2/axis 2 (Y0.2/Y0.3) position of the Machine unit (single-precision floating-point values)	○	○	-	-	-	Y	R	0
SR491									
SR492	Y0.2/axis 2 (Y0.2/Y0.3) target frequency for fixed slope	○	○	-	-	-	Y	R	0
SR493									
SR494	Y0.3 position (unit: number of pulse)	○	○	-	-	-	Y	R/W	0
SR495									
SR496	Y0.3 starting/ending frequency	○	○	-	-	-	Y	R/W	200
SR497	Y0.3 accelerating/decelerating time	○	○	-	-	-	Y	R/W	200
SR498	Axis 2 (Y0.2) backlash compensation pulse	○	○	-	-	-	Y	R/W	0
SR499	Y0.3 backlash compensation pulse	○	○	-	-	-	Y	R/W	0
SR500	Y0.4/axis 3 (Y0.4/Y0.5) position (unit: number of pulse)	○	○	-	-	-	Y	R/W	0
SR501									
SR502	Y0.4/axis 3 (Y0.4/Y0.5) output mode	○	○	-	-	-	Y	R/W	0
SR503	Y0.4/axis 3 (Y0.4/Y0.5) starting/ending frequency	○	○	-	-	-	Y	R/W	200
SR504	Y0.4/axis 3 (Y0.4/Y0.5) accelerating time	○	○	-	-	-	Y	R/W	200
SR505	Y0.4/axis 3 (Y0.4/Y0.5) decelerating time	○	○	-	-	-	Y	R/W	200
SR506	Y0.4/axis 3 (Y0.4/Y0.5) JOG frequency	○	○	-	-	-	Y	R/W	200
SR507	Y0.4/axis 3 (Y0.4/Y0.5) number in the current position planning table	○	○	0	0	-	N	R	0

SR	Function	AS100/200 Series		OFF ↓ ON	STOP ↓ RUN	RUN ↓ STOP	Latched	Attribute	Default
		AS300 Series	AS100/200 Series						
SR508	Y0.4/axis 3 (Y0.4/Y0.5) numerator value transferred from the machine unit	○	○	-	-	-	H	R/W	0
SR509	Y0.4/axis 3 (Y0.4/Y0.5) denominator value transferred from the machine unit	○	○	-	-	-	H	R/W	0
SR510	Y0.4/axis 3 (Y0.4/Y0.5) position of the Machine unit (single-precision floating-point values)	○	○	-	-	-	Y	R	0
SR511									
SR512	Y0.4/axis 3 (Y0.4/Y0.5) target frequency for fixed slope	○	○	-	-	-	Y	R	0
SR513									
SR514	Y0.5 position (unit: number of pulse)	○	○	-	-	-	Y	R/W	0
SR515									
SR516	Y0.5 starting/ending frequency	○	○	-	-	-	Y	R/W	200
SR517	Y0.5 accelerating/decelerating time	○	○	-	-	-	Y	R/W	200
SR518	Axis 3 (Y0.4) backlash compensation pulse	○	○	-	-	-	Y	R/W	0
SR519	Y0.5 backlash compensation pulse	○	○	-	-	-	Y	R/W	0
SR520	Y0.6/axis 4 (Y0.6/Y0.7) position (unit: number of pulse)	○	○	-	-	-	Y	R/W	0
SR521									
SR522	Y0.6/axis 4 (Y0.6/Y0.7) output mode	○	○	-	-	-	Y	R/W	0
SR523	Y0.6/axis 4 (Y0.6/Y0.7) starting/ending frequency	○	○	-	-	-	Y	R/W	200
SR524	Y0.6/axis 4 (Y0.6/Y0.7) accelerating time	○	○	-	-	-	Y	R/W	200
SR525	Y0.6/axis 4 (Y0.6/Y0.7) decelerating time	○	○	-	-	-	Y	R/W	200
SR526	Y0.6/axis 4 (Y0.6/Y0.7) JOG frequency	○	○	-	-	-	Y	R/W	200
SR527	Y0.6/axis 4 (Y0.6/Y0.7) number in the current position planning table	○	○	0	0	-	N	R	0
SR528	Y0.6/axis 4 (Y0.6/Y0.7) numerator value transferred from the machine unit	○	○	-	-	-	H	R/W	0
SR529	Y0.6/axis 4 (Y0.6/Y0.7) denominator value transferred from the machine unit	○	○	-	-	-	H	R/W	0
SR530	Y0.6/axis 4 (Y0.6/Y0.7) position of the Machine unit(single-precision floating-point values)	○	○	-	-	-	Y	R	0
SR531									
SR532	Y0.6/axis 4 (Y0.6/Y0.7) target frequency for fixed slope	○	○	-	-	-	Y	R	0
SR533									
SR534	Y0.7 position (unit: number of pulse)	○	○	-	-	-	Y	R/W	0
SR535									
SR536	Y0.7 starting/ending frequency	○	○	-	-	-	Y	R/W	200
SR537	Y0.7 accelerating/decelerating time	○	○	-	-	-	Y	R/W	200
SR538	Axis 4 (Y0.6) backlash compensation pulse	○	○	-	-	-	Y	R/W	0
SR539	Y0.7 backlash compensation pulse	○	○	-	-	-	Y	R/W	0
SR540	Y0.8/axis 5 (Y0.8/Y0.9) position where (unit: number of pulse)	○	○	-	-	-	Y	R/W	0
SR541									
SR542	The axis 5 (Y0.8/Y0.9) output mode	○	○	-	-	-	Y	R/W	0

SR	Function	AS100/200 Series		OFF	STOP	RUN	Latched	Attribute	Default
		AS300 Series	AS100/200 Series	↓ ON	↓ RUN	↓ STOP			
SR543	Y0.8/axis 5 (Y0.8/Y0.9) starting/ending frequency	○	○	-	-	-	Y	R/W	200
SR544	Y0.8/axis 5 (Y0.8/Y0.9) accelerating time	○	○	-	-	-	Y	R/W	200
SR545	Y0.8/axis 5 (Y0.8/Y0.9) decelerating time	○	○	-	-	-	Y	R/W	200
SR546	Y0.8/axis 5 (Y0.8/Y0.9) JOG frequency	○	○	-	-	-	Y	R/W	200
SR547	Y0.8/axis 5 (Y0.8/Y0.9) number in the current position planning table	○	○	0	0	-	N	R	0
SR548	Y0.8/axis 5 (Y0.8/Y0.9) numerator value transferred from the machine unit	○	○	-	-	-	H	R/W	0
SR549	Y0.8/axis 5 (Y0.8/Y0.9) denominator value transferred from the machine unit	○	○	-	-	-	H	R/W	0
SR550	Y0.8/axis 5 (Y0.8/Y0.9) position of the Machine unit (single-precision floating-point values)	○	○	-	-	-	Y	R	0
SR551									
SR552	Y0.8/axis 5 (Y0.8/Y0.9) target frequency for fixed slope	○	○	-	-	-	Y	R	0
SR553									
SR554	Y0.9 position (unit: number of pulse)	○	○	-	-	-	Y	R/W	0
SR555									
SR556	Y0.9 starting/ending frequency	○	○	-	-	-	Y	R/W	200
SR557	Y0.9 accelerating/decelerating time	○	○	-	-	-	Y	R/W	200
SR558	Axis 5 (Y0.8) backlash compensation pulse	○	○	-	-	-	Y	R/W	0
SR559	Y0.9 backlash compensation pulse	○	○	-	-	-	Y	R/W	0
SR560	Y0.10/axis 6 (Y0.10/Y0.11) position (unit: number of pulse)	○	○	-	-	-	Y	R/W	0
SR561									
SR562	Y0.10/axis 6 (Y0.10/Y0.11) output mode	○	○	-	-	-	Y	R/W	0
SR563	Y0.10/axis 6 (Y0.10/Y0.11) starting/ending frequency	○	○	-	-	-	Y	R/W	200
SR564	Y0.10/axis 6 (Y0.10/Y0.11) accelerating time	○	○	-	-	-	Y	R/W	200
SR565	Y0.10/axis 6 (Y0.10/Y0.11) decelerating time	○	○	-	-	-	Y	R/W	200
SR566	Y0.10/axis 6 (Y0.10/Y0.11) JOG frequency	○	○	-	-	-	Y	R/W	200
SR567	Y0.10/axis 6 (Y0.10/Y0.11) number in the current position planning table	○	○	0	0	-	N	R	0
SR568	Y0.10/axis 6 (Y0.10/Y0.11) numerator value transferred from the machine unit	○	○	-	-	-	H	R/W	0
SR569	Y0.10/axis 6 (Y0.10/Y0.11) denominator value transferred from the machine unit	○	○	-	-	-	H	R/W	0
SR570	Y0.10/axis 6 (Y0.10/Y0.11) position of the Machine unit (single-precision floating-point values)	○	○	-	-	-	Y	R	0
SR571									
SR572	Y0.10/axis 6 (Y0.10/Y0.11) target frequency for fixed slope	○	○	-	-	-	Y	R	0
SR573									
SR574	Y0.11 position (unit: number of pulse)	○	○	-	-	-	Y	R/W	0
SR575									
SR576	Y0.11 starting/ending frequency	○	○	-	-	-	Y	R/W	200

SR	Function	AS300 Series	AS100/200 Series	OFF	STOP	RUN	Latched	Attribute	Default
				↓ ON	↓ RUN	↓ STOP			
SR577	Y0.11 accelerating/decelerating time	○	○	-	-	-	Y	R/W	200
SR578	Axis 6 (Y0.10) backlash compensation pulse	○	○	-	-	-	Y	R/W	0
SR579	Y0.11 backlash compensation pulse	○	○	-	-	-	Y	R/W	0
*SR580	Axis 1 (Y0.0/Y0.1) positive limit in ISPSOft (unit: number of pulse)	○	○	-	-	-	H	R/W	0
*SR581									
*SR582	Axis 1 (Y0.0/Y0.1) negative limit in ISPSOft (unit: number of pulse)	○	○	-	-	-	H	R/W	0
*SR583									
*SR584	Axis 2 (Y0.2/Y0.3) positive limit in ISPSOft (unit: number of pulse)	○	○	-	-	-	H	R/W	0
*SR585									
*SR586	Axis 2 (Y0.2/Y0.3) negative limit in ISPSOft (unit: number of pulse)	○	○	-	-	-	H	R/W	0
*SR587									
*SR588	Axis 3(Y0.4/Y0.5) positive limit in ISPSOft (unit: number of pulse)	○	○	-	-	-	H	R/W	0
*SR589									
*SR590	Axis 3(Y0.4/Y0.5) negative limit in ISPSOft (unit: number of pulse)	○	○	-	-	-	H	R/W	0
*SR591									
*SR592	Axis 4(Y0.6/Y0.7) positive limit in ISPSOft (unit: number of pulse)	○	○	-	-	-	H	R/W	0
*SR593									
*SR594	Axis 4(Y0.6/Y0.7) negative limit in ISPSOft (unit: number of pulse)	○	○	-	-	-	H	R/W	0
*SR595									
*SR596	Axis 5(Y0.8/Y0.9) positive limit in ISPSOft (unit: number of pulse)	○	○	-	-	-	H	R/W	0
*SR597									
*SR598	Axis 5(Y0.8/Y0.9) negative limit in ISPSOft (unit: number of pulse)	○	○	-	-	-	H	R/W	0
*SR599									
*SR600	Axis 6(Y0.10/Y0.11) positive limit in ISPSOft (unit: number of pulse)	○	○	-	-	-	H	R/W	0
*SR601									
*SR602	Axis 6(Y0.10/Y0.11) negative limit in ISPSOft (unit: number of pulse)	○	○	-	-	-	H	R/W	0
*SR603									
SR610	Axis 1 (Y0.0/Y0.1) current output speed (unit: Hz)	○	○	0	0	0	N	R	0
SR611									
SR612	axis 2 (Y0.2/Y0.3) current output speed (unit: Hz)	○	○	0	0	0	N	R	0
SR613									
SR614	Axis 3 (Y0.4/Y0.5) current output speed (unit: Hz)	○	○	0	0	0	N	R	0
SR615									
SR616	Axis 4 (Y0.6/Y0.7) current output speed (unit: Hz)	○	○	0	0	0	N	R	0
SR617									
SR618	Axis 5 (Y0.8/Y0.9) current output speed (unit: Hz)	○	○	0	0	0	N	R	0
SR619									
SR620	Axis 6 (Y0.10/Y0.11) current output speed (unit: Hz)	○	○	0	0	0	N	R	0
SR621									

SR	Function	AS300 Series	AS100/200 Series	OFF ↓ ON	STOP ↓ RUN	RUN ↓ STOP	Latched	Attribute	Default
SR623	External input interrupt condition: the X0.0–X0.15 input points are falling-edge triggered	○	○	FFFF	FFFF	-	N	R	FFFF
SR624	External interrupt condition: the X0.0–X0.15 input points are rising-edge triggered	○	○	FFFF	FFFF	-	N	R	FFFF
SR625	Condition of the high-speed comparison interrupt I200–I233	○	○	FFFF	FFFF	-	N	R	FFFF
SR626	Condition of the high-speed comparison interrupt I240–I253	○	○	FFFF	FFFF	-	N	R	FFFF
SR627	Condition of the high-speed comparison interrupt I260–I267	○	○	FFFF	FFFF	-	N	R	FFFF
SR628	Condition of the communication interrupts I300–I307	○	○	FFFF	FFFF	-	N	R	FFFF
SR629	Condition of the output interrupts I500–I505	○	○	FFFF	FFFF	-	N	R	FFFF
SR630	Condition of the output interrupts I510–I519	○	○	FFFF	FFFF	-	N	R	FFFF
SR632	Condition of the timer interrupts I601–I604	○	○	FFFF	FFFF	-	N	R	FFFF
SR633	Condition of the extension module interrupts I400–I415	○	○	FFFF	FFFF	-	N	R	FFFF
SR634	Condition of the extension module interrupts I416–I431	○	○	FFFF	FFFF	-	N	R	FFFF
SR640	Set the outputting time 0-20ms sooner (unit: 1ms) to work with the Y0.0 output pulse	○	○	0	-	-	N	R/W	0
SR641	Set the outputting time 0-20ms sooner (unit: 1ms) to work with the Y0.1 output pulse	○	○	0	-	-	N	R/W	0
SR642	Set the outputting time 0-20ms sooner (unit: 1ms) to work with the Y0.2 output pulse	○	○	0	-	-	N	R/W	0
SR643	Set the outputting time 0-20ms sooner (unit: 1ms) to work with the Y0.3 output pulse	○	○	0	-	-	N	R/W	0
SR644	Set the outputting time 0-20ms sooner (unit: 1ms) to work with the Y0.4 output pulse	○	○	0	-	-	N	R/W	0
SR645	Set the outputting time 0-20ms sooner (unit: 1ms) to work with the Y0.5 output pulse	○	○	0	-	-	N	R/W	0
SR646	Set the outputting time 0-20ms sooner (unit: 1ms) to work with the Y0.6 output pulse	○	○	0	-	-	N	R/W	0
SR647	Set the outputting time 0-20ms sooner (unit: 1ms) to work with the Y0.7 output pulse	○	○	0	-	-	N	R/W	0
SR648	Set the outputting time 0-20ms sooner (unit: 1ms) to work with the Y0.8 output pulse	○	○	0	-	-	N	R/W	0
SR649	Set the outputting time 0-20ms sooner (unit: 1ms) to work with the Y0.9 output pulse	○	○	0	-	-	N	R/W	0
SR650	Set the outputting time 0-20ms sooner (unit: 1ms) to work with the Y0.10 output pulse	○	○	0	-	-	N	R/W	0
SR651	Set the outputting time 0-20ms sooner (unit: 1ms) to work with the Y0.11 output pulse	○	○	0	-	-	N	R/W	0
*SR652	Pulse number in acceleration from the latest position output (32-bit)	○	○	0	0	-	N	R	0
*SR653		○	○	0	0	-	N	R	0
*SR654	Pulse number in deceleration from the latest position	○	○	0	0	-	N	R	0

SR	Function	AS300 Series	AS100/200 Series	OFF	STOP	RUN	Latched	Attribute	Default
				↓ ON	↓ RUN	↓ STOP			
*SR655	output (32-bit)	○	○	0	0	-	N	R	0
SR656	SDO abort code for ECAT communication of Delta servo/inverter (32-bit)	○	-	0	0	-	N	R/W	0
SR658	The CAN communication ID of Delta servo/inverter where an error occurs	○	○	0	-	-	N	R/W	0
	The ECAT communication ID of Delta servo/inverter where an error occurs	○	-	0	-	-	N	R/W	0
SR659	Error code for CAN communication of Delta servo/inverter	○	○	0	-	-	N	R/W	0
	Error code for ECAT communication of Delta servo/inverter	○	-	0	-	-	N	R/W	0
SR661	PR command on CAN communication ID 1 of Delta servo	○	○	0	-	-	N	R	0
	PR command on ECAT communication ID 1 of Delta servo Current state of ECAT communication ID 1 of Delta inverter	○	-	0	-	-	N	R	0
SR662	PR command on CAN communication ID 2 of Delta servo	○	○	0	-	-	N	R	0
	PR command on ECAT communication ID 2 of Delta servo Current state of ECAT communication ID 2 of Delta inverter	○	-	0	-	-	N	R	0
SR663	PR command on CAN communication ID 3 of Delta servo	○	○	0	-	-	N	R	0
	PR command on ECAT communication ID 3 of Delta servo Current state of ECAT communication ID 3 of Delta inverter	○	-	0	-	-	N	R	0
SR664	PR command on CAN communication ID 4 of Delta servo	○	○	0	-	-	N	R	0
	PR command on ECAT communication ID 4 of Delta servo Current state of ECAT communication ID 4 of Delta inverter	○	-	0	-	-	N	R	0
SR665	PR command on CAN communication ID 5 of Delta servo	○	○	0	-	-	N	R	0
	PR command on ECAT communication ID 5 of Delta servo Current state of ECAT communication ID 1 of Delta inverter	○	-	0	-	-	N	R	0
SR666	PR command on CAN communication ID 6 of Delta servo	○	○	0	-	-	N	R	0
	PR command on ECAT communication ID 6 of Delta servo Current state of ECAT communication ID 6 of Delta inverter	○	-	0	-	-	N	R	0
SR667	PR command on CAN communication ID 7 of Delta servo	○	○	0	-	-	N	R	0
	PR command on ECAT communication ID 7 of Delta servo Current state of ECAT communication ID 7 of Delta inverter	○	-	0	-	-	N	R	0
SR668	PR command on CAN communication ID 8 of Delta servo	○	○	0	-	-	N	R	0
	PR command on ECAT communication ID 8 of Delta servo Current state of ECAT communication ID 8 of Delta inverter	○	-	0	-	-	N	R	0
SR671	Alarm code for CAN communication ID 1 of Delta servo	○	○	0	-	-	N	R	0
	Alarm code for ECAT communication ID 1 of Delta servo	○	-	0	-	-	N	R	0

SR	Function			OFF	STOP	RUN	Latched	Attribute	Default
		AS300 Series	AS100/200 Series	↓ ON	↓ RUN	↓ STOP			
SR672	Alarm code for CAN communication ID 2 of Delta servo	○	○	0	-	-	N	R	0
	Alarm code for ECAT communication ID 2 of Delta servo	○	-	0	-	-	N	R	0
SR673	Alarm code for CAN communication ID 3 of Delta servo	○	○	0	-	-	N	R	0
	Alarm code for ECAT communication ID 3 of Delta servo	○	-	0	-	-	N	R	0
SR674	Alarm code for CAN communication ID 4 of Delta servo	○	○	0	-	-	N	R	0
	Alarm code for ECAT communication ID 4 of Delta servo	○	-	0	-	-	N	R	0
SR675	Alarm code for CAN communication ID 5 of Delta servo	○	○	0	-	-	N	R	0
	Alarm code for ECAT communication ID 5 of Delta servo	○	-	0	-	-	N	R	0
SR676	Alarm code for CAN communication ID 6 of Delta servo	○	○	0	-	-	N	R	0
	Alarm code for ECAT communication ID 6 of Delta servo	○	-	0	-	-	N	R	0
SR677	Alarm code for CAN communication ID 7 of Delta servo	○	○	0	-	-	N	R	0
	Alarm code for ECAT communication ID 7 of Delta servo	○	-	0	-	-	N	R	0
SR678	Alarm code for CAN communication ID 8 of Delta servo	○	○	0	-	-	N	R	0
	Alarm code for ECAT communication ID 8 of Delta servo	○	-	0	-	-	N	R	0
SR681	Current DO state of the CAN communication ID 1 of Delta servo	○	○	0	-	-	N	R	0
	Current DO state of the ECAT communication ID 1 of Delta servo	○	-	0	-	-	N	R	0
SR682	Current DO state of the CAN communication ID 2 of Delta servo	○	○	0	-	-	N	R	0
	Current DO state of the ECAT communication ID 2 of Delta servo	○	-	0	-	-	N	R	0
SR683	Current DO state of the CAN communication ID 3 of Delta servo	○	○	0	-	-	N	R	0
	Current DO state of the ECAT communication ID 3 of Delta servo	○	-	0	-	-	N	R	0
SR684	Current DO state of the CAN communication ID 4 of Delta servo	○	○	0	-	-	N	R	0
	Current DO state of the ECAT communication ID 4 of Delta servo	○	-	0	-	-	N	R	0
SR685	Current DO state of the CAN communication ID 5 of Delta servo	○	○	0	-	-	N	R	0
	Current DO state of the ECAT communication ID 5 of Delta servo	○	-	0	-	-	N	R	0
SR686	Current DO state of the CAN communication ID 6 of Delta servo	○	○	0	-	-	N	R	0
	Current DO state of the ECAT communication ID 6 of Delta servo	○	-	0	-	-	N	R	0
SR687	Current DO state of the CAN communication ID 7 of Delta servo	○	○	0	-	-	N	R	0
	Current DO state of the ECAT communication ID 7 of Delta servo	○	-	0	-	-	N	R	0

SR	Function	AS300 Series	AS100/200 Series	OFF ↓ ON	STOP ↓ RUN	RUN ↓ STOP	Latched	Attribute	Default
SR688	Current DO state of the CAN communication ID 8 of Delta servo	○	○	0	-	-	N	R	0
	Current DO state of the ECAT communication ID 8 of Delta servo	○	-	0	-	-	N	R	0
SR691	Current position of CAN communication ID 1 of Delta servo (32-bit)	○	○	0	-	-	N	R	0
SR692	Current position of ECAT communication ID 1 of Delta servo (32-bit)	○	-	0	-	-	N	R	0
SR693	Current position of CAN communication ID 2 of Delta servo (32-bit)	○	○	0	-	-	N	R	0
SR694	Current position of ECAT communication ID 2 of Delta servo (32-bit)	○	-	0	-	-	N	R	0
SR695	Current position of CAN communication ID 3 of Delta servo (32-bit)	○	○	0	-	-	N	R	0
SR696	Current position of ECAT communication ID 3 of Delta servo (32-bit)	○	-	0	-	-	N	R	0
SR697	Current position of CAN communication ID 4 of Delta servo (32-bit)	○	○	0	-	-	N	R	0
SR698	Current position of ECAT communication ID 4 of Delta servo (32-bit)	○	-	0	-	-	N	R	0
SR699	Current position of CAN communication ID 5 of Delta servo (32-bit)	○	○	0	-	-	N	R	0
SR700	Current position of ECAT communication ID 5 of Delta servo (32-bit)	○	-	0	-	-	N	R	0
SR701	Current position of CAN communication ID 6 of Delta servo (32-bit)	○	○	0	-	-	N	R	0
SR702	Current position of ECAT communication ID 6 of Delta servo (32-bit)	○	-	0	-	-	N	R	0
SR703	Current position of CAN communication ID 7 of Delta servo (32-bit)	○	○	0	-	-	N	R	0
SR704	Current position of ECAT communication ID 7 of Delta servo (32-bit)	○	-	0	-	-	N	R	0
SR705	Current position of CAN communication ID 8 of Delta servo (32-bit)	○	○	0	-	-	N	R	0
SR706	Current position of ECAT communication ID 8 of Delta servo (32-bit)	○	-	0	-	-	N	R	0
SR711	Target position of CAN communication ID 1 of the Delta servo (32-bit)	○	○	0	-	-	N	R	0
SR712	Target position of ECAT communication ID 1 of the Delta servo (32-bit)	○	-	0	-	-	N	R	0
SR713	Target position of CAN communication ID 2 of the Delta servo (32-bit)	○	○	0	-	-	N	R	0
SR714	Target position of ECAT communication ID 2 of the Delta servo (32-bit)	○	-	0	-	-	N	R	0

SR	Function	AS100/200 Series		OFF ↓ ON	STOP ↓ RUN	RUN ↓ STOP	Latched	Attribute	Default
		AS300 Series							
SR715	Target position of CAN communication ID 3 of the Delta servo (32-bit)	○	○	0	-	-	N	R	0
SR716	Target position of ECAT communication ID 3 of the Delta servo (32-bit)	○	-	0	-	-	N	R	0
SR717	Target position of CAN communication ID 4 of the Delta servo (32-bit)	○	○	0	-	-	N	R	0
SR718	Target position of ECAT communication ID 4 of the Delta servo (32-bit)	○	-	0	-	-	N	R	0
SR719	Target position of CAN communication ID 5 of the Delta servo (32-bit)	○	○	0	-	-	N	R	0
SR720	Target position of ECAT communication ID 5 of the Delta servo (32-bit)	○	-	0	-	-	N	R	0
SR721	Target position of CAN communication ID 6 of the Delta servo (32-bit)	○	○	0	-	-	N	R	0
SR722	Target position of ECAT communication ID 6 of the Delta servo (32-bit)	○	-	0	-	-	N	R	0
SR723	Target position of CAN communication ID 7 of the Delta servo (32-bit)	○	○	0	-	-	N	R	0
SR724	Target position of ECAT communication ID 7 of the Delta servo (32-bit)	○	-	0	-	-	N	R	0
SR725	Target position of CAN communication ID 8 of the Delta servo (32-bit)	○	○	0	-	-	N	R	0
SR726	Target position of ECAT communication ID 8 of the Delta servo (32-bit)	○	-	0	-	-	N	R	0
SR731	Current DI state of CAN communication ID 1 of Delta servo	○	○	0	-	-	N	R	0
	Current DI state of ECAT communication ID 1 of Delta servo	○	-	0	-	-	N	R	0
SR732	Current DI state of CAN communication ID 2 of Delta servo	○	○	0	-	-	N	R	0
	Current DI state of ECAT communication ID 2 of Delta servo	○	-	0	-	-	N	R	0
SR733	Current DI state of CAN communication ID 3 of Delta servo	○	○	0	-	-	N	R	0
	Current DI state of ECAT communication ID 3 of Delta servo	○	-	0	-	-	N	R	0
SR734	Current DI state of CAN communication ID 4 of Delta servo	○	○	0	-	-	N	R	0
	Current DI state of ECAT communication ID 4 of Delta servo	○	-	0	-	-	N	R	0
SR735	Current DI state of CAN communication ID 5 of Delta servo	○	○	0	-	-	N	R	0
	Current DI state of ECAT communication ID 5 of Delta servo	○	-	0	-	-	N	R	0

SR	Function			OFF ↓ ON	STOP ↓ RUN	RUN ↓ STOP	Latched	Attribute	Default
		AS300 Series	AS100/200 Series						
SR736	Current DI state of CAN communication ID 6 of Delta servo	○	○	0	-	-	N	R	0
	Current DI state of ECAT communication ID 6 of Delta servo	○	-	0	-	-	N	R	0
SR737	Current DI state of CAN communication ID 7 of Delta servo	○	○	0	-	-	N	R	0
	Current DI state of ECAT communication ID 7 of Delta servo	○	-	0	-	-	N	R	0
SR738	Current DI state of CAN communication ID 8 of Delta servo	○	○	0	-	-	N	R	0
	Current DI state of ECAT communication ID 8 of Delta servo	○	-	0	-	-	N	R	0
SR741	Current torque of CAN communication ID 1 of Delta servo (unit: 0.1%)	○	○	0	-	-	N	R	0
	Current torque of ECAT communication ID 1 of Delta servo (unit: 0.1%)	○	-	0	-	-	N	R	0
SR742	Current torque of CAN communication ID 2 of Delta servo (unit: 0.1%)	○	○	0	-	-	N	R	0
	Current torque of ECAT communication ID 2 of Delta servo (unit: 0.1%)	○	-	0	-	-	N	R	0
SR743	Current torque of CAN communication ID 3 of Delta servo (unit: 0.1%)	○	○	0	-	-	N	R	0
	Current torque of ECAT communication ID 2 of Delta servo (unit: 0.1%)	○	-	0	-	-	N	R	0
SR744	Current torque of CAN communication ID 4 of Delta servo (unit: 0.1%)	○	○	0	-	-	N	R	0
	Current torque of ECAT communication ID 4 of Delta servo (unit: 0.1%)	○	-	0	-	-	N	R	0
SR745	Current torque of CAN communication ID 5 of Delta servo (unit: 0.1%)	○	○	0	-	-	N	R	0
	Current torque of ECAT communication ID 5 of Delta servo (unit: 0.1%)	○	-	0	-	-	N	R	0
SR746	Current torque of CAN communication ID 6 of Delta servo (unit: 0.1%)	○	○	0	-	-	N	R	0
	Current torque of ECAT communication ID 6 of Delta servo (unit: 0.1%)	○	-	0	-	-	N	R	0
SR747	Current torque of CAN communication ID 7 of Delta servo (unit: 0.1%)	○	○	0	-	-	N	R	0
	Current torque of ECAT communication ID 7 of Delta servo (unit: 0.1%)	○	-	0	-	-	N	R	0
SR748	Current torque of CAN communication ID 8 of Delta servo (unit: 0.1%)	○	○	0	-	-	N	R	0
	Current torque of ECAT communication ID 8 of Delta servo (unit: 0.1%)	○	-	0	-	-	N	R	0

SR	Function	AS100/200 Series		OFF	STOP	RUN	Latched	Attribute	Default
		AS300 Series		↓ ON	↓ RUN	↓ STOP			
SR751	Current state of CAN communication ID 21 of Delta inverter	○	○	0	-	-	N	R	0
	PR command on ECAT communication ID 9 of Delta servo Current state of ECAT communication ID 9 of Delta inverter	○	-	0	-	-	N	R	0
SR752	Current state of CAN communication ID 22 of Delta inverter	○	○	0	-	-	N	R	0
	PR command on ECAT communication ID 10 of Delta servo Current state of ECAT communication ID 10 of Delta inverter	○	-	0	-	-	N	R	0
SR753	Current state of CAN communication ID 23 of Delta inverter	○	○	0	-	-	N	R	0
	PR command on ECAT communication ID 11 of Delta servo Current state of ECAT communication ID 11 of Delta inverter	○	-	0	-	-	N	R	0
SR754	Current state of CAN communication ID 24 of Delta inverter	○	○	0	-	-	N	R	0
	PR command on ECAT communication ID 12 of Delta servo Current state of ECAT communication ID 12 of Delta inverter	○	-	0	-	-	N	R	0
SR755	Current state of CAN communication ID 25 of Delta inverter	○	○	0	-	-	N	R	0
	PR command on ECAT communication ID 13 of Delta servo Current state of ECAT communication ID 13 of Delta inverter	○	-	0	-	-	N	R	0
SR756	Current state of CAN communication ID 26 of Delta inverter	○	○	0	-	-	N	R	0
	PR command on ECAT communication ID 14 of Delta servo Current state of ECAT communication ID 14 of Delta inverter	○	-	0	-	-	N	R	0
SR757	Current state of CAN communication ID 27 of Delta inverter	○	○	0	-	-	N	R	0
	PR command on ECAT communication ID 15 of Delta servo Current state of ECAT communication ID 15 of Delta inverter	○	-	0	-	-	N	R	0
SR758	Current state of CAN communication ID 28 of Delta inverter	○	○	0	-	-	N	R	0
	PR command on ECAT communication ID 16 of Delta servo	○	-	0	-	-	N	R	0

SR	Function			OFF ↓ ON	STOP ↓ RUN	RUN ↓ STOP	Latched	Attribute	Default
		AS300 Series	AS100/200 Series						
	Current state of ECAT communication ID 16 of Delta inverter								
SR761	Current motor speed of CAN communication ID 21 of Delta inverter	○	○	0	-	-	N	R	0
	Alarm code for ECAT communication ID 9 of Delta servo	○	-	0	-	-	N	R	0
SR762	Current motor speed of CAN communication ID 22 of Delta inverter	○	○	0	-	-	N	R	0
	Alarm code for ECAT communication ID 10 of Delta servo	○	-	0	-	-	N	R	0
SR763	Current motor speed of CAN communication ID 23 of Delta inverter	○	○	0	-	-	N	R	0
	Alarm code for ECAT communication ID 11 of Delta servo	○	-	0	-	-	N	R	0
SR764	Current motor speed of CAN communication ID 24 of Delta inverter	○	○	0	-	-	N	R	0
	Alarm code for ECAT communication ID 12 of Delta servo	○	-	0	-	-	N	R	0
SR765	Current motor speed of CAN communication ID 25 of Delta inverter	○	○	0	-	-	N	R	0
	Alarm code for ECAT communication ID 13 of Delta servo	○	-	0	-	-	N	R	0
SR766	Current motor speed of CAN communication ID 26 of Delta inverter	○	○	0	-	-	N	R	0
	Alarm code for ECAT communication ID 14 of Delta servo	○	-	0	-	-	N	R	0
SR767	Current motor speed of CAN communication ID 27 of Delta inverter	○	○	0	-	-	N	R	0
	Alarm code for ECAT communication ID 15 of Delta servo	○	-	0	-	-	N	R	0
SR768	Current motor speed of CAN communication ID 28 of Delta inverter	○	○	0	-	-	N	R	0
	Alarm code for ECAT communication ID 16 of Delta servo	○	-	0	-	-	N	R	0
SR771	Current torque of CAN communication ID 21 of Delta inverter (unit: 0.1%)	○	○	0	-	-	N	R	0
	Current torque of ECAT communication ID 9 of Delta servo (unit: 0.1%)	○	-	0	-	-	N	R	0
SR772	Current torque of CAN communication ID 22 of Delta inverter (unit: 0.1%)	○	○	0	-	-	N	R	0
	Current torque of ECAT communication ID 10 of Delta servo (unit: 0.1%)	○	-	0	-	-	N	R	0
SR773	Current torque of CAN communication ID 23 of Delta inverter (unit: 0.1%)	○	○	0	-	-	N	R	0
	Current torque of ECAT communication ID 11 of Delta servo (unit: 0.1%)	○	-	0	-	-	N	R	0
SR774	Current torque of CAN communication ID 24 of Delta inverter (unit: 0.1%)	○	○	0	-	-	N	R	0
	Current torque of ECAT communication ID 12 of Delta servo (unit: 0.1%)	○	-	0	-	-	N	R	0
SR775	Current torque of CAN communication ID 25 of Delta inverter (unit: 0.1%)	○	○	0	-	-	N	R	0
	Current torque of ECAT communication ID 13 of Delta	○	-	0	-	-	N	R	0

SR	Function	AS100/200 Series		OFF	STOP	RUN	Latched	Attribute	Default
		AS300 Series		↓ ON	↓ RUN	↓ STOP			
	servo (unit: 0.1%)								
SR776	Current torque of CAN communication ID 26 of Delta inverter (unit: 0.1%)	○	○	0	-	-	N	R	0
	Current torque of ECAT communication ID 14 of Delta servo (unit: 0.1%)	○	-	0	-	-	N	R	0
SR777	Current torque of CAN communication ID 27 of Delta inverter (unit: 0.1%)	○	○	0	-	-	N	R	0
	Current torque of ECAT communication ID 15 of Delta servo (unit: 0.1%)	○	-	0	-	-	N	R	0
SR778	Current torque of CAN communication ID 28 of Delta inverter (unit: 0.1%)	○	○	0	-	-	N	R	0
	Current torque of ECAT communication ID 16 of Delta servo (unit: 0.1%)	○	-	0	-	-	N	R	0
SR781	Current DI state of CAN communication ID 21 of Delta inverter	○	○	0	-	-	N	R	0
	Current DI state of ECAT communication ID 9 of Delta servo	○	-	0	-	-	N	R	0
SR782	Current DI state of CAN communication ID 22 of Delta inverter	○	○	0	-	-	N	R	0
	Current DI state of ECAT communication ID 10 of Delta servo	○	-	0	-	-	N	R	0
SR783	Current DI state of CAN communication ID 23 of Delta inverter	○	○	0	-	-	N	R	0
	Current DI state of ECAT communication ID 11 of Delta servo	○	-	0	-	-	N	R	0
SR784	Current DI state of CAN communication ID 24 of Delta inverter	○	○	0	-	-	N	R	0
	Current DI state of ECAT communication ID 12 of Delta servo	○	-	0	-	-	N	R	0
SR785	Current DI state of CAN communication ID 25 of Delta inverter	○	○	0	-	-	N	R	0
	Current DI state of ECAT communication ID 13 of Delta servo	○	-	0	-	-	N	R	0
SR786	Current DI state of CAN communication ID 26 of Delta inverter	○	○	0	-	-	N	R	0
	Current DI state of ECAT communication ID 14 of Delta servo	○	-	0	-	-	N	R	0
SR787	Current DI state of CAN communication ID 27 of Delta inverter	○	○	0	-	-	N	R	0
	Current DI state of ECAT communication ID 15 of Delta servo	○	-	0	-	-	N	R	0
SR788	Current DI state of CAN communication ID 28 of Delta inverter	○	○	0	-	-	N	R	0
	Current DI state of ECAT communication ID 16 of Delta servo	○	-	0	-	-	N	R	0
SR791 SR792	Read the self-defined value from CAN communication ID 1 of Delta servo (32-bit)	○	○	0	-	-	N	R	0

SR	Function	AS300 Series	AS100/200 Series	OFF ↓ ON	STOP ↓ RUN	RUN ↓ STOP	Latched	Attribute	Default
	Read the self-defined value from ECAT communication ID 1 of Delta servo (32-bit)	○	-	0	-	-	N	R	0
SR793	Read the self-defined value from CAN communication ID 2 of Delta servo (32-bit)	○	○	0	-	-	N	R	0
SR794	Read the self-defined value from ECAT communication ID 2 of Delta servo (32-bit)	○	-	0	-	-	N	R	0
SR795	Read the self-defined value from CAN communication ID 3 of Delta servo (32-bit)	○	○	0	-	-	N	R	0
SR796	Read the self-defined value from ECAT communication ID 3 of Delta servo (32-bit)	○	-	0	-	-	N	R	0
SR797	Read the self-defined value from CAN communication ID 4 of Delta servo (32-bit)	○	○	0	-	-	N	R	0
SR798	Read the self-defined value from ECAT communication ID 4 of Delta servo (32-bit)	○	-	0	-	-	N	R	0
SR799	Read the self-defined value from CAN communication ID 5 of Delta servo (32-bit)	○	○	0	-	-	N	R	0
SR800	Read the self-defined value from ECAT communication ID 5 of Delta servo (32-bit)	○	-	0	-	-	N	R	0
SR801	Read the self-defined value from CAN communication ID 6 of Delta servo (32-bit)	○	○	0	-	-	N	R	0
SR802	Read the self-defined value from ECAT communication ID 6 of Delta servo (32-bit)	○	-	0	-	-	N	R	0
SR803	Read the self-defined value from CAN communication ID 7 of Delta servo (32-bit)	○	○	0	-	-	N	R	0
SR804	Read the self-defined value from ECAT communication ID 7 of Delta servo (32-bit)	○	-	0	-	-	N	R	0
SR805	Read the self-defined value from CAN communication ID 8 of Delta servo (32-bit)	○	○	0	-	-	N	R	0
SR806	Read the self-defined value from ECAT communication ID 8 of Delta servo (32-bit)	○	-	0	-	-	N	R	0
SR811	The acceptable range for CAN communication ID 1 of Delta servo to determine the positioning is complete. (If the setting value is 0, it indicates the current position should be the same as the target position to determine the positioning is complete. If the setting value is 5, it indicates the distance between the current position and the target position can be +5 to -5 for the PLC to set a completion flag.)	○	○	0	-	-	N	R/W	0
	The acceptable range for ECAT communication ID 1 of Delta servo to determine the positioning is complete.	○	-	0	-	-	N	R/W	0
SR812	The acceptable range for CAN communication ID 2 of Delta servo to determine the positioning is complete.	○	○	0	-	-	N	R/W	0
	The acceptable range for ECAT communication ID 2 of Delta servo to determine the positioning is complete.	○	-	0	-	-	N	R/W	0

SR	Function			OFF ↓ ON	STOP ↓ RUN	RUN ↓ STOP	Latched	Attribute	Default
		AS300 Series	AS100/200 Series						
SR813	The acceptable range for CAN communication ID 3 of Delta servo to determine the positioning is complete.	○	○	0	-	-	N	R/W	0
	The acceptable range for ECAT communication ID 3 of Delta servo to determine the positioning is complete.	○	-	0	-	-	N	R/W	0
SR814	The acceptable range for CAN communication ID 4 of Delta servo to determine the positioning is complete.	○	○	0	-	-	N	R/W	0
	The acceptable range for ECAT communication ID 4 of Delta servo to determine the positioning is complete.	○	-	0	-	-	N	R/W	0
SR815	The acceptable range for CAN communication ID 5 of Delta servo to determine the positioning is complete.	○	○	0	-	-	N	R/W	0
	The acceptable range for ECAT communication ID 5 of Delta servo to determine the positioning is complete.	○	-	0	-	-	N	R/W	0
SR816	The acceptable range for CAN communication ID 6 of Delta servo to determine the positioning is complete.	○	○	0	-	-	N	R/W	0
	The acceptable range for ECAT communication ID 6 of Delta servo to determine the positioning is complete.	○	-	0	-	-	N	R/W	0
SR817	The acceptable range for CAN communication ID 7 of Delta servo to determine the positioning is complete.	○	○	0	-	-	N	R/W	0
	The acceptable range for ECAT communication ID 7 of Delta servo to determine the positioning is complete.	○	-	0	-	-	N	R/W	0
SR818	The acceptable range for CAN communication ID 8 of Delta servo to determine the positioning is complete.	○	○	0	-	-	N	R/W	0
	The acceptable range for ECAT communication ID 8 of Delta servo to determine the positioning is complete.	○	-	0	-	-	N	R/W	0
SR820	Code for the state of the master/slave in CANopen DS301 communication	○	○	-	-	-	Y	R	0
SR821	CANopen DS301 version code	○	○	-	-	-	Y	R	-
SR822	CANopen communication baudrate (unit: 1kbps)	○	○	-	-	-	H	R	125
*SR823	The number of hardware receiving error during CANopen communication (Max. 255)	○	○	0	-	-	N	R	0
*SR824	The number of hardware sending error during CANopen communication (Max. 255)	○	○	0	-	-	N	R	0
SR825	Code for the master state in CANopen DS301 communication	○	○	-1	-	-	N	R	-1
SR826	State of slave ID 1–16 in CANopen DS301 communication	○	○	-1	-	-	N	R	-1
SR827	State of slave ID 17–32 in CANopen DS301 communication	○	○	-1	-	-	N	R	-1
SR828	State of slave ID 33–48 in CANopen DS301 communication	○	○	-1	-	-	N	R	-1
SR829	State of slave ID 49–64 in CANopen DS301 communication	○	○	-1	-	-	N	R	-1
SR830	State of slave ID 1 in CANopen DS301 communication	○	○	-1	-	-	N	R	-1
SR831	State of slave ID 2 in CANopen DS301 communication	○	○	-1	-	-	N	R	-1

SR	Function	AS300 Series	AS100/200 Series	OFF ↓ ON	STOP ↓ RUN	RUN ↓ STOP	Latched	Attribute	Default
SR832	State of slave ID 3 in CANopen DS301 communication	○	○	-1	-	-	N	R	-1
SR833	State of slave ID 4 in CANopen DS301 communication	○	○	-1	-	-	N	R	-1
SR834	State of slave ID 5 in CANopen DS301 communication	○	○	-1	-	-	N	R	-1
SR835	State of slave ID 6 in CANopen DS301 communication	○	○	-1	-	-	N	R	-1
SR836	State of slave ID 7 in CANopen DS301 communication	○	○	-1	-	-	N	R	-1
SR837	State of slave ID 8 in CANopen DS301 communication	○	○	-1	-	-	N	R	-1
SR838	State of slave ID 9 in CANopen DS301 communication	○	○	-1	-	-	N	R	-1
SR839	State of slave ID 10 in CANopen DS301 communication	○	○	-1	-	-	N	R	-1
SR840	State of slave ID 11 in CANopen DS301 communication	○	○	-1	-	-	N	R	-1
SR841	State of slave ID 12 in CANopen DS301 communication	○	○	-1	-	-	N	R	-1
SR842	State of slave ID 13 in CANopen DS301 communication	○	○	-1	-	-	N	R	-1
SR843	State of slave ID 14 in CANopen DS301 communication	○	○	-1	-	-	N	R	-1
SR844	State of slave ID 15 in CANopen DS301 communication	○	○	-1	-	-	N	R	-1
SR845	State of slave ID 16 in CANopen DS301 communication	○	○	-1	-	-	N	R	-1
SR846	State of slave ID 17 in CANopen DS301 communication	○	○	-1	-	-	N	R	-1
SR847	State of slave ID 18 in CANopen DS301 communication	○	○	-1	-	-	N	R	-1
SR848	State of slave ID 19 in CANopen DS301 communication	○	○	-1	-	-	N	R	-1
SR849	State of slave ID 20 in CANopen DS301 communication	○	○	-1	-	-	N	R	-1
SR850	State of slave ID 21 in CANopen DS301 communication	○	○	-1	-	-	N	R	-1
SR851	State of slave ID 22 in CANopen DS301 communication	○	○	-1	-	-	N	R	-1
SR852	State of slave ID 23 in CANopen DS301 communication	○	○	-1	-	-	N	R	-1
SR853	State of slave ID 24 in CANopen DS301 communication	○	○	-1	-	-	N	R	-1
SR854	State of slave ID 25 in CANopen DS301 communication	○	○	-1	-	-	N	R	-1
SR855	State of slave ID 26 in CANopen DS301 communication	○	○	-1	-	-	N	R	-1
SR856	State of slave ID 27 in CANopen DS301 communication	○	○	-1	-	-	N	R	-1
SR857	State of slave ID 28 in CANopen DS301 communication	○	○	-1	-	-	N	R	-1
SR858	State of slave ID 29 in CANopen DS301 communication	○	○	-1	-	-	N	R	-1
SR859	State of slave ID 30 in CANopen DS301 communication	○	○	-1	-	-	N	R	-1
SR860	State of slave ID 31 in CANopen DS301 communication	○	○	-1	-	-	N	R	-1
SR861	State of slave ID 32 in CANopen DS301 communication	○	○	-1	-	-	N	R	-1
SR862	State of slave ID 33 in CANopen DS301 communication	○	○	-1	-	-	N	R	-1
SR863	State of slave ID 34 in CANopen DS301 communication	○	○	-1	-	-	N	R	-1
SR864	State of slave ID 35 in CANopen DS301 communication	○	○	-1	-	-	N	R	-1
SR865	State of slave ID 36 in CANopen DS301 communication	○	○	-1	-	-	N	R	-1
SR866	State of slave ID 37 in CANopen DS301 communication	○	○	-1	-	-	N	R	-1
SR867	State of slave ID 38 in CANopen DS301 communication	○	○	-1	-	-	N	R	-1
SR868	State of slave ID 39 in CANopen DS301 communication	○	○	-1	-	-	N	R	-1
SR869	State of slave ID 40 in CANopen DS301 communication	○	○	-1	-	-	N	R	-1
SR870	State of slave ID 41 in CANopen DS301 communication	○	○	-1	-	-	N	R	-1

SR	Function	AS100/200 Series		OFF	STOP	RUN	Latched	Attribute	Default
		AS300 Series	AS100/200 Series	↓ ON	↓ RUN	↓ STOP			
SR871	State of slave ID 42 in CANopen DS301 communication	○	○	-1	-	-	N	R	-1
SR872	State of slave ID 43 in CANopen DS301 communication	○	○	-1	-	-	N	R	-1
SR873	State of slave ID 44 in CANopen DS301 communication	○	○	-1	-	-	N	R	-1
SR874	State of slave ID 45 in CANopen DS301 communication	○	○	-1	-	-	N	R	-1
SR875	State of slave ID 46 in CANopen DS301 communication	○	○	-1	-	-	N	R	-1
SR876	State of slave ID 47 in CANopen DS301 communication	○	○	-1	-	-	N	R	-1
SR877	State of slave ID 48 in CANopen DS301 communication	○	○	-1	-	-	N	R	-1
SR878	State of slave ID 49 in CANopen DS301 communication	○	○	-1	-	-	N	R	-1
SR879	State of slave ID 50 in CANopen DS301 communication	○	○	-1	-	-	N	R	-1
SR880	State of slave ID 51 in CANopen DS301 communication	○	○	-1	-	-	N	R	-1
SR881	State of slave ID 52 in CANopen DS301 communication	○	○	-1	-	-	N	R	-1
SR882	State of slave ID 53 in CANopen DS301 communication	○	○	-1	-	-	N	R	-1
SR883	State of slave ID 54 in CANopen DS301 communication	○	○	-1	-	-	N	R	-1
SR884	State of slave ID 55 in CANopen DS301 communication	○	○	-1	-	-	N	R	-1
SR885	State of slave ID 56 in CANopen DS301 communication	○	○	-1	-	-	N	R	-1
SR886	State of slave ID 57 in CANopen DS301 communication	○	○	-1	-	-	N	R	-1
SR887	State of slave ID 58 in CANopen DS301 communication	○	○	-1	-	-	N	R	-1
SR888	State of slave ID 59 in CANopen DS301 communication	○	○	-1	-	-	N	R	-1
SR889	State of slave ID 60 in CANopen DS301 communication	○	○	-1	-	-	N	R	-1
SR890	State of slave ID 61 in CANopen DS301 communication	○	○	-1	-	-	N	R	-1
SR891	State of slave ID 62 in CANopen DS301 communication	○	○	-1	-	-	N	R	-1
SR892	State of slave ID 63 in CANopen DS301 communication	○	○	-1	-	-	N	R	-1
SR893	State of slave ID 64 in CANopen DS301 communication	○	○	-1	-	-	N	R	-1
SR900	Number of samples in the data logger (32-bit)	○	○	0	-	-	N	R	0
SR901									
SR902	Code for the executions of data logger and the memory card (works with SM456).	○	○	0	-	-	N	R/W	0
*SR1000	Ethernet IP address (32-bit)	○	○	-	-	-	H	R/W	0
*SR1001									
*SR1002	Ethernet netmask address (32-bit)	○	○	-	-	-	H	R/W	0
*SR1003									
*SR1004	Ethernet gateway address (32-bit)	○	○	-	-	-	H	R/W	0
*SR1005									
*SR1006	Duration of the TCP connection (sec.)	○	○	-	-	-	H	R/W	30
*SR1007	Ethernet transmission speed	○	○	0	-	-	N	R	0
*SR1009	Number of TCP connections	○	○	0	-	-	N	R	0
*SR1010	Specific time when to resend through the TCP connection (ms)	○	○	-	-	-	N	R/W	20
*SR1011	Connection number of Modbus/TCP Server	○	○	0	-	-	N	R	0

SR	Function	AS300 Series	AS100/200 Series	OFF	STOP	RUN	Latched	Attribute	Default
				↓ ON	↓ RUN	↓ STOP			
*SR1012	Connection number of Modbus/TCP Client	○	○	0	-	-	N	R	0
*SR1013	Connection number of EtherNet/IP Adapter	○	○	0	-	-	N	R	0
*SR1014	Connection number of EtherNet/IP Scanner	○	○	0	-	-	N	R	0
*SR1015	Modbus/TCP Server packet receiving timeout (ms)	○	○	10	-	-	N	R/W	10
*SR1016	The delay time for the data to be sent after the connection of Modbus/TCP Client is established. (ms) (0~1000)	○	○	0	-	-	N	R/W	0
*SR1017	The maximum number of Ethernet packets that can be handled in one scan cycle.	○	○	-	-	-	Y	R/W	80
*SR1018	The number of Ethernet packets that is handled in the last scan cycle.	○	○	0	-	-	N	R	0
*SR1019	The accumulated number of Ethernet packets which are dropped after the packets in the buffer zone is full.	○	○	0	-	-	N	R/W	0
*SR1020	State of the EtherNet/IP connection 1	○		0	-	-	N	R	0
*SR1021	State of the EtherNet/IP connection 2	○	○	0	-	-	N	R	0
*SR1022	State of the EtherNet/IP connection 3	○	○	0	-	-	N	R	0
*SR1023	State of the EtherNet/IP connection 4	○		0	-	-	N	R	0
*SR1024	State of the EtherNet/IP connection 5	○	○	0	-	-	N	R	0
*SR1025	State of the EtherNet/IP connection 6	○		0	-	-	N	R	0
*SR1026	State of the EtherNet/IP connection 7	○	○	0	-	-	N	R	0
*SR1027	State of the EtherNet/IP connection 8	○		0	-	-	N	R	0
*SR1028	State of the EtherNet/IP connection 9	○	○	0	-	-	N	R	0
*SR1029	State of the EtherNet/IP connection 10	○	○	0	-	-	N	R	0
*SR1030	State of the EtherNet/IP connection 11	○	○	0	-	-	N	R	0
*SR1031	State of the EtherNet/IP connection 12	○	○	0	-	-	N	R	0
*SR1032	State of the EtherNet/IP connection 13	○	○	0	-	-	N	R	0
*SR1033	State of the EtherNet/IP connection 14	○	○	0	-	-	N	R	0
*SR1034	State of the EtherNet/IP connection 15	○	○	0	-	-	N	R	0
*SR1035	State of the EtherNet/IP connection 16	○	○	0	-	-	N	R	0
*SR1036	State of the EtherNet/IP connection 17	○	○	0	-	-	N	R	0
*SR1037	State of the EtherNet/IP connection 18	○	○	0	-	-	N	R	0
*SR1038	State of the EtherNet/IP connection 19	○	○	0	-	-	N	R	0
*SR1039	State of the EtherNet/IP connection 20	○	○	0	-	-	N	R	0
*SR1040	State of the EtherNet/IP connection 21	○	○	0	-	-	N	R	0
*SR1041	State of the EtherNet/IP connection 22	○	○	0	-	-	N	R	0
*SR1042	State of the EtherNet/IP connection 23	○	○	0	-	-	N	R	0
*SR1043	State of the EtherNet/IP connection 24	○	○	0	-	-	N	R	0
*SR1044	State of the EtherNet/IP connection 25	○	○	0	-	-	N	R	0
*SR1045	State of the EtherNet/IP connection 26	○	○	0	-	-	N	R	0
*SR1046	State of the EtherNet/IP connection 27	○	○	0	-	-	N	R	0
*SR1047	State of the EtherNet/IP connection 28	○	○	0	-	-	N	R	0
*SR1048	State of the EtherNet/IP connection 29	○	○	0	-	-	N	R	0
*SR1049	State of the EtherNet/IP connection 30	○	○	0	-	-	N	R	0

SR	Function	AS100/200 Series		OFF	STOP	RUN	Latched	Attribute	Default
		AS300 Series		↓ ON	↓ RUN	↓ STOP			
*SR1050	State of the EtherNet/IP connection 31	○	○	0	-	-	N	R	0
*SR1051	State of the EtherNet/IP connection 32	○	○	0	-	-	N	R	0
SR1052	Refresh time for the EtherNet/IP connection 1 (unit: ms)	○	○	0	-	-	N	R	0
SR1053	Refresh time for the EtherNet/IP connection 2 (unit: ms)	○	○	0	-	-	N	R	0
SR1054	Refresh time for the EtherNet/IP connection 3 (unit: ms)	○	○	0	-	-	N	R	0
SR1055	Refresh time for the EtherNet/IP connection 4 (unit: ms)	○	○	0	-	-	N	R	0
SR1056	Refresh time for the EtherNet/IP connection 5 (unit: ms)	○	○	0	-	-	N	R	0
SR1057	Refresh time for the EtherNet/IP connection 6 (unit: ms)	○	○	0	-	-	N	R	0
SR1058	Refresh time for the EtherNet/IP connection 7 (unit: ms)	○	○	0	-	-	N	R	0
SR1059	Refresh time for the EtherNet/IP connection 8 (unit: ms)	○	○	0	-	-	N	R	0
SR1060	Refresh time for the EtherNet/IP connection 9 (unit: ms)	○	○	0	-	-	N	R	0
SR1061	Refresh time for the EtherNet/IP connection 10 (unit: ms)	○	○	0	-	-	N	R	0
SR1062	Refresh time for the EtherNet/IP connection 11 (unit: ms)	○	○	0	-	-	N	R	0
SR1063	Refresh time for the EtherNet/IP connection 12 (unit: ms)	○	○	0	-	-	N	R	0
SR1064	Refresh time for the EtherNet/IP connection 13 (unit: ms)	○	○	0	-	-	N	R	0
SR1065	Refresh time for the EtherNet/IP connection 14 (unit: ms)	○	○	0	-	-	N	R	0
SR1066	Refresh time for the EtherNet/IP connection 15 (unit: ms)	○	○	0	-	-	N	R	0
SR1067	Refresh time for the EtherNet/IP connection 16 (unit: ms)	○	○	0	-	-	N	R	0
SR1068	Refresh time for the EtherNet/IP connection 17 (unit: ms)	○	○	0	-	-	N	R	0
SR1069	Refresh time for the EtherNet/IP connection 18 (unit: ms)	○	○	0	-	-	N	R	0
SR1070	Refresh time for the EtherNet/IP connection 19 (unit: ms)	○	○	0	-	-	N	R	0
SR1071	Refresh time for the EtherNet/IP connection 20 (unit: ms)	○	○	0	-	-	N	R	0
SR1072	Refresh time for the EtherNet/IP connection 21 (unit: ms)	○	○	0	-	-	N	R	0
SR1073	Refresh time for the EtherNet/IP connection 22 (unit: ms)	○	○	0	-	-	N	R	0
SR1074	Refresh time for the EtherNet/IP connection 23 (unit: ms)	○	○	0	-	-	N	R	0
SR1075	Refresh time for the EtherNet/IP connection 24 (unit: ms)	○	○	0	-	-	N	R	0
SR1076	Refresh time for the EtherNet/IP connection 25 (unit: ms)	○	○	0	-	-	N	R	0
SR1077	Refresh time for the EtherNet/IP connection 26 (unit: ms)	○	○	0	-	-	N	R	0
SR1078	Refresh time for the EtherNet/IP connection 27 (unit: ms)	○	○	0	-	-	N	R	0
SR1079	Refresh time for the EtherNet/IP connection 28 (unit: ms)	○	○	0	-	-	N	R	0
SR1080	Refresh time for the EtherNet/IP connection 29 (unit: ms)	○	○	0	-	-	N	R	0
SR1081	Refresh time for the EtherNet/IP connection 30 (unit: ms)	○	○	0	-	-	N	R	0
SR1082	Refresh time for the EtherNet/IP connection 31 (unit: ms)	○	○	0	-	-	N	R	0
SR1083	Refresh time for the EtherNet/IP connection 32 (unit: ms)	○	○	0	-	-	N	R	0
SR1092	Modbus TCP Server port (PLC CPU as Server); available for FW V1.10.20 or later.	○	○	502	-	-	N	R/W	502
SR1093	Modbus TCP Client port (PLC CPU as Client); available for FW V1.10.20 or later.	○	○	502	-	-	N	R/W	502
SR1100	Value of the input packet counter (high byte)	○	○	0	-	-	N	R	0
SR1101	Value of the input packet counter (low byte)	○	○						

SR	Function			OFF ↓ ON	STOP ↓ RUN	RUN ↓ STOP	Latched	Attribute	Default
		AS300 Series	AS100/200 Series						
SR1102	Value of the input octet counter (high byte)	○	○	0	-	-	N	R	0
SR1103	Value of the input octet counter (low byte)		○						
SR1104	Value of the output packet counter (high byte)	○	○	0	-	-	N	R	0
SR1105	Value of the output packet counter (low byte)		○						
SR1106	Value of the output octet counter (high byte)	○	○	0	-	-	N	R	0
SR1107	Value of the output octet counter (low byte)		○						
SR1110	Code to change the NTP parameter (NTP should be enabled and the change command code 16#1234 should be entered. Once the PLC completes the change, the change code will be cleared automatically.)	○	○	0	0	-	N	R/W	0
SR1111	NTP server IP byte (high byte)	○	○	0	0	-	N	R/W	0
SR1112	NTP server IP byte (low byte)	○	○	0	0	-	N	R/W	0
SR1113	NTP cycle refreshing time (unit: minute)	○	○	0	0	-	N	R/W	0
SR1114	NTP time zone (unit: hour)	○	○	0	0	-	N	R/W	0
SR1116	Email counter	○	○	0	-	-	N	R	0
SR1117	Email error counter	○	○	0	-	-	N	R	0
*SR1120	Actual connection time for data exchange through the Ethernet connection 1 (unit: time)	○	○	0	-	-	N	R	0
*SR1121	Actual connection time for data exchange through the Ethernet connection 2 (unit: time)	○	○	0	-	-	N	R	0
*SR1122	Actual connection time for data exchange through the Ethernet connection 3 (unit: time)	○	○	0	-	-	N	R	0
*SR1123	Actual connection time for data exchange through the Ethernet connection 4 (unit: time)	○	○	0	-	-	N	R	0
*SR1124	Actual connection time for data exchange through the Ethernet connection 5 (unit: time)	○	○	0	-	-	N	R	0
*SR1125	Actual connection time for data exchange through the Ethernet connection 6 (unit: time)	○	○	0	-	-	N	R	0
*SR1126	Actual connection time for data exchange through the Ethernet connection 7 (unit: time)	○	○	0	-	-	N	R	0
*SR1127	Actual connection time for data exchange through the Ethernet connection 8 (unit: time)	○		0	-	-	N	R	0
*SR1128	Actual connection time for data exchange through the Ethernet connection 9 (unit: time)	○	○	0	-	-	N	R	0
*SR1129	Actual connection time for data exchange through the Ethernet connection 10 (unit: time)	○		0	-	-	N	R	0
*SR1130	Actual connection time for data exchange through the Ethernet connection 11 (unit: time)	○	○	0	-	-	N	R	0
*SR1131	Actual connection time for data exchange through the Ethernet connection 12 (unit: time)	○		0	-	-	N	R	0
*SR1132	Actual connection time for data exchange through the Ethernet connection 13 (unit: time)	○		0	-	-	N	R	0
*SR1133	Actual connection time for data exchange through the Ethernet connection 14 (unit: time)	○	○	0	-	-	N	R	0

SR	Function	AS300 Series	AS100/200 Series	OFF ↓ ON	STOP ↓ RUN	RUN ↓ STOP	Latched	Attribute	Default
*SR1134	Actual connection time for data exchange through the Ethernet connection 15 (unit: time)	○		0	-	-	N	R	0
*SR1135	Actual connection time for data exchange through the Ethernet connection 16 (unit: time)	○	○	0	-	-	N	R	0
*SR1136	Actual connection time for data exchange through the Ethernet connection 17 (unit: time)	○	○	0	-	-	N	R	0
*SR1137	Actual connection time for data exchange through the Ethernet connection 18 (unit: time)	○	○	0	-	-	N	R	0
*SR1138	Actual connection time for data exchange through the Ethernet connection 19 (unit: time)	○	○	0	-	-	N	R	0
*SR1139	Actual connection time for data exchange through the Ethernet connection 20 (unit: time)	○	○	0	-	-	N	R	0
*SR1140	Actual connection time for data exchange through the Ethernet connection 21 (unit: time)	○	○	0	-	-	N	R	0
*SR1141	Actual connection time for data exchange through the Ethernet connection 22 (unit: time)	○	○	0	-	-	N	R	0
*SR1142	Actual connection time for data exchange through the Ethernet connection 23 (unit: time)	○	○	0	-	-	N	R	0
*SR1143	Actual connection time for data exchange through the Ethernet connection 24 (unit: time)	○	○	0	-	-	N	R	0
*SR1144	Actual connection time for data exchange through the Ethernet connection 25 (unit: time)	○	○	0	-	-	N	R	0
*SR1145	Actual connection time for data exchange through the Ethernet connection 26 (unit: time)	○	○	0	-	-	N	R	0
*SR1146	Actual connection time for data exchange through the Ethernet connection 27 (unit: time)	○	○	0	-	-	N	R	0
*SR1147	Actual connection time for data exchange through the Ethernet connection 28 (unit: time)	○	○	0	-	-	N	R	0
*SR1148	Actual connection time for data exchange through the Ethernet connection 29 (unit: time)	○	○	0	-	-	N	R	0
*SR1149	Actual connection time for data exchange through the Ethernet connection 30 (unit: time)	○	○	0	-	-	N	R	0
*SR1150	Actual connection time for data exchange through the Ethernet connection 31 (unit: time)	○	○	0	-	-	N	R	0
*SR1151	Actual connection time for data exchange through the Ethernet connection 32 (unit: time)	○	○	0	-	-	N	R	0
*SR1152	The error code for data exchange through the Ethernet connection 1	○	○	0	-	-	N	R	0
*SR1153	The error code for data exchange through the Ethernet connection 2	○	○	0	-	-	N	R	0
*SR1154	The error code for data exchange through the Ethernet connection 3	○	○	0	-	-	N	R	0
*SR1155	The error code for data exchange through the Ethernet connection 4	○	○	0	-	-	N	R	0

SR	Function			OFF ↓ ON	STOP ↓ RUN	RUN ↓ STOP	Latched	Attribute	Default
		AS300 Series	AS100/200 Series						
*SR1156	The error code for data exchange through the Ethernet connection 5	○	○	0	-	-	N	R	0
*SR1157	The error code for data exchange through the Ethernet connection 6	○	○	0	-	-	N	R	0
*SR1158	The error code for data exchange through the Ethernet connection 7	○	○	0	-	-	N	R	0
*SR1159	The error code for data exchange through the Ethernet connection 8	○	○	0	-	-	N	R	0
*SR1160	The error code for data exchange through the Ethernet connection 9	○	○	0	-	-	N	R	0
*SR1161	The error code for data exchange through the Ethernet connection 10	○	○	0	-	-	N	R	0
*SR1162	The error code for data exchange through the Ethernet connection 11	○	○	0	-	-	N	R	0
*SR1163	The error code for data exchange through the Ethernet connection 12	○	○	0	-	-	N	R	0
*SR1164	The error code for data exchange through the Ethernet connection 13	○	○	0	-	-	N	R	0
*SR1165	The error code for data exchange through the Ethernet connection 14	○	○	0	-	-	N	R	0
*SR1166	The error code for data exchange through the Ethernet connection 15	○	○	0	-	-	N	R	0
*SR1167	The error code for data exchange through the Ethernet connection 16	○	○	0	-	-	N	R	0
*SR1168	The error code for data exchange through the Ethernet connection 17	○	○	0	-	-	N	R	0
*SR1169	The error code for data exchange through the Ethernet connection 18	○	○	0	-	-	N	R	0
*SR1170	The error code for data exchange through the Ethernet connection 19	○	○	0	-	-	N	R	0
*SR1171	The error code for data exchange through the Ethernet connection 20	○	○	0	-	-	N	R	0
*SR1172	The error code for data exchange through the Ethernet connection 21	○	○	0	-	-	N	R	0
*SR1173	The error code for data exchange through the Ethernet connection 22	○	○	0	-	-	N	R	0
*SR1174	The error code for data exchange through the Ethernet connection 23	○	○	0	-	-	N	R	0
*SR1175	The error code for data exchange through the Ethernet connection 24	○	○	0	-	-	N	R	0
*SR1176	The error code for data exchange through the Ethernet connection 25	○	○	0	-	-	N	R	0
*SR1177	The error code for data exchange through the Ethernet connection 26	○	○	0	-	-	N	R	0

SR	Function	AS300 Series	AS100/200 Series	OFF ↓ ON	STOP ↓ RUN	RUN ↓ STOP	Latched	Attribute	Default
*SR1178	The error code for data exchange through the Ethernet connection 27	○	○	0	-	-	N	R	0
*SR1179	The error code for data exchange through the Ethernet connection 28	○	○	0	-	-	N	R	0
*SR1180	The error code for data exchange through the Ethernet connection 29	○	○	0	-	-	N	R	0
*SR1181	The error code for data exchange through the Ethernet connection 30	○	○	0	-	-	N	R	0
*SR1182	The error code for data exchange through the Ethernet connection 31	○	○	0	-	-	N	R	0
*SR1183	The error code for data exchange through the Ethernet connection 32	○	○	0	-	-	N	R	0
SR1191	Current DO state of the ECAT communication ID 9 of Delta servo	○	-	0	0	-	N	R	0
SR1192	Current DO state of the ECAT communication ID 10 of Delta servo	○	-	0	0	-	N	R	0
SR1193	Current DO state of the ECAT communication ID 11 of Delta servo	○	-	0	0	-	N	R	0
SR1194	Current DO state of the ECAT communication ID 12 of Delta servo	○	-	0	0	-	N	R	0
SR1195	Current DO state of the ECAT communication ID 13 of Delta servo	○	-	0	0	-	N	R	0
SR1196	Current DO state of the ECAT communication ID 14 of Delta servo	○	-	0	0	-	N	R	0
SR1197	Current DO state of the ECAT communication ID 15 of Delta servo	○	-	0	0	-	N	R	0
SR1198	Current DO state of the ECAT communication ID 16 of Delta servo	○	-	0	0	-	N	R	0
SR1201	Current position of the ECAT communication ID 9 of Delta servo (32-bit)	○	-	0	0	-	N	R	0
SR1202									
SR1203	Current position of ECAT communication ID 10 of Delta servo (32-bit)	○	-	0	0	-	N	R	0
SR1204									
SR1205	Current position of the ECAT communication ID 11 of Delta servo (32-bit)	○	-	0	0	-	N	R	0
SR1206									
SR1207	Current position of ECAT communication ID 12 of Delta servo (32-bit)	○	-	0	0	-	N	R	0
SR1208									
SR1209	Current position of the ECAT communication ID 13 of Delta servo (32-bit)	○	-	0	0	-	N	R	0
SR1210									
SR1211	Current position of ECAT communication ID 14 of Delta servo (32-bit)	○	-	0	0	-	N	R	0
SR1212									
SR1213	Current position of ECAT communication ID 15 of Delta servo (32-bit)	○	-	0	0	-	N	R	0
SR1214									

SR	Function	AS300 Series	AS100/200 Series	OFF	STOP	RUN	Latched	Attribute	Default
				↓ ON	↓ RUN	↓ STOP			
SR1215	Current position of ECAT communication ID 16 of Delta servo (32-bit)	○	-	0	0	-	N	R	0
SR1216									
SR1221	Target position of ECAT communication ID 9 of the Delta servo (32-bit)	○	-	0	0	-	N	R	0
SR1222									
SR1223	Target position of ECAT communication ID 10 of the Delta servo (32-bit)	○	-	0	0	-	N	R	0
SR1224									
SR1225	Target position of ECAT communication ID 11 of the Delta servo (32-bit)	○	-	0	0	-	N	R	0
SR1226									
SR1227	Target position of ECAT communication ID 12 of the Delta servo (32-bit)	○	-	0	0	-	N	R	0
SR1228									
SR1229	Target position of ECAT communication ID 13 of the Delta servo (32-bit)	○	-	0	0	-	N	R	0
SR1230									
SR1231	Target position of ECAT communication ID 14 of the Delta servo (32-bit)	○	-	0	0	-	N	R	0
SR1232									
SR1233	Target position of ECAT communication ID 15 of the Delta servo (32-bit)	○	-	0	0	-	N	R	0
SR1234									
SR1235	Target position of ECAT communication ID 16 of the Delta servo (32-bit)	○	-	0	0	-	N	R	0
SR1236									
SR1241	Read the self-defined value from ECAT communication ID 9 of Delta servo (32-bit)	○	-	0	0	-	N	R	0
SR1242									
SR1243	Read the self-defined value from ECAT communication ID 10 of Delta servo (32-bit)	○	-	0	0	-	N	R	0
SR1244									
SR1245	Read the self-defined value from ECAT communication ID 11 of Delta servo (32-bit)	○	-	0	0	-	N	R	0
SR1246									
SR1247	Read the self-defined value from ECAT communication ID 12 of Delta servo (32-bit)	○	-	0	0	-	N	R	0
SR1248									
SR1249	Read the self-defined value from ECAT communication ID 13 of Delta servo (32-bit)	○	-	0	0	-	N	R	0
SR1250									
SR1251	Read the self-defined value from ECAT communication ID 14 of Delta servo (32-bit)	○	-	0	0	-	N	R	0
SR1252									
SR1253	Read the self-defined value from ECAT communication ID 15 of Delta servo (32-bit)	○	-	0	0	-	N	R	0
SR1254									
SR1255	Read the self-defined value from ECAT communication ID 16 of Delta servo (32-bit)	○	-	0	0	-	N	R	0
SR1256									
SR1261	The acceptable range for ECAT communication ID 9 of Delta servo to determine the positioning is complete.	○	-	0	0	-	N	R/W	0
SR1262	The acceptable range for ECAT communication ID 10 of Delta servo to determine the positioning is complete.	○	-	0	0	-	N	R/W	0
SR1263	The acceptable range for ECAT communication ID 11 of Delta servo to determine the positioning is complete.	○	-	0	0	-	N	R/W	0
SR1264	The acceptable range for ECAT communication ID 12 of Delta servo to determine the positioning is complete.	○	-	0	0	-	N	R/W	0

SR	Function	AS300 Series	AS100/200 Series	OFF ↓ ON	STOP ↓ RUN	RUN ↓ STOP	Latched	Attribute	Default
SR1265	The acceptable range for ECAT communication ID 13 of Delta servo to determine the positioning is complete.	○	-	0	0	-	N	R/W	0
SR1266	The acceptable range for ECAT communication ID 14 of Delta servo to determine the positioning is complete.	○	-	0	0	-	N	R/W	0
SR1267	The acceptable range for ECAT communication ID 15 of Delta servo to determine the positioning is complete.	○	-	0	0	-	N	R/W	0
SR1268	The acceptable range for ECAT communication ID 16 of Delta servo to determine the positioning is complete.	○	-	0	0	-	N	R/W	0
SR1291	The axis 1 will output the next segment or a specific number of segment during the execution of TPO instruction; this should work with SM591.	○	○	0	0	-	N	R/W	0
SR1292	The axis 2 will output the next segment or a specific number of segment during the execution of TPO instruction; this should work with SM592.	○	○	0	0	-	N	R/W	0
SR1293	The axis 3 will output the next segment or a specific number of segment during the execution of TPO instruction; this should work with SM593.	○	○	0	0	-	N	R/W	0
SR1294	The axis 4 will output the next segment or a specific number of segment during the execution of TPO instruction; this should work with SM594.	○	○	0	0	-	N	R/W	0
SR1295	The axis 5 will output the next segment or a specific number of segment during the execution of TPO instruction; this should work with SM595.	○	○	0	0	-	N	R/W	0
SR1296	The axis 6 will output the next segment or a specific number of segment during the execution of TPO instruction; this should work with SM596.	○	○	0	0	-	N	R/W	0
*SR1312	Communication code for RTU-EN01 connection 1	○	○	0	-	-	N	R	0
*SR1313	Communication code for RTU-EN01 connection 2	○	○	0	-	-	N	R	0
*SR1314	Communication code for RTU-EN01 connection 3	○	○	0	-	-	N	R	0
*SR1315	Communication code for RTU-EN01 connection 4	○	○	0	-	-	N	R	0
SR1318	Socket input counter	○	○	0	-	-	N	R	0
SR1319	Socket output counter	○	○	0	-	-	N	R	0
SR1320	Socket error counter	○	○	0	-	-	N	R	0
*SR1335	Actual cycle time of connection 1–32 for data exchange through COM1; unit: ms	○	○	0	-	-	N	R	0
*SR1336	Number of the connection that is currently performing a cyclical data exchange through COM1	○	○	0	-	-	N	R	0
*SR1340	Error code for data exchange through the COM1 connection 1	○	○	0	-	-	N	R	0
*SR1341	Error code for data exchange through the COM1 connection 2	○	○	0	-	-	N	R	0
*SR1342	Error code for data exchange through the COM1 connection 3	○	○	0	-	-	N	R	0

SR	Function			OFF ↓ ON	STOP ↓ RUN	RUN ↓ STOP	Latched	Attribute	Default
		AS300 Series	AS100/200 Series						
*SR1343	Error code for data exchange through the COM1 connection 4	○	○	0	-	-	N	R	0
*SR1344	Error code for data exchange through the COM1 connection 5	○	○	0	-	-	N	R	0
*SR1345	Error code for data exchange through the COM1 connection 6	○	○	0	-	-	N	R	0
*SR1346	Error code for data exchange through the COM1 connection 7	○	○	0	-	-	N	R	0
*SR1347	Error code for data exchange through the COM1 connection 8	○	○	0	-	-	N	R	0
*SR1348	Error code for data exchange through the COM1 connection 9	○	○	0	-	-	N	R	0
*SR1349	Error code for data exchange through the COM1 connection 10	○	○	0	-	-	N	R	0
*SR1350	Error code for data exchange through the COM1 connection 11	○	○	0	-	-	N	R	0
*SR1351	Error code for data exchange through the COM1 connection 12	○	○	0	-	-	N	R	0
*SR1352	Error code for data exchange through the COM1 connection 13	○	○	0	-	-	N	R	0
*SR1353	Error code for data exchange through the COM1 connection 14	○	○	0	-	-	N	R	0
*SR1354	Error code for data exchange through the COM1 connection 15	○	○	0	-	-	N	R	0
*SR1355	Error code for data exchange through the COM1 connection 16	○	○	0	-	-	N	R	0
*SR1356	Error code for data exchange through the COM1 connection 17	○	○	0	-	-	N	R	0
*SR1357	Error code for data exchange through the COM1 connection 18	○	○	0	-	-	N	R	0
*SR1358	Error code for data exchange through the COM1 connection 19	○	○	0	-	-	N	R	0
*SR1359	Error code for data exchange through the COM1 connection 20	○	○	0	-	-	N	R	0
*SR1360	Error code for data exchange through the COM1 connection 21	○	○	0	-	-	N	R	0
*SR1361	Error code for data exchange through the COM1 connection 22	○	○	0	-	-	N	R	0
*SR1362	Error code for data exchange through the COM1 connection 23	○	○	0	-	-	N	R	0
*SR1363	Error code for data exchange through the COM1 connection 24	○	○	0	-	-	N	R	0
*SR1364	Error code for data exchange through the COM1 connection 25	○	○	0	-	-	N	R	0

SR	Function	AS100/200 Series		OFF	STOP	RUN	Latched	Attribute	Default
		AS300 Series	AS100/200 Series	↓ ON	↓ RUN	↓ STOP			
*SR1365	Error code for data exchange through the COM1 connection 26	○	○	0	-	-	N	R	0
*SR1366	Error code for data exchange through the COM1 connection 27	○	○	0	-	-	N	R	0
*SR1367	Error code for data exchange through the COM1 connection 28	○	○	0	-	-	N	R	0
*SR1368	Error code for data exchange through the COM1 connection 29	○	○	0	-	-	N	R	0
*SR1369	Error code for data exchange through the COM1 connection 30	○	○	0	-	-	N	R	0
*SR1370	Error code for data exchange through the COM1 connection 31	○	○	0	-	-	N	R	0
*SR1371	Error code for data exchange through the COM1 connection 32	○	○	0	-	-	N	R	0
*SR1375	Actual cycle time of connection 1–32 for data exchange through COM2; unit: ms	○	○	0	-	-	N	R	0
*SR1376	Number of the connection that is currently performing a cyclical data exchange through COM2	○	○	0	-	-	N	R	0
*SR1380	Error code for data exchange through the COM2 connection 1	○	○	0	-	-	N	R	0
SR1381	Error code for data exchange through the COM2 connection 2	○	○	0	-	-	N	R	0
SR1382	Error code for data exchange through the COM2 connection 3	○	○	0	-	-	N	R	0
SR1383	Error code for data exchange through the COM2 connection 4	○	○	0	-	-	N	R	0
SR1384	Error code for data exchange through the COM2 connection 5	○	○	0	-	-	N	R	0
SR1385	Error code for data exchange through the COM2 connection 6	○	○	0	-	-	N	R	0
SR1386	Error code for data exchange through the COM2 connection 7	○	○	0	-	-	N	R	0
SR1387	Error code for data exchange through the COM2 connection 8	○	○	0	-	-	N	R	0
SR1388	Error code for data exchange through the COM2 connection 9	○	○	0	-	-	N	R	0
SR1389	Error code for data exchange through the COM2 connection 10	○	○	0	-	-	N	R	0
SR1390	Error code for data exchange through the COM2 connection 11	○	○	0	-	-	N	R	0
SR1391	Error code for data exchange through the COM2 connection 12	○	○	0	-	-	N	R	0
SR1392	Error code for data exchange through the COM2 connection 13	○	○	0	-	-	N	R	0

SR	Function			OFF ↓ ON	STOP ↓ RUN	RUN ↓ STOP	Latched	Attribute	Default
		AS300 Series	AS100/200 Series						
SR1393	Error code for data exchange through the COM2 connection 14	○	○	0	-	-	N	R	0
SR1394	Error code for data exchange through the COM2 connection 15	○	○	0	-	-	N	R	0
SR1395	Error code for data exchange through the COM2 connection 16	○	○	0	-	-	N	R	0
SR1396	Error code for data exchange through the COM2 connection 17	○	○	0	-	-	N	R	0
SR1397	Error code for data exchange through the COM2 connection 18	○	○	0	-	-	N	R	0
SR1398	Error code for data exchange through the COM2 connection 19	○	○	0	-	-	N	R	0
SR1399	Error code for data exchange through the COM2 connection 20	○	○	0	-	-	N	R	0
SR1400	Error code for data exchange through the COM2 connection 21	○	○	0	-	-	N	R	0
SR1401	Error code for data exchange through the COM2 connection 22	○	○	0	-	-	N	R	0
SR1402	Error code for data exchange through the COM2 connection 23	○	○	0	-	-	N	R	0
SR1403	Error code for data exchange through the COM2 connection 24	○	○	0	-	-	N	R	0
SR1404	Error code for data exchange through the COM2 connection 25	○	○	0	-	-	N	R	0
SR1405	Error code for data exchange through the COM2 connection 26	○	○	0	-	-	N	R	0
SR1406	Error code for data exchange through the COM2 connection 27	○	○	0	-	-	N	R	0
SR1407	Error code for data exchange through the COM2 connection 28	○	○	0	-	-	N	R	0
SR1408	Error code for data exchange through the COM2 connection 29	○	○	0	-	-	N	R	0
SR1409	Error code for data exchange through the COM2 connection 30	○	○	0	-	-	N	R	0
SR1410	Error code for data exchange through the COM2 connection 31	○	○	0	-	-	N	R	0
SR1411	Error code for data exchange through the COM2 connection 32	○	○	0	-	-	N	R	0
SR1430	Then connection number of OPC UA Server	○	-	0	-	-	N	R	0
SR1431	The connection number of OPC UA Client	○	-	0	-	-	N	R	0
*SR1435	Actual cycle time for data exchange through Function Card 1; unit: ms	○	-	0	-	-	N	R	0
*SR1436	Number of the connection that is currently performing a cyclical data exchange through Function Card 1	○	-	0	-	-	N	R	0

SR	Function	AS100/200 Series		OFF	STOP	RUN	Latched	Attribute	Default
		AS300 Series		↓ ON	↓ RUN	↓ STOP			
*SR1440	Error in data exchange connection 1 through Function Card 1	○	-	0	-	-	N	R	0
*SR1441	Error in data exchange connection 2 through Function Card 1	○	-	0	-	-	N	R	0
*SR1442	Error in data exchange connection 3 through Function Card 1	○	-	0	-	-	N	R	0
*SR1443	Error in data exchange connection 4 through Function Card 1	○	-	0	-	-	N	R	0
*SR1444	Error in data exchange connection 5 through Function Card 1	○	-	0	-	-	N	R	0
*SR1445	Error in data exchange connection 6 through Function Card 1	○	-	0	-	-	N	R	0
*SR1446	Error in data exchange connection 7 through Function Card 1	○	-	0	-	-	N	R	0
*SR1447	Error in data exchange connection 8 through Function Card 1	○	-	0	-	-	N	R	0
*SR1448	Error in data exchange connection 9 through Function Card 1	○	-	0	-	-	N	R	0
*SR1449	Error in data exchange connection 10 through Function Card 1	○	-	0	-	-	N	R	0
*SR1450	Error in data exchange connection 11 through Function Card 1	○	-	0	-	-	N	R	0
*SR1451	Error in data exchange connection 12 through Function Card 1	○	-	0	-	-	N	R	0
*SR1452	Error in data exchange connection 13 through Function Card 1	○	-	0	-	-	N	R	0
*SR1453	Error in data exchange connection 14 through Function Card 1	○	-	0	-	-	N	R	0
*SR1454	Error in data exchange connection 15 through Function Card 1	○	-	0	-	-	N	R	0
*SR1455	Error in data exchange connection 16 through Function Card 1	○	-	0	-	-	N	R	0
*SR1456	Error in data exchange connection 17 through Function Card 1	○	-	0	-	-	N	R	0
*SR1457	Error in data exchange connection 18 through Function Card 1	○	-	0	-	-	N	R	0
*SR1458	Error in data exchange connection 19 through Function Card 1	○	-	0	-	-	N	R	0
*SR1459	Error in data exchange connection 20 through Function Card 1	○	-	0	-	-	N	R	0
*SR1460	Error in data exchange connection 21 through Function Card 1	○	-	0	-	-	N	R	0
*SR1461	Error in data exchange connection 22 through Function Card 1	○	-	0	-	-	N	R	0

SR	Function	AS300 Series	AS100/200 Series	OFF ↓ ON	STOP ↓ RUN	RUN ↓ STOP	Latched	Attribute	Default
*SR1462	Error in data exchange connection 23 through Function Card 1	○	-	0	-	-	N	R	0
*SR1463	Error in data exchange connection 24 through Function Card 1	○	-	0	-	-	N	R	0
*SR1464	Error in data exchange connection 25 through Function Card 1	○	-	0	-	-	N	R	0
*SR1465	Error in data exchange connection 26 through Function Card 1	○	-	0	-	-	N	R	0
*SR1466	Error in data exchange connection 27 through Function Card 1	○	-	0	-	-	N	R	0
*SR1467	Error in data exchange connection 28 through Function Card 1	○	-	0	-	-	N	R	0
*SR1468	Error in data exchange connection 29 through Function Card 1	○	-	0	-	-	N	R	0
*SR1469	Error in data exchange connection 30 through Function Card 1	○	-	0	-	-	N	R	0
*SR1470	Error in data exchange connection 31 through Function Card 1	○	-	0	-	-	N	R	0
*SR1471	Error in data exchange connection 32 through Function Card 1	○	-	0	-	-	N	R	0
*SR1475	Actual cycle time for data exchange through Function Card 2; unit: ms	○	-	0	-	-	N	R	0
*SR1476	Number of the connection that is currently performing a cyclical data exchange through Function Card 2	○	-	0	-	-	N	R	0
*SR1480	Error in data exchange connection 1 through Function Card 2	○	-	0	-	-	N	R	0
*SR1481	Error in data exchange connection 2 through Function Card 2	○	-	0	-	-	N	R	0
*SR1482	Error in data exchange connection 3 through Function Card 2	○	-	0	-	-	N	R	0
*SR1483	Error in data exchange connection 4 through Function Card 2	○	-	0	-	-	N	R	0
SR1484	Error in data exchange connection 5 through Function Card 2	○	-	0	-	-	N	R	0
*SR1485	Error in data exchange connection 6 through Function Card 2	○	-	0	-	-	N	R	0
*SR1486	Error in data exchange connection 7 through Function Card 2	○	-	0	-	-	N	R	0
*SR1487	Error in data exchange connection 8 through Function Card 2	○	-	0	-	-	N	R	0
*SR1488	Error in data exchange connection 9 through Function Card 2	○	-	0	-	-	N	R	0
*SR1489	Error in data exchange connection 10 through Function Card 2	○	-	0	-	-	N	R	0

SR	Function	AS100/200 Series		OFF	STOP	RUN	Latched	Attribute	Default
		AS300 Series		↓ ON	↓ RUN	↓ STOP			
*SR1490	Error in data exchange connection 11 through Function Card 2	○	-	0	-	-	N	R	0
*SR1491	Error in data exchange connection 12 through Function Card 2	○	-	0	-	-	N	R	0
*SR1492	Error in data exchange connection 13 through Function Card 2	○	-	0	-	-	N	R	0
*SR1493	Error in data exchange connection 14 through Function Card 2	○	-	0	-	-	N	R	0
*SR1494	Error in data exchange connection 15 through Function Card 2	○	-	0	-	-	N	R	0
*SR1495	Error in data exchange connection 16 through Function Card 2	○	-	0	-	-	N	R	0
*SR1496	Error in data exchange connection 17 through Function Card 2	○	-	0	-	-	N	R	0
*SR1497	Error in data exchange connection 18 through Function Card 2	○	-	0	-	-	N	R	0
*SR1498	Error in data exchange connection 19 through Function Card 2	○	-	0	-	-	N	R	0
*SR1499	Error in data exchange connection 20 through Function Card 2	○	-	0	-	-	N	R	0
*SR1500	Error in data exchange connection 21 through Function Card 2	○	-	0	-	-	N	R	0
*SR1501	Error in data exchange connection 22 through Function Card 2	○	-	0	-	-	N	R	0
*SR1502	Error in data exchange connection 23 through Function Card 2	○	-	0	-	-	N	R	0
*SR1503	Error in data exchange connection 24 through Function Card 2	○	-	0	-	-	N	R	0
*SR1504	Error in data exchange connection 25 through Function Card 2	○	-	0	-	-	N	R	0
*SR1505	Error in data exchange connection 26 through Function Card 2	○	-	0	-	-	N	R	0
*SR1506	Error in data exchange connection 27 through Function Card 2	○	-	0	-	-	N	R	0
*SR1507	Error in data exchange connection 28 through Function Card 2	○	-	0	-	-	N	R	0
*SR1508	Error in data exchange connection 29 through Function Card 2	○	-	0	-	-	N	R	0
*SR1509	Error in data exchange connection 30 through Function Card 2	○	-	0	-	-	N	R	0
*SR1510	Error in data exchange connection 31 through Function Card 2	○	-	0	-	-	N	R	0
*SR1511	Error in data exchange connection 32 through Function Card 2	○	-	0	-	-	N	R	0

SR	Function			OFF ↓ ON	STOP ↓ RUN	RUN ↓ STOP	Latched	Attribute	Default
		AS300 Series	AS100/200 Series						
*SR1520	The actual communication time for data exchange connection 1 through AS-FEN02; unit: ms	○	-	0	-	-	N	R	0
*SR1521	The actual communication time for data exchange connection 2 through AS-FEN02; unit: ms	○	-	0	-	-	N	R	0
*SR1522	The actual communication time for data exchange connection 3 through AS-FEN02; unit: ms	○	-	0	-	-	N	R	0
*SR1523	The actual communication time for data exchange connection 4 through AS-FEN02; unit: ms	○	-	0	-	-	N	R	0
*SR1524	The actual communication time for data exchange connection 5 through AS-FEN02; unit: ms	○	-	0	-	-	N	R	0
*SR1525	The actual communication time for data exchange connection 6 through AS-FEN02; unit: ms	○	-	0	-	-	N	R	0
*SR1526	The actual communication time for data exchange connection 7 through AS-FEN02; unit: ms	○	-	0	-	-	N	R	0
*SR1527	The actual communication time for data exchange connection 8 through AS-FEN02; unit: ms	○	-	0	-	-	N	R	0
*SR1528	Error in data exchange connection 1 through AS-FEN02	○	-	0	-	-	N	R	0
*SR1529	Error in data exchange connection 2 through AS-FEN02	○	-	0	-	-	N	R	0
*SR1530	Error in data exchange connection 3 through AS-FEN02	○	-	0	-	-	N	R	0
*SR1531	Error in data exchange connection 4 through AS-FEN02	○	-	0	-	-	N	R	0
*SR1532	Error in data exchange connection 5 through AS-FEN02	○	-	0	-	-	N	R	0
*SR1533	Error in data exchange connection 6 through AS-FEN02	○	-	0	-	-	N	R	0
*SR1534	Error in data exchange connection 7 through AS-FEN02	○	-	0	-	-	N	R	0
*SR1535	Error in data exchange connection 8 through AS-FEN02	○	-	0	-	-	N	R	0
*SR1536	TCP connection number of AS-FEN02 / AS-FECAT	○	-	0	-	-	N	R	0
*SR1537	Number of Modbus/TCP Server connections through AS-FEN02 / AS-FECAT	○	-	0	-	-	N	R	0
*SR1538	Number of Modbus/TCP Client connections through AS-FEN02	○	-	0	-	-	N	R	0
*SR1539	Number of EtherNet/IP Adapter connections through AS-FEN02	○	-	0	-	-	N	R	0
*SR1559	Number of the remote modules connected to the CPU module (all right-side modules not included)	○	○	0	-	-	N	R	0
*SR1560	Number of the right-side modules connected to the CPU module	○	○	0	-	-	N	R	0
*SR1561	Model code of the 1 <sup>st</sup> right-side module connected to the CPU module or the remote module	○	○	0	-	-	N	R	0
*SR1562	Model code of the 2 <sup>nd</sup> right-side module connected to the CPU module or the remote module	○	○	0	-	-	N	R	0
*SR1563	Model code of the 3 <sup>rd</sup> right-side module connected to the CPU module or the remote module	○	○	0	-	-	N	R	0
*SR1564	Model code of the 4 <sup>th</sup> right-side module connected to the CPU module or the remote module	○	○	0	-	-	N	R	0

SR	Function	AS100/200 Series		OFF	STOP	RUN	Latched	Attribute	Default
		AS300 Series		↓ ON	↓ RUN	↓ STOP			
*SR1565	Model code of the 5 <sup>th</sup> right-side module connected to the CPU module or the remote module	○	○	0	-	-	N	R	0
*SR1566	Model code of the 6 <sup>th</sup> right-side module connected to the CPU module or the remote module	○	○	0	-	-	N	R	0
*SR1567	Model code of the 7 <sup>th</sup> right-side module connected to the CPU module or the remote module	○	○	0	-	-	N	R	0
*SR1568	Model code of the 8 <sup>th</sup> right-side module connected to the CPU module or the remote module	○	○	0	-	-	N	R	0
*SR1569	Model code of the 9 <sup>th</sup> right-side module connected to the CPU module or the remote module	○	○	0	-	-	N	R	0
*SR1570	Model code of the 10 <sup>th</sup> right-side module connected to the CPU module or the remote module	○	○	0	-	-	N	R	0
*SR1571	Model code of the 11 <sup>th</sup> right-side module connected to the CPU module or the remote module	○	○	0	-	-	N	R	0
*SR1572	Model code of the 12 <sup>th</sup> right-side module connected to the CPU module or the remote module	○	○	0	-	-	N	R	0
*SR1573	Model code of the 13 <sup>th</sup> right-side module connected to the CPU module or the remote module	○	○	0	-	-	N	R	0
*SR1574	Model code of the 14 <sup>th</sup> right-side module connected to the CPU module or the remote module	○	○	0	-	-	N	R	0
*SR1575	Model code of the 15 <sup>th</sup> right-side module connected to the CPU module or the remote module	○	○	0	-	-	N	R	0
*SR1576	Model code of the 16 <sup>th</sup> right-side module connected to the CPU module or the remote module	○	○	0	-	-	N	R	0
*SR1577	Model code of the 17 <sup>th</sup> right-side module connected to the CPU module or the remote module	○	○	0	-	-	N	R	0
*SR1578	Model code of the 18 <sup>th</sup> right-side module connected to the CPU module or the remote module	○	○	0	-	-	N	R	0
*SR1579	Model code of the 19 <sup>th</sup> right-side module connected to the CPU module or the remote module	○	○	0	-	-	N	R	0
*SR1580	Model code of the 20 <sup>th</sup> right-side module connected to the CPU module or the remote module	○	○	0	-	-	N	R	0
*SR1581	Model code of the 21 <sup>st</sup> right-side module connected to the CPU module or the remote module	○	○	0	-	-	N	R	0
*SR1582	Model code of the 22 <sup>nd</sup> right-side module connected to the CPU module or the remote module	○	○	0	-	-	N	R	0
*SR1583	Model code of the 23 <sup>th</sup> right-side module connected to the CPU module or the remote module	○	○	0	-	-	N	R	0
*SR1584	Model code of the 24 <sup>th</sup> right-side module connected to the CPU module or the remote module	○	○	0	-	-	N	R	0
*SR1585	Model code of the 25 <sup>th</sup> right-side module connected to the CPU module or the remote module	○	○	0	-	-	N	R	0
*SR1586	Model code of the 26 <sup>th</sup> right-side module connected to the CPU module or the remote module	○	○	0	-	-	N	R	0
*SR1587	Model code of the 27 <sup>th</sup> right-side module connected to the CPU module or the remote module	○	○	0	-	-	N	R	0

SR	Function			OFF ↓ ON	STOP ↓ RUN	RUN ↓ STOP	Latched	Attribute	Default
		AS300 Series	AS100/200 Series						
*SR1588	Model code of the 28 <sup>th</sup> right-side module connected to the CPU module or the remote module	○	○	0	-	-	N	R	0
*SR1589	Model code of the 29 <sup>th</sup> right-side module connected to the CPU module or the remote module	○	○	0	-	-	N	R	0
*SR1590	Model code of the 30 <sup>th</sup> right-side module connected to the CPU module or the remote module	○	○	0	-	-	N	R	0
*SR1591	Model code of the 31 <sup>st</sup> right-side module connected to the CPU module or the remote module	○	○	0	-	-	N	R	0
*SR1592	Model code of the 32 <sup>nd</sup> right-side module connected to the CPU module or the remote module	○	○	0	-	-	N	R	0
SR1600	Activate the drive parameter restoration 0: Disable (default) 1: When PLC is powered on or is switched from STOP to RUN, the parameters will be stored. After the process to restore parameters is done, the state will be cleared to 0.	○	○	-	-	-	Y	R/W	0
SR1601	Designate the target drive number to perform parameter restoration (SR1601.0-SR1601.15 corresponds to the target drive number 1-16 0: Disable (default) ON: the designated target drive performs parameter restoration	○	○	-	-	-	Y	R/W	0
SR1602	Designate the target drive number to perform parameter restoration (Reserved SR1602.0-SR1602.15 for the target drive number 17-32 for future use.)	○	○	-	-	-	Y	R/W	0
SR1603	Total number of the drives that encountered errors during parameters restoration. 0: no error occurred 1-16: Total number of the drives that encountered errors during parameters restoration.	○	○	0	-	-	N	R	0
SR1604	The number of the most recent drive that encountered errors during parameters restoration. 0-255: the last digit of the IP address of the most recent drive that encountered errors during parameters restoration. (Only works when SM1161 is ON.)	○	○	0	-	-	N	R	0
SR1605	The error code of the most recent occurred error on the drive during parameters restoration.	○	○	0	-	-	N	R	0
*SR1700	Flag to define the frequency to compensate backlashes at Y0.0/Y0.1 for CSFO instruction (Hz)	○	○	0	0	-	N	R/W	0
*SR1702	Flag to define the frequency to compensate backlashes at Y0.2/Y0.3 for CSFO instruction (Hz)	○	○	0	0	-	N	R/W	0
*SR1704	Flag to define the frequency to compensate backlashes at Y0.4/Y0.5 for CSFO instruction (Hz)	○	○	0	0	-	N	R/W	0
*SR1706	Flag to define the frequency to compensate backlashes at Y0.6/Y0.7 for CSFO instruction (Hz)	○	○	0	0	-	N	R/W	0

SR	Function	AS300 Series	AS100/200 Series	OFF ↓ ON	STOP ↓ RUN	RUN ↓ STOP	Latched	Attribute	Default
*SR1708	Flag to define the frequency to compensate backlashes at Y0.8/Y0.9 for CSFO instruction (Hz)	○	○	0	0	-	N	R/W	0
*SR1710	Flag to define the frequency to compensate backlashes at Y0.10/Y0.11 for CSFO instruction (Hz)	○	○	0	0	-	N	R/W	0

Note 1: for SR\*, refer to SM/SR table for more details

Note 2: the communication card in the table refers to AS-F232, AS-F422 and AS-F485.

### 2.2.15 Special Data Registers Refresh Conditions

Special data register	Time to refresh
SR0–SR2	Refresh the register when there is a program execution error.
SR4–SR6	Refresh the register when there is a grammar check error
SR8–SR9	Refresh the register when there is a watchdog timer error.
SR27	Update the value in the built-in AD for AS-F2AD. The system resets it to OFF.
SR28–SR31	Refresh the register when the output is used repeatedly by more than one high-speed output instruction.
SR32	Refresh the register once when there is an error. -1: no error occurred.
SR36	The register is refreshed by you. You set the flag SM36 to ON and the system saves the data to the memory card. After saving is complete, the system automatically resets it to OFF
SR38	Register is refreshed by the system. You reset it to OFF.
SR40–SR161	Refresh the register when there is an error.
SR162–SR163	After the manufactured PLC leaves the factory, every minute the PLC is supplied with power is counted and the register is refreshed every minute.
SR166–SR171	Register is refreshed by the system.
SR172–SR175	Register is refreshed by you.
SR176–SR179	Refresh the register according to the settings in HWCONFIG.
SR180	Refresh the register when the PLC is powered on and powered off.
SR182–SR183	Refresh the register according to the settings in HWCONFIG when the PLC is powered on. You can edit the settings afterwards.
SR185	Refresh the register for the cycle time after a cycle scan whenever a remote module is activated
SR190–SR197	Register is refreshed by you.
SR198–SR199	After a cycle scan when the PLC is powered on.
SR201–SR213	The register is refreshed according to the settings in HWCONFIG when the PLC is powered on. You can edit the settings afterwards.
SR215–SR216	The register is refreshed by the system.
SR217–SR218	The register is refreshed according to the settings in HWCONFIG when powered on. You can edit the settings afterwards.
SR220–SR226	Refresh the register every scan cycle.
SR227–SR308	Refresh the register when the program is downloaded to the PLC.
SR309–SR390	Refresh the register when the status of the PLC changes.
SR391–SR397	Refresh the register every scan cycle.
SR403–SR404	Register is refreshed by the system.
SR407	Refresh the register every second.
SR408–SR416	Refresh the register whenever the instruction END is executed.
SR421–SR424	Register is refreshed by you.
SR440–SR443	Refresh the register when the PLC is powered on.
SR444–SR451	Refresh the register when the PLC is powered on.
SR453	Refresh the register when there is an error.
SR460	Refresh the register whenever the high-speed output instruction is executed and the program is scanned. If the instruction is not executed, you can edit the settings.
SR462–SR466	Register is refreshed by you.
SR467	Register is refreshed by the system.
SR468–SR469	When the PLC is supplied with power, the register is refreshed according to the position planning table. You can edit the settings afterwards.

Special data register	Time to refresh
SR470	Register is refreshed by the system.
SR472	Register is refreshed by you.
SR474	Refresh the register whenever the high-speed output instruction is executed and the program is scanned. If the instruction is not executed, you can edit the settings.
SR476–SR477	Register is refreshed by you.
SR480	Refresh the register whenever the high-speed output instruction is executed and the program is scanned. If the instruction is not executed, you can edit the settings.
SR482–SR486	Register is refreshed by you.
SR487	Register is refreshed by the system.
SR488–SR489	Refresh the register when the PLC is powered on according to the position planning table. You can edit the settings afterwards.
SR490	Register is refreshed by the system.
SR492	Register is refreshed by you.
SR494	Refresh the register whenever the high-speed output instruction is executed and the program is scanned. If the instruction is not executed, you can edit the settings.
SR496–SR497	Register is refreshed by you.
SR500	Refresh the register whenever the high-speed output instruction is executed and the program is scanned. If the instruction is not executed, you can edit the settings.
SR502–SR506	Register is refreshed by you.
SR507	Register is refreshed by the system.
SR508–SR509	Refresh the register when the PLC is powered on according to the position planning table. You can edit the settings afterwards.
SR510	Register is refreshed by the system.
SR512	Register is refreshed by you.
SR514	Refresh the register whenever the high-speed output instruction is executed and the program is scanned. If the instruction is not executed, you can edit the settings.
SR516–SR517	Register is refreshed by you.
SR520	Refresh the register whenever the high-speed output instruction is executed and the program is scanned. If the instruction is not executed, you can edit the settings.
SR522–SR526	Register is refreshed by you.
SR527	Register is refreshed by the system.
SR528–SR529	Refresh the register when the PLC is powered on according to the position planning table. You can edit the settings afterwards.
SR530	Register is refreshed by the system.
SR532	Register is refreshed by you.
SR534	Refresh the register whenever the high-speed output instruction is executed and the program is scanned. If the instruction is not executed, you can edit the setting.
SR536–SR537	Register is refreshed by a user.
SR540	Refresh the register whenever the high-speed output instruction is executed and the program is scanned. If the instruction is not executed, you can edit the settings.
SR542–SR546	Register is refreshed by a user.
SR547	Register is refreshed by the system.
SR548–SR549	Refresh the register when the PLC is supplied with power according to the position planning table. You can edit the settings afterwards.
SR550	Register is refreshed by the system.
SR552	Register is refreshed by you.
SR554	Refresh the register whenever the high-speed output instruction is executed and the program is

Special data register	Time to refresh
	scanned. If the instruction is not executed, you can edit the settings.
SR556–SR557	Register is refreshed by you.
SR560	Refresh the register whenever the high-speed output instruction is executed and the program is scanned. If the instruction is not executed, you can edit the settings.
SR562–SR566	Register is refreshed by you.
SR567	Register is refreshed by the system.
SR568–SR569	Refresh the register when the PLC is powered on according to the position planning table. You can edit the settings afterwards.
SR570	Register is refreshed by the system.
SR572	Register is refreshed by you.
SR574	Refresh the register whenever the high-speed output instruction is executed and the program is scanned. If the instruction is not executed, you can edit the settings.
SR576–SR579	Register is refreshed by you.
SR580–SR603	Refresh the register according to the settings in HWCONFIG when the PLC is powered on. You can edit the settings afterwards.
SR610–SR621	Refresh the register whenever the output instruction is executed.
SR623–SR634	Refresh the register whenever the EIX or DIX instruction is executed. ON: interrupt is enabled OFF: interrupt is disabled
SR640–SR651	Register is refreshed by you.
SR652–SR655	Register is refreshed by the system.
SR656–SR657	Register is refreshed by the system. You reset it to OFF.
SR658–SR726	Register is refreshed by the system.
SR731–SR738	Register is refreshed by the system.
SR741–SR748	Register is refreshed by the system.
SR751–SR768	Register is refreshed by you.
SR771–SR778	Register is refreshed by the system.
SR781–SR788	Register is refreshed by the system.
SR791–SR806	Register is refreshed by the system.
SR811–SR818	Register is refreshed by you.
SR820	Refresh the register according to the settings in CANopen Builder.
SR821	Refresh the register when the firmware is updated.
SR822	Refresh the register according to the settings in HWCONFIG.
SR823–SR893	Register is refreshed by the system.
SR900–SR901	Register is refreshed by the system.
SR902	Register is refreshed by you.
SR1000–SR1006	1. Register is refreshed by you. 2. Register is refreshed after power-on or after HWCONFIG is downloaded.
SR1007	Register is refreshed by the system.
SR1009	Register is refreshed by the system.
SR1010	Register is refreshed by you.
SR1011–SR1014	Register is refreshed by the system.
SR1015	Register is refreshed by you.
SR1016	Register is refreshed by you.
SR1017	Register is refreshed by you.
SR1018	Refresh the register every scan cycle by the system.

Special data register	Time to refresh
SR1019	1. Refresh the register every scan cycle by the system. 2. Register is refreshed by you.
SR1020–SR1107	1. Refresh the register when a connection is established. 2. Refresh the register every scan cycle.
SR1092–SR1093	Register is refreshed by you.
SR1110	Register is refreshed by you. The system resets it to OFF.
SR1111–SR1114	Register is refreshed by you.
SR1116–SR1117	Refresh the register when the program is downloaded to the PLC.
SR1120–SR1183	Refresh the register when the communication is complete.
SR1191–SR1198	Register is refreshed by the system.
SR1201–SR1216	Register is refreshed by the system.
SR1221–SR1236	Register is refreshed by the system.
SR1241–SR1256	Register is refreshed by the system.
SR1261–SR1268	Register is refreshed by you.
SR1291–SR1296	Register is refreshed by you. The system resets it to OFF.
SR1312–SR1315	Refresh the register during communication
SR1318–SR1320	Refresh the register when the parameter is downloaded to the PLC, or when the PLC is supplied with power.
SR1335–SR1336	Refresh the register every scan cycle after the function of data exchange is enabled.
SR1340–SR1371	Refresh the register when there is an error.
SR1375–SR1376	Refresh the register every scan cycle after the function of data exchange is enabled.
SR1380–SR1411	Refresh the register when there is an error.
SR1430–SR1431	Register is refreshed by the system.
SR1435–SR1436	Refresh the register during communication
SR1440–SR1471	Refresh the register when error occurs during communication
SR1475–SR1476	Refresh the register during communication
SR1480–SR1511	Refresh the register when error occurs during communication
SR1520–SR1535	Refresh the register after the communication through AS-FEN02 is complete.
SR1536–SR1539	Register is refreshed by the system.
SR1559–SR1592	Register is refreshed by the system when when the system is supplied with power, disconnect from the remote module or reestablish the remote module connection.
SR1600–SR1602	Register is refreshed by you.
SR1603–SR1605	The error occurred on the drive during parameters restoration; Register is refreshed by the system.
SR1700, SR1702, SR1704, SR1706, SR1708, SR1710	Register is refreshed by you.

## 2.2.16 Additional Remarks on Special Auxiliary Relays and Special Data Registers

### 1. Scan timeout timer

- SM8/SR8

When a scan timeout occurs during the execution of the program, the error LED on the PLC changes to continuous ON, and SM8 changes to ON.

SR8 contains the step address at which the watchdog timer changed to ON.

### 2. Clearing the warning light

- SM22

Setting SM22 to ON clears the error log and the warning light.

### 3. CPU module and AD/DA Function Card

- Analog Input

AS-F2AD (applicable for AS300 Series PLC)		
Item	Voltage Input	Current Input
Analog Signal Input	DC 0–10 V	DC 4–20 mA
Resolution	12-bit	11-bit
Digital Conversion Range	0 - 4000	0 - 2000
SR Number	SR168 (Channel 1 of AS-F2AD card 1) SR169 (Channel 2 of AS-F2AD card 1) SR170 (Channel 1 of AS-F2AD card 2) SR171 (Channel 2 of AS-F2AD card 2)	

AS-F2DA (applicable for AS300 Series PLC)		
Item	Voltage Output	Current Output
Analog Signal Output	DC 0–10 V	DC 4–20 mA
Resolution	12-bit	11-bit
Digital Conversion Range	0 - 4000	0 - 2000
SR Number	SR172 (Channel 1 of AS-F2AD card 1) SR173 (Channel 2 of AS-F2AD card 1) SR174 (Channel 1 of AS-F2AD card 2) SR175 (Channel 2 of AS-F2AD card 2)	


AS218 built-in AD function			
Item	Voltage Input	Current Input	
Analog Signal Output	DC -10V ~ +10V	DC -20mA ~ 20mA	DC 4mA ~ 20mA*1
Resolution	12-bit	11-bit	11-bit
Digital Conversion Range	-2000 ~ 2000	-1000 ~ 1000	0 ~ 1000
SR Number	SR168 (CH1) SR169 (CH2)		

\*1: This is only available for AS218 with FW V1.06.20 and ISPSOft V3.08 or later.


- Analog-input error codes in SM27/SR27

When the conversion value in the analog input exceeding the allowable range or is encountered any connection lost, SM27 warning flag will be ON and the analog input error code will be stored in SR27. If the Input Warning in HWCONFIG is set to Enable, AS300 and AS200 Series CPU with FW V1.10.00 or later support this function. See the following setting images for reference.

AS300 Series: AS-F2AD installed in function card 1/2



AS200 Series: Built-in AD/DA Setting



Error code	Description	Solution
16#0040	The value to be converted from the built-in AD input channel 1 or AS-F2AD (function card 1) exceeds the allowable range.	Check the actual input signal
16#0041	The value to be converted from the built-in AD input channel 2 or AS-F2AD (function card 1) exceeds the allowable range.	Check the actual input signal
16#0042	The value to be converted from the input channel 1 of AS-F2AD (function card 2) exceeds the allowable range.	Check the actual input signal
16#0043	The value to be converted from the input channel 2 of AS-F2AD (function card 2) exceeds the allowable range.	Check the actual input signal
16#0044	The connection to current input 4mA~20mA mode from the built-in AD input channel 1 or AS-F2AD (function card 1) is losing.	Check the connection
16#0045	The connection to current input 4mA~20mA mode from the built-in AD input channel 2 or AS-F2AD (function card 1) is losing.	Check the connection
16#0046	The connection to current input 4mA~20mA mode from the input channel 1 of AS-F2AD (function card 2) is losing.	Check the connection
16#0047	The connection to current input 4mA~20mA mode from the input channel 2 of AS-F2AD (function card 2) is losing.	Check the connection

Function card: AS-F2AD

Analog Input mode	Corresponding value range	Remarks
Voltage: 0V ~ 10V	0 ~ 4000	1. Value > 4047 is seen as out of range 2. No connection lost detection
Current 4mA ~ 20mA	0 ~ 2000	1. Value < -24 or > 2023 is seen as out of range 2. Value < -36 is seen as connection lost.

AS218 built-in analog input:

Analog Input mode	Corresponding value range	Remarks
Voltage: -10V ~ 10V	-2000 ~ 2000	1. Value < -2024 or > 2023 is seen as out of range 2. No connection lost detection
Current: -20mA ~ 20mA	-1000 ~ 1000	1. Value < -1012 or > 1011 is seen as out of range 2. No connection lost detection
Current: 4mA ~ 20mA	0 ~ 1000	1. Value < -12 or > 1011 is seen as out of range 2. Value < -36 is seen as connection lost.

- Analog Output

AS-F2DA (applicable for AS300 Series PLC)		
Item	Voltage Input	Current Input
Analog Signal Input	DC 0–10 V	DC 4–20 mA
Resolution	12-bit	11-bit
Digital Conversion Range	0 - 4000	0 - 4000
SR Number	SR172 (Channel 1 of AS-F2DA card 1) SR173 (Channel 2 of AS-F2DA card 1) SR174 (Channel 1 of AS-F2DA card 2) SR175 (Channel 2 of AS-F2DA card 2)	

AS218 built-in DA function		
Item	Voltage Output	Current Output
Analog Signal Output	DC -10V ~ +10V	DC -0mA ~ 20mA
Resolution	12-bit	12-bit
Digital Conversion Range	-2000 ~ 2000	0 ~ 4000
SR Number	SR172 (CH1) SR173 (CH2)	

#### 4. The real-time clock

- SM220, SR220–SR226, and SR391–SR397

SM220: Calibrate the real-time clock within  $\pm 30$  seconds

When SM220 changes from OFF to ON, the system calibrates the real-time clock.

If the second value in the real-time clock is in the range 0–29, the minutes value is fixed, and the seconds value is cleared to zero.

If the value of the second in the real-time clock is in the range 30–59, the minutes value increases by one, and the seconds value is cleared to zero.

This table lists the corresponding functions and values of SR220–SR226 and SR391–SR397.

Device		Function	Value
Binary-coded decimal system	Decimal system		
SR220	SR391	Year	00–99 (A.D.)
SR221	SR392	Month	1–12
SR222	SR393	Day	1–31
SR223	SR394	Hour	0–23
SR224	SR395	Minute	0–59
SR225	SR396	Second	0–59
SR226	SR397	Week	1–7

SR391–SR397 correspond to SR220–SR226. The difference between SR220–SR226 and SR391–SR397 is that the former uses the binary-coded decimal while the latter uses the decimal system. For example, December is represented as 12 in SR392 while it is represented as 1100 in the binary-coded decimal. Refer to Chapter 6 for more information on the real-time clock.

## 5. Communication functions

- SM96–SM107, SM209–SM212, SR201–SR202, and SR209–SR216

SR215 and SR216 record the function card codes. The following table lists the functions represented by the interface codes.

<b>Code</b>	0	1	2	3	4	5	6
<b>Function</b>	No card	RS232	RS422	RS485	F2AD	F2DA	FCOPM
<b>Code</b>	7	8	9	10	11	7	8
<b>Function</b>	FEN02	FPFN02	FOPC02	FFTP01	FECAT	FEN02	FPFN02

The function cards including FCOPM, FEN02, PPFN02, FOPC02, FFTP01, FECAT are only supported as Function Card 2.

When the communication port protocol for the PLC is RS485, RS232, or RS422, then SR209 records the communication format of the COM1 port on the PLC, and SR212 records the communication format of the COM2 port on the PLC. The following table lists the settings for the communication protocols. Refer to Chapter 6 for more information on the communication instructions.

<b>b0</b>	Data length			7 (value=0)		8 (value=1)	
<b>b1</b> <b>b2</b>	Parity bits			00	:	None	
				01	:	Odd parity bits	
				10	:	Even parity bits	
<b>b3</b>	Stop bits			1 bit (value=0)		2 bits (value=1)	
<b>b4</b> <b>b5</b> <b>b6</b> <b>b7</b>	0001	(H 1)	:	4800			
	0010	(H 2)	:	9600			
	0011	(H 3)	:	19200			
	0100	(H 4)	:	38400			
	0101	(H 5)	:	57600			
	0110	(H 6)	:	115200			

	0111	(H 7)	:	230400	
	1000	(H 8)	:	500000	
	1001	(H 9)	:	921000	
	1010	(16#A)	:	Undefined	
	1011	(16#B)	:	Undefined	
	1100	(16#C)	:	Undefined	
	1101	(16#D)	:	Undefined	
	1110	(16#E)	:	Undefined	
	1111	(16#F)	:	User-defined*1	
<b>b8-b15</b>	Undefined (reserved)				

\*1: Refer to the HWCONFIG settings in ISPSOft for the user-defined baudrate.

\*2: Refer to section 6.19.3 for the use of communication flags and registers.

## 6. Clearing the device contents

- SM203/SM204/SM205

Device number	Device which is cleared
SM203/SM204 All non-latched areas are cleared.	The non-latched areas in the input relays, the output relays, the stepping relays, and the auxiliary relays are cleared. The non-latched areas in the timers, the counters, and the 32-bit counters are cleared. The non-latched areas in the data registers and the index registers are cleared. The watchdog timer does not act during this period of time.
SM205 All latched areas are cleared.	The latched areas in the timers, counters, and 32-bit counters are cleared. The latched auxiliary relays are cleared. The latched data registers are cleared. The watchdog timer does not act during this period of time.

Refer to Section 2.1.4 for more information on the latched areas in the device range.

## 7. PLC error log

- SR40-SR161

SR40: The maximum number of error logs stored in SR40 is 20. If the number of the error logs exceeds the maximum number 20, only 20 of them will be stored. Each error log occupies 6 registers.

SR41: The error log pointer points to the latest error log. When an error occurs, the value of the error log pointer increases by one. The range of pointer values is 0–19. For example, the error log pointer points to the fourth error log when the value in SR41 is 3. If the value in SR41 is 20, that means the number of error logs exceeds 20 and is now in cycle.

SR42~SR161: The time of the error and the position where the error occurs are recorded in SR42~SR161. The Isot column records the CPU (0) and the remote module number (1~15). The following table lists the corresponding functions of these data registers.

Number	Slot	Module ID	Error code	Time when the error occurs					
				Year	Month	Day	Hour	Minute	Second
1	SR42 Low byte	SR43	SR44	SR45 High byte	SR45 Low byte	SR46 High byte	SR46 Low byte	SR47 High byte	SR47 Low byte

Number	Slot	Module ID	Error code	Time when the error occurs					
				Year	Month	Day	Hour	Minute	Second
2	SR48 Low byte	SR49	SR50	SR51 High byte	SR51 Low byte	SR52 High byte	SR52 Low byte	SR53 High byte	SR53 Low byte
3	SR54 Low byte	SR55	SR56	SR57 High byte	SR57 Low byte	SR58 High byte	SR58 Low byte	SR59 High byte	SR59 Low byte
4	SR60 Low byte	SR61	SR62	SR63 High byte	SR63 Low byte	SR64 High byte	SR64 Low byte	SR65 High byte	SR65 Low byte
5	SR66 Low byte	SR67	SR68	SR69 High byte	SR69 Low byte	SR70 High byte	SR70 Low byte	SR71 High byte	SR71 Low byte
6	SR72 Low byte	SR73	SR74	SR75 High byte	SR75 Low byte	SR76 High byte	SR76 Low byte	SR77 High byte	SR77 Low byte
7	SR78 Low byte	SR79	SR80	SR81 High byte	SR81 Low byte	SR82 High byte	SR82 Low byte	SR83 High byte	SR83 Low byte
8	SR84 Low byte	SR85	SR86	SR87 High byte	SR87 Low byte	SR88 High byte	SR88 Low byte	SR89 High byte	SR89 Low byte
9	SR90 Low byte	SR91	SR92	SR93 High byte	SR93 Low byte	SR94 High byte	SR94 Low byte	SR95 High byte	SR95 Low byte
10	SR96 Low byte	SR97	SR98	SR99 High byte	SR99 Low byte	SR100 High byte	SR100 Low byte	SR101 High byte	SR101 Low byte
11	SR102 Low byte	SR103	SR104	SR105 High byte	SR105 Low byte	SR106 High byte	SR106 Low byte	SR107 High byte	SR107 Low byte
12	SR108 Low byte	SR109	SR110	SR111 High byte	SR111 Low byte	SR112 High byte	SR112 Low byte	SR113 High byte	SR113 Low byte
13	SR114 Low byte	SR115	SR116	SR117 High byte	SR117 Low byte	SR118 High byte	SR118 Low byte	SR119 High byte	SR119 Low byte
14	SR120 Low byte	SR121	SR122	SR123 High byte	SR123 Low byte	SR124 High byte	SR124 Low byte	SR125 High byte	SR125 Low byte
15	SR126 Low byte	SR127	SR128	SR129 High byte	SR129 Low byte	SR130 High byte	SR130 Low byte	SR131 High byte	SR131 Low byte
16	SR132 Low byte	SR133	SR134	SR135 High byte	SR135 Low byte	SR136 High byte	SR136 Low byte	SR137 High byte	SR137 Low byte
17	SR138 Low byte	SR139	SR140	SR141 High byte	SR141 Low byte	SR142 High byte	SR142 Low byte	SR143 High byte	SR143 Low byte
18	SR144 Low byte	SR145	SR146	SR147 High byte	SR147 Low byte	SR148 High byte	SR148 Low byte	SR149 High byte	SR149 Low byte
19	SR150 Low byte	SR151	SR152	SR153 High byte	SR153 Low byte	SR154 High byte	SR154 Low byte	SR155 High byte	SR155 Low byte
20	SR156 Low byte	SR157	SR158	SR159 High byte	SR159 Low byte	SR160 High byte	SR160 Low byte	SR161 High byte	SR161 Low byte

## 8. PLC download log

- SR227-SR308

SR227: The maximum number of download logs which are stored in SR227 is 20. Every download log occupies 4 registers. The download actions which are recorded are numbered, as shown in the following table.

Number (HEX)	Download action
0x0001	Downloading the program
0x0002	Downloading the PLC setting
0x0003	Downloading the I/O module table
0x000A	PLC operation codes (ISP)
0x000B	PLC parameters (HWCONFIG)
0x000C	Module configurations (HWCONFIG)
0x000D	PLC operation codes and programs (ISP)
0x000E	PLC operation codes (Online editing)
0x000F	PLC operation codes and programs (Online editing)
0x0010	PLC operation codes and programs (Restoration from SD card)
0x0011	Module configurations and PLC parameters (HWCONFIG)
0x0012	Module configurations and data exchange table (HWCONFIG)
0x0013	Module configurations and data exchange table (HWCONFIG)
0x0014	Module configurations (EIP Builder)
0x0015	Module configurations, PLC parameters and data exchange table (Restoration from SD card)

Note: ISPSooft V3.13 or later and CPU with FW V1.10 or later supports 0x000A – 0x0015.

SR228: The download log pointer points to the latest download log. When a download action is executed, the value of the download log pointer increases by one. The range of pointer values is 0–19. For example, the download log pointer points to the fourth download log when the value in SR228 is 3.

The time of the downloading and the action numbers are recorded in SR229–SR30. The following table lists the corresponding functions of these data registers.

No.	Action number	*Time when the download occurs					
		Year	Month	Day	Hour	Minute	Second
1	SR229	SR230 High byte	SR230 Low byte	SR231 High byte	SR231 Low byte	SR232 High byte	SR232 Low byte
2	SR233	SR234 High byte	SR234 Low byte	SR235 High byte	SR235 Low byte	SR236 High byte	SR236 Low byte
3	SR237	SR238 High byte	SR238 Low byte	SR239 High byte	SR239 Low byte	SR240 High byte	SR240 Low byte
4	SR241	SR242 High byte	SR242 Low byte	SR243 High byte	SR243 Low byte	SR244 High byte	SR244 Low byte
5	SR245	SR246 High byte	SR246 Low byte	SR247 High byte	SR247 Low byte	SR248 High byte	SR248 Low byte
6	SR249	SR250 High byte	SR250 Low byte	SR251 High byte	SR251 Low byte	SR252 High byte	SR252 Low byte

No.	Action number	*Time when the download occurs					
		Year	Month	Day	Hour	Minute	Second
7	SR253	SR254 High byte	SR254 Low byte	SR255 High byte	SR255 Low byte	SR256 High byte	SR256 Low byte
8	SR257	SR258 High byte	SR258 Low byte	SR259 High byte	SR259 Low byte	SR260 High byte	SR260 Low byte
9	SR261	SR262 High byte	SR262 Low byte	SR263 High byte	SR263 Low byte	SR264 High byte	SR264 Low byte
10	SR265	SR266 High byte	SR266 Low byte	SR267 High byte	SR267 Low byte	SR268 High byte	SR268 Low byte
11	SR269	SR270 High byte	SR270 Low byte	SR271 High byte	SR271 Low byte	SR272 High byte	SR272 Low byte
12	SR273	SR274 High byte	SR274 Low byte	SR275 High byte	SR275 Low byte	SR276 High byte	SR276 Low byte
13	SR277	SR278 High byte	SR278 Low byte	SR279 High byte	SR279 Low byte	SR280 High byte	SR280 Low byte
14	SR281	SR282 High byte	SR282 Low byte	SR283 High byte	SR283 Low byte	SR284 High byte	SR284 Low byte
15	SR285	SR286 High byte	SR286 Low byte	SR287 High byte	SR287 Low byte	SR288 High byte	SR288 Low byte
16	SR289	SR290 High byte	SR290 Low byte	SR291 High byte	SR291 Low byte	SR292 High byte	SR292 Low byte
17	SR293	SR294 High byte	SR294 Low byte	SR295 High byte	SR295 Low byte	SR296 High byte	SR296 Low byte
18	SR297	SR298 High byte	SR298 Low byte	SR299 High byte	SR299 Low byte	SR300 High byte	SR300 Low byte
19	SR301	SR302 High byte	SR302 Low byte	SR303 High byte	SR303 Low byte	SR304 High byte	SR304 Low byte
20	SR305	SR306 High byte	SR306 Low byte	SR307 High byte	SR307 Low byte	SR308 High byte	SR308 Low byte

\* The format for the download action time: the data is stored as a binary-coded decimal. The following table lists the range of values.

Function	Value
Year	00–99 (A.D.)
Month	01–12
Day	01–31
Hour	00–23
Minute	00–59
Second	00–59

## 9. The PLC status change log

- SR309–SR390

SR309: The maximum number of PLC status change logs stored in SR309 is 20. Each PLC status change log occupies 4 registers. The recorded PLC status change actions are numbered, as shown in the following table.

PLC status change	Number
PLC powered on.	1
PLC disconnected.	2
PLC starts to run.	3
PLC stops.	4
Default setting in the PLC	5
Emergency stop	7
Write RTC	8

SR310: The PLC status change log pointer points to the latest PLC status change log. When the PLC status changes, the value of the PLC status change log pointer increases by one. The range of pointer values is 0–19. For example, PLC status change log pointer points to the fourth PLC status change log when the value in SR310 is 3.

The time when the PLC status change actions occur is recorded in SR311–SR390. The following table lists the corresponding functions of these data registers.

Number	Action number	*Time when the PLC status change occurs					
		Year	Month	Day	Hour	Minute	Second
1	SR311	SR312 High byte	SR312 Low byte	SR313 High byte	SR313 Low byte	SR314 High byte	SR314 Low byte
2	SR315	SR316 High byte	SR316 Low byte	SR317 High byte	SR317 Low byte	SR318 High byte	SR318 Low byte
3	SR319	SR320 High byte	SR320 Low byte	SR321 High byte	SR321 Low byte	SR322 High byte	SR322 Low byte
4	SR323	SR324 High byte	SR324 Low byte	SR325 High byte	SR325 Low byte	SR326 High byte	SR326 Low byte
5	SR327	SR328 High byte	SR328 Low byte	SR329 High byte	SR329 Low byte	SR330 High byte	SR330 Low byte
6	SR331	SR332 High byte	SR332 Low byte	SR333 High byte	SR333 Low byte	SR334 High byte	SR334 Low byte
7	SR335	SR336 High byte	SR336 Low byte	SR337 High byte	SR337 Low byte	SR338 High byte	SR338 Low byte
8	SR339	SR340 High byte	SR340 Low byte	SR341 High byte	SR341 Low byte	SR342 High byte	SR342 Low byte
9	SR343	SR344 High byte	SR344 Low byte	SR345 High byte	SR345 Low byte	SR346 High byte	SR346 Low byte
10	SR347	SR348 High byte	SR348 Low byte	SR349 High byte	SR349 Low byte	SR350 High byte	SR350 Low byte

Number	Action number	*Time when the PLC status change occurs					
		Year	Month	Day	Hour	Minute	Second
11	SR351	SR352 High byte	SR352 Low byte	SR353 High byte	SR353 Low byte	SR354 High byte	SR354 Low byte
12	SR355	SR356 High byte	SR356 Low byte	SR357 High byte	SR357 Low byte	SR358 High byte	SR358 Low byte
13	SR359	SR360 High byte	SR360 Low byte	SR361 High byte	SR361 Low byte	SR362 High byte	SR362 Low byte
14	SR363	SR364 High byte	SR364 Low byte	SR365 High byte	SR365 Low byte	SR366 High byte	SR366 Low byte
15	SR367	SR368 High byte	SR368 Low byte	SR369 High byte	SR369 Low byte	SR370 High byte	SR370 Low byte
16	SR371	SR372 High byte	SR372 Low byte	SR373 High byte	SR373 Low byte	SR374 High byte	SR374 Low byte
17	SR375	SR376 High byte	SR376 Low byte	SR377 High byte	SR377 Low byte	SR378 High byte	SR378 Low byte
18	SR379	SR380 High byte	SR380 Low byte	SR381 High byte	SR381 Low byte	SR382 High byte	SR382 Low byte
19	SR383	SR384 High byte	SR384 Low byte	SR385 High byte	SR385 Low byte	SR386 High byte	SR386 Low byte
20	SR387	SR388 High byte	SR388 Low byte	SR389 High byte	SR389 Low byte	SR390 High byte	SR390 Low byte


\*Format for the PLC status change time: the data is stored as a binary-coded decimal. The following table lists the range of values.

Function	Value
Year	00–99 (A.D.)
Month	01–12
Day	01–31
Hour	00–23
Minute	00–59
Second	00–59

### 10. The PLC operation flag

- SM400-SM403

SM400: The flag is always ON when CPU runs.




SM401: The flag is always OFF when CPU runs.

SM402: The flag is ON only at the first scan. The pulse width equals one scan time. You can use this contact for

the initial value setting.

SM403: The flag is OFF only at the first scan. That is, the negative pulse is generated the moment the PLC runs.




### 11. The initial clock pulse

- SM404 · SM405 · SM406 · SM407

The PLC provides seven types of clock pulses. When the PLC is powered on, the seven types of clock pulses act automatically.

Device	Function
SM404	10 millisecond clock pulse during which the pulse is ON for 5 milliseconds and then is OFF for 5 milliseconds
SM405	100 millisecond clock pulse during which the pulse is ON for 50 milliseconds and then is OFF for 50 milliseconds
SM406	200 millisecond clock pulse during which the pulse is ON for 100 milliseconds and then is OFF for 100 milliseconds
SM407	One second clock pulse during which the pulse is ON for 500 milliseconds and then is OFF for 500 milliseconds

The clock pulses are illustrated in the following graphs.



**12. The flags related to the memory card**

- SM36, SM450-SM453, SM456-SR36, SR453, SR902

You use the memory card to back up the data in the PLC. Refer to Chapter 6 for instructions concerning the memory card.

Device	Function
SM36	Enable saving data to the memory card. When ON, the PLC runs according to the value in the SR36.
SM450	Memory card is present. ON: memory card is present. OFF: memory card is not present.
SM451	Memory card is write-protected.
SM452	Data in the memory card is being accessed. ON: data in the memory card is being accessed. OFF: data in the memory card is not accessed.
SM453	Error during the operation of the memory card. ON: error occurred. OFF: no error.
SM456	Execution of data logger and the memory card. ON: execution by the values in SR902.
SR453	When an error occurs in the memory card, the error codes are stored here. A. 16#005D: no memory card installed B. 16#005E: an error occurs when the memory card is initialized C. 16#005F: the path is incorrect or the file does not exist D. 16#0060: cannot create the default folder E. 16#0061: the memory space is insufficient F. 16#0062: the memory card is write protected G. 16#0063: an error occurs when the data is written into the file

Device	Function
	H. 16#0064: the data cannot be read from the memory card I. 16#0065: the file is a read-only file J. 16#0066: when restoring the memory card PLC is in RUN status K. 16#0067: when restoring the memory card PLC ID is not matched when restoring the memory card L. 16#0068: when restoring the memory card the password is not matched M. 16#0069: when restoring the memory card, the file path and the file name contain the CPU module name, but it is not matched with the actual CPU module
SR902	The code for the executions of data logger and the memory card (works with SM456); for example, H5AA5: write the sampling data from the data logger into the memory card.
SR36	<p>Use the following function codes to backup or restore data. Enable SM36 for the function codes to work.</p> <p>A. K1122 (backup) <sup>#1</sup>, it indicates backing up the PLC programs to the memory card. (PLC ID and password are included) Execute this backup when the PLC is in the RUN/Stop status. Default backup file name: SDCard\PLC CARD\AS300\SysDup\user_program.dup</p> <p>B. K2211 (restore) <sup>#2</sup>, it indicates restoring the PLC programs from the memory card. (PLC ID and password are included) Execute the restoring when the PLC is in the Stop status. Default restore file name: SDCard\PLC CARD\AS300\SysDup\user_program.dup</p> <p>C. K3344 (backup) <sup>#1</sup>, it indicates backing up the latched values (D, S, M, C, HC) and the latched range to the memory card. Execute this backup when the PLC is in the RUN/Stop status. Default backup file name: SDCard\PLC CARD\AS300\SysDup\retained_data.dup</p> <p>D. K4433 (restore) <sup>#2</sup>, it indicates restoring the latched values (D, S, M, C, HC) and the latched range from the memory card. Execute the restoring when the PLC is in the Stop status. Default restore file name: SDCard\PLC CARD\AS300\SysDup\retained_data.dup</p> <p>E. K5566 (backup) <sup>#1</sup>, it indicates backing up the PLC programs and parameters to the memory card. (the status and values of retainable devices are NOT included). Execute this backup when the PLC is in the Stop status.</p> <p>F. K5577 (backup) <sup>#1</sup>, it indicates backing up the PLC programs and parameters to the memory card. (the status and values of retainable devices are included). Execute this backup when the PLC is in the Stop status. *E &amp; F functions are the same as the backup function in ISPSOFT Card Utility. Default file name: SDCard\PLC CARD\AS300\SysDup\AS300_save_backup.dup</p> <p>G. K6755 (restore) <sup>#2</sup>, it indicates restoring all PLC data from the memory card (backup files from the function code E or F). Execute the restoring when the PLC is in the Stop status. Default file name: SDCard\PLC CARD\AS300\SysDup\AS300_save_backup.dup Note: if you need to restore from POWER-ON, you need to modify the backup file name and save the file to SDCard\PLC CARD\AS300\SysDup\AS300_BACKUP.dup before performing restoring from POWER-ON.</p> <p>H. K5588 (backup) <sup>#1</sup>, it indicates backing up all FR file registers from the PLC to the memory card. Execute this backup when the PLC is in the Stop status. Default file name: SDCard\PLC CARD\AS300\SysDup\AS300_FR_backup.dup</p> <p>I. K8855 (restore) <sup>#2</sup>, it indicates restoring all FR file registers from the memory card to the PLC. Execute the restoring when the PLC is in the Stop status. The file name should be the same as the file name in H shows. (Default file name: SDCard\PLC CARD\AS300\SysDup\AS300_FR_backup.dup)</p>

#1: While backing up, if there is a file with the same file name, the system overwrites the existing file.

#2: While restoring, if the file path and the file name are not identical to the backup file, the system does not execute the restoring.

NOTE 1: The default file names shown above use AS300 as example. If the PLC you are using is NOT AS300, you can modify the file name. If the backup file name is not correct, the system does not execute the restoring and sends out error codes.

NOTE 2: The function codes A, B, C and D shown in SR36 are available for firmware V1.04.30 or later. The function codes E, F and G in SR36 are available for firmware V1.04.90 or later. The function codes H and I in SR36 are available for firmware V1.05.30 or later.

NOTE 3: The definitaitons of the abovementioned PLC program, parameters and retainable devices:  
 The PLC program includes PLC programming execution codes, programming codes, project password and PLC ID.  
 The parameters include HWCONFIG configurations, data mapping table and position planning table.  
 The latched area means parameters and all the values set in this area are retainable.

● **While restoring the PLC program from the memeory card, the system verifies the backup file, PLC ID and password.**

◆ PLC ID check: if the backup file is set with PLC ID, it prevents restoring the PLC program to the wrong PLC.

	CPU module with PLC ID	CPU module without PLC ID
Backup file with PLC ID	PLC ID matched: checking the password PLC ID not matched: not restoring	Not restoring
Backup file without PLC ID	Not restoring	Checking the password

◆ Password check: if the backup file is set with password, it ensures the security of the PLC program and prevents restoring the PLC program to the wrong PLC.

	CPU module with password	CPU module without password
Backup file with password	Password matched: restoring Password not matched: not restoring	Restoring and you can also set the CPU module with password
Backup file without password	Not restoring	Restoring

● SR36 only stores 2 logs :

- A. The number 1234 means the PLC stores the error log (SR40–SR161) in the memory card.
- B. The number 3456 means the PLC stores the error log (SR40–SR161) and the PLC state changing log (SR309–SR390) in the memory card.

**13. The high-speed output instruction is being executed. The output immediatly stops when the instruction is disabled or stops.**

- SM587: while using the position planning table to control the output, the axis should refer to the following flags for the action to stop. This function is available for firmware V.1.06.00 or later.
- SM476, SM477, SM496, SM497, SM516, SM517, SM536, SM537, SM556, SM557, SM576, SM577:  
 OFF (default): deceleration stop  
 ON: immediate stop
- SM463, SM474, SM483, SM494, SM503, SM514, SM523, SM534, SM543, SM554, SM563, SM574 : use these flags to pause output.  
 When the flag changes from OFF to ON, it means stop the output. This works with these flags; refer to the section above for more actions on stop.

When the flag changes from ON to OFF, it means execute the rest of the outputs.

- The flag for position output axis 1-6 (even number high speed pulse output points) in ramp up / ramp down area is available for firmware V1.06.00 or later.

- SM586

OFF (default): use high-intensity 250 steps to switch to different speeds in the ramp up/ramp down area and the error rate of switching time is about 10%.

ON : use high-intensity 25 steps to switch to different speeds in the ramp up/ramp down area and the error rate of switching time is about 1%.

#### 14. Position control output limit in ISPSOft

- SR580-SR603

Positive output limit: set the limit in ISPSOft. When the output position is greater than the positive limit, the output stops immediately.

Negative output limit: set the limit in ISPSOft. When the output position is smaller than the negative limit, the output stops immediately.

When the positive and negative output limits are both 0, the function is disabled. This function works with the output instructions. The system only checks the limit set in ISPSOft when the instruction is executed. Thus the system does not come to an immediate stop even when it is beyond the output limit. If an immediate stop is needed, using the external input as the way to check the limit is recommended.

#### 15. Backlash compensation function

- SR478, SR479, SR498, SR499, SR518, SR519, SR538, SR539, SR558, SR559, SR578, SR579

For AS series, up to 12 high-speed outputs (Y0.0-Y0.11) can be set. Each output works with a corresponding SR for users to set the output number for backlash compensations. The setting range is 0-32767. If the setting value is  $\leq 0$ , this function is disabled.

- This function is available for firmware version 1.02.30 and later. The output instructions that support odd number axis outputs and are directional output by default are JOG, DZRN, DPLSV, DDRVI, DDRVA, DPPMR, DPPMA, DCICR, DCICA, DCICCR, DCICCA, DCCMR, DCCMA, DPPGB and TPO. For even number axis outputs, you can use the following instructions JOG, DPLSV, DDRVI and DDRVA. For firmware version 1.10 or later, CSFO instruction is also supported.
- If the above-mentioned supported instructions are used and the instruction is stopped right after the output direction is changed, if the backlash compensation function is enabled under this condition, PLC needs to run the compensated ones before a real stop. So that there will be no uncompensated backlashes left when the next output is enabled.

#### 16. Flags to show the output number of the current positioning output in the ramp up / ramp down area.

(available for firmware V1.06.00 or later)

- SR652-653 (32-bit value)

The output number in the ramp up area: the accumulated output number counted from the acceleration starting point to the target speed point (not included).

- SR654-655 (32-bit value)

The output number in the ramp down area: the accumulated output number counted from the target speed point (not included) to the output stopping point.

#### 17. Flags to show the CAN communication quality (available for firmware V1.06.00 or later)

- SR823

Hardware receiving error counter for CAN communication: when the error number exceeds 127, it indicates the hardware error occurrence is too frequent, you need to check the communication cables or adjust the transmission speed or modify the sample points manually.

- SR824

Hardware sending error counter for CAN communication: when the error number exceeds 127, it indicates the hardware error occurrence is too frequent, you need to check the communication cables or adjust the transmission speed or modify the sample points manually.

## 18. Ethernet IP related flags

- SM1000, SR1000~SR1015 and (SR1016, SR1536~SR1539 are available for firmware V1.06.00 or later)

SM/SR	Function	Action
SM1000	Ethernet setting flag.	ON: the values in SR1000–SR1006 are written into the flash memory. After writing the values, the PLC resets it to OFF. NOTE 1: do not set the flag to ON continuously to avoid damage to the flash memory. NOTE 2: the PLC must be in STOP state before writing the values into the flash memory.
SR1000	Ethernet IP address (32-bit)	For example: 192.168.1.5, SR1000 is 16#C0A8 and SR1001 is 0105.
SR1001		
SR1002	Ethernet netmask address (32-bit)	For example: 255.255.255.0, SR1002 is 16#FFFF, and SR1003 is FF00
SR1003		
SR1004	Ethernet gateway address (32-bit)	For example: 192.168.1.1, SR1004 is 16#C0A8, and SR1005 is 0101
SR1005		
SR1006	Duration of the TCP connection	Unit: second; default: 30 seconds; setting range: 1-32000; if the setting value exceeds the setting range, when
SR1007	Current Ethernet speed	When the value exceeds the range, the system treats the value as the minimum 1 or the maximum 32000.
SR1009	Current TCP connection number	Unit: Mbps Number of all the TCP connections
SR1010	Time to restart TCP communication	Unit: ms; default: 20 ms; setting range: 0-32000; when the value exceeds the range, the system treats the value as the minimum 0 or the maximum 32000. If the setting value is 0, it indicates system restarts communication automatically.
SR1011	Modbus/TCP Server connection number	The system is refreshed automatically.
SR1012	Modbus/TCP Client connection number	The system is refreshed automatically.
SR1013	EtherNet/IP Adapter connection number	The system is refreshed automatically.
SR1014	EtherNet/IP Scanner connection number	The system is refreshed automatically.
SR1015	Modbus/TCP Server packet receiving timeout	Unit: ms; default: 10 ms; setting range: 0-32000; when the value exceeds the range, the system treats the value as the minimum 0 or the maximum 32000
SR1016	The delay time for the data to be sent after the connection of Modbus/TCP Client is established. (ms) (0~1000)	Unit: ms; default: 10 ms; setting range: 0-1000; when the value exceeds the range, the system treats the value as the minimum 0 or the maximum 1000
SR1536	Current AS-FEN02 / AS-FECAT TCP connection number	Number of all AS-FEN02 TCP connections
SR1537	AS-FEN02 / AS-FECAT Modbus/TCP Serves connection number	The system is refreshed automatically.

SM/SR	Function	Action
SR1538	AS-FEN02 Modbus/TCP Client connection number	The system is refreshed automatically.
SR1539	AS-FEN02 EtherNet/IP Adapter connection number	The system is refreshed automatically.

- Ethernet communication quality related, available for AS CPU firmware version 1.10.00 or later.

SR	Function	Action
SR1017	The maximum number of Ethernet packets that can be handled in one scan cycle.	Default: 80 packets, setting range: 10-1000; when the value exceeds the range, the system treats the value as the minimum 10 or the maximum 1000. Register is refreshed by you.
SR1018	The number of Ethernet packets that is handled in the last scan cycle.	Refresh the register every scan cycle by the system.
SR1019	The accumulated number of Ethernet packets which are dropped after the packets in the buffer zone is full.	1. Refresh the register every scan cycle by the system. 2. Register can be cleared to 0 by you.

Example:

1. Determine the Ethernet communication quality

Step 1: Check if the value in SR1019 is 0.

SR1019 = 0	Good communication quality
SR1019 > 0	Error occurred during communication, go to step 2

Step 2: Check the current values in SR1017 and SR1018

The result of SR1018/SR1017 is <0.8	If the communication workload is less than 80%, the communication quality is good; set the value in SR1019 to 0. If the error occurs from time to time, ask your network administrator to check if there is any device that can cause communication error in the network.
The result of SR1018/SR1017 is ≥ 0.8	If the communication workload is larger or equal to 80%, the communication is under high load. If the value in SR1019 is NOT 0, it indicates the communication may not be normal. You need to lower the workload of data exchange or refresh the network capacity.

SR1017	<input type="text"/>	80
SR1018	<input type="text"/>	79
SR1019	<input type="text"/>	7985

2. Refresh the network capacity

- ◆ When you raise the value in SR1017, the value in SR1019 should also be raised. But if the value in SR1019 stays the same but the result of SR1018/SR1017 is still high (over 0.8), that indicates the communication workload is still quite full. It is suggested to raise a value in SR1017 and the ratio should be lower than 0.8. You need to clear the value in SR1019 to see if it works whenever you change the value in SR1017.

SR1017	<input type="text"/>	150
SR1018	<input type="text"/>	110
SR1019	<input type="text"/>	0

- ◆ When the network traffic is heavy, if you raise the value in SR1017, every 10 more increased value, adds around 2.2 ms more on the scan time. (the test environment: no extension module, no RTU or data exchange table.) Therefore, after the value in SR1017 is raised, you need to pay attention on the scan

time. If the network traffic is not too heavy, the value in SR1017 will not affect the scan time too much. However, if the network is abnormal, CPU uses more resources on the packet handling and that will increase the scan time. You need to consider the network workload and the scan time, when you set the value in SR1017.

- ◆ If the packets cannot be handled in the allowable scan time, you can consider the followings to lower the network workload.
  - Decrease the network connections with the CPU, for example, decrease the data exchange numbers via Modbus TCP or EtherNet/IP.
  - Lower the refreshing rate in data exchange, for example lessen the refreshing cycle for data exchange via Modbus TCP, or increase the value in RPI for data exchange via EtherNet/IP.

- SM1090, SM1091, SM1106-SM1109

SM	Function	Action
SM1090	TCP connection is busy.	ON: TCP connection timeout
SM1091	UDP connection is busy.	ON: UDP connection timeout
SM1110	AS-FEN02 Ethernet - Filter Setting Error	When the program is downloaded to the PLC
SM1106	Ethernet connection error	ON: PHY initialization fails. OFF: PHY initialization succeeds.
SM1107	Ethernet basic setting error	ON: basic setting error OFF: correct basic setting
SM1109	TCP/UDP socket local port is already used.	ON: the same port in use

For the error codes, the corresponding LED indicators, and other troubleshooting, Refer to Chapter 12 in the AS300 Series Operation Manual.

## 19. Email settings

- SM1113, SM1116-SM1155

If the sending an email fails, the flag of the email service error SM1113 is ON.

The following table lists the triggers for sending email and the corresponding flags (SM1116–SM1155).

Function \ Item	Trigger 1	Trigger 2	Trigger 3	Trigger 4
Email service	SM1116	SM1126	SM1136	SM1146
	ON: enabled, OFF: disabled			
Email sending	SM1117	SM1127	SM1137	SM1147
	ON: sending email now, OFF: email sent			
Emails sent successfully	SM1119	SM1129	SM1139	SM1149
	ON: email sent successfully			
Email sending error 1	SM1120	SM1130	SM1140	SM1150
	The email cannot be sent due to email content error			
SMTP response timeout	SM1122	SM1132	SM1142	SM1152

Function \ Item	Trigger 1	Trigger 2	Trigger 3	Trigger 4
	After sending the email, the SMTP server response timeout.			
SMTP server response error	SM1123	SM1133	SM1143	SM1153
	After sending the email, the SMTP server response error.			
Email sending error 2 of	SM1124	SM1134	SM1144	SM1154
	After sending the email, the size of the attachment exceeds the limit.			
Email sending Error 3	SM1125	SM1135	SM1145	SM1155
	After sending the email, the attachment is not found, SM1125 is ON.			

## 20. Flags and registers concerning data exchange

- Flags for data exchange through COM1 connections

SM	Type	Function
SM750	R/W	Data exchange through COM1 enabled by ISPSOft.
SM752–SM783	R/W	Connection 1–32 through COM1 for data exchange started.
SM784–SM815	R	Data received through COM 1 connection 1–32 for data exchange.
SM816–SM847	R	Error in the COM1 connection 1–32 for data exchange.

- Flags for data exchange through COM2 connections

SM	Type	Function
SM862	R/W	Data exchange through COM2 enabled by ISPSOft.
SM864–SM895	R/W	Connection 1–32 through COM2 for data exchange started.
SM896–SM927	R	Data received through COM2 connection 1–32 for data exchange.
SM928–SM959	R	Error in the COM2 connection 1–32 for data exchange

- Registers for data exchange through COM1 and COM2 connections

SR	Function
SR1335	Actual cycle time of connection 1–32 for data exchange through COM1
SR1336	Number of the connection that is currently performing a cyclical data exchange through COM1
SR1340–SR1371	Error code for data exchange through the COM1 connection 1–32
SR1375	Actual cycle time of connection 1–32 for data exchange through COM2
SR1376	Number of connection that is currently performing a cyclical data exchange through COM2
SR1380–SR1411	Error code for data exchange through the COM2 connection 1–32

The error codes 1–7 are the standard response error codes of the Modbus protocol. Error code 9 means timeout.

- Flags for data exchange through Function Card 1 and Function Card 2 (available for firmware V1.06.00 or later)

SM	Type	Function Card 1
----	------	-----------------

SM1710	R/W	Data exchange through Function Card 1 enabled by ISPSoft
SM1712 ~ SM1743	R/W	Connection 1-32 for data exchange through Function Card 1 started
SM1744 ~ SM1775	R	Successful data exchange connection 1-32 through Function Card 1
SM1776 ~ SM1807	R	Error in data exchange connection 1-32 through Function Card 1
<b>SM</b>	<b>Type</b>	<b>Function Card 2</b>
SM1822	R/W	Data exchange through Function Card 1 enabled by ISPSoft
SM1824 ~ SM1855	R/W	Connection 1-32 for data exchange through Function Card 1 started
SM1856 ~ SM1887	R	Successful data exchange connection 1-32 through Function Card 1
SM1888 ~ SM1919	R	Error in data exchange connection 1-32 through Function Card 1

- Registers for data exchange through Function Card 1 and Function Card 2 (available for firmware V1.06.00 or later)

SR	Function
SR1435	Actual cycle time for data exchange through Function Card 1
SR1436	Number of the connection that is currently performing a cyclical data exchange through Function Card 1
SR1440 ~ SR1471	Error in data exchange connection 1-32 through Function Card 1 Error codes 1-7 is related to Modbus issues; refer to manual from the slaves for more information. Error code 9 indicates communication timeout.
SR1475	Actual cycle time for data exchange through Function Card 2
SR1476	Number of the connection that is currently performing a cyclical data exchange through Function Card 2
SR1480 ~ SR1511	Error in data exchange connection 1-32 through Function Card 2 Error codes 1-7 is related to Modbus issues; refer to manual from the slaves for more information. Error code 9 indicates communication timeout.

- Flags for data exchange through Ethernet connections

SM	Type	Function
SM1167	R/W	Data exchange through Ethernet port enabled by ISPSoft.
SM1168–SM1199	R/W	Connection 1–32 through Ethernet port for data exchange started.
SM1200–SM1231	R	Data received through Ethernet port connection 1–32 for data exchange.
SM1232–SM1263	R	Error in the Ethernet port connection 1–32 for data exchange

- Registers for data exchange through Ethernet connections

SR	Function
SR1120–SR1151	Actual connection time for data exchange through the Ethernet connection 1–32
SR1152–SR1183	The error code for data exchange through the Ethernet connection 1–32

- Flags for data exchange through Ethernet connection in AS Series PLC CPU (available for firmware V1.10.20 or later)

SM	Type	Function
SM1092	R/W	Incorrect Modbus TCP server port

SR	Function
SR1092	Modbus TCP Server port (PLC CPU as Server)
SR1093	Modbus TCP Client port (PLC CPU as Client)

Operation details:

- When the PLC CPU acts as a Modbus TCP Server
  - By default, the protocol uses port 502 as the communication port in the Modbus TCP communication.
  - But if port 502 is not available, you can use SR1092 to set up the port for communication.
  - The setting here is not retainable. When you power off and power on the PLC CPU, the communication port will be port 502 again by default. Use the PLC program to set up.
  - If the port number which is set in SR1092 is already taken by other functions, such as socket or web. The setting here will be invalid. And SM1092 will switch to ON, indicating incorrect Modbus TCP server port.
- When the PLC CPU acts as a Modbus TCP Client
  - By default, the protocol uses port 502 as the communication port in the Modbus TCP communication.
  - But if port 502 is not available, you can use SR1093 to set up the port for communication.
  - The setting here is not retainable. When you power off and power on the PLC CPU, the communication port will be port 502 again by default. Use the PLC program to set up.
  - The setting value here is only for the communication port of Modbus TCP Client. The communication ports of PLC CPU will NOT be affected.

- Flags for data exchange through Ethernet connection in AS-FEN02 (available for firmware V1.06.00 or later)

SM	Type	Function
SM1006	R/W	Data exchange through AS-FEN02 enabled by ISPSOft.
SM1008 ~ SM1015	R/W	Connection 1–8 through AS-FEN02 for data exchange started.
SM1016 ~ SM1023	R	Successful data exchange connection 1-8 through AS-FEN02
SM1024 ~ SM1031	R	Error in the AS-FEN02 connection 1–8 for data exchange

- Registers for data exchange through Ethernet connection in AS-FEN02 (available for firmware V1.06.00 or later)

SR	Function
SR1520 ~ SR1527	The actual communication time for data exchange connection 1-8 through AS-FEN02
SR1528 ~ SR1535	Error in data exchange connection 1-8 through AS-FEN02

- Error codes for Ethernet connections

Error code	Description
16#00XX	Remote module response error Code 1–7 are standard Modbus TCP protocol error codes
16#F000	Ethernet connection is not established
16#F001	Remote module response timeout
16#F003	TCP connection timeout
16#F007	Response error
16#F009	Connection lost in the remote module

- The list of SM/SR states when connecting to RTU-EN01 through Ethernet port

SM / SR		Description	
SM1312 - SM1315		The communication state flags of RTU-EN01 connection ID 1-4	
SR1312 - SR1315		The communication state codes of RTU-EN01 connection ID 1-4	
SR	SM state	Description	
0	OFF	Connection closed	
1	ON	Successful connection	
2	OFF	Communication timeout	
3	OFF	Connection closed by force	
4	OFF	RTU-EN01 response: error in contents	
5	OFF	RTU-EN01 response: error	
6	OFF	Network not connected or connection failed	
SM state		RX & RCR Read data (input mapping area)	RY & RCR Write data (output mapping area)
OFF → ON		Clear to 0	Clear to 0
ON → OFF		No change	No change

Note: Before the connection is established, it is suggested NOT to use data (RX/RX/RCR Read/RCR Write) in the mapping area.

- Ethernet/IP communication flags are available for PLC FW V1.06 or later.

SM	Attr.	Ethernet/IP Data Exchange Description
SM1375	R/W	Data exchange through EtherNet/IP (Scanner) started.
SM1376 - SM1407	R/W	Connection 1-32 for data exchange through EtherNet/IP (Scanner) started
SM1408 - SM1439	R	Error in data exchange connection 1-32 through EtherNet/IP (Scanner)
SM1440 - SM1447	R	Error in I/O connection 1-8 through EtherNet/IP (Adapter)
SM1448 – SM1455*1	R	I/O connection 1-8 is established through EtherNet/IP (Adapter)

\*1: only available for PLC FW V1.06.50 or later

- Ethernet/IP communication registers are available for PLC FW V1.06 or later.

SR	Attr.	Ethernet/IP Data Exchange Description
SR1020 - SR1051	R	Status code of the connection 1-32 for data exchange through EtherNet/IP (Scanner)

- Ethernet/IP communication error codes are listed below. Refer to Chapter 9 in AS Series Operation Manual for more details.

Error Code	Description	Solution
16#0100	I/O connections duplicated	1. Check if the system has created the I/O connections. 2. Change the connection type to Listen Only.
16#0106	Scanner ownership of I/O connections conflicts	1. Check the scanner owner. 2. Reconfigure the invalid scanner. 3. Change the connection to multicast.
16#0110	Incorrect adapter configuration	1. Check the I/O connection status. 2. Activate the I/O connections again.
16#0111	Adapter RPI not supported	Check the RPI for the adapter.
16#0113	Insufficient I/O connections	1. Check if the number of connections exceeds the limit. 2. Reduce the number of the product connections.
16#0119	The connection of non-Listen only is not established.	1. Check if the system has created the I/O connections. 2. Check the scanner I/O connection status.

16#0127	Incorrect adapter input size	Check the module number and the product setup file to see if they match.
16#0128	Incorrect adapter output size	Check the output size in the connection parameters.
16#012D	Consumed TAG does not exist.	Check if the parameters in the Consumed tag are set correctly.
16#012E	Produced TAG does not exist.	Check if the parameters in the Produced tag are set correctly.
16#0204	I/O connection connecting timeout	No response from the adapter; check if the power and the network connection for the adapter are working properly.
16#0302	Network bandwidth NOT available for data	1. Check the I/O connection limit between the scanner and the adapter. 2. Increase the RPI value or reduce the number of connections.
16#0315	Incorrect adapter input/output instance	Check the module number and the product setup file to see if they match.
16#0203	I/O connection communication timeout	No response from the adapter; check if the power and the network connection for the adapter are working properly.

21. Flags SM230-SM261 is to activate modules when selecting “Manual + Flags” in “I/O allocation setting when Power On”.

When selecting “Manual + Flags (only I/O module of CPU module)” in “I/O allocation setting when Power On”, use flags SM230-SM261 to activate the 1st – 32nd module on the right-side of the CPU module. (available for FW V1.06.00 or later).

When selecting “Manual + Flags (I/O module of CPU & Remote module)”, use flags SM230-SM261 to activate the 1st – 32nd module on the right-side of the CPU module remotely (available for FW V1.08.50 or later and ISPSOft V3.12 or later supports this function.)


For less module applications, you can use the same PLC program and download the I/O allocation table once for various I/O applications. Two things to be noted when applying this mode:

- A. You need to use a bigger I/O allocation planning beforehand and store this planning in AS series PLC.
- B. You can simply use special flags to mark which I/O module will NOT be used to meet the actual I/O module placement. But you cannot rearrange the original order of the module placement.

Add a new selection “Manual + Flags” for the setting option “I/O module allocation setting when Power ON”. Select this option, you need to use it with flags SM230-SM261. For less module applications, you can simply use special flags to mark which I/O module will NOT be used to meet the actual I/O module placement. In this mode, you can use the same PLC program and download the I/O allocation table once for various I/O applications.

Example:

Step 1: Select "Manual + Flags (I/O module of CPU & Remote module)" for the setting option "I/O module allocation setting when Power ON" in HWCONFIG.



Step 2: Create an entire module allocation and download the I/O allocation table to HWCONFIG.

Step 3: When 16AP, 04DA, 08AM (right-side module) and 16AP as well as 06X6 (remote module) are not needed in the application, you can set the flags SM231 (indicating 16AP), SM233 (indicating 04DA), SM235 (including 08AM), SM237 (indicating remote 16AP) and SM239 (indicating remote 06X6) to OFF to meet the actual I/O module placement. You do not need to change their order number in the PLC program. After turn the power off and then power-on again, the actual placement is as below. The IO number in the PLC program does NOT need to be changed.



Actual I/O Module Placement



The order numbers, the model names and their corresponding device numbers in the complete I/O allocation list.

Right-side modules:

Order number	0	1	2	3	4	5	6	7
Model	AS332	16AP	16AP	04AD	04DA	06XA	08AM	08AN
Corresponding device starts from		X1.0/ Y1.0	X2.0/ Y2.0	D28040	D28060	D28080	X3.0	Y3.0

Remote modules:

Order number	0	1	2	3	4
Model	SCM	16AP	06XA	06XA	16AP
Corresponding device starts from	D29000	X4.0/Y4.0	D59040	D29060	X5.0/Y5.0

The order number and the corresponding device numbers stay the same.

Right-side modules:

Order number	0	1	3	5	7
Model	AS332	16AP	04AD	06XA	08AN
Corresponding device starts from		X1.0/Y1.0	D28040	D28080	Y3.0

Remote modules:

Order number	0	2	4
Model	SCM	06XA	16AP
Corresponding device starts from	D29000	D59040	X5.0/Y5.0


Note: The order number rule also applies when you use the FROM/TO or other module-related instructions.

22. Number of modules and the device codes

SR	Description
SR1559	Number of the remote modules connected to the CPU module (all right-side modules not included)
SR1560	Number of the right-side modules connected to the CPU module
SR1561~SR1592	Model code of the 1 <sup>st</sup> – 32 <sup>nd</sup> right-side module connected to the CPU module or the remote module

DIO modules					
Model	Device code	Model	Device code	Model	Device code
AS08AM10N-A	16#0201	AS08AN01T-A	16#0206	AS08AN01P-A	16#0207
AS08AN01R-A	16#0208	AS16AM10N-A	16#0210	AS16AP11T-A	16#0212
AS16AP11P-A	16#0213	AS16AP11R-A	16#0214	AS16AN01T-A	16#0216
AS16AN01P-A	16#0217	AS16AN01R-A	16#0218	AS32AM10N-A	16#0220
AS32AN02T-A	16#0226	AS64AM10N-A	16#0230	AS64AN02T-A	16#0236
AIO modules (temperature, loadcell)					
Model	Device code	Model	Device code	Model	Device code
AS04AD-A	16#0301	AS08AD-B	16#0302	AS08AD-C	16#0303
AS02ADH-A	16#0304	AS04DA-A	16#0305	AS06XA-A	16#0309
AS04RTD-A	16#0310	AS06RTD-A	16#0311	AS04TC-A	16#0315
AS08TC-A	16#0316	AS02LC-A	16#0320		
NIO modules (communication)					
Model	Device code	Model	Device code	Model	Device code
AS00SCM-A	16#0401	AS01DNET-A	16#0402		
PIO modules (positioning and counter)					
Model	Device code	Model	Device code	Model	Device code
AS02PU-A	16#0501	AS04PU-A	16#0502	AS02HC-A	16#0505

Example:



After power-on, the module allocation of the above example is as shown below.


SR1559 = 2; SR1560 = 4

The order number is counted by the right-side modules connected to the CPU module and then counted by the RTU number.

SR number (order)	SR1651 (#1)	SR1652 (#2)	SR1653 (#3)	SR1654 (#4)	SR1655 (#5)
Device code	16#0309	16#0311	16#0212	16#0212	16#0301
SR number (order)	SR1656 (#6)	SR1657 (#7)	SR1658 (#8)	SR1659 (#9)	
Device code	16#0315	16#0302	16#0210	16#0210	

If RTU is disconnected, after reconnected, the system refreshes the SR.

SR1559 = 1; SR1560 = 4



### 23. Auto-reset flags for pulse output

- While executing the pulse output instructions, to avoid the control over the same pulse output device is taken repeatedly by different type or different triggered output instructions. PLC auto-resets the right to control the pulse instruction to the first executed instruction till the assigned instruction is completely stopped. Because of the unique characteristic, PLC scan cannot detect if the pulse instruction is stopped when you use the pulse output instruction in the ST language, interrupt subroutine or one-time function block. Therefore, the right to control the pulse instruction is kept and any ongoing instructions can neither be executed nor outputted normally.
- To free the right to execute other pulse output instructions, you can use the auto-reset flags for the PLC to check if the output is complete.


Note: you can set the auto-reset flags to ON and once the output is complete, the flag resets to OFF automatically.

Even number axis for output	Y0.0	Y0.2	Y0.4	Y0.6	Y0.8	Y0.10
Auto-reset when the output is complete.	SM470	SM490	SM510	SM530	SM550	SM570
Odd number axis for output	Y0.1	Y0.3	Y0.5	Y0.7	Y0.9	Y0.11
Auto-reset when the output is complete.	SM475	SM495	SM515	SM535	SM555	SM575


● List of pulse output instructions:

Instruction	Even number axis	Odd number axis	Auto-reset flag	Auto-reset timing	Remarks
PWM/DPWM	✓	✓	Yes	Auto-reset flag is ON	<ul style="list-style-type: none"> <li>No need to set up the number of pulses to output.</li> <li>It is suggested to use in applications that the instruction is stopped and the instruction will not be scanned again. (for example ST language programming, interrupts, and one-time function block).</li> </ul>
JOG/DJOG	✓	✓			
DPLSV	✓	✓			
DPPGB	✓				
CSFO	✓				
PLSR	✓	✓	Yes	Auto-reset flag is ON, and pulse output is complete.	<ul style="list-style-type: none"> <li>Need to set up the number of pulses to output.</li> <li>Directional output instructions with positive/negative limits</li> <li>For more than two axes, each axis requires an auto-reset flag; one axis, one auto-reset flag.</li> </ul>
PLSY	✓	✓			
DDRVI	✓	✓			
DDRVA	✓	✓			
DDRVM	✓				
DPPMR	✓				
DPPMA	✓				
DCICR	✓				
DCICA	✓				
DCICCR	✓				
DCICCA	✓				
DCCMR	✓				
DCCMA	✓				
DZRN	✓		Yes FW: V1.12.00 or later	Auto-reset flag is ON, and pulse output is complete.	<ul style="list-style-type: none"> <li>Instructions will be scanned and monitored; no need for an auto-reset flag.</li> <li>Do NOT use it in one-time function block.</li> <li>You need to use the auto-reset flag along with the instruction, when executing in ST programming language.</li> </ul>
DZRN2	✓	✓			

Example 1 (used in function blocks or interrupts)



Function block (FB) or interrupts:



**Explanation**

- i. When M0 is ON, Y0.0 outputs 1000 pulses at 1kHz, and set SM470 on Y0.0.
- ii. When Y0.0 output is complete, PLC frees the right for the Y0.0 to be ready again.
- iii. When M0 is from OFF to ON again, Y0.0 output can start again.

**Example 2 (used in ST programming language)**

```

0001 IF M0 THEN
0002     DDRVI(10000, 1000, Y0.0, Y0.1);
0003     M1 := TRUE;
0004 ELSIF M1 AND SM461 THEN
0005     SM470 := TRUE;
0006     M1 := FALSE;
0007 END_IF;
0008

```

**Explanation**

- i. When M0 is ON, Y0.0 outputs 1000 pulses at 1kHz, and set M1 to ON to record Y0.0 is taken.
- ii. When M0 is OFF, once Y0.0 output is complete, SM461 is ON. IF M1 is ON, it triggers the auto-reset flag of Y0.0 (SM470=ON) and PLC frees the right for the Y0.0 to be ready again.
- iii. When M0 is from OFF to ON again, Y0.0 output can start again.

**24. Auto-reset flags for Delta CAN communicaiton**

- While executing the CAN instructions, to avoid the control over the same ID of Servo/Inverter is taken repeatedly by different type or diffent triggered CAN instrucionts. PLC assigns the right to control the pulse instruction to the first executed instruction till the assigned instruction is completely stopped. Because of the unique characteristic, PLC scan cannot detect if the CAN instruction is stopped when you use the CAN instruction in the ST language, interrupt subroutine or one-time function block. Therefore, the right to control the CAN instruction is kept and any ongoing instructions can nether be executed nor control the servo/inverter normally.
- To free the right to execute other CAN output instructions, you can use the auto-reset flags for the PLC to check if the communicaton between Delta Servo or Delta Moto is complete.  
Note: you can set the auto-reset flags to ON and once the CAN communication is complete, the flag resets to OFF automatically.

Delta Servo Station ID	1	2	3	4	5	6	7	8
Auto-reset the right to execute other CAN instructions.	SM1581	SM1582	SM1583	SM1584	SM1585	SM1586	SM1587	SM1588
Delta Moto Station ID	21	22	23	24	25	26	27	28
Auto-reset the right to execute other CAN instructions.	SM1601	SM1602	SM1603	SM1604	SM1605	SM1606	SM1607	SM1608


2

● List of CAN communicaiton instrucionts:


Instrucion	Delta Servo	Delta inverter	Auto-reset flag	Auto-reset timing	Remarks
INITC	√	√	Yes	Auto-reset flag is ON	
ASDON	√	√			
CASD	√	√			
DDRVIC	√				
DDRVAC	√				
DPLSVC	√	√			
ZRNC/DZRNC	√				
RSTD	√	√			
DCSFOC	√				
DTQC	√	√			
DTQLC	√	√			
ZRNM	√				
EMER	√	√			
COPRW	√	√			
COPWL/DCOPWL	√	√			
ECAMD	√				
DECAMS	√				
ECAMA	√				
ECAMC	√				

Example 1 (used in function blocks)

POU:



FB:



Explanation

- i. When M0 is ON, Servo #1 runs to the relative position 10000 PUU at the speed of 100.0 r/min. And set M1 to ON to record that communication right of Servo#1 is taken.
- ii. When SM1631 is ON (positioning completed) and M1 is ON, trigger SM1581 to ON to have the PLC free the communication right for Servo #1.
- iii. When M0 is from OFF to ON again, Servo #1 is ready to positioning again.

**Example 2 (used in ST programming language)**

```

0001 IF M0 THEN
0002     DDRVIC(1, 10000, 1000);
0003     M1 := TRUE;
0004 ELSIF M1 AND SM1631 THEN
0005     SM1581 := TRUE;
0006     M1 := FALSE;
0007 END_IF;
0008


```

**Explanation**

- i. When M0 is ON, Servo #1 runs to the relative position 10000 PUU at the speed of 100.0 r/min. And set M1 to ON to record that communication right of Servo#1 is taken.
- ii. When M0 is OFF, SM1631 ON (positioning completed) and M1 ON, trigger SM1581 to ON to have the PLC free the communication right for Servo #1.
- iii. When M0 is from OFF to ON again, Servo #1 is ready to positioning again.


**25. Use DPLSY in high-speed comparison interrupt (I2xx), available for FW V1.08.70 or later.****Example of the PLC program:**

- Start the instructions of high speed counter (DCNT) and high speed comparison (DHSCS) in the program cycle.



Note: When M0 is ON, HC200 high-speed counter is started. When the counted value in S2 reached 50, the high-speed comparison interrupt I200 is triggered.

- Write an instruction DPLSY in the high-speed comparison interrupt I200.



Note: Auto-reset the control when outputting 1000 pulses at 1kHz frequency from Y0.0. are complete.

- **The procedure**

There are four procedures A-D, when the input counted value changes 49 -> 50 to output the pulses through Y0.0.

- The input counted value changes from 49 to 50.
- The high-speed comparison interrupt is triggered. The PLC program is interrupted and the high-speed comparison interrupt is executed.
- Execute instruction DPLSY that is written in the high-speed comparison interrupt.
- Pulses are outputted from Y0.0.

Since the interrupt is affected by the time it is triggered and by the PLC on-going executions, such as IO points refreshing, communication implementing and so forth, the time when the pulses to be outputted can be greatly delayed.

To improve the execution time, new SM flags are added.

- **SM120-SM151: To pre-store the parameters for DPLSY to output**

Set the SM in this category to ON to save the DPLSY to-be-outputted parameters, including output point number, target frequency and number of pulses to the PLC flash memory. When the high-speed comparison interrupt is triggered and any of the SM360-391 is set to ON, the output can be started right away. Once any of SM120-151 is used, it is set to OFF. You need to set it to ON before using it again.

- **SM360-SM391: To enable triggering DPLSY in the interrupt to output pulses**


When the high-speed comparison interrupt is triggered and any of the SM360-391 is set to ON, the output can be started right away to output any of the SM120-151 stored DPLSY parameters. Auto-reset the control, after the output is complete.

The corresponding numbers of high-speed comparison interrupt to the newly added SMs are listed below.

Number of the high-speed comparison interrupt	To pre-store the parameters for DPLSY to output	To enable triggering DPLSY in the interrupt to output pulses
I200	SM120	SM360
I201	SM121	SM361
I202	SM122	SM362
I203	SM123	SM363
I210	SM124	SM364
I211	SM125	SM365
I212	SM126	SM366
I213	SM127	SM367
I220	SM128	SM368
I221	SM129	SM369
I222	SM130	SM370
I223	SM131	SM371
I230	SM132	SM372
I231	SM133	SM373
I232	SM134	SM374
I233	SM135	SM375
I240	SM136	SM376
I241	SM137	SM377

I242	SM138	SM378
I243	SM139	SM379
I250	SM140	SM380
I251	SM141	SM381
I252	SM142	SM382
I253	SM143	SM383
I260	SM144	SM384
I261	SM145	SM385
I262	SM146	SM386
I263	SM147	SM387
I264	SM148	SM388
I265	SM149	SM389
I266	SM150	SM390
I267	SM151	SM391

Use the above-mentioned new SM in the PLC program.



### Explanation

Set M0 to ON to trigger SM120 to ON to save the DPLSY to-be-outputted parameters (outputting 1000 pulses at 1kHz frequency) to the PLC flash memory.

Stat HC200 high-speed counter and set SM360 to ON. When the counted value in S<sub>2</sub> reached 50, the high-speed comparison interrupt I200 is triggered. The moment when the interrupt is triggered, Y0.0 starts to output 1000 pulses at 1kHz frequency.

- The high-speed comparison interrupt I200



**2**

**Explanation**

Since the execution of high-speed output has been completed in POU, there is no need to write any program in the interrupt.

**26. Use backlash compensation in CSFO (available for FW V1.08.30 or later)**

PLC uses the propositional conversion formula to converse the frequency and pulse numbers for inputs into what are suitable for outputs. From input to output, this process not only takes time and it may also cause backlash issues. When the number of pulses run through the input goes larger, so does the backlash.

To precise operation, use the following SM/SR to compensate for backlashes caused by a longtime CSFO operation.

Output axis designated by CSFO	Flag to activate the backlash compensation	Increase the frequency to compensate backlashes (Hz)
Y0.0 / Y0.1	SM1700	SR1700
Y0.2 / Y0.3	SM1701	SR1702
Y0.4 / Y0.5	SM1702	SR1704
Y0.6 / Y0.7	SM1703	SR1706
Y0.8 / Y0.9	SM1704	SR1708
Y0.10 / Y0.11	SM1705	SR1710

- **SM1700~1705: Flag to activate the backlash compensation**

**ON:** To increase the actual output frequency and the number of output pulses to close the distance between the position of input and output. The compensation stops automatically once the positions of input and output are the same. You can also set this flag to OFF, if the positions of input and output do not need to be the same.


**OFF:** To decrease the actual output frequency and the number of output pulses to stop compensating till the output falls behind to its original delayed position.

NOTE: Be sure to close the flag to deactivate the compensation before stopping the execution of CSFO. If not, you may find the compensated output is still running even after the execution of CSFO has stopped.

- **SR1700~1710: Increase the frequency to compensate backlashes**

You can define the frequency, ranging from 50 Hz~10 KHz (unit: 50 Hz) for the compensation of the backlashes. At first, it is recommended to try a lower frequency. Otherwise, sudden and quick movements may have an impact on the mechanism operation. The compensation stops automatically once the positions of input and output are the same. The frequency unit is 50 Hz; thus, if using 80 Hz, it will be seen as 50 Hz and 120Hz will be treated as 100 Hz.

The illustration of using backlash compensation in CSFO.  
Number of pulses



The ratio of the number of input and output pulses is 1:1.  
The timings are shown as ①, ②, ③, ④. See the explanations below.

- ① : Since the number of pulse runs through input is large and the input frequency is fast, the output cannot catch up with it, the distance between input and output grows bigger and bigger. The backlash compensation has not started yet.
- ② : Enable the flag to activate the backlash compensation. Increase the number of output pulses according to the frequency of input and compensation till the positions of input and output are the same.
- ③ : Disable the flag to deactivate the backlash compensation. Decrease the actual output frequency and number of output pulses to stop compensating till the output falls behind to its original delayed position.
- ④ : When the flag to activate the backlash compensation is enabled or disable, the PLC calculates and to increase or decrease the output frequency to enhance the smoothness of the compensation.

The example here shows if the current output frequency is 1 KHz and the compensated frequency is 100 Hz, the actual output frequency should be around 1.1 KHz.

### 2.2.17 Index Registers (E)

The Index register is a 16-bit data register. It is similar to the General register in that data can be read from it and written to it; however, it is mainly used as the index register. The range of index registers is E0–E9. Refer to Section 4.4 in the AS300 Series Programming Manual for more information about using index registers.

### 2.2.18 File Registers (FR)

- The AS300 Series PLC provides you with File registers for storing larger numbers of parameters.
- You can edit, upload, and download the parameters in the File registers through ISPSoft.
- You can read the values in File registers while operating the PLC. Refer to the MEMW instruction (API 2303) in the AS300 Series Programming Manual for more information about how to write to the File registers.

**MEMO**

---

# Chapter 3 Instruction Tables

## Table of Contents

- 3.1 Types of Instructions..... 3-2**
  - 3.1.1 Basic Instructions ..... 3-2
  - 3.1.2 Applied Instructions ..... 3-2
  
- 3.2 Understanding Instruction Tables ..... 3-3**
  - 3.2.1 Basic Instructions ..... 3-3
  - 3.2.2 Applied Instructions (Sorted numerically) ..... 3-4
  - 3.2.3 Applied Instructions (Sorted Alphabetically) ..... 3-5
  - 3.2.4 Device Tables ..... 3-6
  
- 3.3 Lists of Basic Instructions ..... 3-8**
  
- 3.4 Lists of Applied Instructions..... 3-11**
  - 3.4.1 Applied Instructions (Sorted numerically by API number)..... 3-11
  - 3.4.2 Applied Instructions (Sorted Alphabetically) ..... 3-48

## 3.1 Types of Instructions

Instructions used in the AS300 Series PLC include basic instructions and applied instructions.

### 3.1.1 Basic Instructions

Classification	Description
Contact instructions	Instructions such as loading the contact, connecting the contact in series, and connecting the contact in parallel
Output instructions	Bit device output; pulse output
Master control Instructions	Setting and resetting the master control
Rising-edge/Falling-edge detection contact instructions	Triggering the instructions that load the contact, connect the contacts in series, and connect the contacts in parallel
Rising-edge/Falling-edge differential output instructions	Bit device differential output
Other instructions	Other instructions

### 3.1.2 Applied Instructions

API	Classification	Description
0000-0083	Comparison instructions	Comparisons such as =, <>, >, >=, <, <=
0100-0118	Arithmetic instructions	Using binary numbers or binary-coded decimal numbers to add, subtract, multiply, or divide
0200-0217	Data conversion instructions	Converting a binary-coded decimal number into a binary number, and converting a binary number into a binary-coded decimal number
0300-0310	Data transfer instructions	Transfer the specified data
0400-0402	Jump instructions	Control jumps to a different part of the program
0500-0504	Program execution instructions	Enabling or disabling the interrupt
0600-0602	I/O refreshing instructions	Refreshing the I/O
0700-0711	Miscellaneous instructions	Instructions such as those that apply to the counters, the teach mode timers, and the special timers
0800-0817	Logic instructions	Logical operations such as logical addition and logical multiplication
0900-0904	Rotation instructions	Rotating/Shifting the specified data
1000-1018	Basic instructions	Timer instructions and counter instructions
1100-1115	Shift instructions	Shifting the specified data
1200-1229	Data processing instructions	16-bit data processing such as decoding and encoding
1300-1302	Structure creation instructions	Nested loops
1400-1430	Module instructions	Reading the data from a specific module and writing the data into a specific module
1500-1517	Floating-point number instructions	Floating-point number operations
1600-1608	Real-time clock instructions	Reading and writing, adding, subtracting and comparing the time
1700-1704	Peripheral instructions	I/O points connected to the peripheral
1806-1821	Communication instructions	Controlling the peripheral through communication
1900-1906	Other instructions	Watchdog timer, program delay timer, pulse width, and index registers




API	Classification	Description
2100-2119	String processing instructions	Conversion between binary or binary-coded decimal numbers and ASCII codes; conversion between binary numbers and strings; conversion between floating-point numbers and strings; string processing
2200-2216	Ethernet instructions	Controlling the Ethernet data exchange
2300-2305	Memory card / File register instructions	Reading the data from the memory card / file register and writing the data to the memory card / file register
2400-2401	Task control instructions	Controlling tasks in the program
2500-2502	Sequential function charts (SFC) instructions	Controlling the SFC instructions
2700-2724	High-speed output instructions	High-speed output and position control instructions
2800-2823	Delta special CANopen / EtherCAT communication instructions	CANopen / EtherCAT communication instructions especially for Delta devices

## 3.2 Understanding Instruction Tables

This section describes the table format that this chapter and the rest of this manual uses to describe each instruction. The format is different depending on the type of instruction: Basic or Applied.

### 3.2.1 Basic Instructions

This section describes the table format that this chapter uses to describe basic instructions in Section 3.3.

Instruction code <sup>①</sup>	Symbol <sup>②</sup>	Function <sup>③</sup>	Operand <sup>④</sup>
LD <sup>④</sup>		Loading the contact A/Connecting the contact A in series/Connecting the contact A in parallel <sup>④</sup>	DX X Y M S T C HC D L SM PR <sup>④</sup>
AND <sup>④</sup>			
OR <sup>④</sup>			



①
②
③
④

Description:



- ①: The instruction name
- ②: The symbol for the instruction in the ladder diagram in ISPSOft
- ③: The function of the instruction
- ④: The operands supported by the instruction

### 3.2.2 Applied Instructions (Sorted numerically)

This section describes the table format that this chapter uses to describe applied instructions (sorted by API number) in Section 3.4.1.

API	Instruction code		Pulse Instruction	Symbol		Function
	16-bit	32-bit				
0000	LD=	DLD=	—			Comparing the contact types ON: S1 = S2 OFF: S1 ≠ S2
0001	LD<>	DLD<>	—			Comparing the contact types ON: S1 ≠ S2 OFF: S1 = S2
0002	LD>	DLD>	—			Comparing the contact types ON: S1 > S2 OFF: S1 ≤ S2

①
②
③
④
⑤
⑥

API	Instruction code		Pulse Instruction	Symbol		Function
	32-bit	64-bit				
0018	FLD=	DFLD=	—			Comparing the floating-point number contact types ON: S1 = S2 OFF: S1 ≠ S2

⑦

Description:

- ①: The applied instruction number
- ②: The instruction name
- ③: If a 16-bit instruction can be used as a 32-bit instruction, add a D in front of the 16-bit instruction to form the 32-bit instruction.
- ④: ✓ indicates that you can use the instruction as a pulse instruction, whereas — indicates that it cannot be used as a pulse instruction. For pulse instructions, add a P in back of the instruction.
- ⑤: The symbol for the instruction in the ladder diagram in ISPSOft
- ⑥: The function of the instruction
- ⑦: For single-precision floating-point instructions (32-bit), an F appears in the instruction.

### 3.2.3 Applied Instructions (Sorted Alphabetically)

This section describes the table format that this chapter uses to describe applied instructions (sorted alphabetically) in Section 3.4.2.

Classification	API	Instruction code		Pulse instruction	Function
		16-bit	32-bit		
E	0501	EI	–	–	Enabling the interrupt
	2208	EIPRW	–	–	Reading and writing via Ethernet/IP connection
	0503	EIX	–	–	Disabling the specific interrupt
	1203	ENCO	–	✓	Encoder
	1905	EPOP	–	✓	Reading the data into the index registers
	1904	EPUSH	–	✓	Storing the contents of the index registers

Description:

①: The initial of the instruction name

②: The applied instruction number

③ ~ ④ : The instruction names


If the 16-bit instruction can be used as the 32-bit instruction, add a D in front of the 16-bit instruction to form the 32-bit instruction.

⑤ : ✓ indicates that you can use the instruction as a pulse instruction, whereas – indicates that it cannot be used as a pulse instruction. For the pulse instruction, add a P at the end of the instruction.

⑥: The function of the instruction

### 3.2.4 Device Tables

This section describes the table format used in the rest of this manual to describe each instruction.



Description:

①: The applied instruction number

②: The instruction name

If the 16-bit instruction can be used as the 32-bit instruction, add a D in front of the 16-bit instruction to form the 32-bit instruction.

③: The operand

④: The function of the instructions

⑤: The devices that are supported by the operand

1. The decimal forms are indicated by "K", but you enter them directly in ISPSOft. For example, enter the decimal number 30 in ISPSOft.
2. The hexadecimal forms are indicated by 16#. For example, the decimal number 30 is represented by 16#1E in the hexadecimal system.
3. The floating-point numbers are indicated by "F" or "DF", but they are represented by decimal points in ISPSOft. For example, the floating-point number F500 is represented by 500.0 in ISPSOft.
4. The strings are indicated by "\$", but they are represented by quotes (" ") in ISPSOft. For example, the string 1234 is represented by "1234" in ISPSOft.

5. ○: The hollow circle

Indicates that the device cannot be modified by an index register.

6. ●: The solid circle

Indicates that the device can be modified by an index register.

⑥ : The unit of the operand






⑦ : The format of the instruction

Indicates whether the instruction can be used as a pulse instruction, a 16-bit instruction, or a 32-bit instruction.

⑧ : The symbol for the instruction in the ladder diagram in ISPSOft.

### 3.3 Lists of Basic Instructions

- Contact instructions

Instruction code	Symbol	Function	Operand
LD		Loading contact A/Connecting contact A in series/Connecting contact A in parallel	DX, X, Y, M, SM, S, T, C, HC, D
AND			
OR			
LDI		Loading contact B/Connecting contact B in series/Connecting contact B in parallel	DX, X, Y, M, SM, S, T, C, HC, D
ANI			
ORI			


- Output instructions

Instruction code	Symbol	Function	Execution condition	Operand
OUT		Driving the coil		DY, Y, M, SM, S, T, C, HC, D
SET		Keeping the device on		DY, Y, M, SM, S, T, C, HC, D

- Master control instructions

Instruction code	Symbol	Function	Operand
MC		Setting the master control	N
MCR		Resetting the master control	N

- Rising-edge/Falling-edge detection contact instructions



Instruction code	Symbol	Function	Operand	Instruction code
LDP		Starting the rising-edge detection/Connect		DX, X, Y, M, SM, S, T, C, HC, D

Instruction code	Symbol	Function	Operand	Instruction code
ANDP		Starting the rising-edge detection in series/Connecting the rising-edge detection in parallel		X, Y, M, SM, S, T, C, HC, D
ORP				
PED				
APED				
OPED				
LDF		Starting the falling-edge detection/Connecting the falling-edge detection in series/Connecting the falling-edge detection in parallel		DX, X, Y, M, SM, S, T, C, HC, D
ANDF				
ORF				
NED				
ANED				
ONED				X, Y, M, SM, S, T, C, HC, D

● Rising-edge/Falling-edge differential output instructions

Instruction code	Symbol	Function	Execution condition	Operand
PLS		Rising-edge differential output		Y, M, SM, S
PLF		Falling-edge differential output		Y, M, SM, S

● Other instructions

















Instruction code	Symbol	Function	Operand
INV		Inverting the logical operation result	—
NP		The circuit is rising edge-triggered.	—
PN		The circuit is falling edge-triggered.	—
FB_NP		The circuit is rising edge-triggered.	Y, M, S, D
FB_PN		The circuit is falling edge-triggered.	Y, M, S, D













3










## 3.4 Lists of Applied Instructions










### 3.4.1 Applied Instructions (Sorted Numerically by API number)

- Comparison instructions

API	Instruction code		Pulse Instruction	Symbol		Function
	16-bit	32-bit				
0000	LD=	DLD=	—			Comparing values ON: $S_1 = S_2$ OFF: $S_1 \neq S_2$
0001	LD<>	DLD<>	—			Comparing values ON: $S_1 \neq S_2$ OFF: $S_1 = S_2$
0002	LD>	DLD>	—			Comparing values ON: $S_1 > S_2$ OFF: $S_1 \leq S_2$
0003	LD>=	DLD>=	—			Comparing values ON: $S_1 \geq S_2$ OFF: $S_1 < S_2$
0004	LD<	DLD<	—			Comparing values ON: $S_1 < S_2$ OFF: $S_1 \geq S_2$
0005	LD<=	DLD<=	—			Comparing values ON: $S_1 \leq S_2$ OFF: $S_1 > S_2$
0006	AND=	DAND=	—			Comparing values ON: $S_1 = S_2$ OFF: $S_1 \neq S_2$
0007	AND<>	DAND<>	—			Comparing values ON: $S_1 \neq S_2$ OFF: $S_1 = S_2$
0008	AND>	DAND>	—			Comparing values ON: $S_1 > S_2$ OFF: $S_1 \leq S_2$
0009	AND>=	DAND>=	—			Comparing values ON: $S_1 \geq S_2$ OFF: $S_1 < S_2$
0010	AND<	DAND<	—			Comparing values ON: $S_1 < S_2$ OFF: $S_1 \geq S_2$
0011	AND<=	DAND<=	—			Comparing values ON: $S_1 \leq S_2$ OFF: $S_1 > S_2$





















API	Instruction code		Pulse Instruction	Symbol	Function
	16-bit	32-bit			
0012	OR=	DOR=	—		Comparing values ON: $S_1 = S_2$ OFF: $S_1 \neq S_2$
0013	OR<>	DOR<>	—		Comparing values ON: $S_1 \neq S_2$ OFF: $S_1 = S_2$
0014	OR>	DOR>	—		Comparing values ON: $S_1 > S_2$ OFF: $S_1 \leq S_2$
0015	OR>=	DOR>=	—		Comparing values ON: $S_1 \geq S_2$ OFF: $S_1 < S_2$
0016	OR<	DOR<	—		Comparing values ON: $S_1 < S_2$ OFF: $S_1 \geq S_2$
0017	OR<=	DOR<=	—		Comparing values ON: $S_1 \leq S_2$ OFF: $S_1 > S_2$
0018	—	FLD=	—		Comparing floating-point numbers ON: $S_1 = S_2$ OFF: $S_1 \neq S_2$
0019	—	FLD<>	—		Comparing floating-point numbers ON: $S_1 \neq S_2$ OFF: $S_1 = S_2$
0020	—	FLD>	—		Comparing floating-point numbers ON: $S_1 > S_2$ OFF: $S_1 \leq S_2$
0021	—	FLD>=	—		Comparing floating-point numbers ON: $S_1 \geq S_2$ OFF: $S_1 < S_2$
0022	—	FLD<	—		Comparing floating-point numbers ON: $S_1 < S_2$ OFF: $S_1 \geq S_2$
0023	—	FLD<=	—		Comparing floating-point numbers ON: $S_1 \leq S_2$ OFF: $S_1 > S_2$
0024	—	FAND=	—		Comparing floating-point numbers ON: $S_1 = S_2$ OFF: $S_1 \neq S_2$

API	Instruction code		Pulse Instruction	Symbol	Function
	16-bit	32-bit			
0025	—	FAND<>	—		Comparing floating-point numbers ON: <b>S<sub>1</sub>≠S<sub>2</sub></b> OFF: <b>S<sub>1</sub> = S<sub>2</sub></b>
0026	—	FAND>	—		Comparing floating-point numbers ON: <b>S<sub>1</sub> &gt; S<sub>2</sub></b> OFF: <b>S<sub>1</sub> &lt;= S<sub>2</sub></b>
0027	—	FAND>=	—		Comparing floating-point numbers ON: <b>S<sub>1</sub> &gt;= S<sub>2</sub></b> OFF: <b>S<sub>1</sub> &lt; S<sub>2</sub></b>
0028	—	FAND<	—		Comparing floating-point numbers ON: <b>S<sub>1</sub> &lt; S<sub>2</sub></b> OFF: <b>S<sub>1</sub> &gt;= S<sub>2</sub></b>
0029	—	FAND<=	—		Comparing floating-point numbers ON: <b>S<sub>1</sub> &lt;= S<sub>2</sub></b> OFF: <b>S<sub>1</sub> &gt; S<sub>2</sub></b>
0030	—	FOR=	—		Comparing floating-point numbers ON: <b>S<sub>1</sub> = S<sub>2</sub></b> OFF: <b>S<sub>1</sub>≠S<sub>2</sub></b>
0031	—	FOR<>	—		Comparing floating-point numbers ON: <b>S<sub>1</sub>≠S<sub>2</sub></b> OFF: <b>S<sub>1</sub> = S<sub>2</sub></b>
0032	—	FOR>	—		Comparing floating-point numbers ON: <b>S<sub>1</sub> &gt; S<sub>2</sub></b> OFF: <b>S<sub>1</sub> &lt;= S<sub>2</sub></b>
0033	—	FOR>=	—		Comparing floating-point numbers ON: <b>S<sub>1</sub> &gt;= S<sub>2</sub></b> OFF: <b>S<sub>1</sub> &lt; S<sub>2</sub></b>
0034	—	FOR<	—		Comparing floating-point numbers ON: <b>S<sub>1</sub> &lt; S<sub>2</sub></b> OFF: <b>S<sub>1</sub> &gt;= S<sub>2</sub></b>
0035	—	FOR<=	—		Comparing floating-point numbers ON: <b>S<sub>1</sub> &lt;= S<sub>2</sub></b> OFF: <b>S<sub>1</sub> &gt; S<sub>2</sub></b>
0036	LD\$=	—	—		Comparing strings ON: <b>S<sub>1</sub> = S<sub>2</sub></b> ON: <b>S<sub>1</sub>≠S<sub>2</sub></b>
0037	LD\$<>	—	—		Comparing strings ON: <b>S<sub>1</sub>≠S<sub>2</sub></b> OFF: <b>S<sub>1</sub> = S<sub>2</sub></b>

API	Instruction code		Pulse Instruction	Symbol	Function
	16-bit	32-bit			
0042	AND\$=	—	—		Comparing strings ON: <b>S<sub>1</sub> = S<sub>2</sub></b> OFF <b>S<sub>1</sub> ≠ S<sub>2</sub></b>
0043	AND\$<>	—	—		Comparing strings ON: <b>S<sub>1</sub> ≠ S<sub>2</sub></b> OFF: <b>S<sub>1</sub> = S<sub>2</sub></b>
0048	OR\$=	—	—		Comparing strings ON: <b>S<sub>1</sub> = S<sub>2</sub></b> OFF: <b>S<sub>1</sub> ≠ S<sub>2</sub></b>
0049	OR\$<>	—	—		Comparing strings ON: <b>S<sub>1</sub> ≠ S<sub>2</sub></b> OFF: <b>S<sub>1</sub> = S<sub>2</sub></b>
0054	CMP	DCMP	✓		Comparing values
0055	ZCP	DZCP	✓		Zone comparison
0056	—	FCMP	✓		Comparing floating-point numbers
0057	—	FZCP	✓		Floating-point zone comparison
0058	MCMP	—	✓		Matrix comparison
0059	CMPT=	—	✓		Comparing tables ON: =
0060	CMPT<>	—	✓		Comparing tables ON: ≠
0061	CMPT>	—	✓		Comparing tables ON: >

API	Instruction code		Pulse Instruction	Symbol		Function
	16-bit	32-bit				
0062	CMPT>=	—	✓			Comparing tables ON: > =
0063	CMPT<	—	✓			Comparing tables ON: <
0064	CMPT<=	—	✓			Comparing tables ON: < =
0065	CHKADR	—	—			Checking the address of the contact type of a pointer register
0066	LDZ=	DLDZ=	—			Comparing the absolute result of the contact type ON:   S1- S2  =   S3  OFF:   S1- S2  ≠   S3
0067	LDZ<>	DLDZ<>	—			Comparing the absolute result of the contact type ON:   S1- S2  ≠   S3  OFF:   S1- S2  =   S3
0068	LDZ>	DLDZ>	—			Comparing the absolute result of the contact type ON:   S1- S2  >   S3  OFF:   S1- S2  <=   S3
0069	LDZ>=	DLDZ>=	—			Comparing the absolute result of the contact type ON:   S1- S2  >=   S3  OFF:   S1- S2  <   S3
0070	LDZ<	DLDZ<	—			Comparing the absolute result of the contact type ON:   S1- S2  <   S3  OFF:   S1- S2  >=   S3
0071	LDZ<=	DLDZ<=	—			Comparing the absolute result of the contact type ON:   S1- S2  <=   S3  OFF:   S1- S2  >   S3
0072	ANDZ=	DANDZ=	—			Comparing the absolute result of the contact type ON:   S1- S2  =   S3  OFF:   S1- S2  ≠   S3

3

API	Instruction code		Pulse Instruction	Symbol		Function
	16-bit	32-bit				
0073	ANDZ<>	DANDZ<>	—			Comparing the absolute result of the contact type ON: $ S_1 - S_2  \neq  S_3 $ OFF: $ S_1 - S_2  =  S_3 $
0074	ANDZ>	DANDZ>	—			Comparing the absolute result of the contact type ON: $ S_1 - S_2  >  S_3 $ OFF: $ S_1 - S_2  \leq  S_3 $
0075	ANDZ>=	DANDZ>=	—			Comparing the absolute result of the contact type ON: $ S_1 - S_2  \geq  S_3 $ OFF: $ S_1 - S_2  <  S_3 $
0076	ANDZ<	DANDZ<	—			Comparing the absolute result of the contact type ON: $ S_1 - S_2  <  S_3 $ OFF: $ S_1 - S_2  \geq  S_3 $
0077	ANDZ<=	DANDZ<=	—			Comparing the absolute result of the contact type ON: $ S_1 - S_2  \leq  S_3 $ OFF: $ S_1 - S_2  >  S_3 $
0078	ORZ=	DORZ=	—			Comparing the absolute result of the contact type ON: $ S_1 - S_2  =  S_3 $ OFF: $ S_1 - S_2  \neq  S_3 $
0079	ORZ<>	DORZ<>	—			Comparing the absolute result of the contact type ON: $ S_1 - S_2  \neq  S_3 $ OFF: $ S_1 - S_2  =  S_3 $
0080	ORZ>	DORZ>	—			Comparing the absolute result of the contact type ON: $ S_1 - S_2  >  S_3 $ OFF: $ S_1 - S_2  \leq  S_3 $
0081	ORZ>=	DORZ>=	—			Comparing the absolute result of the contact type ON: $ S_1 - S_2  \geq  S_3 $ OFF: $ S_1 - S_2  <  S_3 $
0082	ORZ<	DORZ<	—			Comparing the absolute result of the contact type ON: $ S_1 - S_2  <  S_3 $ OFF: $ S_1 - S_2  \geq  S_3 $

API	Instruction code		Pulse Instruction	Symbol	Function
	16-bit	32-bit			
0083	ORZ<=	DORZ<=	—		Comparing the absolute result of the contact type ON: $ S_1 - S_2  \leq  S_3 $ OFF: $ S_1 - S_2  >  S_3 $


















● Arithmetic instructions

API	Instruction code		Pulse instruction	Symbol	Function
	16-bit	32-bit			
0100	+	D+	✓		Adding binary numbers $S_1 + S_2 = D$
0101	-	D-	✓		Subtracting binary numbers $S_1 - S_2 = D$
0102	*	D*	✓		Multiplying binary numbers $S_1 * S_2 = D$
0103	/	D/	✓		Dividing binary numbers $S_1 / S_2 = D$
0104	—	F+	✓		Adding floating-point numbers $S_1 + S_2 = D$
0105	—	F-	✓		Subtracting floating-point numbers $S_1 - S_2 = D$
0106	—	F*	✓		Multiplying floating-point numbers $S_1 * S_2 = D$
0107	—	F/	✓		Dividing floating-point numbers $S_1 / S_2 = D$

API	Instruction code		Pulse instruction	Symbol		Function																																								
	16-bit	32-bit																																												
0112	BK+	DBK+	✓	<table border="1"> <tr><td colspan="2">BK+</td></tr> <tr><td>En</td><td>D</td></tr> <tr><td>S1</td><td></td></tr> <tr><td>S2</td><td></td></tr> <tr><td>n</td><td></td></tr> </table> <table border="1"> <tr><td colspan="2">DBK+</td></tr> <tr><td>En</td><td>D</td></tr> <tr><td>S1</td><td></td></tr> <tr><td>S2</td><td></td></tr> <tr><td>n</td><td></td></tr> </table>	BK+		En	D	S1		S2		n		DBK+		En	D	S1		S2		n		<table border="1"> <tr><td colspan="2">BK+P</td></tr> <tr><td>En</td><td>D</td></tr> <tr><td>S1</td><td></td></tr> <tr><td>S2</td><td></td></tr> <tr><td>n</td><td></td></tr> </table> <table border="1"> <tr><td colspan="2">DBK+P</td></tr> <tr><td>En</td><td>D</td></tr> <tr><td>S1</td><td></td></tr> <tr><td>S2</td><td></td></tr> <tr><td>n</td><td></td></tr> </table>	BK+P		En	D	S1		S2		n		DBK+P		En	D	S1		S2		n		Adding binary numbers in blocks
BK+																																														
En	D																																													
S1																																														
S2																																														
n																																														
DBK+																																														
En	D																																													
S1																																														
S2																																														
n																																														
BK+P																																														
En	D																																													
S1																																														
S2																																														
n																																														
DBK+P																																														
En	D																																													
S1																																														
S2																																														
n																																														
0113	BK-	DBK-	✓	<table border="1"> <tr><td colspan="2">BK-</td></tr> <tr><td>En</td><td>D</td></tr> <tr><td>S1</td><td></td></tr> <tr><td>S2</td><td></td></tr> <tr><td>n</td><td></td></tr> </table> <table border="1"> <tr><td colspan="2">DBK-</td></tr> <tr><td>En</td><td>D</td></tr> <tr><td>S1</td><td></td></tr> <tr><td>S2</td><td></td></tr> <tr><td>n</td><td></td></tr> </table>	BK-		En	D	S1		S2		n		DBK-		En	D	S1		S2		n		<table border="1"> <tr><td colspan="2">BK-P</td></tr> <tr><td>En</td><td>D</td></tr> <tr><td>S1</td><td></td></tr> <tr><td>S2</td><td></td></tr> <tr><td>n</td><td></td></tr> </table> <table border="1"> <tr><td colspan="2">DBK-P</td></tr> <tr><td>En</td><td>D</td></tr> <tr><td>S1</td><td></td></tr> <tr><td>S2</td><td></td></tr> <tr><td>n</td><td></td></tr> </table>	BK-P		En	D	S1		S2		n		DBK-P		En	D	S1		S2		n		Subtracting binary numbers in blocks
BK-																																														
En	D																																													
S1																																														
S2																																														
n																																														
DBK-																																														
En	D																																													
S1																																														
S2																																														
n																																														
BK-P																																														
En	D																																													
S1																																														
S2																																														
n																																														
DBK-P																																														
En	D																																													
S1																																														
S2																																														
n																																														
0114	\$+	—	✓	<table border="1"> <tr><td colspan="2">\$+</td></tr> <tr><td>En</td><td>D</td></tr> <tr><td>S1</td><td></td></tr> <tr><td>S2</td><td></td></tr> </table>	\$+		En	D	S1		S2		<table border="1"> <tr><td colspan="2">\$+P</td></tr> <tr><td>En</td><td>D</td></tr> <tr><td>S1</td><td></td></tr> <tr><td>S2</td><td></td></tr> </table>	\$+P		En	D	S1		S2		Linking strings																								
\$+																																														
En	D																																													
S1																																														
S2																																														
\$+P																																														
En	D																																													
S1																																														
S2																																														
0115	INC	DINC	✓	<table border="1"> <tr><td colspan="2">INC</td></tr> <tr><td>En</td><td>D</td></tr> </table> <table border="1"> <tr><td colspan="2">DINC</td></tr> <tr><td>En</td><td>D</td></tr> </table>	INC		En	D	DINC		En	D	<table border="1"> <tr><td colspan="2">INCP</td></tr> <tr><td>En</td><td>D</td></tr> </table> <table border="1"> <tr><td colspan="2">DINCP</td></tr> <tr><td>En</td><td>D</td></tr> </table>	INCP		En	D	DINCP		En	D	Adding one to a binary number																								
INC																																														
En	D																																													
DINC																																														
En	D																																													
INCP																																														
En	D																																													
DINCP																																														
En	D																																													
0116	DEC	DDEC	✓	<table border="1"> <tr><td colspan="2">DEC</td></tr> <tr><td>En</td><td>D</td></tr> </table> <table border="1"> <tr><td colspan="2">DDEC</td></tr> <tr><td>En</td><td>D</td></tr> </table>	DEC		En	D	DDEC		En	D	<table border="1"> <tr><td colspan="2">DECP</td></tr> <tr><td>En</td><td>D</td></tr> </table> <table border="1"> <tr><td colspan="2">DDECP</td></tr> <tr><td>En</td><td>D</td></tr> </table>	DECP		En	D	DDECP		En	D	Subtracting one from a binary number																								
DEC																																														
En	D																																													
DDEC																																														
En	D																																													
DECP																																														
En	D																																													
DDECP																																														
En	D																																													
0117	MUL16	MUL32	✓	<table border="1"> <tr><td colspan="2">MUL16</td></tr> <tr><td>En</td><td>D</td></tr> <tr><td>S1</td><td></td></tr> <tr><td>S2</td><td></td></tr> </table> <table border="1"> <tr><td colspan="2">MUL32</td></tr> <tr><td>En</td><td>D</td></tr> <tr><td>S1</td><td></td></tr> <tr><td>S2</td><td></td></tr> </table>	MUL16		En	D	S1		S2		MUL32		En	D	S1		S2		<table border="1"> <tr><td colspan="2">MUL16P</td></tr> <tr><td>En</td><td>D</td></tr> <tr><td>S1</td><td></td></tr> <tr><td>S2</td><td></td></tr> </table> <table border="1"> <tr><td colspan="2">MUL32P</td></tr> <tr><td>En</td><td>D</td></tr> <tr><td>S1</td><td></td></tr> <tr><td>S2</td><td></td></tr> </table>	MUL16P		En	D	S1		S2		MUL32P		En	D	S1		S2		Multiplying binary numbers for 16-bit multiplying binary numbers for 32-bit								
MUL16																																														
En	D																																													
S1																																														
S2																																														
MUL32																																														
En	D																																													
S1																																														
S2																																														
MUL16P																																														
En	D																																													
S1																																														
S2																																														
MUL32P																																														
En	D																																													
S1																																														
S2																																														
0118	DIV16	DIV32	✓	<table border="1"> <tr><td colspan="2">DIV16</td></tr> <tr><td>En</td><td>D</td></tr> <tr><td>S1</td><td></td></tr> <tr><td>S2</td><td></td></tr> </table> <table border="1"> <tr><td colspan="2">DIV32</td></tr> <tr><td>En</td><td>D</td></tr> <tr><td>S1</td><td></td></tr> <tr><td>S2</td><td></td></tr> </table>	DIV16		En	D	S1		S2		DIV32		En	D	S1		S2		<table border="1"> <tr><td colspan="2">DIV16P</td></tr> <tr><td>En</td><td>D</td></tr> <tr><td>S1</td><td></td></tr> <tr><td>S2</td><td></td></tr> </table> <table border="1"> <tr><td colspan="2">DIV32P</td></tr> <tr><td>En</td><td>D</td></tr> <tr><td>S1</td><td></td></tr> <tr><td>S2</td><td></td></tr> </table>	DIV16P		En	D	S1		S2		DIV32P		En	D	S1		S2		Dividing binary numbers for 16-bit Dividing binary numbers for 32-bit								
DIV16																																														
En	D																																													
S1																																														
S2																																														
DIV32																																														
En	D																																													
S1																																														
S2																																														
DIV16P																																														
En	D																																													
S1																																														
S2																																														
DIV32P																																														
En	D																																													
S1																																														
S2																																														

● Data conversion instructions

API	Instruction code		Pulse instruction	Symbol		Function																								
	16-bit	32-bit																												
0200	BCD	DBCD	✓	<table border="1"> <tr><td colspan="2">BCD</td></tr> <tr><td>En</td><td>D</td></tr> <tr><td>S</td><td></td></tr> </table> <table border="1"> <tr><td colspan="2">DBCD</td></tr> <tr><td>En</td><td>D</td></tr> <tr><td>S</td><td></td></tr> </table>	BCD		En	D	S		DBCD		En	D	S		<table border="1"> <tr><td colspan="2">BCDP</td></tr> <tr><td>En</td><td>D</td></tr> <tr><td>S</td><td></td></tr> </table> <table border="1"> <tr><td colspan="2">DBCDP</td></tr> <tr><td>En</td><td>D</td></tr> <tr><td>S</td><td></td></tr> </table>	BCDP		En	D	S		DBCDP		En	D	S		Converting a binary number into the binary-coded decimal number
BCD																														
En	D																													
S																														
DBCD																														
En	D																													
S																														
BCDP																														
En	D																													
S																														
DBCDP																														
En	D																													
S																														
0201	BIN	DBIN	✓	<table border="1"> <tr><td colspan="2">BIN</td></tr> <tr><td>En</td><td>D</td></tr> <tr><td>S</td><td></td></tr> </table> <table border="1"> <tr><td colspan="2">DBIN</td></tr> <tr><td>En</td><td>D</td></tr> <tr><td>S</td><td></td></tr> </table>	BIN		En	D	S		DBIN		En	D	S		<table border="1"> <tr><td colspan="2">BINP</td></tr> <tr><td>En</td><td>D</td></tr> <tr><td>S</td><td></td></tr> </table> <table border="1"> <tr><td colspan="2">DBINP</td></tr> <tr><td>En</td><td>D</td></tr> <tr><td>S</td><td></td></tr> </table>	BINP		En	D	S		DBINP		En	D	S		Converting a binary-coded decimal number into a binary number
BIN																														
En	D																													
S																														
DBIN																														
En	D																													
S																														
BINP																														
En	D																													
S																														
DBINP																														
En	D																													
S																														

API	Instruction code		Pulse instruction	Symbol		Function
	16-bit	32-bit				
0202	FLT	DFLT	✓	   	Converting a binary integer into a binary floating-point number	
0204	INT	DINT	✓	   	Converting a 32-bit floating-point number into a binary integer	
0206	MMOV	—	✓	 	Converting a 16-bit value into a 32-bit value	
0207	RMOV	—	✓	 	Converting a 32-bit value into a 16-bit value	
0208	GRY	DGRY	✓	   	Converting a binary number into a Gray code	
0209	GBIN	DGBIN	✓	   	Converting a Gray code into a binary number	
0210	NEG	DNEG	✓	   	Two's complement of a number	
0211	—	FNEG	✓	 	Reversing the sign of a 32-bit floating-point number	
0212	—	FBCD	✓	 	Converting a binary floating-point number into a decimal floating-point number	
0213	—	FBIN	✓	 	Converting a decimal floating-point number into a binary floating-point number	
0214	BKBCD	—	✓	 	Converting a binary numbers in blocks into a binary-coded decimal numbers in blocks	
0215	BKBIN	—	✓	 	Converting a binary numbers in blocks into a binary-coded decimal numbers in blocks	
0216	SCAL	DSCAL	✓	   	Finding a scaled value (point-slope)	

API	Instruction code		Pulse instruction	Symbol		Function																																															
	16-bit	32-bit																																																			
0217	SCLP	DSCLP	✓	<table border="1"> <tr><td colspan="2">SCLP</td></tr> <tr><td>En</td><td></td></tr> <tr><td>S1</td><td>D</td></tr> <tr><td>S2</td><td></td></tr> </table> <table border="1"> <tr><td colspan="2">SCLPP</td></tr> <tr><td>En</td><td></td></tr> <tr><td>S1</td><td>D</td></tr> <tr><td>S2</td><td></td></tr> </table> <table border="1"> <tr><td colspan="2">DSCLP</td></tr> <tr><td>En</td><td></td></tr> <tr><td>S1</td><td>D</td></tr> <tr><td>S2</td><td></td></tr> </table> <table border="1"> <tr><td colspan="2">DSCLPP</td></tr> <tr><td>En</td><td></td></tr> <tr><td>S1</td><td>D</td></tr> <tr><td>S2</td><td></td></tr> </table>	SCLP		En		S1	D	S2		SCLPP		En		S1	D	S2		DSCLP		En		S1	D	S2		DSCLPP		En		S1	D	S2		Finding a scaled value (two points)																
SCLP																																																					
En																																																					
S1	D																																																				
S2																																																					
SCLPP																																																					
En																																																					
S1	D																																																				
S2																																																					
DSCLP																																																					
En																																																					
S1	D																																																				
S2																																																					
DSCLPP																																																					
En																																																					
S1	D																																																				
S2																																																					
0222	SCLM	DSCLM	✓	<table border="1"> <tr><td colspan="2">SCLM</td></tr> <tr><td>En</td><td></td></tr> <tr><td>S1</td><td>D</td></tr> <tr><td>S2</td><td></td></tr> <tr><td>S3</td><td></td></tr> <tr><td>S4</td><td></td></tr> </table> <table border="1"> <tr><td colspan="2">SCLMP</td></tr> <tr><td>En</td><td></td></tr> <tr><td>S1</td><td>D</td></tr> <tr><td>S2</td><td></td></tr> <tr><td>S3</td><td></td></tr> <tr><td>S4</td><td></td></tr> </table> <table border="1"> <tr><td colspan="2">DSCLM</td></tr> <tr><td>En</td><td></td></tr> <tr><td>S1</td><td>D</td></tr> <tr><td>S2</td><td></td></tr> <tr><td>S3</td><td></td></tr> <tr><td>S4</td><td></td></tr> </table> <table border="1"> <tr><td colspan="2">DSCLMP</td></tr> <tr><td>En</td><td></td></tr> <tr><td>S1</td><td>D</td></tr> <tr><td>S2</td><td></td></tr> <tr><td>S3</td><td></td></tr> <tr><td>S4</td><td></td></tr> </table>	SCLM		En		S1	D	S2		S3		S4		SCLMP		En		S1	D	S2		S3		S4		DSCLM		En		S1	D	S2		S3		S4		DSCLMP		En		S1	D	S2		S3		S4		Multi-point area ratio operation
SCLM																																																					
En																																																					
S1	D																																																				
S2																																																					
S3																																																					
S4																																																					
SCLMP																																																					
En																																																					
S1	D																																																				
S2																																																					
S3																																																					
S4																																																					
DSCLM																																																					
En																																																					
S1	D																																																				
S2																																																					
S3																																																					
S4																																																					
DSCLMP																																																					
En																																																					
S1	D																																																				
S2																																																					
S3																																																					
S4																																																					

3

● Data transfer instructions

API	Instruction code		Pulse instruction	Symbol		Function																															
	16-bit	32-bit																																			
0300	MOV	DMOV	✓	<table border="1"> <tr><td colspan="2">MOV</td></tr> <tr><td>En</td><td></td></tr> <tr><td>S</td><td>D</td></tr> </table> <table border="1"> <tr><td colspan="2">MOV P</td></tr> <tr><td>En</td><td></td></tr> <tr><td>S</td><td>D</td></tr> </table> <table border="1"> <tr><td colspan="2">DMOV</td></tr> <tr><td>En</td><td></td></tr> <tr><td>S</td><td>D</td></tr> </table> <table border="1"> <tr><td colspan="2">DMOV P</td></tr> <tr><td>En</td><td></td></tr> <tr><td>S</td><td>D</td></tr> </table>	MOV		En		S	D	MOV P		En		S	D	DMOV		En		S	D	DMOV P		En		S	D	Transferring data S: Data source D: Data destination								
MOV																																					
En																																					
S	D																																				
MOV P																																					
En																																					
S	D																																				
DMOV																																					
En																																					
S	D																																				
DMOV P																																					
En																																					
S	D																																				
0302	\$MOV	—	✓	<table border="1"> <tr><td colspan="2">\$MOV</td></tr> <tr><td>En</td><td></td></tr> <tr><td>S</td><td>D</td></tr> </table> <table border="1"> <tr><td colspan="2">\$MOV P</td></tr> <tr><td>En</td><td></td></tr> <tr><td>S</td><td>D</td></tr> </table>	\$MOV		En		S	D	\$MOV P		En		S	D	Transferring a string																				
\$MOV																																					
En																																					
S	D																																				
\$MOV P																																					
En																																					
S	D																																				
0303	CML	DCML	✓	<table border="1"> <tr><td colspan="2">CML</td></tr> <tr><td>En</td><td></td></tr> <tr><td>S</td><td>D</td></tr> </table> <table border="1"> <tr><td colspan="2">CML P</td></tr> <tr><td>En</td><td></td></tr> <tr><td>S</td><td>D</td></tr> </table> <table border="1"> <tr><td colspan="2">DCML</td></tr> <tr><td>En</td><td></td></tr> <tr><td>S</td><td>D</td></tr> </table> <table border="1"> <tr><td colspan="2">DCML P</td></tr> <tr><td>En</td><td></td></tr> <tr><td>S</td><td>D</td></tr> </table>	CML		En		S	D	CML P		En		S	D	DCML		En		S	D	DCML P		En		S	D	Inverting data								
CML																																					
En																																					
S	D																																				
CML P																																					
En																																					
S	D																																				
DCML																																					
En																																					
S	D																																				
DCML P																																					
En																																					
S	D																																				
0304	BMOV	DBMOV	✓	<table border="1"> <tr><td colspan="2">BMOV</td></tr> <tr><td>En</td><td></td></tr> <tr><td>S</td><td>D</td></tr> <tr><td>n</td><td></td></tr> </table> <table border="1"> <tr><td colspan="2">BMOV P</td></tr> <tr><td>En</td><td></td></tr> <tr><td>S</td><td>D</td></tr> <tr><td>n</td><td></td></tr> </table> <table border="1"> <tr><td colspan="2">DBMOV</td></tr> <tr><td>En</td><td></td></tr> <tr><td>S</td><td>D</td></tr> <tr><td>n</td><td></td></tr> </table> <table border="1"> <tr><td colspan="2">DBMOV P</td></tr> <tr><td>En</td><td></td></tr> <tr><td>S</td><td>D</td></tr> <tr><td>n</td><td></td></tr> </table>	BMOV		En		S	D	n		BMOV P		En		S	D	n		DBMOV		En		S	D	n		DBMOV P		En		S	D	n		Transferring all data
BMOV																																					
En																																					
S	D																																				
n																																					
BMOV P																																					
En																																					
S	D																																				
n																																					
DBMOV																																					
En																																					
S	D																																				
n																																					
DBMOV P																																					
En																																					
S	D																																				
n																																					
0305	NMOV	DNMOV	✓	<table border="1"> <tr><td colspan="2">NMOV</td></tr> <tr><td>En</td><td></td></tr> <tr><td>S</td><td>D</td></tr> <tr><td>n</td><td></td></tr> </table> <table border="1"> <tr><td colspan="2">NMOV P</td></tr> <tr><td>En</td><td></td></tr> <tr><td>S</td><td>D</td></tr> <tr><td>n</td><td></td></tr> </table> <table border="1"> <tr><td colspan="2">DNMOV P</td></tr> <tr><td>En</td><td></td></tr> <tr><td>S</td><td>D</td></tr> <tr><td>n</td><td></td></tr> </table> <table border="1"> <tr><td colspan="2">DNMOV</td></tr> <tr><td>En</td><td></td></tr> <tr><td>S</td><td>D</td></tr> <tr><td>n</td><td></td></tr> </table>	NMOV		En		S	D	n		NMOV P		En		S	D	n		DNMOV P		En		S	D	n		DNMOV		En		S	D	n		Transferring data to several devices
NMOV																																					
En																																					
S	D																																				
n																																					
NMOV P																																					
En																																					
S	D																																				
n																																					
DNMOV P																																					
En																																					
S	D																																				
n																																					
DNMOV																																					
En																																					
S	D																																				
n																																					
0306	XCH	DXCH	✓	<table border="1"> <tr><td colspan="2">XCH</td></tr> <tr><td>En</td><td></td></tr> <tr><td>S1</td><td>S2</td></tr> </table> <table border="1"> <tr><td colspan="2">XCH P</td></tr> <tr><td>En</td><td></td></tr> <tr><td>S1</td><td>S2</td></tr> </table> <table border="1"> <tr><td colspan="2">DXCH</td></tr> <tr><td>En</td><td></td></tr> <tr><td>S1</td><td>S2</td></tr> </table> <table border="1"> <tr><td colspan="2">DXCH P</td></tr> <tr><td>En</td><td></td></tr> <tr><td>S1</td><td>S2</td></tr> </table>	XCH		En		S1	S2	XCH P		En		S1	S2	DXCH		En		S1	S2	DXCH P		En		S1	S2	Exchanging the data								
XCH																																					
En																																					
S1	S2																																				
XCH P																																					
En																																					
S1	S2																																				
DXCH																																					
En																																					
S1	S2																																				
DXCH P																																					
En																																					
S1	S2																																				

API	Instruction code		Pulse instruction	Symbol		Function
	16-bit	32-bit				
0307	BXCH	—	✓			Exchanging all data
0308	SWAP	DSWAP	✓			Exchanging the high byte with the low byte
0309	SMOV	—	✓			Transferring the digits
0310	MOVB	—	✓			Transferring several bits

- Jump instructions




API	Instruction code		Pulse instruction	Symbol		Function
	16-bit	32-bit				
0400	CJ	—	✓			Conditional jump
0401	JMP	—	—			Unconditional jump
0402	GOEND	—	—			Jump to END

- Program execution instructions









API	Instruction code		Pulse instruction	Symbol		Function
	16-bit	32-bit				
0500	DI	—	—			Disabling an interrupt
0501	EI	—	—			Enabling an interrupt
0503	EIX	—	—			Disabling a specific interrupt
0504	DIX	—	—			Enabling a specific interrupt

- I/O refreshing instructions

API	Instruction code		Pulse instruction	Symbol		Function
	16-bit	32-bit				
0600	REF	—	✓			Refreshing the I/O

API	Instruction code		Pulse instruction	Symbol		Function
	16-bit	32-bit				
0601	—	DHSRF	✓			Refreshing the values of high-speed comparison
0602	REFF	—	✓			Refreshing the I/O filtering time

● Miscellaneous instructions

API	Instruction code		Pulse instruction	Symbol		Function
	16-bit	32-bit				
0700	ALT	—	✓			Alternating between ON and OFF
0701	TTMR	—	—			Teach mode timer
0702	STMR	—	—			Special timer
0703	RAMP	DRAMP	—			Cyclic ramp signal
0704	MTR	—	—			Matrix input
0705	ABSD	DABSD	—			Absolute drum sequencer
0706	INCD	—	—			Incremental drum sequencer
0708	—	DPIDE	—			PID algorithm

API	Instruction code		Pulse instruction	Symbol	Function
	16-bit	32-bit			
0709	XCMP	—	—		Setting up to compare the inputs of multiple work stations
0710	YOUT	—	—		Comparing the outputs of multiple work stations
0711	—	DSUNRS	✓		Setting up the sunrise and sunset times

● Logic instructions

API	Instruction code		Pulse instruction	Symbol	Function
	16-bit	32-bit			
0800	WAND	DAND	✓		Logical AND operation
0801	MAND	—	✓		Matrix AND operation
0802	WOR	DOR	✓		Logical OR operation
0803	MOR	—	✓		Matrix OR operation
0804	WXOR	DXOR	✓		Logical exclusive OR operation
0805	MXOR	—	✓		Matrix exclusive OR operation
0808	WINV	DINV	✓		Logical reversed INV operation

API	Instruction code		Pulse instruction	Symbol		Function
	16-bit	32-bit				
0809	LD&	DLD&	—			$S_1 \& S_2$
0810	LD	DLD	—			$S_1   S_2$
0811	LD^	DLD^	—			$S_1 \wedge S_2$
0812	AND&	DAND&	—			$S_1 \& S_2$
0813	AND	DAND	—			$S_1   S_2$
0814	AND^	DAND^	—			$S_1 \wedge S_2$
0815	OR&	DOR&	—			$S_1 \& S_2$
0816	OR	DOR	—			$S_1   S_2$
0817	OR^	DOR^	—			$S_1 \wedge S_2$

● Rotation instructions

API	Instruction code		Pulse instruction	Symbol		Function
	16-bit	32-bit				
0900	ROR	DROR	✓			Rotating bits in a group to the right
0901	ROR	DROR	✓			Rotating bits in a group to the right with the carry flag

API	Instruction code		Pulse instruction	Symbol		Function
	16-bit	32-bit				
0902	ROL	DROL	✓		Rotating bits in a group to the left	
0903	RCL	DRCL	✓		Rotating bits in a group to the left with the carry flag	
0904	MBR	—	✓		Rotating bits to the right or the left in a matrix	

● Timer and counter instructions

API	Instruction code		Pulse instruction	Symbol		Function
	16-bit	32-bit				
1000	RST	DRST	—		Resetting the contact to OFF or clearing the value in the register	
1001	TMR	—	—		16-bit timer (Unit: 100ms)	
1002	TMRH	—	—		16-bit timer (Unit: 1ms)	
1003	CNT	—	—		16-bit counter	
1004	—	DCNT	—		32-bit counter (Including the use of high-speed counters)	
1005	—	DHSCS	—		Setting high-speed comparison	
1006	—	DHSCR	—		Resetting high-speed comparison	
1007	—	DHSZ	—		High-speed input zone comparison	
1008	—	DSPD	—		Speed detection	
1009	PWD	—	—		Pulse width detection	

API	Instruction code		Pulse instruction	Symbol	Function
	16-bit	32-bit			
1010	—	DCAP	—		Capturing the high-speed count value in the external input interrupt
1011	TMRM	—	—		16-bit timer (Unit: 10ms)
1012	IETS	—	✓		The start of the instruction execution time measurement
1013	IETE	—	✓		The end of the instruction execution time measurement
1014	—	DHSCY	—		Cyclic counting, comparing and outputting
1015	PPDT	—	—		Detecting the time difference between two phases
1016	ATMR	—	—		16-bit contact timer (Unit: 100 ms)
1017	ATMRH	—	—		16-bit contact timer (Unit: 1 ms)
1018	ATMRM	—	—		16-bit contact timer (Unit: 10 ms)

● Shift instructions

API	Instruction code		Pulse instruction	Symbol	Function
	16-bit	32-bit			
1100	SFTR	—	✓		Shifting the states of the devices to the right
1101	SFTL	—	✓		Shifting the states of the devices to the left
1102	WSFR	DWSFR	✓		Shifting the data in the word devices to the right

















API	Instruction code		Pulse instruction	Symbol		Function
	16-bit	32-bit				
1103	WSFL	DWSFL	✓	<div style="display: flex; flex-direction: column; align-items: center;"> <div style="border: 1px solid black; padding: 2px; margin-bottom: 2px;">WSFL</div> <div style="display: flex; justify-content: space-between; width: 100%;"> <span>En</span> <span>D</span> </div> <div style="display: flex; justify-content: space-between; width: 100%;"> <span>S</span> <span>n1</span> </div> <div style="display: flex; justify-content: space-between; width: 100%;"> <span>n2</span> </div> </div> <div style="display: flex; flex-direction: column; align-items: center;"> <div style="border: 1px solid black; padding: 2px; margin-bottom: 2px;">DWSFL</div> <div style="display: flex; justify-content: space-between; width: 100%;"> <span>En</span> <span>D</span> </div> <div style="display: flex; justify-content: space-between; width: 100%;"> <span>S</span> <span>n1</span> </div> <div style="display: flex; justify-content: space-between; width: 100%;"> <span>n2</span> </div> </div>	<div style="display: flex; flex-direction: column; align-items: center;"> <div style="border: 1px solid black; padding: 2px; margin-bottom: 2px;">WSFLP</div> <div style="display: flex; justify-content: space-between; width: 100%;"> <span>En</span> <span>D</span> </div> <div style="display: flex; justify-content: space-between; width: 100%;"> <span>S</span> <span>n1</span> </div> <div style="display: flex; justify-content: space-between; width: 100%;"> <span>n2</span> </div> </div> <div style="display: flex; flex-direction: column; align-items: center;"> <div style="border: 1px solid black; padding: 2px; margin-bottom: 2px;">DWSFLP</div> <div style="display: flex; justify-content: space-between; width: 100%;"> <span>En</span> <span>D</span> </div> <div style="display: flex; justify-content: space-between; width: 100%;"> <span>S</span> <span>n1</span> </div> <div style="display: flex; justify-content: space-between; width: 100%;"> <span>n2</span> </div> </div>	Shifting the data in the word devices to the left
1104	SFWR	DSFWR	✓	<div style="display: flex; flex-direction: column; align-items: center;"> <div style="border: 1px solid black; padding: 2px; margin-bottom: 2px;">SFWR</div> <div style="display: flex; justify-content: space-between; width: 100%;"> <span>En</span> <span>D</span> </div> <div style="display: flex; justify-content: space-between; width: 100%;"> <span>S</span> <span>n</span> </div> </div> <div style="display: flex; flex-direction: column; align-items: center;"> <div style="border: 1px solid black; padding: 2px; margin-bottom: 2px;">DSFWR</div> <div style="display: flex; justify-content: space-between; width: 100%;"> <span>En</span> <span>D</span> </div> <div style="display: flex; justify-content: space-between; width: 100%;"> <span>S</span> <span>n</span> </div> </div>	<div style="display: flex; flex-direction: column; align-items: center;"> <div style="border: 1px solid black; padding: 2px; margin-bottom: 2px;">SFWRP</div> <div style="display: flex; justify-content: space-between; width: 100%;"> <span>En</span> <span>D</span> </div> <div style="display: flex; justify-content: space-between; width: 100%;"> <span>S</span> <span>n</span> </div> </div> <div style="display: flex; flex-direction: column; align-items: center;"> <div style="border: 1px solid black; padding: 2px; margin-bottom: 2px;">DSFWRP</div> <div style="display: flex; justify-content: space-between; width: 100%;"> <span>En</span> <span>D</span> </div> <div style="display: flex; justify-content: space-between; width: 100%;"> <span>S</span> <span>n</span> </div> </div>	Shifting the data and writing it to the word device
1105	SFRD	DSFRD	✓	<div style="display: flex; flex-direction: column; align-items: center;"> <div style="border: 1px solid black; padding: 2px; margin-bottom: 2px;">SFRD</div> <div style="display: flex; justify-content: space-between; width: 100%;"> <span>En</span> <span>D</span> </div> <div style="display: flex; justify-content: space-between; width: 100%;"> <span>S</span> <span>n</span> </div> </div> <div style="display: flex; flex-direction: column; align-items: center;"> <div style="border: 1px solid black; padding: 2px; margin-bottom: 2px;">DSFRD</div> <div style="display: flex; justify-content: space-between; width: 100%;"> <span>En</span> <span>D</span> </div> <div style="display: flex; justify-content: space-between; width: 100%;"> <span>S</span> <span>n</span> </div> </div>	<div style="display: flex; flex-direction: column; align-items: center;"> <div style="border: 1px solid black; padding: 2px; margin-bottom: 2px;">SFRDP</div> <div style="display: flex; justify-content: space-between; width: 100%;"> <span>En</span> <span>D</span> </div> <div style="display: flex; justify-content: space-between; width: 100%;"> <span>S</span> <span>n</span> </div> </div> <div style="display: flex; flex-direction: column; align-items: center;"> <div style="border: 1px solid black; padding: 2px; margin-bottom: 2px;">DSFRDP</div> <div style="display: flex; justify-content: space-between; width: 100%;"> <span>En</span> <span>D</span> </div> <div style="display: flex; justify-content: space-between; width: 100%;"> <span>S</span> <span>n</span> </div> </div>	Shifting the data and reading it from the word device
1106	SFPO	DSFPO	✓	<div style="display: flex; flex-direction: column; align-items: center;"> <div style="border: 1px solid black; padding: 2px; margin-bottom: 2px;">SFPO</div> <div style="display: flex; justify-content: space-between; width: 100%;"> <span>En</span> <span>D</span> </div> <div style="display: flex; justify-content: space-between; width: 100%;"> <span>S</span> </div> </div> <div style="display: flex; flex-direction: column; align-items: center;"> <div style="border: 1px solid black; padding: 2px; margin-bottom: 2px;">DSFPO</div> <div style="display: flex; justify-content: space-between; width: 100%;"> <span>En</span> <span>D</span> </div> <div style="display: flex; justify-content: space-between; width: 100%;"> <span>S</span> </div> </div>	<div style="display: flex; flex-direction: column; align-items: center;"> <div style="border: 1px solid black; padding: 2px; margin-bottom: 2px;">SFPOP</div> <div style="display: flex; justify-content: space-between; width: 100%;"> <span>En</span> <span>D</span> </div> <div style="display: flex; justify-content: space-between; width: 100%;"> <span>S</span> </div> </div> <div style="display: flex; flex-direction: column; align-items: center;"> <div style="border: 1px solid black; padding: 2px; margin-bottom: 2px;">DSFPOP</div> <div style="display: flex; justify-content: space-between; width: 100%;"> <span>En</span> <span>D</span> </div> <div style="display: flex; justify-content: space-between; width: 100%;"> <span>S</span> </div> </div>	Reading the latest data from the data list
1107	SFDEL	DSFDEL	✓	<div style="display: flex; flex-direction: column; align-items: center;"> <div style="border: 1px solid black; padding: 2px; margin-bottom: 2px;">SFDEL</div> <div style="display: flex; justify-content: space-between; width: 100%;"> <span>En</span> <span>D</span> </div> <div style="display: flex; justify-content: space-between; width: 100%;"> <span>S</span> </div> </div> <div style="display: flex; flex-direction: column; align-items: center;"> <div style="border: 1px solid black; padding: 2px; margin-bottom: 2px;">DSFDEL</div> <div style="display: flex; justify-content: space-between; width: 100%;"> <span>En</span> <span>D</span> </div> <div style="display: flex; justify-content: space-between; width: 100%;"> <span>S</span> </div> </div>	<div style="display: flex; flex-direction: column; align-items: center;"> <div style="border: 1px solid black; padding: 2px; margin-bottom: 2px;">SFDELP</div> <div style="display: flex; justify-content: space-between; width: 100%;"> <span>En</span> <span>D</span> </div> <div style="display: flex; justify-content: space-between; width: 100%;"> <span>S</span> </div> </div> <div style="display: flex; flex-direction: column; align-items: center;"> <div style="border: 1px solid black; padding: 2px; margin-bottom: 2px;">DSFDELP</div> <div style="display: flex; justify-content: space-between; width: 100%;"> <span>En</span> <span>D</span> </div> <div style="display: flex; justify-content: space-between; width: 100%;"> <span>S</span> </div> </div>	Deleting the data from the data list
1108	SFINS	DSFINS	✓	<div style="display: flex; flex-direction: column; align-items: center;"> <div style="border: 1px solid black; padding: 2px; margin-bottom: 2px;">SFINS</div> <div style="display: flex; justify-content: space-between; width: 100%;"> <span>En</span> <span>D</span> </div> <div style="display: flex; justify-content: space-between; width: 100%;"> <span>S</span> </div> </div> <div style="display: flex; flex-direction: column; align-items: center;"> <div style="border: 1px solid black; padding: 2px; margin-bottom: 2px;">DSFINS</div> <div style="display: flex; justify-content: space-between; width: 100%;"> <span>En</span> <span>D</span> </div> <div style="display: flex; justify-content: space-between; width: 100%;"> <span>S</span> </div> </div>	<div style="display: flex; flex-direction: column; align-items: center;"> <div style="border: 1px solid black; padding: 2px; margin-bottom: 2px;">SFINSP</div> <div style="display: flex; justify-content: space-between; width: 100%;"> <span>En</span> <span>D</span> </div> <div style="display: flex; justify-content: space-between; width: 100%;"> <span>S</span> </div> </div> <div style="display: flex; flex-direction: column; align-items: center;"> <div style="border: 1px solid black; padding: 2px; margin-bottom: 2px;">DSFINSP</div> <div style="display: flex; justify-content: space-between; width: 100%;"> <span>En</span> <span>D</span> </div> <div style="display: flex; justify-content: space-between; width: 100%;"> <span>S</span> </div> </div>	Inserting the data into the data list
1109	MBS	—	✓	<div style="display: flex; flex-direction: column; align-items: center;"> <div style="border: 1px solid black; padding: 2px; margin-bottom: 2px;">MBS</div> <div style="display: flex; justify-content: space-between; width: 100%;"> <span>En</span> <span>D</span> </div> <div style="display: flex; justify-content: space-between; width: 100%;"> <span>S</span> </div> </div> <div style="display: flex; flex-direction: column; align-items: center;"> <div style="border: 1px solid black; padding: 2px; margin-bottom: 2px;">MBS</div> <div style="display: flex; justify-content: space-between; width: 100%;"> <span>En</span> <span>D</span> </div> <div style="display: flex; justify-content: space-between; width: 100%;"> <span>S</span> </div> </div>	<div style="display: flex; flex-direction: column; align-items: center;"> <div style="border: 1px solid black; padding: 2px; margin-bottom: 2px;">MBSP</div> <div style="display: flex; justify-content: space-between; width: 100%;"> <span>En</span> <span>D</span> </div> <div style="display: flex; justify-content: space-between; width: 100%;"> <span>S</span> </div> </div> <div style="display: flex; flex-direction: column; align-items: center;"> <div style="border: 1px solid black; padding: 2px; margin-bottom: 2px;">MBSP</div> <div style="display: flex; justify-content: space-between; width: 100%;"> <span>En</span> <span>D</span> </div> <div style="display: flex; justify-content: space-between; width: 100%;"> <span>S</span> </div> </div>	Shifting the matrix bits
1110	SFR	DSFR	✓	<div style="display: flex; flex-direction: column; align-items: center;"> <div style="border: 1px solid black; padding: 2px; margin-bottom: 2px;">SFR</div> <div style="display: flex; justify-content: space-between; width: 100%;"> <span>En</span> <span>D</span> </div> <div style="display: flex; justify-content: space-between; width: 100%;"> <span>S</span> </div> </div> <div style="display: flex; flex-direction: column; align-items: center;"> <div style="border: 1px solid black; padding: 2px; margin-bottom: 2px;">DSFR</div> <div style="display: flex; justify-content: space-between; width: 100%;"> <span>En</span> <span>D</span> </div> <div style="display: flex; justify-content: space-between; width: 100%;"> <span>S</span> </div> </div>	<div style="display: flex; flex-direction: column; align-items: center;"> <div style="border: 1px solid black; padding: 2px; margin-bottom: 2px;">SFRP</div> <div style="display: flex; justify-content: space-between; width: 100%;"> <span>En</span> <span>D</span> </div> <div style="display: flex; justify-content: space-between; width: 100%;"> <span>S</span> </div> </div> <div style="display: flex; flex-direction: column; align-items: center;"> <div style="border: 1px solid black; padding: 2px; margin-bottom: 2px;">DSFRP</div> <div style="display: flex; justify-content: space-between; width: 100%;"> <span>En</span> <span>D</span> </div> <div style="display: flex; justify-content: space-between; width: 100%;"> <span>S</span> </div> </div>	Shifting the values of the bits in the registers by $n$ bits to the right
1111	SFL	DSFL	✓	<div style="display: flex; flex-direction: column; align-items: center;"> <div style="border: 1px solid black; padding: 2px; margin-bottom: 2px;">SFL</div> <div style="display: flex; justify-content: space-between; width: 100%;"> <span>En</span> <span>D</span> </div> <div style="display: flex; justify-content: space-between; width: 100%;"> <span>S</span> </div> </div> <div style="display: flex; flex-direction: column; align-items: center;"> <div style="border: 1px solid black; padding: 2px; margin-bottom: 2px;">DSFL</div> <div style="display: flex; justify-content: space-between; width: 100%;"> <span>En</span> <span>D</span> </div> <div style="display: flex; justify-content: space-between; width: 100%;"> <span>S</span> </div> </div>	<div style="display: flex; flex-direction: column; align-items: center;"> <div style="border: 1px solid black; padding: 2px; margin-bottom: 2px;">SFLP</div> <div style="display: flex; justify-content: space-between; width: 100%;"> <span>En</span> <span>D</span> </div> <div style="display: flex; justify-content: space-between; width: 100%;"> <span>S</span> </div> </div> <div style="display: flex; flex-direction: column; align-items: center;"> <div style="border: 1px solid black; padding: 2px; margin-bottom: 2px;">DSFLP</div> <div style="display: flex; justify-content: space-between; width: 100%;"> <span>En</span> <span>D</span> </div> <div style="display: flex; justify-content: space-between; width: 100%;"> <span>S</span> </div> </div>	Shifting the values of the bits in the registers by $n$ bits to the left
1112	BSFR	—	✓	<div style="display: flex; flex-direction: column; align-items: center;"> <div style="border: 1px solid black; padding: 2px; margin-bottom: 2px;">BSFR</div> <div style="display: flex; justify-content: space-between; width: 100%;"> <span>En</span> <span>D</span> </div> <div style="display: flex; justify-content: space-between; width: 100%;"> <span>S</span> </div> </div> <div style="display: flex; flex-direction: column; align-items: center;"> <div style="border: 1px solid black; padding: 2px; margin-bottom: 2px;">BSFR</div> <div style="display: flex; justify-content: space-between; width: 100%;"> <span>En</span> <span>D</span> </div> <div style="display: flex; justify-content: space-between; width: 100%;"> <span>S</span> </div> </div>	<div style="display: flex; flex-direction: column; align-items: center;"> <div style="border: 1px solid black; padding: 2px; margin-bottom: 2px;">BSFRP</div> <div style="display: flex; justify-content: space-between; width: 100%;"> <span>En</span> <span>D</span> </div> <div style="display: flex; justify-content: space-between; width: 100%;"> <span>S</span> </div> </div> <div style="display: flex; flex-direction: column; align-items: center;"> <div style="border: 1px solid black; padding: 2px; margin-bottom: 2px;">BSFRP</div> <div style="display: flex; justify-content: space-between; width: 100%;"> <span>En</span> <span>D</span> </div> <div style="display: flex; justify-content: space-between; width: 100%;"> <span>S</span> </div> </div>	Shifting the states of the $n$ bit devices by one bit to the right

API	Instruction code		Pulse instruction	Symbol		Function
	16-bit	32-bit				
1113	BSFL	—	✓			Shifting the states of the n bit devices by one bit to the left
1114	NSFR	DNSFR	✓			Shifting n registers to the right
1115	NSFL	DNSFL	✓			Shifting n registers to the left

3

● Data processing instructions

API	Instruction code		Pulse instruction	Symbol		Function
	16-bit	32-bit				
1200	SER	DSER	✓			Searching the data
1201	SUM	DSUM	✓			Number of bits whose states are ON
1202	DECO	—	✓			Decoder
1203	ENCO	—	✓			Encoder
1204	SEGD	—	✓			Seven-segment decoding
1205	SORT	DSORT	✓			Sorting the data
1206	ZRST	—	✓			Resetting the zone

API	Instruction code		Pulse instruction	Symbol		Function
	16-bit	32-bit				
1207	BON	DBON	✓	   	Checking the state of the bit	
1208	MEAN	DMEAN	✓	   	Mean	
1209	CCD	—	✓	 	Sum check	
1210	ABS	DABS	✓	   	Absolute value	
1211	MINV	—	✓	 	Inverting the matrix bits	
1212	MBRD	—	✓	 	Reading the matrix bit	
1213	MBWR	—	✓	 	Writing the matrix bit	
1214	MBC	—	✓	 	Counting the bits with the value 0 or 1	
1215	DIS	—	✓	 	Disuniting 16-bit data	
1216	UNI	—	✓	 	Uniting 16-bit data	
1217	WSUM	DWSUM	✓	   	Getting the sum	

API	Instruction code		Pulse instruction	Symbol		Function																																								
	16-bit	32-bit																																												
1221	LIMIT	DLIMIT	✓	<table border="1"> <tr><td>LIMIT</td><td></td></tr> <tr><td>En</td><td></td></tr> <tr><td>S1</td><td>D</td></tr> <tr><td>S2</td><td></td></tr> <tr><td>S3</td><td></td></tr> </table> <table border="1"> <tr><td>DLIMIT</td><td></td></tr> <tr><td>En</td><td></td></tr> <tr><td>S1</td><td>D</td></tr> <tr><td>S2</td><td></td></tr> <tr><td>S3</td><td></td></tr> </table>	LIMIT		En		S1	D	S2		S3		DLIMIT		En		S1	D	S2		S3		<table border="1"> <tr><td>LIMITP</td><td></td></tr> <tr><td>En</td><td></td></tr> <tr><td>S1</td><td>D</td></tr> <tr><td>S2</td><td></td></tr> <tr><td>S3</td><td></td></tr> </table> <table border="1"> <tr><td>DLIMITP</td><td></td></tr> <tr><td>En</td><td></td></tr> <tr><td>S1</td><td>D</td></tr> <tr><td>S2</td><td></td></tr> <tr><td>S3</td><td></td></tr> </table>	LIMITP		En		S1	D	S2		S3		DLIMITP		En		S1	D	S2		S3		Confining a value within bounds
LIMIT																																														
En																																														
S1	D																																													
S2																																														
S3																																														
DLIMIT																																														
En																																														
S1	D																																													
S2																																														
S3																																														
LIMITP																																														
En																																														
S1	D																																													
S2																																														
S3																																														
DLIMITP																																														
En																																														
S1	D																																													
S2																																														
S3																																														
1222	BAND	DBAND	✓	<table border="1"> <tr><td>BAND</td><td></td></tr> <tr><td>En</td><td></td></tr> <tr><td>S1</td><td>D</td></tr> <tr><td>S2</td><td></td></tr> <tr><td>S3</td><td></td></tr> </table> <table border="1"> <tr><td>DBAND</td><td></td></tr> <tr><td>En</td><td></td></tr> <tr><td>S1</td><td>D</td></tr> <tr><td>S2</td><td></td></tr> <tr><td>S3</td><td></td></tr> </table>	BAND		En		S1	D	S2		S3		DBAND		En		S1	D	S2		S3		<table border="1"> <tr><td>BANDP</td><td></td></tr> <tr><td>En</td><td></td></tr> <tr><td>S1</td><td>D</td></tr> <tr><td>S2</td><td></td></tr> <tr><td>S3</td><td></td></tr> </table> <table border="1"> <tr><td>DBANDP</td><td></td></tr> <tr><td>En</td><td></td></tr> <tr><td>S1</td><td>D</td></tr> <tr><td>S2</td><td></td></tr> <tr><td>S3</td><td></td></tr> </table>	BANDP		En		S1	D	S2		S3		DBANDP		En		S1	D	S2		S3		Deadband control
BAND																																														
En																																														
S1	D																																													
S2																																														
S3																																														
DBAND																																														
En																																														
S1	D																																													
S2																																														
S3																																														
BANDP																																														
En																																														
S1	D																																													
S2																																														
S3																																														
DBANDP																																														
En																																														
S1	D																																													
S2																																														
S3																																														
1223	ZONE	DZONE	✓	<table border="1"> <tr><td>ZONE</td><td></td></tr> <tr><td>En</td><td></td></tr> <tr><td>S1</td><td>D</td></tr> <tr><td>S2</td><td></td></tr> <tr><td>S3</td><td></td></tr> </table> <table border="1"> <tr><td>DZONE</td><td></td></tr> <tr><td>En</td><td></td></tr> <tr><td>S1</td><td>D</td></tr> <tr><td>S2</td><td></td></tr> <tr><td>S3</td><td></td></tr> </table>	ZONE		En		S1	D	S2		S3		DZONE		En		S1	D	S2		S3		<table border="1"> <tr><td>ZONEP</td><td></td></tr> <tr><td>En</td><td></td></tr> <tr><td>S1</td><td>D</td></tr> <tr><td>S2</td><td></td></tr> <tr><td>S3</td><td></td></tr> </table> <table border="1"> <tr><td>DZONEP</td><td></td></tr> <tr><td>En</td><td></td></tr> <tr><td>S1</td><td>D</td></tr> <tr><td>S2</td><td></td></tr> <tr><td>S3</td><td></td></tr> </table>	ZONEP		En		S1	D	S2		S3		DZONEP		En		S1	D	S2		S3		Controlling the zone
ZONE																																														
En																																														
S1	D																																													
S2																																														
S3																																														
DZONE																																														
En																																														
S1	D																																													
S2																																														
S3																																														
ZONEP																																														
En																																														
S1	D																																													
S2																																														
S3																																														
DZONEP																																														
En																																														
S1	D																																													
S2																																														
S3																																														
1224	—	FMEAN	✓	<table border="1"> <tr><td>FMEAN</td><td></td></tr> <tr><td>En</td><td></td></tr> <tr><td>S</td><td>D</td></tr> <tr><td>n</td><td></td></tr> </table>	FMEAN		En		S	D	n		<table border="1"> <tr><td>FMEANP</td><td></td></tr> <tr><td>En</td><td></td></tr> <tr><td>S</td><td>D</td></tr> <tr><td>n</td><td></td></tr> </table>	FMEANP		En		S	D	n		Mean of the floating point numbers																								
FMEAN																																														
En																																														
S	D																																													
n																																														
FMEANP																																														
En																																														
S	D																																													
n																																														
1225	—	FSUM	✓	<table border="1"> <tr><td>FSUM</td><td></td></tr> <tr><td>En</td><td></td></tr> <tr><td>S</td><td>D</td></tr> <tr><td>n</td><td></td></tr> </table>	FSUM		En		S	D	n		<table border="1"> <tr><td>FSUMP</td><td></td></tr> <tr><td>En</td><td></td></tr> <tr><td>S</td><td>D</td></tr> <tr><td>n</td><td></td></tr> </table>	FSUMP		En		S	D	n		Sum of the floating point numbers																								
FSUM																																														
En																																														
S	D																																													
n																																														
FSUMP																																														
En																																														
S	D																																													
n																																														
1226	DTM	—	✓	<table border="1"> <tr><td>DTM</td><td></td></tr> <tr><td>En</td><td></td></tr> <tr><td>S</td><td>D</td></tr> <tr><td>m</td><td></td></tr> <tr><td>n</td><td></td></tr> </table>	DTM		En		S	D	m		n		<table border="1"> <tr><td>DTMP</td><td></td></tr> <tr><td>En</td><td></td></tr> <tr><td>S</td><td>D</td></tr> <tr><td>m</td><td></td></tr> <tr><td>n</td><td></td></tr> </table>	DTMP		En		S	D	m		n		Transfer and move data																				
DTM																																														
En																																														
S	D																																													
m																																														
n																																														
DTMP																																														
En																																														
S	D																																													
m																																														
n																																														
1228	ZSET	—	✓	<table border="1"> <tr><td>ZSET</td><td></td></tr> <tr><td>En</td><td></td></tr> <tr><td>SBit</td><td></td></tr> <tr><td>EBit</td><td></td></tr> </table>	ZSET		En		SBit		EBit		<table border="1"> <tr><td>ZSETP</td><td></td></tr> <tr><td>En</td><td></td></tr> <tr><td>SBit</td><td></td></tr> <tr><td>EBit</td><td></td></tr> </table>	ZSETP		En		SBit		EBit		Zone setup																								
ZSET																																														
En																																														
SBit																																														
EBit																																														
ZSETP																																														
En																																														
SBit																																														
EBit																																														
1229	—	FSORT	✓	<table border="1"> <tr><td>FSORT</td><td></td></tr> <tr><td>En</td><td></td></tr> <tr><td>src</td><td>dst</td></tr> <tr><td>group</td><td></td></tr> <tr><td>column</td><td></td></tr> <tr><td>ref</td><td></td></tr> </table>	FSORT		En		src	dst	group		column		ref		<table border="1"> <tr><td>FSORTP</td><td></td></tr> <tr><td>En</td><td></td></tr> <tr><td>src</td><td>dst</td></tr> <tr><td>group</td><td></td></tr> <tr><td>column</td><td></td></tr> <tr><td>ref</td><td></td></tr> </table>	FSORTP		En		src	dst	group		column		ref		Sorting data in floating-point format																
FSORT																																														
En																																														
src	dst																																													
group																																														
column																																														
ref																																														
FSORTP																																														
En																																														
src	dst																																													
group																																														
column																																														
ref																																														

● Structure creation instructions

API	Instruction code		Pulse instruction	Symbol	Function								
	16-bit	32-bit											
1300	FOR	—	—	<table border="1"> <tr><td>FOR</td><td></td></tr> <tr><td>S</td><td></td></tr> </table>	FOR		S		Start of the nested loop				
FOR													
S													
1301	NEXT	—	—	<table border="1"> <tr><td>NEXT</td><td></td></tr> </table>	NEXT		End of the nested loop						
NEXT													
1302	BREAK	—	—	<table border="1"> <tr><td>BREAK</td><td></td></tr> <tr><td>En</td><td></td></tr> <tr><td>D</td><td></td></tr> <tr><td>P</td><td></td></tr> </table>	BREAK		En		D		P		Terminating the FOR-NEXT loop
BREAK													
En													
D													
P													

● Module instructions

API	Instruction code		Pulse instruction	Symbol	Function																												
	16-bit	32-bit																															
1400	FROM	DFROM	✓	<table border="1"> <tr> <td>FROM</td> <td>FROMP</td> </tr> <tr> <td>En</td> <td>En</td> </tr> <tr> <td>m1</td> <td>m1</td> </tr> <tr> <td>m2</td> <td>m2</td> </tr> <tr> <td>m3</td> <td>m3</td> </tr> <tr> <td>n</td> <td>n</td> </tr> <tr> <td>D</td> <td>D</td> </tr> <tr> <td>DFROM</td> <td>DFROMP</td> </tr> <tr> <td>En</td> <td>En</td> </tr> <tr> <td>m1</td> <td>m1</td> </tr> <tr> <td>m2</td> <td>m2</td> </tr> <tr> <td>m3</td> <td>m3</td> </tr> <tr> <td>n</td> <td>n</td> </tr> <tr> <td>D</td> <td>D</td> </tr> </table>	FROM	FROMP	En	En	m1	m1	m2	m2	m3	m3	n	n	D	D	DFROM	DFROMP	En	En	m1	m1	m2	m2	m3	m3	n	n	D	D	Reading the data from the control register in the special module
FROM	FROMP																																
En	En																																
m1	m1																																
m2	m2																																
m3	m3																																
n	n																																
D	D																																
DFROM	DFROMP																																
En	En																																
m1	m1																																
m2	m2																																
m3	m3																																
n	n																																
D	D																																
1401	TO	DTO	✓	<table border="1"> <tr> <td>TO</td> <td>TOP</td> </tr> <tr> <td>En</td> <td>En</td> </tr> <tr> <td>m1</td> <td>m1</td> </tr> <tr> <td>m2</td> <td>m2</td> </tr> <tr> <td>m3</td> <td>m3</td> </tr> <tr> <td>S</td> <td>S</td> </tr> <tr> <td>n</td> <td>n</td> </tr> <tr> <td>DTO</td> <td>DTOP</td> </tr> <tr> <td>En</td> <td>En</td> </tr> <tr> <td>m1</td> <td>m1</td> </tr> <tr> <td>m2</td> <td>m2</td> </tr> <tr> <td>m3</td> <td>m3</td> </tr> <tr> <td>S</td> <td>S</td> </tr> <tr> <td>n</td> <td>n</td> </tr> </table>	TO	TOP	En	En	m1	m1	m2	m2	m3	m3	S	S	n	n	DTO	DTOP	En	En	m1	m1	m2	m2	m3	m3	S	S	n	n	Writing the data to the control register in the special module
TO	TOP																																
En	En																																
m1	m1																																
m2	m2																																
m3	m3																																
S	S																																
n	n																																
DTO	DTOP																																
En	En																																
m1	m1																																
m2	m2																																
m3	m3																																
S	S																																
n	n																																
1402	—	DPUCONF	✓	<table border="1"> <tr> <td>DPUCONF</td> <td>DPUCONFP</td> </tr> <tr> <td>En</td> <td>En</td> </tr> <tr> <td>Module</td> <td>Module</td> </tr> <tr> <td>Done</td> <td>Done</td> </tr> <tr> <td>Axis</td> <td>Axis</td> </tr> <tr> <td>Error</td> <td>Error</td> </tr> <tr> <td>Mode</td> <td>Mode</td> </tr> <tr> <td>ErrCode</td> <td>ErrCode</td> </tr> <tr> <td>SSpeed</td> <td>SSpeed</td> </tr> <tr> <td>Atime</td> <td>Atime</td> </tr> <tr> <td>Dtime</td> <td>Dtime</td> </tr> <tr> <td>MSpeed</td> <td>MSpeed</td> </tr> <tr> <td>Z_no</td> <td>Z_no</td> </tr> <tr> <td>Offset</td> <td>Offset</td> </tr> </table>	DPUCONF	DPUCONFP	En	En	Module	Module	Done	Done	Axis	Axis	Error	Error	Mode	Mode	ErrCode	ErrCode	SSpeed	SSpeed	Atime	Atime	Dtime	Dtime	MSpeed	MSpeed	Z_no	Z_no	Offset	Offset	Setting output control parameters of PU module
DPUCONF	DPUCONFP																																
En	En																																
Module	Module																																
Done	Done																																
Axis	Axis																																
Error	Error																																
Mode	Mode																																
ErrCode	ErrCode																																
SSpeed	SSpeed																																
Atime	Atime																																
Dtime	Dtime																																
MSpeed	MSpeed																																
Z_no	Z_no																																
Offset	Offset																																
1403	PUSTAT	—	—	<table border="1"> <tr> <td>PUSTAT</td> </tr> <tr> <td>En</td> </tr> <tr> <td>Module</td> <td>C_Pos</td> </tr> <tr> <td>Axis</td> <td>Execute</td> </tr> <tr> <td>ZeroS</td> <td>Pause</td> </tr> <tr> <td></td> <td>Error</td> </tr> <tr> <td></td> <td>ErrCode</td> </tr> </table>	PUSTAT	En	Module	C_Pos	Axis	Execute	ZeroS	Pause		Error		ErrCode	Reading PU module output state																
PUSTAT																																	
En																																	
Module	C_Pos																																
Axis	Execute																																
ZeroS	Pause																																
	Error																																
	ErrCode																																
1404	—	DPUPLS	—	<table border="1"> <tr> <td>DPUPLS</td> </tr> <tr> <td>En</td> </tr> <tr> <td>Module</td> <td>Down</td> </tr> <tr> <td>Axis</td> <td>Error</td> </tr> <tr> <td>TarPulse</td> <td>ErrCode</td> </tr> <tr> <td>TarSpeed</td> <td></td> </tr> </table>	DPUPLS	En	Module	Down	Axis	Error	TarPulse	ErrCode	TarSpeed		PU module pulse output (no acceleration)																		
DPUPLS																																	
En																																	
Module	Down																																
Axis	Error																																
TarPulse	ErrCode																																
TarSpeed																																	
1405	—	DPUDRI	—	<table border="1"> <tr> <td>DPUDRI</td> </tr> <tr> <td>En</td> </tr> <tr> <td>Module</td> <td>Down</td> </tr> <tr> <td>Axis</td> <td>Error</td> </tr> <tr> <td>RTarPosi</td> <td>ErrCode</td> </tr> <tr> <td>TarSpeed</td> <td></td> </tr> </table>	DPUDRI	En	Module	Down	Axis	Error	RTarPosi	ErrCode	TarSpeed		Relative position output of PU module (with acceleration and deceleration)																		
DPUDRI																																	
En																																	
Module	Down																																
Axis	Error																																
RTarPosi	ErrCode																																
TarSpeed																																	

API	Instruction code		Pulse instruction	Symbol	Function
	16-bit	32-bit			
1406	—	DPUDRA	—	<div style="border: 1px solid black; padding: 2px; width: fit-content;">                     DPUDRA                      En                      Module    Down                      Axis        Error                      ATarPos1   ErrCode                      TarSpeed                 </div>	Absolute addressing output of PU module (with acceleration and deceleration)
1407	—	DPUZRN	—	<div style="border: 1px solid black; padding: 2px; width: fit-content;">                     DPUZRN                      En                      Module    Done                      Axis        Error                      Mode        ErrCode                      TarSpeed                      JogSpeed                 </div>	PU module homing
1408	—	DPUJOG	—	<div style="border: 1px solid black; padding: 2px; width: fit-content;">                     DPUJOG                      En                      Module    Busy                      Axis        Error                      JogSpeed   ErrCode                 </div>	PU module jog output
1409	—	DPUMPG	—	<div style="border: 1px solid black; padding: 2px; width: fit-content;">                     DPUMPG                      En                      Module    OPulse                      Axis        OSpeed                      InMode     Error                      InPulse    ErrCode                      InSpeed                      Rate                 </div>	PU module MPG output
1410	—	DPUCNT	—	<div style="border: 1px solid black; padding: 2px; width: fit-content;">                     DPUCNT                      En                      Module    InPulse                      InMode    InSpeed                      Period     Error                      ZeroS     ErrCode                 </div>	High-speed counter function of PU module
1415	—	DLCCAL	—	<div style="border: 1px solid black; padding: 2px; width: fit-content;">                     DLCCAL                      En                      Group     CPoint                      Module    Done                      ChNo      Adone                      Trigger    Error                      TPoint    ErrCode                      TWeight                 </div>	LC module channel calibration

API	Instruction code		Pulse instruction	Symbol	Function
	16-bit	32-bit			
1416	—	DLCWEI	—	<pre> DLCWEI En Group Weight Module Status ChNo Error Stable ErrCode ZeroS TareS TareW                     </pre>	Reading weight value via LC module
1417	—	DMPID	—	<pre> DMPID En GROUP PV MODULE PV CH LAMP UPDATE ERRCode PID RUN OFF PID_MGDE PID_MAN MOUT_AUTO AUTO_DOW TLE_DP TLE_MG IT PID_EG PID_DE PID_LURJ DISE_DOW ALPHA ZETA MOUT HMAX CYCLE                     </pre>	PID algorithm for RTD/TC module
1418	—	DHCCNT	—	<pre> DHCCNT En Module CurCnt ChNo ST Update MT Action AStat Value RefCnt Dir CntStat Error ErrCode                     </pre>	HC module counter value counted
1419	—	DHCCAP	—	<pre> DHCCAP En Module Capt1 ChNo Cmpl1 TrgSel Capt2 Cmpl2 Error ErrCode                     </pre>	HC module counter value captured
1420	HCDO	—	—	<pre> HCDO En Module Dostate Update Error Dodata ErrCode                     </pre>	HC module digital output point
1421	—	DHCCMP	—	<pre> DHCCMP En Module Match1 ChNo Match2 Update Error Comp1 ErrCode Action1 Yno1 Comp2 Action2 Yno2                     </pre>	HC module counter value in comparison for output

API	Instruction code		Pulse instruction	Symbol	Function																																				
	16-bit	32-bit																																							
1422	—	DHCCMPT	—	<table border="1"> <tr><td colspan="2">DHCCMPT</td></tr> <tr><td>En</td><td></td></tr> <tr><td>Module</td><td>CurNo</td></tr> <tr><td>ChNo</td><td>Error</td></tr> <tr><td>Update</td><td>ErrCode</td></tr> <tr><td>CmpLen</td><td></td></tr> <tr><td>CompS</td><td></td></tr> <tr><td>ActionS</td><td></td></tr> <tr><td>YnoS</td><td></td></tr> <tr><td>InoS</td><td></td></tr> </table>	DHCCMPT		En		Module	CurNo	ChNo	Error	Update	ErrCode	CmpLen		CompS		ActionS		YnoS		InoS		HC module counter value in group comparison for output																
DHCCMPT																																									
En																																									
Module	CurNo																																								
ChNo	Error																																								
Update	ErrCode																																								
CmpLen																																									
CompS																																									
ActionS																																									
YnoS																																									
InoS																																									
1423	—	DHCMEAS	—	<table border="1"> <tr><td colspan="2">DHCMEAS</td></tr> <tr><td>En</td><td></td></tr> <tr><td>Module</td><td>Freq</td></tr> <tr><td>ChNo</td><td>RPM</td></tr> <tr><td>Update</td><td>Error</td></tr> <tr><td>Cnt/Rev</td><td>ErrCode</td></tr> <tr><td>Smpl</td><td></td></tr> <tr><td>Avg</td><td></td></tr> </table>	DHCMEAS		En		Module	Freq	ChNo	RPM	Update	Error	Cnt/Rev	ErrCode	Smpl		Avg		HC module measurements of frequency and revolution																				
DHCMEAS																																									
En																																									
Module	Freq																																								
ChNo	RPM																																								
Update	Error																																								
Cnt/Rev	ErrCode																																								
Smpl																																									
Avg																																									
1424	ADLOG	DADLOG	—	<table border="1"> <tr><td colspan="2">ADLOG</td><td colspan="2">DADLOG</td></tr> <tr><td>En</td><td></td><td>En</td><td></td></tr> <tr><td>Group</td><td>Datalog</td><td>Group</td><td>Datalog</td></tr> <tr><td>Module</td><td>CurNo</td><td>Module</td><td>CurNo</td></tr> <tr><td>ChNo</td><td>Cmplt</td><td>ChNo</td><td>Cmplt</td></tr> <tr><td>Mode</td><td>Error</td><td>Mode</td><td>Error</td></tr> <tr><td>Period</td><td>ErrCode</td><td>Period</td><td>ErrCode</td></tr> <tr><td>Points</td><td></td><td>Points</td><td></td></tr> <tr><td>Postrig</td><td></td><td>Postrig</td><td></td></tr> </table>	ADLOG		DADLOG		En		En		Group	Datalog	Group	Datalog	Module	CurNo	Module	CurNo	ChNo	Cmplt	ChNo	Cmplt	Mode	Error	Mode	Error	Period	ErrCode	Period	ErrCode	Points		Points		Postrig		Postrig		Record data of analog input module
ADLOG		DADLOG																																							
En		En																																							
Group	Datalog	Group	Datalog																																						
Module	CurNo	Module	CurNo																																						
ChNo	Cmplt	ChNo	Cmplt																																						
Mode	Error	Mode	Error																																						
Period	ErrCode	Period	ErrCode																																						
Points		Points																																							
Postrig		Postrig																																							
1425	ADPEAK	DADPEAK	—	<table border="1"> <tr><td colspan="2">ADPEAK</td><td colspan="2">DADPEAK</td></tr> <tr><td>En</td><td></td><td>En</td><td></td></tr> <tr><td>Group</td><td>MAX</td><td>Group</td><td>MAX</td></tr> <tr><td>Module</td><td>MIN</td><td>Module</td><td>MIN</td></tr> <tr><td>ChNo</td><td>Error</td><td>ChNo</td><td>Error</td></tr> <tr><td></td><td>ErrCode</td><td></td><td>ErrCode</td></tr> </table>	ADPEAK		DADPEAK		En		En		Group	MAX	Group	MAX	Module	MIN	Module	MIN	ChNo	Error	ChNo	Error		ErrCode		ErrCode	Record peak data of analog input module												
ADPEAK		DADPEAK																																							
En		En																																							
Group	MAX	Group	MAX																																						
Module	MIN	Module	MIN																																						
ChNo	Error	ChNo	Error																																						
	ErrCode		ErrCode																																						
1426	IOLINKR	—	—	<table border="1"> <tr><td colspan="2">IOLINKR</td></tr> <tr><td>En</td><td></td></tr> <tr><td>Group</td><td>Done</td></tr> <tr><td>Module</td><td>Error</td></tr> <tr><td>Port</td><td>ErrCode</td></tr> <tr><td>Index</td><td>ReadLen</td></tr> <tr><td>SubIndex</td><td>DataRead</td></tr> <tr><td>DataType</td><td></td></tr> </table>	IOLINKR		En		Group	Done	Module	Error	Port	ErrCode	Index	ReadLen	SubIndex	DataRead	DataType		Read the parameter from the O-Link device																				
IOLINKR																																									
En																																									
Group	Done																																								
Module	Error																																								
Port	ErrCode																																								
Index	ReadLen																																								
SubIndex	DataRead																																								
DataType																																									

3

API	Instruction code		Pulse instruction	Symbol	Function
	16-bit	32-bit			
1427	IOLINKW	—	—	<div style="border: 1px solid black; padding: 5px; width: fit-content;">           IOLINKW            En            Group Done            Module Error            Port ErrCode            Index            SubIndex            DataType            WriteLen            DataWrite         </div>	Write the parameter into the IO-Link device
1430	MLPF	—	—	<div style="border: 1px solid black; padding: 5px; width: fit-content;">           MLPF            En            Group Error            Module ErrCode            ChNo            Fcutoff         </div>	Digital low-pass filter for analog input signals

● Floating-point number instructions

API	Instruction code		Pulse instruction	Symbol		Function
	16-bit	32-bit				
1500	—	FSIN	✓	<div style="border: 1px solid black; padding: 2px; display: inline-block;">           FSIN            En            S D         </div>	<div style="border: 1px solid black; padding: 2px; display: inline-block;">           FSINP            En            S D         </div>	Sine of a floating-point number
1501	—	FCOS	✓	<div style="border: 1px solid black; padding: 2px; display: inline-block;">           FCOS            En            S D         </div>	<div style="border: 1px solid black; padding: 2px; display: inline-block;">           FCOSP            En            S D         </div>	Cosine of a floating-point number
1502	—	FTAN	✓	<div style="border: 1px solid black; padding: 2px; display: inline-block;">           FTAN            En            S D         </div>	<div style="border: 1px solid black; padding: 2px; display: inline-block;">           FTANP            En            S D         </div>	Tangent of a floating-point number
1503	—	FASIN	✓	<div style="border: 1px solid black; padding: 2px; display: inline-block;">           FASIN            En            S D         </div>	<div style="border: 1px solid black; padding: 2px; display: inline-block;">           FASINP            En            S D         </div>	Arcsine of a floating-point number
1504	—	FACOS	✓	<div style="border: 1px solid black; padding: 2px; display: inline-block;">           FACOS            En            S D         </div>	<div style="border: 1px solid black; padding: 2px; display: inline-block;">           FACOSP            En            S D         </div>	Arccosine of a floating-point number
1505	—	FATAN	✓	<div style="border: 1px solid black; padding: 2px; display: inline-block;">           FATAN            En            S D         </div>	<div style="border: 1px solid black; padding: 2px; display: inline-block;">           FATANP            En            S D         </div>	Arctangent of a floating-point number
1506	—	FSINH	✓	<div style="border: 1px solid black; padding: 2px; display: inline-block;">           FSINH            En            S D         </div>	<div style="border: 1px solid black; padding: 2px; display: inline-block;">           FSINHP            En            S D         </div>	Hyperbolic sine of a floating-point number
1507	—	FCOSH	✓	<div style="border: 1px solid black; padding: 2px; display: inline-block;">           FCOSH            En            S D         </div>	<div style="border: 1px solid black; padding: 2px; display: inline-block;">           FCOSH P            En            S D         </div>	Hyperbolic cosine of a floating-point number
1508	—	FTANH	✓	<div style="border: 1px solid black; padding: 2px; display: inline-block;">           FTANH            En            S D         </div>	<div style="border: 1px solid black; padding: 2px; display: inline-block;">           FTANHP            En            S D         </div>	Hyperbolic tangent of a floating-point number

API	Instruction code		Pulse instruction	Symbol		Function
	16-bit	32-bit				
1509	—	FRAD	✓			Converting from degrees to radians
1510	—	FDEG	✓			Converting from radians to degrees
1511	SQR	DSQR	✓	 	 	Square root of a binary number
1512	—	FSQR	✓			Square root of a floating-point number
1513	—	FEXP	✓			Exponent of a floating-point number
1514	—	FLOG	✓			Logarithm of a floating-point number
1515	—	FLN	✓			Natural logarithm of a binary floating-point number
1516	—	FPOW	✓			Raising a floating-point number to a power
1517	RAND	—	✓			Random number

● Real-time clock instructions

API	Instruction code		Pulse instruction	Symbol		Function
	16-bit	32-bit				
1600	TRD	—	✓			Reading the time
1601	TWR	—	✓			Writing the time
1602	T+	—	✓			Adding the time
1603	T-	—	✓			Subtracting the time
1604	HOUR	—	—			Running-time meter

API	Instruction code		Pulse instruction	Symbol	Function
	16-bit	32-bit			
1605	TCMP	—	✓		Comparing the time
1606	TZCP	—	✓		Time zone comparison
1607	DST	—	✓		Daylight saving time
1608	WWON	—	—		Weekly working time setup

● Peripheral instructions

API	Instruction code		Pulse instruction	Symbol	Function
	16-bit	32-bit			
1700	TKY	DTKY	—		Ten-key keypad
1701	HKY	DHKY	—		Sixteen-key keypad
1702	DSW	—	—		DIP switch
1703	ARWS	—	—		Arrow keys
1704	SEGL	—	—		Seven-segment display with latches

● Communication instructions

API	Instruction code		Pulse instruction	Symbol	Function
	16-bit	32-bit			
1806	LRC	—	—		Longitudinal parity check

API	Instruction code		Pulse instruction	Symbol	Function
	16-bit	32-bit			
1807	CRC	—	—		Cyclic redundancy check
1808	MODRW	—	—		Reading and Writing MODBUS data
1812	COMRS	—	—		Sending and receiving communication data
1813	COMDF	—	✓		Setting the communication format for a serial communication port
1814	VFDRW	—	—		Serial communication instruction, exclusively for Delta AC motor drive
1815	ASDRW	—	—		Serial communication instruction, exclusively for Delta servo drive
1816	CCONF	—	✓		Setting the parameters in the data exchange table for a communication port
1817	MODRWE	—	—		Reading and writing Modbus data without using any flags
1818	DNETRW	—	—		Reading and writing DeviceNet communication data
<u>1819</u>	CANRS	—	—		User-defined CAN communication sending and receiving

API	Instruction code		Pulse instruction	Symbol	Function																				
	16-bit	32-bit																							
1820	DMVSH	—	—	<table border="1"> <tr><td colspan="2">DMVSH</td></tr> <tr><td>En</td><td></td></tr> <tr><td>Mode</td><td>Shoot1</td></tr> <tr><td>Start1</td><td>Shoot2</td></tr> <tr><td>Start2</td><td>RdData</td></tr> <tr><td>Ready</td><td>Ok</td></tr> <tr><td>ComNo</td><td>Err</td></tr> <tr><td>Id_lp</td><td>ErrCode</td></tr> <tr><td>Address</td><td></td></tr> <tr><td>Length</td><td></td></tr> </table>	DMVSH		En		Mode	Shoot1	Start1	Shoot2	Start2	RdData	Ready	Ok	ComNo	Err	Id_lp	ErrCode	Address		Length		Enabling Delta DMV detection and communication
DMVSH																									
En																									
Mode	Shoot1																								
Start1	Shoot2																								
Start2	RdData																								
Ready	Ok																								
ComNo	Err																								
Id_lp	ErrCode																								
Address																									
Length																									
1821	DESO	—	—	<table border="1"> <tr><td colspan="2">DESO</td></tr> <tr><td>En</td><td></td></tr> <tr><td>ComNo</td><td>OK</td></tr> <tr><td>ListNo</td><td>Error</td></tr> <tr><td></td><td>ErrCode</td></tr> </table>	DESO		En		ComNo	OK	ListNo	Error		ErrCode	Execute the appointed communication number of the data exchange table once										
DESO																									
En																									
ComNo	OK																								
ListNo	Error																								
	ErrCode																								

● Other instructions

API	Instruction code		Pulse instruction	Symbol	Function																
	16-bit	32-bit																			
1900	WDT	—	✓	<table border="1"> <tr><td colspan="2">WDT</td></tr> <tr><td>En</td><td></td></tr> <tr><td colspan="2">WDT</td></tr> <tr><td>En</td><td></td></tr> </table>	WDT		En		WDT		En		Watchdog timer								
WDT																					
En																					
WDT																					
En																					
1901	DELAY	—	✓	<table border="1"> <tr><td colspan="2">DELAY</td></tr> <tr><td>En</td><td></td></tr> <tr><td>S</td><td></td></tr> <tr><td colspan="2">DELAYP</td></tr> <tr><td>En</td><td></td></tr> <tr><td>S</td><td></td></tr> </table>	DELAY		En		S		DELAYP		En		S		Delaying the execution of a program				
DELAY																					
En																					
S																					
DELAYP																					
En																					
S																					
1902	GPWM	—	—	<table border="1"> <tr><td colspan="2">GPWM</td></tr> <tr><td>En</td><td></td></tr> <tr><td>S1</td><td>S2</td></tr> <tr><td>S2</td><td></td></tr> </table>	GPWM		En		S1	S2	S2		General pulse width modulation								
GPWM																					
En																					
S1	S2																				
S2																					
1904	EPUSH	—	✓	<table border="1"> <tr><td colspan="2">EPUSH</td></tr> <tr><td>En</td><td></td></tr> <tr><td>D</td><td></td></tr> <tr><td colspan="2">EPUSHP</td></tr> <tr><td>En</td><td></td></tr> <tr><td>D</td><td></td></tr> </table>	EPUSH		En		D		EPUSHP		En		D		Storing the contents of the index registers				
EPUSH																					
En																					
D																					
EPUSHP																					
En																					
D																					
1905	EPOP	—	✓	<table border="1"> <tr><td colspan="2">EPOP</td></tr> <tr><td>En</td><td></td></tr> <tr><td>D</td><td></td></tr> <tr><td colspan="2">EPOPP</td></tr> <tr><td>En</td><td></td></tr> <tr><td>D</td><td></td></tr> </table>	EPOP		En		D		EPOPP		En		D		Reading data into the index registers				
EPOP																					
En																					
D																					
EPOPP																					
En																					
D																					
1906	INFO	—	✓	<table border="1"> <tr><td colspan="2">INFO</td></tr> <tr><td>En</td><td></td></tr> <tr><td>S</td><td></td></tr> <tr><td>D</td><td></td></tr> <tr><td colspan="2">INFOF</td></tr> <tr><td>En</td><td></td></tr> <tr><td>S</td><td></td></tr> <tr><td>D</td><td></td></tr> </table>	INFO		En		S		D		INFOF		En		S		D		Reading the system data
INFO																					
En																					
S																					
D																					
INFOF																					
En																					
S																					
D																					

● String processing instructions

API	Instruction code		Pulse instruction	Symbol	Function																								
	16-bit	32-bit																											
2100	BINDA	DBINDA	✓	<table border="1"> <tr><td colspan="2">BINDA</td></tr> <tr><td>En</td><td></td></tr> <tr><td>S</td><td>D</td></tr> <tr><td colspan="2">DBINDA</td></tr> <tr><td>En</td><td></td></tr> <tr><td>S</td><td>D</td></tr> <tr><td colspan="2">BINDAP</td></tr> <tr><td>En</td><td></td></tr> <tr><td>S</td><td>D</td></tr> <tr><td colspan="2">DBINDAP</td></tr> <tr><td>En</td><td></td></tr> <tr><td>S</td><td>D</td></tr> </table>	BINDA		En		S	D	DBINDA		En		S	D	BINDAP		En		S	D	DBINDAP		En		S	D	Converting a signed decimal number into ASCII code
BINDA																													
En																													
S	D																												
DBINDA																													
En																													
S	D																												
BINDAP																													
En																													
S	D																												
DBINDAP																													
En																													
S	D																												
2101	BINHA	DBINHA	✓	<table border="1"> <tr><td colspan="2">BINHA</td></tr> <tr><td>En</td><td></td></tr> <tr><td>S</td><td>D</td></tr> <tr><td colspan="2">DBINHA</td></tr> <tr><td>En</td><td></td></tr> <tr><td>S</td><td>D</td></tr> <tr><td colspan="2">BINHAP</td></tr> <tr><td>En</td><td></td></tr> <tr><td>S</td><td>D</td></tr> <tr><td colspan="2">DBINHAP</td></tr> <tr><td>En</td><td></td></tr> <tr><td>S</td><td>D</td></tr> </table>	BINHA		En		S	D	DBINHA		En		S	D	BINHAP		En		S	D	DBINHAP		En		S	D	Converting a binary hexadecimal number into hexadecimal ASCII code
BINHA																													
En																													
S	D																												
DBINHA																													
En																													
S	D																												
BINHAP																													
En																													
S	D																												
DBINHAP																													
En																													
S	D																												
2102	BCDDA	DBCDDA	✓	<table border="1"> <tr><td colspan="2">BCDDA</td></tr> <tr><td>En</td><td></td></tr> <tr><td>S</td><td>D</td></tr> <tr><td colspan="2">BCDDAP</td></tr> <tr><td>En</td><td></td></tr> <tr><td>S</td><td>D</td></tr> <tr><td colspan="2">DBCDDA</td></tr> <tr><td>En</td><td></td></tr> <tr><td>S</td><td>D</td></tr> <tr><td colspan="2">DBCDDAP</td></tr> <tr><td>En</td><td></td></tr> <tr><td>S</td><td>D</td></tr> </table>	BCDDA		En		S	D	BCDDAP		En		S	D	DBCDDA		En		S	D	DBCDDAP		En		S	D	Converting a binary-coded decimal number into ASCII code
BCDDA																													
En																													
S	D																												
BCDDAP																													
En																													
S	D																												
DBCDDA																													
En																													
S	D																												
DBCDDAP																													
En																													
S	D																												

API	Instruction code		Pulse instruction	Symbol		Function																													
	16-bit	32-bit																																	
2103	DABIN	DDABIN	✓	<table border="1"> <tr><td>En</td><td>DABIN</td><td>D</td></tr> <tr><td>S</td><td></td><td></td></tr> </table> <table border="1"> <tr><td>En</td><td>DABINP</td><td>D</td></tr> <tr><td>S</td><td></td><td></td></tr> </table> <table border="1"> <tr><td>En</td><td>DDABIN</td><td>D</td></tr> <tr><td>S</td><td></td><td></td></tr> </table> <table border="1"> <tr><td>En</td><td>DDABINP</td><td>D</td></tr> <tr><td>S</td><td></td><td></td></tr> </table>	En	DABIN	D	S			En	DABINP	D	S			En	DDABIN	D	S			En	DDABINP	D	S			Converting a signed decimal ASCII code into a signed decimal binary number						
En	DABIN	D																																	
S																																			
En	DABINP	D																																	
S																																			
En	DDABIN	D																																	
S																																			
En	DDABINP	D																																	
S																																			
2104	HABIN	DHABIN	✓	<table border="1"> <tr><td>En</td><td>HABIN</td><td>D</td></tr> <tr><td>S</td><td></td><td></td></tr> </table> <table border="1"> <tr><td>En</td><td>HABINP</td><td>D</td></tr> <tr><td>S</td><td></td><td></td></tr> </table> <table border="1"> <tr><td>En</td><td>DHABIN</td><td>D</td></tr> <tr><td>S</td><td></td><td></td></tr> </table> <table border="1"> <tr><td>En</td><td>DHABINP</td><td>D</td></tr> <tr><td>S</td><td></td><td></td></tr> </table>	En	HABIN	D	S			En	HABINP	D	S			En	DHABIN	D	S			En	DHABINP	D	S			Converting a hexadecimal ASCII code into a hexadecimal binary number						
En	HABIN	D																																	
S																																			
En	HABINP	D																																	
S																																			
En	DHABIN	D																																	
S																																			
En	DHABINP	D																																	
S																																			
2105	DABCD	DDABCD	✓	<table border="1"> <tr><td>En</td><td>DABCD</td><td>D</td></tr> <tr><td>S</td><td></td><td></td></tr> </table> <table border="1"> <tr><td>En</td><td>DABCDP</td><td>D</td></tr> <tr><td>S</td><td></td><td></td></tr> </table> <table border="1"> <tr><td>En</td><td>DDABCD</td><td>D</td></tr> <tr><td>S</td><td></td><td></td></tr> </table> <table border="1"> <tr><td>En</td><td>DDABCDP</td><td>D</td></tr> <tr><td>S</td><td></td><td></td></tr> </table>	En	DABCD	D	S			En	DABCDP	D	S			En	DDABCD	D	S			En	DDABCDP	D	S			Converting an ASCII code into a binary-coded decimal number						
En	DABCD	D																																	
S																																			
En	DABCDP	D																																	
S																																			
En	DDABCD	D																																	
S																																			
En	DDABCDP	D																																	
S																																			
2106	\$LEN	—	✓	<table border="1"> <tr><td>En</td><td>\$LEN</td><td>D</td></tr> <tr><td>S</td><td></td><td></td></tr> </table> <table border="1"> <tr><td>En</td><td>\$LENP</td><td>D</td></tr> <tr><td>S</td><td></td><td></td></tr> </table>	En	\$LEN	D	S			En	\$LENP	D	S			Calculating the length of a string																		
En	\$LEN	D																																	
S																																			
En	\$LENP	D																																	
S																																			
2109	\$FSTR	—	✓	<table border="1"> <tr><td>En</td><td>\$FSTR</td><td>D</td></tr> <tr><td>S1</td><td></td><td></td></tr> <tr><td>S2</td><td></td><td></td></tr> </table> <table border="1"> <tr><td>En</td><td>\$FSTRP</td><td>D</td></tr> <tr><td>S1</td><td></td><td></td></tr> <tr><td>S2</td><td></td><td></td></tr> </table>	En	\$FSTR	D	S1			S2			En	\$FSTRP	D	S1			S2			Converting a floating-point number into a string												
En	\$FSTR	D																																	
S1																																			
S2																																			
En	\$FSTRP	D																																	
S1																																			
S2																																			
2110	\$FVAL	—	✓	<table border="1"> <tr><td>En</td><td>\$FVAL</td><td>D</td></tr> <tr><td>S</td><td></td><td></td></tr> </table> <table border="1"> <tr><td>En</td><td>\$FVALP</td><td>D</td></tr> <tr><td>S</td><td></td><td></td></tr> </table>	En	\$FVAL	D	S			En	\$FVALP	D	S			Converting a string into a floating-point number																		
En	\$FVAL	D																																	
S																																			
En	\$FVALP	D																																	
S																																			
2111	\$RIGHT	—	✓	<table border="1"> <tr><td>En</td><td>\$RIGHT</td><td>D</td></tr> <tr><td>S</td><td></td><td></td></tr> <tr><td>n</td><td></td><td></td></tr> </table> <table border="1"> <tr><td>En</td><td>\$RIGHTP</td><td>D</td></tr> <tr><td>S</td><td></td><td></td></tr> <tr><td>n</td><td></td><td></td></tr> </table>	En	\$RIGHT	D	S			n			En	\$RIGHTP	D	S			n			Retrieving characters from a string begins from the right.												
En	\$RIGHT	D																																	
S																																			
n																																			
En	\$RIGHTP	D																																	
S																																			
n																																			
2112	\$LEFT	—	✓	<table border="1"> <tr><td>En</td><td>\$LEFT</td><td>D</td></tr> <tr><td>S</td><td></td><td></td></tr> <tr><td>n</td><td></td><td></td></tr> </table> <table border="1"> <tr><td>En</td><td>\$LEFTP</td><td>D</td></tr> <tr><td>S</td><td></td><td></td></tr> <tr><td>n</td><td></td><td></td></tr> </table>	En	\$LEFT	D	S			n			En	\$LEFTP	D	S			n			Retrieving characters from a string begins from the left.												
En	\$LEFT	D																																	
S																																			
n																																			
En	\$LEFTP	D																																	
S																																			
n																																			
2113	\$MIDR	—	✓	<table border="1"> <tr><td>En</td><td>\$MIDR</td><td>D</td></tr> <tr><td>S1</td><td></td><td></td></tr> <tr><td>S2</td><td></td><td></td></tr> </table> <table border="1"> <tr><td>En</td><td>\$MIDRP</td><td>D</td></tr> <tr><td>S1</td><td></td><td></td></tr> <tr><td>S2</td><td></td><td></td></tr> </table>	En	\$MIDR	D	S1			S2			En	\$MIDRP	D	S1			S2			Retrieving a part of a string												
En	\$MIDR	D																																	
S1																																			
S2																																			
En	\$MIDRP	D																																	
S1																																			
S2																																			
2115	\$SER	—	✓	<table border="1"> <tr><td>En</td><td>\$SER</td><td>D</td></tr> <tr><td>S1</td><td></td><td></td></tr> <tr><td>S2</td><td></td><td></td></tr> <tr><td>N</td><td></td><td></td></tr> </table> <table border="1"> <tr><td>En</td><td>\$SERP</td><td>D</td></tr> <tr><td>S1</td><td></td><td></td></tr> <tr><td>S2</td><td></td><td></td></tr> <tr><td>N</td><td></td><td></td></tr> </table>	En	\$SER	D	S1			S2			N			En	\$SERP	D	S1			S2			N			Searching a string						
En	\$SER	D																																	
S1																																			
S2																																			
N																																			
En	\$SERP	D																																	
S1																																			
S2																																			
N																																			
2116	\$RPLC	—	✓	<table border="1"> <tr><td>En</td><td>\$RPLC</td><td>D</td></tr> <tr><td>S1</td><td></td><td></td></tr> <tr><td>S2</td><td></td><td></td></tr> <tr><td>S3</td><td></td><td></td></tr> <tr><td>S4</td><td></td><td></td></tr> </table> <table border="1"> <tr><td>En</td><td>\$RPLCP</td><td>D</td></tr> <tr><td>S1</td><td></td><td></td></tr> <tr><td>S2</td><td></td><td></td></tr> <tr><td>S3</td><td></td><td></td></tr> <tr><td>S4</td><td></td><td></td></tr> </table>	En	\$RPLC	D	S1			S2			S3			S4			En	\$RPLCP	D	S1			S2			S3			S4			Replacing the characters in a string
En	\$RPLC	D																																	
S1																																			
S2																																			
S3																																			
S4																																			
En	\$RPLCP	D																																	
S1																																			
S2																																			
S3																																			
S4																																			
2117	\$DEL	—	✓	<table border="1"> <tr><td>En</td><td>\$DEL</td><td>D</td></tr> <tr><td>S1</td><td></td><td></td></tr> <tr><td>S2</td><td></td><td></td></tr> <tr><td>S3</td><td></td><td></td></tr> </table> <table border="1"> <tr><td>En</td><td>\$DELP</td><td>D</td></tr> <tr><td>S1</td><td></td><td></td></tr> <tr><td>S2</td><td></td><td></td></tr> <tr><td>S3</td><td></td><td></td></tr> </table>	En	\$DEL	D	S1			S2			S3			En	\$DELP	D	S1			S2			S3			Deleting the characters in a string						
En	\$DEL	D																																	
S1																																			
S2																																			
S3																																			
En	\$DELP	D																																	
S1																																			
S2																																			
S3																																			
2118	\$CLR	—	✓	<table border="1"> <tr><td>En</td><td>\$CLR</td><td>D</td></tr> <tr><td>S</td><td></td><td></td></tr> </table> <table border="1"> <tr><td>En</td><td>\$CLRP</td><td>D</td></tr> <tr><td>S</td><td></td><td></td></tr> </table>	En	\$CLR	D	S			En	\$CLRP	D	S			Clearing a string																		
En	\$CLR	D																																	
S																																			
En	\$CLRP	D																																	
S																																			
2119	\$INS	—	✓	<table border="1"> <tr><td>En</td><td>\$INS</td><td>D</td></tr> <tr><td>S1</td><td></td><td></td></tr> <tr><td>S2</td><td></td><td></td></tr> <tr><td>S3</td><td></td><td></td></tr> </table> <table border="1"> <tr><td>En</td><td>\$INSP</td><td>D</td></tr> <tr><td>S1</td><td></td><td></td></tr> <tr><td>S2</td><td></td><td></td></tr> <tr><td>S3</td><td></td><td></td></tr> </table>	En	\$INS	D	S1			S2			S3			En	\$INSP	D	S1			S2			S3			Inserting a string						
En	\$INS	D																																	
S1																																			
S2																																			
S3																																			
En	\$INSP	D																																	
S1																																			
S2																																			
S3																																			
2122	SPLIT	—	✓	<table border="1"> <tr><td>En</td><td>SPLIT</td><td>D1</td></tr> <tr><td>S1</td><td></td><td></td></tr> <tr><td>S2</td><td></td><td>D2</td></tr> <tr><td>S3</td><td></td><td></td></tr> <tr><td>S4</td><td></td><td></td></tr> </table> <table border="1"> <tr><td>En</td><td>SPLITP</td><td>D1</td></tr> <tr><td>S1</td><td></td><td></td></tr> <tr><td>S2</td><td></td><td>D2</td></tr> <tr><td>S3</td><td></td><td></td></tr> <tr><td>S4</td><td></td><td></td></tr> </table>	En	SPLIT	D1	S1			S2		D2	S3			S4			En	SPLITP	D1	S1			S2		D2	S3			S4			Splitting a string
En	SPLIT	D1																																	
S1																																			
S2		D2																																	
S3																																			
S4																																			
En	SPLITP	D1																																	
S1																																			
S2		D2																																	
S3																																			
S4																																			
2123	MERGE	—	✓	<table border="1"> <tr><td>En</td><td>MERGE</td><td>D1</td></tr> <tr><td>S1</td><td></td><td></td></tr> <tr><td>S2</td><td></td><td>D2</td></tr> <tr><td>S3</td><td></td><td></td></tr> </table> <table border="1"> <tr><td>En</td><td>MERGE P</td><td>D1</td></tr> <tr><td>S1</td><td></td><td></td></tr> <tr><td>S2</td><td></td><td>D2</td></tr> <tr><td>S3</td><td></td><td></td></tr> </table>	En	MERGE	D1	S1			S2		D2	S3			En	MERGE P	D1	S1			S2		D2	S3			Merging a string						
En	MERGE	D1																																	
S1																																			
S2		D2																																	
S3																																			
En	MERGE P	D1																																	
S1																																			
S2		D2																																	
S3																																			






● Ethernet instructions

API	Instruction code		Pulse instruction	Symbol		Function																																																								
	16-bit	32-bit																																																												
2200	SOPEN	—	✓	<table border="1"> <tr><td colspan="2">SOPEN</td></tr> <tr><td>En</td><td></td></tr> <tr><td>S1</td><td></td></tr> <tr><td>S2</td><td></td></tr> <tr><td>S3</td><td></td></tr> </table>	SOPEN		En		S1		S2		S3		<table border="1"> <tr><td colspan="2">SOPENP</td></tr> <tr><td>En</td><td></td></tr> <tr><td>S1</td><td></td></tr> <tr><td>S2</td><td></td></tr> <tr><td>S3</td><td></td></tr> </table>	SOPENP		En		S1		S2		S3		Opening a socket																																				
SOPEN																																																														
En																																																														
S1																																																														
S2																																																														
S3																																																														
SOPENP																																																														
En																																																														
S1																																																														
S2																																																														
S3																																																														
2201	SSEND	—	✓	<table border="1"> <tr><td colspan="2">SSEND</td></tr> <tr><td>En</td><td></td></tr> <tr><td>S1</td><td></td></tr> <tr><td>S2</td><td></td></tr> </table>	SSEND		En		S1		S2		<table border="1"> <tr><td colspan="2">SSENDP</td></tr> <tr><td>En</td><td></td></tr> <tr><td>S1</td><td></td></tr> <tr><td>S2</td><td></td></tr> </table>	SSENDP		En		S1		S2		Sending data through the socket																																								
SSEND																																																														
En																																																														
S1																																																														
S2																																																														
SSENDP																																																														
En																																																														
S1																																																														
S2																																																														
2203	SCLOSE	—	✓	<table border="1"> <tr><td colspan="2">SCLOSE</td></tr> <tr><td>En</td><td></td></tr> <tr><td>S1</td><td></td></tr> <tr><td>S2</td><td></td></tr> </table>	SCLOSE		En		S1		S2		<table border="1"> <tr><td colspan="2">SCLOSEP</td></tr> <tr><td>En</td><td></td></tr> <tr><td>S1</td><td></td></tr> <tr><td>S2</td><td></td></tr> </table>	SCLOSEP		En		S1		S2		Closing a socket																																								
SCLOSE																																																														
En																																																														
S1																																																														
S2																																																														
SCLOSEP																																																														
En																																																														
S1																																																														
S2																																																														
2204	MSEND	—	✓	<table border="1"> <tr><td colspan="2">MSEND</td></tr> <tr><td>En</td><td></td></tr> <tr><td>S1</td><td>D</td></tr> <tr><td>S2</td><td></td></tr> <tr><td>S3</td><td></td></tr> </table>	MSEND		En		S1	D	S2		S3		<table border="1"> <tr><td colspan="2">MSENDP</td></tr> <tr><td>En</td><td></td></tr> <tr><td>S1</td><td>D</td></tr> <tr><td>S2</td><td></td></tr> <tr><td>S3</td><td></td></tr> </table>	MSENDP		En		S1	D	S2		S3		Sending an email																																				
MSEND																																																														
En																																																														
S1	D																																																													
S2																																																														
S3																																																														
MSENDP																																																														
En																																																														
S1	D																																																													
S2																																																														
S3																																																														
2206	INTOA	—	✓	<table border="1"> <tr><td colspan="2">INTOA</td></tr> <tr><td>En</td><td></td></tr> <tr><td>S</td><td>D</td></tr> </table>	INTOA		En		S	D	<table border="1"> <tr><td colspan="2">INTOAP</td></tr> <tr><td>En</td><td></td></tr> <tr><td>S</td><td>D</td></tr> </table>	INTOAP		En		S	D	Converting an IP address of the integer type into an IP address of the string type																																												
INTOA																																																														
En																																																														
S	D																																																													
INTOAP																																																														
En																																																														
S	D																																																													
2207	IATON	—	✓	<table border="1"> <tr><td colspan="2">IATON</td></tr> <tr><td>En</td><td></td></tr> <tr><td>S</td><td>D</td></tr> </table>	IATON		En		S	D	<table border="1"> <tr><td colspan="2">IATONP</td></tr> <tr><td>En</td><td></td></tr> <tr><td>S</td><td>D</td></tr> </table>	IATONP		En		S	D	Converting an IP address of the string type into an IP address of the integer type																																												
IATON																																																														
En																																																														
S	D																																																													
IATONP																																																														
En																																																														
S	D																																																													
2208	EIPRW	—	—	<table border="1"> <tr><td colspan="2">EIPRW</td></tr> <tr><td>En</td><td></td></tr> <tr><td>S1</td><td>D1</td></tr> <tr><td>S2</td><td>D2</td></tr> <tr><td>S3</td><td></td></tr> <tr><td>S4</td><td></td></tr> <tr><td>S5</td><td></td></tr> <tr><td>S6</td><td></td></tr> <tr><td>S7</td><td></td></tr> <tr><td>n</td><td></td></tr> <tr><td>S</td><td></td></tr> </table>	EIPRW		En		S1	D1	S2	D2	S3		S4		S5		S6		S7		n		S			Reading and writing EtherNet/IP data																																		
EIPRW																																																														
En																																																														
S1	D1																																																													
S2	D2																																																													
S3																																																														
S4																																																														
S5																																																														
S6																																																														
S7																																																														
n																																																														
S																																																														
2209	SCONF	—	✓	<table border="1"> <tr><td colspan="2">SCONF</td></tr> <tr><td>En</td><td></td></tr> <tr><td>S1</td><td></td></tr> <tr><td>S2</td><td></td></tr> <tr><td>S3</td><td></td></tr> <tr><td>S4</td><td></td></tr> <tr><td>S5</td><td></td></tr> <tr><td>S6</td><td></td></tr> <tr><td>S7</td><td></td></tr> <tr><td>S8</td><td></td></tr> <tr><td>S9</td><td></td></tr> <tr><td>S10</td><td></td></tr> </table>	SCONF		En		S1		S2		S3		S4		S5		S6		S7		S8		S9		S10		<table border="1"> <tr><td colspan="2">SCONFP</td></tr> <tr><td>En</td><td></td></tr> <tr><td>S1</td><td></td></tr> <tr><td>S2</td><td></td></tr> <tr><td>S3</td><td></td></tr> <tr><td>S4</td><td></td></tr> <tr><td>S5</td><td></td></tr> <tr><td>S6</td><td></td></tr> <tr><td>S7</td><td></td></tr> <tr><td>S8</td><td></td></tr> <tr><td>S9</td><td></td></tr> <tr><td>S10</td><td></td></tr> </table>	SCONFP		En		S1		S2		S3		S4		S5		S6		S7		S8		S9		S10		Setting TCP/UDP socket parameters								
SCONF																																																														
En																																																														
S1																																																														
S2																																																														
S3																																																														
S4																																																														
S5																																																														
S6																																																														
S7																																																														
S8																																																														
S9																																																														
S10																																																														
SCONFP																																																														
En																																																														
S1																																																														
S2																																																														
S3																																																														
S4																																																														
S5																																																														
S6																																																														
S7																																																														
S8																																																														
S9																																																														
S10																																																														
2210	MCONF	—	✓	<table border="1"> <tr><td colspan="2">MCONF</td></tr> <tr><td>En</td><td></td></tr> <tr><td>S1</td><td></td></tr> <tr><td>S2</td><td></td></tr> <tr><td>S3</td><td></td></tr> <tr><td>S4</td><td></td></tr> <tr><td>S5</td><td></td></tr> <tr><td>S6</td><td></td></tr> <tr><td>S7</td><td></td></tr> <tr><td>S8</td><td></td></tr> <tr><td>S9</td><td></td></tr> <tr><td>S10</td><td></td></tr> <tr><td>S11</td><td></td></tr> <tr><td>S12</td><td></td></tr> </table>	MCONF		En		S1		S2		S3		S4		S5		S6		S7		S8		S9		S10		S11		S12		<table border="1"> <tr><td colspan="2">MCONF</td></tr> <tr><td>En</td><td></td></tr> <tr><td>S1</td><td></td></tr> <tr><td>S2</td><td></td></tr> <tr><td>S3</td><td></td></tr> <tr><td>S4</td><td></td></tr> <tr><td>S5</td><td></td></tr> <tr><td>S6</td><td></td></tr> <tr><td>S7</td><td></td></tr> <tr><td>S8</td><td></td></tr> <tr><td>S9</td><td></td></tr> <tr><td>S10</td><td></td></tr> <tr><td>S11</td><td></td></tr> <tr><td>S12</td><td></td></tr> </table>	MCONF		En		S1		S2		S3		S4		S5		S6		S7		S8		S9		S10		S11		S12		Reading/Writing Modbus TCP data
MCONF																																																														
En																																																														
S1																																																														
S2																																																														
S3																																																														
S4																																																														
S5																																																														
S6																																																														
S7																																																														
S8																																																														
S9																																																														
S10																																																														
S11																																																														
S12																																																														
MCONF																																																														
En																																																														
S1																																																														
S2																																																														
S3																																																														
S4																																																														
S5																																																														
S6																																																														
S7																																																														
S8																																																														
S9																																																														
S10																																																														
S11																																																														
S12																																																														
2211	EMCONF1	—	□	<table border="1"> <tr><td colspan="2">EMCONF1</td></tr> <tr><td>En</td><td></td></tr> <tr><td>Server</td><td></td></tr> <tr><td>Port</td><td></td></tr> <tr><td>LMail</td><td></td></tr> <tr><td>Sub</td><td></td></tr> <tr><td>Verify</td><td></td></tr> <tr><td>User</td><td></td></tr> <tr><td>Passw</td><td></td></tr> </table>	EMCONF1		En		Server		Port		LMail		Sub		Verify		User		Passw		<table border="1"> <tr><td colspan="2">EMCONF1P</td></tr> <tr><td>En</td><td></td></tr> <tr><td>Server</td><td></td></tr> <tr><td>Port</td><td></td></tr> <tr><td>LMail</td><td></td></tr> <tr><td>Sub</td><td></td></tr> <tr><td>Verify</td><td></td></tr> <tr><td>User</td><td></td></tr> <tr><td>Passw</td><td></td></tr> </table>	EMCONF1P		En		Server		Port		LMail		Sub		Verify		User		Passw		Setting email server parameter values																				
EMCONF1																																																														
En																																																														
Server																																																														
Port																																																														
LMail																																																														
Sub																																																														
Verify																																																														
User																																																														
Passw																																																														
EMCONF1P																																																														
En																																																														
Server																																																														
Port																																																														
LMail																																																														
Sub																																																														
Verify																																																														
User																																																														
Passw																																																														


API	Instruction code		Pulse instruction	Symbol	Function															
	16-bit	32-bit																		
2212	EMCONF2	—	✓	<table border="1"> <tr> <td>EMCONF2</td> <td>EMCONF2P</td> </tr> <tr> <td>En</td> <td>En</td> </tr> <tr> <td>Index</td> <td>Index</td> </tr> <tr> <td>Mail</td> <td>Mail</td> </tr> </table>	EMCONF2	EMCONF2P	En	En	Index	Index	Mail	Mail	Setting email address							
EMCONF2	EMCONF2P																			
En	En																			
Index	Index																			
Mail	Mail																			
2214	—	MQTT_Connect	—	<table border="1"> <tr> <td>MQTT_Connect</td> </tr> <tr> <td>En</td> </tr> <tr> <td>Execute</td> <td>Status</td> </tr> <tr> <td>SID</td> </tr> <tr> <td>BrokenN-</td> </tr> <tr> <td>ClientID</td> </tr> <tr> <td>ClearSes-</td> </tr> <tr> <td>WillTopic</td> </tr> <tr> <td>WillMes-</td> </tr> <tr> <td>WillResa-</td> </tr> <tr> <td>WillQce</td> </tr> <tr> <td>WillFlag</td> </tr> <tr> <td>KeepAli-</td> </tr> </table>	MQTT_Connect	En	Execute	Status	SID	BrokenN-	ClientID	ClearSes-	WillTopic	WillMes-	WillResa-	WillQce	WillFlag	KeepAli-	Establishing a MQTT connection	
MQTT_Connect																				
En																				
Execute	Status																			
SID																				
BrokenN-																				
ClientID																				
ClearSes-																				
WillTopic																				
WillMes-																				
WillResa-																				
WillQce																				
WillFlag																				
KeepAli-																				
2215	MQTT_Publish	—	—	<table border="1"> <tr> <td>MQTT_Publish</td> </tr> <tr> <td>En</td> </tr> <tr> <td>Execute</td> <td>Done</td> </tr> <tr> <td>SID</td> <td>Busy</td> </tr> <tr> <td>BrokenN-</td> <td>Error</td> </tr> <tr> <td>Topic</td> <td>ErrCode</td> </tr> <tr> <td>Message</td> </tr> <tr> <td>Size</td> </tr> <tr> <td>Qce</td> </tr> <tr> <td>Retain</td> </tr> <tr> <td>Dup</td> </tr> </table>	MQTT_Publish	En	Execute	Done	SID	Busy	BrokenN-	Error	Topic	ErrCode	Message	Size	Qce	Retain	Dup	Publishing a MQTT message
MQTT_Publish																				
En																				
Execute	Done																			
SID	Busy																			
BrokenN-	Error																			
Topic	ErrCode																			
Message																				
Size																				
Qce																				
Retain																				
Dup																				
2216	MQTT_Subscribe	—	—	<table border="1"> <tr> <td>MQTT_Subscribe</td> </tr> <tr> <td>En</td> </tr> <tr> <td>Execute</td> <td>Status</td> </tr> <tr> <td>SID</td> <td>Message</td> </tr> <tr> <td>BrokenN-</td> <td>RecvTop-</td> </tr> <tr> <td>Topic</td> </tr> <tr> <td>Qce</td> </tr> </table>	MQTT_Subscribe	En	Execute	Status	SID	Message	BrokenN-	RecvTop-	Topic	Qce	Subscribing to a MQTT topic					
MQTT_Subscribe																				
En																				
Execute	Status																			
SID	Message																			
BrokenN-	RecvTop-																			
Topic																				
Qce																				

● Memory card / File register instructions



API	Instruction code		Pulse instruction	Symbol	Function																
	16-bit	32-bit																			
2300	MWRIT	—	✓	<table border="1"> <tr> <td>MWRIT</td> <td>MWRITP</td> </tr> <tr> <td>En</td> <td>En</td> </tr> <tr> <td>C</td> <td>C</td> </tr> <tr> <td>S</td> <td>S</td> </tr> <tr> <td>S1</td> <td>S1</td> </tr> <tr> <td>S2</td> <td>S2</td> </tr> <tr> <td>S3</td> <td>S3</td> </tr> <tr> <td>S4</td> <td>S4</td> </tr> </table>	MWRIT	MWRITP	En	En	C	C	S	S	S1	S1	S2	S2	S3	S3	S4	S4	Writing data from the PLC into a memory card
MWRIT	MWRITP																				
En	En																				
C	C																				
S	S																				
S1	S1																				
S2	S2																				
S3	S3																				
S4	S4																				

API	Instruction code		Pulse instruction	Symbol	Function
	16-bit	32-bit			
2301	MREAD	—	✓		Reading data from the memory card into the PLC
2302	MTWRIT	—	✓		Writing a string into the memory card
2303	MEMW	—	✓		Writing data into the file register
2304	MDEL	—	✓		Deleting files on the memory card
2305	Record_trigger	—	—		Recording and writing data into a file

- Task control instructions














API	Instruction code		Pulse instruction	Symbol	Function
	16-bit	32-bit			
2400	TKON	—	✓		Enabling a cyclic task
2401	TKOFF	—	✓		Disabling a cyclic task

- Sequential function charts (SFC) instructions

API	Instruction code		Pulse instruction	Symbol	Function
	16-bit	32-bit			
2500	SFCRUN	—	—		Enabling SFC
2501	SFCPSE	—	—		Pausing SFC
2502	SFCSTP	—	—		Stopping SFC

- High-speed output instructions

API	Instruction code		Pulse instruction	Symbol	Function
	16-bit	32-bit			
2700	—	DPLSY	—		High-speed pulse output (without ramp-up/down process)

API	Instruction code		Pulse instruction	Symbol	Function
	16-bit	32-bit			
2701	–	DPLSR	–		High-speed pulse output (with ramp-up/down process)
2702	PWM	DPWM	–		Pulse width modulation
2703	JOG	DJOG	–		JOG output
2704	–	DZRN	–		Zero return
2705	–	DPLSV	–		Adjustable pulse output
2706	–	DDRVI	–		Relative position control
2707	–	DDRVA	–		Absolute position control
2708	CSFO	–	–		Catch speed and proportional output
2709	–	DDRVM	–		Mark alignment positioning
2710	–	DPPMR	–		2-Axis relative-coordinate point-to-point synchronized motion
2711	–	DPPMA	–		2-Axis absolute-coordinate point-to-point synchronized motion
2712	–	DCICR	–		2-Axis relative-position clockwise arc interpolation
2713	–	DCICA	–		2-Axis absolute-position clockwise arc interpolation
2714	–	DCICCR	–		2-Axis relative-position counterclockwise arc interpolation

API	Instruction code		Pulse instruction	Symbol	Function																												
	16-bit	32-bit																															
2715	–	DCICCA	–	<table border="1"> <tr><td colspan="2">DCICCA</td></tr> <tr><td>En</td><td></td></tr> <tr><td>S1</td><td>D1</td></tr> <tr><td>S2</td><td>D2</td></tr> <tr><td>S3</td><td></td></tr> <tr><td>S4</td><td></td></tr> <tr><td>S5</td><td></td></tr> </table>	DCICCA		En		S1	D1	S2	D2	S3		S4		S5		2-Axis absolute-position counterclockwise arc interpolation														
DCICCA																																	
En																																	
S1	D1																																
S2	D2																																
S3																																	
S4																																	
S5																																	
2716	–	DCCMR	–	<table border="1"> <tr><td colspan="2">DCCMR</td></tr> <tr><td>En</td><td></td></tr> <tr><td>S1</td><td>D1</td></tr> <tr><td>S2</td><td>D2</td></tr> <tr><td>S3</td><td></td></tr> <tr><td>S4</td><td></td></tr> </table>	DCCMR		En		S1	D1	S2	D2	S3		S4		Relative-position circle drawing																
DCCMR																																	
En																																	
S1	D1																																
S2	D2																																
S3																																	
S4																																	
2717	–	DCCMA	–	<table border="1"> <tr><td colspan="2">DCCMA</td></tr> <tr><td>En</td><td></td></tr> <tr><td>S1</td><td>D1</td></tr> <tr><td>S2</td><td>D2</td></tr> <tr><td>S3</td><td></td></tr> <tr><td>S4</td><td></td></tr> </table>	DCCMA		En		S1	D1	S2	D2	S3		S4		Absolute-position circle drawing																
DCCMA																																	
En																																	
S1	D1																																
S2	D2																																
S3																																	
S4																																	
2718	TPO	–	–	<table border="1"> <tr><td colspan="2">TPO</td></tr> <tr><td>En</td><td></td></tr> <tr><td>S</td><td>D1</td></tr> <tr><td></td><td>D2</td></tr> </table>	TPO		En		S	D1		D2	The position planning table controls the output																				
TPO																																	
En																																	
S	D1																																
	D2																																
2719	–	DTPWS	✓	<table border="1"> <tr><td colspan="2">DTPWS</td></tr> <tr><td>En</td><td></td></tr> <tr><td>S1</td><td></td></tr> <tr><td>S2</td><td></td></tr> <tr><td>S3</td><td></td></tr> </table> <table border="1"> <tr><td colspan="2">DTPWSP</td></tr> <tr><td>En</td><td></td></tr> <tr><td>S1</td><td></td></tr> <tr><td>S2</td><td></td></tr> <tr><td>S3</td><td></td></tr> </table>	DTPWS		En		S1		S2		S3		DTPWSP		En		S1		S2		S3		Setting single-axis output parameters in the position planning table								
DTPWS																																	
En																																	
S1																																	
S2																																	
S3																																	
DTPWSP																																	
En																																	
S1																																	
S2																																	
S3																																	
2720	–	DTPWL	✓	<table border="1"> <tr><td colspan="2">DTPWL</td></tr> <tr><td>En</td><td></td></tr> <tr><td>S1</td><td></td></tr> <tr><td>S2</td><td></td></tr> <tr><td>S3</td><td></td></tr> <tr><td>S4</td><td></td></tr> </table> <table border="1"> <tr><td colspan="2">DTPWLP</td></tr> <tr><td>En</td><td></td></tr> <tr><td>S1</td><td></td></tr> <tr><td>S2</td><td></td></tr> <tr><td>S3</td><td></td></tr> <tr><td>S4</td><td></td></tr> </table>	DTPWL		En		S1		S2		S3		S4		DTPWLP		En		S1		S2		S3		S4		Setting linear interpolation parameters in the position planning table				
DTPWL																																	
En																																	
S1																																	
S2																																	
S3																																	
S4																																	
DTPWLP																																	
En																																	
S1																																	
S2																																	
S3																																	
S4																																	
2721	–	DPTWC	✓	<table border="1"> <tr><td colspan="2">DPTWC</td></tr> <tr><td>En</td><td></td></tr> <tr><td>S1</td><td></td></tr> <tr><td>S2</td><td></td></tr> <tr><td>S3</td><td></td></tr> <tr><td>S4</td><td></td></tr> <tr><td>S5</td><td></td></tr> </table> <table border="1"> <tr><td colspan="2">DTPWCP</td></tr> <tr><td>En</td><td></td></tr> <tr><td>S1</td><td></td></tr> <tr><td>S2</td><td></td></tr> <tr><td>S3</td><td></td></tr> <tr><td>S4</td><td></td></tr> <tr><td>S5</td><td></td></tr> </table>	DPTWC		En		S1		S2		S3		S4		S5		DTPWCP		En		S1		S2		S3		S4		S5		Setting arc interpolation parameters in the position planning table
DPTWC																																	
En																																	
S1																																	
S2																																	
S3																																	
S4																																	
S5																																	
DTPWCP																																	
En																																	
S1																																	
S2																																	
S3																																	
S4																																	
S5																																	
2723	–	DPPGB	–	<table border="1"> <tr><td colspan="2">DPPGB</td></tr> <tr><td>En</td><td></td></tr> <tr><td>S1</td><td>D1</td></tr> <tr><td>S2</td><td>D2</td></tr> <tr><td>S3</td><td></td></tr> <tr><td>S4</td><td></td></tr> </table>	DPPGB		En		S1	D1	S2	D2	S3		S4		Point to point go back and forth																
DPPGB																																	
En																																	
S1	D1																																
S2	D2																																
S3																																	
S4																																	
2724	–	DZRN2	–	<table border="1"> <tr><td colspan="2">DZRN2</td></tr> <tr><td>En</td><td></td></tr> <tr><td>TFreq</td><td>Pulse</td></tr> <tr><td>JFreq</td><td>Dir</td></tr> <tr><td>Mode</td><td></td></tr> <tr><td>DOG</td><td></td></tr> <tr><td>NL</td><td></td></tr> </table>	DZRN2		En		TFreq	Pulse	JFreq	Dir	Mode		DOG		NL		Zero return 2 (output direction can be set)														
DZRN2																																	
En																																	
TFreq	Pulse																																
JFreq	Dir																																
Mode																																	
DOG																																	
NL																																	

● Delta Special CANopen / EtherCAT Communication Instructions

API	Instruction code		Pulse instruction	Symbol	Function										
	16-bit	32-bit													
2800	INITC	–	–	<table border="1"> <tr><td colspan="2">INITC</td></tr> <tr><td>En</td><td></td></tr> <tr><td>S</td><td></td></tr> </table>	INITC		En		S		Initializing the servo for CANopen communication				
INITC															
En															
S															
2801	ASDON	–	–	<table border="1"> <tr><td colspan="2">ASDON</td></tr> <tr><td>En</td><td></td></tr> <tr><td>S1</td><td></td></tr> <tr><td>S2</td><td></td></tr> </table>	ASDON		En		S1		S2		Servo-ON and Servo-OFF		
ASDON															
En															
S1															
S2															
2802	CASD	–	–	<table border="1"> <tr><td colspan="2">CASD</td></tr> <tr><td>En</td><td></td></tr> <tr><td>S1</td><td></td></tr> <tr><td>S2</td><td></td></tr> <tr><td>S3</td><td></td></tr> </table>	CASD		En		S1		S2		S3		Setting the acceleration time and deceleration time for a servo
CASD															
En															
S1															
S2															
S3															
2803	–	DDRVIC	–	<table border="1"> <tr><td colspan="2">DDRVIC</td></tr> <tr><td>En</td><td></td></tr> <tr><td>S1</td><td></td></tr> <tr><td>S2</td><td></td></tr> <tr><td>S3</td><td></td></tr> </table>	DDRVIC		En		S1		S2		S3		Servo relative position control
DDRVIC															
En															
S1															
S2															
S3															

API	Instruction code		Pulse instruction	Symbol	Function
	16-bit	32-bit			
2804	–	DDRVAC	–	<div style="border: 1px solid black; padding: 2px;">                     DDRVAC                      En                      S1                      S2                      S3                 </div>	Servo absolute position control
2805	–	DPLSVC	–	<div style="border: 1px solid black; padding: 2px;">                     DPLSVC                      En                      S1                      S2                 </div>	Servo speed control
2806	ZRNC	DZRNC	–	<div style="display: flex; justify-content: space-around;"> <div style="border: 1px solid black; padding: 2px;">                     ZRNC                      En                      S1                      S2                      S3                 </div> <div style="border: 1px solid black; padding: 2px;">                     DZRNC                      En                      S1                      S2                      S3                 </div> </div>	Servo homing
2807	COPRW	–	–	<div style="border: 1px solid black; padding: 2px;">                     COPRW                      En                      S1                      S2                      S3                      S4                      S5                      D                 </div>	Reading and writing CANopen communication data
2808	COPWL	DCOPWL	–	<div style="display: flex; justify-content: space-around;"> <div style="border: 1px solid black; padding: 2px;">                     COPWL                      En                      S1                      S2                      S3                      D                 </div> <div style="border: 1px solid black; padding: 2px;">                     DCOPWL                      En                      S1                      S2                      S3                      D                 </div> </div>	Writing multiple CANopen parameter values
2809	RSTD	–	–	<div style="border: 1px solid black; padding: 2px;">                     RSTD                      En                      Node                      Para                      Ok                      Err                 </div>	Sending Reset or NMT command
2810	ZRNM	–	–	<div style="border: 1px solid black; padding: 2px;">                     ZRNM                      En                      Node                      Mode                      Ok                      Err                 </div>	Setting the homing mode for Delta servo
2811	EMER	–	–	<div style="border: 1px solid black; padding: 2px;">                     EMER                      En                      Node                      Dest                      Len                      Ok                      Err                 </div>	Reading Emergency message
2812	–	DCSFOC	–	<div style="border: 1px solid black; padding: 2px;">                     DCSFOC                      En                      Xno                      InCnt                      InSpd                      Gear                      Axis                      OutCnt                      OutSpd                 </div>	Controlling the tracking function of a servo via communication
2813	ECAMD	–	–	<div style="border: 1px solid black; padding: 2px;">                     ECAMD                      En                      Slave                      Source                      Len                      CAddr                      Done                      Err                      ErrCode                 </div>	Downloading E-CAM chart to the Slave
2814	–	DECAMS	–	<div style="border: 1px solid black; padding: 2px;">                     DECAMS                      En                      Slave                      Smode                      CAddr                      CLen                      Rpuu                      Cmode                      WbPuu                      OutT                      CaPuu                      CwPuu                      Orate                      Done                      Err                      ErrCode                 </div>	E-CAM parameter setting and planning
2815	ECAMA	–	–	<div style="border: 1px solid black; padding: 2px;">                     ECAMA                      En                      Slave                      CAMEn                      CAMSt                      MIPuu                      SOPuu                      Err                      ErrCode                 </div>	Activating E-CAM control and displaying the status
2816	ECAMC	–	–	<div style="border: 1px solid black; padding: 2px;">                     ECAMC                      En                      Slave                      CAddr                      CLen                      Done                      Err                      ErrCode                 </div>	Modifying the starting address for E-CAM chart and the E-CAM chart length in the servo

API	Instruction code		Pulse instruction	Symbol	Function
	16-bit	32-bit			
2817	—	DTQC	—	DTQC En Node CurTQ TarTQ Reach Lspeed Err	Torque control
2818	—	DTQLC	—	DTQLC En Node CurTQ TarSpd Reach LimitTQ Err	Speed of torque control
2820	INITEC	—	—	INITEC En SlaveN- Done Stype Enou ErrCode	Initializing the slaves for EtherCAT communication
2821	ECATRW	—	—	ECATRW En Slave Done RWCo- Enou Index ErrCode SubInd- Length Data	Reading and writing EtherCAT SDO data
2822	MOTST	—	—	MOTST En Slave Position Reset State Done Enou ErrCode	Reading Motion state of an EtherCAT slave
2823	ECATST	—	—	ECATST En Slave State Done Enou ErrCode	Reading the state of an EtherCAT slave

## 3.4.2 Applied Instructions (Sorted Alphabetically)

Classification	API	Instruction code		Pulse instruction	Function
		16-bit	32-bit		
Symbol	0114	\$+	–	✓	Linking two strings
	2118	\$CLR	–	✓	Clearing a string
	2117	\$DEL	–	✓	Deleting the characters in a string
	2109	\$FSTR	–	✓	Converting a floating-point number into a string
	2110	\$FVAL	–	✓	Converting a string into a floating-point number
	2119	\$INS	–	✓	Inserting a string
	2112	\$LEFT	–	✓	Retrieving characters in a string begins from the left.
	2106	\$LEN	–	✓	Calculating the length of a string
	2113	\$MIDR	–	✓	Retrieving a part of a string
	0302	\$MOV	–	✓	Transferring a string
	2111	\$RIGHT	–	✓	Retrieving characters in a string begins from the right.
	2116	\$RPLC	–	✓	Replacing the characters in a string
	2115	\$SER	–	✓	Searching a string
	0102	*	D*	✓	Multiplication of binary numbers
	0103	/	D/	✓	Division of binary numbers
	0100	+	D+	✓	Addition of binary numbers
	A	1210	ABS	DABS	✓
0705		ABSD	DABSD	–	Absolute drum sequencer
1424		ADLOG	DADLOG	–	Record data of analog input module.
1425		ADPEAK	DADPEAK	–	Record peak data of analog input module.
0700		ALT	–	✓	Alternating between ON and OFF
0043		AND\$<>	–	–	S1≠S2
0042		AND\$=	–	–	S1 = S2
0812		AND&	DAND&	–	S1&S2
0814		AND^	DAND^	–	S1^S2
0813		AND	DAND	–	S1 S2
0010		AND<	DAND<	–	S1 < S2
0011		AND<=	DAND<=	–	S1<=S2
0007		AND<>	DAND<>	–	S1≠S2
0006		AND=	DAND=	–	S1 = S2
0008		AND>	DAND>	–	S1 > S2
0009		AND>=	DAND>=	–	S1>=S2

Classification	API	Instruction code		Pulse instruction	Function
		16-bit	32-bit		
	0076	ANDZ<	DANDZ<	–	S1-S2  <  S3
	0077	ANDZ<=	DANDZ<=	–	S1-S2 <= S3
	0073	ANDZ<>	DANDZ<>	–	S1-S2 ≠ S3
	0072	ANDZ=	DANDZ=	–	S1-S2 = S3
	0074	ANDZ>	DANDZ>	–	S1-S2  >  S3
	0075	ANDZ>=	DANDZ>=	–	S1-S2 >= S3
	1703	ARWS	–	–	Arrow key input
	2801	ASDON	–	–	Servo-ON and servo-OFF
	1815	ASDRW	–	–	Serial communication instruction exclusive for Delta servo drive
	1016	ATMR	–	–	16-bit contact timer (Unit: 100 ms)
	1017	ATMRH	–	–	16-bit contact timer (Unit: 1 ms)
	1018	ATMRM	–	–	16-bit contact timer (Unit: 10 ms)
	B	1222	BAND	DBAND	✓
0200		BCD	DBCD	✓	Converting a binary number into a binary-coded decimal number
2102		BCDDA	DBCDDA	✓	Converting a binary-coded decimal number into ASCII code
0201		BIN	DBIN	✓	Converting a binary-coded decimal number into a binary number
2100		BINDA	DBINDA	✓	Converting a signed decimal number into ASCII code
2101		BINHA	DBINHA	✓	Converting a binary hexadecimal number into the hexadecimal ASCII code
0113		BK-	DBK-	✓	Subtracting binary numbers in blocks
0112		BK+	DBK+	✓	Adding binary numbers in blocks
0214		BKBCD	–	✓	Converting binary numbers in blocks into binary-coded decimal numbers in blocks
0215		BKBIN	–	✓	Converting binary numbers in blocks into binary-coded decimal numbers in blocks
0304		BMOV	DBMOV	✓	Transferring all data
1207		BON	DBON	✓	Checking the state of a bit
1302		BREAK	–	–	Terminating the FOR-NEXT loop
1113		BSFL	–	✓	Shifting the states of the n bit devices by one bit to the left
1112		BSFR	–	✓	Shifting the states of the n bit devices by one bit to the right
0307		BXCH	–	✓	Exchanging all data
C	1819	CANRS	–	–	User-defined CAN communication sending and receiving
	2802	CASD	–	–	Setting the acceleration time and deceleration time for a servo

Classification	API	Instruction code		Pulse instruction	Function
		16-bit	32-bit		
	1209	CCD	–	✓	Checksum
	1816	CCONF	–	✓	Setting the parameters in the data exchange table of a communication port
	0065	CHKADR	–	–	Checking the address of the pointer register
	0400	CJ	–	✓	Conditional jump
	0303	CML	DCML	✓	Inverting data
	0054	CMP	DCMP	✓	Comparing values
	0063	CMPT<	–	✓	Comparing tables ON: <
	0064	CMPT<=	–	✓	Comparing tables ON: <=
	0060	CMPT<>	–	✓	Comparing tables ON: ≠
	0059	CMPT=	–	✓	Comparing tables ON: =
	0061	CMPT>	–	✓	Comparing tables ON: >
	0062	CMPT>=	–	✓	Comparing tables ON: >=
	1003	CNT	–	–	16-bit counter
	1813	COMDF	–	✓	Setting the communication format for a serial communication port
	1812	COMRS	–	–	Sending and receiving communication data
	2807	COPRW	–	–	Reading and writing CANopen communication data
	2808	COPWL	DCOPWL	–	Writing multiple CANopen parameter values
	1807	CRC	–	–	Cyclic redundancy check
	2708	CSFO	–	–	Catch speed and proportional output
D	0101	–	D-	✓	Subtracting binary numbers $S_1 - S_2 = D$
	1010	–	DCAP	–	Capturing the high-speed count value in the external input interrupt
	2717	–	DCCMA	–	Absolute-position circle drawing
	2716	–	DCCMR	–	Relative-position circle drawing
	2713	–	DCICA	–	2-Axis absolute-position clockwise arc interpolation
	2715	–	DCICCA	–	2-Axis absolute-position counterclockwise arc interpolation
	2714	–	DCICCR	–	2-Axis relative-position counterclockwise arc interpolation
	2712	–	DCICR	–	2-Axis relative-position clockwise arc interpolation

Classification	API	Instruction code		Pulse instruction	Function
		16-bit	32-bit		
	1004	–	DCNT	–	32-bit counter
	2812	–	DCSFOC	–	Controlling the tracking function of a servo via communication
	2707	–	DDRVA	–	Absolute position control
	2804	–	DDRVA	–	Servo absolute position control
	2706	–	DDRVI	–	Relative position control
	2803	–	DDRVIC	–	Servo relative position control
	2709	–	DDRVM	–	Mark alignment positioning
	2814	–	DECAMS	–	E-CAM parameter setting and planning
	1419	–	DHCCAP	–	HC module counter value captured
	1421	–	DHCCMP	–	HC module counter value in comparison for output
	1422	–	DHCCMPT	–	HC module counter value in group comparison for output
	1418	–	DHCCNT	–	HC module counter value counted
	1423	–	DHCMEAS	–	HC module measurements of frequency and revolution
	1006	–	DHSCR	–	Resetting high-speed comparison
	1005	–	DHSCS	–	Setting high-speed comparison
	1014	–	DHSCY	–	Cyclic counting, comparing and outputting
	0601	–	DHSRF	✓	Refreshing the values of high-speed comparison
	1007	–	DHSZ	–	High-speed input zone comparison
	1415	–	DLCCAL	–	LC module channel calibration
	1417	–	DMPID	–	PID algorithm for RTD/TC module
	0708	–	DPIDE	–	PID algorithm
	2701	–	DPLSR	–	High-speed pulse output (with ramp-up/down process)
	2705	–	DPLSV	–	Adjustable pulse output
	2805	–	DPLSVC	–	Servo speed control
	2700	–	DPLSY	–	High-speed pulse output (without ramp-up/down process)
	2723	–	DPPGB	–	Point to point go back and forth
	2711	–	DPPMA	–	2-Axis absolute-coordinate point-to-point synchronized motion
	2710	–	DPPMR	–	2-Axis relative-coordinate point-to-point synchronized motion
	2721	–	DPTWC	✓	Setting arc interpolation parameters in the position planning table
	1410	–	DPUCNT	–	High-speed counter function of PU module
	1402	–	DPUCONF	✓	Setting output control parameters of PU

Classification	API	Instruction code		Pulse instruction	Function
		16-bit	32-bit		
					module
	1406	–	DPUDRA	–	Absolute addressing output of PU module (with acceleration and deceleration)
	1405	–	DPUDRI	–	Relative position output of PU module (with acceleration and deceleration)
	1408	–	DPUJOG	–	PU module jog output
	1409	–	DPUMPG	–	PU module MPG output
	1404	–	DPUPLS	–	PU module pulse output (no acceleration)
	1407	–	DPUZRN	–	PU module homing
	1008	–	DSPD	–	Detecting speed
	0711	–	DSUNRS	–	Setting up the sunrise and sunset times
	2720	–	DTPWL	✓	Setting linear interpolation parameters in the position planning table
	2719	–	DTPWS	✓	Setting single-axis output parameters in the position planning table
	2817	–	DTQC	–	Torque control
	2818	–	DTQLC	–	Speed of torque control
	2704	–	DZRN	–	Zero return
	2724	–	DZRN2	–	Zero return 2 (output direction can be set)
	2105	DABCD	DDABCD	✓	Converting an ASCII code into a binary-coded decimal number
	2103	DABIN	DDABIN	✓	Converting a signed decimal ASCII code into a signed decimal binary number
	0116	DEC	DDEC	✓	Subtracting one from a binary number
	1202	DECO	–	✓	Decoder
	1901	DELAY	–	✓	Delaying the execution of a program
	1821	DESO	–	–	Execute the appointed communication number of the data exchange table once
	0500	DI	–	–	Disabling the interrupt
	1215	DIS	–	✓	Disuniting the 16-bit data
	0118	DIV16	DIV32	✓	Division of binary numbers for 16-bit Division of binary numbers for 32-bit
	0504	DIX	–	–	Enabling a specific interrupt
	<u>1820</u>	DMVSH	–	–	Enabling Delta DMV detection and communication
	1818	DNETRW	–	–	Reading and writing DeviceNet communication data
	1607	DST	–	✓	Daylight saving time
	1702	DSW	–	–	DIP switch
	1226	–	DTM	✓	Transfer and move data
E	2815	ECAMA	–	–	Activating E-CAM control and displaying

Classification	API	Instruction code		Pulse instruction	Function
		16-bit	32-bit		
					the status
	2816	ECAMC	–	–	Modifying the starting address for E-CAM chart and the E-CAM chart length in the servo
	2813	ECAMD	–	–	Downloading E-CAM chart to the Slave
	2821	ECATRW	–	–	Reading and writing EtherCAT SDO data
	2823	ECATST	–	–	Reading the state of an EtherCAT slave
	0501	EI	–	–	Enabling an interrupt
	2208	EIPRW	–	–	Reading and writing through an EtherNet/IP connection
	0503	EIX	–	–	Disabling a specific interrupt
	2211	EMCONF1	–	✓	Setting email server parameter values
	2212	EMCONF2	–	✓	Setting email address
	2811	EMER	–	–	Reading Emergency message
	1203	ENCO	–	✓	Encoder
	1905	EPOP	–	✓	Reading data into the index registers
	1904	EPUSH	–	✓	Storing the contents of the index registers
	0105	–	F-	✓	Subtracting floating-point numbers $S_1 - S_2 = D$
	0106	–	F*	✓	Multiplying floating-point numbers $S_1 * S_2 = D$
	0107	–	F/	✓	Dividing floating-point numbers $S_1 / S_2 = D$
	0104	–	F+	✓	Adding floating-point numbers $S_1 + S_2 = D$
	1504	–	FACOS	✓	Arccosine of the floating-point number
	0028	–	FAND<	–	$S_1 < S_2$
	0029	–	FAND<=	–	$S_1 <= S_2$
	0025	–	FAND<>	–	$S_1 \neq S_2$
	0024	–	FAND=	–	$S_1 = S_2$
	0026	–	FAND>	–	$S_1 > S_2$
	0027	–	FAND>=	–	$S_1 >= S_2$
	1503	–	FASIN	✓	Arcsine of a floating-point number
	1505	–	FATAN	✓	Arctangent of a floating-point number
	0212	–	FBCD	✓	Converting a binary floating-point number into a decimal floating-point number
	0213	–	FBIN	✓	Converting a decimal floating-point number into a binary floating-point number
	0056	–	FCMP	✓	Comparing floating-point numbers
	1501	–	FCOS	✓	Cosine of a floating-point number

Classification	API	Instruction code		Pulse instruction	Function
		16-bit	32-bit		
	1507	–	FCOSH	✓	Hyperbolic cosine of a floating-point number
	1510	–	FDEG	✓	Converting radians to degrees
	1513	–	FEXP	✓	The exponent of a floating-point number
	0022	–	FLD<	–	S1 < S2
	0023	–	FLD<=	–	S1 <= S2
	0019	–	FLD<>	–	S1 ≠ S2
	0018	–	FLD=	–	S1 = S2
	0020	–	FLD>	–	S1 > S2
	0021	–	FLD>=	–	S1 >= S2
	1515	–	FLN	✓	Natural logarithm of a binary floating-point number
	1514	–	FLOG	✓	Logarithm of a floating-point number
	1224	–	FMEAN	✓	The mean of floating point numbers
	0211	–	FNEG	✓	Reversing the sign of a floating-point number
	0034	–	FOR<	–	S1 < S2
	0035	–	FOR<=	–	S1 <= S2
	0031	–	FOR<>	–	S1 ≠ S2
	0030	–	FOR=	–	S1 = S2
	0032	–	FOR>	–	S1 > S2
	0033	–	FOR>=	–	S1 >= S2
	1516	–	FPOW	✓	Raising a floating-point number to a power
	1509	–	FRAD	✓	Converting degrees to radians
	1500	–	FSIN	✓	Sine of a floating-point number
	1506	–	FSINH	✓	Hyperbolic sine of a floating-point number
	1229	–	FSORT	✓	Sorting data in floating-point format
	1512	–	FSQR	✓	Square root of a floating-point number
	1225	–	FSUM	✓	The sum of floating point numbers
	1502	–	FTAN	✓	Tangent of a floating-point number
	1508	–	FTANH	✓	Hyperbolic tangent of a floating-point number
	0057	–	FZCP	✓	Floating-point zone comparison
	0202	FLT	DFLT	✓	Converting a binary integer into a binary floating-point number
	1300	FOR	–	–	Start of a nested loop
	1400	FROM	DFROM	✓	Reading data from the control register in the extension module
	0209	GBIN	DGBIN	✓	Converting a Gray code into a binary

Classification	API	Instruction code		Pulse instruction	Function
		16-bit	32-bit		
					number
G	0402	GOEND	–	–	Jumping to END
	1902	GPWM	–	–	General pulse width modulation
	0208	GRY	DGRY	✓	Converting a binary number into a Gray code
	2104	HABIN	DHABIN	✓	Converting a hexadecimal ASCII code into a hexadecimal binary number
H	1420	HCDO	–	–	HC module digital output point
	1701	HKY	DHKY	–	Hexadecimal key input
	1604	HOUR	–	–	Running-time meter
	2207	IATON	–	✓	Converting an IP address of the string type into an IP address of the integer type
I	1012	IETS	–	✓	The start of the instruction execution time measurement
	1013	IETE	–	✓	The end of the instruction execution time measurement
	0115	INC	DINC	✓	Adding one to a binary number
	0706	INCD	–	–	Incremental drum sequencer
	1906	INFO	–	✓	Reading the system data
	2800	INITC	–	–	Initializing the servo for CANopen communication
	2820	INITEC	–	–	Initializing the slaves for EtherCAT communication
	0204	INT	DINT	✓	Converting a 32-bit floating-point number into a binary integer
	2206	INTOA	–	✓	Converting an IP address of the integer type into an IP address of the string type
	1426	IOLINKR	–	–	Read the parameter from the O-Link device
	1427	IOLINKW	–	–	Write the parameter into the IO-Link device
	0401	JMP	–	–	Unconditional jump
	J	2703	JOG	DJOG	–
1416		LCWEI	–	–	Reading weight value via LC module
L	0037	LD\$<>	–	–	S1≠S2
	0036	LD\$=	–	–	S1=S2
	0809	LD&	DLD&	–	S1&S2
	0811	LD^	DLD^	–	S1^S2
	0810	LD	DLD	–	S1 S2
	0004	LD<	DLD<	–	S1<S2
	0005	LD<=	DLD<=	–	S1<=S2
	0001	LD<>	DLD<>	–	S1≠S2

Classification	API	Instruction code		Pulse instruction	Function
		16-bit	32-bit		
	0000	LD=	DLD=	–	S1=S2
	0002	LD>	DLD>	–	S1>S2
	0003	LD>=	DLD>=	–	S1>=S2
	0070	LDZ<	DLDZ<	–	S1-S2 < S3
	0071	LDZ<=	DLDZ<=	–	S1-S2 <= S3
	0067	LDZ<>	DLDZ<>	–	S1-S2 ≠ S3
	0066	LDZ=	DLDZ=	–	S1-S2 = S3
	0068	LDZ>	DLDZ>	–	S1-S2 > S3
	0069	LDZ>=	DLDZ>=	–	S1-S2 >= S3
	1221	LIMIT	DLIMIT	☐	Confining a value within bounds
	1806	LRC	–	–	Longitudinal parity check
M	2214	–	MQTT_Connect	–	Establishing a MQTT connection
	0801	MAND	–	✓	Matrix AND operation
	2304	MDEL	–	✓	Deleting files on the memory card
	2123	MERGE	–	✓	Merging a string
	1214	MBC	–	✓	Counting the bits with the value 0 or 1
	0904	MBR	–	✓	Rotating the matrix bits
	1212	MBRD	–	✓	Reading the matrix bit
	1109	MBS	–	✓	Shifting the matrix bits
	1213	MBWR	–	✓	Writing the matrix bit
	0058	MCMP	–	✓	Matrix comparison
	2210	MCONF	–	✓	Reading/Writing Modbus TCP data
	1208	MEAN	DMEAN	✓	Mean
	2303	MEMW	–	✓	Writing data into the file register
	1211	MINV	–	✓	Inverting matrix bits
	1430	MLPF	–	–	Digital low-pass filter for analog input signals
	0206	MMOV	–	✓	Converting a 16-bit value into a 32-bit value
	1808	MODRW	–	–	Reading/Writing MODBUS data
	1817	MODRWE	–	–	Reading and writing Modbus data without using any flags
	0803	MOR	–	✓	Matrix OR operation
	2822	MOTST	–	–	Reading Motion state of an EtherCAT slave
	0300	MOV	DMOV	✓	Transferring data
	0310	MOVB	–	✓	Transferring several bits
2215	MQTT_Publish	–	–	Publishing a MQTT message	

Classification	API	Instruction code		Pulse instruction	Function
		16-bit	32-bit		
	2216	MQTT_Subscribe	–	–	Subscribing to a MQTT topic
	2301	MREAD	–	✓	Reading data from the memory card into the PLC
	2204	MSEND	–	✓	Sending an email
	0704	MTR	–	–	Matrix input
	2302	MTWRIT	–	✓	Writing a string into the memory card
	0117	MUL16	MUL32	✓	Multiplying binary numbers for 16-bit/32-bit
	2300	MWRIT	–	✓	Writing data from the PLC to the memory card
	0805	MXOR	–	✓	Matrix exclusive OR operation
	0210	NEG	DNEG	✓	Two's complement
N	1301	NEXT	–	–	End of the nested loop
	0305	NMOV	DNMOV	✓	Transferring data to several devices
	1115	NSFL	DNSFL	✓	Shifting <b>n</b> registers to the left
	1114	NSFR	DNSFR	✓	Shifting <b>n</b> registers to the right
	0049	OR\$<>	–	–	S1≠S2
O	0048	OR\$=	–	–	S1=S2
	0815	OR&	DOR&	–	S1&S2
	0817	OR^	DOR^	–	S1^S2
	0816	OR	DOR	–	S1 S2
	0016	OR<	DOR<	–	S1<S2
	0017	OR<=	DOR<=	–	S1<=S2
	0013	OR<>	DOR<>	–	S1 ≠ S2
	0012	OR=	DOR=	–	S1=S2
	0014	OR>	DOR>	–	S1>S2
	0015	OR>=	DOR>=	–	S1>=S2
	0082	ORZ<	DORZ<	–	S1-S2 < S3
	0083	ORZ<=	DORZ<=	–	S1-S2 <= S3
	0079	ORZ<>	DORZ<>	–	S1-S2 ≠ S3
	0078	ORZ=	DORZ=	–	S1-S2 = S3
	0080	ORZ>	DORZ>	–	S1-S2 > S3
	0081	ORZ>=	DORZ>=	–	S1-S2 >= S3
1015	PPDT	–	–	Detecting the time difference between two phases	
P	1403	PUSTAT	–	–	Reading PU module output state
	1009	PWD	–	–	Pulse width detection
	2702	PWM	DPWM	–	Pulse width modulation

Classification	API	Instruction code		Pulse instruction	Function
		16-bit	32-bit		
	0703	RAMP	DRAMP	–	Ramp signal
R	1517	RAND	–	✓	Random number
	0903	RCL	DRCL	✓	Rotating to the left with the carry flag
	0901	RCR	DRCR	✓	Rotating to the right with the carry flag
	2305	Record_trigger	–	–	Recording and writing data into a file
	0600	REF	–	✓	Refreshing the I/O
	0602	REFF	–	✓	Refreshing the I/O filtering time
	0207	RMOV	–	✓	Converting a 32-bit value into a 16-bit value
	0902	ROL	DROL	✓	Rotating to the left
	0900	ROR	DROR	✓	Rotating to the right
	1000	RST	DRST	–	Resetting the contact or clearing the register
	2809	RSTD	–	–	Sending Reset or NMT command
	0216	SCAL	DSCAL	✓	Scale value operation
	S	0222	SCLM	DSCLM	✓
2203		SCLOSE	–	✓	Closing the socket
0217		SCLP	DSCLP	✓	Parameter type of scale value operation
2209		SCONF	–	✓	Setting TCP/UDP socket parameters
1204		SEGD	–	✓	Seven-segment decoding
1704		SEGL	–	–	Seven-segment display with latches
1200		SER	DSER	✓	Searching the data
2501		SFCPSE	–	–	Causing SFC to pause
2500		SFCRUN	–	–	Enabling SFC
2502		SFCSTP	–	–	Stopping SFC
1107		SFDEL	DSFDEL	✓	Deleting the data from the data list
1108		SFINS	DSFINS	✓	Inserting the data into the data list
1111		SFL	DSFL	✓	Shifting the values of the bits in the registers by n bits to the left
1106		SFPO	DSFPO	✓	Reading the latest data from the data list
1110		SFR	DSFR	✓	Shifting the values of the bits in the registers by n bits to the right
1105		SFRD	DSFRD	✓	Shifting the data and reading it from the word device
1101		SFTL	–	✓	Shifting the states of the devices to the left
1100		SFTR	–	✓	Shifting the states of the devices to the right
1104		SFWR	DSFWR	✓	Shifting the data and writing it into the word device

Classification	API	Instruction code		Pulse instruction	Function
		16-bit	32-bit		
	0309	SMOV	–	✓	Transferring the digits
	2122	SPLIT	–	✓	Splitting a string
	2200	SOPEN	–	✓	Opening the socket
	1205	SORT	DSORT	✓	Sorting the data
	1511	SQR	DSQR	✓	Square root of a binary number
	2201	SSEND	–	✓	Sending the data through the socket
	0702	STMR	–	–	Special timer
	1201	SUM	DSUM	✓	Number of bits whose states are ON
	0308	SWAP	DSWAP	✓	Exchange the high byte with the low byte
	1603	T-	–	✓	Subtracting a time
T	1602	T+	–	✓	Adding a time
	1605	TCMP	–	✓	Comparing a time
	2401	TKOFF	–	✓	Disabling a cyclic task
	2400	TKON	–	✓	Enabling a cyclic task
	1700	TKY	DTKY	–	Ten key input
	1001	TMR	–	–	16-bit timer (unit: 100 ms)
	1002	TMRH	–	–	16-bit timer (unit: 1 ms)
	1011	TMRM	–	–	16-bit timer (unit: 10 ms)
	1401	TO	DTO	✓	Writing the data to the control register in the special module
	2718	TPO	–	–	The position planning table controls the output
	1600	TRD	–	✓	Reading the time
	0701	TTMR	–	–	Teach mode timer
	1601	TWR	–	✓	Writing the time
	1606	TZCP	–	✓	Time zone comparison
1216	UNI	–	✓	Uniting the 16-bit data	
U	1814	VFDRW	–	–	Serial communication instruction exclusively for Delta AC motor drive
V	0800	WAND	DAND	✓	Logical AND operation
W	1608	WWON	–	–	Weekly working time setup
	1900	WDT	–	✓	Watchdog timer
	0808	WINV	DINV	✓	Logical reversed INV operation
	0802	WOR	DOR	✓	Logical OR operation
	1103	WSFL	DWSFL	✓	Shifting data in the word devices to the left
	1102	WSFR	DWSFR	✓	Shifting data in the word devices to the right
	1217	WSUM	DWSUM	✓	Getting the sum

Classification	API	Instruction code		Pulse instruction	Function
		16-bit	32-bit		
	0804	WXOR	DXOR	✓	Logical exclusive OR operation
	0306	XCH	DXCH	✓	Exchanging data
X	0709	XCMP	–	–	Setup for comparing the inputs of multiple work stations
	0710	YOUT	–	–	Comparing the outputs of multiple work stations
Y	0055	ZCP	DZCP	✓	Zone comparison
Z	1223	ZONE	DZONE	✓	Controlling the zone
	2806	ZRNC	DZRNC	–	Servo homing
	2810	ZRNM	–	–	Setting the homing mode for Delta servo
	1206	ZRST	–	✓	Resetting the zone
	1228	ZSET	–	✓	Zone setup

---

# Chapter 4 Instruction Structure

## Table of Contents

- 4.1 Applied Instructions - API Description ..... 4-2
- 4.2 Operand Usage Description ..... 4-4
- 4.3 Restrictions on the Use of Instructions ..... 4-7
- 4.4 Index Registers ..... 4-9
- 4.5 Pointer Registers ..... 4-12
- 4.6 Pointer Registers of Timers ..... 4-14
- 4.7 Pointer Registers for 16-bit Counters ..... 4-16
- 4.8 Pointer Registers for 32-bit Counters ..... 4-18
- 4.9 File Register ..... 4-20

## 4.1 Applied Instructions - API Description

This section describes the way this manual documents each API instruction. Every instruction has its own instruction code and API number. The instructions are divided into sections based on the related functions of the instructions, so that all the arithmetic instructions are in one section, and all the comparison instructions are in another section. The following example uses the MOV instruction. The API number of the instruction in the table is 0300, the instruction code is MOV, and the function is transferring data.


API	Instruction code			Operand								Function				
0300	D	MOV	P	S · D								Transferring the data				

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
S	●	●			●	●	●	●	●		○	○	○	○		○
D		●			●	●	●	●			○	○				

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
S		●	●				●		●		●	●	
D		●	●				●		●		●	●	

Pulse instruction	16-bit instruction	32-bit instruction
AS	AS	AS

**Symbol:**



**S** : Data source  
**D** : Data destination

- The devices used by the instruction are listed in the operand column. **S**, **D**, **n**, and **m** are used as the operands according to their functions. When more than one operand is used, and these operands share the same function, they are differentiated by subscripts; for example, **S<sub>1</sub>**, and **S<sub>2</sub>**.
- If you can use a 16-bit instruction as a 32-bit instruction, the letter **D** prepended to the 16-bit instruction code to form the 32-bit instruction form. If you can use the instruction as a pulse instruction, the letter **P** is appended to the instruction code. For example, "D\*\*\*P" in which "\*\*\*\*" is the instruction code indicates a 32-bit pulse instruction.
- F** in the operand area indicates a single precision floating point number (32-bit).
- The solid circle ● indicates that the device can be modified by an index register, and the hollow circle ○ indicates that the device cannot be modified by an index register. For example, the data register designated by the operand **S** can be modified by an index register.
- The applicable model is indicated in the table. You can check whether you can use the instruction as a pulse instruction, a 16-bit instruction, a 32-bit instruction, or a 64-bit instruction according to the information in the table.
- If you want to use an instruction in a function block, and the output, input, and data devices are supported in the operands, you have to use the pointer registers. AS indicates that to use a timer, a 16-bit counter, and a 32-bit

counter that are supported in the operands, you have to use the timer pointer register, the 16-bit counter pointer register, and the 32-bit counter pointer register. Refer to Sections 4.4–4.7 for more information or Section 7.2.4 in the ISPSOft manual.

7. The symbols representing the MOV instruction in ISPSOft are:

**MOV, MOVP, DMOV, and DMOVP** are the Instruction codes for this instruction

**En:** Enable

**S:** The data source (the applicable format of the operand is a word/double word.)


**D:** The data destination (the applicable format of the operand is a word/double word.)

**Applied instructions composition**

Some applied instructions are composed of instruction codes. For example, the EI, DI, and WDT instructions; however, most applied instructions consist of instruction codes and several operands.

Every applied instruction has its own API number and instruction code. For example, the instruction code API 0300 is the MOV (transfer data) instruction. You can enter an applied instruction in three ways.


Enter the instruction directly: you can enter the instruction in ISPSOft. For the MOV instruction, enter the instruction name and the operands to designate “MOV D0



Enter the instruction by dragging: you can drag the MOV instruction from **APIs** in ISPSOft to the ladder diagram editor.

Enter the instruction from the toolbar: you can click **API/FB Selection** on the toolbar in ISPSOft, and then click **API**.

Finally, click the MOV instruction in **Data Transfer**.



<b>S</b>	Source operand If there is more than one source operand, the source operands are represented by subscript (for example <b>S<sub>1</sub></b> , <b>S<sub>2</sub></b> ).
<b>D</b>	Destination operand If there is more than one destination operand, the destination operands are represented by subscript (for example, <b>D<sub>1</sub></b> , <b>D<sub>2</sub></b> ).
If the operand only can be a constant K/H or a register value, it is represented by <b>m</b> , <b>m<sub>1</sub></b> , <b>m<sub>2</sub></b> , <b>n</b> , <b>n<sub>1</sub></b> , or <b>n<sub>2</sub></b> .	


**The length of the operand (6-bit, 32-bit, or floating-point number instructions):**

**16-bit or 32-bit instructions**

Operand values in instructions are divided into 16-bit values and the 32-bit values. In order to process data of difference lengths, the instructions are divided into 16-bit and 32-bit instructions. To differentiate a 32-bit instruction from the 16-bit form, a D is added in front of the 16-bit instruction code (16-bit MOV and 32-bit DMOV).


**The floating-point number instruction**

16-bit MOV instruction



When M1 is ON, the data in D0 is transferred to D1.

32-bit DMOV instruction




When M1 is ON, the data in (D1, D0) is transferred to (D3, D2).

**Floating-point number instructions**

Floating-point number instructions support 32-bit floating-point number instructions that correspond to the single-precision floating-point number instructions. Refer to Chapter 2 for more information about floating-point numbers.

4

32-bit single-precision floating-point number F+ instruction



When X0.0 is ON, the data in (D11, D10) and (D21, D20) is transferred to (D31, D30).

**Continuous execution and pulse execution of instructions**

1. Instruction execution can be divided into continuous and pulse execution. You can reduce the scan cycle with pulse instructions because when the instruction is not executed, less time is needed to execute the program.
2. The pulse function allows the related instruction to enable the rising edge-triggered control input. The instruction is ON for one scan cycle.
3. If the control input stays ON, and the related instruction is not executed, the control input must be switched from OFF to ON again in order to execute the instruction.
4. The following shows the difference between pulse and continuous instruction:

<p>Pulse execution</p>	<p>When M1 switches from OFF to ON, the MOVP instruction is executed once. The instruction is not executed again in the scan cycle. Therefore, it is called a pulse instruction.</p>
<p>Continuous execution</p>	<p>Whenever M1 is ON during the scan cycle, the MOV instruction is executed once. Therefore, the instruction is called a continuous instruction.</p>

When the conditional contact M1 is OFF, neither instruction is executed, and the value in the destination operand D does not change.

## 4.2 Operand Usage Description

There are 2 types of operands in the AS Series: user-defined and system-defined.

### User-defined operands

- Input relays: X0.0–X63.15 or X0–X63
- Output relays: Y0.0–Y63.15 or Y0–Y63
- Internal relays: M0–M8191
- Stepping relays: S0–S2047
- Timers: T0–T511
- 16-bit counters: C0–C511
- 32-bit counters: HC0–HC255
- Data registers: D0–D29999 or D0.0–D29999.15
- File registers: FR0–FR65535
- Special auxiliary flags: SM0–SM2047
- Special data registers: SR0–SR2047
- Index registers: E0–E9
- Constants: The decimal constants are indicated by K, and the hexadecimal constants are indicated by 16#.
- Strings: "\$"
- Floating-point numbers: The single-precision floating-point numbers are indicated by F.
- The length of the data in one register is generally 16 bits. If you want to store 32-bit data in the register, designate two consecutive registers for the data.
- If the operand in a 32-bit instruction uses D0, it occupies the 32-bit data register composed of (D1, D0). D1 represents the higher 16 bits, and D0 represents the lower 16 bits. The same rule applies to the timer and the 16-bit counter.
- When you use the 32-bit counter HC as the data register, it can only be used by the operand in a 32-bit instruction.
- You can only use index registers in 16-bit instructions.

Refer to Chapter 2 Devices for more information.

**System-defined operands**

- The system assigns the variables to declare such as BOOL, WORD, INT and so on: U0–U16387 and W0–W29999.
- To start or stop a task use the TK0–TK31 instructions.

The following table lists the pointer type variable symbols, the supporting devices and usage.

Pointer type	Usage	
General pointer (Pointer)	Device range	PR0–PR15 · PR0.0–PR15.15
	Maximum quantity	Use up to 16 pointers in each function block
	Can be assigned to	Variable symbols of WORD/DWORD/LWORD/INT/DINT/LINT types or data register, input relay or output relay devices (e.g. X0, Y0, etc.)
Pointer for a timer (T_POINTER)	Device range	TR0–TR7
	Maximum quantity	Use up to 8 pointers in each function block
	Can be assigned to	Variable symbols of timer type or timer type devices
Pointer for a counter (C_POINTER)	Device range	CR0–CR7
	Maximum quantity	Use up to 8 pointers in each function block
	Can be assigned to	Variable symbols of counter type or counter type devices
Pointer for a high-speed counter (HC_POINTER)	Device range	HCR0–HCR7
	Maximum quantity	Use up to 8 pointers in each function block
	Can be assigned to	Variable symbols of 32-bit counter type or 32-bit counter type devices

### 4.3 Restrictions on the Use of Instructions

- You can use the following instructions only in function blocks: API0065 CHKADR, FB\_NP, FB\_PN, NED, ANED, ONED, PED, APED, OPED
- You cannot use the following instruction in interrupt tasks: GOEND
- You cannot use the in function blocks: LDP, ANDP, ORP, LDF, ANDF, ORF, PLS, PLF, NP, PN, MC/MCR, GOEND and all pulse instructions in applied instructions.


If you want to use some of the instructions mentioned above, you can use the substitute instructions in the following table.

Instruction which cannot be used in the function block	Substitute instruction in the function block
LDP/ANDP/ORP	PED/APED/OPED
LDF/ANDF/ORF	NED/ANED/ONED
PLS	-
PLF	-
NP	FB_NP
PN	FB_PN
MC	-
MCR	-
All pulse instructions in applied commands	*1

\*1: Pulse instructions cannot be used in function blocks. If you want to get the function of the pulse instruction in a function block, refer to the following example.

**Example:**

1. First, declare 10 bit variables tempBit[10] to be used in the system.
2. When StartBit1 switches from OFF to ON, method 1 (network 1) and method 2 (network 2) can only execute the MOV instruction once; you can choose which one to use.
3. You cannot use the variable tempBit in the system more than once.



- Use the following instructions with the Ladder Programming Language

For the following instructions, you need to start the instruction execution while the PLC switch from STOP to RUN. And when the following instructions stop executing, the PLC should stop programming too. It is suggested to use the following instructions with the Ladder Programming Language. Do NOT use the programming language that only does one time execution, for example, function blocks that only can be called once. Or do not use the programming language that stops scanning once the executing the instruction stops, for example ST and SFC programming languages. If the function block can be called several times by different programs, it is not suitable for the following instructions either.


Type of Instruction	Instructions
Timer and Counter Instructions	CNT, DCNT, DHSCS, DHSCR, DHSZ, DHSCY
Peripheral Instructions	TKY, DTKY, HKY, DHKY, DSW, ARWS
Miscellaneous Instruction	RAMP, DRAMP, MTR, INCD
Module Instructions	DPUCONF, PUSTAT
CANopen Communication Instructions	CANRS, COPRW, COPWL, DCOPWL, ZRNM, ECAMD, ECAMS, ECAMA, ECAMC
Memory Card / File Register Instructions	MEMW
Communication Instructions	DNETRW
Other Instructions	INFO

## 4.4 Index Registers


Index registers are 16-bit data registers. They are similar to the general register in that you can read data from them and write data into them. However, they are mainly used as index registers. The range of index registers is E0–E9. It is not recommended to use the index registers for global variables; they can only be used for partial variables and for temporary.

Index registers are used as follows.

- Using the register name to modify the device:




When M0 is ON, E0=10, E1=17, D1@E0=D(1+10)=D11, D11 is ON.



NOTE 1: AS Series support using the register name to modify the device; for example, D0.1@E0 but does not support 2-layered modification for example, D0@E1.1@E0.

NOTE 2: When E0=17, D0.1@E0=D0.(1+17)=D1.2, and D1.2 is ON. The bit part 1@E0=(1+17)=18. However, the maximum bit number is 15. Since  $m=18/16=1$  and the remainder is 2, the last modification result is D(0+1).2=D1.2. D1.2 is ON.

When M0 is ON, E0=10, and M1@E0=M(1+10)=M11. M11 is ON.



2. Declaring the variables first, and then modifying the device:

- Declare the three variables StartBit, Var1, and Var2 in ISPSOft.


The type of StartBit is a Boolean array, and its size is 2 bits. The range is from StartBit[0] to StartBit[1].

The type of Var1 is a word array, and its size is 11 words. The range is from Var1[0] to Var1[10].

The type of Var2 is a word, and its size is one word.

Local Symbols					
Class	Identifiers	Address	Type...	Initial Value	Identifier Comment...
VAR	StartBit	N/A [Auto]	ARRAY [2] OF BOOL	N/A	
VAR	Var1	N/A [Auto]	ARRAY [11] OF WORD	N/A	
VAR	Var2	N/A [Auto]	WORD	N/A	

- When StartBit[0] is ON, E0=10, E1=1, Var1[0]@E0=Var1[10], Var2=Var1[10], and StartBit[0]@E1=StartBit[1]. StartBit[1] is ON.




Additional remark: When you declare the variables in ISPSOft, and the variables are added to the contents of the registers to form the addresses to the actual data, you must note the addresses to prevent the program from being executed incorrectly.

3. Using index registers in an interrupt instruction:

- The index registers E0~E9 in the main program (e.g. POU, SFC, and FB) are different from the ones (index registers E0~E9) in the interrupt program. They are independent groups of index registers and they work separately.
- You can use ISPSOft to monitor the values of index registers in the main program.
- Application: If you use E0 in the main program and in the interrupt program. When an interrupt occurs, before executing the interrupt program, the system stores the value of E0 in the main program. After the interrupt program is executed, the value of E0 in the main program will be retained. So that the interrupt program will not affect the value of E0 in the main program and the result of the main program execution can stay unaffected.
- Refer to the following example, if you need to monitor the values of index registers E0-E9 in the interrupt program, or if the main program is also using the values of index registers E0-E9 in the interrupt program. (Note: It is NOT recommended to use index registers as global variables. If you need to use it as a global variable, you need to declare or define other devices to use it as a global variable.)

- Example: Declare D100 as the variable of the index register E0. And this example use MOVE instruction to demonstrate. Whenever an external interrupt occurs at X0.0, the value in D200 accumulates the occurrences in the values in D1000 ~ D1199.



## 4.5 Pointer Registers

- ISPSOft supports function blocks. When the variable declaration type is VAR\_IN\_OUT, and the data type is POINTER, the variable is a pointer register. The value in the pointer register can refer directly to the value stored in a device X, Y, or D; and the pointer register can point to the address associated with the variable set automatically in ISPSOft.
- You can declare 16 pointer registers in every function block. The range is PR0–PR15, or PR0.0–PR15.15.

**Example:**


Create a program organization unit (POU) in ISPSOft.

Create a function block called FB0.



Create the program in the function block FB0.

**4**



Declare the variable in the function block FB0.

Choose VAR\_IN\_OUT as the declaration type, Point1 as the identifier, POINTER as the data type. The variable is the pointer register.

Local Symbols						
Class	Identifiers	Address	Type...	Initial Value	Identifier Comment...	
VAR	VarBit1	N/A [Auto]	BOOL	FALSE		
VAR	Var1	N/A [Auto]	WORD	0		
VAR	Var2	N/A [Auto]	WORD	0		
▶ VAR_IN_OUT	Point1	N/A [Auto]	POINTER	N/A		


Declare the variable in the program organization unit (POU).

Local Symbols						
Class	Identifiers	Address	Type...	Initial Value	Identifier Comment...	
VAR	StartBit	N/A [Auto]	ARRAY [2] OF BOOL	N/A		
VAR	CVar1	N/A [Auto]	ARRAY [2] OF WORD	N/A		
▶ VAR	MyFB0	N/A [Auto]	FB0	N/A		

Call the function block FB0 in the program organization unit (POU).


The program in the program organization unit (POU) operates as shown below.

Network 1: When StartBit[0] is ON, the address of D0 is transmitted to Point 1 in FB0.



When VarBit1 in FB0 is ON, E0=1, Var1=D0, Point1@E0=D (0+1)=D1, and Var2=D1.

Network 2: When StartBit[1] is ON, the address of CVar1[0] is transmitted to Point1 in FB0.



Var2=CVar1[1] · When VarBit1 in FB0 is ON, E0=1, Var1=CVar1[0], Point1@E0=CVar1 (0+1)=Cvar1[1], and Var2=CVar1[1].

## 4.6 Pointer Registers of Timers

- ISPSOft supports function blocks. If you want to use a timer in a function block, you must declare a timer pointer register in the function block. The address of the timer is transmitted to the timer pointer register when the function block is called.
- When the variable declaration type is VAR\_IN\_OUT, and the data type is T\_POINTER, the variable is the timer pointer register. The value in the timer pointer register can refer directly to the value stored in the device T, or in the variable which is the timer in ISPSOft.
- You can declare up to 8 timer pointer registers in every function block. The range is TR0–TR7.
- If you want to use an instruction in the function block, and the timer is supported by the operands, you must use a timer pointer register.

### Example: using a timer in a function block.

1. Create a program organization unit (POU) in ISPSOft.
2. Create a function block which is called FB0.




3. Declare the variable in the function block FB0.

Choose VAR\_IN\_OUT as the declaration type, TPoint1 as the identifier, and T\_POINTER as the data type. The variable is the timer pointer register.

Local Symbols						
	Class	Identifiers	Address	Type...	Initial Value	Identifier Comment...
	VAR	VarBit1	N/A [Auto]	BOOL	FALSE	
	VAR_IN_OUT	TPoint1	N/A [Auto]	T_POINTER	N/A	
▶	VAR	VarOut	N/A [Auto]	BOOL	FALSE	

4. The program in the function block FB0 appears as shown below.




5. Declare the variable in the program organization unit (POU).

The data type of CVar1 should be TIMER.

Local Symbols					
Class	Identifiers	Address	Type...	Initial Value	Identifier Comment...
VAR	StartBit	N/A [Auto]	ARRAY [2] OF BOOL	[2(FALSE)]	
VAR	CVar1	T0	TIMER	N/A	
▶ VAR	MyFB0	N/A [Auto]	FB0	N/A	


6. Call the function block FB0 in the program organization unit (POU).  
 7. The program in the program organization unit (POU) operates as shown below.

Network 1: When StartBit[0] is ON, the address of T511 is transmitted to TPoint1 in FB0.



When VarBit1 in the FB0 is ON, the TMR instruction is executed, and TPoint1 (T511) starts counting. When the value of TPoint1 matches the TPoint1 setting, VarOut is ON.

Network 2: When StartBit[1] is ON, the address of CVar1[0] is transmitted to TPoint1 in FB0.



When VarBit1 in FB0 is ON, the TMR instruction is executed, and TPoint (CVar1) starts counting. When the value of TPoint1 matches the TPoint1 setting, VarOut is ON.

## 4.7 Pointer Registers for 16-bit Counters

- ISPSOft supports function blocks. If you want to use a 16-bit counter in a function block, you must declare a 16-bit counter pointer register in the function block. The address of the 16-bit counter is transmitted to the 16-bit counter pointer register when the function block is called.
- When the variable declaration type is VAR\_IN\_OUT, and the data type is C\_POINTE, the variable is the 16-bit counter pointer register. The value in the 16-bit counter pointer register can refer directly to the value stored in the device T, or in the variable which is the counter in ISPSOft.
- You can declare up to eight 16-bit counter pointer registers in every function block. The range is CR0–CR7.
- If you want to use an instruction in the function block, and the counter is supported by the operands, you have to use a 16-bit counter pointer register.

### Example: using a 16-bit counter in a function block.

1. Create a program organization unit (POU) in ISPSOft.
2. Create a function block which is called FB0.



3. Declare the variable in the function block FB0.

Choose VAR\_IN\_OUT as the declaration type, CPoint1 as the identifier, C\_POINTER as the data type. The variable is a 16-bit counter pointer register.

Local Symbols						
Class	Identifiers	Address	Type...	Initial Value	Identifier Comment...	
VAR	VarBit1	N/A [Auto]	BOOL	FALSE		
▶ VAR_IN_OUT	CPoint1	N/A [Auto]	C_POINTER	N/A		

4. The program in the function block FB0 appears as shown below:



5. Declare the variable in the program organization unit (POU).


The data type of CVar1 should be COUNTER.

Local Symbols						
Class	Identifiers	Address	Type...	Initial Value	Identifier Comment...	
VAR	StartBit	N/A [Auto]	ARRAY [2] OF BOOL	[2(FALSE)]		
VAR	CVar1	C1	COUNTER	N/A		
▶ VAR	MyFB0	N/A [Auto]	FB0	N/A		

6. Call the function block FB0 in the program organization unit (POU).


7. The program in the program organization unit (POU) operates as shown below.

Network 1: When StartBit[0] is ON, the address of C0 is transmitted to CPoint1 in FB0.



When VarBit1 in FB0 is ON, CPoint1 (C0) is ON.

Network 2: When StartBit[1] is ON, the address of CVar1 is transmitted to CPoint1 in FB0.



When VarBit1 in FB0 is ON, CPoint1 (CVar1) is ON.

## 4.8 Pointer Registers for 32-bit Counters

- ISPSOft supports function blocks. If you want to use a 32-bit counter in the function block, you must declare a 32-bit counter pointer register in the function block. The address of the 32-bit counter is transmitted to the 32-bit counter pointer register when the function block is called.
- When the variable declaration type is VAR\_IN\_OUT, and the data type is HC\_POINTER, the variable is a 32-bit counter pointer register. The value in a 32-bit counter pointer register can refer directly to the value stored in the device HC or in the variable which is the counter in ISPSOft.
- You can declare up to eight 32-bit counter pointer registers in every function block. The range is HCR0–HCR7.
- If you want to use an instruction in the function block, and the 32-bit counter is supported by the operands, you must use the 32-bit counter pointer register.

**Example: using a 32-bit counter in a function block.**

1. Create a function block called FB0.



2. Declare the variable in the function block FB0.

Choose VAR\_IN\_OUT as the declaration type, HCPoint1 as the identifier, HC\_POINTER as the data type. The variable is a 32-bit counter pointer register.

Local Symbols						
Class	Identifiers	Address	Type...	Initial Value	Identifier Comment...	
VAR	VarBit1	N/A [Auto]	BOOL	FALSE		
▶ VAR_IN_OUT	HCPoint1	N/A [Auto]	HC_POINTER	N/A		

3. The program in the function block FB0 appears as follows:




4. Declare the variable in the program organization unit (POU).

The data type of CVar1 should be COUNTER, and you must fill in the address column with a valid address of the 32-bit counter.

Local Symbols						
Class	Identifiers	Address	Type...	Initial Value	Identifier Comment...	
VAR	StartBit	N/A [Auto]	ARRAY [2] OF BOOL	[2(FALSE)]		
VAR	CVar1	HC1	COUNTER	N/A		
▶ VAR	MyFB0	N/A [Auto]	FB0	N/A		


5. Call the function block FB0 in the program organization unit (POU).
6. The program in the program organization unit (POU) operates as follows:

Network 1: When StartBit[0] is ON, the address of HC0 is transmitted to HCPoint1 in FB0.



When VarBit1 in FB0 is ON, HCPPoint1 (HC0) is ON.

Network: When StartBit[1] is ON, the address of CVar1 is transmitted to HCPPoint1 in FB0.



When VarBit1 in FB0 is ON, HCPPoint1 (CVar1) is ON.

## 4.9 File Register

- AS Series PLC provides File registers (FR) for storing larger numbers of parameters.
- You can edit, upload, and download the parameters in the file registers with ISPSOft.
- The values in file registers can be read while the PLC is running. Refer to the MEMW instruction (API 2303) in the AS300 Series Programming Manual for more information about how to read and write parameters to file registers.

---

# Chapter 5 Basic Instructions

## Table of Contents

5.1	List of Basic Instructions .....	5-2
5.2	Basic Instructions.....	5-3

## 5.1 List of Basic Instructions

The following table lists the Basic instructions covered in this chapter.

Instruction code	Function	Operand	Operation time (μs)
<u>LD/AND/OR</u>	Loading contact A/Connecting contact A in series/Connecting contact A in parallel	DX, X, Y, M, SM, S, T, C, HC, D	0.025
<u>LDI/ANI/ORI</u>	Loading contact B/Connecting contact B in series/Connecting contact B in parallel	DX, X, Y, M, SM, S, T, C, HC, D	0.03
<u>OUT</u>	Driving the coil	DY, Y, M, SM, S, T, C, HC, D	0.04
<u>SET</u>	Keeping the device on	DY, Y, M, SM, S, T, C, HC, D	0.04
<u>MC/MCR</u>	Setting/Resetting the master control	N	0.24
<u>LDP/ANDP/ORP</u>	Starting the rising-edge detection/Connecting the rising-edge detection in series/Connecting the rising-edge detection in parallel	DX, X, Y, M, SM, S, T, C, HC, D	0.22
<u>LDF/ANDF/ORF</u>	Starting the falling-edge detection/Connecting the falling-edge detection in series/Connecting the falling-edge detection in parallel	DX, X, Y, M, SM, S, T, C, HC, D	0.22
<u>PED/APED/OPED</u>	Starting the rising-edge detection/Connecting the rising edge-detection in series/Connecting the rising-edge detection in parallel	X, Y, M, SM, S, T, C, HC, D	0.22
<u>NED/ANED/ONED</u>	Starting the falling-edge detection/Connecting the falling-edge detection in series/Connecting the falling-edge detection in parallel	X, Y, M, SM, S, T, C, HC, D	0.22
<u>PLS</u>	Rising-edge output	Y, M, SM, S, D	0.22
<u>PLF</u>	Falling-edge output	Y, M, SM, S, D	0.22
<u>INV</u>	Inverting the logical operation result	–	0.22
<u>NP</u>	The circuit is rising edge-triggered.	–	0.24
<u>PN</u>	The circuit is falling edge-triggered.	–	0.24
<u>FB_NP</u>	The circuit is rising edge-triggered.	Y, M, S, D	0.24
<u>FB_PN</u>	The circuit is falling edge-triggered.	Y, M, S, D	0.24


## 5.2 Basic Instructions

Instruction code	Operand	Function
LD/AND/OR	S	Loading contact A/Connecting contact A in series/Connecting contact A in parallel

Device	DX	DY	X	Y	M	SM	S	T	C	HC	D
S	●		●	●	●	○	●	●	●	●	●

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
S	●												

### Symbol




### Explanation

- LD applies to contact A that starts from the main line or contact A which is the start of a contact circuit. Use it to save the current contents, and store the contact state in the accumulative register.
- AND connects contact A in series. It reads the state of the contact that is specified as connected in series, and performs the AND operation with the previous logical operation result. It stores the final result in the accumulative register.
- OR connects contact A in parallel. It reads the state of the contact that is specified as connected in parallel, and performs the OR operation with the previous logical operation result. It stores the final result in the accumulative register.

### Example

- Contact A of X0.0 is loaded, contact A of X0.1 is connected in series, contact A of X0.2 is connected in parallel, and the coil Y0.0 is driven.
- When both X0.0 and X0.1 are ON, or when X0.2 is ON, Y0.0 is ON.




Instruction code	Operand	Function
LDI/ANI/ORI	S	Loading contact B/Connecting contact B in series/Connecting contact B in parallel

Device	DX	DY	X	Y	M	SM	S	T	C	HC	D
S	●		●	●	●	○	●	●	●	●	●

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
S	●												

**Symbol**




**Explanation**

1. LDI applies to contact B that starts from the main line or contact B that is the start of a contact circuit. Use it to save the current contents, and store the contact state in the accumulative register.
2. ANI connects contact B in series. It reads the state of the contact that is specified as connected in series, and performs the AND operation with the previous logical operation result. It stores the final result in the accumulative register.
3. ORI connects contact B in parallel. It reads the state of the contact that is specified as connected in parallel, and performs the OR operation with the previous logical operation result. It stores the final result in the accumulative register.

**Example**

1. Contact B of X0.0 is loaded, contact B of X0.1 is connected in series, contact B of X0.2 is connected in parallel, and the coil Y0.0 is driven.
2. When both X0.0 and X0.1 are ON, or when X0.2 is ON, Y0.0 is ON.



Instruction code	Operand	Function
OUT	D	Driving the coil

Device	DX	DY	X	Y	M	SM	S	T	C	HC	D
D		●		●	●	○	●				●

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
D	●												

**Symbol**




**Explanation**

1. The logical operation result prior to the application of the OUT instruction is output to the specified device.
2. The following table describes the action of the coil contact.

Operation result	OUT		
	Coil	Contact	
		Contact A (normally open)	Contact B (normally closed)
False	OFF	OFF	ON
True	ON	ON	OFF

**Example**

1. Contact B of X0.0 is loaded, contact A of X0.1 is connected in series, and the coil Y0.0 is driven.
2. When X0.0 is OFF, and X0.1 is ON, Y0.0 is ON.



Instruction code		Operand						Function					
SET		D						Keeping the device on					
Device	DX	DY	X	Y	M	SM	S	T	C	HC	D		
D		●		●	●	○	●				●		
Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
D	●												

**Symbol**




**Explanation**


When the instruction SET is driven, the specified device is set to ON. It does not matter if the SET instruction is still driven, the specified device stays ON. You can set the specified device to OFF with the RST instruction.

**Example**

1. Contact B of X0.0 is loaded, contact A of Y0.0 is connected in series, and Y0.1 stays ON.
2. When X0.0 is OFF, and Y0.0 is ON, Y0.1 is ON. Even if the operation result changes, Y0.1 still stays ON.



Instruction code	Operand	Function
MC/MCR	N	Setting/Resetting the master control


**Symbol****Explanation**

- MC sets the master control. When the MC instruction is executed, the instructions between MC and MCR are executed as usual. When the MC instruction is OFF, the actions of the instructions between MC and MCR are as described in the following table.

Instruction type	Description
General-purpose timer	The timer value is reset to zero. The coil and the contact are OFF.
Timer in the function block	The timer value is reset to zero. The coil and the contact are OFF.
Accumulative timer	The coil is OFF. The timer value and the state of the contact remain the same.
Counter	The coil is OFF. The timer value and the state of the contact remain the same.
Coils driven by OUT	All coils are OFF.
Devices driven by SET and RST	The states of the devices remain the same.
Applied instruction	All applied instructions are not executed. The FOR/NEXT loop is still repeated N times, but the actions of the instructions inside the FOR/NEXT loop follow those of the instructions between MC and MR.

- MCR resets the master control, and is placed at the end of the master control program. There should not be any contact instruction before MCR.
- MC/MCR supports the nested program structure. There are at most 32 levels of nested program structures (N0~N31). Refer to the example below.

Example




5

Instruction code	Operand	Function
LDP/ANDP/ORP	S	Starting the rising-edge detection/Connecting the rising-edge detection in series/Connecting the rising-edge detection in parallel

Device	DX	DY	X	Y	M	SM	S	T	C	HC	D
S	●		●	●	●	○	●	●	●	●	●

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
S	●												

**Symbol**




**Explanation**

1. LDP stores the current contents, and stores the rising-edge detection of the contact in the accumulative register.
2. ANDP connects the rising-edge detection of the contact in series.
3. ORP connects the rising-edge detection of the contact in parallel.
4. The system must scan LDP/ANDP/ORP to get the state of the device. Changes to the device state are not detected until LDP/ANDP/ORP is scanned the next time.
5. Use the corresponding PED, APED, and OPED instructions in subroutines.

**Example**

1. The rising-edge detection of X0.0 starts, the rising-edge detection of X0.1 is connected in series, the rising-edge detection of X0.2 is connected in parallel, and the coil Y0.0 is driven.
2. When both X0.0 and X0.1 are switched from OFF to ON, or when X0.2 is switched from OFF to ON, Y0.0 is ON for a scan cycle.




Instruction code	Operand	Function
LDF/ANDF/ORF	S	Starting the falling-edge detection/Connecting the falling-edge detection in series/Connecting the falling-edge detection in parallel

Device	DX	DY	X	Y	M	SM	S	T	C	HC	D
S	●		●	●	●	○	●	●	●	●	●

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
S	●												

**Symbol**




**Explanation**

1. LDF saves the current contents, and stores the contact falling-edge detection in the accumulative register.
2. ANDF connects the falling-edge detection of the contact in series.
3. ORP connects the falling-edge detection of the contact in parallel.
4. The system must scan LDF/ANDF/ORF to get the state of the device. Changes to the device state are not detected until LDF/ANDF/ORF is scanned the next time.
5. Use the corresponding NED, ANED, and ONED instructions in subroutines.

**Example**

1. The falling-edge detection of X0.0 starts, the falling-edge detection of X0.1 is connected in series, the falling-edge detection of X0.2 is connected in parallel, and the coil Y0.0 is driven.
2. When both X0.0 and X0.1 switches from OFF to ON, or when X0.2 switches from OFF to ON, Y0.0 is ON for a scan cycle.




Instruction code		Operand		Function	
PED/APED/OPED		$S_1 \cdot S_2$		Starting the rising-edge detection/Connecting the rising edge-detection in series/Connecting the rising-edge detection in parallel	

Device	DX	DY	X	Y	M	SM	S	T	C	HC	D
$S_1$			●	●	●	○	●	●	●	●	●
$S_2$				●	●		●				●

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
$S_1$	●												
$S_2$	●												

### Symbol




### Explanation

1. PED/APED/OPED correspond to LDP/ANDP/ORP. The only difference between PED/APED/OPED and LDP/ANDP/ORP is that you must specify the bit device  $S_2$  in which to store the previous state of the contact when PED/APED/OPED is executed. Do not use the device  $S_2$  repeatedly in the program. Otherwise, the wrong execution result appears.
2. APED connects the rising-edge detection of the contact in series.
3. OPED connects the rising-edge detection of the contact in parallel.
4. The system must scan PED/APED/OPED to get the state of the device. Changes to the device state are not detected until PED/APED/OPED is scanned the next time
5. You can use PED/APED/OPED only in function blocks.
6. The state of the operation result is automatically output after the instruction is executed. You do not need to use an input device for this.

**Example**

1. The rising-edge detection of X0.0 starts, the rising-edge detection of X0.1 is connected in series, the rising-edge detection of X0.2 is connected in parallel, and the coil Y0.0 is driven.
2. When both X0.0 and X0.1 switch from OFF to ON, or when X0.2 switches from OFF to ON, Y0.0 is ON for a scan cycle.




Instruction code	Operand	Function
NED/ANED/ONED	$S_1 \cdot S_2$	Starting the falling-edge detection/Connecting the falling-edge detection in series/Connecting the falling-edge detection in parallel

Device	DX	DY	X	Y	M	SM	S	T	C	HC	D
$S_1$			●	●	●	○	●	●	●	●	●
$S_2$				●	●		●				●

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
$S_1$	●												
$S_2$	●												

### Symbol




### Explanation

1. NED/ANED/ONED correspond to LDF/ANDF/ORF. The only difference between NED/ANED/ONED and LDF/ANDF/ORF is that you must specify the bit device  $S_2$  in which to store the previous state of the contact when NED/ANED/ONED is executed. Do not use the device  $S_2$  repeatedly in the program. Otherwise, the wrong execution result appears.
2. ANED connects the falling-edge detection of the contact in series.
3. ONED connects the falling-edge detection of the contact in parallel.
4. The system must scan NED/ANED/ONED to get the state of the device. Changes to the device state are not detected until NED/ANED/ONED is scanned the next time
5. You can use NED/ANED/ONED only in function blocks.
6. The state of the operation result is automatically output after the instruction is executed. You do not need to use input device for this.

**Example**

1. The falling -edge detection of X0.0 starts, the falling -edge detection of X0.1 is connected in series, the falling -edge detection of X0.2 is connected in parallel, and the coil Y0.0 is driven.
2. When both X0.0 and X0.1 switch from OFF to ON, or when X0.2 switches from OFF to ON, Y0.0 is ON for a scan cycle.



Instruction code		Operand										Function	
PLS		D										Rising-edge output	
Device	DX	DY	X	Y	M	SM	S	T	C	HC	D		
D				●	●	○	●				●		
Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
D	●												

**Symbol**




**Explanation**


1. When the conditional contact switches from OFF to ON, the PLS instruction is executed, and the device D sends out a pulse for a scan cycle.
2. Do not use the PLS instruction in function blocks.
3. ISPSOft V3.06.01 supports data type D and the BOOL type variable for declaration.

**Example**

When X0.0 is ON, M0 is ON for a pulse time. When M0 is ON, Y0.0 is set to ON.



**Timing diagram**



Instruction code		Operand						Function					
PLF		D						Falling-edge output					
Device	DX	DY	X	Y	M	SM	S	T	C	HC	D		
D				●	●	○	●				●		
Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
D	●												

Symbol




Explanation


1. When the conditional contact switches from ON to OFF, the instruction PLF is executed, and the device D sends out a pulse for a scan cycle.
2. Do not use the instruction PLS in function blocks.
3. ISPSOft V3.17 supports data type D and the BOOL type variable for declaration.

Example


When X0.0 is ON, M0 is ON for a pulse time. When M0 is ON, Y0.0 is set to ON.



Timing chart




Instruction code	Operand	Function
INV	-	Inverting the logical operation result

**Symbol****Explanation**

The logical operation result preceding the INV instruction is inverted, and the inversion result stored in the accumulative register.

**Example**

When X0.0 is ON, Y0.0 is OFF. When X0.0 is OFF, Y0.0 is ON.



Instruction code	Operand	Function
NP	-	Triggering the circuit on the rising edge.


**Symbol**



**Explanation**


1. When the value in the accumulative register switches from 0 to 1, the NP instruction keeps the value 1 in the accumulative register for a scan cycle. After the second scan cycle is finished, the value in the accumulative register changes to 0.
2. Use the FB\_NP instruction in function blocks.

**Example**




Instruction	Operation
LD M0	Contact A of M0 is loaded.
AND M1	Contact A of M1 is connected in series.
NP	The circuit is rising edge-triggered.
OUT Y0.0	The coil Y0.0 is driven.

**Timing diagram**




5


Instruction code	Operand	Function
PN	-	Triggering the circuit on the falling edge.

**Symbol****Explanation**

- When the value in the accumulative register switches from 1 to 0, the PN instruction keeps the value 1 in the accumulative register for a scan cycle. After the second scan cycle is finished, the value in the accumulative register changes to 0.
- Use the FB\_PN instruction in function blocks.

**Example**

Instruction	Operation
LD M0	Contact A of M0 is loaded.
AND M1	Contact A of M1 is connected in series.
PN	The circuit is falling edge-triggered.
OUT Y0.0	The coil Y0.0 is driven.

**Timing diagram**

Instruction code		Operand						Function					
FB_NP		<b>S</b>						Triggering the circuit on the rising edge.					
Device	DX	DY	X	Y	M	SM	S	T	C	HC	D		
<b>S</b>				●	●		●				●		
Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
<b>S</b>	●												


**Symbol**



**Explanation**


1. When the value in the accumulative register turns from 0 to 1, the FB\_NP instruction keeps the value 1 in the accumulative register for a scan cycle. After the second scan cycle is finished, the value in the accumulative register changes to 0.
2. The previous state of the contact is stored in the bit device **S**. Do not use **S** repeatedly in the program. Otherwise, the wrong execution result appears.
3. Use FB\_NP only in function blocks.

**Example**



Instruction		Operation
LD	M0	Contact A of M0 is loaded.
AND	M1	Contact A of M1 is connected in series.
<b>FB_NP</b>	D0.0	The circuit is rising edge-triggered.
OUT	Y0.0	The coil Y0.0 is driven.

**Timing diagram**



Instruction code		Operand						Function					
FB_PN		S						Triggering the circuit on the falling edge.					
Device	DX	DY	X	Y	M	SM	S	T	C	HC	D		
S				●	●		●				●		
Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
S	●												


**Symbol**



**Explanation**


1. When the value in the accumulative register switches from 1 to 0, the FB\_PN instruction keeps the value 1 in the accumulative register for a scan cycle. After the second scan cycle is finished, the value in the accumulative register changes to 0.
2. The previous state of the contact is stored in the bit device **S**. Do not use **S** repeatedly in the program. Otherwise, the wrong execution result appears.
3. Use FB\_PN only in function blocks.

**Example**



Instruction	Operand	Operation
LD	M0	Contact A of M0 is loaded.
AND	M1	Contact A of M1 is connected in series.
<b>FB_PN</b>	D0.0	The circuit is falling edge-triggered.
OUT	Y0.0	The coil Y0.0 is driven.

**Timing diagram**



**MEMO**



---

## Chapter 6 Applied Instructions

### Table of Contents

<b>6.1 Comparison Instructions</b> .....	<b>6-4</b>
6.1.1 List of Comparison Instructions .....	6-4
6.1.2 Explanation of Comparison Instructions.....	6-7
<b>6.2 Arithmetic Instructions</b> .....	<b>6-46</b>
6.2.1 List of Arithmetic Instructions .....	6-46
6.2.2 Explanation of Arithmetic Instructions.....	6-47
<b>6.3 Data Conversion Instructions</b> .....	<b>6-78</b>
6.3.1 List of Data Conversion Instructions .....	6-78
6.3.2 Explanation of Data Conversion Instructions .....	6-79
<b>6.4 Data Transfer Instructions</b> .....	<b>6-122</b>
6.4.1 List of Data Transfer Instructions.....	6-122
6.4.2 Explanation of Data Transfer Instructions .....	6-123
<b>6.5 Jump Instructions</b> .....	<b>6-150</b>
6.5.1 List of Jump Instructions.....	6-150
6.5.2 Explanation of Jump Instructions.....	6-151
<b>6.6 Program Execution Instructions</b> .....	<b>6-159</b>
6.6.1 List of Program Execution Instructions .....	6-159
6.6.2 Explanation of Program Execution Instructions .....	6-160
<b>6.7 IO Refreshing Instructions</b> .....	<b>6-172</b>
6.7.1 List of IO Refreshing Instructions .....	6-172
6.7.2 Explanation of IO Refreshing Instructions .....	6-173
<b>6.8 Miscellaneous Instructions</b> .....	<b>6-181</b>
6.8.1 List of Convenience Instructions.....	6-181
6.8.2 Explanation of Convenience Instructions.....	6-182
<b>6.9 Logic Instructions</b> .....	<b>6-235</b>
6.9.1 List of Logic Instructions .....	6-235
6.9.2 Explanation of Logic Instructions .....	6-236
<b>6.10 Rotation Instructions</b> .....	<b>6-257</b>
6.10.1 List of Rotation Instructions .....	6-257
6.10.2 Explanation of Rotation Instructions.....	6-258

<b>6.11 Timer and Counter Instructions</b> .....	<b>6-269</b>
6.11.1 List of Timer and Counter Instructions .....	6-269
6.11.2 Explanation of Timer and Counter Instructions .....	6-270
<b>6.12 Shift Instructions</b> .....	<b>6-317</b>
6.12.1 List of Shift Instructions.....	6-317
6.12.2 Explanation of Shift Instructions.....	6-318
<b>6.13 Data Processing Instructions</b> .....	<b>6-359</b>
6.13.1 List of Data Processing Instructions .....	6-359
6.13.2 Explanation of Data Processing Instructions .....	6-360
<b>6.14 Structure Creation Instructions</b> .....	<b>6-425</b>
6.14.1 List of Structure Creation Instructions.....	6-425
6.14.2 Explanation of Structure Creation Instructions.....	6-426
<b>6.15 Module Instructions</b> .....	<b>6-434</b>
6.15.1 List of Module Instructions .....	6-434
6.15.2 Explanation of Module Instructions .....	6-435
<b>6.16 Floating-point Number Instructions</b> .....	<b>6-560</b>
6.16.1 List of Floating-point Number Instructions .....	6-560
6.16.2 Explanation of Floating-point Number Instructions .....	6-561
<b>6.17 Real-time Clock Instructions</b> .....	<b>6-596</b>
6.17.1 List of Real-time Clock Instructions.....	6-596
6.17.2 Explanation of Real-time Clock Instructions .....	6-597
<b>6.18 Peripheral Instructions</b> .....	<b>6-628</b>
6.18.1 List of Peripheral Instructions .....	6-628
6.18.2 Explanation of Peripheral Instructions .....	6-629
<b>6.19 Communication Instructions</b> .....	<b>6-645</b>
6.19.1 List of Communication Instructions.....	6-645
6.19.2 Explanation of Communication Instructions.....	6-646
6.19.3 Descriptions on the Communication-related Flags and Registers .....	6-733
<b>6.20 Other Instructions</b> .....	<b>6-737</b>
6.20.1 List of Other Instructions .....	6-737
6.20.2 Explanation of Other Instructions .....	6-738
<b>6.21 String Processing Instructions</b> .....	<b>6-750</b>
6.21.1 List of String Processing Instructions .....	6-750
6.21.2 Explanation of String Processing Instructions .....	6-751
<b>6.22 Ethernet Instructions</b> .....	<b>6-814</b>
6.22.1 List of Ethernet Instructions .....	6-814
6.22.2 Explanation of Ethernet Instructions .....	6-815

<b>6.23 Memory Card Instructions</b> .....	<b>6-878</b>
6.23.1 List of Memory Card Instructions .....	6-878
6.23.2 Explanation of Memory Card Instructions.....	6-879
<b>6.24 Task Control Instructions</b> .....	<b>6-904</b>
6.24.1 List of Task Control Instructions .....	6-904
6.24.2 Explanation of Task Control Instructions .....	6-905
<b>6.25 SFC Instructions</b> .....	<b>6-909</b>
6.25.1 List of SFC Instructions .....	6-909
6.25.2 Explanation of SFC Instructions.....	6-910
<b>6.26 High-speed Output Instructions</b> .....	<b>6-917</b>
6.26.1 List of High-speed Output Instructions .....	6-917
6.26.2 Explanation of High-speed Output Instructions .....	6-918
<b>6.27 Delta CANopen Communication Instructions</b> .....	<b>6-1032</b>
6.27.1 List of Delta CANopen Communication Instructions .....	6-1032
6.27.2 Explanation of Delta CANopen Communication Instructions .....	6-1033
6.27.3 Frequently asked questions in Delta special CANopen communication and Troubleshooting.....	6-1116

## 6.1 Comparison Instructions

### 6.1.1 List of Comparison Instructions

The following table lists the Comparison instructions covered in this section.

API	Instruction code		Pulse instruction	Function
	16-bit	32-bit		
<b>0000</b>	LD=	DLD=	–	S1 = S2
<b>0001</b>	LD<>	DLD<>	–	S1≠S2
<b>0002</b>	LD>	DLD>	–	S1 > S2
<b>0003</b>	LD>=	DLD>=	–	S1 ≥ S2
<b>0004</b>	LD<	DLD<	–	S1 < S2
<b>0005</b>	LD<=	DLD<=	–	S1 ≤ S2
<b>0006</b>	AND=	DAND=	–	S1 = S2
<b>0007</b>	AND<>	DAND<>	–	S1≠S2
<b>0008</b>	AND>	DAND>	–	S1 > S2
<b>0009</b>	AND>=	DAND>=	–	S1 ≥ S2
<b>0010</b>	AND<	DAND<	–	S1 < S2
<b>0011</b>	AND<=	DAND<=	–	S1 ≤ S2
<b>0012</b>	OR=	DOR=	–	S1 = S2
<b>0013</b>	OR<>	DOR<>	–	S1 ≠ S2
<b>0014</b>	OR>	DOR>	–	S1 > S2
<b>0015</b>	OR>=	DOR>=	–	S1 ≥ S2
<b>0016</b>	OR<	DOR<	–	S1 < S2
<b>0017</b>	OR<=	DOR<=	–	S1 ≤ S2
<b>0018</b>	–	FLD=	–	S1 = S2
<b>0019</b>	–	FLD<>	–	S1≠S2
<b>0020</b>	–	FLD>	–	S1 > S2
<b>0021</b>	–	FLD>=	–	S1 ≥ S2
<b>0022</b>	–	FLD<	–	S1 < S2
<b>0023</b>	–	FLD<=	–	S1 ≤ S2
<b>0024</b>	–	FAND=	–	S1 = S2
<b>0025</b>	–	FAND<>	–	S1≠S2
<b>0026</b>	–	FAND>	–	S1 > S2
<b>0027</b>	–	FAND>=	–	S1 ≥ S2
<b>0028</b>	–	FAND<	–	S1 < S2
<b>0029</b>	–	FAND<=	–	S1 ≤ S2
<b>0030</b>	–	FOR=	–	S1 = S2
<b>0031</b>	–	FOR<>	–	S1≠S2

API	Instruction code		Pulse instruction	Function
	16-bit	32-bit		
<b>0032</b>	–	FOR>	–	$S1 > S2$
<b>0033</b>	–	FOR>=	–	$S1 \geq S2$
<b>0034</b>	–	FOR<	–	$S1 < S2$
<b>0035</b>	–	FOR<=	–	$S1 \leq S2$
<b>0036</b>	LD\$=	–	–	$S1 = S2$
<b>0037</b>	LD\$<>	–	–	$S1 \neq S2$
<b>0042</b>	AND\$=	–	–	$S1 = S2$
<b>0043</b>	AND\$<>	–	–	$S1 \neq S2$
<b>0048</b>	OR\$=	–	–	$S1 = S2$
<b>0049</b>	OR\$<>	–	–	$S1 \neq S2$
<b>0054</b>	CMP	DCMP	✓	Comparing values
<b>0055</b>	ZCP	DZCP	✓	Zone comparison
<b>0056</b>	–	FCMP	✓	Comparing the floating-point numbers
<b>0057</b>	–	FZCP	✓	Floating-point zone comparison
<b>0058</b>	MCMP	–	✓	Matrix comparison
<b>0059</b>	CMPT=	–	✓	Comparing tables ON: =
<b>0060</b>	CMPT<>	–	✓	Comparing tables ON: <>
<b>0061</b>	CMPT>	–	✓	Comparing tables ON: >
<b>0062</b>	CMPT>=	–	✓	Comparing tables ON: $\geq$
<b>0063</b>	CMPT<	–	✓	Comparing tables ON: <
<b>0064</b>	CMPT<=	–	✓	Comparing tables ON: $\leq$
<b>0065</b>	CHKADR	–	–	Checking the address in a pointer register
<b>0066</b>	LDZ=	DLDZ=	–	$ S1-S2 = S3 $
<b>0067</b>	LDZ<>	DLDZ<>	–	$ S1-S2 \neq S3 $
<b>0068</b>	LDZ>	DLDZ>	–	$ S1-S2  >  S3 $
<b>0069</b>	LDZ>=	DLDZ>=	–	$ S1-S2  \geq  S3 $
<b>0070</b>	LDZ<	DLDZ<	–	$ S1-S2  <  S3 $
<b>0071</b>	LDZ<=	DLDZ<=	–	$ S1-S2  \leq  S3 $
<b>0072</b>	ANDZ=	DANDZ=	–	$ S1-S2 = S3 $
<b>0073</b>	ANDZ<>	DANDZ<>	–	$ S1-S2 \neq S3 $
<b>0074</b>	ANDZ>	DANDZ>	–	$ S1-S2  >  S3 $
<b>0075</b>	ANDZ>=	DANDZ>=	–	$ S1-S2  \geq  S3 $

API	Instruction code		Pulse instruction	Function
	16-bit	32-bit		
<b>0076</b>	ANDZ<	DANDZ<	–	$ S1-S2  <  S3 $
<b>0077</b>	ANDZ<=	DANDZ<=	–	$ S1-S2  \leq  S3 $
<b>0078</b>	ORZ=	DORZ=	–	$ S1-S2 = S3 $
<b>0079</b>	ORZ<>	DORZ<>	–	$ S1-S2  \neq  S3 $
<b>0080</b>	ORZ>	DORZ>	–	$ S1-S2  >  S3 $
<b>0081</b>	ORZ>=	DORZ>=	–	$ S1-S2  \geq  S3 $
<b>0082</b>	ORZ<	DORZ<	–	$ S1-S2  <  S3 $
<b>0083</b>	ORZ<=	DORZ<=	–	$ S1-S2  \leq  S3 $

### 6.1.2 Explanation of Comparison Instructions


API	Instruction code			Operand							Function						
0000-0005	D	LD※		S <sub>1</sub> · S <sub>2</sub>							Comparing values LD※						

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	“\$”	F
S <sub>1</sub>	●	●			●	●	●	●	●		○	○	○	○		
S <sub>2</sub>	●	●			●	●	●	●	●		○	○	○	○		

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
S <sub>1</sub>		●	●			●	●				●	●	
S <sub>2</sub>		●	●			●	●				●	●	

Pulse instruction	16-bit instruction	32-bit instruction
-	AS	AS

**Symbol**



S<sub>1</sub> : Data source 1

S<sub>2</sub> : Data source 1

Taking LD= and DLD= for example


**Explanation**

- These instructions compare the values in S<sub>1</sub> and S<sub>2</sub>. Take the LD= instruction for example. When the comparison result is that the value in S<sub>1</sub> is equal to that in S<sub>2</sub>, the continuity condition of the instruction is met. When the comparison result is that the value in S<sub>1</sub> is not equal to that in S<sub>2</sub>, the discontinuity condition of the instruction is met.
- Only the 32-bit instruction can use the 32-bit counter, but not the device E.

API number	16-bit instruction	32-bit instruction	Continuity condition	Discontinuity condition
0000	LD =	DLD =	S <sub>1</sub> = S <sub>2</sub>	S <sub>1</sub> ≠ S <sub>2</sub>
0001	LD < >	DLD < >	S <sub>1</sub> ≠ S <sub>2</sub>	S <sub>1</sub> = S <sub>2</sub>
0002	LD >	DLD >	S <sub>1</sub> > S <sub>2</sub>	S <sub>1</sub> ≤ S <sub>2</sub>
0003	LD > =	DLD > =	S <sub>1</sub> ≥ S <sub>2</sub>	S <sub>1</sub> < S <sub>2</sub>
0004	LD <	DLD <	S <sub>1</sub> < S <sub>2</sub>	S <sub>1</sub> ≥ S <sub>2</sub>
0005	LD < =	DLD < =	S <sub>1</sub> ≤ S <sub>2</sub>	S <sub>1</sub> > S <sub>2</sub>

**Example**

- When the value in C10 is equal to 200, Y0.10 is ON.
- When the value in D200 is greater than -30, Y0.11 stays ON.
- When the value in (C201, C200) is less than 678,493, or when M3 is ON, M50 is ON.




API	Instruction code			Operand								Function					
0006-0011	D	AND※		$S_1 \cdot S_2$								Comparing values AND※					

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	“\$”	F
$S_1$	●	●			●	●	●	●	●		○	○	○	○		
$S_2$	●	●			●	●	●	●	●		○	○	○	○		

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
$S_1$		●	●			●	●				●	●	
$S_2$		●	●			●	●				●	●	

Pulse instruction	16-bit instruction	32-bit instruction
-	AS	AS

**Symbol**



$S_1$  : Data source 1  
 $S_2$  : Data source 2

Taking AND= and DAND= for example


**Explanation**

- These instructions compare the values in  $S_1$  and  $S_2$ . Take the AND= instruction for example. When the comparison result is that the value in  $S_1$  is equal to that in  $S_2$ , the continuity condition of the instruction is met. When the comparison result is that the value in  $S_1$  is not equal to that in  $S_2$ , the discontinuity condition of the instruction is met.
- Only the 32-bit instruction can use the 32-bit counter, but not the device E.

API number	16-bit instruction	32-bit instruction	Continuity condition	Discontinuity condition
0006	AND =	DAND =	$S_1 = S_2$	$S_1 \neq S_2$
0007	AND < >	DAND < >	$S_1 \neq S_2$	$S_1 = S_2$
0008	AND >	DAND >	$S_1 > S_2$	$S_1 \leq S_2$
0009	AND > =	DAND > =	$S_1 \geq S_2$	$S_1 < S_2$
0010	AND <	DAND <	$S_1 < S_2$	$S_1 \geq S_2$
0011	AND < =	DAND < =	$S_1 \leq S_2$	$S_1 > S_2$

**Example**

- When X0.0 is ON and the current value in C10 is equal to 100, Y0.10 is ON.
- When X0.1 is OFF and the value in D0 is not equal to -10, Y0.11 stays ON.
- When X0.2 is ON and the value in (D11, D10) is less than 678,493, or when M3 is ON, M50 is ON.




API	Instruction code			Operand								Function				
0012-0017	D	OR※		$S_1 \cdot S_2$								Comparing values OR※				

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
$S_1$	●	●			●	●	●	●	●		○	○	○	○		
$S_2$	●	●			●	●	●	●	●		○	○	○	○		

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
$S_1$		●	●			●	●				●	●	
$S_2$		●	●			●	●				●	●	

Pulse Instruction	16-bit instruction	32-bit instruction
-	AS	AS

Symbol



$S_1$  : Data source 1

$S_2$  : Data source 2

Taking OR= and DOR= for example


Explanation

1. These instructions compare the values in  $S_1$  and  $S_2$ . Take the OR= instruction for example. When the comparison result is that the value in  $S_1$  is equal to that in  $S_2$ , the continuity condition of the instruction is met. When the comparison result is that the value in  $S_1$  is not equal to that in  $S_2$ , the discontinuity condition of the instruction is met.
2. Only the 32-bit instruction can use the 32-bit counter, but not the device E.

API number	16-bit instruction	32-bit instruction	Continuity condition	Discontinuity condition
0012	OR =	DOR =	$S_1 = S_2$	$S_1 \neq S_2$
0013	OR < >	DOR < >	$S_1 \neq S_2$	$S_1 = S_2$
0014	OR >	DOR >	$S_1 > S_2$	$S_1 \leq S_2$
0015	OR > =	DOR > =	$S_1 \geq S_2$	$S_1 < S_2$
0016	OR <	DOR <	$S_1 < S_2$	$S_1 \geq S_2$
0017	OR < =	DOR < =	$S_1 \leq S_2$	$S_1 > S_2$

Example

1. When X0.1 is ON, or when the current value in C10 is equal to 100, Y0.10 is ON.
2. When both X0.2 and M30 are ON, or when the value in (D101, D100) is greater than or equal to 1000,000, M60 is ON.



API	Instruction code			Operand							Function						
0018-0023	FLD※			$S_1 \cdot S_2$							Comparing floating-point numbers LD※						

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
<b>S<sub>1</sub></b>	●	●			●	●	●	●	●		○					○
<b>S<sub>2</sub></b>	●	●			●	●	●	●	●		○					○

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
<b>S<sub>1</sub></b>									●				
<b>S<sub>2</sub></b>									●				

Pulse Instruction	16-bit instruction	32-bit instruction
-	-	AS

Symbol



Taking FLD= for example

**S<sub>1</sub>** : Data source 1

**S<sub>2</sub>** : Data source 2


Explanation

- These instructions compare the 32-bit single precision floating point number
- Compare values in **S<sub>1</sub>** and **S<sub>2</sub>**. Take the FLD= instruction for example. When the comparison result is that the value in **S<sub>1</sub>** is equal to that in **S<sub>2</sub>**, the continuity condition of the instruction is met. When the comparison result is that the value in **S<sub>1</sub>** is not equal to that in **S<sub>2</sub>**, the discontinuity condition of the instruction is met. Refer to Additional Remarks point 2 below for more information on the instruction of FLD=.

API number	32-bit instruction	Continuity condition	Discontinuity condition
0018	FLD =	$S_1 = S_2$	$S_1 \neq S_2$
0019	FLD < >	$S_1 \neq S_2$	$S_1 = S_2$
0020	FLD >	$S_1 > S_2$	$S_1 \leq S_2$
0021	FLD > =	$S_1 \geq S_2$	$S_1 < S_2$
0022	FLD <	$S_1 < S_2$	$S_1 \geq S_2$
0023	FLD < =	$S_1 \leq S_2$	$S_1 > S_2$

**Example**

Take the FLD = instruction for example. When the value in D0 is equal to that in D2, Y0.0 is ON.

**Additional remarks**

1. If the value in **S<sub>1</sub>** or **S<sub>2</sub>** exceeds the range of values that can be represented by floating-point numbers, the contact is OFF, SM is ON, and the error code in SR0 is 16#2013.
2. If the floating-point value in **S<sub>1</sub>** or **S<sub>2</sub>** is from external input, or from ISPSOft, chances are a minor value difference may occur and the result of the "FLD=" instruction may not be dependable. Use instructions "FLD<" and "FAND>" or "FLD>" and "FAND<" instead when the floating-point value in **S<sub>1</sub>** or **S<sub>2</sub>** is from external input, or from ISPSOft.


API	Instruction code			Operand								Function				
0024-0029	FAND※			$S_1 \cdot S_2$								Comparing floating-point numbers AND※				

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
S <sub>1</sub>	●	●			●	●	●	●	●		○					○
S <sub>2</sub>	●	●			●	●	●	●	●		○					○

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
S <sub>1</sub>									●				
S <sub>2</sub>									●				

Pulse Instruction	16-bit instruction	32-bit instruction
-	-	AS

Symbol



S<sub>1</sub> : Data source 1

S<sub>2</sub> : Data source 2

Taking FAND= and DFAND= for example


Explanation

1. These instructions compare the 32-bit single precision floating point numbers
2. Compare values in S<sub>1</sub> and S<sub>2</sub>. Take the FAND= instruction for example. When the comparison result is that the value in S<sub>1</sub> is equal to that in S<sub>2</sub>, the continuity condition of the instruction is met. When the comparison result is that the value in S<sub>1</sub> is not equal to that in S<sub>2</sub>, the discontinuity condition of the instruction is met.

API number	32-bit instruction	Continuity condition	Discontinuity condition
0024	FAND =	$S_1 = S_2$	$S_1 \neq S_2$
0025	FAND < >	$S_1 \neq S_2$	$S_1 = S_2$
0026	FAND >	$S_1 > S_2$	$S_1 \leq S_2$
0027	FAND > =	$S_1 \geq S_2$	$S_1 < S_2$
0028	FAND <	$S_1 < S_2$	$S_1 \geq S_2$
0029	FAND < =	$S_1 \leq S_2$	$S_1 > S_2$

**Example**

Take the instruction FAND = for example. When X1.0 is ON and the value in D1 is equal to that in D2, Y1.0 is ON.

**Additional remarks**

1. If the value in **S<sub>1</sub>** or **S<sub>2</sub>** exceeds the range of values that can be represented by floating-point numbers, the contact is OFF, SM is ON, and the error code in SR0 is 16#2013.

API	Instruction code			Operand							Function					
0030-0035	FOR※			$S_1 \cdot S_2$							Comparing floating-point numbers OR※					

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	“\$”	F
S <sub>1</sub>	●	●			●	●	●	●	●		○					○
S <sub>2</sub>	●	●			●	●	●	●	●		○					○

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
S <sub>1</sub>									●				
S <sub>2</sub>									●				

Pulse Instruction	16-bit instruction	32-bit instruction
-	-	AS

Symbol



S<sub>1</sub> : Data source1  
S<sub>2</sub> : Data source2

Taking FOR= and DFOR= for example


Explanation

- These instructions compare the 32-bit single precision floating point numbers.
- Compare values in S<sub>1</sub> and S<sub>2</sub>. Take the FOR= instruction for example. When the comparison result is that the value in S<sub>1</sub> is equal to that in S<sub>2</sub>, the continuity condition of the instruction is met. When the comparison result is that the value in S<sub>1</sub> is not equal to that in S<sub>2</sub>, the discontinuity condition of the instruction is met.

API number	32-bit instruction	Continuity condition	Discontinuity condition
0030	FOR =	$S_1 = S_2$	$S_1 \neq S_2$
0031	FOR < >	$S_1 \neq S_2$	$S_1 = S_2$
0032	FOR >	$S_1 > S_2$	$S_1 \leq S_2$
0033	FOR > =	$S_1 \geq S_2$	$S_1 < S_2$
0034	FOR <	$S_1 < S_2$	$S_1 \geq S_2$
0035	FOR < =	$S_1 \leq S_2$	$S_1 > S_2$

**Example**

When X1.0 is ON, or when the value in D1 is equal to that in D2, Y1.0 is ON.

**Additional remarks**

1. If the value in **S<sub>1</sub>** or **S<sub>2</sub>** exceeds the range of values that can be represented by floating-point numbers, the contact is OFF, SM is ON, and the error code in SR0 is 16#2013.


API	Instruction code	Operand	Function
0036-0037	LD\$※	S <sub>1</sub> · S <sub>2</sub>	Comparing strings LD\$※

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
S <sub>1</sub>	●	●			●	●		●	●						○	
S <sub>2</sub>	●	●			●	●		●	●						○	

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
S <sub>1</sub>													●
S <sub>2</sub>													●

Pulse Instruction	16-bit instruction	32-bit instruction
-	AS	-

Symbol



S<sub>1</sub> : Data source1  
 S<sub>2</sub> : Data source2


Taking LD\$= for example

Explanation


- These instructions compare the strings in S<sub>1</sub> and S<sub>2</sub>.
- S<sub>1</sub> and S<sub>2</sub> can contain strings up to 256 characters(16#00 the end symbol is included).
- Take the instruction LD\$= for example. When the comparison result is that the value in S<sub>1</sub> is equal to that in S<sub>2</sub>, the continuity condition of the instruction is met. When the comparison result is that the value in S<sub>1</sub> is not equal to that in S<sub>2</sub>, the discontinuity condition of the instruction is met.

API number	16-bit instruction	Continuity condition	Discontinuity condition
0036	LD\$ =	S <sub>1</sub> = S <sub>2</sub>	S <sub>1</sub> ≠ S <sub>2</sub>
0037	LD\$ < >	S <sub>1</sub> ≠ S <sub>2</sub>	S <sub>1</sub> = S <sub>2</sub>

- Only when the data in S-S+n (n indicates the n<sup>th</sup> device, up to 256 characters in each string) includes 16#00 can the data be compared complete strings. For example:




5. When the two strings are the same, the corresponding comparison results of the instructions are listed below. For example:



Comparison symbol	Comparison operation result
\$ =	Continuity
\$ < >	Discontinuity

**Example**

When the string starting with the data in D0-16#00 is equal to the string starting with D2-16#00, Y0.0 is ON.



**Additional remarks**

1. If the string contains more than 256 characters or the string does not end with 16#00, the instruction is not executed, SM is ON, and the error code in SR0 is 16#200E.
2. During the string comparison, the string ends when the end symbol 16#00 is found. The symbol 16#00 determines the length of the string.


API	Instruction code		Operand						Function					
0042-0043		AND\$※	$S_1 \cdot S_2$						Comparing strings AND\$※					

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
<b>S<sub>1</sub></b>	●	●			●	●		●	●						○	
<b>S<sub>2</sub></b>	●	●			●	●		●	●						○	

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
<b>S<sub>1</sub></b>													●
<b>S<sub>2</sub></b>													●

Pulse Instruction	16-bit instruction	32-bit instruction
-	AS	-

**Symbol**



**S<sub>1</sub>** : Data source1  
**S<sub>2</sub>** : Data source2


Taking AND\$= for example

**Explanation**


1. These instructions compare the strings in **S<sub>1</sub>** and **S<sub>2</sub>**.
2. **S<sub>1</sub>** and **S<sub>2</sub>** can contain string up to 256 characters (16#00 the end symbol is included).
3. Take the AND\$= instruction for example. When the comparison result is that the value in **S<sub>1</sub>** is equal to that in **S<sub>2</sub>**, the continuity condition of the instruction is met. When the comparison result is that the value in **S<sub>1</sub>** is not equal to that in **S<sub>2</sub>**, the discontinuity condition of the instruction is met.

API number	16-bit instruction	Continuity condition	Discontinuity condition
0042	AND\$ =	<b>S<sub>1</sub> = S<sub>2</sub></b>	<b>S<sub>1</sub> ≠ S<sub>2</sub></b>
0043	AND\$ < >	<b>S<sub>1</sub> ≠ S<sub>2</sub></b>	<b>S<sub>1</sub> = S<sub>2</sub></b>

Only when the data in **S-S+n** (n indicates the n<sup>th</sup> device, up to 256 characters in each string) includes 16#00 can the instruction compare the data as complete strings. For example:




4. When two strings are the same, the corresponding comparison operation results of the instructions are listed below. For example:



Comparison symbol	Comparison operation result
\$ =	Continuity
\$ < >	Discontinuity

**Example**

When the string starting with the data in D0-16#00 is equal to the string starting with D2-16#00, Y0.0 is ON.



**Additional remarks**

1. If the string contains more than 256 characters or the string does not end with 16#00, the instruction is not executed, SM is ON, and the error code in SR0 is 16#200E.
2. During the string comparison, the string ends when the end symbol 16#00 is found. The symbol 16#00 determines the length of the string.


API	Instruction code	Operand	Function
0048-0049	OR\$※	S <sub>1</sub> · S <sub>2</sub>	Comparing strings OR\$※

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
S <sub>1</sub>	●	●			●	●		●	●						○	
S <sub>2</sub>	●	●			●	●		●	●						○	

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
S <sub>1</sub>													●
S <sub>2</sub>													●

Pulse Instruction	16-bit instruction	32-bit instruction
-	AS	-

Symbol



S<sub>1</sub> : Data source1

S<sub>2</sub> : Data source2


Taking OR\$= for example

Explanation


1. These instructions compare the strings in S<sub>1</sub> and S<sub>2</sub>.
2. S<sub>1</sub> and S<sub>2</sub> can contain up to 256 characters (16#00 the end symbol is included).
3. Take the instruction OR\$= for example. When the comparison result is that the value in S<sub>1</sub> is equal to that in S<sub>2</sub>, the continuity condition of the instruction is met. When the comparison result is that the value in S<sub>1</sub> is not equal to that in S<sub>2</sub>, the discontinuity condition of the instruction is met.

API number	16-bit instruction	Continuity condition	Discontinuity condition
0048	OR\$ =	S <sub>1</sub> = S <sub>2</sub>	S <sub>1</sub> ≠ S <sub>2</sub>
0049	OR\$ < >	S <sub>1</sub> ≠ S <sub>2</sub>	S <sub>1</sub> = S <sub>2</sub>

Only when the data in S-S+n (n indicates the n<sup>th</sup> device, up to 256 characters in each string) includes 16#00 can the instruction compare the data as complete strings. For example:




4. When two strings are the same, the corresponding comparison operation results of the instructions are listed below. For example:



Comparison symbol	Comparison operation result
\$ =	Continuity
\$ < >	Discontinuity

**Example**

When the string starting with the data in D0-16#00 is equal to the string starting with D2-16#00, Y0.0 is ON.



**6**

**Additional remarks**

1. If the string contains more than 256 characters or the string does not end with 16#00, the instruction is not executed, SM is ON, and the error code in SR0 is 16#200E.
2. During the string comparison, the string ends when the end symbol 16#00 is found. The symbol 16#00 determines the length of the string.


API	Instruction code			Operand								Function					
0054	D	CMP		P	<b>S<sub>1</sub> · S<sub>2</sub> · D</b>								Comparing values				

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	“\$”	F
<b>S<sub>1</sub></b>	●	●			●	●	●	●	●		○	○	○	○		
<b>S<sub>2</sub></b>	●	●			●	●	●	●	●		○	○	○	○		
<b>D</b>		●	●	●				●								

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
<b>S<sub>1</sub></b>		●	●			●	●				●	●	
<b>S<sub>2</sub></b>		●	●			●	●				●	●	
<b>D</b>	●												

Pulse Instruction	16-bit instruction	32-bit instruction
AS	AS	AS

**Symbol**




- S<sub>1</sub>** : Comparison value1
- S<sub>2</sub>** : Comparison value2
- D** : Comparison result

**Explanation**


1. These instructions compare the single decimal numbers in **S<sub>1</sub>** and **S<sub>2</sub>** and store the comparison results in **D**.
2. The operand **D** occupies 3 consecutive devices. The comparison results are stored in **D**, **D+1**, and **D+2**. If the value in **S<sub>1</sub>** is greater than the value in **S<sub>2</sub>**, **D** is ON. If the value in **S<sub>1</sub>** is equal to the value in **S<sub>2</sub>**, **D+1** is ON. If the value in **S<sub>1</sub>** is less than the value in **S<sub>2</sub>**, **D+2** is ON.
3. Only the DCMP and DCMPP instructions can use the 32-bit counter, but not the device E.

**Example**

1. If the operand **D** is M0, the comparison results are stored in M0, M1 and M2, as shown below.
2. When X0.0 is ON, the CMP instruction is executed. M0, M1, or M2 is ON. When X0.0 is OFF, the execution of the CMP instruction stops and the state of M0, the state of M1, and the state of M2 remain unchanged.



3. If you need to clear the comparison result, use the RST or ZRST instruction.



#### Additional remarks

1. If you declare the operand **D** in ISPSOft, the data type is ARRAY [3] of BOOL.
2. If **D+2** exceeds the device range, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2003.


API	Instruction code			Operand							Function						
0055	D	ZCP	P	$S_1 \cdot S_2 \cdot S \cdot D$							Zone comparison						

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
$S_1$	●	●			●	●	●	●	●		○	○	○	○		
$S_2$	●	●			●	●	●	●	●		○	○	○	○		
$S$	●	●			●	●	●	●	●		○	○	○	○		
$D$		●	●	●				●								

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
$S_1$		●	●			●	●				●	●	
$S_2$		●	●			●	●				●	●	
$S$		●	●			●	●				●	●	
$D$	●												

Pulse Instruction	16-bit instruction	32-bit instruction
AS	AS	AS

Symbol




- S1** : Minimum value of the zone comparison
- S2** : Maximum value of the zone comparison
- S** : Comparison value
- D** : Comparison result

Explanation


- These instructions compare signed decimal numbers in  $S$  and  $S_1$ , and compare the signed decimal numbers in  $S$  and  $S_2$ , and stores the comparison results in  $D$ .
- The value in  $S_1$  must be less than that in  $S_2$ . If the value in  $S_1$  is larger than that in  $S_2$ ,  $S_1$  is the maximum/minimum value during the execution of the ZCP instruction.
- The operand  $D$  occupies three consecutive devices. The comparison results are stored in  $D$ ,  $D+1$ , and  $D+2$ .  
If the value in  $S_1$  is less than the value in  $S$ ,  $D$  is ON.  
If the value in  $S$  is between the values in  $S_1$  and  $S_2$ ,  $D+1$  is ON.  
If the value in  $S$  is greater than the value in  $S_2$ ,  $D+2$  is ON.
- Only the DZCP and DZCPP instructions can use the 32-bit counter, but not the device E.

**Example**

1. If the operand **D** is M0, the comparison results are stored in M0, M1 and M2, as shown below.
2. When X0.0 is ON, the ZCP instruction is executed. M0, M1, or M2 is ON. When X0.0 is OFF, the ZCP instruction is not executed, and the state of M0, the state of M1, and the state of M2 remain unchanged.



3. If you need to clear the comparison result, use the RST or ZRST instruction.



**Additional remarks**

1. If you declare the operand **D** in ISPSOft, the data type is ARRAY [3] of BOOL.
2. If **D+2** exceeds the device range, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2003.


API	Instruction code			Operand							Function						
0056		FCMP	P	<b>S<sub>1</sub> · S<sub>2</sub> · D</b>							Comparing floating-point numbers						

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
<b>S<sub>1</sub></b>	●	●			●	●	●	●	●		○					○
<b>S<sub>2</sub></b>	●	●			●	●	●	●	●		○					○
<b>D</b>		●	●	●				●		○						

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
<b>S<sub>1</sub></b>									●				
<b>S<sub>2</sub></b>									●				
<b>D</b>	●												

Pulse Instruction	16-bit instruction	32-bit instruction
AS	-	AS

**Symbol**




- S<sub>1</sub>** : Floating-point comparison value1
- S<sub>2</sub>** : Floating-point comparison value2
- D** : Comparison result

**Explanation**

- This instruction compares the floating-point numbers in **S<sub>1</sub>** and **S<sub>2</sub>**, and stores the comparison results (> · = · <) in **D**.
- The operand **D** occupies three consecutive devices. The comparison results are stored in **D**, **D+1**, and **D+2**. If the value in **S<sub>1</sub>** is greater than the value in **S<sub>2</sub>**, **D** is ON. If the value in **S<sub>1</sub>** is equal to the value in **S<sub>2</sub>**, **D+1** is ON. If the value in **S<sub>1</sub>** is less than the value in **S<sub>2</sub>**, **D+2** is ON.

**Example**

- If the operand **D** is M10, the comparison results is stored in M10, M11 and M12, as shown below.
- When X0.0 is ON, the FCMP instruction is executed. M10, M11, or M12 is ON. When X0.0 is OFF, the FCMP instruction is not executed and the state of M10, the state of M11, and the state of M12 remain unchanged.
- If you want to get the comparison result  $\geq$ ,  $\leq$ , or  $\neq$ , connect M10–M12 in series or in parallel.
- If you want to clear the comparison result, use the RST or ZRST instruction.

**Additional remarks**

1. If the value in **S<sub>1</sub>** or **S<sub>2</sub>** exceeds the range of values that can be represented by the floating-point numbers, the contact is OFF, SM is ON, and the error code in SR0 is 16#2013.
2. If you declare the operand **D** in ISPSOft, the data type is ARRAY [3] of BOOL.
3. If **D+2** exceeds the device range, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2003.


API	Instruction code			Operand							Function						
0057		FZCP	P	$S_1 \cdot S_2 \cdot S \cdot D$							Floating-point zone comparison						

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
$S_1$	●	●			●	●	●	●	●		○					○
$S_2$	●	●			●	●	●	●	●		○					○
$S$	●	●			●	●	●	●	●		○					○
$D$		●	●	●				●		○						

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
$S_1$									●				
$S_2$									●				
$S$									●				
$D$	●												

Pulse Instruction	16-bit instruction	32-bit instruction
AS	-	AS

**Symbol**




- $S_1$  : Minimum value of the zone comparison
- $S_2$  : Maximum value of the zone comparison
- $S$  : Comparison value
- $D$  : Comparison result

**Explanation**

- This instruction compares the floating-point numbers in  $S$  and  $S_1$ , and compare the floating-point numbers in  $S$  with that in  $S_2$ , and then stores the results in  $D$ .
- The value in  $S_1$  must be less than that in  $S_2$ . If the value in  $S_1$  is larger than that in  $S_2$ ,  $S_1$  is the maximum/minimum value during the execution of the FZCP instruction.
- The operand  $D$  occupies three consecutive devices. The comparison results are stored in  $D$ ,  $D+1$ , and  $D+2$ . If the value in  $S_1$  is greater than the value in  $S$ ,  $D$  is ON. If the value in  $S$  is between the value in  $S_1$  and the value in  $S_2$ ,  $D+1$  is ON. If the compared value in  $S_2$  is less than the value in  $S$ ,  $D+2$  is ON.

**Example**

- If the operand  $D$  is M0, the comparison results are stored in M0, M1 and M2.
- When X0.0 is ON, the FZCP instruction is executed. M0, M1, or M2 is ON. When X0.0 is OFF, the FZCP instruction is not executed, and the state of M0, the state of M1, and the state of M2 remain unchanged.
- If you want to clear the comparison result, use the RST or ZRST instruction.

**Additional remarks**

1. If the value in **S<sub>1</sub>** or **S<sub>2</sub>** or **S** exceeds the range of values that can be represented by the floating-point numbers, the contact is OFF, SM is ON, and the error code in SR0 is 16#2013.
2. If you declare the operand **D** in ISPSOft, the data type is ARRAY [3] of BOOL.
3. If **D+2** exceeds the device range, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2003.


API	Instruction code			Operand							Function					
0058		MCMP	P	$S_1 \cdot S_2 \cdot n \cdot D$							Matrix comparison					

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
S <sub>1</sub>	●	●			●	●		●	●		○					
S <sub>2</sub>	●	●			●	●		●	●		○					
n	●	●			●	●		●	●		○		○	○		
D		●			●	●		●			○					

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
S <sub>1</sub>		●				●							
S <sub>2</sub>		●				●							
n		●				●							
D		●				●							

Pulse Instruction	16-bit instruction	32-bit instruction
AS	AS	-

**Symbol**



- S<sub>1</sub> : Matrix source device 1
- S<sub>2</sub> : Matrix source device 2
- n : Length of the array
- D : Pointer

**Explanation**

1. This instruction searches for the bits with different states, starting from the bits specified by adding one to the current value in **D**. After finding the bits with different states, the instruction stores the bit number in **D**, and the comparison is finished.
2. The operand **n** must be between 1–256.
3. When SM607 is ON, the equivalent values are compared. When SM607 is OFF, the different values are compared. When the matching bits are found, the comparison stops immediately, and SM610 is ON. When the last bits are compared, SM608 is ON, and the bit number is stored in **D**. The comparison starts from the 0<sup>th</sup> bits in the next scan cycle, and SM609 is ON. When the value in **D** exceeds the range, SM611 is ON.
4. When the MCMP instruction is executed, you need a 16-bit register to specify a certain bit among the 16n bits in the matrix for the operation. The register is called the pointer, and is specified by you. The value in the register is between 0–16n-1, and corresponds to the bit between b0 to b16n-1. During the operation, you are prevented from altering the value of the pointer in case the search for the matching bits is affected. If the value of the pointer exceeds the range, SM611 is ON, and the MCMP instruction is not executed.
5. If SM608 and SM610 occur simultaneously, they are ON simultaneously.




API	Instruction code			Operand								Function				
0059-0064		CMPT※	P	$S_1 \cdot S_2 \cdot n \cdot D$								Comparing tables				

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	“\$”	F
S <sub>1</sub>	●	●			●	●		●	●		○		○	○		
S <sub>2</sub>	●	●			●	●		●	●		○					
n	●	●			●	●		●	●		○	○	○	○		
D		●	●	●				●		●						

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
S <sub>1</sub>		●				●							
S <sub>2</sub>		●				●							
n		●				●							
D	●												

Pulse Instruction	16-bit instruction	32-bit instruction
AS	AS	-


**Symbol**




- S<sub>1</sub> : Source device 1
- S<sub>2</sub> : Source device 2
- n : Data length
- D : Comparison result

**Explanation**

- This instruction compares **n** signed decimal numbers in devices starting at **S<sub>1</sub>** with those in devices starting at **S<sub>2</sub>**, and then stores the comparison results in **D**.
- The operand **n** must be between 1–256.
- The value that is written into the operand **D** is a one-bit value.
- When the results of the comparison using the CMPT# instruction are that all devices are ON, SM620 is ON. Otherwise, SM620 is OFF.
- If the operand **S<sub>1</sub>** is a device, the comparison is as shown below.



6. If the operand  $S_1$  is a constant between -32768 to 32767, the comparison is as shown below.




7. The corresponding comparison operation results of the instructions are listed in the following table.

API number	16-bit instruction	Comparison operation result	
		ON	OFF
0059	CMPT =	$S_1 = S_2$	$S_1 \neq S_2$
0060	CMPT < >	$S_1 \neq S_2$	$S_1 = S_2$
0061	CMPT >	$S_1 > S_2$	$S_1 \leq S_2$
0062	CMPT > =	$S_1 \geq S_2$	$S_1 < S_2$
0063	CMPT <	$S_1 < S_2$	$S_1 \geq S_2$
0064	CMPT < =	$S_1 \leq S_2$	$S_1 > S_2$

**Example**

The data in D0–D3 are compared with that in D10–D13. If the comparison result is that the data in D0–D3 are the same as that in D10–D13, Y0.1–Y0.4 are ON.

6



**Additional remarks**

1. If the value in the operand  $n$  is not between 1–256, the instruction is not executed, SM is ON, and the error code in SR0 is 16#200B.
2. If the number of devices specified by  $S_1-S_1+n$ ,  $S_2-S_2+n$ , or  $D$  is insufficient, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2003.


API	Instruction code		Operand				Function					
0065		CHKADR	<b>S · n · D</b>				Checking the addresses in a pointer register					

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
<b>S</b>																
<b>n</b>	●	●			●	●		●	●		○	○	○	○		
<b>D</b>		●	●	●				●		○						

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
<b>S</b>													
<b>n</b>		●				●							
<b>D</b>	●												

Pulse Instruction	16-bit instruction	32-bit instruction
-	AS	-

**Symbol**



**S** : Pointer register

**n** : Number of devices

**D** : Check result

**Explanation**

1. This instruction checks whether the value in **S** and (the value in **S**)+**n**-1 exceed the device range. If the result is that the value in **S** and (the value in **S**)+**n**-1 do not exceed the device range, the device **D** is ON. Otherwise, it is OFF.
2. **S** supports the pointer registers D, T, C, HC (POINTER/T\_POINTER/C\_POINTER/HC\_POINTER).
3. The operand **n** must be between 1–1024.
4. You can use the CHKADR instruction only in a function block. Use CHKADR during the initial program development phase or when you are not sure if the device range will be exceeded. After the program is written and debugged, you can delete this instruction.

**Example**

1. Create a program (Prog0) and a function block (FB0) in ISPSOft.




Declare two variables in the program.

Local Symbols				
Declaration Type	Identifiers	Address	Type...	Initial Value
VAR	myfb0	N/A [Auto]	FB0	N/A
VAR	StartBit	N/A [Auto]	BOOL	FALSE


2. Declare VarPR1, VarTR1, VarCR1, and VarHCR1 in the function block, and assign the data types POINTER, T\_POINTER, C\_POINTER, and HC\_POINTER to them respectively.

Local Symbols				
Declaration Type	Identifiers	Address	Type...	Initial Value
VAR_IN_OUT	VarPR1	N/A [Auto]	POINTER	N/A
VAR_IN_OUT	VarTR1	N/A [Auto]	T_POINTER	N/A
VAR_IN_OUT	VarCR1	N/A [Auto]	C_POINTER	N/A
VAR_IN_OUT	VarHCR1	N/A [Auto]	HC_POINTER	N/A
VAR	PR_ChkBit	N/A [Auto]	BOOL	FALSE
VAR	TR_ChkBit	N/A [Auto]	BOOL	FALSE
VAR	CR_ChkBit	N/A [Auto]	BOOL	FALSE
VAR	HCR_ChkBit	N/A [Auto]	BOOL	FALSE
VAR	chkPR	N/A [Auto]	BOOL	N/A
VAR	chkTR	N/A [Auto]	BOOL	N/A
VAR	chkCR	N/A [Auto]	BOOL	N/A
VAR	chkHCR	N/A [Auto]	BOOL	N/A


3. Call the function block FB0 in the program, and assign D29999, T0, C511, and HC50 to VarPR1, VarTR1, VarCR1, and VarHCR1 in FB0 respectively.




4. Use the CHKADR instruction to check whether VarPR1, VarTR1, VarCR1, and VarHCR1 exceed the range.
5. When chkPR is ON, the actual device represented by VarPR1 is D29999. Since the legal range of devices is from D0 to D29999, and  $D29999+10-1=D30008$  which exceeds the range, PR\_ChkBit is OFF.




6. When chkTR is ON, the actual device represented by VarTR1 is T0. Since the legal range of devices is from T0 to T511, and  $T0+10-1=T9$  which does not exceed the range, TR\_ChkBit is ON.



7. When chkCR is ON, the actual device represented by C511. Since the legal range of devices is from C0 to C511, and  $C511+10-1=C520$  which exceeds the range, CR\_ChkBit is OFF.



8. When chkHCR is ON, the actual device represented by HC50 is VarHCR1. Since the legal range of devices is from HC0 to HC255, and  $HC50+10-1=HC59$  which does not exceed the range, HCR\_ChkBit is ON.



#### Additional remarks

1. If the value (the actual device address) in **S** exceeds the device range, the CHKADR instruction is not executed, SM is ON, and the error code in SR0 is 16#2003.
2. If the value in the operand **n** is not between 1–1024, the CHKADR instruction is not executed, SM is ON, and the error code in SR0 is 16#200B.


API	Instruction code		Operand								Function				
0066-0071	D	LDZ※	S <sub>1</sub> · S <sub>2</sub> · S <sub>3</sub>								Comparing contact type absolute values LDZ※				

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	“\$”	F
S <sub>1</sub>	●	●			●	●	●	●	●		○	○	○	○		
S <sub>2</sub>	●	●			●	●	●	●	●		○	○	○	○		
S <sub>3</sub>	●	●			●	●	●	●	●		○	○	○	○		

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
S <sub>1</sub>		●	●			●	●				●	●	
S <sub>2</sub>		●	●			●	●				●	●	
S <sub>3</sub>		●	●			●	●				●	●	

Pulse Instruction	16-bit instruction	32-bit instruction
-	AS	AS

Symbol



- S<sub>1</sub> : Data source1
- S<sub>2</sub> : Data source2
- S<sub>3</sub> : Comparison result

Taking LDZ= and DLDZ= for example

Explanation


- These instructions compare the absolute value of the difference between S<sub>1</sub> and S<sub>2</sub> with the absolute value of S<sub>3</sub>. Take the LDZ= instruction for example. If the comparison result is that the absolute value of the difference between S<sub>1</sub> and S<sub>2</sub> is equal to the absolute value of S<sub>3</sub>, the continuity condition of the instruction is met. If the comparison result is that the absolute value of the difference between S<sub>1</sub> and S<sub>2</sub> is not equal to the absolute value of S<sub>3</sub>, the discontinuity condition of the instruction is met.

2. Only the 32-bit instruction can use the 32-bit HC device, but not the device E.

API number	16-bit instruction	32-bit instruction	Continuity condition	Discontinuity condition
0066	LDZ =	DLDZ =	$ S_1 - S_2  =  S_3 $	$ S_1 - S_2  \neq  S_3 $
0067	LDZ < >	DLDZ < >	$ S_1 - S_2  \neq  S_3 $	$ S_1 - S_2  =  S_3 $
0068	LDZ >	DLDZ >	$ S_1 - S_2  >  S_3 $	$ S_1 - S_2  \leq  S_3 $
0069	LDZ > =	DLDZ > =	$ S_1 - S_2  \geq  S_3 $	$ S_1 - S_2  <  S_3 $
0070	LDZ <	DLDZ <	$ S_1 - S_2  <  S_3 $	$ S_1 - S_2  \geq  S_3 $
0071	LDZ < =	DLDZ < =	$ S_1 - S_2  \leq  S_3 $	$ S_1 - S_2  >  S_3 $

**Example**

1. When the absolute difference of D10 and D11 is greater than 200, Y0.0 is ON. While the absolute difference is less than 200, Y0.0 is OFF.




API	Instruction code		Operand									Function				
0072-0077	D	ANDZ※	$S_1 \cdot S_2 \cdot S_3$									Comparing contact type absolute values ANDZ※				

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	“\$”	F
$S_1$	●	●			●	●	●	●	●		○	○	○	○		
$S_2$	●	●			●	●	●	●	●		○	○	○	○		
$S_3$	●	●			●	●	●	●	●		○	○	○	○		

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
$S_1$		●	●			●	●				●	●	
$S_2$		●	●			●	●				●	●	
$S_3$		●	●			●	●				●	●	

Pulse Instruction	16-bit instruction	32-bit instruction
-	AS	AS

Symbol



- $S_1$  : Data source1
- $S_2$  : Data source2
- $S_3$  : Comparison result

Taking ANDZ= and DANDZ= for example

Explanation


- These instructions compare the absolute value of the difference between  $S_1$  and  $S_2$  with the absolute value of  $S_3$ . Take the ANDZ= instruction for example. If the comparison result is that the absolute value of the difference between  $S_1$  and  $S_2$  is equal to the absolute value of  $S_3$ , the continuity condition of the instruction is met. If the comparison result is that the absolute value of the difference between  $S_1$  and  $S_2$  is not equal to the absolute value of  $S_3$ , the discontinuity condition of the instruction is met.

2. Only the 32-bit instruction can use the 32-bit HC device, but not the device E.

API number	16-bit instruction	32-bit instruction	Continuity condition	Discontinuity condition
0072	ANDZ =	DANDZ =	$ S_1 - S_2  =  S_3 $	$ S_1 - S_2  \neq  S_3 $
0073	ANDZ < >	DANDZ < >	$ S_1 - S_2  \neq  S_3 $	$ S_1 - S_2  =  S_3 $
0074	ANDZ >	DANDZ >	$ S_1 - S_2  >  S_3 $	$ S_1 - S_2  \leq  S_3 $
0075	ANDZ > =	DANDZ > =	$ S_1 - S_2  \geq  S_3 $	$ S_1 - S_2  <  S_3 $
0076	ANDZ <	DANDZ <	$ S_1 - S_2  <  S_3 $	$ S_1 - S_2  \geq  S_3 $
0077	ANDZ < =	DANDZ < =	$ S_1 - S_2  \leq  S_3 $	$ S_1 - S_2  >  S_3 $

**Example**

1. When M0 is ON and the absolute difference of D10 and D11 is greater than 200, Y0.0 is ON. While the absolute difference is less than 200, Y0.0 is OFF.




API	Instruction code		Operand									Function				
0078-0083	D	ORZ※	$S_1 \cdot S_2 \cdot S_3$									Comparing contact type absolute values ORZ※				

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	“\$”	F
$S_1$	●	●			●	●	●	●	●		○	○	○	○		
$S_2$	●	●			●	●	●	●	●		○	○	○	○		
$S_3$	●	●			●	●	●	●	●		○	○	○	○		

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
$S_1$		●	●			●	●				●	●	
$S_2$		●	●			●	●				●	●	
$S_3$		●	●			●	●				●	●	

Pulse Instruction	16-bit instruction	32-bit instruction
-	AS	AS

Symbol



- $S_1$  : Data source1
- $S_2$  : Data source2
- $S_3$  : Comparison result

Taking ORZ= and DORZ= for example

Explanation


- These instructions compare the absolute value of the difference between  $S_1$  and  $S_2$  with the absolute value of  $S_3$ . Take the ORZ= instruction for example. If the comparison result is that the absolute value of the difference between  $S_1$  and  $S_2$  is equal to the absolute value of  $S_3$ , the continuity condition of the instruction is met. If the comparison result is that the absolute value of the difference between  $S_1$  and  $S_2$  is not equal to the absolute value of  $S_3$ , the discontinuity condition of the instruction is met.

2. Only the 32-bit instruction can use the 32-bit HC device, but not the device E.

API number	16-bit instruction	32-bit instruction	Continuity condition	Discontinuity condition
0078	ORZ =	DORZ =	$ S_1 - S_2  =  S_3 $	$ S_1 - S_2  \neq  S_3 $
0079	ORZ < >	DORZ < >	$ S_1 - S_2  \neq  S_3 $	$ S_1 - S_2  =  S_3 $
0080	ORZ >	DORZ >	$ S_1 - S_2  >  S_3 $	$ S_1 - S_2  \leq  S_3 $
0081	ORZ > =	DORZ > =	$ S_1 - S_2  \geq  S_3 $	$ S_1 - S_2  <  S_3 $
0082	ORZ <	DORZ <	$ S_1 - S_2  <  S_3 $	$ S_1 - S_2  \geq  S_3 $
0083	ORZ < =	DORZ < =	$ S_1 - S_2  \leq  S_3 $	$ S_1 - S_2  >  S_3 $

**Example**

1. When M0 is ON and the absolute difference of D10 and D11 is greater than 200, Y0.0 is ON. While the absolute difference is less than 200, Y0.0 is OFF.



## 6.2 Arithmetic Instructions

### 6.2.1 List of Arithmetic Instructions

The following table lists the Arithmetic instructions covered in this section.

API	Instruction code		Pulse instruction	Function
	16-bit	32-bit		
<b><u>0100</u></b>	+	D+	✓	Adding binary numbers
<b><u>0101</u></b>	-	D-	✓	Subtracting binary numbers
<b><u>0102</u></b>	*	D*	✓	Multiplying binary numbers
<b><u>0103</u></b>	/	D/	✓	Dividing binary numbers
<b><u>0104</u></b>	-	F+	✓	Adding floating-point numbers
<b><u>0105</u></b>	-	F-	✓	Subtracting floating-point numbers
<b><u>0106</u></b>	-	F*	✓	Multiplying floating-point numbers
<b><u>0107</u></b>	-	F/	✓	Dividing floating-point numbers
<b><u>0112</u></b>	BK+	DBK+	✓	Adding binary numbers in blocks
<b><u>0113</u></b>	BK-	DBK-	✓	Subtracting binary numbers in blocks
<b><u>0114</u></b>	\$+	-	✓	Linking strings
<b><u>0115</u></b>	INC	DINC	✓	Adding one to a binary number
<b><u>0116</u></b>	DEC	DDEC	✓	Subtracting one from a binary number
<b><u>0117</u></b>	MUL16	MUL32	✓	MUL16: Multiplying binary numbers for 16-bit instructions MUL32: Multiplying binary numbers for 32-bit instructions
<b><u>0118</u></b>	DIV16	DIV32	✓	DIV16: Dividing binary numbers for 16-bit instructions DIV32: Dividing binary numbers for 32-bit instructions

### 6.2.2 Explanation of Arithmetic Instructions


API	Instruction code			Operand							Function						
0100	D	+	P	$S_1 \cdot S_2 \cdot D$							Adding binary numbers						

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
S <sub>1</sub>	●	●			●	●	●	●	●		○	○	○	○		
S <sub>2</sub>	●	●			●	●	●	●	●		○	○	○	○		
D		●			●	●	●	●			○	○				


Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
S <sub>1</sub>		●	●			●	●				●	●	
S <sub>2</sub>		●	●			●	●				●	●	
D		●	●			●	●				●	●	

Pulse instruction	16-bit instruction	32-bit instruction
AS	AS	AS

#### Symbol



S<sub>1</sub> : Augend  
 S<sub>2</sub> : Addend  
 D : Sum




#### Explanation

1. This instruction adds the binary value in **S<sub>2</sub>** to the binary value in **S<sub>1</sub>**, and stores the sum in **D**.
2. Only the 32-bit instructions can use the 32-bit counter, but not the device E.
3. Instruction flags: SM600 (zero flag), SM601 (borrow flag), and SM602 (carry flag)
4. When the operation result is zero, SM600 is ON. Otherwise, it is OFF.
5. For 16-bit binary values, when the operation result exceeds the range of 16-bit binary values, SM602 is ON. Otherwise, it is OFF.
6. For 32-bit binary values, when the operation result exceeds the range of 32-bit binary values, SM602 is ON. Otherwise, it is OFF.

**Example 1**


Adding 16-bit binary values: when X0.0 is ON, the instruction adds the addend in D10 to the augend in D0, and stores the sum in D20.



- When the values in D0 and D10 are 100 and 10 respectively, D0 plus D10 equals 110, and 110 is stored in D20.
- When the values in D0 and D10 are 16#7FFF and 16#1 respectively, D0 plus D10 equals 16#8000, and 16#8000 is stored in D20.
- When the values in D0 and D10 are 16#FFFF and 16#1 respectively, D0 plus D10 equals 16#10000. Since the operation result exceeds the range of 16-bit binary values, SM602 is ON, and the value stored in D20 is 16#0. Since the operation result is 16#0, SM600 is ON.

**Example 2**

Adding 32-bit binary values: when X0.0 is ON, the instruction adds the addend in (D41, D40) to the augend in (D31, D30), and stores the sum in (D51, D50). The data in D30, D40, and D50 is the lower 16-bit data, whereas the data in D31, D41, and D51 is the higher 16-bit data.



- When the values in (D31, D30) and (D41, D40) are 11111111 and 44444444 respectively, (D31, D30) plus (D41, D40) equals 55555555, and 55555555 is stored in (D51, D50).
- When the values in (D31, D30) and (D41, D40) are 16#80000000 and 16#FFFFFFFF respectively, (D31, D30) plus (D41, D40) equals 16#17FFFFFFF. Since the operation result exceeds the range of 32-bit binary values, SM602 is ON, and the value stored in (D51, D50) is 16#7FFFFFFF.



**Flags**

For 16-bit binary values:

- 1. If the operation result is zero, SM600 is ON.
- 2. If the operation result exceeds 65,535, SM602 is ON.

For 32-bit values:

- 1. If the operation result is zero, SM600 is set to ON.
- 2. If the operation result exceeds 4,294,967,295, SM602 is set to ON.




API	Instruction code			Operand							Function					
0101	D	-	P	<b>S<sub>1</sub> · S<sub>2</sub> · D</b>							Subtracting binary numbers					

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
<b>S<sub>1</sub></b>	●	●			●	●	●	●	●		○	○	○	○		
<b>S<sub>2</sub></b>	●	●			●	●	●	●	●		○	○	○	○		
<b>D</b>		●			●	●	●	●			○	○				

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
<b>S<sub>1</sub></b>		●	●			●	●				●	●	
<b>S<sub>2</sub></b>		●	●			●	●				●	●	
<b>D</b>		●	●			●	●				●	●	

Pulse instruction	16-bit instruction	32-bit instruction
AS	AS	AS

**Symbol**




- S<sub>1</sub>** : Minuend
- S<sub>2</sub>** : Subtrahend
- D** : Difference

**Explanation**

1. This instruction subtracts the binary value in **S<sub>2</sub>** from the binary value in **S<sub>1</sub>**, and stores the difference in **D**.
2. Only the 32-bit instructions can use the 32-bit counter, but not the device E.
3. Instruction flags: SM600 (zero flag), SM601 (borrow flag), and SM602 (carry flag)
4. When the operation result is zero, SM600 is ON. Otherwise, it is OFF.
5. When borrowing occurs during the arithmetic, SM601 is ON. Otherwise, it is OFF.

**Example 1**


Subtracting 16-bit binary values: when X0.0 is ON, the instruction subtracts the subtrahend in D10 from the minuend in D0, and stores the difference in D20.



- When the values in D0 and D10 are 100 and 10 respectively, D0 minus D10 leaves 90, and 90 is stored in D20.
- When the values in D0 and D10 are 16#8000 and 16#1 respectively, D0 minus D10 leaves 16#7FFF, and 16#7FFF is stored in D20.
- When the values in D0 and D10 are 16#1 and 16#2 respectively, D0 minus D10 leaves 16#FFFF. Since borrowing occurs during the operation, SM601 is ON, and the value stored in D20 is 16#FFFF.
- When the values in D0 and D10 are 16#0 and 16#FFFF respectively, D0 minus D10 leaves 16#F0001. Since borrowing occurs during the operation, SM601 is ON, and the value stored in D20 is 16#1.

**Example 2**

Adding 32-bit binary values: when X0.0 is ON, the instruction subtracts the subtrahend in (D41, D40) from the minuend in (D31, D30), and stores the sum in (D51, D50). The data in D30, D40, and D50 is the lower 16-bit data, whereas the data in D31, D41, and D51 is the higher 16-bit data.



- When the values in (D31, D30) and (D41, D40) are 55555555 and 11111111 respectively, (D31, D30) minus (D41, D40) leaves 44444444, and 44444444 is stored in (D51, D50).
- When the values in (D31, D30) and (D41, D40) are 16#80000000 and 16#FFFFFFFF respectively, (D31, D30) minus (D41, D40) leaves 16#F8000001. Since borrowing occurs during the operation, SM601 is ON, and the value stored in (D51, D50) is 16#80000001.


API	Instruction code			Operand							Function					
0102	D	*	P	$S_1 \cdot S_2 \cdot D$							Multiplying binary numbers					

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
<b>S<sub>1</sub></b>	●	●			●	●	●	●	●		○	○	○	○		
<b>S<sub>2</sub></b>	●	●			●	●	●	●	●		○	○	○	○		
<b>D</b>		●			●	●	●	●			○					

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
<b>S<sub>1</sub></b>		●	●			●	●				●	●	
<b>S<sub>2</sub></b>		●	●			●	●				●	●	
<b>D</b>		●	●			●	●				●	●	

Pulse instruction	16-bit instruction	32-bit instruction
AS	AS	AS

**Symbol:**




**S<sub>1</sub>** : Multiplicand  
**S<sub>2</sub>** : Multiplier  
**D** : Product

6


**Explanation**

1. This instruction multiplies the signed binary value in **S<sub>1</sub>** by the signed binary value in **S<sub>2</sub>**, and stores the product in **D**.
2. Only the instruction D\* can use the 32-bit counter.
3. Multiplying 16-bit binary values:



The product is a 32-bit value, and is stored in the register (D+1, D), which is composed of 32 bits. When the sign bit b31 is 0, the product is a positive value. When the sign bit b31 is 1, the product is a negative value.


4. Multiplying 32-bit binary values:



The product is a 64-bit value, and is stored in the register (D+3, D+2, D+1, D0), which is composed of 64 bits. When the sign bit b63 is 0, the product is a positive value. When the sign bit b63 is 1, the product is a negative value.

**Example**

The instruction multiplies the 16-bit value in D0 by the 16-bit value in D10, and stores the 32-bit product in (D21, D20). The data in D21 is the higher 16-bit data, whereas the data in D20 is the lower 16-bit data. Whether the result is a positive value or a negative value depends on the state of the highest bit b31. When b31 is OFF, the result is a positive value. When b31 is ON, the result is a negative value.



$D0 \times D10 = (D21, D20)$

16-bit value  $\times$  16-bit value = 32-bit value


API	Instruction code			Operand							Function					
0103	D	/	P	<b>S<sub>1</sub> · S<sub>2</sub> · D</b>							Dividing binary numbers					

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
<b>S<sub>1</sub></b>	●	●			●	●	●	●	●		○	○	○	○		
<b>S<sub>2</sub></b>	●	●			●	●	●	●	●		○	○	○	○		
<b>D</b>		●			●	●	●	●			○					

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
<b>S<sub>1</sub></b>		●	●			●	●				●	●	
<b>S<sub>2</sub></b>		●	●			●	●				●	●	
<b>D</b>		●	●			●	●				●	●	

Pulse instruction	16-bit instruction	32-bit instruction
AS	AS	AS


**Symbol**



- S<sub>1</sub>** : Dividend
- S<sub>2</sub>** : Divisor
- D** : Quotient; remainder


**Explanation**

1. This instruction divides the signed binary value in **S<sub>1</sub>** by the signed binary value in **S<sub>2</sub>**, and stores the quotient and the remainder in **D**.
2. Only the 32-bit instructions can use the 32-bit counter.
3. When the sign bit is 0, the value is a positive one. When the sign bit is 1, the value is a negative one.
4. Dividing 16-bit values:



The operand **D** occupies two consecutive devices. The quotient is stored in **D**, and the remainder is stored in **D+1**.


5. Dividing 32-bit values:



The operand **D** occupies two devices. The quotient is stored in (**D+1, D**), and the remainder is stored in (**D+3, D+2**).

**Example**

When X0.0 is ON, the instruction divides the dividend in D0 by the divisor in D10, and stores the quotient in D20, and stores the remainder in D21. Whether the result is a positive value or a negative value depends on the state of the highest bit.



**Additional remarks**

1. If the device exceeds the range, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2003.
2. If the divisor is 0, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2012.
3. If you declare the operand **D** used during the execution of the 16-bit instruction in ISPSOft, the data type is ARRAY [2] of WORD/INT.
4. If you declare the operand **D** used during the execution of the 32-bit instruction in ISPSOft, the data type is ARRAY [2] of DWORD/DINT.


API	Instruction code			Operand							Function				
0104		F+	P	<b>S<sub>1</sub> · S<sub>2</sub> · D</b>							Adding floating-point numbers				

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
<b>S<sub>1</sub></b>	●	●			●	●	●	●	●							○
<b>S<sub>2</sub></b>	●	●			●	●	●	●	●							○
<b>D</b>		●			●	●	●	●								

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
<b>S<sub>1</sub></b>									●				
<b>S<sub>2</sub></b>									●				
<b>D</b>									●				

Pulse instruction	16-bit instruction	32-bit instruction
AS	-	AS

**Symbol**




- S<sub>1</sub>** : Augend
- S<sub>2</sub>** : Addend
- D** : Sum

**6 Explanation**

1. This instruction adds the 32-bit single-precision floating-point numbers in **S<sub>2</sub>** and **S<sub>1</sub>**, and stores the sum in **D**.
2. Instruction flags: SM600 (zero flag), SM601 (borrow flag), and SM602 (carry flag)
  - When the operation result is zero, SM600 is ON. Otherwise, it is OFF.
  - When the absolute value of the operation result is less than the value that can be represented by the minimum floating-point number, the value in **D** is 16#FF800000 and SM601 is ON.
  - When the absolute value of the operation result is larger than the value that can be represented by the maximum floating-point number, the value in **D** is 16#7F800000 and SM602 is ON.

**Example**

Adding single-precision floating-point numbers: when X0.0 is ON, the instruction adds the addend 16#4046B852 in (D21, D20) to the augend 16#3FB9999A in (D11, D10), and stores the sum 16#4091C28F in (D31, D30). 16#4046B852, 16#3FB9999A, and 16#4091C28F represent the floating point numbers 3.105, 1.450, and 4.555 respectively.



**Additional remark**

If the value in **S1** or the value in **S2** exceeds the range of values that can be represented by the floating-point numbers, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2013.


API	Instruction code			Operand							Function				
0105		F-	P	<b>S<sub>1</sub> · S<sub>2</sub> · D</b>							Subtracting floating-point numbers				

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
<b>S<sub>1</sub></b>	●	●			●	●	●	●	●							○
<b>S<sub>2</sub></b>	●	●			●	●	●	●	●							○
<b>D</b>		●			●	●	●	●								

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
<b>S<sub>1</sub></b>									●				
<b>S<sub>2</sub></b>									●				
<b>D</b>									●				

Pulse instruction	16-bit instruction	32-bit instruction
AS	-	AS

**Symbol**




- S<sub>1</sub>** : Minuend
- S<sub>2</sub>** : Subtrahend
- D** : Difference

**6**


**Explanation**

1. This instruction subtracts the 32-bit single-precision floating-point number in **S<sub>2</sub>** from the 32-bit single-precision floating-point numbers number in **S<sub>1</sub>**, and stores the difference in **D**.
2. Instruction flags: SM600 (zero flag), SM601 (borrow flag), and SM602 (carry flag)
  - When the operation result is zero, SM600 is ON.
  - When the absolute value of the operation result is less than the value that can be represented by the minimum floating-point number, the value in **D** is 16#FF800000 and SM601 is ON.
  - When the absolute value of the operation result is larger than the value that can be represented by the maximum floating-point number, the value in **D** is 16#7F800000 and SM602 is ON.



**Example**

Subtracting 32-bit single-precision floating-point numbers: when X0.0 is ON, the instruction subtracts the subtrahend in (D21, D20) from the minuend in (D21, D20), and stores the difference in (D31, D30).



**Additional remarks**

If the value in **S1** or the value in **S2** exceeds the range of values that can be represented by the floating-point numbers, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2013.


API	Instruction code			Operand							Function				
0106		F*	P	$S_1 \cdot S_2 \cdot D$							Multiplying floating-point numbers				

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
S <sub>1</sub>	●	●			●	●	●	●	●							○
S <sub>2</sub>	●	●			●	●	●	●	●							○
D		●			●	●	●	●								

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
S <sub>1</sub>									●				
S <sub>2</sub>									●				
D									●				

Pulse instruction	16-bit instruction	32-bit instruction
AS	-	AS

**Symbol**




- S<sub>1</sub> : Multiplicand
- S<sub>2</sub> : Multiplier
- D : Product

**6**


**Explanation**

1. This instruction multiplies the 32-bit single-precision floating-point number in S<sub>1</sub> by the 32-bit single-precision floating-point number in S<sub>2</sub>, and stores the product in D.
2. Instruction flags: SM600 (zero flag), SM601 (borrow flag), and SM602 (carry flag)
  - When the operation result is zero, SM600 is ON.
  - When the absolute value of the operation result is less than the value that can be represented by the minimum floating-point number, the value in D is 16#FF800000 and SM601 is ON.
  - When the absolute value of the operation result is larger than the value that can be represented by the maximum floating-point number, the value in D is 16#7F800000 and SM602 is ON.



**Example**

Multiplying 32-bit single-precision floating-point numbers: when X0.0 is ON, the instruction multiplies the multiplicand 32.5 by the multiplier in (D1, D0), and stores the product in (D11, D10).



**Additional remarks**

If the value in **S1** or the value in **S2** exceeds the range of values that can be represented by the floating-point numbers, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2013.


API	Instruction code			Operand							Function					
0107		F/	P	<b>S<sub>1</sub> · S<sub>2</sub> · D</b>							Dividing floating-point numbers					

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
<b>S<sub>1</sub></b>	●	●			●	●	●	●	●							○
<b>S<sub>2</sub></b>	●	●			●	●	●	●	●							○
<b>D</b>		●			●	●	●	●								

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
<b>S<sub>1</sub></b>									●				
<b>S<sub>2</sub></b>									●				
<b>D</b>									●				

Pulse instruction	16-bit instruction	32-bit instruction
AS	-	AS

**Symbol**




**S<sub>1</sub>** : Dividend  
**S<sub>2</sub>** : Divisor  
**D** : Quotient

**6**


**Explanation**

- This instruction divides the 32-bit single-precision floating-point number in **S<sub>1</sub>** by the 32-bit single-precision floating-point number in **S<sub>2</sub>**, and stores the quotient in **D**.
- Instruction flags: SM600 (zero flag), SM601 (borrow flag), and SM602 (carry flag)
  - When the operation result is zero, SM600 is ON.
  - When the absolute value of the operation result is less than the value that can be represented by the minimum floating-point number, the value in **D** is 16#FF800000 and SM601 is ON.
  - When the absolute value of the operation result is larger than the value that can be represented by the maximum floating-point number, the value in **D** is 16#7F800000 and SM602 is ON.



**Example**

Dividing 32-bit single-precision floating-point numbers: when X0.0 is ON, the instruction divides the dividend in (D1, D0) by the divisor 100.7, and stores the quotient in (D11, D10).



**Additional remarks**

- 1. If the divisor is 0, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2012.
- 2. If the value in **S1** or the value in **S2** exceeds the range of values that can be represented by the floating-point numbers, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2013.

API	Instruction code			Operand							Function					
0112	D	BK+	P	$S_1 \cdot S_2 \cdot n \cdot D$							Adding binary values in blocks					

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
S <sub>1</sub>	●	●			●	●	●	●	●							
S <sub>2</sub>	●	●			●	●	●	●	●				○	○		
n	●	●			●	●	●	●	●				○	○		
D		●			●	●	●	●								

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
S <sub>1</sub>		●				●					●	●	
S <sub>2</sub>		●				●					●	●	
n		●				●					●	●	
D		●				●					●	●	

Pulse instruction	16-bit instruction	32-bit instruction
AS	AS	AS

**Symbol**


<table border="1"> <thead> <tr> <th colspan="2">BK+</th> </tr> </thead> <tbody> <tr> <td>En</td> <td></td> </tr> <tr> <td>S1</td> <td>D</td> </tr> <tr> <td>S2</td> <td></td> </tr> <tr> <td>n</td> <td></td> </tr> </tbody> </table>	BK+		En		S1	D	S2		n		<table border="1"> <thead> <tr> <th colspan="2">BK+P</th> </tr> </thead> <tbody> <tr> <td>En</td> <td></td> </tr> <tr> <td>S1</td> <td>D</td> </tr> <tr> <td>S2</td> <td></td> </tr> <tr> <td>n</td> <td></td> </tr> </tbody> </table>	BK+P		En		S1	D	S2		n	
BK+																					
En																					
S1	D																				
S2																					
n																					
BK+P																					
En																					
S1	D																				
S2																					
n																					
<table border="1"> <thead> <tr> <th colspan="2">DBK+</th> </tr> </thead> <tbody> <tr> <td>En</td> <td></td> </tr> <tr> <td>S1</td> <td>D</td> </tr> <tr> <td>S2</td> <td></td> </tr> <tr> <td>n</td> <td></td> </tr> </tbody> </table>	DBK+		En		S1	D	S2		n		<table border="1"> <thead> <tr> <th colspan="2">DBK+P</th> </tr> </thead> <tbody> <tr> <td>En</td> <td></td> </tr> <tr> <td>S1</td> <td>D</td> </tr> <tr> <td>S2</td> <td></td> </tr> <tr> <td>n</td> <td></td> </tr> </tbody> </table>	DBK+P		En		S1	D	S2		n	
DBK+																					
En																					
S1	D																				
S2																					
n																					
DBK+P																					
En																					
S1	D																				
S2																					
n																					

- S<sub>1</sub> : Augend
- S<sub>2</sub> : Addend
- n : Data length
- D : Sum


**Explanation**

1. This instruction adds **n** pieces of data in devices starting from **S<sub>2</sub>** to those in devices starting from **S<sub>1</sub>**. The augends and the addends are binary values, and the instruction stores the sums in **D**.
2. The operand **n** must be between 1–256.
3. Only the 32-bit instructions can use the 32-bit counter.
4. When the operation result is zero, SM600 is ON.
5. For the 16-bit instructions, when the operation result is less than –32,768, SM601 is ON.
6. For the 16-bit instructions, when the operation result is larger than 32,767, SM602 is ON.
7. For the 32-bit instructions, when the operation result is less than –21,474,836,488, SM601 is ON.
8. For the 32-bit instructions, when the operation result is larger than 2,147,483,647, SM602 is ON.

9. 16-bit instruction example: when the operand **S<sub>2</sub>** is a device (not a constant or a hexadecimal value)





10. 16-bit instruction example: when the operand **S<sub>2</sub>** is a constant or a hexadecimal value





**Example 1**

When X0.0 is ON, the instruction adds the binary values in D10–D14 to the binary values in D0–D4, and stores the sums.



**Example 2**

When X0.0 is ON, the instruction adds the addend 10 to the binary values in D0–D4, and stores the sums in D100–D104.



**Additional remarks**

1. For 16-bit instructions, if the devices  $S_1-S_1+n-1$ ,  $S_2-S_2+n-1$ , or  $D-D+n-1$  exceed the device range, the instruction is not executed, SM is ON, and the error code in SR0 is 16#2003.
2. For 32-bit instructions, if the devices  $S_1-S_1+2*n-1$ ,  $S_2-S_2+2*n-1$ , or  $D-D+2*n-1$  exceed the device range, the instruction is not executed, SM is ON, and the error code in SR0 is 16#2003.
3. If  $n$  is not between 1–256, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#200B.
4. For 16-bit instructions, if  $S_1-S_1+n-1$  overlap  $D-D+n-1$ , the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#200C.
5. For 32-bit instructions, if  $S_1-S_1+2*n-1$  overlap  $D-D+2*n-1$ , the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#200C.
6. For 16-bit instructions, if  $S_2-S_2+n-1$  overlap  $D-D+n-1$ , the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#200C.
7. For 32-bit instructions, if  $S_2-S_2+2*n-1$  overlap  $D-D+2*n-1$ , the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#200C.

API	Instruction code			Operand							Function					
0113	D	BK-	P	$S_1 \cdot S_2 \cdot n \cdot D$							Subtracting binary values in blocks					

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
$S_1$	●	●			●	●	●	●	●							
$S_2$	●	●			●	●	●	●	●				○	○		
$n$	●	●			●	●	●	●	●				○	○		
$D$		●			●	●	●	●								

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
$S_1$		●				●					●	●	
$S_2$		●				●					●	●	
$n$		●				●					●	●	
$D$		●				●					●	●	

Pulse instruction	16-bit instruction	32-bit instruction
AS	AS	AS

### Symbol


BK-	BK-P
En	En
$S_1$	$S_1$
$S_2$	$S_2$
$n$	$n$
DBK-	DBK-P
En	En
$S_1$	$S_1$
$S_2$	$S_2$
$n$	$n$

- $S_1$  : Minuend  
 $S_2$  : Subtrahend  
 $n$  : Data length  
 $D$  : Difference


### Explanation

- This instruction subtracts  $n$  pieces of data in devices starting from  $S_2$  from those in devices starting from  $S_1$ . The minuends and the subtrahends are binary values, and the instruction stores the differences in  $D$ .
- The operand  $n$  must be between 1–256.
- Only the 32-bit instructions can use the 32-bit counter.
- When the operation result is zero, SM600 is ON.
- For 16-bit instructions, when the operation result is less than  $-32,768$ , SM601 is ON.
- For 16-bit instructions, when the operation result is larger than  $32,767$ , SM602 is ON.
- For 32-bit instructions, when the operation result is less than  $-2,147,483,648$ , SM601 is ON.

- 8. For 32-bit instructions, when the operation result is larger than 2,147,483,647, SM602 is ON.
- 9. 16-bit instruction example: when the operand **S<sub>2</sub>** is a device (not a constant or a hexadecimal value)





- 10. 16-bit instruction example: when the operand **S<sub>2</sub>** is a constant or a hexadecimal value




**Example 1**

When X0.0 is ON, the instruction subtracts the binary values in D10–D14 from the binary values in D0–D4, and stores the differences in D100–D104.



**Example 2**

When X0.0 is ON, the instruction subtracts the subtrahend 1 from the binary values in D0–D4, and stores the differences in D100–D104.



**Additional remarks**

1. For 16-bit instructions, if the devices  $S_1-S_1+n-1$ ,  $S_2-S_2+n-1$ , or  $D-D+n-1$  exceed the device range, the instruction is not executed, SM is ON, and the error code in SR0 is 16#2003.
2. For 32-bit instructions, if the devices  $S_1-S_1+2*n-1$ ,  $S_2-S_2+2*n-1$ , or  $D-D+2*n-1$  exceed the device range, the instruction is not executed, SM is ON, and the error code in SR0 is 16#2003.
3. If  $n$  is not between 1–256, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#200B.
4. For 16-bit instructions, if  $S_1-S_1+n-1$  overlap  $D-D+n-1$ , the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#200C.
5. For 32-bit instructions, if  $S_1-S_1+2*n-1$  overlap  $D-D+2*n-1$ , the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#200C.
6. For 16-bit instructions, if  $S_2-S_2+n-1$  overlap  $D-D+n-1$ , the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#200C.
7. For 32-bit instructions, if  $S_2-S_2+2*n-1$  overlap  $D-D+2*n-1$ , the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#200C.

API	Instruction code			Operand								Function				
0114		\$+	P	<b>S<sub>1</sub> · S<sub>2</sub> · D</b>								Linking strings				

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
S <sub>1</sub>	●	●			●	●		●	●						○	
S <sub>2</sub>	●	●			●	●		●	●						○	
D		●			●	●		●								

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
S <sub>1</sub>													●
S <sub>2</sub>													●
D													●

Pulse instruction	16-bit instruction	32-bit instruction
AS	AS	-


**Symbol**


\$+	\$+P
En	En
S <sub>1</sub> D	S <sub>1</sub> D
S <sub>2</sub>	S <sub>2</sub>

- S<sub>1</sub> : String 1
- S<sub>2</sub> : String 2
- D : Device in which the string is stored

**Explanation**

1. This instruction links the string starting with the data in the device specified by S<sub>1</sub> (exclusive of 16#00), and the string starting with the data in the device specified by S<sub>2</sub> (exclusive of 16#00) and stores the result in D. In addition, the instruction adds the code 16#00 to the end of the linked string in D. When the instruction is not executed, the data in D is unchanged.
2. When S<sub>1</sub>, S<sub>2</sub> or D is not a string (\$), the content of the data source can be up to 256 characters (including the ending code 16#00).
3. If successful, the string in S<sub>1</sub> and the string in S<sub>2</sub> are linked and stored in D, as shown below.






4. When **S<sub>1</sub>**, **S<sub>2</sub>** or **D** is not a string (\$),the ending code 16#00 is added to the end of the data that is moved.
5. If **S<sub>1</sub>** or **S<sub>2</sub>** is not a string, then when the instruction is executed and the first character is the code 16#00, 16#00 is still linked and moved.
6. The string “abcde” in **S<sub>1</sub>** is shown as below.

S <sub>1</sub>	b(16#62)	a(16#61)
S <sub>1</sub> +1	d(16#64)	c(16#63)
S <sub>1</sub> +2	(16#00)	e(16#65)

**Example**

Suppose **S<sub>1</sub>** is the string “ab” and **S<sub>2</sub>** is the string “c”. After the conditional contact M0 is enabled, the data in D65534 is 16#6261 and the data in D65535 is 16#0063.



**Additional remarks**

1. If **S<sub>1</sub>** or **S<sub>2</sub>** is a string, at most 31 characters can be moved.
2. If D is not sufficient to contain the string composed of the strings in **S<sub>1</sub>** and **S<sub>2</sub>**, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2003.
3. If the string of **S<sub>1</sub>+S<sub>2</sub>** is more than 256 characters (the ending code 16#00 included), the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2003.
4. If **S<sub>1</sub>** or **S<sub>2</sub>** overlaps **D**, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#200C.
5. If the string in **S<sub>1</sub>** or **S<sub>2</sub>** does not end with 16#00, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#200E.


API	Instruction code			Operand							Function				
0115	D	INC	P	D							Adding one to a binary number				

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
D		●			●	●	●	●			○	○				

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
D		●	●			●	●				●	●	

Pulse instruction	16-bit instruction	32-bit instruction
AS	AS	AS

**Symbol**



**D** : Destination device

**Explanation**

6

1. This instruction adds 1 to the value in **D**.
2. Only the DINC instruction can use the 32-bit counter.
3. For the 16-bit operation, 32,767 plus 1 equals -32,768. For the 32-bit operation, 2,147,483,647 plus 1 equals -2,147,483,648.

**Example**

When X0.0 switches from OFF to ON, the value in D0 increases by one.




API	Instruction code			Operand							Function						
0116	D	DEC	P	D							Subtracting one from a binary number						

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
D		●			●	●	●	●			○	○				

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
D		●	●			●	●				●	●	

Pulse instruction	16-bit instruction	32-bit instruction
AS	AS	AS

**Symbol**



**D** : Destination device

**Explanation**

1. This instruction subtracts 1 from the value in **D**.
2. Only the DDEC instruction can use the 32-bit counter.
3. For the 16-bit operation, -32,768 minus 1 leaves 32,767. For the 32-bit operation, -2,147,483,648 minus 1 leaves 2,147,483,647.

**Example**

When X0.0 switches from OFF to ON, the value in D0 decreases by one.




API	Instruction code			Operand							Function					
0117		MUL16 MUL32	P	$S_1 \cdot S_2 \cdot D$							Multiplying 16-bit binary numbers Multiplying 32-bit binary numbers					

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
S <sub>1</sub>	●	●			●	●	●	●	●		○	○	○	○		
S <sub>2</sub>	●	●			●	●	●	●	●		○	○	○	○		
D		●			●	●	●	●			○	○				

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
S <sub>1</sub>		●	●			●	●				●	●	
S <sub>2</sub>		●	●			●	●				●	●	
D		●	●			●	●				●	●	

Pulse instruction	16-bit instruction	32-bit instruction
AS	AS	AS


**Symbol**



S<sub>1</sub> : Multiplicand  
 S<sub>2</sub> : Multiplier  
 D : Product


**Explanation**

1. This instruction multiplies the signed binary value in S<sub>1</sub> by the signed binary value in S<sub>2</sub>, and stores the product in D.
2. Only the MUL32 instruction can use an HC device.
3. 16-bit binary multiplication:



The product is a 16-bit value stored in D which is a 16-bit register. If b15 in D is 0, the product stored in D is a positive value. If b15 in D is 1, the product stored in D is a negative value.


4. 32-bit binary multiplication:



The product is a 32-bit value stored in (D, D+1) which is a 32-bit register. If b31 in D is 0, the product stored in (D, D+1) is a positive value. If b31 in D is 1, the product stored in (D, D+1) is a negative value.

**Example**

The instruction multiplies the 16-bit value in D0 by the 16-bit value in D10, and stores the product in D20. The sign of the product (positive or negative) depends on the leftmost bit (bit 15) in D20. If bit 15 in D20 is 0, the product stored in D20 is a positive value. If bit 15 in D20 is 1, the product stored in D20 is a negative value.



D0×D10=D20

16-bit value×16-bit value=16-bit value

**Additional remarks**

1. If the product of a 16-bit multiplication is not a 16-bit signed value available, and is greater than the maximum 16-bit positive number K32767, or less than the minimum negative number K-32768, the carry flag SM602 is ON, and only the low 16 bits are written.
2. If you need the complete result of a 16-bit multiplication (a 32-bit value), use the \*/P instruction (API 0102). Refer to the explanation for the \* instruction (API 0102) for more information.
3. If the product of a 32-bit multiplication is not a 32-bit signed value available, and is greater than the maximum 32-bit positive number K2147483647, or less than the minimum negative number K-2147483648, the carry flag SM602 is ON, and only the low 32 bits are written.
4. If you need the complete result of a 32-bit multiplication (a 64-bit value), use API 0102 D\*/D\*P. Refer to the explanation for the \* instruction (API 0102) for more information.


API	Instruction code			Operand							Function					
0118		DIV16 DIV32	P	<b>S<sub>1</sub> · S<sub>2</sub> · D</b>							Dividing 16-bit binary numbers Dividing 32-bit binary numbers					

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
<b>S<sub>1</sub></b>	●	●			●	●	●	●	●		○	○	●	●		
<b>S<sub>2</sub></b>	●	●			●	●	●	●	●		○	○	●	●		
<b>D</b>		●			●	●	●	●			○	○				

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
<b>S<sub>1</sub></b>		●	●			●	●				●	●	
<b>S<sub>2</sub></b>		●	●			●	●				●	●	
<b>D</b>		●	●			●	●				●	●	

Pulse instruction	16-bit instruction	32-bit instruction
AS	AS	AS


**Symbol**



- S<sub>1</sub>** : Dividend
- S<sub>2</sub>** : Divisor
- D** : Quotient; remainder


**Explanation**

1. This instruction divides the signed binary value in **S<sub>1</sub>** by the signed binary value in **S<sub>2</sub>**, and stores the quotient in **D**.
2. Only the 32-bit instruction can use an HC device.
3. Sign bit=0 (Positive number); sign bit =1 (Negative number)
4. 16-bit binary division:



The quotient is stored in **D**.


5. 32-bit binary division:



D occupies two consecutive devices. The quotient is stored in (D+1, D).

**Example**

When X0.0 is ON, the instruction divides the dividend in D0 by the divisor in D10, and stores the quotient D20. Whether the quotient is a positive value or a negative value depends on the leftmost bit in D20.



**Additional remarks**

1. If the device is not available, the instruction is not executed, SM0 will be ON, and the error code stored in SR0 is 16#2003.
2. If the divisor is 0, the instruction is not executed, SM0 will be ON, and the error code stored in SR0 is 16#2012.
3. If you want to store the remainder, use the “/” instruction (Dividing binary values). Refer to the explanation for the “/” instruction (API 0103) for more information.

## 6.3 Data Conversion Instructions

### 6.3.1 List of Data Conversion Instructions

The following table lists the Data Conversion instructions covered in this section.

API	Instruction code		Pulse instruction	Function
	16-bit	32-bit		
<u>0200</u>	BCD	DBCD	✓	Converting a binary number into a binary-coded decimal number
<u>0201</u>	BIN	DBIN	✓	Converting a binary-coded decimal number into a binary number
<u>0202</u>	FLT	DFLT	✓	Converting a binary integer into a binary floating-point number
<u>0204</u>	INT	DINT	✓	Converting a 32-bit floating-point number into a binary integer
<u>0206</u>	MMOV	–	✓	Converting a 16-bit value into a 32-bit value
<u>0207</u>	RMOV	–	✓	Converting a 32-bit value into a 16-bit value
<u>0208</u>	GRY	DGRY	✓	Converting a binary number into a Gray code
<u>0209</u>	GBIN	DGBIN	✓	Converting a Gray code into a binary number
<u>0210</u>	NEG	DNEG	✓	Two's complement
<u>0211</u>	–	FNEG	✓	Reversing the sign of a 32-bit floating-point number
<u>0212</u>	–	FBCD	✓	Converting a binary floating-point number into a decimal floating-point number
<u>0213</u>	–	FBIN	✓	Converting a decimal floating-point number into a binary floating-point number
<u>0214</u>	BKBCD	–	✓	Converting a binary numbers in blocks into a binary-coded decimal numbers in blocks
<u>0215</u>	BKBIN	–	✓	Converting a binary numbers in blocks into a binary-coded decimal numbers in blocks
<u>0216</u>	SCAL	DSCAL	✓	Finding a scaled value (point-slope)
<u>0217</u>	SCLP	DSCLP	✓	Finding a scaled value (two points)
<u>0222</u>	SCLM	DSCLM	✓	Multi-point section ratio operation

6.3.2 Explanation of Data Conversion Instructions


API	Instruction code			Operand				Function			
0200	D	BCD	P	S, D				Converting a binary number into a binary-coded decimal number			

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	“\$”	F
S	●	●			●	●	●	●	●		○	○				
D		●			●	●	●	●			○	○				

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
S		●	●			●	●				●	●	
D		●	●			●	●				●	●	

Pulse instruction	16-bit instruction	32-bit instruction
AS	AS	AS

Symbol




**S** : Source device  
**D** : Conversion result

Explanation

1. This instruction converts a binary value in **S** into a binary-coded decimal value, and stores the conversion result in **D**.
2. Only the DBCD instruction can use the 32-bit counter, but not the device E.
3. The four fundamental arithmetic operations in the PLC, the INC instruction, and the DEC instruction all operate on binary numbers. To show the decimal value on the display, use the BCD instruction to convert a binary value into a binary-coded decimal value

**Example**

1. When X0.0 is ON, the instruction converts a binary value in D10 into a binary-code decimal value, and stores the conversion result in D100.



2. If D10=16#04D2=1234, the conversion result is D100=16#1234.

**Additional remarks**

1. If the conversion result exceeds the range 0–9,999, the instruction BCD is not executed, SM0 is ON, and the error code in SR0 is 16#200D. The binary-coded decimal value is represented by the hexadecimal value, but one of digits is not between 0–9.
2. If the conversion result exceeds the range 0–99,999,999, the instruction DBCD is not executed, SM0 is ON, and the error code in SR0 is 16#200D. The binary-coded decimal value is represented by the hexadecimal value, but one of digits is not between 0–9.


API	Instruction code			Operand							Function					
0201	D	BIN	P	S, D							Converting a binary-coded decimal number into a binary number					

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
S	●	●			●	●	●	●	●		○	○				
D		●			●	●	●	●			○	○				

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
S		●	●			●	●				●	●	
D		●	●			●	●				●	●	

Pulse instruction	16-bit instruction	32-bit instruction
AS	AS	AS

**Symbol**




**S** : Source device  
**D** : Conversion result

**Explanation**

1. This instruction converts a binary-coded decimal value in **S** into a binary value, and stores the conversion result in **D**.
2. The 16-bit binary-coded decimal value in **S** must be between 0–9,999, and the 32-bit binary-coded decimal value in **S** must be between 0–99,999,999.
3. Only the 32-bit instructions can use the 32-bit counter, but not the device E.
4. The system converts constants and hexadecimal values into binary values automatically. Therefore, you do not need to use the instruction for that conversion.



**Example**

When X0.0 is ON, the instruction converts the binary-coded decimal value in D0 into the binary value, and stores the conversion result in D10.



**Additional remarks**

1. If the value in **S** is not the binary-coded decimal value, an operation error occurs, SM0 is ON, and the error code in SR0 is 16#200D. The binary-coded decimal value is represented by the hexadecimal value, but one of digits is not between 0–9.
2. Application of the BCD and BIN instructions:
  - Before the value of the binary-coded decimal type of DIP switch is read into the PLC, use the BIN instruction to convert the data into the binary value and store the conversion result in the PLC.
  - If you want to display the data stored inside the PLC in a seven-segment display of the binary-coded decimal type, use the BCD instruction to convert the data into the binary-coded decimal value before the data is sent to the seven-segment display.
  - When X1.0 is ON, the BIN instruction converts the binary-coded decimal value in X0.0–X0.15 into the binary value, and stores the conversion result in D100. Subsequently, the BCD instruction converts the binary value in D100 into the binary-coded decimal value, and stores the conversion result in Y0.0–Y0.15.



6

API	Instruction code			Operand							Function						
0202	D	FLT	P	<b>S, D</b>							Converting a binary integer into a binary floating-point number						

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
<b>S</b>	●	●			●	●	●	●	●		○	○				
<b>D</b>		●					●	●			○					

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
<b>S</b>		●	●			●	●				●	●	
<b>D</b>									●				

Pulse instruction	16-bit instruction	32-bit instruction
AS	AS	AS

### Symbol

FLT	FLTP
En	En
S	D
DFLT	DFLTP
En	En
S	D

**S** : Source device


**D** : Conversion result

### Explanation

- This instruction converts the binary integer in **S** into the single-precision floating-point number and stores the conversion result in **D**.
- The operand **S** used in the instruction FLT cannot be the 32-bit counter, and not the device E.
- The source device **S** used in the instruction FLT occupies one register, and **D** used in FLT occupies two registers.
- The source device **S** used in the instruction DFLT occupies two registers, and **D** used in DFLT also occupies two registers.
  - When the absolute value of the conversion result is larger than the value that can be represented by the maximum floating-point number, SM602 is ON, and the maximum floating-point number is stored in **D**.
  - When the absolute value of the conversion result is less than the value that can be represented by the minimum floating-point number, SM601 is ON, and the minimum floating-point number is stored in **D**.
  - When the conversion result is zero, SM600 is ON.

**Example 1**



1. When X0.0 is ON, the instruction converts the binary integer in D0 into a single-precision floating-point number, and stores the conversion result in (D13, D12).
2. When X0.1 is ON, the instruction converts the binary integer in (D1, D0) into a single-precision floating-point number, and stores the conversion result in (D21, D20).
3. Suppose the value in D0 is 10. When X0.0 is ON, the instruction converts 10 into the single-precision floating-point number 16#41200000, and then stores 16#41200000 in the 32-bit register (D13, D12).
4. Suppose the value in the 32-bit register (D1, D0) is 100,000. When X0.1 is ON, the instruction converts 100,000 into the single-precision floating-point number 16#47C35000, and stores 16#47C35000 in the 32-bit register (D21, D20).


**Example 2**

You can use the applied instructions to perform the following calculation.

- Convert the binary integer in D10 into the single-precision floating-point number, and store the conversion result in (D101, D100).
- Convert the binary-coded decimal value in X0.0–X0.15 into the binary value, and store the conversion result in D200.
- Convert the binary integer in D200 into the single-precision floating-point number, and store the conversion result in (D203, D202).
- Divide the constant 615 by the constant 10, and store the quotient which is the single-precision floating-point number in (D301, D300).
- Divide the single-precision floating-point number in (D101, D100) by the single-precision floating-point number in (D203, D202), and store the quotient which is the single-precision floating-point number in (D401, D400).

- Multiply the single-precision floating-point number in (D401, D400) by the single-precision floating-point number in (D301, D300), and store the product which is the single-precision floating-point number in (D21, D20).
- Convert the single-precision floating-point number in (D21, D20) into the decimal floating-point number, and store the conversion result in (D31, D30).
- Convert the single-precision floating-point number in (D21, D20) into the binary integer, and store the conversion result in (D41, D40).






API	Instruction code			Operand						Function					
0204	D	INT	P	S, D						Converting a 32-bit floating-point number into a binary integer					

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
S	●	●			●	●	●	●	●		○					
D		●			●	●	●	●			○	○				

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
S									●				
D		●	●			●	●				●	●	

Pulse instruction	16-bit instruction	32-bit instruction
AS	AS	AS

**Symbol**




**S** : Source device  
**D** : Conversion result

**Explanation**

- This instruction converts a single-precision floating-point number in **S** into a binary integer, then rounds the binary floating-point number down to the nearest whole digit to become a binary integer, and then the instruction stores the binary integer in **D**.
- The source device **S** used in the INT instruction occupies two registers, and **D** used in INT occupies one register.
- The source device **S** used in the DINT instruction occupies two registers, and **D** used in DINT also occupies two registers.
- The operand **D** used in the INT instruction cannot be the 32-bit counter, but not the device E.
- The INT instruction is the opposite of the FLT instruction .
- When the conversion result is zero, SM600 is ON.
- During the conversion, if the floating-point number is rounded down to the nearest whole digit, SM601 is ON.
- When the conversion result exceeds the range, SM602 is ON.
- For the INT/IINTP instructions, the range of conversion result is between -32,768 and 32,767.
- For the DINT/DINTP instructions, the range of conversion result is between -2,147,483,648 and 2,147,483,647.

**Example**

1. When X0.0 is ON, the instruction converts the single-precision floating-point number in (D1, D0) into a binary integer, and stores the conversion result in D10. The instruction rounds the binary floating-point number down to the nearest whole digit.
2. When X0.1 is ON, the instruction converts the single-precision floating-point number in (D21, D20) into a binary integer, and stores the conversion result in (D31, D30). The instruction rounds the binary floating-point number down to the nearest whole digit.



**Additional remarks**

If the value in **S** exceeds the range of values that can be represented by the floating-point numbers, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2013.

API	Instruction code			Operand							Function					
0206		MMOV	P	S, D							Converting a 16-bit value into a 32-bit value					

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
S	●	●			●	●		●	●		○	○	○	○		
D		●			●	●	●	●			○					

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
S		●				●	●				●	●	
D			●				●						

Pulse instruction	16-bit instruction	32-bit instruction
AS	AS	-

**Symbol**




**S** : Source device  
**D** : Conversion result

**Explanation**

This instruction copies the data in the 16-bit device **S** to the 32-bit device **D**, and copies the sign bit from **S** to **D**.

**Example**

When X0.0 is ON, the instruction copies the value of b15 in D4 to b15–b31 in (D7, D6), copies the values of b0–b14 to the corresponding bits in (D7, D6), and ignores the bits b15–b30. The data in (D7, D6) is a negative value (same as the source).



API	Instruction code				Operand							Function					
0207		RMOV	P		S, D							Converting a 32-bit value into a 16-bit value					
Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F	
S	●	●			●	●	●	●	●		○		○	○			
D		●			●	●		●			○	○					


  

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
S			●				●						
D		●				●	●				●	●	

Pulse instruction	16-bit instruction	32-bit instruction
AS	AS	-

**Symbol**




**S** : Source device  
**D** : Conversion result

**Explanation**

This instruction copies the data in the 32-bit device **S** to the 16-bit device **D**, and copies the sign bit from b31 to b15 so that the value in D4 is negative (same as b31).

**Example**

When X0.0 is ON, the instruction copies the value of b31 in D7 to b15 in D4, copies the values of b0–b14 to the corresponding bits in D4, and ignores bits b15–b30. The data in (D7, D6) is a negative value (same as the source).



API	Instruction code			Operand							Function					
0208	D	GRY	P	S, D							Converting a binary number into a Gray code					

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	“\$”	F
S	●	●			●	●	●	●	●		○	○	○	○		
D		●			●	●	●	●			○	○				

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
S		●	●			●	●				●	●	
D		●	●			●	●				●	●	

Pulse instruction	16-bit instruction	32-bit instruction
AS	AS	AS

**Symbol**



**S** : Source device  
**D** : Conversion result

**Explanation**


1. This instruction converts the binary value in the device specified by **S** into a Gray code, and stores the conversion result in the device specified by **D**.
2. Only the DGRY instruction can use the 32-counter, but not the device E.
3. The value in **S** should be within the available range.

The value in **S** in the 16-bit instruction must be between 0–32,767.

The value in **S** in the 32-bit instruction must be between 0–2,147,483,647.

**Example**

When X0.0 is ON, the instruction converts the constant 6513 into a Gray code, and stores the conversion result in Y1.0–Y1.15.





API	Instruction code			Operand							Function						
0209	D	GBIN	P	S, D							Converting a Gray code into a binary number						

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	“\$”	F
S	●	●			●	●	●	●	●		○	○	○	○		
D		●			●	●	●	●			○	○				

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
S		●	●			●	●				●	●	
D		●	●			●	●				●	●	

Pulse instruction	16-bit instruction	32-bit instruction
AS	AS	AS

**Symbol**



**S** : Source device  
**D** : Conversion result

**Explanation**



1. This instruction converts the Gray code in the device specified by **S** into the binary value, and stores the conversion result in the device specified by **D**.
2. Use this instruction to convert the Gray code in the absolute position encoder which is connected to the input terminal of the PLC to the binary value. The conversion result is stored in the specified register.
3. Only the DGBIN instruction can use the 32-counter, but not the device E.
4. The value in the device **D** must be within the available range.

The value in the device **D** in the 16-bit instruction must be between 0–32,767.

The value in the device **D** in the 32-bit instruction must be between 0–2,147,483,647.

**Example**

When X0.0 is ON, the instruction converts the Gray code in the absolute position encoder which is connected to the inputs X0.0–X0.15 into the binary value, and stores the conversion result in D10.



**Additional remarks**

If the value in **S** is less than 0, the operation error occurs, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2003.


API	Instruction code			Operand							Function					
0210	D	NEG	P	D							Finding the two's complement					

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
D		●			●	●	●	●			○	○				

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
D		●	●			●	●				●	●	

Pulse instruction	16-bit instruction	32-bit instruction
AS	AS	AS

**Symbol**




**D** : Device in which the two's complement is stored

**Explanation**

1. This instruction converts a negative binary value into the two's complement.
2. Only the DNEG instruction can use the 32-bit counter.
3. Generally, you use the NEGP and DNEGP pulse instructions.

**Example 1**


When X0.0 is switched from OFF to ON, this instruction inverts all bits in D0 (0 becomes 1, and 1 becomes 0), and 1 is added to the result, and then stores the final value in the original register D10.



**Example 2**

Finding the two's complement of the negative value:

1. When the value of the 15<sup>th</sup> bit in D0 is 1, M0 is ON, and the value in D0 is a negative value.
2. When M0 is ON, the NEG instruction finds the two's complement of the negative value in D0 (the corresponding positive value).




**Example 3**

Finding the two's complement of the difference between two values:

When X0.0 is ON,

1. If the value in D0 is greater than that in D2, M0 is ON.
2. If the value in D0 is equal to that in D2, M1 is ON.
3. If the value in D0 is less than that in D2, M2 is ON.
4. The value in D4 is a positive value.



**Additional remarks**

Binary representation of the value and its absolute value:

1. Whether the data is a positive value or a negative value depends on the value of the highest bit in the register. If the highest bit in the register is 0, the data is a positive value. If the highest bit is 1, the data is a negative value.
2. You can convert the negative value into its absolute value with the instruction NEG.

```
(D0)=2
0000000000000010

(D0)=1
0000000000000001

(D0)=0
0000000000000000
```


API	Instruction code			Operand							Function			
0211		FNEG	P	D							Reversing the sign of a 32-bit floating-point number			

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
D		●			●	●	●	●			○					

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
D									●				

Pulse instruction	16-bit instruction	32-bit instruction
AS	-	AS

**Symbol**



**D** : Device in which the sign of the value is reversed


**Explanation**

This instruction reverses the sign of a single-precision floating-point number in **D**.

**Example**

Before the instruction is executed, the value in (D1, D0) is the negative value 16#AE0F9000. When X0.0 switches from OFF to ON, the instruction reverses the sign of the single-precision floating-point number in (D1, D0). In other words, after the instruction is executed, the value in (D1, D0) is the positive value 16#2E0F9000.

Before the instruction is executed, the value in (D1, D0) is the positive value 16#2E0F9000. When X0.0 switches from OFF to ON, the instruction reverses the sign of the single-precision floating-point number in (D1, D0). In other words, after the instruction is executed, the value in (D1, D0) is the negative value 16#AE0F9000.



API	Instruction code			Operand						Function					
0212		FBCD	P	S, D						Converting a binary floating-point number into a decimal floating-point number					

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	“\$”	F
S	●	●			●	●	●	●	●		○					○
D		●			●	●		●			○					

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
S									●				
D									●				

Pulse instruction	16-bit instruction	32-bit instruction
AS	-	AS

**Symbol**



**S** : Data source  
**D** : Conversion result

**Explanation**

- This instruction converts three single-precision floating-point numbers in the register specified by **S** into the decimal floating-point number, and stores the conversion result in the register specified by **D**.
- The floating-point operation in the PLC is based on single-precision floating-point numbers. Use the FBCD instruction to convert a single-precision floating-point number into a decimal floating-point number.
- Instruction flags: SM600 (zero flag), SM601 (borrow flag), and SM602 (carry flag)


When the absolute value of the conversion result is larger than the value that can be represented by the maximum floating-point number, SM602 is ON.

When the absolute value of the conversion result is less than the value that can be represented by the minimum floating-point number, SM601 is ON.

When the conversion result is zero, SM600 is ON.

**Example**

When X0.0 is ON, the instruction converts the single-precision floating-point number in (D1, D0) into the decimal floating-point number, and stores the conversion result in (D3, D2).



Binary floating-point number 

D 1	D 0
-----	-----

 Real number: 23 bits; Exponent: 8 bits; sign: 1 bit



Decimal floating-point number 

D 3	D 2
-----	-----

 Exponent    Real number  
Mathematical form  $\Rightarrow [D2] \times 10^{[D3]}$

**Additional remarks**

If the value in **S** exceeds the range of values that can be represented by the floating-point numbers, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2013.


API	Instruction code			Operand							Function					
0213		FBIN	P	S, D							Converting a decimal floating-point number into a binary floating-point number					

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	“\$”	F
S	●	●			●	●		●	●		●					
D		●			●	●	●	●			●					

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
S									●				
D									●				

Pulse instruction	16-bit instruction	32-bit instruction
AS	-	AS

**Symbol**





**S** : Data source  
**D** : Conversion result

**Explanation**

- This instruction converts the decimal floating-point number in the register specified by **S** into the single-precision floating-point number, and stores the conversion result in the register specified by **D**.
- Suppose the value in **S** is 1234, and the value in **S**+1 is 3. The instruction converts the value in **S** into 1.234x10<sup>6</sup>.
- The value in **D** should be a single-precision floating-point number, and the values in **S** and **S**+1 represent the decimal real number and the decimal exponent respectively.
- Use the FBIN instruction to convert a decimal floating-point number into a single-precision floating-point number.
- The real number of decimal floating-point numbers are from -9,999 to +9,999, the exponents of decimal floating-point numbers are from -41 to +35. The practical range of decimal floating-point numbers in the PLC is between ±1175x10<sup>-41</sup> and ±3402x10<sup>+35</sup>. When the operation result is zero, SM600 is ON.


**Example 1**

- When X0.0 is ON, the instruction converts the decimal floating-point number in the register in (D1, D0) into the single-precision floating-point number, and stores the conversion result is stored in (D3, D2).



**Example 2**

- Before the floating-point operation is performed, use the FLT instruction to convert the binary integer into a single-precision floating-point number. Make sure the value to be converted is a binary integer before conversion. You can use the FBIN instruction to convert the floating-point number into the single-precision floating-point number.
- When X0.0 is ON, K314 and K-2 are moved to D0 and D1 respectively, and then FBIN combines them into the decimal floating-point number (3.14=314x10<sup>-2</sup>).



**Additional remarks**

If the real number part of the decimal floating-point number in **S** is not between -9,999 to +9,999, or if the exponent of the decimal floating-point number in **S** is not between -41 to +35, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2013.

API	Instruction code			Operand							Function					
0214		BKBCD	P	<b>S, n, D</b>							Converting binary numbers in blocks into binary-coded decimal numbers in blocks					

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
S	●	●			●	●		●	●							
n	●	●			●	●		●	●				○	○		
D		●			●	●		●								

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
S		●				●							
n		●				●							
D		●				●							

Pulse instruction	16-bit instruction	32-bit instruction
AS	AS	-

**Symbol**




- S** : Data source
- n** : Data length
- D** : Conversion result

**Explanation**

1. The instruction converts **n** pieces of data (the binary values) starting from **S** into the binary-coded decimal values, and stores the conversion results in **D**.
2. The operand **n** must be between 1–256.

**Example**

When M1 is ON, the instruction converts the binary values in D0 and D1 into the binary-coded decimal values, and stores the conversion results in D4 and D5.



**Additional remarks**

1. If **n** is less than 1, or larger than 256, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#200B.
2. If the devices specified by **S+n-1** and **D+n-1** exceed the range of possible devices, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2003.
3. If the conversion result is not between 0–9,999, the instruction is not executed, and the error code in SR0 is 16#200D. The binary-coded decimal value is represented by the hexadecimal number, but one of digits is not in between 0–9.
4. If **S–S+n-1** overlaps **D–D+n-1**, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#200C.


API	Instruction code			Operand							Function					
0215		BKBIN	P	S, n, D							Converting binary numbers in blocks into binary-coded decimal numbers in blocks					

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
S	●	●			●	●		●	●							
n	●	●			●	●		●	●				○	○		
D		●			●	●		●								

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
S		●				●							
n		●				●							
D		●				●							

Pulse instruction	16-bit instruction	32-bit instruction
AS	AS	-

**Symbol**




- S** : Data source
- n** : Data length
- D** : Conversion result

**Explanation**

1. The instruction converts **n** pieces of data (the binary-coded decimal values) starting from **S** into the binary values, and stores the conversion results in **D**.
2. The binary-coded decimal value in **S** must be between 0–9,999.
3. The operand **n** must be between 1 and 256.

**Example**

When M1 is ON, the instruction converts the binary-code decimal values in D0 and D1 into the binary values, and stores the conversion results in D4 and D5.



**Additional remarks**

1. If **n** is not between 1–256, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#200B.
2. If the devices specified by **S+n-1** and **D+n-1** exceed the range of possible devices, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2003.
3. If the data in **S** is not a binary-coded decimal, the instruction is not executed, and the error code in SR0 is 16#200D. The binary-coded decimal value is represented by the hexadecimal number, but one of digits is not between 0–9.
4. If **S–S+n-1** overlap **D–D+n-1**, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#200C.


API	Instruction code			Operand						Function					
0216		SCAL	P	<b>S<sub>1</sub>, S<sub>2</sub>, S<sub>3</sub>, D</b>						Finding a scaled value (point-slope)					

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
S <sub>1</sub>	●	●			●	●		●	●		○	○	○	○		
S <sub>2</sub>	●	●			●	●		●	●		○	○	○	○		
S <sub>3</sub>	●	●			●	●		●	●		○	○	○	○		
D		●			●	●		●			○	○				

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
S <sub>1</sub>		●	●			●	●						
S <sub>2</sub>		●	●			●	●						
S <sub>3</sub>		●	●			●	●						
D		●	●			●	●						

Pulse instruction	16-bit instruction	32-bit instruction
AS	AS	AS

**Symbol**



- S<sub>1</sub>** : Data source
- S<sub>2</sub>** : Slope
- S<sub>3</sub>** : Offset
- D** : Destination device


**Explanation**

- This instruction finds a scaled linear value for the number in **S<sub>1</sub>** using the slope of the line in **S<sub>2</sub>** and the offset in **S<sub>3</sub>** to define the scaling factor, and stores the result in **D**.
- The operation equation in the instruction is  $D=(S_1 \times S_2) \div 1,000 + S_3$
- To get the values in **S<sub>2</sub>** and **S<sub>3</sub>**, use the slope equation and the offset equation below first, and then round off the results to the nearest whole digit. Enter the final 16-bit values into **S<sub>2</sub>** and **S<sub>3</sub>**.

The slope equation:  $S_2 = [(Maximum\ destination\ value - Minimum\ destination\ value) \div (Maximum\ source\ value - Minimum\ source\ value)] \times 1,000$

The offset equation:  $S_3 = Minimum\ destination\ value - Minimum\ source\ value \times S_2 \div 1,000$



The output curve is shown below:



**Example 1**



1. Suppose the values in **S<sub>1</sub>**, **S<sub>2</sub>**, and **S<sub>3</sub>** are 500, 168, and -4 respectively. When X0.0 is ON, the SCAL instruction calculates the scaled value, and stores the scaled value in D0.
2. For equation:  $D0 = (500 \times 168) \div 1,000 + (-4) = 80$

6



**Example 2**

1. Suppose the values in **S<sub>1</sub>**, **S<sub>2</sub>**, and **S<sub>3</sub>** are 500, -168, and 534 respectively. When X0.0 is ON, the SCAL instruction calculates the scaled value, and stores the scaled value in D10.
2. For the equation:  $D10=(500 \times -168) \div 1,000 + 534 = 450$

**Additional remarks**

1. You must know the slope and the offset to use SCAL. If the slope and the offset are unknown, you can use the SCLP instruction.
2. When the 16-bit instruction is performed, the value entered into **S<sub>2</sub>** must be between -32,768 to 32,767. If the value in **S<sub>2</sub>** exceeds the range, use the SCLP instruction.
3. When the 32-bit instruction is performed, the value entered into **S<sub>2</sub>** must be between -2,147,483,648 to 2,147,483,647. If the value in **S<sub>2</sub>** exceeds the range, use the SCLP instruction.
4. When you use the slope equation, note that the maximum source value should be larger than the minimum source value. However, the maximum destination value is not necessarily larger than the minimum destination value.
5. For the 16-bit instruction, if the value in **D** is larger than 32,767, the value stored in **D** is 32,767. If the value in **D** is less than -32,768, the value stored in **D** is -32,768.
6. When the 32-bit instruction is performed, if the value in **D** is larger than 2,147,483,647, the value stored in **D** will be 2,147,483,647. If the value in **D** is less than -2,147,483,648, the value stored in **D** will be -2,147,483,648.

API	Instruction code			Operand							Function					
0217	D	SCLP	P	$S_1 \cdot S_2 \cdot S_3 \cdot D$							Finding a scaled value (two points)					

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
S <sub>1</sub>	●	●			●	●	●	●	●		○	○	○	○		○
S <sub>2</sub>	●	●			●	●	●	●	●							
D		●			●	●	●	●			○	○				

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
S <sub>1</sub>		●	●			●	●		●				
S <sub>2</sub>		●	●			●	●		●				
D		●	●			●	●		●				

Pulse instruction	16-bit instruction	32-bit instruction
AS	AS	AS

**Symbol**

SCLP		SCLPP	
En		En	
S <sub>1</sub>	D	S <sub>1</sub>	D
S <sub>2</sub>		S <sub>2</sub>	

DSCLP		DSCLPP	
En		En	
S <sub>1</sub>	D	S <sub>1</sub>	D
S <sub>2</sub>		S <sub>2</sub>	

- S<sub>1</sub> : Data source
- S<sub>2</sub> : Parameter
- D : Destination device

**Explanation**

1. This instruction finds a scaled linear value for the value in S<sub>1</sub> using two points in S<sub>2</sub> to define the scaling factor, and stores the result in D.
2. Only the 32-bit instructions can use the 32-bit counter, but not the device E.
3. The following table list the constant usage for the operand S<sub>1</sub>

Constant	16-bit instruction	32-bit instruction	
		SM685 ON	SM685 OFF
Constant	○	X	○
Hexadecimal	○	X	○
Floating number	X	○	X

The flag SM685 (whether to use floating point operation or not) can only be used for 32-bit instructions.

4. The operand  $S_2$  used in the 16-bit instruction is set as shown in the following table.

Device number	Parameter	Setting range
$S_2$	Maximum source value	-32,768 to 32,767
$S_{2+1}$	Minimum source value	-32,768 to 32,767
$S_{2+2}$	Maximum destination value	-32,768 to 32,767
$S_{2+3}$	Minimum destination value	-32,768 to 32,767

5. The operand  $S_2$  used in the 16-bit instruction occupies four devices.

6. The operand  $S_2$  used in the 32-bit instruction is set as shown in the following table.

Device number	Parameter	Setting range	
		Integer	Floating-point number
$S_2 \sim S_{2+1}$	Maximum source value	-2,147,483,648 to 2,147,483,647	The range of 32-bit floating-point numbers
$S_{2+2} \sim 3$	Minimum source value		
$S_{2+4} \sim 5$	Maximum destination value		
$S_{2+6} \sim 7$	Minimum destination value		

7. The operand  $S_2$  used in the 32-bit instruction occupies eight devices.
8. If the values in the 32-bit instruction are floating-point numbers, set SM658 to ON. If the values are decimal integers, set SM685 to OFF.
9. The operation equation in the instruction is:  

$$D = [(S_1 - \text{Minimum source value}) \times (\text{Maximum destination value} - \text{Minimum destination value})] \div (\text{Maximum source value} - \text{Minimum source value}) + \text{Minimum destination value}$$
10. The operational relation between the source value and the destination value is:

$$y = kx + b$$

$$y = \text{Destination value (D)}$$

$$k = \text{Slope} = (\text{Maximum destination value} - \text{Minimum destination value}) \div (\text{Maximum source value} - \text{Minimum source value})$$


$$x = \text{Source value (S}_1\text{)}$$

$$b = \text{Offset} = \text{Minimum destination value} - \text{Minimum source value} \times \text{Slope}$$

The parameters above are substituted for y, k, x, and b in the equation  $y = kx + b$  to get the operation equation as follows:



$$y = kx + b = D = kS_1 + b = \text{Slope} \times S_1 + \text{Offset} = \text{Slope} \times S_1 + \text{Minimum destination value} - \text{Minimum source value} \times \text{Slope} = \text{Slope} \times (S_1 - \text{Minimum source value}) + \text{Minimum destination value} = (S_1 - \text{Minimum source value}) \times (\text{Maximum destination value} - \text{Minimum destination value}) \div (\text{Maximum source value} - \text{Minimum source value}) + \text{Minimum destination value}$$

11. If  $S_1$  is larger than the maximum source value, the maximum source value is the value in  $S_1$ . If  $S_1$  is less than the minimum source value, the minimum source value is the value in  $S_1$ . The output curve is shown below.





**Example 1**

1. Suppose the value in  $S_1$  is 500, the maximum source value in D0 is 3,000, the minimum source value in D1 is 200, the maximum destination value in D2 is 500, and the minimum destination value in D3 is 30. When X0.0 is ON, the SCLP instruction calculates the scale value and stores it in D10.
2. The operation equation:  $D10 = [(500 - 200) \times (500 - 30)] \div (3,000 - 200) + 30 = 80.35$   
80.35 is rounded off to the nearest whole digit, and becomes 80. 80 is stored in D10.





**Example 2**

1. Suppose the value in  $S_1$  is 500, the maximum source value in D0 is 3,000, the minimum source value in D1 is 200, the maximum destination value in D2 is 30, and the minimum destination value in D3 is 500. When X0.0 is ON, the SCLP instruction calculates the scales value, and stores it in D10.
2. The operation equation:  $D10 = [(500 - 200) \times (30 - 500)] \div (3,000 - 200) + 500 = 449.64$   
449.64 is rounded off to the nearest whole digit, and becomes 450. 450 is stored in D10.



**Example 3**

- Suppose the value in **S<sub>1</sub>** is 500.0, the maximum source value in D0 is 3000.0, the minimum source value in D2 is 200.0, the maximum destination value in D4 is 500.0, and the minimum destination value in D6 is 30.0. When X0.0 is ON, SM685 is set to ON, the instruction DSCLP calculates the scale value and stores it in D10.
- The operation equation:  $D10 = [(500.0 - 200.0) \times (500.0 - 30.0)] \div (3000.0 - 200.0) + 30.0 = 80.35$   
80.35 is rounded off to the nearest whole digit, and becomes 80.0. 80.0 is stored in D10.



**Additional remarks**

1. The value in  $S_1$  for 16-bit instructions must be between the minimum source value and the maximum source value; that is, between -32,768 to 32,767. If the value exceeds the boundary value, the calculation uses the boundary value.
2. The integer in  $S_1$  for 32-bit instructions must be between the minimum source value and the maximum source value; that is, between -2,147,483,648 to 2,147,483,647. If the integer exceeds the boundary value, the calculation uses the boundary value.

3. The floating-point number in **S<sub>1</sub>** for 32-bit instructions must be between the minimum source value and the maximum source value; that is, within the range of floating-point numbers. If the floating-point number exceeds the boundary value, the calculation uses the boundary value.
4. Note that the maximum source value must be larger than the minimum source value. However, the maximum destination value is not necessarily larger than the minimum destination value.
5. When the maximum source value is the same as the minimum source value, the instruction is not executed, SM0 is ON and the error code in SR0 is 16#2012.
6. If you declare **S<sub>2</sub>** for a 16-bit instruction in ISPSOft, the data type is ARRAY [4] of WORD.
7. If you declare **S<sub>2</sub>** for a 32-bit instruction in ISPSOft, the data type is ARRAY [4] of DWORD.


API	Instruction			Operand							Description						
0222	D	SCLM	P	<b>S<sub>1</sub>, S<sub>2</sub>, S<sub>3</sub>, S<sub>4</sub>, D</b>							Multi-point section ratio operation						

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
S <sub>1</sub>					●	●	●	●								
S <sub>2</sub>					●	●	●	●					○	○		
S <sub>3</sub>					●	●	●	●	●							
S <sub>4</sub>					●	●	●	●	●							
D					●	●	●	●								


Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
S <sub>1</sub>		●	●			●	●		●				
S <sub>2</sub>		●	●			●	●						
S <sub>3</sub>		●	●			●	●						
S <sub>4</sub>		●	●			●	●						
D		●	●			●	●		●				

Pulse Instruction	16-bit instruction	32-bit instruction
AS	AS	AS

**Symbol**



- S<sub>1</sub> : Data source
- S<sub>2</sub> : Number of multi-point sections
- S<sub>3</sub> : Comparison value in a multi-point section
- S<sub>4</sub> : Conversion reference value
- D : Operation result



**Explanation**


1. Only the 32-bit instruction can use HC devices but not E devices. The firmware of V1.04.00 and later for AS300 PLC supports the instruction.
2. See the following table about data types that the operands **S<sub>1</sub>**, **S<sub>3</sub>** and **S<sub>4</sub>** correspond to. (○ represents 'Usable'. X represents 'Unusable'.)

Constant	16-bit instruction	32-bit instruction	
		SM685 ON	SM685 OFF
<b>K</b>	○	X	○
<b>16#</b>	○	X	○
<b>F</b>	X	○	X

Note: SM685=ON (the floating point number operation) works for the 32-bit instruction only.

3. **S<sub>1</sub>** is the data source. **S<sub>2</sub>** is the number of multi-point sections and the value should be between 2 and 50. If the value exceeds the range, the instruction will be executed automatically at the minimum value or maximum value. **S<sub>3</sub>** is a setting value for comparison in a multi-point section. **S<sub>4</sub>** is a conversion reference value that a multi-point section comparison value corresponds to, e.g. the number of sections, **S<sub>2</sub>** is 10. Then **S<sub>3</sub> ~ S<sub>3</sub>+9** are comparison values in 10 sections. **S<sub>4</sub> ~ S<sub>4</sub>+9** are 10 corresponding conversion reference values.
4. The comparison order for multi-point sections is 0, 1, 2 ... **S<sub>2</sub>-1**. The comparison rule is **S<sub>1</sub> >= S<sub>3</sub>+0** and **S<sub>1</sub> < S<sub>3</sub>+1**. If **S<sub>1</sub>** value does not belong to a section, the comparison will move on to the next section. For example, **S<sub>1</sub> >= S<sub>3</sub>+1** and **S<sub>1</sub> < S<sub>3</sub>+2**, the comparison keeps going until the number of comparison times reaches **S<sub>2</sub> - 1**.


5. The instruction compares sections in the order from small to large. Please design the value comparison of  $S_3$  section in the order from small to large as well.
6. See the figure below for the conversion of multi-point section values. (Set the number of sections,  $S_2$  to 4.)



7. If  $S_1$  value is between  $S_3+0$  and  $S_3+1$ , the conversion formula:  $D = ( ( S_1 - S_3+0 ) \times ( S_4+1 - S_4+0 ) / ( S_3+1 - S_3+0 ) ) + S_4+0$ .
8. If  $S_1$  value does not belong to any specified section, the execution result in D is explained as below.
 

If  $S_1$  value > the last specified section, D will store the last conversion reference value of S4, e.g. if  $S_1$  value >  $S_3+3$  value in the figure above,  $D=S_4+3$ .

If  $S_1$  value < the first specified section, D will store the first conversion reference value of S4, e.g. if  $S_1$  value <  $S_3+0$  value in the figure above,  $D=S_4+0$ .
9. If  $S_3$  and  $S_4$  of the 16-bit instruction are declared on ISPSOft, the data type is ARRAY [S2] of WORD.
10. If  $S_3$  and  $S_4$  of the 32-bit instruction are declared on ISPSOft, the data type is ARRAY [S2] of DWORD (SM685=OFF) or ARRAY [S2] of REAL (SM685=ON).
11. For PLC CPU with firmware V1.12.10 or later, DSCLM instruction (32-bit) supports the application of Thread Gauge Calibration. And the differences of the thread ring and pitch diameter between the physical parameter and the number of output pulses can be corrected.
12. Operational steps:
  - 1) Measure each pitch diameter of the thread ring and the corresponding number of output pulses and then enter the measured values in  $S_3$  and  $S_4$  respectively.




Calibration section number	Target position Value in <b>S<sub>3</sub></b>	Number of actual output pulses Value in <b>S<sub>4</sub></b>
1	-5000 (D100, D101)	-5002 (D200, D201)
2	-4000 (D102, D103)	-4003 (D202, D203)
.		
.		
6	0 (D110, D111)	0 (D210, D211)
7	1000 (D112, D113)	1003 (D212, D213)
.		
.		
16	10000 (D130, D131)	10005 ( D230 · D231 )

6

2) The low byte in **S<sub>2</sub>** is where you specify the calibration section number; up to 50 sections can be set. While high byte in **S<sub>2</sub>** is where you specify the axis number to execute calibration function; the value in high byte can be 0, indicating the data conversion is underway. The value in high byte can be 1 to 12, indicating output points Y0.0 to Y0.11, and the calibration is underway on the specified output point. The operands **S<sub>1</sub>** and **D** are invalid while executing calibration.

3) Use EN contact to start DSCLM instruction (calibration) and the positioning instruction will act according to the calibration parameters to modify the number of actual output pulses on the specified output point. When DSCLM instruction is closed, the calibration is closed.

**Example**



The comparison values of **S<sub>3</sub>** for multi-point sections are given as follows.

Device	D100	D101	D102	D103
Content	100	200	300	400

The corresponding conversion reference values of **S<sub>4</sub>** are given as follows.

Device	D200	D201	D202	D203
Content	4000	3000	1500	2000

Here is the explanation about the value in D2 obtained through a conversion based on the data resource D0.

Set D0=10,  
 Since D0<D100 (in the first section), D2=D200=4000 (the first conversion reference value)

Set D0=K150,  
 D0 value is in between (D100, D101) = (100, 200) and the corresponding reference value is (D200, D201) = (4000, 3000)  
 Therefore,  
 $D2 = (150-100) * (3000-4000) / (200-100) + 4000 = 3500$

Set D0=450  
 Since D0>D103 (in the last section), D2=D203=2000 (the last conversion reference value)

Set D0=K250  
 D0 value is between (D101, D102) = (200, 300) and the corresponding reference value is (D201, D202) = (3000, 1500).  
 Therefore,  
 $D2 = (250-200) * (1500-3000) / (300-200) + 3000 = 2250$

Set D0=K350  
 D0 is between (D102, D103) = (300, 400) and the corresponding reference value is (D202, D203) = (1500, 2000)  
 Therefore,  
 $D2 = (350-300) * (2000-1500) / (400-300) + 1500 = 1750$

## 6.4 Data Transfer Instructions

### 6.4.1 List of Data Transfer Instructions

The following table lists the Data Transfer instructions covered in this section.

API	Instruction code		Pulse instruction	Function
	16-bit	32-bit		
<b><u>0300</u></b>	MOV	DMOV	✓	Transferring data
<b><u>0302</u></b>	\$MOV	–	✓	Transferring a string
<b><u>0303</u></b>	CML	DCML	✓	Inverting data
<b><u>0304</u></b>	BMOV	DBMOV	✓	Transferring data in blocks
<b><u>0305</u></b>	NMOV	DNMOV	✓	Transferring data to multiple devices
<b><u>0306</u></b>	XCH	DXCH	✓	Exchanging data
<b><u>0307</u></b>	BXCH	–	✓	Exchanging data in blocks
<b><u>0308</u></b>	SWAP	DSWAP	✓	Exchanging the high byte with the low byte
<b><u>0309</u></b>	SMOV	–	✓	Transferring digits in blocks
<b><u>0310</u></b>	MOVB	–	✓	Transferring bits in blocks

### 6.4.2 Explanation of Data Transfer Instructions


API	Instruction code			Operand								Function				
0300	D	MOV	P	S, D								Transferring data				

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
S	●	●			●	●	●	●	●		○	○	○	○		○
D		●			●	●	●	●			○	○				

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
S		●	●			●	●		●		●	●	
D		●	●			●	●		●		●	●	

Pulse instruction	16-bit instruction	32-bit instruction
AS	AS	AS

#### Symbol



**S** : Data source  
**D** : Data destination

#### Explanation

- This instruction transfers the data in **S** to **D**.
- You must use a 32-bit instruction when the data in **S** is a floating-point number.
- Only the 32-bit instructions can use the 32-bit counter, but not the device E.

#### Example

- To transfer 16-bit data, use MOV.
  - When X0.0 is OFF, the data in D0 is unchanged. When X0.0 is ON, the instruction transfers 10 to the data register D0.
  - When X0.1 is OFF, the data in D10 is unchanged. When X0.1 is ON, the instruction transfers the current value of T0 to the data register D10.


2. For 32-bit data, use DMOV.

- When X0.2 is OFF, the data in (D31, D30) and (D41, D40) is unchanged. When X0.2 is ON, the instruction transfers the current value in (D21, D20) to (D31, D30), and transfers the current value of HC0 to (D41, D40).

3. For floating-point numbers, use DMOV.

- When X0.3 is OFF, the data in (D51, D50) is unchanged. When X0.3 is ON, the instruction converts the floating-point number 3.450 into a binary floating-point number, and transfers the conversion result is to (D51, D50).


NETWORK 1



NETWORK 2



NETWORK 3



NETWORK 4



6


API	Instruction code			Operand						Function					
0302		\$MOV	P	<b>S, D</b>						Transferring a string					

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
<b>S</b>	●	●			●	●		●	●						○	
<b>D</b>		●			●	●		●								

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
<b>S</b>													●
<b>D</b>													●

Pulse instruction	16-bit instruction	32-bit instruction
AS	AS	-

### Symbol



**S** : Data source

**D** : Data destination

### Explanation

1. This instruction transfers the string in **S** to **D**, and adds the code 16#00 to the end of the string.
2. When the operand **S** is not a string, the instruction adds the code 16#00 to the end of the data transferred.
3. When the ending code 16#00 cannot be found in **S** for 256 characters in a row or even beyond the device range, the instruction is not executed; SM0 is ON and the error code in SR0 is 16#200E.
4. When the operand **S** is not a string and the instruction is executed, the string starting with the data in the device specified by **S** (including 16#00) is transferred to **D**. When the instruction is not executed, the data in **D** is unchanged.
5. If **D** is not sufficient to contain the string composed of the values in **S**, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2003.
6. Suppose the operand **S** is not a string. When the instruction is executed and the first character in **S** is the code 16#00, 16#00 is still transferred to **D**.

7. When 16#00 appears in the low byte, the execution of the instruction is as follows.

Before the instruction is executed:

b15~b8 b7~b0		B15~b8 b7~b0			
S	16#31	16#30	D	16#38	16#39
S+1	16#33	16#32	D+1	16#36	16#37
S+2	16#35	16#34	D+2	16#34	16#35
S+3	16#30	16#00	D+3	16#32	16#33

After the instruction is executed:

b15~b8 b7~b0		b15~b8 b7~b0			
S	16#31	16#30	D	16#31	16#30
S+1	16#33	16#32	D+1	16#33	16#32
S+2	16#35	16#34	D+2	16#35	16#34
S+3	16#30	16#00	D+3	16#00	16#00

↑ 16#30 in the high byte is not transferred.
 ↑ 16#32 in the high byte turns into 16#00.

8. When 16#00 appears in the high byte, the execution of the instruction is as follows. The transfer stops when the code 16#00, leaving the remainder of **D** unchanged.

Before the instruction is executed:

b15~b8 b7~b0		b15~b8 b7~b0			
S	16#31	16#30	D	16#38	16#39
S+1	16#33	16#32	D+1	16#36	16#37
S+2	16#00	16#34	D+2	16#34	16#35
S+3	16#37	16#36	D+3	16#32	16#33

After the instruction is executed:

b15~b8 b7~b0		b15~b8 b7~b0			
S	16#31	16#30	D	16#31	16#30
S+1	16#33	16#32	D+1	16#33	16#32
S+2	16#00	16#34	D+2	16#00	16#34
S+3	16#37	16#36	D+3	16#32	16#33

9. When **S** overlaps **D** and the device number of **S** is less than the device number of **D**, the transfer of the data to **D** starts from the ending code 16#00.

Before the instruction is executed:

b15~b8		b7~b0	b15~b8		b7~b0
D0	16#31	16#30	D1	16#33	16#32
D1	16#33	16#32	D2	16#35	16#34
D2	16#35	16#34	D3	16#30	16#00
D3	16#30	16#00	D4	16#38	16#37

After the instruction is executed:

b15~b8		b7~b0	b15~b8		b7~b0
D0	16#31	16#30	D1	16#31	16#30
D1	16#33	16#32	D2	16#33	16#32
D2	16#35	16#34	D3	16#35	16#34
D3	16#30	16#00	D4	16#00	16#00

**Example 1**

Suppose the data in **S** is the string "1234" (even number of bytes). When X0.0 is enabled, the data 1234 and the ending code 16#00 is transferred to D0–D3 and 16#00 is added to the high byte in **D**, as follows.



The operand **S**:


String	'1'	'2'	'3'	'4'
Hexadecimal value	16#31	16#32	16#33	16#34

After the instruction is executed, the data in **D** is as follows.

Device	High byte	Low byte	Note
D0	16#32	16#31	'1'=16#31; '2'=16#32
D1	16#34	16#33	'3'=16#33; '4'=16#34
D2	16#00	16#00	The ending code 16#00 is in the low byte. 16#00 is automatically added in the high byte.
D3	Unchanged	Unchanged	

**Example 2**

Suppose the data in **S** is the string "12345" (odd number of bytes). When X0.0 is enabled, the data 12345 is transferred to D0–D3 as follows.



The operand **S**:

String	'1'	'2'	'3'	'4'	'5'
Hexadecimal value	16#31	16#32	16#33	16#34	16#35

After the instruction is executed, the data in the operand **D** is as follows.

Device	High byte	Low byte	Note
D0	16#32	16#31	'1'=16#31; '2'=16#32
D1	16#34	16#33	'3'=16#33; '4'=16#34
D2	16#00	16#35	The ending code 16#00 is in the high byte.
D3	Unchanged	Unchanged	

**Example 3**

When the data in **S** is not a string and the ending code 16#00 appears in the low byte, the execution of the instruction is as follows.



The operand **S**:

Device	High byte	Low byte	Note
D100	16#31	16#30	'1'=16#31; '0'=16#30
D101	16#33	16#32	'3'=16#33; '2'=16#32
D102	16#35	16#34	'5'=16#35; '4'=16#34
D103	16#30	16#00	'0'=16#30; 16#00 is the ending code.

After the instruction is executed, the data in the operand **D** is as follows.

Device	High byte	Low byte	Note
D0	16#31	16#30	'1'=16#31; '0'=16#30
D1	16#33	16#32	'3'=16#33; '2'=16#32
D2	16#35	16#34	'5'=16#35; '4'=16#34
D3	16#00	16#00	The ending code 16#00 is in the low byte. 16#00 is automatically added in the high byte.
D4	Unchanged	Unchanged	

**Example 4**

When the data in **S** is not a string and the ending code 16#00 appears in the high byte, the execution of the instruction is as follows.



The operand **S**:


Device	High byte	Low byte	Note
D100	16#31	16#30	'1'=16#31; '0'=16#30
D101	16#33	16#32	'3'=16#33; '2'=16#32
D102	16#00	16#34	16#00 is the ending code. '4'=16#34
D103	16#37	16#36	'7'=16#37; '6'=16#36

After the instruction is executed, the data in the operand **D** is as follows.

Device	High byte	Low byte	Note
D0	16#31	16#30	'1'=16#31; '0'=16#30
D1	16#33	16#32	'3'=16#33; '2'=16#32
D2	16#00	16#34	16#00 is the ending code. '4'=16#34
D3	Unchanged	Unchanged	

**Example 5**

When **S** overlaps **D**, and the device number of **S** is less than the device number of **D**, the transfer of the data to **D** starts from the ending code 16#00.



The operand **S**:

Device	High byte	Low byte	Note
D0	16#31	16#30	'1'=16#31; '0'=16#30
D1	16#33	16#32	'3'=16#33; '2'=16#32
D2	16#35	16#34	'5'=16#35; '4'=16#34
D3	16#30	16#00	'0'=16#30; 16#00 is the ending code.
D4	16#38	16#37	'8'=16#38; '7'=16#37

**6**

After the instruction is executed, the data in **D** is as follows.

Device	High byte	Low byte	Note
D1	16#31	16#30	'1'=16#31; '0'=16#30
D2	16#33	16#32	'3'=16#33; '2'=16#32
D3	16#35	16#34	'5'=16#35; '4'=16#34
D4	16#00	16#00	The ending code 16#00 is in the low byte. 16#00 is automatically added in the high byte.
D5	Unchanged	Unchanged	


API	Instruction code			Operand							Function					
0303	D	CML	P	S, D							Inverting data					

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
S	●	●			●	●	●	●	●		○	○	○	○		
D		●			●	●	●	●			○	○				

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
S		●	●			●	●						
D		●	●			●	●						

Pulse instruction	16-bit instruction	32-bit instruction
AS	AS	AS

**Symbol**




**S** : Data source  
**D** : Data destination

**Explanation**

1. This instruction inverts all bits in **S**; that is, 0 becomes 1, and 1 becomes 0, and stores the inversion result in **D**. If the data in **S** is a constant, the instruction converts it into a binary value.
2. Only the 32-bit instructions can use the 32-bit counter, but not the device E.


**Example 1**

When X0.0 is ON, the instruction inverts all bit in D1, and stores the conversion result in Y0.0–Y0.15.



**Example 2**

The circuits below can be represented with the CML instruction.




API	Instruction code			Operand						Function					
0304	D	BMOV	P	S, D, n						Transferring data in blocks					

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	“\$”	F
S	●	●			●	●	●	●	●							
D		●			●	●	●	●								
n	●	●			●	●	●	●	●				○	○		

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
S		●	●			●	●						
D		●	●			●	●						
n		●	●			●	●						

Pulse instruction	16-bit instruction	32-bit instruction
AS	AS	AS

**Symbol**




- S** : Data source
- D** : Data destination
- n** : Data length


**Explanation**

1. This instruction transfers **n** pieces of data in a block starting from the device specified by **S** to the devices starting from the device specified by **D**.
2. The value in **n** must be between 1–256.
3. Only the 32-bit instructions can use the 32-bit counter, but not the device E.
4. To prevent overlapping the source and the destination, the instruction transfers the data in the following way (using the 16-bit instruction as an example).

When the device number of **S** is larger than the device number of **D**, the data is transferred in the order from ① to ③.





When the device number of **S** is less than the device number of **D**, the data is transferred in the order from ③ to ①.



**Example 1**

When X0.0 is ON, the instruction transfers the data in D0–D3 to D20–D23.





6


**Example 2**

To prevent overlapping the source and the destination, the data is transferred in the following way.

1. When the device number of **S** is larger than the device number of **D**, the data is transferred in the order from ① to ③.



2. When the device number of **S** is less than the device number of **D**, the data is transferred in the order from ③ to ①.



#### Additional remarks

1. If  $D+n-1$  exceeds the device range, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2003.
2. If  $S+n-1$  exceeds the device range, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2003.
3. If  $n$  is not between 1–256, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#200B.


API	Instruction code			Operand							Function				
0305	D	NMOV	P	S, D, n							Transferring data to multiple devices				

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
S	●	●			●	●	●	●	●				○	○		
D		●			●	●	●	●								
n	●	●			●	●	●	●	●				○	○		

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
S		●	●			●	●						
D		●	●			●	●						
n		●	●			●	●						

Pulse instruction	16-bit instruction	32-bit instruction
AS	AS	AS


**Symbol**



**S** : Data source  
**D** : Data destination  
**n** : Data length


**Explanation**

1. This instruction transfers the data in **S** to the **n** devices starting from the device specified by **D**. When the instruction is not executed, the data in **D** is unchanged.
2. Only the 32-bit instructions can use the 32-bit counter.
3. The value in **n** in the NMOV instruction must be between 1–256.



**Example**

When M0 is ON, 100 is transferred to D0-D9.

**Additional remarks**

1. If  $D-D+n-1$  exceeds the device range, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2003.
2. If the value in  $n$  in the 16-bit instruction is not between 1–256, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#200B.


API	Instruction code			Operand							Function				
0306	D	XCH	P	S <sub>1</sub> , S <sub>2</sub>							Exchanging data				

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
S <sub>1</sub>		●			●	●	●	●				○				
S <sub>2</sub>		●			●	●	●	●				○				

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
S <sub>1</sub>		●	●			●	●						
S <sub>2</sub>		●	●			●	●						

Pulse instruction	16-bit instruction	32-bit instruction
AS	AS	AS

**Symbol**



S<sub>1</sub> : Data to exchange


S<sub>2</sub> : Data to exchange

**Explanation**

1. This instruction exchanges the data in the device specified by S<sub>1</sub> with the data in the device specified by S<sub>2</sub>.
2. Only the 32-bit instructions can use the 32-bit counter, but not the device E.


**Example 1**

When X0.0 is switched from OFF to ON, the instruction exchanges the data in D20 with the data in D40.



**Example 2**

When X0.0 switches from OFF to ON, the instruction exchanges the data in D100 with the data in D200.




API	Instruction code			Operand							Function					
0307		BXCH	P	$S_1 \cdot S_2 \cdot n$							Exchanging data in blocks					

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
$S_1$		●			●	●		●								
$S_2$		●			●	●		●								
$n$	●	●			●	●		●	●				○	○		

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
$S_1$		●				●							
$S_2$		●				●							
$n$		●				●							

Pulse instruction	16-bit instruction	32-bit instruction
AS	AS	-


**Symbol**



- $S_1$  : Data to exchange
- $S_2$  : Data to exchange
- $n$  : Data length



**Explanation**

1. This instruction exchanges the data in  $S_1-S_1+n-1$  with the data in  $S_2-S_2+n-1$ .
2. The value in  $n$  must be between 1–256.



**Example**

When X0.0 is ON, the instruction exchanges the data in D10–D14 with the data in D100–D104.



**Additional remarks**

1. If  $S_1+n-1$  exceeds the device range, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2003.
2. If  $S_2+n-1$  exceeds the device range, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2003.
3. If the value in  $n$  is not between 1–256, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#200B.


API	Instruction code			Operand								Function				
0308	D	SWAP	P	<b>S</b>								Exchanging the high byte with the low byte				

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	“\$”	F
<b>S</b>		●			●	●	●	●			○	○				

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
<b>S</b>		●	●			●	●						

Pulse instruction	16-bit instruction	32-bit instruction
AS	AS	AS

**Symbol**




**S** : Data source

**Explanation**

1. The 16-bit instruction exchanges the data in the low byte in **S** with the data in the high byte in **S**.
2. The 32-bit instruction exchanges the data in the low byte of the high word in **S** with the data in the high byte of the high word in **S**, and exchanges the data in the low byte of the low word in **S** with the data in the high byte of the low word in **S**.
3. Only the 32-bit instructions can use the 32-bit counter, but not the device E.


**Example 1**

When X0.0 is ON, the instruction exchanges the data in the low byte in D0 with the data in the high byte in D0.



**Example 2**

When X0.0 is ON, the instruction exchanges the data in the low byte in D11 with the data in the high byte in D11, and exchanges the data in the low byte in D10 with the data in the high byte in D10.




API	Instruction code			Operand							Function					
0309		SMOV	P	<b>S, m<sub>1</sub>, m<sub>2</sub>, D, n</b>							Transferring digits in blocks					

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	“\$”	F
<b>S</b>	●	●			●	●		●	●				○	○		
<b>m<sub>1</sub></b>	●	●			●	●		●	●				○	○		
<b>m<sub>2</sub></b>	●	●			●	●		●	●				○	○		
<b>D</b>		●			●	●		●								
<b>n</b>	●	●			●	●		●	●				○	○		

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
<b>S</b>		●				●							
<b>m<sub>1</sub></b>		●				●							
<b>m<sub>2</sub></b>		●				●							
<b>D</b>		●				●							
<b>n</b>		●				●							

Pulse instruction	16-bit instruction	32-bit instruction
AS	AS	-


**Symbol**



- S** : Data source
- m<sub>1</sub>** : Start digit to transfer from the source device
- m<sub>2</sub>** : Number of digits to transfer
- D** : Data destination
- n** : Start digit where the source data is stored in the destination device


**Explanation**

1. This instruction allocates and combines data. The instruction transfers **m<sub>2</sub>** digits of the number starting from the **m<sub>1</sub><sup>th</sup>** digit of the number in **S** to the **m<sub>2</sub>** digits of the number starting from the **n<sup>th</sup>** digit of the number in **D**.
2. The value in **m<sub>1</sub>** must be between 1–4. The value in **m<sub>2</sub>** must be between 1–**m<sub>1</sub>**. The value in **n** must be between **m<sub>2</sub>–4** (the instruction treats four bits as a unit.)
3. When SM605 is OFF, the data in **S** are binary-coded decimal numbers.



Suppose the number in **S** is K1234, and the number in **D** is K5678. After the instruction is executed, the number in **S** is 1234, and the number in **D** is 5128.

- When SM605 is ON, the data involved in the instruction is binary numbers.




Suppose the number in **S** is 16#1234, and the number in **D** is 16#5678. After the instruction is executed, the number in **S** is 16#1234, and the number in **D** is 16#5128.

**6**

**Example 1**


- When SM605 is OFF, the data in **S** are binary-coded decimal numbers. When X0.0 is ON, the instruction transfers two digits of the decimal number starting from the fourth digit of the decimal number (the digit in the thousands place of the decimal number) in D10 to the two digits of the decimal number starting from the third digit of the decimal number (the digit in the hundreds place of the decimal number) in D20. After the instruction is executed, the digits in the thousands place of the decimal number ( $10^3$ ) and the ones place of the decimal number ( $10^0$ ) in D20 are unchanged.
- When the binary-code decimal number is not between 0–9,999, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#200D.




Suppose the number in D10 is 1234, and the number in D20 is 5678. After the instruction is executed, the number in D10 is unchanged, and the number in D20 is 5128.

**Example 2**

When SM605 is ON, the data are binary numbers. The SMOV instruction transfers the digit composed of four bits. The instruction does not transform the data into binary-coded decimal numbers.







Suppose the number in D10 is 16#1234, and the number in D20 is 16#5678. After the instruction is executed, the number in D10 is unchanged, and the number in D20 is 16#5128.

**Example 3**

1. You can use the instruction to combine the values of the DIP switches that are connected to the input terminals whose numbers are not consecutive.
2. The two digits of the value of the DIP switch at the right are transferred to the two digits of the number which start from the second digit of the number in D2, and the one digit of the value of the DIP switch at the left is transferred to the first digit of the number in D1.
3. You can use the SMOV instruction to transfer the first digit of the number in D1 to the third digit of the number in D2. In other words, the two DIP switches can be combined into one DIP switch by means of the SMOV instruction.





#### Additional remarks

1. Suppose the data are binary-coded decimal numbers. If the number in **S** is not between 0–9999, or if the number in **D** is not between 0–9999, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#200D.
2. If **m<sub>1</sub>** is less than 1, or if **m<sub>1</sub>** is larger than 4, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#200B.
3. If **m<sub>2</sub>** is less than 1, or if **m<sub>2</sub>** is larger than **m<sub>1</sub>**, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#200B.
4. If **n** is less than **m<sub>2</sub>**, or if **n** is larger than 4, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#200B.


API	Instruction code			Operand							Function					
0310		MOVB	P	S, n, D							Transferring bits in blocks					

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
S	●	●	●	●	●	●	●	●		●						
n	●	●			●	●		●	●		○	○	○	○		
D		●	●	●				●								

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
S	●												
n		●				●							
D	●												

Pulse instruction	16-bit instruction	32-bit instruction
AS	AS	-

**Symbol**




- S** : Data source
- n** : Data length
- D** : Data destination

**Explanation**

1. This instruction transfers **n** pieces of data in devices starting from the device specified by **S** to the devices starting from the device specified by **D**.
2. When **S** is T, C or HC, the instruction transfers only the state of the device, but does not transfer the current value of the device.
3. The value in **n** must be between 1–256. When **n** not between 1–256, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#200B.

**Example**

When X0.0 is ON, the instruction transfers the data in D0.8–D0.13 to D1.2–D1.7.



**Additional remarks**

1. If **D+n-1** exceeds the device range, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2003.
2. If **S+n-1** exceeds the device range, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2003.

## 6.5 Jump Instructions

### 6.5.1 List of Jump Instructions

The following table lists the Jump instructions covered in this section.

API	Instruction code		Pulse instruction	Function
	16-bit	32-bit		
<u>0400</u>	CJ	–	✓	Conditional jump
<u>0401</u>	JMP	–	–	Unconditional jump
<u>0402</u>	GOEND	–	–	Jumping to the end of the program

## 6.5.2 Explanation of Jump Instructions


API	Instruction code			Operand								Function				
0400		CJ	P	<b>S</b>								Conditional jump				

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
<b>S</b>																

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
<b>S</b>													

Pulse instruction	16-bit instruction	32-bit instruction
AS	AS	-

### Symbol



**S** : Jump destination


### Explanation

- This instruction jumps from the current program execution to a label (destination) in a different part of the program in the PLC. You specify the label (pointer) in **S**. You can use the CJ or CJP instruction to shorten the scan time. You can also use the CJ or CJP instruction when using a dual output.
- If the program specified by the jump destination (label) is prior to the CJ instruction, the watchdog timer error occurs, and the PLC stops running the program. Use this instruction carefully.
- You can specify the same label repeatedly with the multiple different CJ instructions.
- When the instruction is executed, the actions of the devices are as described below.
  - The state of Y, the state of M, and the state of **S** remain the same as before the execution of the jump.
  - The timer keeps counting and when it reaches the time setting value, the program drives the output T-coil.
  - For more information on the MC and MCR instructions, refer to Example 2 below.
  - The general applied instructions are not executed.

### Example 1


- When X0.0 is ON, the program execution jumps from NETWORK 1 to LABEL1 (NETWORK 3) and skips NETWORK 2.

2. When X0.0 is OFF, the execution of the program goes from NETWORK 1 to NETWORK 2 to NETWORK 3 in sequence, and the CJ instruction is not executed.



**Example 2**

1. You can use the CJ instruction between the MC and the MCR instructions in the five conditions below.
  - (a) The execution of the program jumps from the part of the program outside one MC/MCR loop to the part of the program outside another MC/MCR loop.
  - (b) The execution of the program jumps from the part of the program outside the MC/MCR loop to the part of the program inside the MC/MCR loop.
  - (c) The execution of the program jumps from the part of the program inside the MC/MCR loop to the part of the program inside the MC/MCR loop.
  - (d) The execution of the program jumps from the part of the program inside the MC/MCR loop to the part of the program outside the MC/MCR loop.
  - (e) The execution of the program jumps from the part of the program inside one the MC/MCR loop to the part of the program inside another the MC/MCR loop.
2. When the PLC executes an MC instruction, it puts the previous state of the switch contact onto the top of the stack inside the PLC. The stack is controlled by the PLC, and cannot be changed. When the PLC executes the MCR instruction, the PLC pops the previous state of the switch contact from the top of the stack. Under the conditions listed in (b), (d), and (e) above, the number of times the items are pushed onto the stack may be different from the number of times the items are popped from the stack. When this situation occurs, at most 32 items can be pushed onto the stack; items can be popped from the stack until the stack is empty. Therefore, when you use CJ or CJP with MC and MCR, be careful of how the program pushes items onto the stack and pops items from the stack.





**Example 3**

The states of the devices are listed below.

Device	State of the contact before the execution of CJ M0=OFF	State of the contact during the execution of CJ M0=ON	State of the output coil during the execution of CJ M0=ON
Y, M, and S	M1, M2, and M3 are OFF.	M1, M2, and M3 switch from OFF to ON.	Y0.1*1, M20, and S1 are OFF.
	M1, M2, and M3 are ON.	M1, M2, and M3 switch from ON to OFF.	Y0.1*1, M20, and S1 are ON.
Timer	M4 is OFF.	M4 switches from OFF to ON.	The timer is not enabled.
	M4 is ON.	M4 switches from ON to OFF	The timer keeps counting and when the timer setting value is reached, it drives the output T-coil.
Accumulative timer	M6 is OFF.	M6 switches from OFF to ON.	ST1 is not enabled.
	M6 is ON.	M6 switches from ON to OFF.	The accumulative timer keeps counting and when the timer setting value is reached, it drives the output T-coil.
Counter	M7 and M10 are OFF.	M10 is ON/OFF.	The counter is not enabled.
	M7 is OFF. M10 is ON/OFF.	M10 is ON/OFF.	C0 stops counting. When M0 switches OFF, C0 keeps counting.
Applied instruction	M11 is OFF.	M11 switches from OFF to ON	The applied instruction is not executed.
	M11 is ON.	M11 switches from ON to OFF	The applied instruction is skipped (not executed).

\*1:Y0.1 is a dual output. When M0 is OFF, Y0.1 is controlled by M1. When M0 is ON, Y0.1 is controlled by M12.





**Additional remarks**

6

Refer to the ISPSOft User Manual for more information on the use of labels (pointers) with Jump instructions.


API	Instruction code			Operand							Function						
0401		JMP		<b>S</b>							Unconditional jump						

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
<b>S</b>																

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
<b>S</b>													

Pulse instruction	16-bit instruction	32-bit instruction
-	AS	-

**Symbol**



**S** : Jump destination

**Explanation**

1. This instruction causes the execution of the program to jump to the part of the program specified by the label in **S** (pointer) without any condition.
2. If the program specified by the label is prior to the instruction JMP, the watchdog timer error occurs, and the PLC stops running the program. Use this instruction carefully.
3. Refer to the CJ instruction (API 400) for more information on the states of devices while executing this instruction.
4. Refer to the ISPSOft User Manual for more information on the use of labels (pointers) with Jump instructions.

API	Instruction code		Operand	Function
0402		GOEND	—	Jumping to END

Pulse instruction	16-bit instruction	32-bit instruction
-	AS	-

**Symbol**



**Explanation**

1. This instruction causes program execution to jump to END in the program.
2. Function blocks and interrupt tasks do not support the GOEND instruction. You cannot use the instruction between the FOR instruction and the NEXT instruction.
3. When the PLC executes the GOEND instruction, the instructions skipped are not executed, the data in all devices is unchanged, and the states of all devices are also unchanged.

## 6.6 Program Execution Instructions

### 6.6.1 List of Program Execution Instructions

The following table lists the Program Execution instructions covered in this section.


API	Instruction code		Pulse instruction	Function
	16-bit	32-bit		
<b><u>0500</u></b>	DI	–	–	Disabling the interrupt function
<b><u>0501</u></b>	EI	–	–	Enabling the interrupt function
<b><u>0503</u></b>	EIX	–	–	Disabling a specific interrupt
<b><u>0504</u></b>	DIX	–	–	Enabling a specific interrupt

## 6.6.2 Explanation of Program Execution Instructions

API	Instruction code	Operand	Function
0500	DI	-	Disabling the interrupt function

Pulse instruction	16-bit instruction	32-bit instruction
-	AS	-

### Symbol



### Explanation

Refer to the EI instruction (API 0501) for more information.

API	Instruction code		Operand	Function
0501		EI	-	Enabling the interrupt function

Pulse instruction	16-bit instruction	32-bit instruction
-	AS	-

**Symbol**




**Explanation**

1. Use the EI instruction to enable interrupt tasks in a program (refer to next page for more information on tasks).
2. You can use the interrupt task between the EI instruction and the DI instruction in a program. You can choose not to use the DI instruction when there is no part of the program in which the interrupt is disabled.
3. During the execution of one interrupt task, a new interrupt generated is not executed, but is stored. After the execution of the present interrupt task is complete, the next interrupt task is executed. For example, during the execution of I0 (by triggered order #1), 2 new I0s (by triggered order #2, by triggered order #3) are generated, only by triggered order #2 I0 will be stored for later execution. by triggered order #3 IO is not stored for execution.
4. When several interrupts occur, the interrupt task with the highest priority is executed first. When several interrupts occur simultaneously, the interrupt task with the smallest pointer number is executed first.
5. When the interrupt task occurs between DI and EI, it cannot be executed, and the interrupt request is ignored. It is suggested that you not use the instruction DI to disable interrupts while PLC is running.
6. When the immediate I/O signal is required in the execution of the interrupt task, you can use the REF instruction or the device DX/DY in the program to refresh the state of the I/O.
7. Every interrupt number has a temporary function that can be masked. See below for the list of interrupt numbers.

**Example:**

- ◆ Set up the timed I601 interrupt task to 500ms in HWCONFIG in ISPSOft.
- ◆ When the PLC runs the program Cyclic\_0, it scans the EI instruction, enables interrupt tasks, and then executes the I601 interrupt task. When the interrupt task execution is complete, the main program is executed.
- ◆ When M0 is ON, the I601 timer interrupt task is disabled.
- ◆ When M1 is ON, the I601 timer interrupt task is enabled.
- ◆ When M2 is ON, the SR632 is 0 and the I601 timer interrupt task is disabled.
- ◆ When M3 is ON, the SR632 is 1 and the I601 timer interrupt task is enabled.


The program Cyclic\_0:



The interrupt task:



Timer interrupts in a diagram:



### Additional remarks

There are 7 types of interrupt tasks:

#### 1. External interrupts (I000–I115)

I000 specifies that the input X0.0 is falling edge triggered.

I100 specifies that the input X0.0 is rising edge triggered.

I001 specifies that the input X0.1 is falling edge triggered.

I101 specifies that the input X0.1 is rising edge triggered.

The rest can be done in the same manner.

#### 2. Hardware high-speed comparison interrupts (I200–I253)

This type of interrupts can be further divided into 6 groups. Each group corresponds to a hardware high-speed counter (refer to the DCNT instruction API 1003 for more information). Each group has with 4 interrupt numbers (refer to the DHSCS instruction API 1005 for more information). For example, the interrupt numbers for the first group are I200–I203, and for the second group are I210–I213.

#### 3. Software high-speed comparison interrupts (I260–I267)

There are 8 interrupts for software high-speed comparisons and these 8 interrupts are shared with 8 high-speed counters.

#### 4. Communication interrupts

You can use the communication interrupt as the RS instruction; that is, receiving a specific character triggers the interrupt, or you can use it as a general interrupt. Refer to the COMRS instruction (API1812) for more information.

COM1: I300

COM2: I302

Card 1: I304

Card 2: I306

5. Extension module interrupts (I400–I431)

Each module has one interrupt. You can set up 1 interrupt service for each extension module.

6. High-speed output interrupts (I500–I519)

When the pulse output is complete, the interrupt request is sent. The interrupts (I500–I505) for the completing the execution of the positioning instruction work with special devices (SM) to activate the interrupt service. For example, when the DDRVI instruction completes the execution of the first axis, the interrupt request I500 is sent; you can set SM471 to ON to activate the interrupt service. The interrupts (I510–I519) for the completing the execution of the position planning table instruction work with the TPO instruction. When the pulse output is complete, the interrupt request is sent.

7. Timer interrupts (I601–I604)

Set the timer interrupts set in HWCONFIG.

For the timer interrupts I601–I603: The default value is 10 milliseconds (unit: 1ms) (1–2000 milliseconds).

For the timer interrupts I604: The default value is 1 milliseconds (unit: 0.1ms) (0.1–200 milliseconds).

The complete list of interrupt numbers, descriptions and the mask-able interrupts (SR) are listed in the following table.

Interrupt number	Description	Mask-able interrupts SR	Bit No.
I000	External interrupt: input X0.0 is falling edge triggered.	SR623	0
I001	External interrupt: input X0.1 is falling edge triggered.		1
I002	External interrupt: input X0.2 is falling edge triggered.		2
I003	External interrupt: input X0.3 is falling edge triggered.		3
I004	External interrupt: input X0.4 is falling edge triggered.		4
I005	External interrupt: input X0.5 is falling edge triggered.		5
I006	External interrupt: input X0.6 is falling edge triggered.		6
I007	External interrupt: input X0.7 is falling edge triggered.		7
I008	External interrupt: input X0.8 is falling edge triggered.		8

Interrupt number	Description	Mask-able interrupts SR	Bit No.
I009	External interrupt: input X0.9 is falling edge triggered.		9
I010	External interrupt: input X0.10 is falling edge triggered.		10
I011	External interrupt: input X0.11 is falling edge triggered.		11
I012	External interrupt: input X0.12 is falling edge triggered.		12
I013	External interrupt: input X0.13 is falling edge triggered.		13
I014	External interrupt: input X0.14 is falling edge triggered.		14
I015	External interrupt: input X0.15 is falling edge triggered.		15
I100	External interrupt: input X0.0 is rising-edge triggered.	SR624	0
I101	External interrupt: input X0.1 is rising-edge triggered.		1
I102	External interrupt: input X0.2 is rising-edge triggered.		2
I103	External interrupt: input X0.3 is rising-edge triggered.		3
I104	External interrupt: input X0.4 is rising-edge triggered.		4
I105	External interrupt: input X0.5 is rising-edge triggered.		5
I106	External interrupt: input X0.6 is rising-edge triggered.		6
I107	External interrupt: input X0.7 is rising-edge triggered.		7
I108	External interrupt: input X0.8 is rising-edge triggered.		8
I109	External interrupt: input X0.9 is rising-edge triggered.		9
I110	External interrupt: input X0.10 is rising-edge triggered.		10
I111	External interrupt: input X0.11 is rising-edge triggered.		11
I112	External interrupt: input X0.12 is rising-edge triggered.		12
I113	External interrupt: input X0.13 is rising-edge triggered.		13
I114	External interrupt: input X0.14 is rising-edge triggered.		14
I115	External interrupt: input X0.15 is rising-edge triggered.	15	
I200	High-speed comparison interrupt 1 for the hardware high-speed counter 1	SR625	0
I201	High-speed comparison interrupt 2 for the hardware high-speed counter 1		1
I202	High-speed comparison interrupt 3 for the hardware high-speed counter 1		2
I203	High-speed comparison interrupt 4 for the hardware high-speed counter 1		3

Interrupt number	Description	Mask-able interrupts SR	Bit No.	
I210	High-speed comparison interrupt 1 for the hardware high-speed counter 2		4	
I211	High-speed comparison interrupt 2 for the hardware high-speed counter 2		5	
I212	High-speed comparison interrupt 3 for the hardware high-speed counter 2		6	
I213	High-speed comparison interrupt 4 for the hardware high-speed counter 2		7	
I220	High-speed comparison interrupt 1 for the hardware high-speed counter 3		8	
I221	High-speed comparison interrupt 2 for the hardware high-speed counter 3		9	
I222	High-speed comparison interrupt 3 for the hardware high-speed counter 3		10	
I223	High-speed comparison interrupt 4 for the hardware high-speed counter 3		11	
I230	High-speed comparison interrupt 1 for the hardware high-speed counter 4		12	
I231	High-speed comparison interrupt 2 for the hardware high-speed counter 4		13	
I232	High-speed comparison interrupt 3 for the hardware high-speed counter 4		14	
I233	High-speed comparison interrupt 4 for the hardware high-speed counter 4		15	
I240	High-speed comparison interrupt 1 for the hardware high-speed counter 5		SR626	0
I241	High-speed comparison interrupt 2 for the hardware high-speed counter 5			1
I242	High-speed comparison interrupt 3 for the hardware high-speed counter 5			2
I243	High-speed comparison interrupt 4 for the hardware high-speed counter 5	3		

Interrupt number	Description	Mask-able interrupts SR	Bit No.
I250	High-speed comparison interrupt 1 for the hardware high-speed counter 6		4
I251	High-speed comparison interrupt 2 for the hardware high-speed counter 6		5
I252	High-speed comparison interrupt 3 for the hardware high-speed counter 6		6
I253	High-speed comparison interrupt 4 for the hardware high-speed counter 6		7
I260	High-speed comparison interrupt 1 for the software high-speed counter	SR627	0
I261	High-speed comparison interrupt 2 for the software high-speed counter		1
I262	High-speed comparison interrupt 3 for the software high-speed counter		2
I263	High-speed comparison interrupt 4 for the software high-speed counter		3
I264	High-speed comparison interrupt 5 for the software high-speed counter		4
I265	High-speed comparison interrupt 6 for the software high-speed counter		5
I266	High-speed comparison interrupt 7 for the software high-speed counter		6
I267	High-speed comparison interrupt 8 for the software high-speed counter		7
I300	Receiving a specific word triggers communication interruption in COM1	SR628	0
I301	Reserved		1
I302	Receiving a specific word triggers communication interruption in COM1		2
I303	Reserved		3
I304	Receiving a specific word triggers communication interruption in function card 1		4
I305	Reserved		5

Interrupt number	Description	Mask-able interrupts SR	Bit No.
I306	Receiving a specific word triggers communication interruption in function card 2		6
I307	Reserved		7
I500	High-speed output interrupt: the 1st axis positioning instruction completes	SR629	0
I501	High-speed output interrupt: the 2nd axis positioning instruction completes		1
I502	High-speed output interrupt: the 3rd axis positioning instruction completes		2
I503	High-speed output interrupt: the 4th axis positioning instruction completes		3
I504	High-speed output interrupt: the 5th axis positioning instruction completes		4
I505	High-speed output interrupt: the 6th axis positioning instruction completes		5
I510	High-speed output interrupt 1: the position planning table instruction completes		SR630
I511	High-speed output interrupt 2: the position planning table instruction completes	1	
I512	High-speed output interrupt 3: the position planning table instruction completes	2	
I513	High-speed output interrupt 4: the position planning table instruction completes	3	
I514	High-speed output interrupt 5: the position planning table instruction completes	4	
I515	High-speed output interrupt 6: the position planning table instruction completes	5	
I516	High-speed output interrupt 7: the position planning table instruction completes	6	
I517	High-speed output interrupt 8: the position planning table instruction completes	7	
I518	High-speed output interrupt 9: the position planning table instruction completes	8	

Interrupt number	Description	Mask-able interrupts SR	Bit No.
I519	High-speed output interrupt 10: the position planning table instruction completes		9
I601	Timer interrupts 1 (unit 1ms)	SR632	0
I602	Timer interrupts 1 (unit 1ms)		1
I603	Timer interrupts 1 (unit 1ms)		2
I604	Timer interrupts 1 (unit 0.1ms)		3

Note: When several interrupts occur simultaneously, the interrupt task whose pointer number is smallest is executed first. The PLC completes the on-going interrupt, and then execute other interrupts according to their pointer numbers. For example, during the execution of I400 interrupt, if I500 and I300 occur simultaneously, the PLC executes the I300 interrupt (smaller pointer number) after executing the I400 interrupt.


API	Instruction code			Operand							Function						
0503		EIX		<b>S</b>							Enabling a specific interrupt						

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
<b>S</b>													○			

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
<b>S</b>													

Pulse instruction	16-bit instruction	32-bit instruction
-	AS	-

**Symbol**



**S** : Data source

**Explanation**

1. The data source **S** can only contain a decimal number, and the number must be an interrupt number. If the number is not an interrupt number, the instruction is not executed and no warning is shown. For example, use EIX500 in **S** when you want to enable the I500 interrupt. Refer to the interrupt number list in the explanation of the EI instruction.
2. The default for interrupt tasks in the AS Series is enabled. If you use the DIX instruction to disable the interrupts, you must use the EIX instruction to enable the interrupts.
3. You can use this instruction to enable the interrupt tasks in SR623–SR634.
4. If this instruction is not executed, then the contents of SR623–SR634 determine whether an interrupt task is performed or not.
5. Refer to the examples for the EI instruction (API 0501) for more information.


API	Instruction code			Operand							Function						
0504		DIX		<b>S</b>							Disabling a specific interrupt						

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	“\$”	F
<b>S</b>													○			

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
<b>S</b>													

Pulse instruction	16-bit instruction	32-bit instruction
-	AS	-

**Symbol**



**S** : Data source

**Explanation**

1. The data source **S** can contain only decimal numbers, and the number must be an interrupt number. If the number in **S** is not an interrupt number, the instruction is not executed and no warning is shown. For example, use DIX500 when you want to disable the I500 interrupt. Refer to the interrupt number list in the explanation of the EI instruction.
2. The default for interrupt tasks in the AS Series is enabled. Use the DIX instruction to disable the interrupts.
3. You can use this instruction to disable the interrupt tasks in SR623–SR634.
4. If this instruction is not executed, then the contents of SR623–SR634 determine whether an interrupt task is performed or not.
5. Refer to the examples for the EI instruction (API 0501) for more information.

## 6.7 I/O Refreshing Instructions

### 6.7.1 I/O List of I/O Refreshing Instructions

The following table lists the I/O Refreshing instructions covered in this section.

API	Instruction code		Pulse instruction	Function
	16-bit	32-bit		
<b><u>0600</u></b>	REF	–	✓	Refreshing the I/O
<b><u>0601</u></b>	–	DHSRF	✓	Immediate refresh of a high-speed comparative value
<b><u>0602</u></b>	REFF	–	✓	Refreshing the I/O filtering time

### 6.7.2 Explanation of I/O Refreshing Instructions

API	Instruction code			Operand								Function				
0600		REF	P	D, n								Refreshing the I/O				

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	“\$”	F
D	○	○														
n								●	●		○	○	○	○		

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
D	●												
n		●				●							

Pulse instruction	16-bit instruction	32-bit instruction
AS	AS	-

#### Symbol

REF	REFP
En	En
D	D
n	n

**D** : I/O point state to refresh

**n** : Number of I/O points states to refresh

#### Explanation

- The I/O states are normally not refreshed until the PLC executes the END instruction. When the PLC starts scanning the program, it reads and stores the states of the external inputs in memory. After executing the END instruction, the PLC sends the states of the outputs in the memory to the output terminals. Therefore, when you need the latest I/O data during the operation process, you can use this instruction, or use the device DX/DY to refresh the input/output.
- The operand **n** must be multiples of eight, such as 8, 16, 24 and up to 256. If the value here is less than a multiple of eight, it will be seen as the next multiple of eight. For example, the value 20 will be seen as its next multiple of eight, 24.
- The number of the high-speed output point is stored in D device for firmware version 1.04.00 and later. If **n** is 1, it indicates to refresh the high-speed output value of the corresponding SR immediately. If **n** is 0, it indicates to stop high-speed output and refresh the SR current value. For example, during the execution of this instruction, if **n** is 0 and the external interrupt input is received through X0.0, it indicates an external interrupt occurs in X0.0 and high-speed outputting through Y0.0 should be stopped immediately. The PLC sets the stop flag SM463 to ON and refresh the current corresponding output position in SR. Note: if the output completion auto-reset flag is set to ON,

the PLC sets the output completion auto-reset flag to OFF and refresh the current corresponding output position in SR. But the PLC does not set the stop flag SM463 to ON.

Value in n	D device	Action Descriptions
n = multiples of eight	Y0.0 or X0.0	Refresh I/O immediately See Example 1 and 2
n = 1*1	High-speed output point	Refresh new pulse position See Example 3
n = 0*1	High-speed output point Without output completion auto-reset flag	Stop high-speed outputting, set the stop flag SM463 to ON and refresh the current corresponding output position. See Example 3
n = 0*1	High-speed output point With output completion auto-reset flag	Set the output completion auto-reset flag to OFF and refresh the current corresponding output position. See Example 3.
n = -1*2	Any input points (X points)	Update the mapped area DS301 TxPDO (Master <= Slave)
n = -1*2	Any output points (Y points)	Update the mapped area DS301 RxPDO (Master => Slave)
n = -2*3	Any input points (X points)	Respond to the received Modbus TCP communication command (PLC acts as Server)

\*1: This function is only available for PLC CPU with firmware V1.04.00 or later.


\*2: For PLC CPU to act as Master, its firmware should be V1.06.40 or later. For PLC CPU to act as Slave, its firmware should be V1.12 or later. This function is not intended to speed up the PDO data mapping time and it is suggested to use this function when the PLC scan time is longer than the PDO refreshing time of DS301.

6

\*3: This function is only available for PCL CPU with firmware V1.10.30 or later. It is especially helpful when the PLC scan time is too long. You can use this function along with a time interrupt to respond the request sent through Modbus TCP communication at a set time to have the communication between the upper device and PLC CPU started sooner. The recommended set time is 5 ms. If the time set for the PLC CPU to react is set too short, the PLC scan time will be increased dramatically. Since the respond to Modbus TCP communication request is to process the request that means during a PLC program scan time more tasks will be added, including reading or writing.


**Example 1**

1. When X0.0 is ON, the PLC reads the states of the inputs X0.0–X0.15 immediately, and refreshes the input signals without any delay.



**Example 2**

When X0.0 is ON, the output signals from Y0.0–Y0.7 are sent to the output terminals. The output signals are refreshed immediately without waiting for the END instruction to be executed.

**Additional remarks**


1. If  $D+n-1$  exceeds the device range, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2003.

**Example 3**

1. During the execution of this instruction, if the external interrupt input is received through X0.0

Value in n	D device	Action Descriptions
n = 1	High-speed output point Y0.0	Refresh new pulse position Y0.0 immediately (SR460)
n = 0	High-speed output point Y0.2 Without output completion auto-reset flag	<ol style="list-style-type: none"> <li>1. Stop high-speed outputting</li> <li>2. Set the stop flag SM483 to ON</li> <li>3. Refresh the current corresponding output position SR480</li> </ol>
n = 0	High-speed output point Y0.4 With output completion auto-reset flag SM510	<ol style="list-style-type: none"> <li>1. Set the output completion auto-reset flag SM510 to OFF</li> <li>2. Refresh the current corresponding output position. SR500</li> </ol>

X0.0 external interrupt program:



API	Instruction			Operand				Description
0601	D	HSRF	P	<b>S, S<sub>1</sub></b>				Immediate refresh of a high-speed comparative value

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	“\$”	F
<b>S</b>							○									
<b>S<sub>1</sub></b>								○								

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
<b>S</b>												●	
<b>S<sub>1</sub></b>			●				●						

Pulse Instruction	16-bit instruction	32-bit instruction
AS	—	AS

### Symbol

DHSRF	DHSRFP
En	En
S	S
S <sub>1</sub>	S <sub>1</sub>

**S** : High-speed counter to be refreshed

**S<sub>1</sub>** : Quantity of I/O to be updated


### Explanation

- The timing for the PLC to update the comparative value in its comparator is when the DHSCS or DHSCR instruction is scanned by a program successfully. However, the refresh may fail if the scan time is too long or the input signal comes too fast. In this event, users can use the instruction to assign the new comparative value to the hardware comparator in the PLC and achieve the real-time comparison.
- S** is the No of the specified high-speed counter to be refreshed. **S<sub>1</sub>** has the same component or variable name as that in the DHSCS or DHSCR instruction and the immediate value can not be set for **S<sub>1</sub>**. If **S<sub>1</sub>** does not have the same operand as that in the high-speed comparison instruction which has been enabled, the instruction execution will not take effect.
- Only the firmware of V1.04.00 and later supports the instruction.

**Example**


1. As PLC runs, the comparative value in DHSCS instruction is 5000.
2. When the X0.0 external interrupt occurs, the comparative value in DHSCS is set to 8000 immediately.

Main program:



X0.0 external interrupt program:

Assign the new comparative value to the same variable (E.g. D10 in the example) first and then execute DHSRF instruction for the update.



API	Instruction code			Operand								Function			
0602		REFF	P	<b>Xno, Length, Filter</b>								Refreshing the I/O filtering time			

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	“\$”	F
<b>Xno</b>	○															
<b>Length</b>					●	●		●	●				○	○		
<b>Filter</b>					●	●		●	●				○	○		

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
<b>Xno</b>	●												
<b>Length</b>		●				●							
<b>Filter</b>		●				●							

Pulse instruction	16-bit instruction	32-bit instruction
AS	AS	-

**Symbol**

REFF	REFFP
En	En
Xno	Xno
Length	Length
Filter	Filter

**Xno** : The starting device number of X to refresh

**n** : Number of I/O points states to refresh

**Filter** : Filtering time to refresh (unit: μs)

**Explanation**

- This instruction works only with AS series (FWV1.06.00) and ISPSOft V3.06 or later versions.
- Xno** is the starting input number to refresh. **Length** is the length to refresh. If the X point is the built-in input point of a CPU, when **Xno** is X0.3, the value of **Length** is 3, after executing the REFF instruction, the input filtering time of X0.3 ~ X0.5 are refreshed.  
Since X input point of the extension module is grouping in 8 for a unit, when **Xno** is X1.9 and the value of **Length** is 3, after executing the REFF instruction, the input filtering time of X1.8 ~ X1.15 are refreshed. When **Xno** is 1.3, and the value of **Length** is 3, after executing the REFF instruction, the input filtering time of X1.0 ~ X1.7 are refreshed. When **Xno** is X1.3 and the value of **Length** is 9, the input filtering time of X1.0 ~ X1.15 are refreshed.
- Xno** and **Length** should be set in the input of PLC input system. If the setting exceeds the range, even if you have executed REFF instruction, the I/O will NOT be refreshed and error message will NOT be shown.
- If the X point is the built-in input point of a CPU, the filtering time unit is μs. While if the X point is the input point of

the extension module, the filtering time unit is ms. This instruction is for refreshing the current filtering time; filtering time set in HWCONFIG will NOT be affected. But when the value of **Filter** in the instruction exceeds the setting range in HWCONFIG, PLC treats the value of **Filter** as the maximum or the minimum value set in HWCONFIG.

5. When power-on, the filtering time of the CPU and the extension module is refreshed according to the filtering time set in HWCONFIG.
6. The REFF instruction refreshes the filtering time only at its first execution.

## 6.8 Miscellaneous Instructions

### 6.8.1 List of Miscellaneous Instructions

The following table lists the miscellaneous instructions covered in this section.

API	Instruction code		Pulse instruction	Function
	16-Bit	32-Bit		
<b><u>0700</u></b>	ALT	–	✓	Alternating between ON and OFF
<b><u>0701</u></b>	TTMR	–	–	Teach mode timer
<b><u>0702</u></b>	STMR	–	–	Special timer
<b><u>0703</u></b>	RAMP	DRAMP	–	Cyclic ramp signal
<b><u>0704</u></b>	MTR	–	–	Matrix input
<b><u>0705</u></b>	ABSD	DABSD	–	Absolute drum sequencer
<b><u>0706</u></b>	INCD	–	–	Incremental drum sequencer
<b><u>0708</u></b>	–	DPIDE	–	PID algorithm
<b><u>0709</u></b>	XCMP	–	–	Setting up to compare the inputs of multiple work stations
<b><u>0710</u></b>	YOUT	–	–	Comparing the outputs of multiple work stations
<b><u>0711</u></b>	–	DSUNRS	✓	Sunrise and sunset times

### 6.8.2 Explanation of Miscellaneous Instructions


API	Instruction code			Operand								Function				
0700		ALT	P	D								Alternating between ON and OFF				

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
D	●	●	●	●				●		○						

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
D	●												

Pulse instruction	16-Bit instruction	32-Bit instruction
AS	AS	-

**Symbol**




**D** : Destination device

**Explanation**

1. This instruction alternates the state of the device specified by **D** between ON and OFF.
2. In general, use the ALTP pulse instruction.


**Example 1**

When X0.0 switches from OFF to ON for the first time, Y0.0 is ON. When X0.0 switches from OFF to ON for the second time, Y0.0 is OFF.




**Example 2**

In the beginning, M0 is OFF; therefore, Y0.0 is ON, and Y0.1 is OFF. When X0.0 switches from OFF to ON for the first time, M0 is ON; therefore, Y0.0 is OFF, and Y0.1 is ON. When X0.0 switches from OFF to ON for the second time, M0 is OFF; therefore, Y0.0 is ON, and Y0.1 is OFF.

**Example 3**

When X0.0 is ON, T0 generates a pulse every two seconds. The output Y0.0 alternates between ON and OFF according to the pulses generated by T0.




API	Instruction code			Operand						Function					
0701		TTMR		<b>D, n</b>						Teach mode timer					

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	“\$”	F
<b>D</b>		●						●			○					
<b>n</b>	●	●						●	●		○		○	○		

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
<b>D</b>		●				●							
<b>n</b>		●				●							

Pulse instruction	16-Bit instruction	32-Bit instruction
-	AS	-

Symbol



**D** : Recorded time

**n** : Multiplier

Explanation


1. This instruction uses seconds as the unit of time. The time for which a button switch has been turned ON is multiplied by **n**, and the product is stored in **D**. **D+1** is for system use only. When the instruction is executed, the value in **D+1** cannot be altered. Otherwise, the time is counted incorrectly.
2. When the conditional contact is ON, **D** is reset to 0.
3. Setting the multiplier: when **n** is 0, **D** uses a second as the timing unit. When **n** is 1, the time for which the button switch has been turned ON is multiplied by 10, and **D** uses 100 milliseconds as the timing unit. When **n** is 2, the time for which the button switch has been turned ON is multiplied by 100, and **D** uses 10 milliseconds as the timing unit. The greater the value in **n**, the higher the timing resolution.

<b>n</b>	<b>D</b>
K0 (unit: 1 second)	1×T
K1 (unit: 100 milliseconds)	10×T
K2 (unit: 10 milliseconds)	100×T

4. When you use on-line editing, reset the conditional contact to initialize the instruction.
5. The value in **n** must be between 0–2.

**Example 1**

1. The instruction multiplies the time for which the button switch X0.0 has been turned ON by n, and stores the product in D0. You can use the button switch (ON) to record the time.
2. When X0.0 is switched OFF, the value in D0 is unchanged.

**Additional remarks**

1. If **D+1** exceeds the device range, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2003.
2. If the value in **n** is not between 0–2, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#200B.
3. If you declare the operand **D** in ISPSOft, the data type is ARRAY [2] of WORD/INT.


API	Instruction code			Operand							Function					
0702		STMR		S, m, D							Special timer					

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
S					○											
m	●	●						●	●		○		○	○		
D		●	●	●				●		○						

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
S											●		
m		●				●							
D	●												

Pulse instruction	16-Bit instruction	32-Bit instruction
-	AS	-

Symbol




- S** : Timer number (T0-T511)
- m** : Setting value of the timer
- D** : Output device

Explanation


1. This instruction generates timing for the off-delay relay, the one-shot circuit, and the flashing circuit.
2. This instruction uses 100 milliseconds as the timing unit. If the setting value for **m** is 50, the time value is 5 seconds.
3. You cannot use this timer repeatedly.
4. **D** occupies four consecutive devices.
5. Before the instruction is executed, reset **D-D+3**.
6. When the conditional contact is not enabled and the value of the device meets one of the two conditions mentioned below, **D**, **D+1**, and **D+3** are ON for **m** seconds before they are switched OFF. When the conditional contact is not enabled and the value of the device does not meet either of the two conditions mentioned below, **D-D+3** keep OFF.
  - The value of the timer is less than or equal to **m**, **D** is ON, and **D+1** is OFF.
  - The value of the timer is less than **m**, **D +2** is OFF, and **D**, **D+1**, and **D+3** are ON.
7. When the on-line editing is used, Reset the conditional contact to initialize the instruction.
8. The value in **m** must be between 1–32767.

**Example**

- 1. When X0.0 is ON, the instruction specifies the timer T0, and the setting value of T0 is five seconds.
- 2. Y0.0 is the off-delay contact. When X0.0 switches to ON, Y0.0 is ON. Five seconds after X0.0 switches to OFF, Y0.0 is OFF.
- 3. When X0.0 switches to OFF, Y0.0 is ON for five seconds.
- 4. When X0.0 switches ON, Y0.2 is ON for five seconds.
- 5. Five seconds after X0.0 switches to ON, Y0.3 is ON. Five seconds after X0.0 switches to OFF, Y0.3 is OFF.



- 6. When the conditional contact X0.0 is followed by the b contact Y0.3, the flasher circuit passes through Y0.1 and Y0.2. When X0.0 is switched OFF, Y0.0, Y0.1, and Y0.3 are switched OFF, and T0 is reset to 0.



**Additional remarks**

1. If **D**+3 exceeds the device range, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2003.
2. If the value in **m** is less than 0, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#200B.
3. If you declare the operand **D** in ISPSOft, the data type is ARRAY [4] of BOOL.


API	Instruction code			Operand						Function					
0703	D	RAMP		<b>S<sub>1</sub>, S<sub>2</sub>, D, n</b>						Cyclic ramp signal					

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
S <sub>1</sub>	●	●					●	●	●		○	○	○	○		
S <sub>2</sub>	●	●					●	●	●		○	○	○	○		
D		●					●	●								
n	●	●					●	●	●		○	○	○	○		

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
S <sub>1</sub>		●	●			●	●						
S <sub>2</sub>		●	●			●	●						
D		●	●			●	●						
n		●	●			●	●						

Pulse instruction	16-Bit instruction	32-Bit instruction
-	AS	AS

**Symbol**



- S<sub>1</sub> : Initial value of the ramp signal
- S<sub>2</sub> : Final value of the ramp signal
- D : Duration of the ramp signal
- n : Number of scan cycles

**Explanation**



1. This instruction gets the linear slope, which has an absolute relationship with the scan time. Therefore it is suggested that you set a fixed scan time or write this instruction in a timer interrupt task.
2. You write the initial value and final value of the ramp signal into S<sub>1</sub> and S<sub>2</sub> respectively in advance. When X0.0 is ON, D increases from the setting value in S<sub>1</sub> to the setting value in S<sub>2</sub>. The number of scan cycles is stored in D+1. When the value in D is equal to that in S<sub>2</sub>, or when the value in D+1 is equal to n (to the number of scan cycles), then SM687 is ON.
3. When the conditional contact is not enabled, the value in D, and D+1 are both 0, and SM687 is OFF.
4. When using on-line editing, Reset the conditional contact to initialize the instruction.
5. Refer to the ISPSOft User Manual for more information on setting a fixed scan time.
6. The value of n must be between 1–32767. When n is out of range, this instruction is not executed.

7. Only the 32-bit instructions can use the 32-bit counter, but not the device **E**.
8. Use the SM686 flag to reset the value in **D** to 0. Refer to the examples below for details.


**Example**

When you use the instruction with an analog signal output, it acts to cushion the starting and stopping of the machinery.

1. During execution, when X0.0 switches to OFF, the execution of the instruction stops. When X0.0 switches to ON again, SM687 is OFF, D12 is reset to the setting value in D10, D13 is reset to 0, and the ramp calculation is restarted.
2. During execution, SM686 is OFF, and when D12 reaches the setting value in D11, SM687 switches to ON as a scan cycle. When D12 resets to the setting value in D10, D13 resets to 0.



3. When SM686 is ON, and D12 reaches the setting value in D11, the value in D12 is not reset to 0, and SM687 is ON. As long as the conditional contact is closed (ON), the value in D12 resets to 0 and SM687 is OFF. When SM686 is ON or OFF, the value in D12 changes as shown below.



#### Additional remarks

1. If  $D+1$  exceeds the device range, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2003.
2. If  $n$  is less than 0, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#200B.
3. For the 16-bit instruction, if you declare the operand **D** in ISPSOft, the data type is ARRAY [2] of WORD/INT.
4. For the 32-Bit instruction, if you declare the operand **D** in ISPSOft, the data type is ARRAY [2] of DWORD/DINT.


API	Instruction code			Operand								Function				
0704		MTR		<b>S, D<sub>1</sub>, D<sub>2</sub>, n</b>								Matrix input				

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	“\$”	F
<b>S</b>	○															
<b>D<sub>1</sub></b>		○														
<b>D<sub>2</sub></b>		○	○	○				○								
<b>n</b>	●	●						●	●		○	○	○	○		

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
<b>S</b>	●												
<b>D<sub>1</sub></b>	●												
<b>D<sub>2</sub></b>	●												
<b>n</b>		●				●							

Pulse instruction	16-Bit instruction	32-Bit instruction
-	AS	-

**Symbol**



- S** : First input device in the matrix scan
- D<sub>1</sub>** : First output device in the matrix scan
- D<sub>2</sub>** : First corresponding device in the matrix scan
- n** : Number of rows to scan

**Explanation**


1. This instruction scans and stores the states of eight sequential input devices. **S** specifies the first input device in the matrix scan.
2. **D<sub>1</sub>** specifies the transistor output device Y as the first device in the matrix scan. When the conditional contact is OFF, the states of the **n** devices starting from **D<sub>1</sub>** are OFF.
3. One row of inputs is refreshed every scan cycle. There are 16 inputs in a row, and the scan starts from the first row and goes to the **n<sup>th</sup>** row.
4. The eight input devices starting from the device specified by **S** are connected to the **n** output devices starting from the device specified by **D<sub>1</sub>** to form the **n** rows of switches. The matrix scan reads the states of the **n** rows of switches, and stores the states in the devices starting from the device specified by **D<sub>2</sub>**.
5. You can connect up to 8 rows of input switches in parallel to get 64 inputs (8x8=64).
6. The interval between executions of this instruction should be longer than the time it takes for the states of the I/O points on the module to be refreshed. Otherwise, the instruction cannot read the correct states of the inputs. See

Additional remarks, below.


7. In general, the conditional contact used in the instruction is SM400: the flag is always ON when CPU runs.
8. The value in **n** must be between 2–8.

### Example 1


1. When M0 is ON, the MTR instruction is executed. The instruction reads the states of the two rows of switches in order, and stores them in the internal relays M10–M17 and M20–M27 respectively.



2. The diagram below is the external wiring diagram of the 2-by-8 matrix input circuit for X0.0–X0.7 and Y0.0–Y0.1. The corresponding internal relays of the 16 switches are M10–M17 and M20–M27.



3. The instruction connects eight input devices starting from X0.0 to the two output devices starting from Y0.0 to form the two rows of switches. The matrix scan reads the states of the two rows of switches, and stores the states in the devices starting from M10 (specified by **D<sub>2</sub>**). That is, it stores the states of the first row of switches in M10–M17, and stores the states of the second row of switches in M20–M27.



#### Additional remarks

1. When this instruction is executed, a cycle time that is too long or a too short causes the state of the switches to be read incorrectly. Use the following tips to solve this issue.
  - When the scan cycle is too short, the I/O may not be able to respond in time and the correct states of the inputs cannot be read. You can set a fixed scan time to solve this issue.
  - When the scan cycle is too long, the switch may be slow to react. You can write this instruction in a timer interrupt task to set a fixed time to execute this instruction.
2. If  $S+7$ ,  $D_1+n-1$ , or  $D_2+(n*8)-1$  exceeds the device range, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2003.
3. If  $n$  is not between 2–8, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#200B.
4. If you declare the operand **S** in ISPSOft, the data type is ARRAY [8] of BOOL.


API	Instruction code			Operand							Function					
0705	D	ABSD		<b>S<sub>1</sub>, S<sub>2</sub>, D, n</b>							Absolute drum sequencer					

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
S <sub>1</sub>	●	●			●	●	●	●	●							
S <sub>2</sub>	●	●			●	●	●	●	●							
D		●	●	●				●								
n	●	●						●	●		○	○	○	○		

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
S <sub>1</sub>		●	●			●	●						
S <sub>2</sub>		●	●			●	●						
D	●												
n		●	●			●	●						

Pulse instruction	16-Bit instruction	32-Bit instruction
-	AS	AS

**Symbol**




- S<sub>1</sub> : Initial device for the comparison
- S<sub>2</sub> : Comparison value
- D : Comparison result
- n : Number of comparison groups

**Explanation**

- Use this instruction to generate multiple pulses corresponding to the current values of the counter.
- Only the DABSD instruction can use the 32-Bit counter, but not the device E.
- When using the ABSD instruction, n must be between 1–256.

**Example 1**

- Before the ABSD instruction is executed, the MOV instruction writes the setting values in D100–D107. The values in the even devices are minimum values, and the values in the odd devices are maximum values.
- When X0.0 is ON, the instruction compares the current value of the counter C10 with the maximum values and the minimum values in D100–D107, and stores the comparison results in M10–M13.
- When X0.0 is OFF, the original states of M10–M13 are unchanged.




4. When the current value of C10 is between the minimum value and the maximum value, M10–M13 are ON. Otherwise, M10–M13 are OFF.

Minimum value	Maximum value	Current value of C10	Output
D100=40	D101=100	$40 \leq C10 \leq 100$	M10=ON
D102=120	D103=210	$120 \leq C10 \leq 210$	M11=ON
D104=140	D105=170	$140 \leq C10 \leq 170$	M12=ON
D106=150	D107=390	$150 \leq C10 \leq 390$	M13=ON

5. Suppose the minimum value is larger than the maximum value. When the current value of C10 is less than the maximum value ( $C10 < 60$ ), or when the current value of C10 is larger than the minimum value ( $C10 > 140$ ), M12 is ON. Otherwise, M12 is OFF.

Minimum value	Maximum value	Current value of C10	Output
D100=40	D101=100	$40 \leq C10 \leq 100$	M10=ON
D102=120	D103=210	$120 \leq C10 \leq 210$	M11=ON
D104=140	D105=60	$60 \leq C10 \leq 140$	M12=OFF
D106=150	D107=390	$150 \leq C10 \leq 390$	M13=ON



#### Additional remarks

1. For the 16-bit instruction, if  $S+2*n-1$  exceeds the device range, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2003.
2. For the 32-bit instruction, if  $S+4*n-1$  exceeds the device range, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2003.
3. For the 16-bit instruction, if  $D+n-1$  exceeds the device range, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2003.
4. For the 32-bit instruction, if  $D+2*n-1$  exceeds the device range, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2003.
5. For both the 16-bit instruction and the 32-bit instruction, if  $n$  is not between 1–256, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#200B.


API	Instruction code			Operand							Function				
0706		INCD		<b>S<sub>1</sub>, S<sub>2</sub>, n, D</b>							Incremental drum sequencer				

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
S <sub>1</sub>	●	●			●	●		●	●							
S <sub>2</sub>	●	●			●	●		●	●							
D		●	●	●				●								
n	●	●						●	●		○	○	○	○		

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
S <sub>1</sub>		●				●							
S <sub>2</sub>		●				●							
D	●												
n		●				●							

Pulse instruction	16-Bit instruction	32-Bit instruction
-	AS	-

**Symbol**




- S<sub>1</sub> : Initial device for comparison
- S<sub>2</sub> : Counter number
- D : Comparison result
- n : Number of comparison groups


**Explanation**

1. This instruction generates multiple pulses for a pair of counters.
2. The instruction compares the current value of S<sub>2</sub> with the setting value in S<sub>1</sub>. When the current value matches the setting value, the instruction resets the current value of S<sub>2</sub> to 0, and stores the current comparison group number in S<sub>2</sub>+1.
3. After the comparison between the current values of S<sub>2</sub> and the n groups of values is complete, SM688 is ON for a scan cycle.
4. When the conditional contact is not enabled, the value in S<sub>2</sub> is 0, the value in S<sub>2</sub>+1 is 0, D-D+n-1 are OFF, and SM688 is OFF.
5. When using on-line editing, Reset the conditional contact to initialize the instruction.
6. The value in n must be between 1–256.

**Example**

1. Before the INCD instruction is executed, the MOV instruction writes the setting values in D100–D104. The values in D100–D104 are 15, 30, 10, 40, and 25 respectively.
2. The instruction compares the current values in C10 with the setting values in D100–D104. When the current value matches the setting value, the instruction resets C10 to 0, and counts again.
3. The instruction stores the current comparison group number in C11.
4. When the value in C11 changes by one, M10–M14 act correspondingly. Referto the following timing diagram.
5. When the comparison between the current values in C10 and the values in D100–D104 is complete, SM688 is ON for a scan cycle.
6. When X0.0 is switched from ON to OFF, C10 and C11 are reset to 0, and M10–M14 are switched OFF. When X0.0 switches to ON again, the instruction execution starts from the beginning.





**Additional remarks**

1. If  $S_2+1$  exceeds the device range, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2003.
2. If  $S_1+n-1$  exceeds the device range, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2003.
3. If  $D+n-1$  exceeds the device range, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2003.
4. If  $n$  is not between 1–256, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#200B.
5. If you declare the operand  $S_2$  in ISPSoft, the data type is ARRAY [2] of WORD/INT.

API	Instruction code			Operand													Function		
0708	D	PIDE		As shown in the following table													PID algorithm		
Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F			
PID_RUN	●	●	●	●				●											
SV								●								○			
PV								●								○			
PID_MODE								●					○	○					
PID_MAN	●	●	●	●				●											
MOUT_AUTO	●	●	●	●				●											
CYCLE								●					○	○					
KC_Kp								●											
Ti_Ki								●											
Td_Kd								●											
Tf								●								○			
PID_EQ	●	●	●	●				●											
PID_DE	●	●	●	●				●											
PID_DIR	●	●	●	●				●											
ERR_DBW								●	●							○			
MV_MAX								●	●							○			
MV_MIN								●	●							○			
MOUT								●											
BIAS								●	●							○			
I_MV								●											
MV								●											

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING

Pulse instruction	16-Bit instruction	32-Bit instruction
-	-	AS

**Symbol**

DPIDE	
En	
PID_RUN	MV
SV	
PV	
PID_MODE	
PID_MAN	
MOUT_AUTO	
CYCLE	
Kc_Kp	
Ti_Ki	
Td_Kd	
Tf	
PID_EQ	
PID_DE	
PID_DIR	
ERR_DBW	
MV_MAX	
MV_MIN	
MOUT	
BIAS	
I_MV	
MV	

<b>EN</b>	: Enable/Disable the instruction
<b>PID_RUN</b>	: Enable the PID algorithm
<b>SV</b>	: Target value (SV)
<b>PV</b>	: Process value (PV)
<b>PID_MODE</b>	: PID control mode
<b>PID_MAN</b>	: PID Auto/Manual mode
<b>MOUT_AUTO</b>	: Manual/Auto output value
<b>CYCLE</b>	: Sampling time (CYCLE)
<b>Kc_Kp</b>	: Proportional gain
<b>Ti_Ki</b>	: Integral coefficient (sec. or 1/sec)
<b>Td_Kd</b>	: Derivative coefficient (sec)
<b>Tf</b>	: Derivate-action time constant (sec)
<b>PID_EQ</b>	: PID formula types
<b>PID_DE</b>	: Calculation of the PID derivative error
<b>PID_DIR</b>	: PID forward/reverse direction (PID_DIR)
<b>ERR_DBW</b>	: Range within which the error value is counted as 0
<b>MV_MAX</b>	: Maximum output value (MV_MAX)
<b>MV_MIN</b>	: Minimum output value (MV_MIN)
<b>MOUT</b>	: Manual output value (MOUT)
<b>BIAS</b>	: Feed forward output value
<b>I_MV</b>	: Accumulated integral value
<b>MV</b>	: Output value (MV)

**Explanation**

1. This instruction implements the PID algorithm. After the sampling time is reached, the instruction applies PID algorithm. PID stands for Proportional, Integral, Derivative. The PID control is widely applied to mechanical, pneumatic, and electronic equipment.
2. The parameter settings are listed in the following table.

Operand	Data type	Function	Setting range	Description
<b>PID_RUN</b>	BOOL	Enabling the PID algorithm		True: use the PID algorithm. False: reset the output value (MV) to 0, and stop using the PID algorithm.
<b>SV</b>	REAL	SV	Range of single-precision floating-point numbers	Target value
<b>PV</b>	REAL	PV	Range of single-precision floating-point numbers	Process value
<b>PID_MODE</b>	DWORD/DINT	PID control mode		<p>0: Automatic control</p> <p>When PID_MAN switches from True to False, invoke the output value (MV) in the automatic algorithm. If the MV exceeds the limits of MV_MAX or MV_MIN, I_MV value stays the same and without updating.</p> <p>1: Auto tuning the parameters for the temperature control. After tuning is done, the system is in auto control mode (PID_MODE is set to 0) and fill in the appropriate parameters (Kc_Kp, Ti_Ki, Td_Kd, and Tf)</p> <p>2: Automatic control (including I_MV): When PID_MAN switches from TRUE to FALSE, the MV value is invoke the output value (MV) in the</p>

Operand	Data type	Function	Setting range	Description
				<p>automatic algorithm. If the MV exceeds the limits of MV_MAX or MV_MIN, I_MV use the formula to calculate the correct value and adjust its value accordingly. This can reduce the response time of the reverse action.</p> <p>Note: when the mode is set to 1, auto tuning the parameter, you cannot use numerical value to set up.</p>
<b>PID_MAN</b>	BOOL	PID A/M mode		<p>True: Manual</p> <p>Output the MV according to MOUT, but it is still between MV_MIN and the MV_MAX. This setting has no effect when PID_MODE is set to 1.</p> <p>False: Automatic</p> <p>Output the MV according to the PID algorithm, and the output value is between MV_MIN and MV_MAX.</p>
<b>MOUT_AUTO</b>	BOOL	MOUT automatic change mode		<p>True: Automatic</p> <p>MOUT varies with the MV.</p> <p>False: Normal</p> <p>MOUT does not vary with the MV.</p>
<b>CYCLE</b>	DWORD/DINT	Sampling time (Ts)	1–40,000 (unit: ms)	When the instruction is scanned, use the PID algorithm according to the sampling time, and refresh MV. The PLC requires that the instruction execute; it will not run the

Operand	Data type	Function	Setting range	Description
				<p>sampling time automatically. If <math>T_s</math> is less than 1, it is counted as 1. If <math>T_s</math> is larger than 40,000, it is counted as 40,000.</p> <p>When using the PID instruction in an interval interrupt task, the sampling time is the same as the interval between the timed interrupt tasks. The sampling cycle setting of the sampling cycle is ignored here.</p>
<b>Kc_Kp</b>	REAL	Calculated proportional coefficient (Kc or Kp, according to the settings in PID_EQ)	Range of positive single-precision floating-point numbers	<p>Calculated proportional coefficient (Kc or Kp)</p> <p>If the P coefficient is less than 0, the Kc_Kp is 0. Independently, if Kc_Kp is 0, it is not controlled by P.</p>
<b>Ti_Ki</b>	REAL	Integral coefficient (Ti or Ki, according to the settings in PID_EQ)	Range of positive single-precision floating-point numbers (unit: Ti = sec; Ki = 1/sec)	<p>If the calculated coefficient I is less than 0, Ti_Ki is 0. If Ti_Ki is 0, it is not controlled by I.</p>

Operand	Data type	Function	Setting range	Description
<b>Td_Kd</b>	REAL	Derivative coefficient (Td or Kd, according to the settings in PID_EQ)	Range of positive single-precision floating-point numbers (unit: sec)	If the calculated coefficient D is less than 0, Td_Kd is 0. If Ti_Ki is 0, it is not controlled by D.
<b>Tf</b>	REAL	Derivate-action time constant	Range of positive single-precision floating-point numbers (unit: sec)	If the derivate-action time constant is less than 0, Tf is 0 and it is not controlled by the derivate-action time constant (derivative smoothing).
<b>PID_EQ</b>	BOOL	PID formula types	TRUE: dependent formula FALSE: independent formula	
<b>PID_DE</b>	BOOL	The calculation of the PID derivative error	TRUE: use the variations in the PV to calculate the control value of the derivative (Derivative of the PV). FALSE: use the variations in the error (E) to calculate the control value of the derivative (derivative of the error).	
<b>PID_DIR</b>	BOOL	PID forward/reverse direction	True: forward action (E=SV-PV) False: reverse action (E=PV-SV)	
<b>ERR_DBW</b>	REAL	Range within which the error value is counted as 0.	Range of single-precision floating-point numbers	The error value (E) is the difference between the SV and the PV. When the setting value is 0, the function disabled; otherwise the CPU


Operand	Data type	Function	Setting range	Description
				<p>module checks whether the present error is less than the absolute value of ERR_DBW, and checks whether the present error meets the cross status condition. If the present error is less than the absolute value of ERR_DBW, and meets the cross status condition, the present error is counted as 0, and the PLC applies the PID algorithm ; otherwise the present error is brought into the PID algorithm according to the normal processing.</p>
<b>MV_MAX</b>	REAL	Maximum output value	Range of single-precision floating-point numbers	<p>Suppose <b>MV_MAX</b> is set to 1,000. When MV is larger than 1,000, 1,000 is the output. The value in <b>MV_MAX</b> should be larger than that in <b>MV_MIN</b>. Otherwise, the maximum MV and the minimum MV are reversed.</p>
<b>MV_MIN</b>	REAL	Minimum output value	Range of	Suppose <b>MV_MIN</b> is

Operand	Data type	Function		Setting range	Description
				single-precision floating-point numbers	set to -1,000. When the MV is less than -1,000, -1,000 is the output.
<b>MOUT</b>	REAL	MV		Range of single-precision floating-point numbers	When set to PID Manual, the MV value is output as the setting value for MOUNT, between MV_MAX and MV_MIN.
<b>BIAS</b>	REAL	Feed forward output value		Range of single-precision floating-point numbers	Feed forward output value, used for the PID feed forward.
<b>I_MV</b> (occupies 15 consecutive DWord devices )	REAL	I_MV	Accumulated integral value	Range of single-precision floating-point numbers	Accumulated integral value temporarily stored, and usually for reference. You can still clear or modify it according to your needs. PID mode in 0 (Automatic control): When the MV is greater than the MV_MAX, or when the MV is less than MV_MIN, the accumulated integral value in I_MV is unchanged. PID mode in 2

6

Operand	Data type	Function		Setting range	Description
					(Automatic control, including I_MV): When PID_MAN switches from TRUE to FALSE, the MV value is invoke the output value (MV) in the automatic algorithm. If the MV exceeds the limits of MV_MAX or MV_MIN, I_MV use the formula to calculate the correct accumulated integral value and adjust its value accordingly. This can reduce the response time of the reverse action.
		I_MV+1	The previous error value is temporarily stored here.		
		I_MV+2– I_MV+5	For system use only		
		I_MV+6	The previous PV is temporarily stored here.		
		I_MV+7– I_MV+14	For system use only		
<b>MV</b>	REAL	MV	The MV is between the MV_MIN and the MV_MAX.		


The diagram of switching to PID\_MAN / MOUT\_AUTO:



1. When switching the control mode (**PID\_MAN=0**) from automatic to manual, you can set the flag MOUT\_AUTO to 1 and the output value of MOUT goes along with the output value of MV. After switching to the manual mode (**PID\_MAN=1**), you can set the MOUT\_AUTO to 0.
2. When **PID\_RUN** changes from TRUE to FALSE, the PLC resets the value in MV to 0. When the value in MV is to be retained, you can set EN to FALSE to dismiss the instruction and to keep the output value in MV.

Example 1

1. Set all parameters before executing this instruction.
2. When M0 is ON, the instruction is executed. When PID\_RUN is ON, the instruction applies the DPID algorithm. When PIC\_RUN is OFF, MV is 0, and store the value in MV. When M0 switches to OFF, the instruction is not executed, and the previous data is unchanged.




Additional remarks

1. The instruction can be used several times, but the registers specified by **I\_MV-I\_MV+14** cannot be the same.
2. **I\_MV** occupies 30 registers.
3. You can only use the 32-bit instruction in cyclic tasks and interval interrupt tasks. When using the 32-bit instruction in an interval interrupt task, the sampling time (Cycle) is the same as the interval between the timed interrupt tasks.
4. When the instruction is scanned, the 32-bit PID algorithm is applied according to the sampling time (Cycle), and it refreshes MV. When you use the instruction in an interrupt task, the sampling time (Cycle) is the same as the

interval between the timed interrupt tasks. The PID algorithm is applied according to the interval between the timed interrupt tasks.

5. Before the 32-bit PID algorithm is applied, the process value used in the PID instruction has to be a stable value. When you need the input value in the module to implement the DPID algorithm, must note the time it takes for the analog input to be converted into the digital input.
6. When the PV (process value) is in the range of **ERR\_DBW**, at the beginning, the present error is brought into the PID algorithm according to the normal processing, and then the CPU module checks whether the present error meets the cross status condition: PV (process value) goes beyond the SV (target value). Once the condition is met, the present error is counted as 0 when applying the PID algorithm. After the PV (process value) is out of the **ERR\_DBW** range, the present error is brought into the PID algorithm again. If PID\_DE is true, that means it uses the variations in the PV to calculate the control value of the derivative, and after the cross status condition is met, the PLC treats  $\Delta PV$  as 0 to apply the PID algorithm. ( $\Delta PV = \text{current PV} - \text{previous PV}$ ). In the following example, the present error is brought into the PID algorithm according to the normal processing in section A, and the present error or  $\Delta PV$  is counted as 0 to apply the PID algorithm in the section B.



#### The PID algorithm:

1. When you set **PID\_MODE** to 0, the PID control mode is the automatic control mode.

- **Independent Formula & Derivative of E (PID\_EQ=False & PID\_DE=False)**

$$MV = K_p E + Ki \int_0^t E dt + K_d * \frac{dE}{dt} + BIAS \quad E = SV - PV \quad \text{or} \quad E = PV - SV$$

- **Independent Formula & Derivative of PV (PID\_EQ=False & PID\_DE=True)**

$$MV = K_p E + Ki \int_0^t E dt - K_d * \frac{dPV}{dt} + BIAS \quad E = SV - PV$$

Or

$$MV = K_p E + Ki \int_0^t E dt + K_d * \frac{dPV}{dt} + BIAS \quad E = PV - SV$$

- **Dependent Formula & Derivative of E (PID\_EQ=True & PID\_DE=False)**

$$MV = K_c \left[ E + \frac{1}{T_i} \int_0^t E dt + T_d * \frac{dE}{dt} \right] + BIAS \quad E = SV - PV \quad \text{or} \quad E = PV - SV$$

- **Dependent Formula & Derivative of PV (PID\_EQ=True & PID\_DE=True)**

$$MV = K_c \left[ E + \frac{1}{T_i} \int_0^t E dt - T_d * \frac{dE}{dt} \right] + BIAS \quad E = SV - PV$$


Or

$$MV = K_c \left[ E + \frac{1}{T_i} \int_0^t E dt + T_d * \frac{dE}{dt} \right] + BIAS \quad E = PV - SV$$


- When you set **PID\_MODE** to 1, the PID control mode is the automatic tuning mode. After the tuning of the parameter is complete, **PID\_MODE** is set to 0. The PID control mode then becomes the automatic control mode.

**PID Block Diagram:**

PID Block Diagram (Independent)



PID Block Diagram (Dependent)




### Suggestions

1. Since you can use the 32-bit instruction in a lot of controlled environments, you must choose the appropriate control function. For example, to prevent improper control, do not use **PID\_MODE** in the motor controlled environment when it is set to 1.
2. When you tune the parameters **Kc\_Kp**, **Ti\_Ki**, and **Td\_Kd** (**PID\_MODE** is set to 0), you must tune KP first (based on experience), and then set **Ti\_Ki** and **Td\_Kd** to 0. When you can handle the control, you can increase **Ti\_Ki** and **Td\_Kd**. When **Kc\_Kp** is 1, it means that the proportional gain is 100%. That is, the error value is increased by a factor of one. When the proportional gain is less than 100%, the error value is decreased. When the proportional gain is larger than 100%, the error value is increased.
3. To prevent the parameters that have been tuned automatically from disappearing after a loss of power, you must store the parameters in the latched data registers when **PID\_MODE** is set to 1. The parameters that have been automatically tuned are not necessarily suitable for every controlled environment. Therefore, you can modify the automatically tuned parameters; however, it is suggested that you only modify the **Ti\_Ki** and the **Td\_Kd**.
4. You can use this instruction with many parameters, but to prevent improper control, do not set the parameters randomly.

**Example 2:** Tuning the parameters used with the PID instruction


Suppose that the transfer function of the plant is the first-order function  $G(s) = \frac{b}{s+a}$ , the SV is 1, the sampling time Ts is 10 milliseconds. It is suggested that you follow these steps when tuning the parameters.

**Step 1:** First, set the  $K_I$  and the  $K_D$  to 0. Next, set the  $K_P$  to 5, 10, 20 and 40 successively, and record the target values and the process values. The results are shown in the following diagram.



**Step 2:** When the  $K_P$  is 40, there is overreaction. When the  $K_P$  is 20, the reaction curve of PV is close to SV, and there is no overreaction. However, due to the fast start-up, the transient output value (MV) is big. Neither 40 nor 20 is a suitable value. When the  $K_P$  is 10, the reaction curve of PV approaches SV smoothly. When  $K_P$  is 5, the reaction is too slow. Therefore,  $K_P = 10$  is the best choice.


**Step 3:** After setting  $K_P$  to 10, increase  $K_I$ . For example,  $K_I$  is successively set to 1, 2, 4, and 8.  $K_I$  should not be larger than  $K_P$ . Then, increase  $K_D$ . For example, successively set  $K_D$  to 0.01, 0.05, 0.1, and 0.2.  $K_D$  should not be larger than ten percent of  $K_P$ . Finally, the relation between PV and SV is shown in the following diagram.





Note: This example is only for reference. You must tune the parameters properly according to the actual condition of the control system.

**Example 3:** Using the automatic tuning function to control the temperature


Because you may not be familiar with the characteristics of the temperature environment to be controlled, you can use the automatic tuning function to make an initial adjustment (**PID\_MODE** is set to 1). After the automatic tuning of the parameter is complete, **PID\_MODE** is set to 0. The controlled environment in this sample is an oven. The following example program shows the setting values for the instruction.



The experimental result of the automatic tuning function is shown in the following graph.




The following graph shows the result of using the automatically tuned parameters to control the temperature.



This graph shows that using automatically tuned parameters can result in a good temperature control result. It only takes about twenty minutes to control the temperature. The following graph shows the result of changing the target temperature from 80°C to 100°C.


6



This graph shows that when the target temperature changes from 80°C to 100°C, the automatically tuned parameters still work to control the temperature in a reasonable amount of time.


**Example 4:** Creating a DPIDE instruction in a function block and setting to the cyclic task mode to read the function block written with a DPIDE instruction to control the temperature.

1. Set the value in DPIDE\_CYCLE to 1000 ms, and execute the DPIDE instruction by reading the function block written with a DPIDE instruction. Whenever the function block is scanned, the PID algorithm is applied according to the sampling time (Cycle), and it refreshes the output value (DPIDE\_MV).
2. Set the DPIDE\_MODE =1 for auto tuning the parameters for the temperature control. After tuning is done, the system is in auto control mode (PID\_MODE is set to 0) and fill in the appropriate parameters (Kc\_Kp, Ti\_Ki, Td\_Kd, and Tf).
3. Main program (cyclic task): Since PLC only executes the DPIDE instruction when it is scanned. If we use TMRH to work with the DPIDE instruction, for example, set the TMRH to 1000 ms, the system calls the function block written with a DPIDE instruction (AS\_DPIDE) every 1000 ms. See the example program below.



4. Function block (AS\_DPIDE): Execute the DPIDE instruction by reading the function block written with a DPIDE instruction. Whenever the function block is scanned, the PID algorithm is applied according to the sampling time (Cycle), and it refreshes the output value (DPIDE\_MV). (Refer to ISPSOft Manual for more details on how to create a function block.)

NOTE: The parameters PID\_MODE, Kc\_Kp, Ti\_Ki, Td\_Kd, Tf and I\_MV in the function block written with a DPIDE instruction should be declared as VAR\_IN\_OUT.



6


**Example 5:** Creating a DPIDE instruction in a time interrupt program to control the temperature. (Note: use the time interrupt as the cycle time of DPIDE.)

1. Set the time interrupt to 1000 ms in HWCONFIG.
2. Create a DPIDE instruction in a time interrupt program. Whenever a time interrupt occurs, the PID algorithm is applied. The setting in DPIDE\_CYCLE is invalid here.
3. Set the DPIDE\_MODE =1 for auto tuning the parameters for the temperature control. After tuning is done, the system is in auto control mode (PID\_MODE is set to 0) and fill in the appropriate parameters (Kc\_Kp, Ti\_Ki, Td\_Kd, and Tf).

Main program (cyclic task)



Time interrupt program I601 and the setting parameters




API	Instruction code			Operand							Function					
0709		XCMP		<b>S<sub>1</sub>, S<sub>2</sub>, S<sub>3</sub>, S<sub>4</sub>, D,</b>							Setting up to compare the inputs of multiple work stations					

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
<b>S<sub>1</sub></b>	○															
<b>S<sub>2</sub></b>							○									
<b>S<sub>3</sub></b>								○								
<b>S<sub>4</sub></b>								○								
<b>D</b>								○								

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
<b>S<sub>1</sub></b>	●												
<b>S<sub>2</sub></b>												●	
<b>S<sub>3</sub></b>		●				●							
<b>S<sub>4</sub></b>			●				●						
<b>D</b>			●				●						

Pulse instruction	16-Bit instruction	32-Bit instruction
-	AS	-

**Symbol**



- S<sub>1</sub>** : Trigger input point
- S<sub>2</sub>** : High-speed counter number
- S<sub>3</sub>** : Setting for the numbers for work station and objects
- S<sub>4</sub>** : Reference value for comparison and the observational error
- D** : First corresponding device for the comparison result in the stack area

**Explanation**

1. This instruction is only available for AS Series PLCs with firmware version 1.04.00 or higher. The instruction cannot be used in the ST programming language, interrupt tasks or function block which is called only once.
2. Use this instruction along with API 0710 YOUT. It is very useful for the applications of assembly and processing with multiple work stations, including painting, carpentry, metalwork sectors and many more.
3. Use **S<sub>1</sub>** for setting the trigger input points; the high-speed inputs are X0.0–X0.15 and the other inputs are general type. Executing the instruction enables the external interrupts for the inputs (X0.0–X0.15). Therefore do NOT use the inputs with interrupt tasks; otherwise, when the instruction is executed, the interrupts are disabled and resumed only after the instruction completes. The general type inputs are affected by the scan time though they are suitable for the environments where the inputs are not as stable.

4. **S<sub>2</sub>** works with 32-bit counters (HC0–HC255). When the inputs are the high-speed trigger input type, implement the hardware high-speed counter and use the DCNT instruction to enable the counter. When you need high-speed output, use the DMOV instruction to copy the output current position; for example copying the axis of SR460 to HC0, (DMOV SR460 HC0).
5. For PLC with FW V1.04.00 (V1.04.00 included) or previous versions:  
**S<sub>3</sub>** occupies three consecutive 16-bit devices. **S<sub>3</sub>+0** is n (the work station number) and **S<sub>3</sub>+1** is m (the maximum object number). **S<sub>3</sub>+2** is the result of the object being filtered. The range for n and m is between 1–32. When this value is out of range, the value used is the maximum (32) or the minimum (1). The range for **S<sub>3</sub>+2** (the number of filter) is between 0–32767. Zero is used for any value less than 0, and a value of 0 disables the filtering function. Be sure to declare an array of 3 words or 3 consecutive word type variables.
6. For PLC with FW V1.06.00 (V1.06.00 included) or higher versions:  
**S<sub>3</sub>** occupies seven consecutive 16-bit devices. **S<sub>3</sub>+0** is n (the work station number) and **S<sub>3</sub>+1** is m (the maximum object number). **S<sub>3</sub>+2** is the result of the object being filtered. The range for n and m is between 1–64. When this value is out of range, the value used is treated as the maximum (32) or the minimum (1). The range for **S<sub>3</sub>+2** (the number of filter) is between 0–32767. Zero is used for any value less than 0 ; and a value of 0 disables the filtering function. **S<sub>3</sub>+3** (Low Word) and **S<sub>3</sub>+4** (High Word) are for rising-edge values. **S<sub>3</sub>+5** (Low Word) and **S<sub>3</sub>+6** (High Word) are for falling-edge values (32-bit). Be sure to declare an array of 7 words or 7 consecutive word type variables.
7. Set the maximum number for **S<sub>3</sub>+1** (m). If  $m < n$ , note the objects and make sure they are sufficient on the production line.
8. **S<sub>4</sub>** occupies 3xn consecutive 32-bit devices (6xn 16-bit devices). If the required space exceeds the range of device D, the instruction is not executed. The value of n is the work station number set in the operand **S<sub>3</sub>**. The following table lists the functions for each device and the corresponding number for **S<sub>4</sub>**. Be sure to declare an array of 3n double words or 3 consecutive double word type variables for **S**.

Function	Work station 1	Work station 2	• • •	Work station n
Reference value for comparison (32-bit)	<b>S<sub>4</sub>+0</b>	<b>S<sub>4</sub>+2</b>	• • •	<b>S<sub>4</sub>+(n-1)x2</b>
Observational error of the compared stack area for the entering-work-station ones (32-bit)	<b>S<sub>4</sub>+2xn</b>	<b>S<sub>4</sub>+2xn+2</b>	• • •	<b>S<sub>4</sub>+(2xn-1)x2</b>
Observational error of the compared stack area for the leaving-work-station ones (32-bit)	<b>S<sub>4</sub>+4xn</b>	<b>S<sub>4</sub>+4xn+2</b>	• • •	<b>S<sub>4</sub>+(3xn-1)x2</b>

When you set the reference value to 0 for a specific work station, the specific work station stops working. You can use this technique to manage work stations.


9. **D** is the first corresponding device for the comparison result in the stack area. **D** occupies 2xn consecutive 16-bit devices and 2xmxn consecutive 32-bit devices (or 4xmxn consecutive 16-bit devices). If the required space exceeds the range of device D, the instruction is not executed. The following table lists the functions for each device and the corresponding number for **D**.

Function	Work station 1	Work station 2	• • •	Work station n
Value of the head index (16-bit)	<b>D+0</b>	<b>D+1</b>	• • •	<b>D+(n-1)</b>
Value of the tail index (16-bit)	<b>D+n</b>	<b>D+(n+1)</b>	• • •	<b>D+(2xn-1)</b>
Compared stack area 1 for the entering -work-station ones (32-bit)	<b>D+2xn</b>	<b>D+2xn+2</b>	• • •	<b>D+2xn+2(n-1)</b>
Compared stack area 1 for the leaving-work-station ones (32-bit)	<b>D+4xn</b>	<b>D+4xn+2</b>	• • •	<b>D+4xn+2(n-1)</b>
⋮	⋮	⋮	⋮	⋮
Compared stack area m for the entering -work-station ones (32-bit)	<b>D+4xmxn-2xn</b>		• • •	<b>D+4xmxn-2</b>
Compared stack area m for the leaving-work-station ones (32-bit)	<b>D+4xmxn</b>		• • •	<b>D+4xmxn+2 (n-1)</b>

**D** tends to occupy more space in the stack area. If the required space exceeds the range of device **D**, the PLC only executes what is valid in the storage and does not show a no warning. It is suggested that you declare an array of  $2xn+4xmxn$  words for **D**.

10. There is no limit on the number of times you can execute the instruction but only one execution can be done at a time.
11. It is suggested to use this instruction with the YOUT instruction (API 0710), and use the same first corresponding device for the comparison result in the stack area (**D**).
12. For PLC with FW V1.04.00 (V1.04.00 included) or previous versions:

The following timing diagram shows executing the high-speed counter and filter (reading from right to left).




- ① PLC reads the current counter value and stores the value in a register.
- ② Drop the shifting counter value: when the signal is unstable (the number of filters is not sufficient).
- ③ Drop the shifting counter value: when the signal is unstable (the number of filters is not sufficient).
- ④ Record the counter value to the compared stack area for the entering-work-station ones, when the signal is stable.

- ⑤ Record the counter value to the compared stack area for the leaving-work-station ones, when the signal is stable.

13. For PLC with FW V1.06.00 (V1.06.00 included) or higher versions:

The following timing diagram shows executing the high-speed counter and filter (reading from right to left).



- ① PLC reads the current counter value and stores the value in a register.
- ② Drop the counter value: the number of filters read is less than the number of filters set.
- ③ Record the counter value to the compared stack area for the entering-work-station ones, when the signal is stable.
- ④ Record the counter value to the compared stack area for the leaving-work-station ones, when the signal is stable.
- ⑤ The number of filters

14. When the signal is rising- or falling-edge triggered, and the PLC completes processing the filters, the PLC reads the high-speed counter value and adds one in the value of the head index. The PLC then records the entering and leaving counter results for each work station. The compared counter result is the current counter value + reference value + observational error. For either rising- or falling-edge triggered, the value of the head index is incremented. The maximum value for the head index mx2 (the maximum number of objects).
15. The value of the head index is cyclically incremented, when the signal is rising- or falling-edge triggered and completes processing the number of filters (the default for trigger input is OFF). The maximum value for the head index is mx2 (the maximum number of objects). For example, if you set the number of objects to 10, the value of the head index (default: 0) is incremented to 1, 2, 3 to 20 and then 1, 2, 3 to 20 repeatedly. When the value of the head index is 0, it means no object has entered after executing the instruction. The PLC adds one to the value of the head index, and then checks the value of the tail index. If the value (after adding one) in the value of the head index equals the value of the tail index, the PLC cancels the addition and records the counter result.
16. When the instruction is executed and the state of the initial input is **OFF**, the **rising-edge trigger** corresponds to the **odd numbers** of the head index value, and the **falling-edge trigger** corresponds to the **even numbers** of the head index value.

17. When the PLC executes the instruction and the state of the initial input is **ON**, the **falling-edge trigger** corresponds to the **odd numbers** of the head index value, and the **rising-edge trigger** corresponds to the **even numbers** of the head index value.
18. When the PLC executes the instruction, it does not clear the values in the accumulated area and the index areas. If the data is in a latched area and needs to be enabled again, use the ZRST instruction to clear the values in the head and tail indexes.

### Example

Refer to the example in the YOUT instruction (API 0710) for more information.


API	Instruction code			Operand							Function						
0710		YOUT		$S_1 \cdot S_2 \cdot S_3 \cdot D$							Comparing the outputs of multiple work stations						

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
$S_1$							○									
$S_2$								○								
$S_3$								○								
<b>D</b>		○	○													

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
$S_1$												●	
$S_2$		●				●							
$S_3$			●				●						
<b>D</b>	●												

Pulse instruction	16-Bit instruction	32-Bit instruction
-	AS	-

### Symbol



- $S_1$  : High-speed counter number
- $S_2$  : Setting for the number for work stations and objects
- $S_3$  : First corresponding device for the comparison result in the stack area
- D** : First corresponding device for the output work station


### Explanation

- This instruction is only available for AS Series PLCs with firmware version 1.04.00 or higher. The instruction cannot be used in the ST programming language, interrupt tasks or function block which is called only once.
- $S_1$  is for the setting of the high-speed counter. Use the same settings for the high-speed counter as for the high-speed counter for the XCMP instruction.
- $S_2$  occupies two consecutive 16-bit devices.  $S_2+0$  is n (the work station number) and  $S_2+1$  is m (the maximum number of objects). The range for n and m is between 1–32 for PLC with FW V1.04.00 (V1.04.00 included) or previous versions. And the range for n and m is between 1–64 for PLC with FW V1.06.00 (V1.06.00 included) or higher versions. When the value is out of range, the value used is the maximum (32) or the minimum (1). The settings for the operands should be the same as for the XCMP instruction.
- $S_3$  is first corresponding device for the comparison result in the stack area.  $S_3$  occupies  $2 \times n$  consecutive 16-bit devices and  $2 \times m \times n$  consecutive 32-bit devices (or  $4 \times m \times n$  consecutive 16-bit devices). For information on the functions of each device and the corresponding number for **D**, refer to the XCMP instruction (API 0709). It is suggested that you use the same variable as you use for the XCMP instruction.

5. There is no limit on the number of times you can execute the instruction but only one execution can be done at a time.
6. It is suggested that you use with the XCMP instruction, and use the same first corresponding device for the comparison result in the stack area (**S<sub>3</sub>**).
7. **D** is only for the outputs of Y and M devices; Y and M should be the BOOL data type. It occupies a consecutive number of work stations X<sub>n</sub>. When used as the output point of Y or the M device, the instruction refreshes the output states.
8. The odd numbered head index values (for example 1, 3, 5,...) are the compared counter results for the object when entering (Compared stack areas for the entering -work-station ones). The even numbered head index values (for example 2, 4, 6,...) are the compared counter result of the object when leaving (Compared stack areas for the entering -work-station ones).
9. When the compared counter result for entering and leaving in the stack area are 0, the actions in this area are not executed and the state of the corresponding output work station is OFF. Add 2 to the value of the tail index and the added value in the tail index should not exceed the value of the head index.
10. When the YOUT instruction is executed, each work station checks the compared value for entering and leaving in the tail index. When the counter value is larger or the same as the compared value for entering, the corresponding output point is ON and adds 1 to the value of the tail index. When the counter value is larger or the same as the compared value for leaving, the corresponding output is OFF and adds 1 to the value of the tail index; but the value of the tail index (after adding 1) does not exceed the value of the head index.

6

**Example: three work stations and up to four objects**





**Step 1:** use the input point X0.4 as the object detection interrupt, HC202 as the high-speed counter for the encoder and output point Y0.0 as the first output point for the work station.

**Step 2:** edit the register to set up the reference values, and the observational error when entering and leaving.

Device D	D500	D502	D504
Reference value for comparison (32-bit)	K2000	K3000	K4000
Device D	D506	D508	D510
Observational error when entering (32-bit)	K100	K120	K130
Device D	D512	D514	D516
Observational error when leaving (32-bit)	K50	K-20	K20
Device D	D2000	D2001	D2002
Value of the head index (16-bit)	K0	K0	K0
Device D	D2003	D2004	D2005
Value of the tail index (16-bit)	K0	K0	K0

**Step 3:** set up the initial values and write the programs.





Set up three work stations for D0, 4 objects for D1 and 50 filters for D2. After the contact M0 is activated, the system sets the object detection, the compared values, the compared counter result of the object entering and leaving, and the output controls for each work station. For example, the system detects two objects have entered and then four triggers to read the compared counter results: 3000, 3500, 4500, and 5000 in HC202 (HC202=K5060). The following table shows the compared value and the head/tail index in the stack area.

Device D	D2000	D2001	D2002
Value of the head index (16-bit)	K4	K4	K4
Device D number	D2003	D2004	D2005
Value of the tail index (16-bit)	K1	K1	K1
Device D number	D2006	D2008	D2010
Compared stack area 1 for the entering -work-station ones (32-bit)	K5100	K6120	K7130
Device D number	D2012	D2014	D2016
Compared stack area 1 for the leaving-work-station ones (32-bit)	K5550	K6480	K7520
Device D number	D2018	D2020	D2022
Compared stack area 1 for the entering -work-station ones (32-bit)	K6600	K7620	K8630
Device D number	D2024	D2026	D2028
Compared stack area 2 for the leaving-work-station ones (32-bit)	K7050	K7980	K9020
Device D number	D2030	D2032	D2034

Compared stack area 3 for the entering -work-station ones (32-bit)	K0	K0	K0
Device D number	D2036	D2038	D2040
Compared stack area 3 for the leaving-work-station ones (32-bit)	K0	K0	K0

The following table shows the state of the output point Y when the high-speed counter HC202 reaches 5200.

Output point Y number	Y0.0	Y0.1	Y0.2
16-bit value	ON	OFF	OFF
Device D number	D2000	D2001	D2002
Value of the head index (16-bit)	K4	K4	K4
Device D number	D2003	D2004	D2005
Value of the tail index (16-bit)	K2	K1	K1

The following table shows the state of the output point Y when the high-speed counter HC202 reaching 6200.

Output point Y number	Y0.0	Y0.1	Y0.2
16-bit value	OFF	ON	OFF
Device D number	D2000	D2001	D2002
Value of the head index (16-bit)	K4	K4	K4
Device D number	D2003	D2004	D2005
Value of the tail index (16-bit)	K3	K2	K1

The following table shows the state of the output point Y when the high-speed counter HC202 reaching 6800.

Output point Y number	Y0.0	Y0.1	Y0.2
16-bit value	ON	OFF	OFF
Device D number	D2000	D2001	D2002
Value of the head index (16-bit)	K4	K4	K4
Device D number	D2003	D2004	D2005
Value of the tail index (16-bit)	K4	K3	K1

The following table shows the state of the output point Y when the high-speed counter HC202 reaching 7300.

Output point Y number	Y0.0	Y0.1	Y0.2
16-bit value	OFF	OFF	ON
Device D number	D2000	D2001	D2002
Value of the head index (16-bit)	K4	K4	K4
Device D number	D2003	D2004	D2005
Value of the tail index (16-bit)	K4	K3	K2

The following table shows the state of the output point Y when the high-speed counter HC202 reaching 7700.

Output point Y number	Y0.0	Y0.1	Y0.2
16-bit value	OFF	ON	OFF
Device D number	D2000	D2001	D2002
Value of the head index (16-bit)	K4	K4	K4
Device D number	D2003	D2004	D2005
Value of the tail index (16-bit)	K4	K4	K3

The following table shows the state of the output point Y when the high-speed counter HC202 reaching 8000.

Output point Y number	Y0.0	Y0.1	Y0.2
Output state	OFF	OFF	OFF
Device D number	D2000	D2001	D2002
Value of the head index (16-bit)	K4	K4	K4
Device D number	D2003	D2004	D2005
Value of the tail index (16-bit)	K4	K4	K3

The following table shows the state of the output point Y when the high-speed counter HC202 reaching 8700.

Output point Y number	Y0.0	Y0.1	Y0.2
Output state	OFF	OFF	ON
Device D number	D2000	D2001	D2002
Value of the head index (16-bit)	K4	K4	K4
Device D number	D2003	D2004	D2005
Value of the tail index (16-bit)	K4	K4	K4

API	Instruction code			Operand							Function					
0711	D	SUNRS	P	Longi ~ SSec							Sunrise and sunset times					


Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
Longi								●								○
Lati								●								○
TimeZ								●					○			
DST	●	●	●	●												
Year								●					○			
Month								●					○			
Date								●					○			
RHour								●								
RMin								●								
RSec								●								
SHour								●								
SMin								●								
SSec								●								

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
Longi									●				
Lati									●				
TimeZ		●				●							
DST	●												
Year		●				●							
Month		●				●							
Date		●				●							
RHour		●				●							
RMin		●				●							
RSec		●				●							
SHour		●				●							
SMin		●				●							
SSec		●				●							

Pulse instruction	16-Bit instruction	32-Bit instruction
AS		AS

Symbol

- Longi** : Longitude (REAL type)
- Lati** : Latitude (REAL type)
- TimeZ** : Time zone(integer) (-12 ~ +14)
- DST** : Daylight saving time
- Year** : Year
- Month** : Month



<b>Date</b>	Date
<b>RHour</b>	The hour to sunrise on the set date (24 hour time format)
<b>RMin</b>	The minute to sunrise on the set date
<b>RSec</b>	The second to sunrise on the set date
<b>SHour</b>	The hour to sunset on the set date (24 hour time format)
<b>SMin</b>	The minute to sunset on the set date
<b>SSec</b>	The second to sunset on the set date

### Explanation


1. The instruction works with the AS series PLC firmware V1.04.50 or later. The sunrise and sunset times may not be as accurate as the local weather report publishes because the values that you have entered may be incorrect or the altitude of where the device is installed may interfere with the accuracy. When the result is not as accurate, you can adjust the values manually. After self-evaluation, the error range of this instruction is less than 5 minutes.
2. Enter values for the local longitude and latitude in numbers. For example, the longitude and latitude of Taoyuan, Taiwan is 121.30098 and 24.99363. Latitudes north of the Equator are denoted by a positive sign. Latitudes south of the Equator are given negative values.
3. Enter values for the local time zone, ranging from -12 to +14. The time zone cannot be calculated through the set longitude and latitude; if the setting is out of range or the value is incorrect, no error message will be shown.
4. When the daylight saving time is enabled (ON), the instruction checks if the daylight saving time on the PLC is enabled. When the daylight saving time is enabled on the PLC, DST time will be added on the sunrise and sunset times.
5. Enter values for the local date, month, and year in decimal format. Make sure you have entered correct values. The instruction does not check if the values are correctly entered.
6. After calculation, the instruction output the hour, minute and second to sunrise and sunset in integer, in decimal format and 24 hour time format.

### Example

Calculate the time to sunrise and sunset in Taoyuan, Taiwan on January 1<sup>st</sup>, 2018. The official time zone in Taiwan is defined by an UTC offset of +08:00. And daily saving time is NOT implemented in Taiwan.

After calculation, the time to sunrise is at 06:39:47 and the time to sunset is at 17:16:42. See the example program below.

Checked with the official weather website, the actual sunrise occurred at 06:39:44 and the actual sunset occurred at 17:16:45. The difference between the PLC calculation and the actual occurrence is  $\pm 3$  seconds.



## 6.9 Logic Instructions

### 6.9.1 List of Logic Instructions

The following table lists the Logic instructions covered in this section.

API	Instruction code		Pulse instruction	Function
	16-bit	32-bit		
<b><u>0800</u></b>	WAND	DAND	✓	Logical AND operation
<b><u>0801</u></b>	MAND	–	✓	Matrix AND operation
<b><u>0802</u></b>	WOR	DOR	✓	Logical OR operation
<b><u>0803</u></b>	MOR	–	✓	Matrix OR operation
<b><u>0804</u></b>	WXOR	DXOR	✓	Logical exclusive OR operation
<b><u>0805</u></b>	MXOR	–	✓	Matrix exclusive OR operation
<b><u>0808</u></b>	WINV	DINV	✓	Logical reversed INV operation
<b><u>0809</u></b>	LD&	DLD&	–	$S_1 \& S_2$
<b><u>0810</u></b>	LD	DLD	–	$S_1   S_2$
<b><u>0811</u></b>	LD^	DLD^	–	$S_1 \wedge S_2$
<b><u>0812</u></b>	AND&	DAND&	–	$S_1 \& S_2$
<b><u>0813</u></b>	AND	DAND	–	$S_1   S_2$
<b><u>0814</u></b>	AND^	DAND^	–	$S_1 \wedge S_2$
<b><u>0815</u></b>	OR&	DOR&	–	$S_1 \& S_2$
<b><u>0816</u></b>	OR	DOR	–	$S_1   S_2$
<b><u>0817</u></b>	OR^	DOR^	–	$S_1 \wedge S_2$

### 6.9.2 Explanation of Logic Instructions


API	Instruction code			Operand							Function					
0800	D	WAND	P	<b>S<sub>1</sub>, S<sub>2</sub>, D</b>							Logical AND operation					

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	“\$”	F
<b>S<sub>1</sub></b>	●	●			●	●	●	●	●		○	○	○	○		
<b>S<sub>2</sub></b>	●	●			●	●	●	●	●		○	○	○	○		
<b>D</b>		●			●	●	●	●			○	○				

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
<b>S<sub>1</sub></b>		●	●			●	●						
<b>S<sub>2</sub></b>		●	●			●	●						
<b>D</b>		●	●			●	●						

Pulse instruction	16-bit instruction	32-bit instruction
AS	AS	AS

#### Symbol





- S<sub>1</sub>** : Data source 1
- S<sub>2</sub>** : Data source 2
- D** : Operation result

#### Explanation

- This instruction applies the logical operator AND to the binary representations in **S<sub>1</sub>** and **S<sub>2</sub>**. It performs the logical AND operation on each pair of corresponding bits and stores the result in **D**.
- Only the DAND instruction can use the 32-bit counter.
- The result in each position is 1 if the first bit is 1 and the second bit is 1; otherwise, the result is 0.



#### Example 1

When X0.0 is ON, the instruction performs the logical operation AND on each pair of corresponding bits in the 16-bit device Y0 and the 16-bit device Y2. It stores the result in Y4.



**Example 2**

When X0.0 is ON, the instruction performs the logical operation AND on each pair of corresponding bits in the 32-bit device (Y11, Y10) and the 32-bit device (Y21, Y20). It stores the result in (Y41, Y40).




API	Instruction code			Operand							Function					
0801		MAND	P	<b>S<sub>1</sub>, S<sub>2</sub>, D, n</b>							Matrix AND operation					

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
<b>S<sub>1</sub></b>	●	●			●	●		●	●							
<b>S<sub>2</sub></b>	●	●			●	●		●	●							
<b>D</b>		●			●	●		●								
<b>n</b>	●	●			●	●		●	●				○	○		

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
<b>S<sub>1</sub></b>		●				●							
<b>S<sub>2</sub></b>		●				●							
<b>D</b>		●				●							
<b>n</b>		●				●							

Pulse instruction	16-bit instruction	32-bit instruction
AS	AS	-

**Symbol**





- S<sub>1</sub>** : Matrix source 1
- S<sub>2</sub>** : Matrix source 2
- D** : Operation result
- n** : Length of the array

**Explanation**

1. This instruction applies the logical operator MAND to the **n** rows of binary representations in **S<sub>1</sub>** and the **n** rows of binary representations in **S<sub>2</sub>**. It performs the matrix operation AND on each pair of corresponding bits, and stores the operation result in **D**.
2. The result in each position is 1 if the first bit is 1 and the second bit is 1; otherwise, the result is 0.
3. The operand **n** must be between 1–256.


**Example**

When X0.0 is ON, this instruction performs the matrix operation AND on each pair of corresponding bits on the data in the 16-bit devices Y0–Y2 and the data in 16-bit devices Y10–Y12. It stores the result in the 16-bit devices Y20–Y22.



#### Additional remarks

1. If  $S_1+n-1$ ,  $S_2+n-1$ , or  $D+n-1$  exceeds the device range, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2003.
2. If  $n$  is not between 1–256, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#200B.
3. Explanation of matrix instructions:
  - A matrix is composed of more than one 16-bit register. The number of registers in a matrix is the length of the array  $n$ . There are  $16 \times n$  bits in a matrix, and the matrix operation is performed on one bit at a time.
  - The matrix instruction takes the  $16 \times n$  bits in a matrix as a string of bits, rather than as values. The matrix operation is performed on each bit.
  - Matrix instructions mainly process the one-to-many or many-to-many status, such as moving, copying, comparing, and searching by bit.
  - You must specify a 16-bit register for the matrix instruction. The 16-bit register specifies a certain bit among the  $16n$  bits in the matrix for the operation, and the 16-bit register is called the pointer. The value in the register is between  $0-16n-1$ , and corresponds to the bit between  $b0-b16n-1$ .
  - Shifting or rotating of the specified data can be involved in the matrix operation. Note that the bit number decreases from the left to the right, as illustrated below.



- The width of the matrix (C) is 16 bits.
- Pr represents the pointer. When the value in Pr is 15, it specifies b15.

Example: The following matrix is composed of the three 16-bit devices Y0, Y1, and Y2. The data in Y0 is 16#AAAA, the data in Y1 is 16#5555, and the data in Y2 is 16#A AFF.

b15	b14	b13	b12	b11	b10	b9	b8	b7	b6	b5	b4	b3	b2	b1	b0	
1	0	1	0	1	0	1	0	1	0	1	0	1	0	1	0	Y0
0	1	0	1	0	1	0	1	0	1	0	1	0	1	0	1	Y1
1	0	1	0	1	0	1	0	1	1	1	1	1	1	1	1	Y2

Example: The following matrix is composed of the three 16-bit devices X 0, X 1, and X 2. The data in X 0 is 16#37, the data in X 1 is 16#68, and the data in X 2 is 16#45.

b15	b14	b13	b12	b11	b10	b9	b8	b7	b6	b5	b4	b3	b2	b1	b0	
0	0	0	0	0	0	0	0	0	0	1	1	0	1	1	1	X0
0	0	0	0	0	0	0	0	0	1	1	0	1	0	0	0	X1
0	0	0	0	0	0	0	0	0	1	0	0	0	1	0	1	X2


API	Instruction code			Operand						Function					
0802	D	WOR	P	<b>S<sub>1</sub>, S<sub>2</sub>, D</b>						Logical OR operation					

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	“\$”	F
<b>S<sub>1</sub></b>	●	●			●	●	●	●	●		○	○	○	○		
<b>S<sub>2</sub></b>	●	●			●	●	●	●	●		○	○	○	○		
<b>D</b>		●			●	●	●	●			○	○				

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
<b>S<sub>1</sub></b>		●	●			●	●						
<b>S<sub>2</sub></b>		●	●			●	●						
<b>D</b>		●	●			●	●						

Pulse instruction	16-bit instruction	32-bit instruction
AS	AS	AS

**Symbol**




- S<sub>1</sub>** : Data source 1
- S<sub>2</sub>** : Data source 2
- D** : Operation result

**Explanation**

1. This instruction applies the logical operator OR to the binary representations in **S<sub>1</sub>** and **S<sub>2</sub>**. It performs the logical inclusive operation OR on each pair of corresponding bits, and stores the operation result in **D**.
2. Only the DOR instruction can use the 32-bit counter but not the device E.
3. The result in each position is 1 if the first bit is 1, the second bit is 1, or both bits are 1; otherwise, the result is 0.


**Example 1**

When X0.0 is ON, This instruction performs the logical inclusive operation OR on each pair of corresponding bits in the 16-bit device Y0 and the 16-bit device Y2. It stores the operation result in Y4.



**Example 2**

When X0.1 is ON, the instruction performs the logical inclusive operation OR on each pair of corresponding bits in the 32-bit device (Y11, Y10) and the 32-bit device (Y21, Y20). It stores the operation result in (Y41, Y40).




API	Instruction code			Operand							Function					
0803		MOR	P	<b>S<sub>1</sub>, S<sub>2</sub>, D, n</b>							Matrix OR operation					

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
S <sub>1</sub>	●	●			●	●		●	●							
S <sub>2</sub>	●	●			●	●		●	●							
D		●			●	●		●								
n	●	●			●	●		●	●				○	○		

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
S <sub>1</sub>		●				●							
S <sub>2</sub>		●				●							
D		●				●							
n		●				●							

Pulse instruction	16-bit instruction	32-bit instruction
AS	AS	-

**Symbol**





- S<sub>1</sub>** : Matrix source 1
- S<sub>2</sub>** : Matrix source 2
- D** : Operation result
- n** : Length of the array

**Explanation**

1. This instruction applies the logical operator OR to the **n** rows of binary representations in **S<sub>1</sub>** and the **n** rows of binary representations in **S<sub>2</sub>**. It performs the matrix operation OR on each pair of corresponding bits and stores the operation result in **D**.
2. The result in each position is 1 if the first bit is 1, the second bit is 1, or both bits are 1; otherwise, the result is 0.
3. The operand **n** must be between 1–256.

**Example**

When X0.0 is ON, the instruction performs the matrix operation OR on each pair of corresponding bits in the 16-bit devices Y0–Y2 and the data in 16-bit devices Y10–Y12. It stores the operation result in the 16-bit devices Y20–Y22.



**Additional remarks**

1. If  $S_1+n-1$ ,  $S_2+n-1$ , or  $D+n-1$  exceeds the device range, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2003.
2. If  $n$  is not between 1–256, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#200B.


API	Instruction code			Operand						Function					
0804	D	WXOR	P	<b>S<sub>1</sub>, S<sub>2</sub>, D</b>						Logical exclusive OR operation					

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
S <sub>1</sub>	●	●			●	●	●	●	●		○	○	○	○		
S <sub>2</sub>	●	●			●	●	●	●	●		○	○	○	○		
D		●			●	●	●	●			○	○				

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
S <sub>1</sub>		●	●			●	●						
S <sub>2</sub>		●	●			●	●						
D		●	●			●	●						

Pulse instruction	16-bit instruction	32-bit instruction
AS	AS	AS

**Symbol**




- S<sub>1</sub>** : Data source 1
- S<sub>2</sub>** : Data source 2
- D** : Operation result

**Explanation**

- This instruction applies the logical operator XOR to the binary representations in **S<sub>1</sub>** and **S<sub>2</sub>**. It performs the logical exclusive operation OR on each pair of corresponding bits, and stores the operation result in **D**.
- Only the DXOR instruction can use the 32-bit counter, but not the device E.
- The result in each position is 1 if the two bits are different, and 0 if they are the same.


**Example 1**

When X0.0 is ON, the instruction performs the exclusive operation OR on each pair of corresponding bits in the 16-bit device Y0 and the 16-bit device Y2. It stores the operation result in Y4.



**Example 2**

When X0.1 is ON, the instruction performs the logical exclusive operation OR on each pair of corresponding bits in the 32-bit device (Y11, Y10) and the 32-bit device (Y21, Y20). It stores the operation result in (Y41, Y40).




API	Instruction code			Operand						Function					
0805		MXOR	P	<b>S<sub>1</sub>, S<sub>2</sub>, D, n</b>						Matrix exclusive OR operation					

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
S <sub>1</sub>	●	●			●	●		●	●							
S <sub>2</sub>	●	●			●	●		●	●							
D		●			●	●		●								
n	●	●			●	●		●	●				○	○		

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
S <sub>1</sub>		●				●							
S <sub>2</sub>		●				●							
D		●				●							
n		●				●							

Pulse instruction	16-bit instruction	32-bit instruction
AS	AS	-

**Symbol**




- S<sub>1</sub> : Matrix source 1
- S<sub>2</sub> : Matrix source 2
- D : Operation result
- n : Length of the array

**Explanation**

1. This instruction applies the logical operator XOR to the **n** rows of binary representations in **S<sub>1</sub>** and the **n** rows of binary representations in of **S<sub>2</sub>**. It performs the matrix exclusive operation OR on each pair of corresponding bits and stores the operation result in **D**.
2. The result in each position is 1 if the two bits are different, and 0 if they are the same.
3. The operand **n** must be between 1–256.

**Example**

When X0.0 is ON, the instruction performs the matrix exclusive operation OR on each pair of corresponding bits in the 16-bit devices Y0–Y2 and the data in 16-bit devices Y10–Y12. It stores the operation result in the 16-bit devices Y20–Y22.



**Additional remarks**

1. If  $S_1+n-1$ ,  $S_2+n-1$ , or  $D+n-1$  exceeds the device range, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2003.
2. If  $n$  is not between 1–256, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#200B.


API	Instruction code			Operand							Function					
0808	D	WINV	P	S, D							Logical reversed INV operation					

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
S	●	●			●	●	●	●	●		○	○	○	○		
D	●	●			●	●	●	●			○	○				

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
S		●	●			●	●						
D		●	●			●	●						

Pulse instruction	16-bit instruction	32-bit instruction
AS	AS	AS

**Symbol**




**S** : Data source  
**D** : Operation result

**Explanation**

1. This instruction applies the INV instruction to the data in **S**, and stores the operation result in **D**.
2. Only the DINV instruction can use the 32-bit counter but not the device E.
3. This instruction performs reverse processing on the data in S. If the state of S is 0 before executing the INV instruction, the state changes to 1 as a result of the INV instruction.


**Example 1**

When X0.0 is ON, the instruction performs the INV operation on the corresponding bits in the 16-bit device Y0. It stores the operation result in the 16-bit device Y4.



**Example 2**

When X0.0 is ON, the instruction performs the INV operation on each pair of corresponding bits in the 32-bit devices Y11–Y10. It stores the operation result in the 32-bit device Y41–Y40.




API	Instruction code			Operand							Function						
0809- 0811	D	LD #		S <sub>1</sub> , S <sub>2</sub>							Contact type of logical operation LD #						

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
S <sub>1</sub>	●	●			●	●	●	●	●		○	○	○	○		
S <sub>2</sub>	●	●			●	●	●	●	●		○	○	○	○		

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
S <sub>1</sub>		●	●			●	●				●	●	
S <sub>2</sub>		●	●			●	●				●	●	

Pulse instruction	16-bit instruction	32-bit instruction
-	AS	AS

**Symbol**



S<sub>1</sub> : Data source 1

S<sub>2</sub> : Data source 2

Taking LD& and DLD& for example

**Explanation**


1. The instruction is used to compare the data in S<sub>1</sub> with that in S<sub>2</sub>. When the comparison result is not 0, the condition of the instruction is met. When the comparison result is 0, the condition of the instruction is not met.
2. Only the instruction DLD # can use the 32-bit counter but not the device E.
3. The instruction LD # can be connected to the mother line directly.

API No.	16-bit instruction	32-bit instruction	Comparison operation result	
			ON	OFF
0809	LD&	DLD&	S <sub>1</sub> &S <sub>2</sub> ≠ 0	S <sub>1</sub> &S <sub>2</sub> = 0
0810	LD	DLD	S <sub>1</sub>  S <sub>2</sub> ≠ 0	S <sub>1</sub>  S <sub>2</sub> = 0
0811	LD^	DLD^	S <sub>1</sub> ^S <sub>2</sub> ≠ 0	S <sub>1</sub> ^S <sub>2</sub> = 0

4. &: Logical AND operation
5. |: Logical OR operation
6. ^: Logical exclusive OR operation

**Example**

1. The logical operator AND takes the data in C0 and C1, and performs the logical AND operation on each pair of corresponding bits. When the operation result is not 0, Y1.0 is ON.
2. The instruction performs the logical operation OR on each pair of corresponding bits in D200 and D300, when the operation result is not 0 and X1.0 is ON, Y1.1 is ON.
3. The instruction performs logical exclusive operation XOR on each pair of corresponding bits in C201 and C200, when the operation result is not 0, or when X1.1 is ON, Y1.2 is ON.



**Additional remarks**

If S<sub>1</sub> or S<sub>2</sub> is illegal, the condition of the instruction is not met, SM0 is ON, and the error in SR0 is 16#2003.


API	Instruction code			Operand							Function						
0812- 0814	D	AND #		<b>S<sub>1</sub>, S<sub>2</sub></b>							Contact type of logical operation AND #						

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
<b>S<sub>1</sub></b>	●	●			●	●	●	●	●		○	○	○	○		
<b>S<sub>2</sub></b>	●	●			●	●	●	●	●		○	○	○	○		

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
<b>S<sub>1</sub></b>		●	●			●	●				●	●	
<b>S<sub>2</sub></b>		●	●			●	●				●	●	

Pulse instruction	16-bit instruction	32-bit instruction
-	AS	AS

**Symbol**



**S<sub>1</sub>** : Data source 1

**S<sub>2</sub>** : Data source 2

Taking AND& and DAND& for example

**Explanation**


1. This instruction compares the data in **S<sub>1</sub>** with that in **S<sub>2</sub>**. When the comparison result is not 0, the condition of the instruction is met. When the comparison result is 0, the condition of the instruction is not met.
2. Only the DAND # instruction can use the 32-bit counter, but not the device E.
3. Connect the AND # instruction and the contact in series.

API No.	16-bit instruction	32-bit instruction	Comparison operation result	
			ON	OFF
0812	AND&	DAND&	<b>S<sub>1</sub>&amp;S<sub>2</sub> ≠ 0</b>	<b>S<sub>1</sub>&amp;S<sub>2</sub> = 0</b>
0813	AND	DAND	<b>S<sub>1</sub> S ≠ 0</b>	<b>S<sub>1</sub> S<sub>2</sub> = 0</b>
0814	AND^	DAND^	<b>S<sub>1</sub>^S<sub>2</sub> ≠ 0</b>	<b>S<sub>1</sub>^S = 0</b>

4. &: Logical AND operation
5. |: Logical OR operation
6. ^: Logical exclusive OR operation

**Example**

1. When X0.0 is ON, the instruction performs the logical operation AND on each pair of corresponding bits in C0 and C10. When the operation result is not 0, Y1.0 is ON.
2. When X0.1 is OFF, the instruction performs the logical operation OR on each pair of corresponding bits in D10 and D0. When the operation result is not 0, Y1.1 is ON.
3. When X0.2 is ON, the instruction performs the logical exclusive operation OR on each pair of corresponding bits in the 32-bit register (D200, D201) and the data in the 32-bit register (D100, D101). When the operation result is not 0, or when X0.3 is ON, Y1.2 is ON.



**Additional remarks**

If the value in **S<sub>1</sub>** or **S<sub>2</sub>** is not valid, the condition of the instruction is not met, SM0 is ON, and the error in SR0 is 16#2003.


API	Instruction code			Operand						Function					
0815- 0817	D	OR #		<b>S<sub>1</sub>, S<sub>2</sub></b>						Contact type of logical operation OR #					

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
<b>S<sub>1</sub></b>	●	●			●	●	●	●	●		○	○	○	○		
<b>S<sub>2</sub></b>	●	●			●	●	●	●	●		○	○	○	○		

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
<b>S<sub>1</sub></b>		●	●			●	●				●	●	
<b>S<sub>2</sub></b>		●	●			●	●				●	●	

Pulse instruction	16-bit instruction	32-bit instruction
-	AS	AS

**Symbol**



**S<sub>1</sub>** : Data source 1

**S<sub>2</sub>** : Data source 2

Taking OR& and DOR& for example

**Explanation**


1. This instruction compares the data in **S<sub>1</sub>** with that in **S<sub>2</sub>**. When the comparison result is not 0, the condition of the instruction is met. When the comparison result is 0, the condition of the instruction is not met.
2. Only the DOR # instruction can use the 32-bit counter.
3. Connect the OR # instruction and the contact in parallel.

API No.	16-bit instruction	32-bit instruction	Comparison operation result	
			ON	OFF
0815	OR&	DOR&	<b>S<sub>1</sub>&amp;S<sub>2</sub> ≠ 0</b>	<b>S<sub>1</sub>&amp;S<sub>2</sub> = 0</b>
0816	OR	DOR	<b>S<sub>1</sub> S<sub>2</sub> ≠ 0</b>	<b>S<sub>1</sub> S<sub>2</sub> = 0</b>
0817	OR^	DOR^	<b>S<sub>1</sub>^S<sub>2</sub> ≠ 0</b>	<b>S<sub>1</sub>^S<sub>2</sub> = 0</b>

4. &: Logical AND operation
5. |: Logical OR operation
6. ^: Logical exclusive OR operation

**Example**

1. When X0.1 is ON, Y0.0 is ON. The instruction performs the logical operation AND on each pair of corresponding bits in C0 and C10. When the operation result is not 0, Y0.0 is ON.
2. When X0.2 and X0.3 are ON, Y0.1 is ON. The instruction performs the logical operation OR on each pair of corresponding bits in the 32-bit register (D10, D11) and the 32-bit register (D20, D21). When the operation result is not 0, Y0.1 is ON. The instruction performs the logical exclusive operation OR on each pair of corresponding bits in the 32-bit counter HCO and the 32-bit register (D200, D201). When the operation result is not 0, Y0.1 is ON.



**Additional remarks**

If the value in S<sub>1</sub> or S<sub>2</sub> is not valid, the condition of the instruction is not met, SM0 is ON, and the error in SR0 is 16#2003.

## 6.10 Rotation Instructions

### 6.10.1 List of Rotation Instructions

The following table lists the Rotation instructions covered in this section.

API	Instruction code		Pulse instruction	Function
	16-bit	32-bit		
<b><u>0900</u></b>	ROR	DROR	✓	Rotating bits in a group to the right
<b><u>0901</u></b>	RCR	DRCR	✓	Rotating bits in a group to the right with the carry flag
<b><u>0902</u></b>	ROL	DROL	✓	Rotating bits in a group to the left
<b><u>0903</u></b>	RCL	DRCL	✓	Rotating bits in a group to the left with the carry flag
<b><u>0904</u></b>	MBR	–	✓	Rotating bits to the right or left in a matrix

### 6.10.2 Explanation of Rotation Instructions


API	Instruction code			Operand							Function				
0900	D	ROR	P	D, n							Rotating bits in a group to the right				

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	“\$”	F
D		●			●	●	●	●			○	○				
n	●	●			●	●	●	●	●		○	○	○	○		

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
D		●	●			●	●						
n		●	●			●	●						

Pulse instruction	16-bit instruction	32-bit instruction
AS	AS	AS

**Symbol**




**D** : Device to rotate  
**n** : Number of bits in a group

**Explanation**

1. This instruction divides the bits in the device specified by **D** into groups (**n** bits in a group), and then rotates these groups to the right without the carry flag.
2. Only the DROR instruction can use the 32-bit counter, but not the device E.
3. For the 16-bit instruction, the value of **n** used must be between 1–6. For the 32-bit instruction, the value of **n** must be between 1–32. When **n** is less than 0, the instruction is not executed. When **n** exceeds the range, the instruction is executed with **n** at the maximum value (32) of the range.
4. In general, the RORP and DRORP pulse instructions are used.

**Example**

When X0.0 switches from OFF to ON, the instruction divides the values of the bits in D10 into groups (four bits in a group), and rotates these groups to the right. The value of the bit marked ※ is transmitted to the carry flag SM602.

**Additional remarks**

1. If the device exceeds the range, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2003.


API	Instruction code			Operand							Function				
0901	D	RCR	P	D, n							Rotating bits in a group to the right with the carry flag				

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
D		●			●	●	●	●			○	○				
n	●	●			●	●	●	●	●		○	○	○	○		

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
D		●	●			●	●						
n		●	●			●	●						

Pulse instruction	16-bit instruction	32-bit instruction
AS	AS	AS

**Symbol**




**D** : Device to rotate  
**n** : Number of bits in a group

**Explanation**

1. This instruction divides the bits in the device specified by **D** into groups (**n** bits in a group), and then rotates these groups to the right with the carry flag SM602.
2. Only the DRCCR instruction can use the 32-bit counter, but not the device E.
3. For 16-bit instructions, the value of **n** used must be between 1–16. For 32-bit instructions, the value of **n** must be between 1–32. When **n** is less than 0, the instruction is not executed. When **n** exceeds the range, the instruction is executed with **n** at the maximum value (32) of the range.
4. In general, the RCRP and DRCRP pulse instructions are used.

**Example**

When X0.0 switches from OFF to ON, the instruction divides the values of the bits in D10 into groups (four bits as a group), and then rotates these groups to the right with the carry flag SM602. The value of the bit marked ※ is transmitted to the carry flag SM602.



**Additional remarks**

1. If the device exceeds the range, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2003.


API	Instruction code			Operand							Function					
0902	D	ROL	P	D, n							Rotating bits in a group to the left					

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
D		●			●	●	●	●			○	○				
n	●	●			●	●	●	●	●		○	○	○	○		

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
D		●	●			●	●						
n		●	●			●	●						

Pulse instruction	16-bit instruction	32-bit instruction
AS	AS	AS

**Symbol**




**D** : Device to rotate  
**n** : Number of bits in a group

**Explanation**

1. This instruction divides the bits in the device specified by **D** into groups (**n** bits in a group), and then rotates these groups to the left.
2. Only the DROL instruction can use the 32-bit counter, but not the device E.
3. For 16-bit instructions, the value of **n** must be between 1–16. For 32-bit instructions, the value of **n** must be between 1–32. When **n** is less than 0, the instruction is not executed. When **n** exceeds the range, the instruction is executed with **n** at the maximum value (32) of the range.
4. In general, the ROLP and DROLP pulse instructions are used.

**Example**

When X0.0 switches from OFF to ON, the instruction divides the values of the bits in D10 into groups (four bits as a group), and then rotates these groups to the left. The value of the bit marked ※ is transmitted to the carry flag SM602.

**Additional remarks**

1. If the device exceeds the range, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2003.


API	Instruction code			Operand							Function				
0903	D	RCL	P	D, n							Rotating bits in a group to the left with the carry flag				

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
D		●			●	●	●	●			○	○				
n	●	●			●	●	●	●	●		○	○	○	○		

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
D		●	●			●	●						
n		●	●			●	●						

Pulse instruction	16-bit instruction	32-bit instruction
AS	AS	AS

**Symbol**




**D** : Device to rotate  
**n** : Number of bits in a group

**Explanation**

1. This instruction divides the bits in the device specified by **D** into groups (**n** bits in a group) , and then rotates these groups to the left with the carry flag SM602.
2. Only the DRCL instruction can use the 32-bit counter, but not the device E.
3. For 16-bit instructions, the value in **n** must be between 1–16. For 32-bit instructions, the value of **n** must be between 1–32. When **n** is less than 0, the instruction is not executed. When **n** exceeds the range, the instruction is executed with **n** at the maximum value (32) of the range.
4. In general, the RCLP and DRCLP pulse instructions are used.

**Example**

When X0.0 switches from OFF to ON, the instruction divides the values of the bits in D10 into groups (four bits as a group), and then rotates these groups to the left with the carry flag SM602. The value of the bit marked ※ is transmitted to the carry flag SM602.

**Additional remarks**

1. If the device exceeds the range, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2003.


API	Instruction code			Operand							Function				
0904		MBR	P	S, D, n							Rotating bits in a group to the right or the left in a matrix				

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
S	●	●			●	●		●	●							
D		●			●	●		●								
n	●	●			●	●		●	●				○	○		

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
S		●				●							
D		●				●							
n		●				●							

Pulse instruction	16-bit instruction	32-bit instruction
AS	AS	-

**Symbol**




- S** : Matrix source
- D** : Operation result
- n** : Length of the array

**Explanation**

1. This instruction rotates the values of **n** rows of bits in **S** to the right or to the left. When SM616 is OFF, the instruction rotates the values of the bits to the left. When SM616 is ON, the instruction rotates the values of the bits to the right. The instruction fills the vacancy resulting from the rotation with the value of the bit rotated last, and stores the operation result in **D**. The value of the bit rotated last not only fills the vacancy, but also is transmitted to the carry flag SM614.
2. For 16-bit instructions, the value of **n** must be between 1–16. For 32-bit instructions, the value of **n** must be between 1–32. When **n** is less than 0, the instruction is not executed. When **n** exceeds the range, the instruction is executed with **n** at the maximum value (32) of the range.
3. In general, the MBRP pulse instruction is used.


**Example 1:**

When X0.0 is ON and SM616 is OFF, the instruction rotates the values of the bits in the 16-bit registers D0–D2 to the left, and stores the operation result in the 16-bit registers D20–D22. The value of the bit marked ※ is transmitted to the carry flag SM614.



**Example 2:**

When X0.0 is ON and SM616 is ON, the instruction rotates the values of the bits in the 16-bit registers D0–D2 to the right, and stores the operation result in the 16-bit registers D20–D22. The value of the bit marked ※ is transmitted to the carry flag SM614.





## 6.11 Timer and Counter Instructions

### 6.11.1 List of Timer and Counter Instructions

The following table lists the Timer and Counter instructions covered in this section.

API	Instruction code		Pulse instruction	Function
	16-bit	32-bit		
<b><u>1000</u></b>	RST	DRST	–	Resetting a contact to OFF or clearing the value in a register.
<b><u>1001</u></b>	TMR	–	–	16-bit timer (Unit: 100ms)
<b><u>1002</u></b>	TMRH	–	–	16-bit timer (Unit: 1ms)
<b><u>1003</u></b>	CNT	–	–	16-bit counter
<b><u>1004</u></b>	–	DCNT	–	32-bit counter (including the use of high-speed counters)
<b><u>1005</u></b>	–	DHSCS	–	Setting high-speed comparison
<b><u>1006</u></b>	–	DHSCR	–	Resetting high-speed comparison
<b><u>1007</u></b>	–	DHSZ	–	High-speed input zone comparison
<b><u>1008</u></b>	–	DSPD	–	Detecting speed
<b><u>1009</u></b>	PWD	–	–	Detecting pulse width
<b><u>1010</u></b>	–	DCAP	–	Capturing the high-speed count value in an external input interrupt
<b><u>1011</u></b>	TMRM	–	–	16-bit timer (Unit: 10ms)
<b><u>1012</u></b>	IETS	–	✓	The start of the instruction execution time measurement
<b><u>1013</u></b>	IETE	–	✓	The end of the instruction execution time measurement
<b><u>1014</u></b>	–	DHSCY	–	Cyclic counting, comparing and outputting
<b><u>1015</u></b>	PPDT	–	–	Detecting the time difference between two phases
<b><u>1016</u></b>	ATMR	–	–	16-bit contact timer (Unit: 100 ms)
<b><u>1017</u></b>	ATMRH	–	–	16-bit contact timer (Unit: 1 ms)
<b><u>1018</u></b>	ATMRM	–	–	16-bit contact timer (Unit: 10 ms)

### 6.11.2 Explanation of Timer and Counter Instructions


API	Instruction code		Operand										Function			
1000	D	RST	D										Resetting a contact or clearing a register			

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
D		○	○	○	○	○	○	○		○	○	○				

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
S	●	●	●			●	●		●		●	●	

Pulse instruction	16-bit instruction	32-bit instruction
-	AS	AS

**Symbol**



**6 Explanation**

1. This instruction clears the values in a 32-bit HC device or two consecutive 16-bit **D** devices. For other devices, use the RST instruction to clear the values.
2. The following table shows the actions of the RST instruction.

Device	State
Bit	Sets the coil and contact to OFF.
T · C	Set the current timer value and counter value to 0, and sets the coil and contact to OFF.
Word	Clears the 16-bit content value to 0.
DWord · HC · Real	Clears the 32-bit content value, including floating point numbers, to 0.


3. If the RST instruction is not executed, the state of the device specified by **D** is unchanged.
4. The instruction supports direct output.

**Example**

When X0.0 is ON, the instruction sets Y0.5 to OFF.



The instruction clears the 32-bit D1 and D0 to zero when X0.0 is ON.




API	Instruction code			Operand								Function					
1001		TMR		S <sub>1</sub> , S <sub>2</sub>								16-bit timer (100ms)					

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
S <sub>1</sub>					○											
S <sub>2</sub>								○				○	○	○		

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
S <sub>1</sub>											●		
S <sub>2</sub>		●				●							

Pulse instruction	16-bit instruction	32-bit instruction
-	AS	-

Symbol



- S<sub>1</sub> : Timer number
- S<sub>2</sub> : Setting value of the timer

Explanation

Refer to the explanation of the TMRH instruction (API 1002) for details.

API	Instruction code				Operand								Function			
1002		TMRH			<b>S<sub>1</sub>, S<sub>2</sub></b>								16-bit timer (1ms)			
Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
<b>S<sub>1</sub></b>					○											
<b>S<sub>2</sub></b>								○				○	○	○		

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
<b>S<sub>1</sub></b>											●		
<b>S<sub>2</sub></b>		●				●							

Pulse instruction	16-bit instruction	32-bit instruction
-	AS	-

### Symbol

	<b>TMRH</b>
<b>En</b>	
<b>S<sub>1</sub></b>	
<b>S<sub>2</sub></b>	

**S<sub>1</sub>** : Timer number

**S<sub>2</sub>** : Setting value for the timer

### Explanation

- The TMR instruction uses 100ms as the timing unit in the timer, while, the TMRH instruction uses 1ms as the timing unit in the timer.
- The value of **S<sub>2</sub>** for both the TMR and TMRH instructions is between 0–32767.
- If you use the same timer repeatedly in the program, including using it in different TMR and TMRH instructions, the timer that completes the measurement first will be the only one that counts.
- The T timer resets to zero automatically when the conditional contact changes from ON to OFF.
- When you add the letter S in front of the device T, the timer in the instruction TMR is an accumulative timer. When the conditional contact is OFF, the value of the accumulative timer is not cleared. When the conditional contact is ON, the timer counts from the current value. Use the RST instruction with the ST accumulative timer when you want to clear the value of the timer.
- If you use the same T timer in the program, it is OFF when one of the conditional contacts is OFF.
- If you use the same T timer for T and ST in the program, T is OFF when one of the conditional contacts is OFF.
- When the instruction TMR is executed, the specified timer coil is ON and the timer begins to count. As the value of the timer matches the setting value, the contact is ON.

9. The timers T0–T411 are defined as general timers, and T412–T511 are subroutine timers by default. Use the hardware configuration software HWCONFIG if you need to change the ranges of the two types of timers.
10. The general timers compare the timing values when the TMR instruction is scanned. The system applies the timer to the condition every time the TMR instruction status is scanned.

For the subroutine timers, the system counts the time and compares the timing values after the END instruction is executed. Use subroutine timers when the TMR instruction is executed not in every scan, but you need longer lasting timing and comparing.

**Example 1** (using general type of counter; counts for 100 ms time window)

When X0.0 is ON, the instruction loads the setting value 50 to the timer T0, and T0 counts from 0 to 50. When the value of T0 matches 50, the contact of T0 is ON.



**Example 2** (using accumulative type of counter; counts for 100 ms time window)

When X0.0 is ON, the instruction loads the setting value 50 to the timer ST0. When the value of T0 is 25 and X0.0 switches from OFF to ON, then T0 counts up from 25 to 50, and the contact of T0 is ON (accumulative).



**Example 3** (using general type of counter; counts for 1 ms time window)

When X0.0 is ON, the instruction loads the setting value 1000 to the timer T5, and T5 counts up from 0 to 1000, and the contact of T5 is ON.



**Example 4** (using accumulative type of counter; counts for 1 ms time window)

When X0.0 is ON, the instruction loads the setting value 1000 to the timer T5. When the value of T5 is 500 and X0.0 switches from OFF to ON, T5 counts up from 500 to 1000, and the contact of T5 is ON (accumulative).




**Example 5** (using a function block in TMRH instruction)


Step 1: Declare the function block as T\_Pointer.



This function block clears the value in D0 every 5 seconds.



Step 2: Appoint T\_Pointer as T0 in the program of unit (POU).



**Additional remarks**

When you declare the operand **S1** in ISPSOft, select the data type TIMER for the general T timer. For an accumulative ST timer, specify the ST device.


API	Instruction code			Operand								Function				
1003		CNT		S <sub>1</sub> , S <sub>2</sub>								16-bit counter				

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
S <sub>1</sub>						○										
S <sub>2</sub>								○				○	○	○		

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
S <sub>1</sub>												●	
S <sub>2</sub>		●				●							

Pulse instruction	16-bit instruction	32-bit instruction
-	AS	-

Symbol



- S<sub>1</sub> : Counter number
- S<sub>2</sub> : Setting value for the counter

Explanation

1. This instruction changes a specified counter coil from OFF to ON, and then increments the value of the counter by 1. When the value of the counter matches the setting value, the contact of the counter is ON.
2. When the value of the counter matches the setting value, the instruction does not change the state of the contact and value of the counter if any more counting pulses are input. Use the RST instruction (API 1000) to reset the counter and enable counting again.
3. Refer to Example 1 below for a demonstration of using CNT instruction in a program of unit (POU). Refer to Example 2 below for a demonstration of using CNT instruction in a function block (FB).
4. You can use the same device C number of CNT instruction that used in a POU for more than once. The system will count according to different contact status, OFF or ON separately.
5. You can NOT use the same device C number of CNT instruction that used in a FB for more than once. It is suggested to use only 1 device C number for FW V1.07.00 (excluded) or prevision versions. For FW V1.07 or later version, you can use up to 8 identical device C number of CNT instruction that used in a FB.


**Example 1** (using CNT instruction in a POU)

When SM408 is ON for the first time, the instruction loads the setting value 10 to the counter C0 and the counter begins counting. After SM408 switches from OFF to ON ten times, the value in C0 is 10 and the contact of C0 is ON. After C0 is ON, if SM408 continues to switch from OFF to ON, the instruction does not increase the value in C0 after it reaches the setting value for C0.




**Example 2** (using a function block in CNT instruction)


Step 1: Declare the function block as C\_Pointer.



This function block



Step 2: Appoint C\_Pointer as C0 and C1 in a program of unit (POU).



**Additional remarks**

When you declare the operand **S1** in ISPSOft, select the data type COUNTER.


API	Instruction code			Operand							Function						
1004		DCNT		<b>S<sub>1</sub>, S<sub>2</sub></b>							32-bit counter						

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	“\$”	F
<b>S<sub>1</sub></b>							○									
<b>S<sub>2</sub></b>								○					○	○		

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
<b>S<sub>1</sub></b>													
<b>S<sub>2</sub></b>			●				●						

Pulse instruction	16-bit instruction	32-bit instruction
-	-	AS

**Symbol**



**S<sub>1</sub>** : Counter value  
**S<sub>2</sub>** : Setting value for the counter

**Explanation**

1. This instruction enables the 32-bit counter between HC0–HC255.
2. If you declare the operand **S<sub>1</sub>** in ISPSOft, you cannot select the CNT data type; instead, specify an HC device number.
3. For the count-up/count-down counters HC0–HC63, when the conditional contact of this instruction switches from OFF to ON, the counters count up by incrementing the values by 1 when SM621–SM684 are OFF or count down by decrementing the values by 1 when SM621–SM684 are ON.
4. Count-up counters HC64–HC199 count up by increasing the values by 1 when the conditional contact of the DCNT instruction switches from OFF to ON.
5. The counter stops counting when the DCNT instruction is OFF, but the instruction does not clear the original count value. Use the RST instruction to clear the count value and reset the contact to OFF.
6. Refer to Example 2 of CNT instruction for a demonstration of using DCNT instruction in a function block (FB).
7. Refer to the following pages for details on the high-speed counter HC200–HC255. Whenever PLC scans this instruction, it refreshes the appointed counter for its updated values. Thus it is suggested to use this instruction in a POU. NOTE: The number of the high-speed can NOT be duplicated.

8. Since AS Series PLC is with various built-in input types, different maximum input frequency are suggested. See the table below for reference. It is possible that the maximum input frequency cannot be reached for the sinking and sourcing type. If the output type is normally open (NO) and the drive current is insufficient. Refer to Chapter 4 from AS Series Hardware and Operation Manual for more information on wiring.

Model Name	Input Type	Input Number	Maximum Input Frequency
AS324MT-A	Differential	X0.0 ~ X0.3	4M Hz
	Sinking / Sourcing	X0.4 ~ X0.11	200K Hz
AS332T-A AS332P-A	Sinking / Sourcing	X0.0 ~ X0.11	200K Hz
		X0.12 ~ X0.15	10K Hz
AS320T-B AS320P-B	Sinking / Sourcing	X0.0 ~ X0.7	200K Hz
AS300N-A		No built-in inputs	
AS228T-A AS228P-A AS228R-A	Sinking / Sourcing	X0.0 ~ X0.7	200K Hz
		X0.8 ~ X0.15	10K Hz
AS218TX-A AS218PX-A AS218RX-A	Sinking / Sourcing	X0.0 ~ X0.7	200K Hz
AS132T-A AS132P-A AS132R-A AS148T-A AS148P-A AS148R-A AS164T-A AS164P-A AS164R-A	Sinking / Sourcing	X0.0 ~ X0.7	200KHz
		X0.8 ~ X0.15	10KHz

**Example 1**

NETWORK1:

When PLC runs, the value of the counter HC0 is cleared and the counter counts because SM621 is OFF. At this time, SM408 is ON for the first time. So the instruction loads the setting value 10 to the counter HC0 and the counter begins counting.


NETWORK2:

After SM408 switches from OFF to ON ten times, the value of the counter HC0 matches the setting value 10, and the contact of HC0 is ON. After HC0 is ON, the value of the counter keeps increasing because SM408 continues to change from OFF to ON even though the value of HC0 has reached the setting value.

NETWORK3:

When HC0 continues to count up and the value reaches the setting value 20, the counter counts down because SM621 is ON in the program. After SM408 switches from OFF to ON ten times and the value of HC0 decreases from 10 to 9, the contact of HC0 is OFF.

After the contact of HC0 is OFF, the value of HC0 still continues to decrease because SM408 continues to change from OFF to ON.



**Additional remarks**

For setting the mode of SM621–SM684, refer to the explanation of the 32-bit counter HC in Chapter 2.


**Example 2**

NETWORK1:

When PLC runs, set the value of the counter HC202 to four time frequency (mode setting should be set before executing the DCNT instruction). And then the value of the counter HC202 is cleared.

NETWORK2:

After the value of the counter HC202 reached the setting value 1000, the contact of HC202 is ON.

**Explanation of the high-speed counter:**

AS Series high-speed counters can be divided into hardware counters (up to a maximum of 200KHz input, and for differential input points up to 4MHz) and software counters (up to a maximum of 10KHz). Refer to hardware specification for more details on the input limit.

Hardware counter

Input HC No.	X0.															
	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15
HC200	P#1												R#4			
HC201	P	D#1											R			
HC202	A#1	B#1											R			
HC203	--#2	--											--			
HC204			P											R		
HC205			P	D										R		
HC206			A	B										R		
HC207			--	--										--		
HC208					P										R	
HC209					P	D									R	
HC210					A	B									R	
HC211					--	--									--	
HC212							P									R
HC213							P	D								R
HC214							A	B								R
HC215							--	--								--
HC216									P							
HC217									P	D						
HC218									A	B						
HC219									--	--						
HC220											P					
HC221											P	D				
HC222											A	B				
HC223											--	--				

Note 1: P: single-phase pulse input, D: Direction signal input, A and B: two phase two input, R: Reset signal input. Only one out of four input modes can be used in PLC programming. For example, if HC200 is edited, the HC20-HC203 can no longer be edited.

Note 2: -- indicates that the counting mode is reserved and not available now. An empty box indicates no function.

Note3: refer to the SM/SR table for count up/down state selection and the number of times for frequency input.

Note 4: the R function (reset input) is disabled by default. Refer to the SM/SR comparison table for how to use R.

Take HC200 for example. SM291 switches to ON to start the R function and then the rising edge of X0.12 triggers clearing the value of HC200. If there is no built-in input points, including X0.12 ~ X0.15, in the PLC you are using, you can use external interrupts or use counter eraser instructions to clear the counters.

**Software counter:**

Input HC No.	X0.															
	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15
HC232													P			
HC233													P	D		
HC234													A	B		
HC235													UP#5	DN#5		
HC236															P	
HC237															P	D
HC238															A	B
HC239															UP	DN
HC240		P														
HC241	UP	DN														
HC242				P												
HC243			UP	DN												
HC244						P										
HC245					UP	DN										
HC246								P								
HC247							UP	DN								
HC248										P						
HC249								UP	DN							
HC250												P				
HC251											UP	DN				
HC252														P		
HC253																P

Note 5: UP: single phase count-up input (same as CW), DN: single phase count-down input (same as CCW)

The high-speed counters between HC200–HC255, are reserved devices inside PLC and are not listed in this table. It is not recommended to use these counters in a program. If there is no built-in input points, including X0.12 ~ X0.15, in the PLC you are using, do NOT use their corresponding counters.

The following table lists the high-speed counter, function, reset, reversing, and counting mode.

HC No.	Count-up/count-down function			Starting the Reset function	Reversing the direction	Counting mode
	SM No.	Attribute	Explanation	SM No.	SM No.	SR No.
HC200	SM300	R/W	Show/ set	SM291	SM281 (Applicable for HC201, HC202 <sup>#7</sup> )	SR190
HC201	SM301	R	Show			
HC202	SM302	R	Show			
HC204	SM304	R/W	Show/ set	SM292	SM282 (Applicable for HC205, HC206 <sup>#7</sup> )	SR191
HC205	SM305	R	Show			
HC206	SM306	R	Show			
HC208	SM308	R/W	Show/ set	SM293	SM283 (Applicable for HC209, HC210 <sup>#7</sup> )	SR192
HC209	SM309	R	Show			
HC210	SM310	R	Show			
HC212	SM312	R/W	Show/ set	SM294	SM284 (Applicable for HC213, HC214 <sup>#7</sup> )	SR193
HC213	SM313	R	Show			
HC214	SM314	R	Show			
HC216	SM316	R/W	Show/ set	--	SM285 (Applicable for HC217, HC218 <sup>#7</sup> )	SR194
HC217	SM317	R	Show			
HC218	SM318	R	Show			
HC220	SM320	R/W	Show/ set	--	SM286 (Applicable for HC221, HC222 <sup>#7</sup> )	SR195
HC221	SM321	R	Show			
HC222	SM322	R	Show			
HC232	SM332	R/W	Show/ set	--	SM287 (Applicable for HC233, HC234 <sup>#7</sup> )	SR196
HC233	SM333	R	Show			
HC234	SM334	R	Show			
HC235	SM335	R	Show	--	SM288 (Applicable for HC237, HC238 <sup>#7</sup> )	SR197
HC236	SM336	R/W	Show/ set			
HC237	SM337	R	Show			
HC238	SM338	R	Show	--	--	Supports one time frequency and rising edge – triggered counting only
HC239	SM339	R	Show			
HC240	SM340	R/W	Show/ set			
HC241	SM341	R	Show	--	--	Supports one time frequency and rising edge – triggered
HC242	SM342	R/W	Show/ set			
HC243	SM343	R	Show			
HC244	SM344	R/W	Show/ set	--	--	Supports one time frequency and rising edge – triggered
HC245	SM345	R	Show			
HC246	SM346	R/W	Show/ set	--	--	Supports one time frequency and rising edge – triggered

HC No.	Count-up/count-down function			Starting the Reset function	Reversing the direction	Counting mode
	SM No.	Attribute	Explanation	SM No.	SM No.	SR No.
						counting only
HC247	SM347	R	Show	--	--	Supports one time frequency and rising edge – triggered counting only
HC248	SM348	R/W	Show/ set			
HC249	SM349	R	Show			
HC250	SM350	R/W	Show/ set			
HC251	SM351	R	Show			
HC252	SM352	R/W	Show/ set			
HC253	SM353	R	Show			

Note 1: All SM special flags in the above table are OFF by default.

Note 2: When SM under “Count-up/count-down function” is OFF, it indicates that the corresponding counter counts up or displays that it is counting up. If SM is ON, it indicates that the corresponding counter counts down or displays that it is counting down.

Note 3: The “ under Attribute indicates “Read only” and R/W indicates “Read/Write”.

Note 4: The SR special registers under “Counting mode” are 1 time frequency input by default. Use 2 for the input value for double frequency and 4 for four times frequency. Four times frequency is only applicable to the A/B 2-phase input counter. If the input value is not 1, 2 or 4 in SR, this indicates that the PLC uses one times frequency.

Note 5: All single-phase counters in the table count using one times frequency, and the rising-edge counting mode changes the input point from OFF to ON.

Note 6: P (Pulse input) and D (Direction) counters can reverse direction. When SM is ON, the counting direction (up/down) is reversed. For example, when the preset direction input is OFF, the counter counts up. When SM switches to ON, the counter changes to count down.

Note 7: Available for FW V1.08 or later.


API	Instruction code			Operand						Function					
1005	D	HSCS		<b>S<sub>1</sub>, S<sub>2</sub>, D</b>						Setting high-speed comparison					

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
<b>S<sub>1</sub></b>							○									
<b>S<sub>2</sub></b>								●					○	○		
<b>D</b>		○	○	○				○								

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
<b>S<sub>1</sub></b>												●	
<b>S<sub>2</sub></b>			●				●						
<b>D</b>	●												

Pulse instruction	16-bit instruction	32-bit instruction
-	-	AS

**Symbol**



- S<sub>1</sub>** : Counter number
- S<sub>2</sub>** : Comparative value
- D** : Comparison result

**6**

**Explanation**

- Use this instruction with high-speed counters with numbers HC200 and above. If the value in the high-speed counter specified by **S<sub>1</sub>** changes by increasing or decreasing by 1, the DHSCS instruction makes the comparison immediately. When the current value of the high-speed counter is equal to the comparative value specified in **S<sub>2</sub>**, the device specified by **D** changes to ON. After that, the device specified by **D** remains ON even if the comparison result is that the current value and the comparative value are not equal.
- If the device specified by **D** is Y0.0–Y0.15, and the value of **S<sub>2</sub>** is equal to the current value, the comparison result of the high-speed counter is output to the output terminals Y0.0–Y0.15. Other Y devices are affected by the scan cycle, but this instruction updates all devices immediately and is not affected by the scan cycle. For PLC with FW V1.06.00 (V1.06.00 included) or later versions, devices Y0.12 ~ Y0.15 are affected by the scan cycle.
- The **D** operand can also specify an I interrupt device between 1200–1267.
- The high-speed counters are divided into software counters and hardware counters. The available high-speed comparators and interrupt device numbers are listed in the following table.


Type	Range of counter numbers	High-speed comparator number	High-speed interrupt device number
Hardware counter	HC200 - HC203	Comparator: HCC00-HCC03	I200-I203
	HC204 - HC207	Comparator: HCC04-HCC07	I210-I213
	HC208 - HC211	Comparator: HCC08-HCC11	I220-I223
	HC212 - HC215	Comparator: HCC12-HCC15	I230-I233
	HC216 - HC219	Comparator: HCC16-HCC19	I240-I243
	HC220 - HC223	Comparator: HCC20-HC223	I250-I253
Software counter	HC232 - HC253	-	I260-I267

5. Explanation of the hardware comparators for DHSCS, DHSCR, DHSCY and DHSZ instructions:
  - Every one group of hardware counters shares 4 high-speed comparators. One DHSCS, or DHSCR instruction occupies 1 high-speed comparator. One DHSZ, DHSCY instruction uses 2 high-speed comparators.
  - During program editing, every group of hardware counters can use 4 high-speed comparators at most for DHSCS, DHSCR, DHSCY or DHSZ instructions; otherwise, a syntax error occurs.
6. Explanation of the software comparators for DHSCS, DHSCR and DHSCY instructions:
  - There are 8 software comparators to compare the Set or Reset function. Each DHSCS, DHSCR or DHSCY instruction uses one high-speed comparator.
  - The software comparators compare the interrupt by assigning a corresponding software comparator according to the interrupt numbers. Note that the same interrupt number cannot be used repeatedly.
  - For DHSCS, DHSCR or DHSCY instructions, the number of Set or Reset comparators cannot exceed eight occurrences in the program; otherwise, a syntax error occurs.
7. Explanation of the software comparators for DHSZ instruction:
  - There are eight software comparators for the zone comparison. One DHSZ instruction uses one comparator.
  - DHSZ instruction can use a maximum of eight software comparators; otherwise, a syntax error occurs if more than eight comparators are used.
8. The instructions DHSCS, DHSCR, DHSCY and DHSZ cannot be used in the ST programming language, interrupt tasks or function block which is called only once.

**Example 1**

When M0 is ON, the DHSCS instruction is executed.


When the current value of HC200 changes from 99 to 100 or from 101 to 100, Y0.10 is ON, which outputs to the external output terminal Y0.10 in real time, and remains ON.



**Example 2**

The Y output of DHSCS instruction is different from the general Y output.

1. When M0 is ON, the DHSCS instruction is executed. When the current value of HC200 changes from 99 to 100 or from 101 to 100, Y0.10 outputs its state to the external output terminal immediately, and is not affected by the program scan time.
2. When the current value of HC200 changes from 99 to 100, the contact of HC200 is ON immediately. When SET Y0.11 is executed, Y0.11 is still affected by the scan time, and outputs its state only after END is passed.




6

**Example 3**

Using an interrupt in hardware high-speed comparison.

When the current value of HC200 changes from 99 to 100 or 101 to 100, the program jumps to the interrupt pointer to execute the interrupt program, and Y0.10 is ON.

Main program:



I200 interrupt program:




API	Instruction code			Operand					Function				
1006	D	HSCR		<b>S<sub>1</sub>, S<sub>2</sub>, D</b>					Resetting high-speed input comparison				

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
<b>S<sub>1</sub></b>							○									
<b>S<sub>2</sub></b>								●					○	○		
<b>D</b>		○	○	○			○	○								

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
<b>S<sub>1</sub></b>												●	
<b>S<sub>2</sub></b>			●				●						
<b>D</b>	●												

Pulse instruction	16-bit instruction	32-bit instruction
-	-	AS

**Symbol**



- S<sub>1</sub>** : Counter number
- S<sub>2</sub>** : Comparative value
- D** : Comparison result


**6**

**Explanation**

- Use this instruction with the high-speed counter numbered HC200 and above. If the value in the high-speed counter specified by **S<sub>1</sub>** changes by increasing or decreasing, the DHSCR instruction makes the comparison immediately. When the current value of the high-speed counter is equal to the comparative value specified in **S<sub>2</sub>**, the device specified by **D** changes to OFF. After that, the device specified by **D** remains OFF even if the comparison result is that the current value and the comparative value are not equal.
- If the device specified by **D** is Y0.0–Y0.15, and the comparative value of **S<sub>2</sub>** is equal to the current value of the counter, the comparison result is output to the external output terminals Y0.0–Y0.15. Other Y devices are affected by the scan cycle, but this instruction updates all devices immediately and is not affected by the scan cycle.
- The **D** operand can also specify the HC device to reset, and is limited to the condition in which the high-speed counter number is the same as that of **S<sub>1</sub>**.
- Refer to the DHSCS instruction (API 1005) for more information.


**Example 1**

1. When M0 is ON and HC200 changes its current value from 99 to 100 or from 101 to 100, Y0.10 is reset to OFF.
2. When HC200 changes its current value from 199 to 200, the contact of HC200 is ON and Y0.11 is ON, but the output is delayed by the program scan time.



**Example 2**

If you specify HC200 as the hardware high-speed counter of the same number, the contact of HC200 is reset to OFF when HC200 changes its current value from 999 to 1000 or from 1001 to 1000.




API	Instruction code			Operand					Function				
1007	D	HSZ		<b>S<sub>1</sub>, S<sub>2</sub>, S<sub>3</sub>, D</b>					High-speed input zone comparison				

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
<b>S<sub>1</sub></b>							○									
<b>S<sub>2</sub></b>								●					○	○		
<b>S<sub>3</sub></b>								●					○	○		
<b>D</b>		○	○	○				○								

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
<b>S<sub>1</sub></b>												●	
<b>S<sub>2</sub></b>			●				●						
<b>S<sub>3</sub></b>			●				●						
<b>D</b>	●												

Pulse instruction	16-bit instruction	32-bit instruction
-	-	AS

Symbol



- S<sub>1</sub>** : Counter number
- S<sub>2</sub>** : Lower bound of the comparison zone
- S<sub>3</sub>** : Upper bound of the comparison zone
- D** : Comparison result (3 consecutive devices)

Explanation

- Use this instruction with the high-speed counter numbers HC200 and above. The lower bound of **S<sub>2</sub>** must be less than the upper bound of **S<sub>3</sub>**. If you do not set the zone limit values properly, the PLC automatically adjusts them.
- If **S<sub>1</sub>** specifies a software counter and the specified counter changes by increasing or decreasing by 1 in value, the DHSZ instruction makes the comparison immediately. The comparison condition and output state are shown in the following table.

Comparison condition	D+0 state	D+1 state	D+2 state
The count value of <b>S<sub>1</sub></b> < the lower bound ( <b>S<sub>2</sub></b> )	ON	OFF	OFF
The lower bound ( <b>S<sub>2</sub></b> ) <= the count value of <b>S<sub>1</sub></b> < the upper bound ( <b>S<sub>3</sub></b> )	OFF	ON	OFF
The count value of <b>S<sub>1</sub></b> >= the upper bound ( <b>S<sub>3</sub></b> )	OFF	OFF	ON

Note: You must set the lower bound (**S<sub>2</sub>**) to be less than the upper bound (**S<sub>3</sub>**). If you set the zone boundaries incorrectly, the PLC automatically makes the adjustment.




API	Instruction code			Operand						Function					
1008	D	SPD		<b>S<sub>1</sub>, S<sub>2</sub>, D</b>						Detecting speed					

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
<b>S<sub>1</sub></b>							○									
<b>S<sub>2</sub></b>								○	○				○	○		
<b>D</b>								○								

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
<b>S<sub>1</sub></b>												●	
<b>S<sub>2</sub></b>			●				●						
<b>D</b>			●				●						

Pulse instruction	16-bit instruction	32-bit instruction
-	-	AS

**Symbol**



- S<sub>1</sub>** : Counter value
- S<sub>2</sub>** : Setting value for the cycle time
- D** : Number of pulses from the previous scan cycle


**Explanation**

1. This instruction requires that you use **S<sub>1</sub>** with the DCNT instruction (API 1004) to enable the high speed counter with counter numbers above HC200 (including HC200).
2. The time units for **S<sub>2</sub>** (the setting value for the cycle time) are millisecond (ms). The setting must be between 10–1000. When the value is out of range, the PLC executes the instruction with **S<sub>2</sub>** at the minimum value or the maximum value and there are no error messages.
3. When the count reaches the setting value in **S<sub>2</sub>**, this instruction stores the number of pulses in the device specified by **D**, and is not affected by the PLC scan cycle.
4. This instruction has no limitation when editing, but it only allows eight sets of speed detection instructions to run simultaneously. The system ignores the ninth set of the speed detection instruction and there are no error messages. When executing this instruction, the setting values for the operand are recorded, and during the execution of this instruction, you cannot edit the parameters.

**Example**

You can use the DSPD instruction for speed detection where there is an input pulse signal at X0.0. When M0 is ON, the instruction updates the number of pulses counted by HC200 in D0 every 500ms.

In the following example, the value in D0 is 7500 and the actual pulse input frequency of X0.0 is 15kHz (7500/500ms).




API	Instruction code				Operand								Function				
1009		PWD			<b>S<sub>1</sub>, S<sub>2</sub>, D</b>								Detecting pulse width				

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
<b>S<sub>1</sub></b>	○															
<b>S<sub>2</sub></b>								○	○				○	○		
<b>D<sub>1</sub></b>								○								
<b>D<sub>2</sub></b>		○	○	○												

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
<b>S<sub>1</sub></b>	●												
<b>S<sub>2</sub></b>		●				●							
<b>D<sub>1</sub></b>			●				●						
<b>D<sub>2</sub></b>	●												

Pulse instruction	16-bit instruction	32-bit instruction
-	AS	-

Symbol




- S<sub>1</sub>** : Number of the input point
- S<sub>2</sub>** : Unit of measurement
- D<sub>1</sub>** : Pulse width detection time (32-bit value)
- D<sub>2</sub>** : Update flag

Explanation


- S<sub>1</sub>** supports the following 12 inputs, X0.0~X011, but **S<sub>1</sub>** cannot share the same inputs with the high speed counter.
- S<sub>2</sub>** is the unit of measurement. The instruction is not executed if the setting value of **S<sub>2</sub>** is not a valid **S<sub>2</sub>** code from the following table.

S <sub>2</sub> code	Measurement Unit	Detection range	Frequency range	Remark
0	1us		1Hz - 10kHz	
1	1ms		0.02Hz - 100Hz	
2	10ns		10Hz - 1MHz	Odd-numbered inputs are NOT supported.
4	1us		1Hz - 10kHz	
5	1ms		0.02Hz - 100Hz	
Other values	The instruction is not executed.			

3. The instruction stores the pulse width detection time (32-bit value) in  $D_1$  and the detection range is 0–100,000,000. If the value is over the maximum value, it is processed as the maximum value. If the value is 0, that means is no input switched from ON to OFF during the execution of this instruction.
4.  $D_2$  is the update flag. Whenever the detection of the  $S_1$  input is completed and the instruction is scanned, the updated flag switches to ON for one scan cycle time. You can check if the detection value has been updated with the update flag. When the system executes the instruction for the first time, the update flag resets to OFF.
5. When the value in  $S_2$  is 0, 1 or 2, refer to the timing diagram below for the procedures performed, such as storing detection values and updating flags during the execution of the instruction. The timer starts when the  $S_1$  input switches from OFF to ON as it is shown in the position ① of the following diagram. The instruction stores the detection time when the  $S_1$  input switches from ON to OFF as shown in the position ② of the following diagram.

Figure 1 Detection mode when the value in  $S_2$  is 0, 1 or 2


6. When the value in  $S_2$  is 4 or 5, refer to the timing diagram below for the procedures performed, such as storing detection values and updating flags during the execution of the instruction. The timer starts when the  $S_1$  input switches from OFF to ON as it is shown in the position ① of the following diagram. The instruction stores the detection time when the  $S_1$  input switches from OFF to ON as shown in the position ② of the following diagram.

Figure 2 Detection mode when the value in  $S_2$  is 4 or 5

7. This instruction has no limitation during editing, but it only allows eight sets of pulse width detection instructions to run simultaneously. The system ignores the ninth or later sets of the pulse width detection instruction and there are no error messages. When executing this instruction, the setting values for the operands are recorded, and you cannot edit the parameters during execution.
8. Before executing this instruction, check the input hardware response time and the pulse time set in HWCONFIG. For example, when the value in **S<sub>2</sub>** is set to 0 or 2, that means the unit of time measurement is microseconds ( $\mu$ s). Set the **S<sub>1</sub>** input value to 0 to disable the Input Point Filter Time in HWCONFIG.

**Example**

Suppose there is a pulse signal of 10kHz in the input X0.0. When M0 is ON, the PWD instruction detects the input signal on X0.0 with the pulse width stored in D10/D11 (32-bit data), the time unit is set to 0, and the detected pulse width from D10 is 50 $\mu$ s.



6


API	Instruction code			Operand								Function					
1010	D	CAP		<b>S<sub>1</sub>, S<sub>2</sub>, D</b>								Capturing the high-speed count value in the external input interrupt					

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
<b>S<sub>1</sub></b>	○															
<b>S<sub>2</sub></b>							○									
<b>D</b>								○								

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
<b>S<sub>1</sub></b>	●												
<b>S<sub>2</sub></b>												●	
<b>D</b>			●				●						

Pulse instruction	16-bit instruction	32-bit instruction
-	-	AS


**Symbol**



- S<sub>1</sub>** : External interrupt input point number
- S<sub>2</sub>** : High-speed counter number
- D** : Register for storing the captured value


**Explanation**

1. You can use only the 16 input points X0.0–X0.15 of the PLC in **S<sub>1</sub>**. Use one of these input points with the external interrupt service program to start the function. Note that **S<sub>1</sub>** cannot share the same input point with the high-speed counter.
2. Select the high-speed counter HC device in **S<sub>2</sub>**. You must use the HC device with the DCNT instruction (API 1004) to start the counting function.
3. The instruction stores the captured value from the high-speed counter (32-bit) in **D** when the interrupt occurs. The instruction stores data when the interrupt occurs, and is not affected by the PLC program scanning.
4. The instruction operation is shown below. The input interrupt is triggered by the falling edge.
  - ① → When the execution of the instruction starts, the value in **D** does not change and you can enter the default setting value.
  - ② → When the interrupt in **S<sub>1</sub>** occurs, the instruction captures the value of the counter specified by **S<sub>2</sub>** immediately and stores it in **D**.




5. The instruction can start DCAP instructions for four different input points at most. If you set one input point as the external interrupt triggered by the rising edge and falling edge, the instruction captures the value when the input is triggered by the rising edge and by falling edge respectively, and stores the count value in the device specified by **D**. When two instructions specify the same interrupt input point, the one that starts first uses the interrupt input point first.
6. Set the HC device number in **S<sub>2</sub>**. It is recommended that you use the high-speed counters between HC200–HC255. For details on the counters, refer to the explanation of the DCNT instruction (API 1004).

**Example**




6

External interrupt is triggered by the rising edge at X0.7.



External interrupt is triggered by the falling edge at X0.7.



**Additional remarks**

1. When M0 is ON, the DCAP instruction is enabled. When an external interrupt occurs at X0.7, the instruction captures the value in HC200 and stores it in (32-bit) D0.
2. When the external input interrupt is triggered by the rising edge once, the instruction modifies E0 to 0 by setting D100, stores the count value in D0 in D10 by modifying E0, and the value in D100 is 0+2.
3. When the external input interrupt is triggered by the falling edge one time, the instruction modifies E0 to 2 by setting D100, stores the count value (10+E0=12) in D0 in D12 by modifying E0, and the value in D100 is 0+2. When the value in D100 is 20, D100 is cleared to 0.
4. If the external interrupt is triggered by the rising edge and falling edge five times respectively, the instruction captures the value 10 times and stores the captured values in D10, D12...D28.

The 1<sup>st</sup> captured value= D10

The 2<sup>nd</sup> captured value= D12

...

...

The 10<sup>th</sup> captured value=D28

The 11<sup>th</sup> captured value=D10


API	Instruction code			Operand								Function				
1011		TMRM		S <sub>1</sub> , S <sub>2</sub>								16-bit timer (10ms)				

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
S <sub>1</sub>					○											
S <sub>2</sub>								○				○	○	○		

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
S <sub>1</sub>											●		
S <sub>2</sub>		●				●							

Pulse instruction	16-bit instruction	32-bit instruction
-	AS	-

**Symbol**



- S<sub>1</sub> : Timer number
- S<sub>2</sub> : Setting value for the timer

**Explanation**

This instruction uses 10ms as the unit of time.

Refer to the explanation of the TMRH instruction (API 1002) for details.


API	Instruction			Operand								Description			
1012		IETS	P	<b>D</b>								The start of the instruction execution time measurement			

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
<b>D</b>								●								

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
<b>D</b>		●				●							

Pulse Instruction	16-bit instruction	32-bit instruction
AS	AS	—

**Symbol**




**D** : The time measurement result

**Explanation**

1. The IETS instruction need be used with the API1013 IETE instruction together in order to measure the time for the execution of the instruction in a PLC program which is specified to execute. The unit for the measured time is 1us.
2. When the IETS instruction is enabled, the timing starts immediately until the IETE instruction is also executed. The measurement result is stored in **D** device.
3. Minimum and maximum time measurement results are 0us and 32767us respectively. After the **IETS** instruction is enabled, the PLC will automatically finish the time measurement and store the measurement result in **D** device if no **IETE** instruction has been scanned and the PLC program scanning reaches the **END** instruction.
4. For the instructions IETS and IETE, there is no limit to how many of them are written in the program. But only one set of IETS and IETE can be enabled every time the scan is executed. If IETS is enabled repeatedly for measuring time, the timing of enabling the last IETS instruction is taken as the start of the time measurement. On the contrary, if the execution of multiple IETE instructions is completely finished, the PLC will see the point when the first IETE instruction is disabled as the end point when the time measurement is finished.
5. The IETS instruction is usually used to measure the running time of a PLC program such as interrupt service program function blocks and etc. Since PLC's time-measurement resource will be occupied as the time measurement function is enabled, we suggest the two instructions should be removed after the measuring is completed in order to avoid occupying the PLC resource during the normal execution.

**Example**

Calculate the instruction execution time based on the formula for the floating point number operation and the operation result is stored in D100.




API	Instruction			Operand								Description			
1013		IETE	P	-								The end of the instruction execution time measurement			

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING

Pulse Instruction	16-bit instruction	32-bit instruction
AS	AS	-

**Symbol**



**Explanation**

The IETE instruction should be used with the API1012 IETS instruction together. Refer to the explanation of the API 1012 instruction for more information.


API	Instruction			Operand								Description				
1014	D	HSCY		HCno ~ CurNo								Cyclic counting, comparing and outputting				

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	“\$”	F
HCno							○									
CmpLen								●					○	○		
CmpS							●	●	●							
Action								●	●							
Yno								●	●							
CurNo								●								

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
HCno												●	
CmpLen		●				●							
CmpS			●				●						
Action		●				●							
Yno		●				●							
CurNo		●				●							

Pulse Instruction	16-bit instruction	32-bit instruction
—	—	AS

**Symbol**



- HCno** : 32-bit input counter number
- CmpLen** : The length of data to be compared
- CmpS** : The source value of data in 32-bit to be compared
- Action** : Action to be taken when the comparison is made.
- Yno** : The number of Y output point
- CurNo** : The current group number that is making the comparison

**Explanation**

- This instruction is available for FW V1.06.10 or later.
- HCno:** If the counter is a general one, the comparison will not begin even when the timing to execute comparison is reached. The comparison begins only when the instruction is scanned. If the counter is a high-speed one, the comparison begins when the timing to execute comparison is reached, not affected by the PLC scan cycle. Refer to DHSCS instruction for more details on the usage and the restriction of the high-speed number.
- CmpLen:** To select a set of groups for comparison. The set group compares in a cyclic manner. The setting value of the group can be between 4 and 32. If the setting value exceeds the acceptable range, this instruction is not executed. And SM0 will be switched to ON. Error code SR0: 0x200B.

4. **CmpS** (supposedly set as D100), **Action** (supposedly set as D200), **Yno** (supposedly set as D300), **CmpLen** (supposedly set as 6), **CurNo** (as it is set below).


<b>CurNo</b> (Current Group Number)	<b>CmpS</b> (The source value of data in 32-bit to be compared)	<b>Action</b> (Action to be taken when the comparison is made.)	<b>Yno</b> (The number of Y output point)
1	D100 = 1000	D200 = 1 (Set)	D300 = 16#04 (Y0.4)
2	D102 = 2000	D201 = 1 (Set)	D301 = 16#05 (Y0.5)
3	D104 = 3000	D202 = 1 (Set)	D302 = 16#06 (Y0.6)
4	D106 = 4500	D203 = 0 (Reset)	D303 = 16#04 (Y0.4)
5	D108 = 5500	D204 = 0 (Reset)	D304 = 16#05 (Y0.5)
6	D110 = 6500	D205 = 0 (Reset)	D305 = 16#06 (Y0.6)

- **CmpS**: The source value of data in 32-bit integer. It takes several Dword space in **CmpLen**. Thus it is suggested to declare the array in the data type of Dword. The compared value is arranged in ascending order when the source value is positive integers. The compared value is arranged in descending order when the source value is negative integers. If the compared value is arranged not by the rules as mentioned, the instruction is not executed and SM0 will be switched to ON. Error code SR0: 0x200B.
  - **Action**: Action to be taken when the comparison is made. The value is in 16-bit integer and it takes one word space in **CmpLen**. The value "1" here means setting the output point to ON. The value "0" here means setting the output point to OFF. Use 16#8000 to clear the counter value to 0 and restart the cyclic counting. Only use the value 1, 0 or 16#8000 in here. It is suggested to declare the array in the data type of Word.
  - **Yno**: The number of the Y output point, this value should be a 16-bit integer. It takes several Word space in **CmpLen**. The format here is hexadecimal. For example, 16#0004 means the Y0.4 output point, 16#0016 Y1.6 output point, and 16#00AF Y10.15 output point. It is suggested to declare the array in the data type of Word.
  - **CurNo**: The current group number that is making the comparison. From the table above, you can see if the setting value in **CmpLen** is 1000, the CurNo. Is 1.
5. When the value you use in **Yno** is not the CPU built-in output points, the outputting is affected by the PLC scan cycle. If you need the immediate output, use CPU built-in output points and hardware type high-speed counter in **HCno**.
6. Since this instruction is for cyclic comparing and outputting, you need to set a way to clear the counter value to 0 to set a range for cyclic operation. It is suggested to use hardware input to set the counter to 0. Or you can also use a setting to clear the counter. For example you need 6 groups to perform cyclic comparison. You can set the setting value in **CmpLen** as 7 and you will have a 7 groups of **CurNo** (defined by **CmpS**). And then use 16#8000 as the setting value in Action to clear HC. See the table below for reference.


<b>CurNo</b> (Current Group Number)	<b>CmpS</b> (The source value of data in 32-bit to be compared)	<b>Action</b> (Action to be taken when the comparison is made.)	<b>Yno</b> (The number of Y output point)
7 ( <b>CurNo</b> =0)	D112 = 8000	D206 = 16#8000 (Clear HC)	D306 = 0 (none)

7. When the instruction is firstly executed, it compares the current counter value to the value set in **CmpS** and set the value in **CurNo** accordingly. See the example table in number 4. If the current counter value is 2000, that corresponds to the value (D102 = 2000) set in **CmpS** and the corresponding value of **CurNo** is 2. From there you know the Y0.5 is ON.
8. See the example in chronological illustration below.
- ① → The instruction is firstly executed, comparing the current counter value (1500) and the value set in **CmpS** (HC202). And set the value in **CurNo** to 1 and Y0.4 output to ON accordingly.
  - ② → When the current counter value reaches 2000, **CurNo** = 2 and Y0.5 is ON.
  - ③ → When the current counter value reaches 3000, **CurNo** = 3 and Y0.6 is ON.

- ④ → When the current counter value reaches 4500, **CurNo** = 4 and Y0.4 is OFF.
- ⑤ → When the current counter value reaches 5500, **CurNo** = 5 and Y0.5 is OFF.
- ⑥ → When the current counter value reaches 6500, **CurNo** = 6 and Y0.6 is OFF.
- ⑦ → The external interrupt is triggered to clear. **CurNo** = 0 and HC202 = 0.
- ⑧ → When the current counter value reaches 1000, **CurNo** = 1 and Y0.4 is ON.



Cyclic comparison for illustration purpose only.




**Example:**

1. Define the following parameters as below.


CurNo (Current Group Number)	CmpS (The source value of data in 32-bit to be compared)	Action (Action to be taken when the comparison is made.)	Yno (The number of Y output point)
1	D100 = 1000	D200 = 1 (Set)	D300 = 16#04 (Y0.4)
2	D102 = 2000	D201 = 1 (Set)	D301 = 16#05 (Y0.5)
3	D104 = 3000	D202 = 1 (Set)	D302 = 16#06 (Y0.6)
4	D106 = 4500	D203 = 0 (Reset)	D303 = 16#04 (Y0.4)
5	D108 = 5500	D204 = 0 (Reset)	D304 = 16#05 (Y0.5)
6	D110 = 6500	D205 = 0 (Reset)	D305 = 16#06 (Y0.6)

2. When M0 is ON, the instruction is executed.

- ① → The instruction is firstly executed, comparing the current counter value and the value set in **CmpS** (HC202).  
And set the value in **CurNo** to 1 and Y0.4 output to ON accordingly.
- ② → When the current counter value reaches 2000, **CurNo** = 2 and Y0.5 is ON.
- ③ → When the current counter value reaches 3000, **CurNo** = 3 and Y0.6 is ON.
- ④ → When the current counter value reaches 4500, **CurNo** = 4 and Y0.4 is OFF.
- ⑤ → When the current counter value reaches 5500, **CurNo** = 5 and Y0.5 is OFF.
- ⑥ → When the current counter value reaches 6500, **CurNo** = 6 and Y0.6 is OFF.
- ⑦ → The external interrupt is triggered to clear. **CurNo** = 0 and HC202 = 0.
- ⑧ → When the current counter value reaches 1000, **CurNo** = 1 and Y0.4 is ON.



External interrupt is triggered at X0.4.




API	Instruction				Operand								Description				
1015		PPDT			HCno ~ CurNo								Detecting the time difference between two phases				

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
XnoA	○															
XnoB	○															
PhaseT								●								
Exe		●	●	●												

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
XnoA	●												
XnoB	●												
PhaseT			●				●						
Exe	●												

Pulse Instruction	16-bit instruction	32-bit instruction
—	AS	—

**Symbol**




- XnoA** : Phase A input
- XnoB** : Phase B input
- Phase T** : Time differences between two phases (32-bit integer)
- Exe** : Timing flag

**Explanation**

1. This instruction is available for FW V1.06.10 or later.
2. You can only use the CPU built-in input points from X0.0 to X0.11 for XnoA and XnoB. And the number of the input points can NOT be duplicated. When the input points used are not from X0.0 to X0.11 or the number of the input points are duplicated, the instruction is not executed. And SM0 will be switched to ON. Error code SR0: 16#2003.
3. When **XnoA** is rising-edge triggered, the timer starts timing immediately, not affected by the PLC scan cycle. When **XnoB** is rising-edge triggered, the timer stops timing immediately, not affected by the PLC scan cycle. And the time that is timed (unit: 1 us) will be stored in **PhaseT**, when this instruction is scanned by the PLC.
4. When the timer starts and this instruction is scanned to execute, the **Exe** flag will be ON. When the timer stops and this instruction is scanned to execute, the **Exe** flag will be OFF.
5. Whenever this instruction is firstly activated, its initial action is to clear the value in **PhaseT** and set the **Exe** flag to OFF.
6. **XnoA** is always timed before **XnoB**. Even if **XnoB** is rising-edge triggered before **XnoA** is triggered. If you need **XnoB** to be timed before **XnoA**, you need to re-define **XnoA**, **XnoB** and the input points in them.
7. There is no limit to the number of times the instruction can be executed. And to use the same number of input points is also no problem. But since PLC uses the number of input point for **XnoA** as the number of the internal timer. It is NOT suggested to use two identical numbers of the input point for **XnoA** at the same time. Or the system will get confused. And the timing result from the timer will be messed up.


8. See the example in chronological illustration below.



- ① → Whenever this instruction is firstly activated, it clears the value in **PhaseT** and sets the **Exe** flag to OFF.
- ② → When **XnoA** is rising-triggered to start timing, the **Exe** flag will be ON.
- ③ → When **XnoB** is rising-triggered to stop timing, the **Exe** flag will be OFF and stores the timed result in **PhaseT**.

**Example**

When M0 is ON, the instruction is executed. This instruction calculates the phase time difference between X0.1 and X0.0 and stores the timed result in D0. (The timed result here is 13790 us.)




API	Instruction code			Operand								Function				
1016		ATMR		Tno, Tsv								16-bit contact timer (Unit: 100 ms)				

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	“\$”	F
Tno					○											
Tsv								○				○	○	○		

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
Tno											●		
Tsv		●				●							

Pulse instruction	16-bit instruction	32-bit instruction
-	AS	-

**Symbol**



**Tno** : Timer number

**Tsv** : Setting value for the timer

**Explanation**

1. The instruction is available for PLC firmware V1.12.00 and later.
2. The ATMR instruction uses 100ms as the timing unit in the timer. Refer to the explanation of the ATMRH instruction (API 1017) for details.


API	Instruction code			Operand								Function				
1017		ATMRH		Tno, Tsv								16-bit contact timer (Unit: 1 ms)				

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
Tno					○											
Tsv								○				○	○	○		

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
Tno											●		
Tsv		●				●							

Pulse instruction	16-bit instruction	32-bit instruction
-	AS	-

**Symbol**



**Tno** : Timer number

**Tsv** : Setting value for the timer

**Explanation**

- The instruction is available for PLC firmware V1.12.00 or later.
- The ATMRH instruction is the same as the combination of AND and TMRH instructions. If the conditional contact is met, the coil for the specified timer is ON and the timer starts timing. When the specified timing value is reached (timing value >= setting value), its contact will act as the following table shows. If the condition for the AND contact action is met but the conditional contact is not met, the ATMRH instruction automatically clears the timing value in the timer.


NO (Normally Open) contact	Continuity
NC (Normally Closed) contact	Discontinuity

**Example**


The program executes as the followings:

When the normally open contact M0 is ON, T0 timer starts timing, when the timing value is greater than or equal to K1000, the normally open contact M100 is ON.

**Ladder diagram (Using TMRH instruction)**



Ladder diagram (Using ATMRH instruction)




API	Instruction code				Operand								Function				
1018		ATMRM			Tno, Tsv								16-bit contact timer (Unit: 10 ms)				
Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F	
Tno					○												
Tsv								○				○	○	○			

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
Tno											●		
Tsv		●				●							

Pulse instruction	16-bit instruction	32-bit instruction
-	AS	-

**Symbol**



**Tno** : Timer number

**Tsv** : Setting value for the timer

**Explanation**

- 1.
2. The instruction is available for PLC firmware V1.12.00 or later.
3. The ATMRM instruction uses 10ms as the timing unit in the timer. Refer to the explanation of the ATMRH instruction (API 1017) for details.

## 6.12 Shift Instructions

### 6.12.1 The List of Shift Instructions

The following table lists the Shift instructions covered in this section.

API	Instruction code		Pulse instruction	Function
	16-bit	32-bit		
<b><u>1100</u></b>	SFTR	–	✓	Shifting the states of devices to the right
<b><u>1101</u></b>	SFTL	–	✓	Shifting the states of devices to the left
<b><u>1102</u></b>	WSFR	DWSFR	✓	Shifting the data in word devices to the right
<b><u>1103</u></b>	WSFL	DWSFL	✓	Shifting the data in word devices to the left
<b><u>1104</u></b>	SFWR	DSFWR	✓	Shifting the data and writing it into a word device
<b><u>1105</u></b>	SFRD	DSFRD	✓	Shifting the data and reading it from a word device
<b><u>1106</u></b>	SFPO	DSFPO	✓	Reading the latest data from the data list
<b><u>1107</u></b>	SFDEL	DSFDEL	✓	Deleting data from the data list
<b><u>1108</u></b>	SFINS	DSFINS	✓	Inserting the data into the data list
<b><u>1109</u></b>	MBS	–	✓	Shifting matrix bits
<b><u>1110</u></b>	SFR	DSFR	✓	Shifting the values of the bits in registers by n bits to the right
<b><u>1111</u></b>	SFL	DSFL	✓	Shifting the values of the bits in registers by n bits to the left
<b><u>1112</u></b>	BSFR	–	✓	Shifting the states of n bit devices by one bit to the right
<b><u>1113</u></b>	BSFL	–	✓	Shifting the states of n bit devices by one bit to the left
<b><u>1114</u></b>	NSFR	DNSFR	✓	Shifting n registers to the right
<b><u>1115</u></b>	NSFL	DNSFL	✓	Shifting n registers to the left

### 6.12.2 Explanation of Shift Instructions


API	Instruction code			Operand								Function				
1100		SFTR	P	S, D, n <sub>1</sub> , n <sub>2</sub>								Shifting the states of devices to the right				

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	“\$”	F
S	●	●	●	●				●								
D		●	●	●				●								
n <sub>1</sub>								●	●		○	○	○	○		
n <sub>2</sub>								●	●		○	○	○	○		

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
S	●												
D	●												
n <sub>1</sub>		●				●							
n <sub>2</sub>		●				●							

Pulse instruction	16-bit instruction	32-bit instruction
AS	AS	-

**Symbol**



- S** : First device where the value is shifted
- D** : First device where the value is shifted
- n<sub>1</sub>** : Length of the data to be shifted
- n<sub>2</sub>** : Number of bits in a group



**Explanation**

1. This instruction divides the states of the n<sub>1</sub> bit devices starting from **D** into groups (n<sub>2</sub> bits in a group), and shifts these groups to the right. This instruction then shifts the states of the n<sub>2</sub> bit devices starting from **S** to the devices starting from **D** to fill the vacancy.
2. In general, the SFTRP pulse instruction is used.
3. The operand n<sub>1</sub> must be between 1–1024. The operand n<sub>2</sub> must be between 1–n<sub>1</sub>. For firmware V1.12.00 or later, the operand n<sub>1</sub> can be between 1–4096.

**Example 1**

1. When X0.0 switches from OFF to ON, the instruction divides the states of the sixteen bit devices starting from M0 to M15 into groups (four bits in a group), and shifts these groups to the right.
2. The shift of the states of the bit devices to the right during a scan is shown below.

- ❶ M3-M0 → Being carried
- ❷ M7-M4 → M3-M0
- ❸ M11-M8 → M7-M4
- ❹ M15-M12 → M11-M8
- ❺ X0.3-X0.0 → M15-M12




**Example 2**

1. When X0.0 switches from OFF to ON, the instruction divides the states of the sixteen bit devices starting from M0 to M15 into groups (five bits as a group), and shifts these groups to the right.
2. The shift of the states of the bit devices to the right during a scan is shown below.

- ❶ M0 → Being carried
- ❷ M5 → M0
- ❸ M10-M6 → M5-M1
- ❹ M15-M11 → M10-M6

⑤ X0.4-X0.0 → M15-M11



**Additional remarks**

1. If  $S+n_2-1$  or  $D+n_1-1$  exceeds the device range, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2003.
2. If  $n_1$  not between 1–1024, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#200B.
3. If  $n_2$  is not between 1– $n_1$ , the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#200B.

API	Instruction code			Operand								Function				
1101		SFTL	P	<b>S, D, n<sub>1</sub>, n<sub>2</sub></b>								Shifting the states of devices to the left				

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	“\$”	F
<b>S</b>	●	●	●	●				●								
<b>D</b>		●	●	●				●								
<b>n<sub>1</sub></b>								●	●		○	○	○	○		
<b>n<sub>2</sub></b>								●	●		○	○	○	○		

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
<b>S</b>	●												
<b>D</b>	●												
<b>n<sub>1</sub></b>		●				●							
<b>n<sub>2</sub></b>		●				●							

Pulse instruction	16-bit instruction	32-bit instruction
AS	AS	-

### Symbol

SFTL		SFTLP	
En		En	
S	D	S	D
n <sub>1</sub>		n <sub>1</sub>	
n <sub>2</sub>		n <sub>2</sub>	

**S** : First device where the value is shifted

**D** : First device where the value is shifted

**n<sub>1</sub>** : Length of the data to be shifted

**n<sub>2</sub>** : Number of bits in a group


### Explanation

- This instruction divides the states of the **n<sub>1</sub>** bit devices starting from **D** into groups (**n<sub>2</sub>** bits in a group), and shifts these groups to the left. This instruction then shifts the states of the **n<sub>2</sub>** bit devices starting from **S** to the devices starting from **D** to fill the vacancy.
- In general, the SFTLP pulse instruction is used.
- The operand **n<sub>1</sub>** must be between 1–1024. The operand **n<sub>2</sub>** must be between 1–**n<sub>1</sub>**. For firmware V1.12.00 or later, the operand **n<sub>1</sub>** can be between 1–4096.


**Example 1**

- When X0.0 switches from OFF to ON, the instruction divides the states of the sixteen bit devices starting from M0 to M15 into groups (four bits in a group), and shifts these groups to the left.
- The shift of the states of the bit devices to the left during a scan is shown below.

- ❶ M15-M12 → Being carried
- ❷ M11-M8 → M15-M12
- ❸ M7-M4 → M11-M8
- ❹ M3-M0 → M7-M4
- ❺ X0.3-X0.0 → M3-M0



6




**Example 2**

- When X0.0 switches from OFF to ON, the instruction divides the states of the sixteen bit devices starting from M0 to M15 into groups (five bits in a group), and shifts these groups to the left.
- The shift of the states of the bit devices to the left during a scan is shown below.

- ❶ M15 → Being carried
- ❷ M10 → M15
- ❸ M9-M5 → M14-M10

- ④ M4-M0 → M9-M5
- ⑤ X0.4-X0.0 → M4-M0



**Additional remarks**

1. If  $S+n_2-1$  or  $D+n_1-1$  exceeds the device range, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2003.
2. If  $n_1$  is not between 1–1024, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#200B.
3. If  $n_2$  is not between 1– $n_1$ , the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#200B.


API	Instruction code			Operand							Function					
1102	D	WSFR	P	<b>S, D, n<sub>1</sub>, n<sub>2</sub></b>							Shifting the data in word devices to the right					

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
<b>S</b>	●	●			●	●		●	●							
<b>D</b>		●			●	●		●								
<b>n<sub>1</sub></b>								●	●		○	○	○	○		
<b>n<sub>2</sub></b>								●	●		○	○	○	○		

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
<b>S</b>		●	●			●	●						
<b>D</b>		●	●			●	●						
<b>n<sub>1</sub></b>		●	●			●	●						
<b>n<sub>2</sub></b>		●	●			●	●						

Pulse instruction	16-bit instruction	32-bit instruction
AS	AS	AS

**Symbol**



- S** : First device where the value is shifted
- D** : First device where the value is shifted
- n<sub>1</sub>** : Length of the data to be shifted
- n<sub>2</sub>** : Number of bits in a group

**Explanation**



1. This instruction divides the data in the **n<sub>1</sub>** word devices starting from **D** into groups (**n<sub>2</sub>** words in a group), and shifts these groups to the right. This instruction then shifts the data in the **n<sub>2</sub>** word devices starting from **S** to the devices starting from **D** to fill the vacancy.
2. In general, the WSFRP pulse instruction is used.
3. For 16-bit instruction, the operand **n<sub>1</sub>** must be between 1–512. For 32-bit instruction, the operand **n<sub>1</sub>** must be between 1–256. For the application of 32-bit instruction, you need to use ISPSOft V3.09.07 or later and AS PLC CPU FW V1.08 or later.
4. The value in the operand **n<sub>2</sub>** must be between 1–**n<sub>1</sub>**.

**Example 1**

1. When M0 switches from OFF to ON, the instruction divides the data in the sixteen word devices starting from D20 to D35 into groups (four words in a group), and shifts these groups to the right.

2. The shift of the data in the word devices to the right during a scan (M0 switches from OFF to ON) is shown below.

- ❶ D23-D20 → Being carried
- ❷ D27-D24 → D23-D20
- ❸ D31-D28 → D27-D24
- ❹ D35-D32 → D31-D28
- ❺ D13-D10 → D35-D32 completed





**Example 2**

1. When M0 switches from OFF to ON, the instruction divides the data in the sixteen word devices starting from D20 to D35 into groups (five words in a group), and shifts these groups to the right.

2. The shift of the data in the word devices to the right during a scan (M0 switches from OFF to ON) is shown below.


- ❶ D20 → Being carried
- ❷ D25 → D20
- ❸ D30-D26 → D25-D21
- ❹ D35-D31 → D30-D26
- ❺ D14-D10 → D35-D31 completed




**Example 3**

1. When M0 switches from OFF to ON, the instruction divides the data in the eight word devices starting from D20 to D35 into groups (two words in a group), and shifts these groups to the right.
2. The shift of the data in the word devices to the right during a scan (M0 switches from OFF to ON) is shown below.

- ❶ D23-D20 → Being carried
- ❷ D27-D24 → D23-D20
- ❸ D31-D28 → D27-D24
- ❹ D35-D32 → D31-D28
- ❺ D13-D10 → D35-D32 completed





#### Additional remarks

1. If  $S+n_2-1$  or  $D+n_1-1$  exceeds the device range, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2003.
2. The  $n_1$  of the 16-bit instruction should be between 1–512, and the  $n_1$  of the 32-bit instruction should be less than 256. If not, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#200B.
3. The  $n_2$  should be between 1– $n_1$ . If not, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#200B.


API	Instruction code			Operand							Function				
1103	D	WSFL	P	<b>S, D, n<sub>1</sub>, n<sub>2</sub></b>							Shifting the data in word devices to the left				

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
<b>S</b>	●	●			●	●		●	●							
<b>D</b>		●			●	●		●								
<b>n<sub>1</sub></b>								●	●		○	○	○	○		
<b>n<sub>2</sub></b>								●	●		○	○	○	○		

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
<b>S</b>		●	●			●	●						
<b>D</b>		●	●			●	●						
<b>n<sub>1</sub></b>		●	●			●	●						
<b>n<sub>2</sub></b>		●	●			●	●						

Pulse instruction	16-bit instruction	32-bit instruction
AS	AS	AS

**Symbol**



- S** : First device in which the value is shifted
- D** : First device in which the value is shifted
- n<sub>1</sub>** : Length of the data to be shifted
- n<sub>2</sub>** : Number of bits in a group

**Explanation**


1. This instruction divides the data in the **n<sub>1</sub>** word devices starting from **D** into groups (**n<sub>2</sub>** words in a group), and shifts these groups to the left. This instruction then shifts the data in the **n<sub>2</sub>** word devices starting from **S** to the devices starting from **D** to fill the vacancy.
2. In general, the WSFLP pulse instruction is used.
3. For 16-bit instruction, the value in the operand **n<sub>1</sub>** must be between 1–512. For 32-bit instruction, the value in the operand **n<sub>1</sub>** must be between 1–256. For the application of 32-bit instruction, you need to use ISPSOft V3.09.07 or later and AS PLC CPU FW V1.08 or later.
4. The operand **n<sub>2</sub>** must be between 1–**n<sub>1</sub>**.

**Example 1**

1. When M0 switches from OFF to ON, the instruction divides the data in the sixteen word devices starting from D20 to D35 into groups (four words in a group), and shifts these groups to the left.

2. The shift of the data in the word devices to the left during a scan (M0 switches from OFF to ON) is shown below.



- ❶ D35-D32 → Being carried
- ❷ D31-D28 → D35-D32
- ❸ D27-D24 → D31-D28
- ❹ D23-D20 → D27-D24
- ❺ D13-D10 → D23-D20 completed

**Example 2**

1. When M0 switches from OFF to ON, the instruction divides the data in the sixteen word devices starting from D20 to D35 into groups (five words in a group), and shifts these groups to the left.

2. The shift of the data in the word devices to the left during a scan (M0 switches from OFF to ON) is shown below.

- ❶ D35 → Being carried
- ❷ D30 → D35
- ❸ D29-D25 → D34-D30
- ❹ D24-D20 → D29-D25
- ❺ D14-D10 → D24-D20 completed



**Additional remarks**

1. If  $S+n_2-1$  or  $D+n_1-1$  exceeds the device range, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2003.
2. The  $n_1$  of the 16-bit instruction should be between 1–512, and the  $n_1$  of the 32-bit instruction should be less than 256. If not, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#200B.
3. The  $n_2$  should be between 1– $n_1$ . If not, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#200B.


API	Instruction code			Operand						Function					
1104	D	SFWR	P	S, D, n						Shifting the data and writing it into a word device					

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
S	●	●			●	●		●	●		○	○	○	○		
D		●			●	●		●								
n	●	●			●	●		●	●		○	○	○	○		

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
S		●	●			●	●						
D		●	●			●	●						
n		●	●			●	●						

Pulse instruction	16-bit instruction	32-bit instruction
AS	AS	AS

**Symbol**



**S** : Device where the data is shifted

**D** : First device


**n** : Data length

**Explanation**

1. This instruction defines the data in the **n** word devices starting from the device specified by **D** as a first in-first out list type, and takes the device specified by **D** as a pointer. This instruction increments the value of the pointer by one, and writes the data in the device specified by **S** into the device specified by the pointer. When the value of the pointer is larger than or equal to **n-1**, the instruction stops writing data, and sets the carry flag SM602 is ON.
2. In general, the SFWRP pulse instruction is used.
3. This instruction is highly used as the function of PUSH. If you need to function of POP, refer to the instructions SFRD and SFPO for more information.
4. For 16-bit instruction, the value in the operand **n** must be between 2–512. For 32-bit instruction, the value in the operand **n** must be between 2–256. For the application of 32-bit instruction, you need to use ISPSOft V3.09.07 or later and AS PLC CPU FW V1.08 or later.

**Example 1**


1. The instruction clears the value of the pointer D0 to 0 first. When M0 switches from OFF to ON, the instruction writes the data in D20 into D1, and increments the value in D0 to 1. When M0 switches from OFF to ON again, the instruction writes the data in D20 to D2, and increments the value in D0 to 2.
2. The instruction shifts and writes the data in the word device as shown below.
  - The data in D20 is written into D1.
  - The value in D0 becomes 1.



6

**Example 2**

- The instruction clears the value of the pointer D0 to 0 first. When M0 switches from OFF to ON, the instruction writes the data in D20/D21 into D2/D3, and increments the value in D0/D1 to 1. When M0 switches from OFF to ON again, the instruction writes the data in D20/D21 to D4/D5, and increments the value in D0/D1 to 2.
- The instruction shifts and writes the data in the word device as shown below.
  - The data in D20/21 is written into D2/D3.
  - The value in D0/D1 becomes 1.

**Additional remarks**

- If the value in **D** is less than 0, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2003.
- If **D+n-1** exceeds the device range, the instruction is not executed. SM0 is ON, and the error code in SR0 is 16#2003.
- For 16-bit instruction, the value in the operand **n** must be between 2–512. For 32-bit instruction, the value in the operand **n** must be between 2–256. If not, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#200B.
- You can use the SFWR instruction with the SFRD (API 1105) instruction to write and read the data in a first in first out (FIFO) method.


API	Instruction code			Operand							Function					
1105	D	SFRD	P	S, D, n							Shifting the data and reading it from a word device					

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
S		●			●	●		●			○					
D		●			●	●		●								
n	●	●			●	●		●	●		○	○	○	○		

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
S		●	●			●	●						
D		●	●			●	●						
n		●	●			●	●						

Pulse instruction	16-bit instruction	32-bit instruction
AS	AS	AS

Symbol




**S** : First device  
**D** : Device where the data is shifted  
**n** : Data length

Explanation


1. This instruction defines the data in the **n** word devices starting from the device specified by **S** as a first in-first out list type, and takes the device specified by **S** as a pointer. This instruction decrements the value in the device specified by **S** by one, writes the data in the device specified by **S+1** into the device specified by **D**, shifts the data in the devices specified by **S+n-1-S+2** to the right, and leaves the data in the device specified by **S+n-1** unchanged. When the value in the device specified by **S** is equal to 0, the instruction stops reading the data, and sets the zero flag SM600 is ON.
2. In general, the SFRDP pulse instruction is used.
3. For 16-bit instruction, the value in the operand **n** must be between 2-512. For 32-bit instruction, the value in the operand **n** must be between 2-256. For the application of 32-bit instruction, you need to use ISPSOft V3.09.07 or later and AS PLC CPU FW V1.08 or later.


**Example 1**

1. Supposedly the value in D20 is 10, when M0 switches from OFF to ON, the instruction writes the data in D21 into D0, shifts the data in D29–D22 one place to the right, leaves the data in D29 unchanged, and the decrements the value in D20 by one.
2. The data in the word device is shifted and read as shown below.
  - The data in D21 is read and shifted to D0.
  - The data in D29-D22 is shifted one place to the right.
  - The value in D20 decreases by one.

**Example 2**

1. Supposedly the value in D20/D21 is 5, when M0 switches from OFF to ON, the instruction writes the data in D22/D23 into D0/D1, shifts the 32-bit data in D29–D22 one place to the right, leaves the data in D28/D29 unchanged, and the decrements the value in D20/D21 by one.
2. The data in the word device is shifted and read as shown below.
  - The data in D22/D23 is read and shifted to D0/D1.
  - The 32-bit data in D29-D22 is shifted one place to the right.
  - The value in D20 decreases by one.





#### Additional remarks

1. If the value in **S** is less than 0, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2003.
2. If **S+n-1** exceeds the device range, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2003.
3. For 16-bit instruction, the value in the operand **n** must be between 2–512. For 32-bit instruction, the value in the operand **n** must be between 2–256. If not, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#200B.
4. You can use this instruction with SFWR instruction (API 1104) to write and read the data in a first in first out (FIFO) method.


API	Instruction code			Operand					Function				
1106	D	SFPO	P	S, D					Reading the latest data from a data list				

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
S		●			●	●		●								
D		●			●	●		●			○	○				

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
S		●	●			●	●						
D		●	●			●	●						

Pulse instruction	16-bit instruction	32-bit instruction
AS	AS	AS

**Symbol**



**S** : First device


**D** : Device where the data is stored

**Explanation**

1. This instruction takes the device specified by **S** as a pointer. This instruction writes the data in the device specified by the value of the pointer into the device specified by **D** and clears it to 0, and decrements the value in the device specified by **S** by one. When the value in the device specified by **S** is equal to 0, the instruction stops reading the data, and sets the zero flag SM600 is ON.
2. In general, the SFPOP pulse instruction is used.
3. This instruction is highly used as the function of PUSH. If you need to function of POP, refer to the instructions SFRD and SFPO for more information.
4. For the application of 32-bit instruction, you need to use ISPSOft V3.09.07 or later and AS PLC CPU FW V1.08 or later.


**Example 1**

Supposedly the value in D0 is 7, when M0 is ON, the instruction writes the data in the device specified by D0 into D10. After the instruction shifts the data, the instruction clears the data in the device specified by D0 to 0, and decrements the value in D0 by 1.



**Example 2**

Supposedly the value in D0/D1 is 4, when M0 is ON, the instruction writes the data in the device specified by D0/D1 into D10/D11. After the instruction shifts the data, the instruction clears the data in the device specified by D0/D1 to 0, and decrements the value in D0/D1 by 1.



**Additional remarks**

1. If the value in **S** is less than 0, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2003.
2. If **S+**(the value in **S**) exceeds the device range, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2003.

API	Instruction code			Operand							Function						
1107	D	SFDEL	P	S, D, n							Deleting data from a data list						

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
S		●			●	●		●								
D		●			●	●		●			○	○				
n	●	●			●	●		●	●		○	○	○	○		

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
S		●	●			●	●						
D		●	●			●	●						
n		●	●			●	●						

Pulse instruction	16-bit instruction	32-bit instruction
AS	AS	AS

**Symbol**



**S** : First device

**D** : Device where the data is stored

**n** : Device where the data is deleted

**Explanation**

- For this instruction, the length of the data is the value in the device specified by **S**, and the data itself is in the devices specified by **S+1–S+(the value in S)**. This instruction stores the data in the device specified by **S+n** in **D** and deletes it, shifts the data in the devices specified by **S+n+1–S+(The value in S)** to the right, clears the data in the device specified by **S+(the value in S)** to 0, and decrements the value in the device specified by **S** by one. When the value in the device specified by **S** is equal to 0, the instruction stops deleting the data, and sets the zero flag SM600 is ON.
- In general, the SFDELP pulse instruction is used.



**Additional remarks**

1. If the value in **S** is less than 0, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2003.
2. If **S+n** exceeds the device range, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2003.
3. If **S+(the value in S)** exceeds the device range, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2003.
4. If **n** is not between 0–**S**, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#200B.


API	Instruction code			Operand							Function					
1108	D	SFINS	P	S, D, n							Inserting data into a data list					

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	“\$”	F
S		●			●	●		●								
D	●	●			●	●		●	●		○	○	○	○		
n	●	●			●	●		●	●		○	○	○	○		

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
S		●	●			●	●						
D		●	●			●	●						
n		●	●			●	●						

Pulse instruction	16-bit instruction	32-bit instruction
AS	AS	AS

**Symbol**



**S** : First device

**D** : Data to be inserted


**n** : Device where the data is inserted

**Explanation**

- For this instruction, the length of the data is the value in the device specified by **S**, and the data itself is in the devices specified by **S+1–S+(the value in S)**. This instruction inserts the data in **D** into **S+n**, shifts the original data in the devices specified by **S+n–S+(the value in S)** to the left, and increments the value in the device specified by **S** by one. When the value in the device specified by **S** is equal to 32767, the instruction stops writing the data, stops incrementing the value in the device specified by **S**, and sets the carry flag SM602 is ON.
- In general, the SFINSP pulse instruction is used.
- For 16-bit instruction, the value in the operand **n** must be between 1–32767. For 32-bit instruction, the value in the operand **n** must be between 1–16383.
- For the application of 32-bit instruction, you need to use ISPSOft V3.09.07 or later and AS PLC CPU FW V1.08 or later.


**Example 1**

Supposedly the value in D0 is 8, and **n** is 4. When M0 is ON, the instruction inserts the data in D200 into D4, shifts the original data in D4–D8 to D5–D9, and increments the value in D0 by one.



**Example 2**

Supposedly the value in D0/D1 is 4, and **n** is 3. When M0 is ON, the instruction inserts the data in D200 into D6/D7, shifts the original data in D6–D9 to D8–D11, and increments the value in D0/D1 by one.



**Additional remarks**

1. If the value in **S** is less than 0, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2003.
2. If **S+n** exceeds the device range, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2003
3. If **S+(the value in S)+1** exceeds the device range, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2003.
4. If **n** is not between 0–**S**, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#200B.


API	Instruction code			Operand							Function					
1109		MBS	P	S, D, n							Shifting matrix bits					

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	“\$”	F
S	●	●			●	●		●	●							
D		●			●	●		●								
n	●	●			●	●		●	●		○		○	○		

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
S		●				●							
D		●				●							
n		●				●							

Pulse instruction	16-bit instruction	32-bit instruction
AS	AS	-

**Symbol**




- S** : Matrix source
- D** : Operation result
- n** : Length of the array

**Explanation**

1. This instruction shifts the values of the **n** rows of bits in **S** to the right or to the left. When SM616 is OFF, the instruction shifts the values of the bits to the left. When SM616 is ON, the instruction shifts the values of the bits to the right. The instruction fills the vacancy (b0 when shifting to the left, and b16n-1 when shifting to the right) resulting from the shift with the state of the borrow flag SM615. The instruction transmits the value of the bit shifted last (from shifting to the left is b16n-1 and from shifting to the right is b0) to the carry flag SM614, and stores the operation result in **D**.
2. The operand **n** must be between 1–256.
3. In general, the MBSP pulse instruction is used.


**Example 1**

When X0.0 is ON, SM616 is OFF. The instructions shifts the values of the bits to the left. Suppose SM615 is OFF. After the instruction shifts the values of the bits in the 16-bit registers D0–D2 to the left, it stores the operation result in the 16-bit registers D20–D22, and SM614 is ON.



**Example 2**

When X0.0 is ON, SM616 is ON. The instruction shifts the values of the bits to the right. Suppose SM615 is ON. After the instruction shifts the values of the bits in the 16-bit registers D0–D2 to the right, it stores the operation result in the 16-bit registers D20–D22, and SM614 is OFF.



**Additional remarks**

1. If  $S+n-1$  or  $D+n-1$  exceeds the device range, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2003.
2. If  $n$  is not between 1–256, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#200B.
3. Instruction flags

SM614: Carry flag for the matrix rotation/shift/output.

SM615: Borrow flag for the matrix shift/output.

SM616: Direction flag for the matrix rotation/shift.


API	Instruction code			Operand							Function						
1110	D	SFR	P	D, n							Shifting the values of the bits in registers by n bits to the right						

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
D		●			●	●	●	●			○	○				
n	●	●			●	●		●	●		○	○	○	○		

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
D		●				●							
n		●				●							

Pulse instruction	16-bit instruction	32-bit instruction
AS	AS	AS

**Symbol**



**D** : Device for the shift  
**n** : Number of bits

**Explanation**


- This instructions shift the values of the bits in **D** by **n** bits to the right. The 16-bit instruction fills the vacancies (b<sub>15</sub>–b<sub>15-n+1</sub>) resulting from the shift with 0 and the 32-bit instruction fills the vacancies (b<sub>31</sub>–b<sub>31-n+1</sub>) resulting from the shift with 0. The value of b<sub>n-1</sub> is transmitted to SM602.
- The operand **n** must be between 1–16 for 16-bit instructions and the operand **n** must be between 1–32 for 32-bit instructions.
- In general, the SFRP/DSFRP pulse instruction is used more commonly.
- Only the DSFR/DSFRP instruction (32-bit instructions) can use the 32-bit counter (high counter) but not the device E.

**Example**

When X0.0 is ON, the instruction shifts the values of b<sub>0</sub>–b<sub>15</sub> in D0 by 6 bits to the right, and transmits the value of b<sub>5</sub> to SM602. The instruction clears the values of b<sub>10</sub>–b<sub>15</sub> to zero after the shift.

The shift of the values of the bits to the right during a scan is shown below.

- ① b<sub>5</sub>-b<sub>0</sub> → Being carried (The value of b<sub>5</sub> is transmitted to SM602.)
- ② b<sub>15</sub>-b<sub>6</sub> → b<sub>9</sub>-b<sub>0</sub>
- ③ 0 → b<sub>15</sub>-b<sub>10</sub>



**Additional remarks**

If **n** is not between 0–16 (for 16-bit instructions) or between 0-32 (for 32-bit instructions), the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#200B.


API	Instruction code			Operand					Function				
1111	D	SFL	P	D, n					Shifting the values of the bits in registers by n bits to the left				

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
D		●			●	●	●	●			○	○				
n	●	●			●	●		●	●		○	○	○	○		

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
D		●				●							
n		●				●							

Pulse instruction	16-bit instruction	32-bit instruction
AS	AS	AS

**Symbol**



**D** : Device for the shift

**n** : Number of bits

**Explanation**


- This instructions shift the values of the bits in **D** by **n** bits to the left. The instructions fill the vacancies ( $b_0$ – $b_{n-1}$ ) resulting from the shift with 0 and transmit the value of  $b_{16-n}$  (for 16-bit instruction) or  $b_{32-n}$  (for 32-bit instruction) to SM602.
- The operand **n** must be between 1–16 for 16-bit instructions and the operand **n** must be between 1–32 for 32-bit instructions.
- In general, the SFRP/DSFRP pulse instruction is used more commonly.
- Only the DSFR/DSFRP instruction (32-bit instructions) can use the 32-bit counter (high counter) but not the device E.

**Example**

When X0.0 is ON, the instruction shifts the values of  $b_0$ – $b_{15}$  in D0 by 6 bits to the right, and transmits the value of  $b_{10}$  to SM602. The instruction fills the values of  $b_0$ – $b_5$  with zeros after the shift.

The shift of the values of the bits to the left during a scan shown below.

- ①  $b_{15}$ – $b_{10}$  → Being carried (The value of  $b_{10}$  is transmitted to SM602.)
- ②  $b_9$ – $b_0$  →  $b_{15}$ – $b_6$
- ③ 0 →  $b_5$ – $b_0$



**Additional remarks**

If **n** is not between 0–16 (for 16-bit instructions) or between 0-32 (for 32-bit instructions), the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#200B.


API	Instruction code			Operand					Function						
1112		BSFR	P	<b>D, n</b>					Shifting the states of <b>n</b> bit devices by one bit to the right						

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
<b>D</b>		●	●	●				●								
<b>n</b>	●	●			●	●		●	●		○	○	○	○		

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
<b>D</b>	●												
<b>n</b>		●				●							

Pulse instruction	16-bit instruction	32-bit instruction
AS	AS	-

**Symbol**




**D** : First device for the shift  
**n** : Data length


**Explanation**

1. This instruction shifts the states of the **n** bit devices starting from **D** by one bit to the right. The instruction clears state of **D+n-1** to 0, and transmits the state of **D** to the carry flag SM602.
2. In general, the BSFRP pulse instruction is used.
3. The operand **n** must be between 1–1024.

**Example**

When X0.0 is ON, the instruction shifts the states of M0–M5 by one bit to the right, clears the state of M5 to zero, and transmits the state of M0 to the carry flag SM602.





**Additional remarks**

1. If **D+n-1** exceeds the device range, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2003.
2. If **n** not between 1–1024, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#200B.

API	Instruction code			Operand								Function				
1113		BSFL	P	D, n								Shifting the states of n bit devices by one bit to the left				

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
D		●	●	●				●								
n	●	●			●	●		●	●		○	○	○	○		

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
D	●												
n		●				●							

Pulse instruction	16-bit instruction	32-bit instruction
AS	AS	-

**Symbol**




**D** : First device for the shift  
**n** : Data length


**Explanation**

1. This instruction shifts the states of the n bit devices starting from D by one bit to the left. The instruction clears the state of D to 0, and transmits the state of D+n-1 to the carry flag SM602.
2. In general, the BSFLP pulse instruction is used.
3. The operand n must be between 1–1024.

**Example**

When X0.0 is ON, the instruction shifts the states of M0–M5 by one bit to the left, clears the state of M0 to 0, and transmits the state of M5 to the carry flag SM602.





**Additional remarks**

1. If  $D+n-1$  exceeds the device range, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2003.
2. If  $n$  not between 1–1024, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#200B.


API	Instruction code			Operand							Function						
1114	D	NSFR	P	D, n							Shifting n registers to the right						

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
D		●			●	●		●								
n	●	●			●	●		●	●		○	○	○	○		

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
D		●	●			●	●						
n		●	●			●	●						

Pulse instruction	16-bit instruction	32-bit instruction
AS	AS	AS

**Symbol**



D : First device for the shift

n : Data length


**Explanation**

1. This instruction shifts the data in the n registers starting from D to the right, and clears the data in D+n-1 to 0.
2. In general, the NSFRP pulse instruction is used.
3. For 16-bit instruction, the value in the operand n must be between 1–512. For 32-bit instruction, the value in the operand n must be between 1–256. For the application of 32-bit instruction, you need to use ISPSOft V3.09.07 or later and AS PLC CPU FW V1.08 or later.

**Example 1**


When M0 switches from OFF to ON, the instruction shifts the data in D1–D6 to the right, and clears the data in D6 to 0.





**Example 2**

When M0 is ON, When M0 switches from OFF to ON, the instruction shifts the 7 pieces of 32-bit data in D0–D13 one place to the right, and clears the data in D12 to 0.



**Additional remarks**

1. If  $D+n-1$  exceeds the device range, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2003.
2. For 16-bit instruction, the value in the operand  $n$  must be between 1–512. For 32-bit instruction, the value in the operand  $n$  must be between 1–256. If not, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#200B.


API	Instruction code			Operand					Function				
1115	D	NSFL	P	D, n					Shifting n registers to the left				

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
D		●			●	●		●								
n	●	●			●	●		●	●		○	○	○	○		

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
D		●	●			●	●						
n		●				●							

Pulse instruction	16-bit instruction	32-bit instruction
AS	AS	AS

**Symbol**



**D** : First device for the shift

**n** : Data length


**Explanation**

1. This instruction shifts the data in the n registers starting from D to the left, and clears the data in D to 0.
2. In general, the NSFLP pulse instruction is used.
3. For 16-bit instruction, the value in the operand n must be between 1–512. For 32-bit instruction, the value in the operand n must be between 1–256. For the application of 32-bit instruction, you need to use ISPSOft V3.09.07 or later and AS PLC CPU FW V1.08 or later.

**Example**

When M0 switches from OFF to ON, the instruction shifts the data in D0–D5 to the left, and clears the data in D0 to 0.





**Additional remarks**

1. If **D+n-1** exceeds the device range, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2003.
2. For 16-bit instruction, the value in the operand **n** must be between 1–512. For 32-bit instruction, the value in the operand **n** must be between 1–256. If not, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#200B.

## 6.13 Data Processing Instructions

### 6.13.1 List of Data Processing Instructions

The following table lists the Data Processing instructions covered in this section.

API	Instruction code		Pulse instruction	Function
	16-bit	32-bit		
<b><u>1200</u></b>	SER	DSER	✓	Searching the data
<b><u>1201</u></b>	SUM	DSUM	✓	Finding the number of bits whose states are ON
<b><u>1202</u></b>	DECO	–	✓	Decoding bits
<b><u>1203</u></b>	ENCO	–	✓	Encoding bits
<b><u>1204</u></b>	SEGD	–	✓	Seven-segment decoding
<b><u>1205</u></b>	SORT	DSORT	✓	Sorting data
<b><u>1206</u></b>	ZRST	–	✓	Resetting a zone
<b><u>1207</u></b>	BON	DBON	✓	Checking the state of a bit
<b><u>1208</u></b>	MEAN	DMEAN	✓	Finding the mean
<b><u>1209</u></b>	CCD	–	✓	Finding the sum check
<b><u>1210</u></b>	ABS	DABS	✓	Finding the absolute value
<b><u>1211</u></b>	MINV	–	✓	Inverting matrix bits
<b><u>1212</u></b>	MBRD	–	✓	Reading a matrix bit
<b><u>1213</u></b>	MBWR	–	✓	Writing a matrix bit
<b><u>1214</u></b>	MBC	–	✓	Counting the bits with the value zero or one
<b><u>1215</u></b>	DIS	–	✓	Disuniting 16-bit data
<b><u>1216</u></b>	UNI	–	✓	Uniting 16-bit data
<b><u>1217</u></b>	WSUM	DWSUM	✓	Finding the sum
<b><u>1221</u></b>	LIMIT	DLIMIT	✓	Confining a value within bounds
<b><u>1222</u></b>	BAND	DBAND	✓	Deadband control
<b><u>1223</u></b>	ZONE	DZONE	✓	Controlling the zone
<b><u>1224</u></b>	–	FMEAN	✓	Finding the mean of floating point numbers
<b><u>1225</u></b>	–	FSUM	✓	Finding the sum of floating point numbers
<b><u>1226</u></b>	DTM	–	✓	Data conversion and move
<b><u>1228</u></b>	ZSET	–	✓	Zone setup

API	Instruction code		Pulse instruction	Function
	16-bit	32-bit		
<b><u>1229</u></b>	–	FSORT	✓	Sorting data in floating-point format

### 6.13.2 Explanation of Data Processing Instructions

API	Instruction code			Operand							Function			
1200	D	SER	P	$S_1, S_2, D, n$							Searching the data			

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
$S_1$	●	●			●	●	●	●	●							
$S_2$	●	●			●	●	●	●	●		○	○	○	○		
D		●			●	●	●	●								
n	●	●			●	●	●	●	●		○	○	○	○		

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
$S_1$		●	●			●	●						
$S_2$		●	●			●	●						
D		●	●			●	●						
n		●	●			●	●						

Pulse instruction	16-bit instruction	32-bit instruction
AS	AS	AS

#### Symbol

SER		DSER	
En		En	
S1	D	S1	D
S2		S2	
N		N	
SERP		DSERP	
En		En	
S1	D	S1	D
S2		S2	
N		N	

$S_1$  : First device for the comparison

$S_2$  : Compared data

D : First device where the comparison result is stored

n : Data length

#### Explanation

- This instruction compares  $n$  signed decimal values in the registers starting from the register specified by  $S_1$  with the signed decimal value in the register specified by  $S_2$ , and stores the comparison results in the registers  $D-D+4$ .


Device	Description
D	Number of equal values
D+1	Data number of the first equal value
D+2	Data number of the last equal value
D+3	Data number of the minimum value
D+4	Data number of the maximum value

- The operand **n** must be between 1–256.
- Only the 32-bit instructions can use the 32-bit counter, but not the device E.

**Example**

- When X0.0 is ON, the instruction compares the values in D10–D19 with the value in D0, and stores the comparison results in D50–D54. When the equal value does not exist in D10–D19, the values in D50–D52 are 0.
- The instruction stores the data number of the minimum value in D53, and stores the data number of the maximum value in D54. If there is more than one minimum value or maximum value, the instruction stores the data number that is bigger.

6



$S_1$	Value	Compared data	Data number	Result	D	Value	Description
D10	88	$S_2$ D0=100	0		D50	4	Number of equal values
D11	100		1	Equal	D51	1	Data number of the first equal value
D12	110		2		D52	8	Data number of the last equal value
D13	150		3		D53	7	Data number of the minimum value
D14	100		4	Equal	D54	9	Data number of the maximum value
D15	300		5				
D16	100		6	Equal			
D17	5		7	Minimum			
D18	100		8	Equal			
D19	500		9	Maximum			

#### Additional remarks

1. If  $S_1+n-1$  or  $D+4$  exceeds the device range, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2003.
2. For 16-bit instructions, if the value in  $n$  is not between 1–256, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#200B.
3. For 32-bit instructions, if the value in  $n$  is not between 1–128, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#200B.
4. For 16-bit instructions, if you declare the operand  $D$  in ISPSOft, the data type is ARRAY [5] of WORD/INT.
5. For 32-bit instructions, if you declare the operand  $D$  in ISPSOft, the data type is ARRAY [5] of DWORD/DINT.


API	Instruction code			Operand							Function				
1201	D	SUM	P	S, D							Finding the number of bits whose states are ON				

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
S	●	●			●	●	●	●	●		○	○	○	○		
D		●			●	●	●	●			○	○				

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
S		●	●			●	●						
D		●	●			●	●						

Pulse instruction	16-bit instruction	32-bit instruction
AS	AS	AS

**Symbol**




**Explanation**

1. This instruction finds the number of bits in **S** whose values are ON and stores the number of ON bits in **D**.
2. When the values of all the bits in the source device specified by **S** are 0, the zero flag SM600 is ON.
3. Only the 32-bit instructions can use the 32-bit counter, but not the device E.

**Example**

When X0.0 is ON, the instruction stores the number of bits whose values are one in D0 in D2.



**Additional remarks**

If the device exceeds the range, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2003.


API	Instruction code			Operand							Function					
1202		DECO	P	S, D, n							Decoding bits					

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
S	●	●	●	●	●	●		●	●	○	○	○				
D		●	●	●	●	●		●				○				
n	●	●			●	●		●	●		○	○	○	○		

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
S	●	●				●							
D	●	●				●							
n		●				●							

Pulse instruction	16-bit instruction	32-bit instruction
AS	AS	-

**Symbol**



- S** : Source device
- D** : Device where the decoded values are stored
- n** : Number of bits whose values are decoded

**Explanation**

1. This instruction decodes the values of the lower **n** bits in the source device specified by **S** as the values of the lower  $2^n$  bits in **D**.
2. The instruction decodes the values of the consecutive **n** bits in the source device specified by **S** as the values of the lower  $2^n$  bits in **D**.
3. When the source device specified by **S** is a timer or counter, the instruction treats the device as a word device.
4. When **D** is a bit device, **n** between 1–8. When **n** is 8, the instruction decodes the values of the eight bits as the values of the 256 bits. Please note that the devices in which the decoded values are stored cannot be used repeatedly.
5. When **D** is a word device, **n** between 1–4. When **n** is 4, the instruction decodes the values of the four bits as the values of the 16 bits.
6. In general, the DECOP pulse instruction is used.






API	Instruction code			Operand							Function					
1203		ENCO	P	S, D, n							Encoding bits					

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
S	●	●	●	●	●	●		●	●	○	○	○				
D		●			●	●		●			○	○				
n	●	●			●	●		●	●		○	○	○	○		

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
S	●	●				●							
D		●				●							
n		●				●							

Pulse instruction	16-bit instruction	32-bit instruction
AS	AS	-

**Symbol**



- S** : Source device
- D** : Device where the encoded values are stored
- n** : Number of bits whose values are encoded

**Explanation**


1. When **S** is a word device, this instruction encodes the values of the lower  $2^n$  bits in the source device specified by **S** as the values of the lower **n** bits in **D**.
2. When **S** is a bit device, the instruction processes the higher bit with the value **S+(n-1)** from the lower  $2^n$  bits and stores the result in **D**.
3. When the source device specified by **S** is a timer or counter, the instruction treats the device as a word device.
4. When **S** is a bit device, **n** is between 1–8. When **n** is 8, the instruction encodes the values of the 256 bits as the values of the eight bits.
5. When **S** is a word device, **n** is between 1–4. When **n** is 4, the instruction encodes the values of the 16 bits as the values of the four bits.
6. In general, the ENCOP pulse instruction is used.

**Example 1**

1. When X0.0 switches from OFF to ON, the ENCO instruction encodes the values of the 8 bits in M0–M7 as the


values of the lower 3 bits in D0, and sets the values of b15–b3 in D0 to 0.

- After the ENCO instruction is executed and X0.0 switches to OFF, the data in **D** is unchanged.



**Example 2**

- When X0.0 switches from OFF to ON, the ENCO instruction encodes the values of b0–b7 in D10 as the values of b2–b0 in D20, and sets the values of b15–b3 in D20 to zero. The values of b8–b18 in D10 are invalid data.
- After the ENCO instruction is executed and X0.0 switches OFF, the data in **D** is unchanged.



**Additional remarks**

- If there is no bit whose value is one in the source device specified by **S**, the instruction is not executed, SM0 is ON,

and the error code in SR0 is 16#2003.

2. If **S** is a bit device and if **n** is not between 1–8, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#200B.
3. If **S** is a word device and if **n** is not between 1–4, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#200B.
4. If **S** is a bit device and if  $\mathbf{S}+(\mathbf{2}^{\mathbf{n}})-1$  exceeds the device range, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2003.
5. If **D** is a bit device and if  $\mathbf{D}+\mathbf{n}-1$  exceeds the device range, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2003.

API	Instruction code			Operand								Function					
1204		SEGD	P	S, D								Seven-segment decoding					
Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F	
S	●	●			●	●		●	●		○	○	○	○			
D		●			●	●		●			○	○					


  

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
S		●				●							
D		●				●							

Pulse instruction	16-bit instruction	32-bit instruction
AS	AS	-

**Symbol**



**S** : Source device


**D** : Device where the seven-segment data is stored

**Explanation**

The instruction decodes the values of the lower four bits (b0–b3) in the source device specified by **S** as the seven-segment data stored in **D**.

**Example**

When X0.0 is ON, the instruction decodes the values of b0–b3 in D0 as the seven-segment data stored in Y0.0–Y0.15. If the data in the source device exceeds four bits, the instruction decodes the values of the lower four bits.



The following table shows the relation between the seven-segment data and the bit pattern of source data.

Hex	Bit pattern	Assignment of segments	Segment state							Display
			B0(a)	B1(b)	B2(c)	B3(d)	B4(e)	B5(f)	B6(g)	
0	0000		ON	ON	ON	ON	ON	ON	OFF	
1	0001		OFF	ON	ON	OFF	OFF	OFF	OFF	
2	0010		ON	ON	OFF	ON	ON	OFF	ON	
3	0011		ON	ON	ON	ON	OFF	OFF	ON	
4	0100		OFF	ON	ON	OFF	OFF	ON	ON	
5	0101		ON	OFF	ON	ON	OFF	ON	ON	
6	0110		ON	OFF	ON	ON	ON	ON	ON	
7	0111		ON	ON	ON	OFF	OFF	ON	OFF	
8	1000		ON	ON	ON	ON	ON	ON	ON	
9	1001		ON	ON	ON	ON	OFF	ON	ON	
A	1010		ON	ON	ON	OFF	ON	ON	ON	
B	1011		OFF	OFF	ON	ON	ON	ON	ON	
C	1100		ON	OFF	OFF	ON	ON	ON	OFF	
D	1101		OFF	ON	ON	ON	ON	OFF	ON	
E	1110		ON	OFF	OFF	ON	ON	ON	ON	
F	1111		ON	OFF	OFF	OFF	ON	ON	ON	

API	Instruction code			Operand							Function						
1205	D	SORT	P	S, m <sub>1</sub> , m <sub>2</sub> , D, n							Sorting data						

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
S								●								
m <sub>1</sub>								●					○	○		
m <sub>2</sub>								●					○	○		
D								●								
n								●					○	○		

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
S		●	●			●	●						
m <sub>1</sub>		●	●			●	●						
m <sub>2</sub>		●	●			●	●						
D		●	●			●	●						
n		●	●			●	●						

Pulse instruction	16-bit instruction	32-bit instruction
AS	AS	AS

**Symbol**

SORT	DSORT
En	En
S	S
D	D
m <sub>1</sub>	m <sub>1</sub>
m <sub>2</sub>	m <sub>2</sub>
n	n
SORTP	DSORTP
En	En
S	S
D	D
m <sub>1</sub>	m <sub>1</sub>
m <sub>2</sub>	m <sub>2</sub>
n	n


- S** : First device where the original data is stored
- m<sub>1</sub>** : Number of rows of data
- m<sub>2</sub>** : Number of columns of data
- D** : First device where the sorted data is stored
- n** : Reference value for sorting the data

**Explanation**

1. This instruction stores the data to be sorted in the **m<sub>1</sub>×m<sub>2</sub>** registers starting from the register specified by **D**. If **S** and **D** specify the same register, the sorted data is the same as the original data in the register specified by **S**.
2. The operand **m<sub>1</sub>** must be between 1–32. The operand **m<sub>2</sub>** must be between 1–6. The operand **n** must be between 1–**m<sub>2</sub>**.
3. When SM604 is OFF, the instruction sorts the data in ascending order. When SM604 is ON, the instruction sorts the data in descending order.
4. It is suggested that you use the SORTP or DSORTP pulse type instruction instead of sorting repeatedly.
5. Only the 32-bit instruction can use the 32-bit counter, but not the device E.

**Example**

- Suppose SM604 is OFF. When X0.0 switches from OFF to ON, the instruction sorts the data in ascending order.



- The data which to be sorted is as in the following table.

		← m <sub>2</sub> columns of data →				
		Column				
		1	2	3	4	5
Row	Column	Student number	Chinese	English	Math	Physics
↑ m <sub>1</sub> rows of data ↓	1	(D0) 1	(D5) 90	(D10) 75	(D15) 66	(D20) 79
	2	(D1) 2	(D6) 55	(D11) 65	(D16) 54	(D21) 63
	3	(D2) 3	(D7) 80	(D12) 98	(D17) 89	(D22) 90
	4	(D3) 4	(D8) 70	(D13) 60	(D18) 99	(D23) 50
	5	(D4) 5	(D9) 95	(D14) 79	(D19) 75	(D24) 69

6

3. When the value in D100 is 3, the data is sorted as in the following table.

		← m <sub>2</sub> columns of data →				
		Column				
Column		1	2	3	4	5
Row		Student number	Chinese	English	Math	Physics
↑ m <sub>1</sub> rows of data ↓	1	(D50) 4	(D55) 70	(D60) 60	(D65) 99	(D70) 50
	2	(D51) 2	(D56) 55	(D61) 65	(D66) 54	(D71) 63
	3	(D52) 1	(D57) 90	(D62) 75	(D67) 66	(D72) 79
	4	(D53) 5	(D58) 95	(D63) 79	(D68) 75	(D73) 69
	5	(D54) 3	(D59) 80	(D64) 98	(D69) 89	(D74) 90

4. When the value in D100 is 5, the data is as in the following table.

		← m <sub>2</sub> columns of data →				
		Column				
Column		1	2	3	4	5
Row		Student number	Chinese	English	Math	Physics
↑ m <sub>1</sub> rows of data ↓	1	(D50) 4	(D55) 70	(D60) 60	(D65) 99	(D70) 50
	2	(D51) 2	(D56) 55	(D61) 65	(D66) 54	(D71) 63
	3	(D52) 5	(D57) 95	(D62) 79	(D67) 75	(D72) 69
	4	(D53) 1	(D58) 90	(D63) 75	(D68) 66	(D73) 79
	5	(D54) 3	(D59) 80	(D64) 98	(D69) 89	(D74) 90

**Additional remarks**

1. If the device exceeds the range, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2003.
2. If **m<sub>1</sub>**, **m<sub>2</sub>**, or **n** exceeds the range, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#200B.

API	Instruction code			Operand							Function				
1206		ZRST	P	D <sub>1</sub> , D <sub>2</sub>							Resetting a zone				

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	“\$”	F
D <sub>1</sub>		●	●	●	●	●	●	●		○	○	○				
D <sub>2</sub>		●	●	●	●	●	●	●		○	○	○				

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
D <sub>1</sub>	●	●				●							
D <sub>2</sub>	●	●				●							

Pulse instruction	16-bit instruction	32-bit instruction
AS	AS	-

### Symbol

ZRST	ZRSTP
En	En
D1	D1
D2	D2

D<sub>1</sub> : First device to be reset


D<sub>2</sub> : Last device to be reset

### Explanation

1. This instruction clears the values in D<sub>1</sub>–D<sub>2</sub>. The device type for D<sub>1</sub>–D<sub>2</sub> should be the same for this instruction.
2. When the device number of D<sub>1</sub> is larger than the device number of D<sub>2</sub>, the instruction resets only D<sub>2</sub>.
3. The ZRST instruction can use the 32-bit counter.

### Example

1. When X0.0 is ON, the instruction resets the auxiliary relays M300–M399 to OFF.
2. When X1.0 is ON, the instruction resets the 16-bit counters C0–C127. The values of C0–C127 are cleared to zero, and the contact and the coil are reset to OFF.
3. When X2.0 is ON, the instruction resets the stepping relays S0–S127 to OFF.
4. When X3.0 is ON, the instruction resets the output relays Y0.0–Y1.15 to OFF.
5. When X4.0 is ON, the instruction resets the 32-bit counters HC0–HC63. The values of HC0–HC63 are cleared to zero, and the contact and the coil are reset to OFF.
6. When X5.0 is ON, the instruction resets the timers T0–T127. The values of T0–T127 are cleared to 0. and the contact and the coil are reset to OFF.



6

**Additional remarks**

1. If **D<sub>1</sub>** and **D<sub>2</sub>** are different types of devices, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2007.
2. If **D<sub>1</sub>** and **D<sub>2</sub>** contain different data formats, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2007.


API	Instruction code			Operand						Function					
1207	D	BON	P	S, D, n						Checking the state of a bit					

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
S	●	●			●	●	●	●	●		○	○	○	○		
D		●	●	●				●		○						
n	●	●			●	●	●	●	●		○	○	○	○		

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
S		●	●			●	●						
D	●												
n		●	●			●	●						

Pulse instruction	16-bit instruction	32-bit instruction
AS	AS	AS

**Symbol**






- S** : Source device
- D** : Device where the check result is stored
- n** : Bit whose state is checked

**Explanation**

- This instruction checks the state of the  $n^{\text{th}}$  bit in **S**, and stores the result in **D**.
- The operand **n** used in the 16-bit instruction must be between 0–15. For 32-bit instructions, **n** must be between 0–31.
- Only the 32-bit instructions can use the 32-bit counter, but not the device **E**.

**Example**

- When X0.0 is ON, Y0.1 is ON if the value of the 15<sup>th</sup> bit in D0 is one. When X0.0 is ON, Y0.1 is OFF if the value of the 15<sup>th</sup> bit in D0 is 0.
- When X0.0 switches to OFF, the state of Y0.1 remains the same as before X0.0 switches to OFF.



**Additional remarks**

If **n** exceeds the range, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#200B.


API	Instruction code			Operand						Function					
1208	D	MEAN	P	S, D, n						Finding the mean					

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
S	●	●			●	●	●	●	●							
D		●			●	●	●	●			○	○				
n	●	●			●	●	●	●	●		○	○	○	○		

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
S		●	●			●	●						
D		●	●			●	●						
n		●	●			●	●						

Pulse instruction	16-bit instruction	32-bit instruction
AS	AS	AS

**Symbol**





- S** : First device
- D** : Device where the mean is stored
- n** : Number of devices

**Explanation**

1. This instruction adds up the values in the **n** devices starting from the device specified by **S**, and the stores the mean of the sum in **D**.
2. If a remainder appears in the calculation, the instruction discards it.
3. For 16-bit instructions, **n** must be between 1–256.
4. For 32-bit instructions, **n** must be between 1–128.
5. Only the 32-bit instructions can use the 32-bit counter, but not the device **E**.

**Example**

When X0.0 is ON, the instruction adds up the values in the three registers starting from D0. The instruction divides the sum by 3. The instruction stores the quotient in D10, and leaves out the remainder.



**Additional remarks**

1. For 16-bit instructions, if **n** not between 1–256, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#200B.
2. For 32-bit instruction, if **n** is not between 1–128, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#200B.
3. If **S+n-1** exceeds the device range, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2003.


API	Instruction code			Operand					Function				
1209		CCD	P	<b>S, D, n</b>					Finding the sum check				

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
<b>S</b>	●	●			●	●		●	●							
<b>D</b>		●			●	●		●								
<b>n</b>	●	●			●	●		●	●		○	○	○	○		

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
<b>S</b>		●				●							
<b>D</b>		●				●							
<b>n</b>		●				●							

Pulse instruction	16-bit instruction	32-bit instruction
AS	AS	-

### Symbol



**S** : First device

**D** : Device where the sum is stored


**n** : Number of pieces of data

### Explanation

1. Communication protocols use the sum check function to compare checksums on the same data on different occasions or on different representations of the data to verify data integrity.
2. When SM606 is OFF, the instruction uses the 16-bit conversion mode. The instruction adds up **n** pieces of data in the registers starting from the register specified by **S** (eight bits as a group). The instruction stores the sum in the register specified by **D**, and stores the values of the parity bits in **D+1**.
3. When SM606 is ON, the instruction uses the 8-bit conversion mode. The instruction adds up the **n** pieces of data in the registers starting from the register specified by **S** (eight bits in a group, and only low eight bits are valid). The instruction stores the sum in the register specified by **D**, and stores the values of the parity bits in **D+1**.
4. The operand **n** must be between 1–256.


**Example 1**

1. When SM606 is OFF, the instruction uses the 16-bit conversion mode.
2. When X0.0 is ON, the instruction adds up the six pieces of data in D0–D2 (eight bits in a group). The instruction stores the sum in D100, and stores the values of the parity bits in D101.




S	Data
D0 Low	100 = 0 1 1 0 0 1 0 0
D0 High	111 = 0 1 1 0 1 1 1 ① ←
D1 Low	120 = 0 1 1 1 1 0 0 0
D1 High	202 = 1 1 0 0 1 0 1 0
D2 Low	123 = 0 1 1 1 1 0 1 ① ←
D2 High	211 = 1 1 0 1 0 0 1 ① ←
D100	867
D101	0 0 0 1 0 0 0 ①

Sum  
 The parity bit is set to 1 if the number of ones is odd.  
 The parity bit is set to 0 if the number of ones is even.




**Example 2**

1. When SM606 is ON, the instruction uses the 8-bit conversion mode.
2. When X0.0 is ON, the instruction adds up the six pieces of data in D0–D5 (eight bits in a group). The instruction stores the sum in D100, and stores the values of the parity bits in D101.



S	Data
D0 Low	100 = 0 1 1 0 0 1 0 0
D1 Low	111 = 0 1 1 0 1 1 1 1 ←
D2 Low	120 = 0 1 1 1 1 0 0 0
D3 Low	202 = 1 1 0 0 1 0 1 0
D4 Low	123 = 0 1 1 1 1 0 1 1 ←
D5 Low	211 = 1 1 0 1 0 0 1 1 ←
D100	867
D101	0 0 0 1 0 0 0 1 ← Sum

The parity bit is set to 1 if the number of ones is odd.  
 The parity bit is set to 0 if the number of ones is even.



**Additional remarks**

1. Suppose SM606 is ON. If  $S+n-1$  exceeds the device range, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2003.
2. Suppose SM606 is OFF. If  $S+n/2-1$  exceeds the device range, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2003.
3. If  $n$  is not between 1–256, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#200B.
4. If you declare the operand **D** in ISPSOft, the data type is ARRAY [2] of WORD/INT.


API	Instruction code			Operand							Function					
1210	D	ABS	P	D							Finding the absolute value					

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
D		●			●	●	●	●			○	○				

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
D		●	●			●	●						

Pulse instruction	16-bit instruction	32-bit instruction
AS	AS	AS

**Symbol**




**D** : Device holding the original value

**Explanation**

1. This instruction finds the absolute value of the value in the device specified by **D**.
2. In general, the ABSP pulse instruction is used.
3. Only the 32-bit instructions can use the 32-bit counter, but not the device E.
4. If the value used here is a smallest negative number for the 16-bit number or 32-bit number, this instruction is not executed.

**Example**

Supposedly the value in D0 is originally -1234. When X0.0 switches from OFF to ON, the instruction finds the absolute value of -1234 in D0. That is, the value in D0 becomes 1234 after the instruction is executed.




API	Instruction code			Operand						Function					
1211		MINV	P	S, D, n						Inverting matrix bits					

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
S	●	●			●	●		●	●							
D		●			●	●		●								
n	●	●			●	●		●	●		○		○	○		

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
S		●				●							
D		●				●							
n		●				●							

Pulse instruction	16-bit instruction	32-bit instruction
AS	AS	-

**Symbol**




- S** : Matrix source
- D** : Operation result
- n** : Length of the array

**Explanation**

1. This instruction inverts the bits in the **n** devices starting from the device specified by **S**, and stores the inversion result in **D**.
2. The operand **n** must be between 1–256.

**Example**

When X0.0 is ON, the instruction inverts the bits in the three 16-bit registers D0–D2, and stores the inversion result in the 16-bit registers D20–D22.



	b15															b0				
D0	0	1	0	1	0	1	0	1	0	1	0	1	0	1	0	1	0	1	0	1
D1	0	1	0	1	0	1	0	1	0	1	0	1	0	1	0	1	0	1	0	1
D2	0	1	0	1	0	1	0	1	0	1	0	1	0	1	0	1	0	1	0	1

↓ After the instruction is executed

	b15															b0				
D20	1	0	1	0	1	0	1	0	1	0	1	0	1	0	1	0	1	0	1	0
D21	1	0	1	0	1	0	1	0	1	0	1	0	1	0	1	0	1	0	1	0
D22	1	0	1	0	1	0	1	0	1	0	1	0	1	0	1	0	1	0	1	0

**Additional remarks**

1. If **S+n-1** or **D+n-1** exceeds the device range, the instruction is not execute, SM0 is ON, and the error code in SR0 is 16#2003.
2. If **n** is not between 1–256, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#200B.


API	Instruction code			Operand						Function					
1212		MBRD	P	S, n, D						Reading a matrix bit					

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
S	●	●			●	●		●	●							
n	●	●			●	●		●	●		○		○	○		
D		●			●	●		●			○					

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
S		●				●							
n		●				●							
D		●				●							

Pulse instruction	16-bit instruction	32-bit instruction
AS	AS	-

**Symbol**



- S** : Matrix source
- n** : Length of the array
- D** : Pointer


**Explanation**

1. This instruction checks the state of SM613. If SM613 is ON, the instruction clears the value of the pointer **D** to zero. The instruction reads the value of the bit specified by the value of the pointer **D** into SM614, and then checks the state of SM612. If SM612 is ON, the instruction increments the value of the pointer **D** by adding one.
2. When the instruction reads the value of the last bit, SM608 is ON, and the instruction stores the bit number in the pointer **D**.
3. The operand **n** must be between 1–256.
4. You specify the value of the pointer. The values are between 0–16**n**–1, and correspond to the range between b0–b16**n**–1. If the value of the pointer exceeds the range, SM611 is set to one, and the instruction is not executed.

**Example**

1. Suppose SM613 is OFF and SM612 is ON when X0.0 switches from OFF to ON.
2. Suppose the current value in D20 is 45. When X0.0 is switched from OFF to ON three times, the instruction gives the following execution results.

- ❶ The value in D20 is 46, SM614 is OFF, and SM608 is OFF.
- ❷ The value in D20 is 47, SM614 is ON, and SM608 is OFF.
- ❸ The value in D20 is 47, SM614 is OFF, and SM608 is ON.



**Additional remarks**

1. If **S+n-1** exceeds the device range, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2003.
2. If **n** is not between 1–256, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#200B.
3. Instruction flags:
  - SM608: The matrix comparison comes to an end. When the last bits are compared, SM608 is ON.
  - SM611: Matrix pointer error flag. When the value of the pointer exceeds the comparison range, SM611 is ON.
  - SM612: Matrix pointer increasing flag. The current value of the pointer increases by one.
  - SM613: Matrix pointer clearing flag. The current value of the pointer is cleared to zero.
  - SM614: Carry flag for the matrix rotation/shift/output.


API	Instruction code			Operand							Function					
1213		MBWR	P	S, n, D							Writing a matrix bit					

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
S		●			●	●		●								
n	●	●			●	●		●	●		○		○	○		
D		●			●	●		●			○					

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
S		●				●							
n		●				●							
D		●				●							

Pulse instruction	16-bit instruction	32-bit instruction
AS	AS	-

**Symbol**




- S** : Matrix source
- n** : Length of the array
- D** : Pointer

**Explanation**

1. This instruction checks the state of SM613. If SM613 is ON, the instruction clears the value of the pointer **D** to 0. The instruction writes the state of SM615 into the bit specified by the value of the pointer **D** and then checks the state of SM612. If SM612 is ON, the instruction increments the value in the pointer **D** by one.
2. When the instruction writes the state of SM615 into the last bit, sets SM608 is ON, and records the bit number in the pointer **D**. If value of the pointer **D** exceeds the range, SM611 is ON.
3. The operand **n** must be between 1–256.
4. You specify the value of the pointer. The values are between 0–16**n**–1, and correspond to the range between b0–b16**n**–1. If the value of the pointer exceeds the range, SM611 is set to one, and the instruction is not executed.

**Example**

1. Suppose SM613 is OFF and SM612 is ON when X0.0 switches from OFF to ON.
2. Suppose the current value in D20 is 45. When X0.0 switches from OFF to ON one time, the instruction gives the execution result shown below. When the value in D20 is 45, SM615 is OFF, and SM608 is OFF.



**Additional remarks**

1. If **S+n-1** exceeds the device range, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2003.

2. If **n** is not between 1–256, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#200B.

3. Instruction flags:

SM608: The matrix comparison comes to an end. When the last bits are compared, SM608 is ON.

SM611: Matrix pointer error flag. When the value of the pointer exceeds the comparison range, SM611 is ON.

SM612: Matrix pointer increasing flag. The current value of the pointer increases by one.

SM613: Matrix pointer clearing flag. The current value of the pointer is cleared to zero.

SM615: Borrow flag for the matrix shift/output.


API	Instruction code			Operand							Function			
1214		MBC	P	S, n, D							Counting the bits with the value zero or one			

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
S		●			●	●		●								
n	●	●			●	●		●	●		○		○	○		
D		●			●	●		●			○					

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
S		●				●							
n		●				●							
D		●				●							

Pulse instruction	16-bit instruction	32-bit instruction
AS	AS	-

**Symbol**




- S : Matrix source
- n : Length of the array
- D : Operation result

**Explanation**

1. This instruction counts the bits with the value one or zero in the n devices starting from the device specified by S. The instruction stores the operation result in D.
2. When SM617 is ON, the instruction counts the bits with the value one. When SM617 is OFF, the instruction counts the bits with the value 0. When the operation result is 0, SM618 is ON.
3. The value in n must be between 1–256.

**Example**

Suppose SM617 is ON. When X0.0 is ON, the instruction counts the bits with the value one, and stores the operation result in D20. Suppose SM617 is OFF. When X0.0 is ON, the instruction counts the bits with the value zero, and stores the operation result in D20.





API	Instruction code				Operand							Function				
1215		DIS		P	<b>S, n, D</b>							Disuniting 16-bit data				

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
<b>S</b>	●	●			●	●		●	●		○	○				
<b>n</b>	●	●			●	●		●	●		○	○	○	○		
<b>D</b>		●			●	●		●								

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
<b>S</b>		●				●							
<b>n</b>		●				●							
<b>D</b>		●				●							

Pulse instruction	16-bit instruction	32-bit instruction
AS	AS	-


**Symbol**



- S** : Data source
- n** : Number of devices
- D** : Operation result

**Explanation**



- This instruction divides the 16-bit value in the register specified by **S** into four groups (four bits in a group), and stores these groups in the low four bits in every register (the registers range from **D** to **D+(n-1)**).



- The value in **n** must be between 1–4.

**Example**

Suppose the value in **D0** is 16#1234. When **M0** is enabled, the instruction divides the value in **D0** into four groups (four bits in a group), and stores these groups in the low four bits in every register (the registers range from **D10** to **D13**).



**Additional remarks**

1. If  $D-D+(n-1)$  exceed the device range, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2003.
2. If  $n$  is not between 1–4, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#200B.


API	Instruction code			Operand							Function						
1216		UNI	P	<b>S, n, D</b>							Uniting 16-bit data						

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
<b>S</b>	●	●			●	●		●	●							
<b>n</b>	●	●			●	●		●	●		○	○	○	○		
<b>D</b>		●			●	●		●			○	○				

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
<b>S</b>		●				●							
<b>n</b>		●				●							
<b>D</b>		●				●							

Pulse instruction	16-bit instruction	32-bit instruction
AS	AS	-


**Symbol**



- S** : Data source
- n** : Data length
- D** : Operation result

**Explanation**



- This instruction divides the 16-bit values in the registers specified by **S–S+(n-1)** into groups (four bits in a group), and stores every group that is in b0–b3 in the register specified by **D** (b0–b15).



- The value in **n** must be between 1–4.

**Example**

Suppose the values in D0–D3 are 16#1234, 16#5678, 16#8765, and 16#4321 respectively. When M0 is enabled, the UNI instruction divides the values in D0–D3 into groups (four bits in a group), and stores every group in b0–b3 in D10(b0–b15).



**Additional remarks**

1. If **S** to **S+(n-1)** exceed the device range, the instruction is not executed, **SM0** is ON, and the error code in **SR0** is 16#2003.
2. If **n** not between 1–4, the instruction is not executed, **SM0** is ON, and the error code in **SR0** is 16#200B.


API	Instruction code			Operand							Function						
1217	D	WSUM	P	S, n, D							Getting the sum						

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
S	●	●			●	●	●	●	●							
n	●	●			●	●	●	●	●		○	○	○	○		
D		●			●	●	●	●			○					

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
S		●	●			●	●						
n		●	●			●	●						
D		●	●			●	●						

Pulse instruction	16-bit instruction	32-bit instruction
AS	AS	AS


**Symbol**



**S** : Data source  
**n** : Data length  
**D** : Operation result

**Explanation**


- The instruction adds up the signed decimal values in **S** to **S+n-1**, and stores the sum in the register specified by **D**.



2. For 16-bit instructions, the value in **n** must be between 1–256.
3. For 32-bit instructions, the value in **n** must be between 1–128.
4. Only the 32-bit instructions can use the 32-bit counter, but not the device E.

**Example**

The WSUM instruction adds up the values in D0–D2, and stores the sum (32-bit) in D10.



**6**

**Additional remarks**

1. For 16-bit instructions, the value in **n** is not between 1–256, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#200B.
2. For 32-bit instructions, the value in **n** is not between 1–128, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#200B.
3. If **S+n-1** or **D** exceeds the device range, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2003.
4. For 16-bit instructions, if you declare the operand **D** in ISPSOft, the data type is DWORD or ARRAY [2] of WORD.
5. For 32-bit instructions, if you declare the operand **D** in ISPSOft, the data type is ARRAY [2] of DWORD.


API	Instruction code			Operand						Function					
1221	D	LIMIT	P	<b>S<sub>1</sub>, S<sub>2</sub>, S<sub>3</sub>, D</b>						Confining a value within bounds					

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
S <sub>1</sub>	●	●			●	●	●	●	●		○	○	○	○		
S <sub>2</sub>	●	●			●	●	●	●	●		○	○	○	○		
S <sub>3</sub>	●	●			●	●	●	●	●		○	○	○	○		
D		●			●	●	●	●			○	○				

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
S <sub>1</sub>		●	●			●	●						
S <sub>2</sub>		●	●			●	●						
S <sub>3</sub>		●	●			●	●						
D		●	●			●	●						

Pulse instruction	16-bit instruction	32-bit instruction
AS	AS	AS

**Symbol**



- S<sub>1</sub> : Minimum output value
- S<sub>2</sub> : Maximum output value
- S<sub>3</sub> : Input value
- D : Output value

**Explanation**

- The instruction compares the input value in S<sub>3</sub> with the minimum output value in S<sub>1</sub> and the maximum output value in S<sub>2</sub>, and stores the comparison result in D.

If the input value in S<sub>3</sub> is smaller than the minimum output value in S<sub>1</sub>, the instructions stores minimum output value S<sub>1</sub> in D.

If the input value in S<sub>3</sub> is larger than the maximum output value in S<sub>2</sub>, the instruction stores the maximum output value S<sub>2</sub> in D.


If the input value in S<sub>3</sub> is between the minimum output value S<sub>1</sub> and the maximum output value S<sub>2</sub>, the instruction stores the input value S<sub>3</sub> in D.

If the minimum output value in **S<sub>1</sub>** is larger than the maximum output value in **S<sub>2</sub>**, the instruction is not executed.

- 2. Only the 32-bit instructions can use the 32-bit counter, but not the device E.

**Example**

- When X0.0 is ON, the instruction converts the state of X1 into a binary value, and stores the conversion result in D0. Then the instruction compares the value in D0 with 500 and 5000, and stores the comparison result in D1.



Minimum output value	Maximum output value	Output value in D0	Function	Output value in D1
500	5000	499	$D0 < 500$	500
		5001	$D0 > 5000$	5000
		600	$500 \leq D0 \leq 5000$	600

**Additional remarks**

If the minimum output value in **S<sub>1</sub>** is larger than the maximum output value in **S<sub>2</sub>**, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2003.

API	Instruction code			Operand						Function					
1222	D	BAND	P	<b>S<sub>1</sub>, S<sub>2</sub>, S<sub>3</sub>, D</b>						Deadband control					

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
S <sub>1</sub>	●	●			●	●	●	●	●		○	○	○	○		
S <sub>2</sub>	●	●			●	●	●	●	●		○	○	○	○		
S <sub>3</sub>	●	●			●	●	●	●	●		○	○	○	○		
D		●			●	●	●	●			○	○				

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
S <sub>1</sub>		●	●			●	●						
S <sub>2</sub>		●	●			●	●						
S <sub>3</sub>		●	●			●	●						
D		●	●			●	●						

Pulse instruction	16-bit instruction	32-bit instruction
AS	AS	AS

**Symbol**



- S<sub>1</sub> : Minimum value of the deadband
- S<sub>2</sub> : Maximum value of the deadband
- S<sub>3</sub> : Input value
- D : Output value

**Explanation**

1. This instruction subtracts the minimum value of the deadband in S<sub>1</sub> or the maximum value of the deadband in S<sub>2</sub> from the input value in S<sub>3</sub>, and stores the difference in D.


If the input value in S<sub>3</sub> is smaller than the minimum value of the deadband in S<sub>1</sub>, the instruction subtracts S<sub>1</sub> from S<sub>3</sub>, and stores the difference in D.

If the input value in S<sub>3</sub> is greater than the maximum value of the deadband in S<sub>2</sub>, the instruction subtracts S<sub>2</sub> from S<sub>3</sub>, and stores the difference in D.

If the input value in S<sub>3</sub> is between the minimum of the deadband in S<sub>1</sub> and the maximum value of the deadband in S<sub>2</sub>, the instruction stores zero in D.

If the minimum value of the deadband in  $S_1$  is larger than the maximum value of the deadband in  $S_2$ , the instruction is not executed.

2. Only the 32-bit instructions can use the 32-bit counter, but not the device E.
3. The following graphs show how this instruction uses the deadband.



4. The minimum value of the deadband in  $S_1$ , the maximum value of the deadband in  $S_2$ , the input value in  $S_3$ , and the output value in  $D$  must be within the range described below.
5. For the BAND instruction, the minimum value of the deadband in  $S_1$ , the maximum value of the deadband in  $S_2$ , the input value in  $S_3$ , and the output value in  $D$  must be between -32768 to 32767. Suppose the minimum value of the deadband in  $S_1$  is 10 and the maximum value of the deadband in  $S_3$  is -32768. The instruction calculates the output value in  $D$  as follows.

$$\text{Output value in } D = -32768 - 10 = 16\#8000 - 16\#000A = 16\#7FF6 = 32758$$

6. For the DBAND instruction, the minimum value of the deadband in  $S_1$ , the maximum value of the deadband in  $S_2$ , the input value in  $S_3$ , and the output value in  $D$  must be between -2147483648 to 2147483647. Suppose the minimum value of the deadband in  $(S_1+1, S_1)$  is 1000 and the maximum value of the deadband in  $(S_3+1, S_3)$  is -2147483648. The instruction calculates the output value in  $(D+1, D)$  as follows.


Output value in  $(D+1, D)$

$$= -2147483648 - 1000 = 16\#80000000 - 16\#000003E8 = 16\#7FFFC18$$

$$= 2147482648$$

**Example 1**

When X0.0 is ON, the instruction subtracts -1000 or 1000 from the binary-coded decimal value in X1, and stores the difference in D1.




The following table shows the execution results.

Minimum value of the deadband	Maximum value of the deadband	Input value in D0	Function	Output value in D1
-1000	1000	-1200	$D0 < -1000 \Rightarrow D1 = D0 - (-1000)$	-200
		1200	$D0 > 1000 \Rightarrow D1 = D0 - 1000$	200
		500	$-1000 \leq D0 \leq 1000 \Rightarrow D0 = 0$	0

**Example 2**

When X0.0 is ON, the instruction subtracts -10000 or 10000 from the binary-coded decimal value in (X2, X1), and stores the difference in (D11, D10).



The following table shows the execution results.

Minimum value of the deadband	Maximum value of the deadband	Input value in (D1, D0)	Function	Output value in (D11, D10)
-10000	10000	-12000	$(D1 \cdot D0) < -10000$ $\Rightarrow (D11 \cdot D10)$ $= (D1 \cdot D0) - (-10000)$	-2000
		12000	$(D1 \cdot D0) > 10000$ $\Rightarrow (D11 \cdot D10)$ $= (D1 \cdot D0) - 10000$	2000
		5000	$-10000 \leq (D1 \cdot D0) \leq 10000$ $\Rightarrow (D1 \cdot D0) = 0$	0

#### Additional remarks

If the minimum value of the deadband in **S<sub>1</sub>** is larger than the maximum value of the deadband in **S<sub>2</sub>**, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2003.

API	Instruction code			Operand						Function					
1223	D	ZONE	P	<b>S<sub>1</sub>, S<sub>2</sub>, S<sub>3</sub>, D</b>						Controlling the zone					

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
<b>S<sub>1</sub></b>	●	●			●	●	●	●	●		○	○	○	○		
<b>S<sub>2</sub></b>	●	●			●	●	●	●	●		○	○	○	○		
<b>S<sub>3</sub></b>	●	●			●	●	●	●	●		○	○	○	○		
<b>D</b>		●			●	●	●	●			○	○				

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
<b>S<sub>1</sub></b>		●	●			●	●						
<b>S<sub>2</sub></b>		●	●			●	●						
<b>S<sub>3</sub></b>		●	●			●	●						
<b>D</b>		●	●			●	●						

Pulse instruction	16-bit instruction	32-bit instruction
AS	AS	AS

### Symbol

ZONE		ZONEP	
En		En	
S <sub>1</sub>	D	S <sub>1</sub>	D
S <sub>2</sub>		S <sub>2</sub>	
S <sub>3</sub>		S <sub>3</sub>	

DZONE		DZONEP	
En		En	
S <sub>1</sub>	D	S <sub>1</sub>	D
S <sub>2</sub>		S <sub>2</sub>	
S <sub>3</sub>		S <sub>3</sub>	

**S<sub>1</sub>** : Negative deviation

**S<sub>2</sub>** : Positive deviation

**S<sub>3</sub>** : Input value

**D** : Output value

### Explanation


- This instruction adds the negative deviation in **S<sub>1</sub>** or the positive deviation in **S<sub>2</sub>** to the input value in **S<sub>3</sub>**, and stores the sum in **D**.

If the input value in **S<sub>3</sub>** is less than 0, the instruction adds the negative deviation in **S<sub>1</sub>** to the input value in **S<sub>3</sub>**, and stores the sum in **D**.

If the input value in **S<sub>3</sub>** is larger than 0, the instruction adds the positive deviation in **S<sub>2</sub>** to the input value in **S<sub>3</sub>**, and stores the sum in **D**.

If the input value in **S<sub>3</sub>** is equal to zero, the instruction stores zero in **D**.

2. The following graphs show how this instruction uses the zone:



3. Only the 32-bit instructions can use the 32-bit counter but not the device E.
4. The negative deviation in **S<sub>1</sub>**, the positive deviation in **S<sub>2</sub>**, the input value in **S<sub>3</sub>**, and the output value in **D** must be within the range described below.

- For the ZONE instruction, the negative deviation in **S<sub>1</sub>**, the positive deviation in **S<sub>2</sub>**, the input value in **S<sub>3</sub>**, and the output value in **D** must be between -32768 to 32767. Suppose the negative deviation in **S<sub>1</sub>** is -100 and the input value in **S<sub>3</sub>** is -32768. The instruction calculates the output value in **D** as follows.

$$\text{Output value in D} = (-32768) + (-100) = 16\#8000 + 16\#FF9C = 16\#7F9C = 32668$$


- For the DZONE instruction, the negative deviation in **S<sub>1</sub>**, the positive deviation in **S<sub>2</sub>**, the input value in **S<sub>3</sub>**, and the output value in **D** must be between -2147483648 to 2147483647. Suppose the negative deviation in (**S<sub>1</sub>+1, S<sub>1</sub>**) is -1000 and the input value in (**S<sub>3</sub>+1, S<sub>3</sub>**) is -2147483648. The instruction calculates the output value in (**D+1, D**) as follows.

Output value in (**D+1, D**)

$$= -2147483648 + (-1000) = 16\#80000000 + 16\#FFFFFFC8 = 16\#7FFFFFFC8 = 2147482648$$

**Example 1**

When X0.0 is ON, the instruction adds -100 or 100 to the binary-coded decimal value in X1, and stores the sum in D10.




The following table shows the execution results.

Negative deviation	Positive deviation	Input value in D0	Function	Output value in D10
-100	100	-10	$D0 < 0 \Rightarrow D10 = (-10) + (-100)$	-110
		0	$D0 = 0 \Rightarrow D10 = 0$	0
		50	$D0 > 0 \Rightarrow D10 = 50 + 100$	150

### Example 2

When X0.0 is ON, the instruction adds -10000 or 10000 to the binary-coded decimal value in (X2, X1), and stores the sum in (D11, D10).



The following table shows the execution results.

Negative deviation	Positive deviation	Input value in (D1, D0)	Function	Output value in (D11, D10)
-10000	10000	-10	$(D1 \cdot D0) < 0$ $\Rightarrow (D11 \cdot D10)$ $= (-10) + (-10000)$	-10010
		0	$(D1 \cdot D0) = 0$ $\Rightarrow (D11 \cdot D10) = 0$	0
		50	$(D1 \cdot D0) > 0$ $\Rightarrow (D11 \cdot D10) = 50 + 10000$	10050


API	Instruction code			Operand							Function					
1224		FMEAN	P	S, D, n							Finding the mean of floating point numbers					

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	“\$”	F
S							●	●								
n							●	●					○	○		
D							●	●			○					

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
S									●				
n			●				●						
D									●				

Pulse instruction	16-bit instruction	32-bit instruction
AS	-	AS

**Symbol**




- S** : First device
- D** : Device where the mean is stored
- n** : Number of devices

**Explanation**


1. This instruction adds up the single precision floating points in the **n** devices starting from the device specified by **S**, divides the sum by the value in **n**, then stores the mean of the sum in **D**.
2. For 16-bit instructions, the value in **n** must be between 1–256,
3. Instruction flags: SM600 (zero flag), SM601 (borrow flag), SM602 (carry flag):
  - When the operation result is zero, SM600 is ON. Otherwise, it is OFF.
  - If the value while adding or the absolute result of the operation is less than the floating point number that can be shown, the D=16#FF800000 and the borrow flag SM601 is ON.
  - If the value while adding or the absolute result of the operation is larger than the floating point number that can be shown, the D=16#7F800000 and the carry flag SM602 is ON.

**Example**

When X0.0 is ON, the instruction adds the values of the 3 single precision floating points in (D1, D0), (D3, D2), (D5, D4) and then divides the addition result by 3, then stores the result in (D11, D10).



$$[(D1, D0) + (D3, D2) + (D5, D4)] / 3 \rightarrow (D11, D10)$$



#### Additional remarks

1. If the value in **n** is not between 1–256, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#200B.
2. If  $S+2*n-1$  exceeds the device range, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2003.
3. If the value in **S** exceeds the range of floating point numbers that can be shown, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2013.


API	Instruction code			Operand							Function					
1225		FSUM	P	S, n, D							Finding the sum of floating point numbers					

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
S							●	●								
n							●	●					○	○		
D							●	●			○					

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
S									●				
n			●				●						
D									●				

Pulse instruction	16-bit instruction	32-bit instruction
AS	-	AS


**Symbol**



- S** : Data source
- n** : Data length
- D** : Operation result


**6 Explanation**

1. This instruction adds up the single precision floating points in the **n** devices starting from the device specified by **S**, then stores the sum in **D**.
2. For 16-bit instructions, the value in **n** must be between 1–256,
3. Instruction flags: SM600 (zero flag), SM601 (borrow flag), SM602 (carry flag):
  - When the operation result is zero, SM600 is ON. Otherwise, it is OFF.
  - If the value while adding or the absolute result of the operation is less than the floating point number that can be shown, the D=16#FF800000 and the borrow flag SM601 is ON.
  - If the value while adding or the absolute result of the operation is larger than the floating point number that can be shown, the D=16#7F800000 and the carry flag SM602 is ON.




**Example**

The FSUM instruction adds up the values of the 3 single precision floating points in (D1, D0), (D3, D2), (D5, D4) and stores the result in (D11, D10).



$$[(D1, D0) + (D3, D2) + (D5, D4)] \rightarrow (D11, D10)$$



**Additional remarks**

1. If the value in **n** is not between 1–256, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#200B.
2. If **S+2\*n-1** exceeds the device range, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2003.
3. If the value in **S** exceeds the range of the floating point numbers that can be shown, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2013.


API	Instruction			Operand							Description				
1226		DTM	P	<b>S, D, m, n</b>							Data conversion and move				

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
<b>S</b>	●	●			●	●		●								
<b>D</b>		●			●	●		●								
<b>m</b>								●					○	○		
<b>n</b>								●					○	○		

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
<b>S</b>		●				●							
<b>D</b>		●				●							
<b>m</b>		●				●							
<b>n</b>		●				●							

Pulse Instruction	16-bit instruction	32-bit instruction
AS	AS	-

**Symbol**



- S** : Source data device
- D** : Device where the conversion result is stored
- m** : Conversion mode selection
- n** : The length of the data to be executed

**Explanation**


1. The parameter **m** is for you to select a conversion mode from the following table. See the details on modes in the following sections. If the parameter value is not one of the values in the following table, there will be no data conversion or move and no error message.

Parameter	Description
0	8-bit data converted into 16-bit data (high 8 bits, low 8 bits)
1	8-bit data converted into 16-bit data (low 8 bits, high 8 bits)
2	16-bit data (high 8 bits, low 8 bits) converted into 8-bit data
3	16-bit data (low 8 bits, high 8 bits) converted into 8-bit data
4	8-bit hex data (high 4 bits, low 4 bits) converted into ASCII data
5	8-bit hex data (low 4 bits, high 4 bits) converted into ASCII data.
6	8-bit ASCII data converted into hex data (high 4 bits, low 4 bits).)
7	8-bit ASCII data converted into hex data (low 4 bits, high 4 bits).
18	String-type data converted into floating-point data (available for FW V1.08 or later)
19	Floating-point data converted into string-type data (available for FW V1.08 or later)
42	Calculate the duration of 2-Axis relative-position clockwise arc interpolation
43	Calculate the duration of 2-Axis relative-position counterclockwise arc interpolation
44	Set up the built-in input points filtering time for the PLC
46	Calculate the relative -position pulse output time in acceleraton and deceleration (available for FW V1.08 or later)

2. **n** is the setting value of data length. The range of the setting value is 1~256. If the input value exceeds the range, the PLC will execute the instruction at the minimum or maximum value.
3. The conversion modes and move modes are explained as below.


- **When m=0:**

If **n=4**, the 8-bit data is converted into the 16-bit data (high 8-bits, low 8-bits), the conversion is as the following figure shows.




- **When m=1:**

If n=4, the 8-bit data is converted into the 16-bit data (low 8-bits, high 8-bits), the conversion is as the following figure shows.




- **When m=2:**

If n=4, the 16-bit data (high 8-bits, low 8-bits) is converted into the 8-bit data, the conversion is as the following figure shows.




- **When m=3:**

If n=2, the 16-bit data (low 8-bits, high 8-bits) is converted into the 8-bit data, the conversion is as the following figure shows.




- **When m=4:**

If  $n=3$ , the 8-bit hex data (high 4-bits, low 4-bits) is converted into the ASCII data and the conversion is as the following figure shows.




- **When m=5:**

If  $n=3$ , the 8-bit hex data (low 4-bits, high 4-bits) is converted into the ASCII data, the conversion is as the following figure shows.




- **When m=6:**

If  $n=4$ , the 8-bit ASCII data is converted into the hex data (high 4-bits, low 4-bits), the conversion is as the following figure shows. ASCII conversion values can be: 0 ~ 9 (0x30~0x39), A ~ F (0x41~0x46), a ~ f (0x61~0x66).



● **When m=7:**

If n=4, the 8-bit ASCII data is converted into the hex data (low 4-bits, high 4-bits), the conversion is as the following figure shows.




● **When m=18:**

Convert the string value in source device S (Lo-byte) into a floating-point value (operand n; decimal point excluded) and store this value in device D.

Note:

1. The setting value in operand n should be less than 8. If the value you set is exceeding the maximum value 8, it will be treated as the maximum value 8. For example if n = k6, when you convert the string 123.45678 into a floating-point value, the result is 123.456.
2. If the source value includes not just numeral characters, the non-numeral characters will be treated as 0 when it is shown before the decimal point and it will be treated as the ending character when it is shown after the decimal point. For example if n = k6, when you convert the string BC12.4K59 into a floating-point value, the result is 0012.4.
3. If there is no decimal point in the string, the string is converted directly into a floating-point value. See the illustration below for reference.




- **When m=19:**

Convert the floating-point value in source device S (Lo-byte) into a string value (operand n; decimal point excluded) and store this value in device D.

Note:

1. The setting value in operand n should be less than 8. If the value you set is exceeding the maximum value 8, it will be treated as the maximum value 8. For example if  $n = k6$ , when you convert the floating-point value F123.45678 into a string value, the result is 123.456.
2. If the source value is bigger than the setting value in the operand n, only the value before the decimal point will be converted. For example, if the floating point value is F123456.78 and n is k4, the conversion result is 1234. See the illustration below for reference.



- **When m=42:**

Operand S1:

S1+0, S1+1: X axis target coordinate (relative positioning)

S1+2, S1+3: Y axis target coordinate (relative positioning)

S1+4, S1+5: Shift of the center (integer type) or central angle (floating point type)

S1+6, S1+7: Target reference frequency (1~200000Hz; if exceeding the allowable range, the system uses the maximum or minimum value instead)

S1+8: Function selections

(K0, K1, K2: Shift of the center mode; shifts at 10 degree, 5 degree or 1 degree)

(K10, K11, K12: Central angle; shifts at 10 degree, 5 degree or 1 degree)

Operand D: D+0, D+1: Calculation of the duration of 2-Axis relative-position clockwise arc interpolation; unit:ms

Operand m: Function code K42

Operand n: Reserved

- **When m=43 :**

Operand S1:

S1+0, S1+1: X axis target coordinate (relative positioning)

S1+2, S1+3: Y axis target coordinate (relative positioning)

S1+4, S1+5: Shift of the center (integer type) or central angle (floating point type)

S1+6, S1+7: Target reference frequency (1~200000Hz; if exceeding the allowable range, the system uses the maximum or minimum value instead)

S1+8: Function selections

(K0, K1, K2: Shift of the center mode; shifts at 10 degree, 5 degree or 1 degree)

(K10, K11, K12: Central angle; shifts at 10 degree, 5 degree or 1 degree)

Operand D: D+0, D+1: Calculation of the duration of 2-Axis relative-position anti-clockwise arc interpolation;  
unit: ms

Operand m: Function code K43

Operand n: Reserved

- **When m=44:**

Operand S1: the starting point of PLC input points (K0~K15 → X0.0~X0.15)

Operand D: filtering time; unit: μs (0~20000)

Operand m: function code K44

Operand n: total number of input points to be updated

- **m=46:**

Operand S1: S1+0, S1+1: number of pulse output (relative -position)

S1+2, S1+3: frequency of pulse output (AS324MT Y0.0/Y0.2: 1~4MHz; others: 1~200KHz)

S1+4: device of pulse output (K0~K11 : Y0.0~Y0.11)

Operand D: D+0, D+1: Caculate the relative -position pulse output time in acceleraton and deceleration;  
unit: ms

Operand m: Function code K46

Operand n: Reserved

### Additional remarks

1. Using the matrix variables of Word data type for S and D is recommended.


API	Instruction			Operand							Description						
1228		ZSET	P	SBit, EBit							Zone setup						

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
SBit		●	●	●				●		○						
EBit		●	●	●				●		○						

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
SBit	●												
EBit	●												

Pulse Instruction	16-bit instruction	32-bit instruction
AS	AS	-

**Symbol**



**SBit** : Starting device of the zone


**EBit** : Ending device of the zone

**Explanation**

1. Set the bit in the zone between SBit and EBit to ON. The type of starting and ending devices should be the same before setting up.
2. If the number of SBit is larger than the number of EBit, only EBit can be set. Set the number SBit to a smaller one.
3. Except T, C and HC devices, this instruction is available for bit-type devices and BOOL type data.

**Example**

1. When M0 is ON, the auxiliary relays M300~M399 are ON.



API	Instruction code			Operand						Function					
1229	F	SORT	P	src ~ ref						Sorting data in floating-point format					

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	“\$”	F
src								●								
group								●					○	○		
column								●					○	○		
ref								●					○	○		
dst								●								

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
src									●				
group			●				●						
column			●				●						
ref			●				●						
dst									●				

Pulse instruction	16-bit instruction	32-bit instruction
AS	AS	AS

Symbol

FSORT	
En	
src	dst
group	
column	
ref	

FSORTP	
En	
src	dst
group	
column	
ref	

**src** : First device where the original data is stored

**group** : Number of rows of data

**column** : Number of columns of data

**dst** : First device where the sorted data is stored

**ref** : Reference value for sorting the data


Explanation

- This instruction stores the data to be sorted in the **group×column×2** registers starting from the register specified by **dst**. If **src** and **dst** specify the same register, the sorted data is the same as the original data in the register specified by **src**.
- The operand **group** must be between 1–32. The operand **column** must be between 1–6. The operand **ref** must be between 1– **column**.

8. When SM604 is OFF, the instruction sorts the data in ascending order. When SM604 is ON, the instruction sorts the data in descending order.
9. It is suggested that you use the pulse type instruction, FSORTP, instead of sorting repeatedly.

**Example**

5. Suppose SM604 is OFF. When X0.0 switches from OFF to ON, the instruction sorts the data in ascending order.



6. The data which to be sorted is as in the following table.

		← Number of columns of data column x 2 →				
		columns of data				
		1	2	3	4	5
		Student number	Chinese	English	Math	Physics
Column \ Row	Row					
↑ Number of rows of data : group x 2 ↓	1	(D0,D1) 1.0	(D10,D11) 90.0	(D20,D21) 75.0	(D30,D31) 66.0	(D40,D41) 79.0
	2	(D2,D3) 2.0	(D12,D13) 55.0	(D22,D23) 65.0	(D32,D33) 54.0	(D42,D43) 63.0
	3	(D4,D4) 3.0	(D14,D15) 80.0	(D24,D25) 98.0	(D34,D35) 89.0	(D44,D45) 90.0
	4	(D6,D7) 4.0	(D16,D17) 70.0	(D26,D27) 60.0	(D36,D37) 99.0	(D46,D47) 50.0
	5	(D8,D9) 5.0	(D18,D19) 95.0	(D28,D29) 79.0	(D38,D39) 75.0	(D48,D49) 69.0

7. When the value in D100 is 3, the data is sorted as in the following table.

		Number of columns of data column x 2				
		columns of data				
Column		1	2	3	4	5
Row		Student number	Chinese	English	Math	Physics
↑ Number of rows of data : group x 2 ↓	1	(D50,D51) 4.0	(D60,D61) 70.0	(D70,D71) 60.0	(D80,D81) 99.0	(D90,D91) 50.0
	2	(D52,D53) 2.0	(D62,D63) 55.0	(D72,D73) 65.0	(D82,D83) 54.0	(D92,D93) 63.0
	3	(D54,D55) 1.0	(D64,D65) 90.0	(D74,D75) 75.0	(D84,D85) 66.0	(D94,D95) 79.0
	4	(D56,D57) 5.0	(D66,D67) 95.0	(D76,D77) 79.0	(D86,D87) 75.0	(D96,D97) 69.0
	5	(D58,D59) 3.0	(D68,D69) 80.0	(D78,D79) 98.0	(D88,D89) 89.0	(D98,D99) 90.0

8. When the value in D100 is 5, the data is as in the following table.

		Number of columns of data column x 2				
		columns of data				
Column		1	2	3	4	5
Row		Student number	Chinese	English	Math	Physics
↑ Number of rows of data : group x 2 ↓	1	(D50,D51) 4.0	(D60,D61) 70.0	(D70,D71) 60.0	(D80,D81) 99.0	(D90,D91) 50.0
	2	(D52,D53) 2.0	(D62,D63) 55.0	(D72,D73) 65.0	(D82,D83) 54.0	(D92,D93) 63.0
	3	(D54,D55) 5.0	(D64,D65) 95.0	(D74,D75) 79.0	(D84,D85) 75.0	(D94,D95) 69.0
	4	(D56,D57) 1.0	(D66,D67) 90.0	(D76,D77) 75.0	(D86,D87) 66.0	(D96,D97) 79.0
	5	(D58,D59) 3.0	(D68,D69) 80.0	(D78,D79) 98.0	(D88,D89) 89.0	(D98,D99) 90.0

**Additional remarks**

3. If value in the the device exceeds the range, the instruction is NOT executed, SM0 is ON, and the error code in SR0 is 16#2003.
4. If the value in **group**, **column**, or **ref** exceeds the range, the instruction is NOT executed, SM0 is ON, and the error code in SR0 is 16#200B.
5. If the value in **src** exceeds the range of a floating-point value, the instruction is NOT executed, SM0 is ON, and the error code in SR0 is 16#2013.

## 6.14 Structure Creation Instructions

### 6.14.1 List of Structure Creation Instructions

The following table lists the Data Processing instructions covered in this section.

API	Instruction code		Pulse instruction	Function
	16-bit	32-bit		
<b><u>1300</u></b>	FOR	–	–	Starting a nested loop
<b><u>1301</u></b>	NEXT	–	–	Ending a nested loop
<b><u>1302</u></b>	BREAK	–	–	Terminating a FOR-NEXT loop

### 6.14.2 Explanation of Structure Creation Instructions


API	Instruction code			Operand								Function				
1300		FOR		S								Starting a nested loop				

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	“\$”	F
S	●	●			●	●		●			●	○	○	○		

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
S		●				●							

Pulse instruction	16-bit instruction	32-bit instruction
-	AS	-

**Symbol**



**S** : Number of times the loop is executed

**Explanation**

Refer to the NEXT instruction (API 1301) for more details.


API	Instruction code		Operand	Function
1301		NEXT	-	Ending a nested loop
		Pulse instruction	16-bit instruction	32-bit instruction
		-	AS	-

**Symbol****Explanation**

- This instruction executes the program between the FOR and NEXT instructions N times, where N is the value in **S** specified for the FOR instruction (API 1300). After the program between the FOR and NEXT instructions is executed N times, the program following the NEXT instruction is executed. The instruction FOR specifies the number of times the program between the FOR and NEXT instructions is executed.
- N must be between 1–32,767. If N is less than 1, the instruction processes it as 1.
- If you do not want to execute the program between the FOR and NEXT instructions, you can skip it with the CJ instruction (API 0400).
- The following conditions result in errors.
  - The NEXT instruction is prior to the FOR instruction.
  - The FOR instruction exists, but the NEXT instruction does not exist.
  - The NEXT instruction follows the FEND or END instruction.
  - The number of times the FOR instruction is used in the program is different from the number of times the NEXT instruction is used in the program.
- The FOR and NEXT instructions support the nested program structure. There can be at most 32 levels of nested program structures. If a loop is executed many times, it takes more time for the PLC to scan the program, and the watchdog timer error may occur. You can use the WDT instruction (API 1900) to resolve the problem.


**Example 1**


After program A is executed three times, the program following the instruction NEXT is executed. Program B is executed four times every time program A is executed. Therefore, program B is executed twelve times in total.



**Example 2**


When X0.0 is OFF, the program between FOR and NEXT is executed. When X0.0 is ON, the CJ instruction is executed. The execution of the program jumps to LABEL 1; i.e. network 6, and network 4-5 are not executed.







**Example 3**

If the program between FOR and NEXT is not to be executed, you can skip it with the CJ instruction. When X0.1 in network 8 is ON, the instruction CJ is executed. The execution of the program jumps to LABEL 1; i.e. network 12, and network 9–11 are not executed.





6



**Additional remarks**

Refer to the ISPSOft User Manual for more information on using labels.


API	Instruction code			Operand							Function					
1302		BREAK		D							Terminating the FOR-NEXT loop					

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	“\$”	F
D		●			●	●		●			○	○				

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
D		●				●							

Pulse instruction	16-bit instruction	32-bit instruction
-	AS	-

**Symbol**




**D** : Device where the remaining number of times the loop can be executed is stored

**Explanation**

1. This instruction terminates the FOR/NEXT loop. The remaining number of times the FOR/NEXT loop can be repeated is stored in **D**. After the loop has executed **D** times, the program jumps to the NEXT instruction and executes the instruction after the NEXT instruction.
2. When the instruction is executed, the remaining number of times the FOR/NEXT loop can be repeated is stored in **D**, including this time the instruction BREAK is executed.
3. When the BREAK instruction is executed for the first time to terminate the FOR/NEXT loop, the program does not jump out of the FOR/NEXT loop to execute the next instruction. If the BREAK instruction is executed more than one time to terminate the FOR/NEXT loop, the program jumps to the NEXT instruction and executes the instruction following the NEXT instruction.

**Example**

When the FOR/NEXT loop is executed, 1 is added to the value in D0. When the value in D0 is equal to 30, the FOR/NEXT loop is terminated, and the remaining number of times the FOR/NEXT loop can be repeated, i.e. 71, is stored in D10. The execution of the program jumps to LABEL 1:, i.e. network 6, and 1 is added to the value in D2.



#### Additional remarks

1. If the instruction BREAK is outside the FOR/NEXT loop, it causes an operation error, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2017.
2. Refer to the ISPSOft User Manual for more information on using labels.

## 6.15 Module Instructions

### 6.15.1 List of Module Instructions

The following table lists the Module instructions covered in this section.

API	Instruction code		Pulse instruction	Function
	16-bit	32-bit		
<b><u>1400</u></b>	FROM	DFROM	✓	Reading data from the control register in an extension module
<b><u>1401</u></b>	TO	DTO	✓	Writing data into the control register in an extension module
<b><u>1402</u></b>	PUCONF	DPUCONF	✓	Setting output control parameters of PU module
<b><u>1403</u></b>	PUSTAT	–	–	Reading PU module output state
<b><u>1404</u></b>	–	DPUPLS	–	PU module output pulse (no acceleration)
<b><u>1405</u></b>	–	DPUDRI	–	Relative position output of PU module (with acceleration and deceleration)
<b><u>1406</u></b>	–	DPUDRA	–	Absolute addressing output of PU module (with acceleration and deceleration)
<b><u>1407</u></b>	–	DPUZRN	–	PU module homing
<b><u>1408</u></b>	–	DPUJOG	–	PU module jog output
<b><u>1409</u></b>	–	DPUMPG	–	PU module MPG output
<b><u>1410</u></b>	–	DPUCNT	–	High-speed counter function of PU module
<b><u>1415</u></b>	–	DLCCAL	–	LC module channel calibration
<b><u>1416</u></b>	–	DLCWEI	–	Reading weight value via LC module
<b><u>1417</u></b>	–	DMPID	–	PID algorithm for RTD/TC module
<b><u>1418</u></b>	–	DHCCNT	–	HC module counter value counted
<b><u>1419</u></b>	–	DHCCAP	–	HC module counter value captured
<b><u>1420</u></b>	HCDO	–	–	HC module digital output point
<b><u>1421</u></b>	–	DHCCMP	–	HC module counter value in comparison for output
<b><u>1422</u></b>	–	DHCCMPT	–	HC module counter value in group comparison for output
<b><u>1423</u></b>	–	DHCMEAS	–	HC module measurements of frequency and revolution
<b><u>1424</u></b>	ADLOG	DADLOG	–	Record data of analog input module
<b><u>1425</u></b>	ADPEAK	DADPEAK	–	Record peak data of analog input module
<b><u>1426</u></b>	IOLINKR	–	–	Read the parameter from the O-Link device
<b><u>1427</u></b>	IOLINKW	–	–	Write the parameter into the IO-Link device
<b><u>1430</u></b>	MLPF	–	–	Digital low-pass filter for analog input signals

### 6.15.2 Explanation of Module Instructions

API	Instruction code			Operand							Function			
1400	D	FROM	P	$m_1, m_2, m_3, D_1, D_2, n$							Reading data from the control register in an extension module			

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
$m_1$					●	●	●	●	●		○	○	○	○		
$m_2$					●	●	●	●	●		○	○	○	○		
$m_3$					●	●	●	●	●		○	○	○	○		
$D_1$					●	●	●	●								
$D_2$					●	●	●	●								
$n$					●	●	●	●	●		○	○	○	○		

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
$m_1$		●	●			●	●						
$m_2$		●	●			●	●						
$m_3$		●	●			●	●						
$D_1$		●	●			●	●						
$D_2$		●	●			●	●						
$n$		●	●			●	●						

Pulse instruction	16-bit instruction	32-bit instruction
AS	AS	AS

#### Symbol

FROM	FROMP
En	En
$m_1$	$m_1$
$m_2$	$m_2$
$m_3$	$m_3$
$n$	$n$
DFROM	DFROMP
En	En
$m_1$	$m_1$
$m_2$	$m_2$
$m_3$	$m_3$
$n$	$n$


- $m_1$  : CPU module number or the remote extension module number
- $m_2$  : Order numbers of the extension number
- $m_3$  : Control register number
- $D_1$  : Device where the data is stored
- $D_2$  : Device where the error code is stored
- $n$  : Data length

### Explanation

1. This instruction reads data from the control register in an extension module. All registers are listed and detailed in the AS Series Module Manual.
2. The value in  $m_1$  must be between 0–16. Zero represents the CPU module, and 1–16 represent the extension modules.
3. The operand  $m_2$  represents the number of the right-side extension modules that are connected to the CPU module or to the remote modules. The first device is number 1, the second device is number 2 and so on. Any types of connected modules are counted and up to 32 devices can be connected.
4. The operand  $m_3$  specifies the control register number.
5. The FROM instruction sets  $D_2$  to 0. When an error occurs, the instruction does not set  $D_2$  to 0. Refer to the Additional remarks below for more information about the error codes. When the instruction is not executed,  $D_2$  does not contain an error code.
6. The operand  $n$  must be between 1–8.
7. Only the 32-bit instructions can use the 32-bit counter, but not the device E.

### Example

When X0.0 is switched from OFF to ON, the instruction reads the data stored in CR#2 from the right side of the first module and stores the data in D100. If no error occurs, the code in D110 is 16#0000.



### Additional remarks

1. If the values in  $m_1$  and  $m_2$  exceed their range, an operation error occurs, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2003.
2. If  $D_1$  to  $D_1+n-1$  exceed the device range, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2003.
3. If the value in  $n$  exceeds the range, the operation error occurs, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#200B.

4. Due to the fact that the FROM instruction decreases the execution efficiency of both the CPU module and the I/O module, it is suggested that you use the pulse type instruction to perform a single trigger as in the example shown above.
5. If there is any error response from the modules, the instruction stores the error code in **D<sub>2</sub>**. The error code descriptions shown in the following table.

Error code	Description
16#1400	Attempted to read the data from the control register (CR) in the module but no such CR number exists.
16#1401	The value is not valid for the module.
16#1402	The module is not responding, communication timeout.

API	Instruction code			Operand							Function					
1401	D	TO	P	<b>m<sub>1</sub>, m<sub>2</sub>, m<sub>3</sub>, S, D, n</b>							Writing data into the control register in an extension module					

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
<b>m<sub>1</sub></b>					●	●	●	●	●		○	○	○	○		
<b>m<sub>2</sub></b>					●	●	●	●	●		○	○	○	○		
<b>m<sub>3</sub></b>					●	●	●	●	●		○	○	○	○		
<b>S</b>					●	●	●	●	●				○	○		
<b>D</b>					●	●	●	●								
<b>n</b>					●	●	●	●	●		○	○	○	○		

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
<b>m<sub>1</sub></b>		●	●			●	●						
<b>m<sub>2</sub></b>		●	●			●	●						
<b>m<sub>3</sub></b>		●	●			●	●						
<b>S</b>		●	●			●	●						
<b>D</b>		●	●			●	●						
<b>n</b>		●	●			●	●						

Pulse instruction	16-bit instruction	32-bit instruction
AS	AS	AS

6

Symbol




- m<sub>1</sub>** : CPU module number or the remote extension module number
- m<sub>2</sub>** : Order numbers of the extension number
- m<sub>3</sub>** : Control register number
- S** : Device where the data is stored
- D** : Device where the error code is stored
- n** : Length of the data to be written

### Explanation

1. This instruction writes data to the control register in an extension module. All registers are listed and detailed in the AS Series Module Manual.
2. The value in  $m_1$  must be between 0–16. Zero represents the CPU module, and 1–16 represent the extension modules.
3. The operand  $m_2$  represents the number of the right-side extension modules that are connected to the CPU module or to the remote modules. The first device is number 1, the second device is number 2 and so on. Any types of connected modules are counted and up to 32 devices can be connected.
4. The operand  $m_3$  specifies the control register number.
5. The TO instruction sets  $D$  to 0. When an error occurs, the instruction does not set  $D_2$  to 0. Refer to the Additional remarks below for more information about the error codes. When the instruction is not executed,  $D$  does not contain an error code.
6. The operand  $m_1$  must be between 1–8.
7. Only the 32-bit instructions can use the 32-bit counter, but not the device E.
8. When  $S$  is a hexadecimal value, the instruction transmits  $n$  hexadecimal values to the I/O module. Supposing  $S$  is 16#0001 and  $n$  is 3. The instruction transmits three 16#0001s to the I/O module.

### Example

When X0.0 switches from OFF to ON, the TO instruction writes the data stored in D100 to CR#2 in the right side of the first module. If no error occurs, the code in D110 is 16#0000.



**Additional remarks**

1. If the values in **m<sub>1</sub>** and **m<sub>2</sub>** exceed their range, an operation error occurs, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2003.
2. If **D<sub>1</sub>-D<sub>1</sub>+n-1** exceed the device range, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2003.
3. If the value in **n** exceeds the range, the operation error occurs, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#200B.
4. Due to the fact that the TO instruction decreases the execution efficiency of both the CPU module and the I/O module, it is suggested that you use the pulse type instruction to perform a single trigger as in the example shown above.
5. If there is any error response from the modules, the instruction stores the error code in **D<sub>2</sub>**. The error code descriptions are shown in the following table.

Error code	Description
16#1400	Attempted to read the data from the control register (CR) in the module but no such CR number exists.
16#1401	The value is not valid for the module.
16#1402	The module is not responding, communication timeout.

API	Instruction				Operand							Description					
1402	D	PUCONF	P	Module ~ Error, ErrCode							Setting output control parameters of PU module						
Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F	
Module								●					○	○			
Axis								●					○	○			
Mode								●					○	○			
SSpeed								●					○	○			
Atime								●					○	○			
Dtime								●					○	○			
MSpeed								●					○	○			
Z_no								●					○	○			
Offset								●					○	○			
Done		●	●	●				●									
Error		●	●	●				●									
ErrCode								●									

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
Module		●				●							
Axis		●				●							
Mode		●				●							
SSpeed		●				●							
Atime		●				●							
Dtime		●				●							
MSpeed			●				●						
Z_no		●				●							
Offset		●				●							
Done	●												
Error	●												
ErrCode		●				●							

Pulse Instruction	16-bit instruction	32-bit instruction
AS	—	AS

**Symbol**

DPUCONF		DPUCONF	
En		En	
Module	Done	Module	Done
Axis	Error	Axis	Error
Mode	ErrCode	Mode	ErrCode
SSpeed		SSpeed	
Atime		Atime	
Dtime		Dtime	
MSpeed		MSpeed	
Z_no		Z_no	
Offset		Offset	

- Module** : Module number
- Axis** : Output axis number
- Mode** : Output mode
- SSpeed** : Speed for starting/ ending frequency
- Atime** : Acceleration time
- Dtime** : Deceleration time
- MSpeed** : Maximum output frequency
- Z\_no** : Number of Z phases to look for after returning to the home position
- Offset** : Specify the number of outputs after returning to the home position
- Done** : Completion flag
- Error** : Error flag
- ErrCode** : Error code

**Explanation**

1. This instruction is available for PLC with FW V1.08.00 or later. For ISPSOFT, we recommend using software version 3.12 and above. The timing to set this instruction is when the En setting changes from OFF to ON.
2. **Module** sets the serial number of modules at the right of the PLC. The first one is number 1, the second one is number 2 and so on. Whatever modules at the right of the PLC must be numbered. The maximum number is 32. The instruction is exclusive to the PU modules at the right of the PLC and is not applicable to the PU modules at the right of the remote module. If the specified module is not a PU module, the error flag **Error** will change to ON.
3. **Axis** sets the output axis number for the specified PU module. The setting values 1~4 represent the axis1~axis4 output of the specified PU module respectively. If the PU module has no corresponding axis number for output, the error flag **Error** will change to ON.

See the following combination of axis numbers and corresponding output points of PU modules.

PU module name	Axis 1	Axis 2	Axis 3	Axis 4
AS02PU	Y0.0 / Y0.1	Y0.2 / Y0.3	NA	NA
AS04PU	Y0.0 / Y0.1	Y0.2 / Y0.3	Y0.4 / Y0.5	Y0.6 / Y0.7

4. **Mode** sets the output mode of an output axis and the setting values are explained in the following table.

Output mode value	Description	Remark
0	Single-point Output pulse (An even-number point for output only)	E.g. Y0.0 or Y0.2 for output
1	Pulse (An even-number point) + direction	E.g. Y0.0 is for the pulse and Y0.1 is for the

	(An odd-number point)	direction. Y0.1: ON, negative direction; Y0.1: OFF, positive direction
2	CW (An even-number point) + CCW (An odd-number point)	E.g. Y0.0 is for CW (positive direction) and Y0.1 is for CCW (negative direction)
3	Phase A (An even-number point) + Phase B (An odd-number point)	E.g. Y0.0 is for phase A and Y0.1 is for phase B. When phase A is leading phase B: positive direction; when phase B is leading phase A: negative direction
Other value	Automatically switch to mode 1 (default value)	

#### 5. **SSpeed~ Offset**

See the explanation of the following non-latched parameters and setting values. If the setting values exceed the range, the instruction will automatically be executed at the minimum or maximum value.

Parameter	Function	Range	Default	Remark
<b>SSpeed</b>	Starting/ending frequency	0 ~ 10,000 (Unit: Hz)	100	
<b>Atime</b>	Acceleration time	0 ~ 10,000 (Unit: ms)	100	
<b>Dtime</b>	Deceleration time	0 ~ 10,000 (Unit: ms)	100	
<b>MSpeed</b>	Maximum output frequency	AS02PU: 100 ~ 200,000 (Unit: Hz)	200K	A 32-bit value
		AS04PU: 100 ~ 100,000 (Unit: Hz)	100K	
<b>Z_no</b>	Number of Z phase signals to seek after returning to the origin.	-100 ~ 100 (Unit: times)	0	0: disabled
<b>Offset</b>	Outputs the offset position after the homing is finished and Z phase seeking is done.	-10,000 ~ 10,000 (Unit: pulses)	0	0: disabled

6. **Done**, an output of the specified PU module has been set as the completion flag. When **Done** is On, it indicates that the parameter setting is successful. You can continue to perform positioning output based on the state of the completion flag (ON). The clearing of the **Done** flag need be conducted by manual. The **Done** flag changes to ON only when the setting is completed.
7. **Error**, an output of the specified PU module is a parameter error flag. Most parameter ranges are filtered automatically by the PLC. Thus if the error flag is ON, it means that there is no specified PU module or the PU module number is wrong or the output axis number is incorrect.

8. The instruction is a pulse instruction. Even if the A contact is adopted as the condition contact, PU module parameters are also set only when the instruction is started. Therefore, if a parameter value is to be updated, restart the instruction to make the parameter set again.
9. Since the set parameters are delivered through the module communication command, confirm the state of the output **Done** or **Error** before a parameter value is modified and then proceed with relevant operations.
10. **ErrCode** shows error codes. See the description as follows.

Error code	Description
16#1400	The module does not support the function.
16#1401	The data stored in the module is illegal or exceeds the allowed range.
16#1402	There is no response from the module; communication timeout occurs.

**Programming Example:** Refer to the description of DPUDRI instruction (API 1405) for more information.


API	Instruction				Operand								Description				
1403		PUSTAT			Module ~ ErrCode								Reading PU module output state				

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
Module								●					○	○		
Axis								●					○	○		
ZeroS	●	●	●	●				●								
C_Pos								●								
Execute		●	●	●				●								
Pause		●	●	●				●								
Error		●	●	●				●								
ErrCode								●								

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
Module		●				●							
Axis		●				●							
ZeroS	●												
C_Pos			●				●						
Execute	●												
Pause	●												
Error	●												
ErrCode		●				●							

Pulse Instruction	16-bit instruction	32-bit instruction
—	AS	—

Symbol



- Module** : Module number
- Axis** : Output axis number
- ZeroS** : Clear present output position to 0
- C\_Pos** : Current output position
- Execute** : Execution flag
- Pause** : Pause flag
- Error** : Error flag
- ErrCode** : Error code

**Explanation**

1. This instruction is available for PLC with FW V1.08.00 or later. For ISPSOft, we recommend using software version 3.12 and above. The En setting must be set to ON so as to update the status of the selected axes continuously.
2. **Module** sets the serial number of modules at the right of the PLC. The first one is number 1, the second one is number 2 and so on. Whatever modules at the right of the PLC must be numbered. The maximum number is 32. The instruction is exclusive to the PU modules at the right of the PLC and is not applicable to the PU modules at the right of the remote module. If the specified module is not a PU module, the error flag **Error** will change to ON.
3. **Axis** sets the output axis number for the specified PU module. The setting values 1~4 represent the axis1~axis4 output of the specified PU module respectively. If the PU module has no corresponding axis number for output, the error flag **Error** will change to ON.
4. **C\_Pos** sets the present position of the output axis for the specified PU module. The parameter value is a latched value and stored in the PU module. If the value is to be cleared to 0, set **ZeroS** from OFF to ON when the instruction is started.
5. **Execute** is an only-read flag which means the output axis of the specified PU module is outputting or not. When **Execute** is On, it means the output is being conducted. When **Execute** is Off, it means the output axis is unused and can accept the next output command.
6. **Pause** is an only-read flag to control the output axis of the specified PU module to pause its output. When **Pause** is On, it means the output is paused, the present velocity is 0 and the present output has not reached the specified target output position. If you restore the output, the flag will be cleared automatically.

Note: While **Pause** is On, **Execute** is constantly On as well.

7. **Error** is an only-read error flag which means an error occurs during the reading of the specified PU module. Refer to the explanation of error codes in **ErrCode**.
8. After the PUSTAT instruction gives the pause command, the flags **Execute**, **Pause** and **Error** become read-only flags and at the moment, their states cannot be modified. The **Execute**, **Pause** and **Error** flags can be set or cleared only when the PUSTAT instruction is turned off.
9. **ErrCode** shows error codes and the explanations are seen in the following table.

Error code	Description
16#1400	The module does not support the function.
16#1401	The data stored in the module is illegal or exceeds the allowed range.
16#1402	There is no response from the module; communication timeout occurs.
16#1403	There is no such output axis number in the PU module.
16#1404	The output frequency of the PU module is illegal.
16#1405	The output axis specified by the PU module is outputting data. It is not allowed to specify the output repeatedly.

**Programming Example:** Refer to the description of DPUDRI instruction (API 1405) for more information.


API	Instruction			Operand							Description						
1404	D	PUPLS		Module ~ ErrCode							PU module output pulse (no acceleration)						

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
Module								●					○	○		
Axis								●					○	○		
TarPulse								●					○	○		
TarSpeed								●					○	○		
Done		●	●	●				●								
Error		●	●	●				●								
ErrCode								●								

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
Module		●				●							
Axis		●				●							
TarPulse			●				●						
TarSpeed			●				●						
Done	●												
Error	●												
ErrCode		●				●							

Pulse Instruction	16-bit instruction	32-bit instruction
—	—	AS

**Symbol**



- Module** : Module number
- Axis** : Output axis number
- TarPulse** : Target number of output pulses
- TarSpeed** : Target output frequency
- Done** : Completion flag
- Error** : Error flag
- ErrCode** : Error code

**Explanation**

- This instruction is available for PLC with FW V1.08.00 or later. For ISPSOft, we recommend using software version 3.12 and above. When En setting is set to ON, this instruction would be effective. Once the setting changes to OFF, Output pulse would be terminated immediately.
- Module** sets the serial number of modules at the right of the PLC. The first one is number 1, the second one is number 2 and so on. Whatever modules at the right of the PLC must be numbered. The maximum number is 32.

The instruction is exclusive to the PU modules at the right of the PLC and is not applicable to the PU modules at the right of the remote module. If the specified module is not a PU module, the error flag **Error** will change to ON.

3. **Axis** sets the output axis number for the specified PU module. The setting values 1~4 represent the axis1~axis4 output of the specified PU module respectively. If the PU module has no corresponding axis number for output, the error flag **Error** will change to ON.
4. **TarPulse** sets the number of output pulses. The pulse number is a positive signed 32-bit value. When the value is 0, it means the output is always being performed, the number of output pulses is not limited and the output is not stopped until the instruction is disabled. When the value is less than 0, the PLC automatically uses 2s complement to transform the value into a positive integer as the number of output pulses.
5. **TarSpeed** sets the target output speed (Unit: Hz). The input value is a signed 32-bit. You can modify the target frequency any time after the instruction is enabled and the PU module will automatically switch to the newly set target frequency after outputting a full pulse.

Note: Before the target frequency is changed, please take into consideration whether the modified speed and PLC scan time match or not.

Module Name	TarSpeed Setting Range
AS02PU	-200,000 (-200K) ~ 200,000 (200K)
AS04PU	-100,000 (-100K) ~ 100,000 (100K)


6. When **TarSpeed** is a positive number (>0), it means that the “positive direction” output point is Off. When **TarSpeed** is a negative number (<0), it means that the “negative direction” output point is On. When **TarSpeed** is 0, it means that the output will be paused after the being executed pulse is output fully.
7. The instruction does not support the function of acceleration and deceleration. Use the DPUDRI instruction instead if you need the function of acceleration and deceleration.
8. The instruction can be used for the speed change. While the instruction is being executed, you can change the value of **TarSpeed** so as to change the output speed.
9. When the outputs have reached the pulse number specified by **TarPulse**, the **Done** flag changes to ON. The **Done** flag need be cleared by manual. The instruction sets the completion flag to ON only when the output is completed.
10. If any error occurs as the instruction is in process of the output, the **Error** flag changes to ON. Refer to the error codes **ErrCode** shows for the trouble shooting.

The error codes that **ErrCode** shows are listed in the following table.

Error code	Description
16#1400	The module does not support the function.
16#1401	The value stored in the module is illegal or exceeds the allowed range.
16#1402	There is no response from the module; communication timeout occurs.
16#1403	There is no such output axis number in the PU module.
16#1404	The output frequency of the PU module is illegal.
16#1405	The output axis specified by the PU module is outputting data. It is not allowed to specify the output repeatedly.
16#1406	PU module stops Output pulse when the positive limit is reached.
16#1407	PU module stops Output pulse when the negative limit is reached.

### Programming Example

1. Set the output point of AS02PU to be "Pulse Y0.0+ direction Y0.1" in HWCONFIG. All parameters of axis 1 are set as default.
2. When M0=ON, execute DPUPLS on axis 1, outputting 20,000 pulses from Y0.0 at a frequency of 2kHz (without acceleration and deceleration). When Y0.1=OFF, the direction is positive.
3. After Output pulses completed, M1 changes to ON.



API	Instruction			Operand							Description				
1405	D	PUDRI		Module ~ ErrCode							Relative position output of PU module (with acceleration and deceleration)				

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
Module								●					○	○		
Axis								●					○	○		
RTarPosi								●					○	○		
TarSpeed								●					○	○		
Done		●	●	●				●								
Error		●	●	●				●								
ErrCode								●								

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
Module		●				●							
Axis		●				●							
RTarPosi			●				●						
TarSpeed			●				●						
Done	●												
Error	●												
ErrCode		●				●							

Pulse Instruction	16-bit instruction	32-bit instruction
—	—	AS

**Symbol**

DPUDRI	
En	
Module	Done
Axis	Error
RTarPosi	ErrCode
TarSpeed	

- Module** : Module number
- Axis** : Output axis number
- RTarPosi** : Number of output pulses for relative positioning
- TarSpeed** : Target output frequency
- Done** : Completion flag
- Error** : Error flag
- ErrCode** : Error code

**Explanation**

- This instruction is available for PLC with FW V1.08.00 or later. For ISPSOft, we recommend using software version 3.12 and above. When En setting is set to ON, this instruction would be effective. Once the setting changes to OFF, Output pulse would decelerate until it stops.
- Module** sets the serial number of modules at the right of the PLC. The first one is number 1, the second one is number 2 and so on. Whatever modules at the right of the PLC must be numbered. The maximum number is 32. The instruction is exclusive to the PU modules at the right of the PLC and is not applicable to the PU modules at the right of the remote module. If the specified module is not a PU module, the error flag **Error** will change to ON.


3. **Axis** sets the output axis number for the specified PU module. The setting values 1~4 represent the axis1~axis4 output of the specified PU module respectively. If the PU module has no corresponding axis number for output, the error flag **Error** will change to ON.
4. **RTarPosi** sets the position for relative positioning. The pulse number is a signed 32-bit value. When the value is greater than 0, the output will go in the positive direction (and the direction output point is off). When the value is less than 0, the output will go in the negative direction (and the direction output point is on). When the value is 0, the output completion flag **Done** changes to ON.
5. **TarSpeed** sets the target output frequency (Unit: Hz). The frequency value is a positive signed 32-bit integer. When the value is less than 0, the instruction will automatically use 2's complement to transform the value into a positive integer. When the value is 0, the instruction will notify the module to enter the pause mode. The actual output is decelerated at the deceleration rate till the output speed is equal to 0 and the pause flag changes to ON. Refer to PUSTAT instruction for more details.

Module Name	TarSpeed Setting Range
AS02PU	-200,000 (-200K) ~ 200,000 (200K)
AS04PU	-100,000 (-100K) ~ 100,000 (100K)

6. After the output is started, the target frequency is allowed to change any time. In the actual frequency change, the PLC will automatically change the frequency based on the set acceleration and deceleration rate in the DPUCONF instruction.
7. When the outputs have reached the pulse number for relative positioning specified by **RTarPosi**, the **Done** flag changes to ON. The **Done** flag need be cleared by manual. The instruction sets the completion flag to ON only when the output is completed.
8. If any error occurs as the instruction is in process of the output, the **Error** flag changes to ON. Refer to the error codes that **ErrCode** shows for the trouble shooting.
9. The error codes that **ErrCode** shows are listed in the following table.

Error code	Description
16#1400	The module does not support the function.
16#1401	The data stored in the module is illegal or exceeds the allowed range.
16#1402	There is no response from the module; communication timeout occurs.
16#1403	There is no such output axis number in the PU module.
16#1404	The output frequency of the PU module is illegal.
16#1405	While the output axis specified by the PU module is outputting data, it is not allowed to specify the output repeatedly.
16#1406	PU module stops Output pulse when the positive limit is reached.
16#1407	PU module stops Output pulse when the negative limit is reached.

## 10. Illustration of the acceleration and deceleration curve of the DPUDRI instruction



- ①: Maximum output frequency value. Refer to the setting in the DPUCONF instruction for the parameter setting. Alternatively, set the parameter value through HWCONFIG.
- ②: The target frequency specified by the PU module output instruction. The target frequency output must not exceed the maximum output frequency. If the maximum output frequency is exceeded, the maximum output frequency is regarded as the output frequency.
- ③: Starting/ending output frequency value. Refer to the setting in the DPUCONF instruction for the parameter setting. Alternatively, set the parameter value through HWCONFIG.
- ④: The acceleration time value. Refer to the setting in the DPUCONF instruction for the parameter setting. Alternatively, set the parameter value through HWCONFIG.
- ⑤: The deceleration time value. Refer to the setting in the DPUCONF instruction for the parameter setting. Alternatively, set the parameter value through HWCONFIG.

The acceleration and deceleration that the PU module controls is performed according to the fixed slope. So the actual acceleration time and deceleration time change based on the output target frequency. The formula for calculation of acceleration rate and deceleration rate are respectively shown as follows.

$(\text{Max. output frequency} - \text{starting frequency}) / \text{acceleration time};$

$(\text{Max. output frequency} - \text{ending frequency}) / \text{deceleration time}.$

**Programming Example:**


1. Configure parameters of AS02PU module in HWCONFIG. Set "Axis 1, DOG, Rising-edge triggered" for input point X0.0, "Axis 1, Z phase, Rising-edge triggered" for input point X0.1 and "Phase A Y0.0+ Phase B Y0.1" for output point. Other parameters of axis 1 are set as default.

2. When M10 is set to ON, DPUCONF instruction would be executed for axis1 to change the output setting to 1 (Pulse Y0.0+ Direction Y0.1) in Mode. Set SSspeed (the speed for starting) to 200Hz, Atime (acceleration time) to 200 ms, Dtime (deceleration time) to 200ms, MSpeed (maximum output frequency) to 100kHz, Z\_NO (Number of Z phases to look for after returning to the home position) to 1, offset (the number of outputs after returning to the home position) to -100, and set M11 to ON when the Done flag changes to ON.
3. When M0=ON, execute PUSTAT on axis1 to read the PU module output state. To clear current output position, you can set M1 to ON so the current position of (rising-edge triggered) D0 on axis1 would be clear to 0.
4. When M20=ON, execute DPUZRN to perform homing on axis1 and execute DPUSTAT to display the current position in D0. The output point Y0.0 outputs pulses at 1 kHz frequency to search home in positive direction. Once the near home signal (DOG) is reached and X0.0=ON, the axis starts decelerating and moving in the negative direction in the Jogspeed of 100Hz. When X0.0=OFF, the axis moves in the positive direction to search for Z phase until the first rising-edge triggered signal of X0.1 (Z phase) is detected, then moves in negative direction after 100 output pulses are complete. Finally, M21 would change to ON after the Done flag changes to ON.
5. Once M30=ON, DPUDRI would be executed on axis 1 to perform relative positioning output. And execute DPUSTAT to display the current position in D0. And from there, the output point Y0.0 outputs 20,000 pulses at 2 kHz frequency (relative addressing). If Y0.1=OFF, the direction is positive. Execute DPUSTAT to display the current position in D0. Finally, M31 would change to ON after the Done flag changes to ON.

Input Point Setting						
	Name	Setting Value	Unit	Default	Minimum	Maximum
▶	X0.0 Mode	Axis 1 DOG Raise edge trigger ▼		General Input	-	-
	X0.1 Mode	Axis 1 Z Raise edge trigger ▼		General Input	-	-
	X0.2 Mode	General Input ▼		General Input	-	-
	X0.3 Mode	General Input ▼		General Input	-	-
	X0.4 Mode	General Input ▼		General Input	-	-
	X0.0 Filter Time	10	ms	10	0	25
	X0.1 Filter Time	10	ms	10	0	25
	X0.2 Filter Time	10	ms	10	0	25
	X0.3 Filter Time	10	ms	10	0	25
	X0.4 Filter Time	10	ms	10	0	25

Output Point Setting						
	Name	Setting Value	Unit	Default	Minimum	Maximum
▶	Y0.0/Y0.1 Output Mode	A phase(Y0.0)+B phase(Y0... ▼		Pulse(Y0.0)+Directi...	-	-
	Y0.2/Y0.3 Output Mode	Pulse(Y0.2)+Direction(Y0.3) ▼		Pulse(Y0.2)+Directi...	-	-

Axis 1						
	Name	Setting Value	Unit	Default	Minimum	Maximum
▶	Start speed	100	Hz	100	0	10000
	Accelerate time	100	ms	100	0	10000
	Decelerate time	100	ms	100	0	10000
	Max speed	200000	Hz	200000	100	200000
	Seek the set number of Z phase after th...	0		0	-100	100
	Output the offset position after the homi...	0	Pulse	0	-10000	10000
	Home mode select	Mode 1 : the axis starts to ... ▼		Mode 1 : the axis st...	-	-
	Negative limited position	0	Pulse	0	-2147483648	2147483647
	Positive limited position	0	Pulse	0	-2147483648	2147483647



6


API	Instruction			Operand							Description						
1406	D	PUDRA		Module ~ ErrCode							Absolute addressing output of PU module (with acceleration and deceleration)						

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
Module								●					○	○		
Axis								●					○	○		
ATarPosi								●					○	○		
TarSpeed								●					○	○		
Done		●	●	●												
Error		●	●	●												
ErrCode								●								

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
Module		●				●							
Axis		●				●							
ATarPosi			●				●						
TarSpeed			●				●						
Done	●												
Error	●												
ErrCode		●				●							

Pulse Instruction	16-bit instruction	32-bit instruction
—	—	AS

Symbol




- Module** : Module number
- Axis** : Output axis number
- ATarPosi** : Number of output pulses for absolute addressing
- TarSpeed** : Target output frequency
- Done** : Completion/pause flag
- Error** : Error flag
- ErrCode** : Error code

**Explanation**

1. This instruction is available for PLC with FW V1.08.00 or later. For ISPSOft, we recommend using software version 3.12 and above. When En setting is set to ON, this instruction would be effective. Once the setting changes to OFF, Output pulse would decelerate until it stops.
2. **ATarPosi** is the position for absolute addressing. The input pulse number is a signed 32 bit value. The PU module will automatically compare it with the present position. If the comparison result is greater than 0, the output will be conducted in the positive direction (and the direction output point is off). If the comparison result is less than 0, the output will be conducted in the negative direction and the direction output point is on). When the value is 0, the instruction sets the **Done** flag to ON.
3. Refer to the DPUDRI instruction for the explanation of other parameters.

**Programming Example:**

1. Configure parameters of AS02PU module in HWCONFIG. Set "Pulse Y0.0+ Direction 0.1" for input point X0.0. Other parameters of axis 1 are set as default.
2. When M0=ON, execute DPUDRA on axis 1 to output pulses from Y0.0 at 2kHz frequency before the current position reaches 20,000 (absolute addressing). The direction would be positive if Y0.1=OFF.
3. After the Output pulse completed, M1 would change to ON.




API	Instruction			Operand							Description						
1407	D	PUZRN		Module ~ ErrCode							PU module homing						

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
Module								●					○	○		
Axis								●					○	○		
Mode								●					○	○		
TarSpeed								●					○	○		
JogSpeed								●					○	○		
Done		●	●	●												
Error		●	●	●												
ErrCode								●								

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
Module		●				●							
Axis		●				●							
Mode		●				●							
TarSpeed			●				●						
JogSpeed		●				●							
Done	●												
Error	●												
ErrCode		●				●							

Pulse Instruction	16-bit instruction	32-bit instruction
—	AS	AS

**Symbol**



- Module** : Module number
- Axis** : Output axis number
- Mode** : Homing mode selection
- TarSpeed** : Maximum output frequency for the homing
- JogSpeed** : The jog frequency for the homing
- Done** : Completion flag
- Error** : Error flag
- ErrCode** : Error code

**Explanation**

- This instruction is available for PLC with FW V1.08.00 or later. For ISPSOft, we recommend using software version 3.12 and above. When En setting is set to ON, this instruction would be effective. Once the setting changes to OFF, Output pulse would stop immediately even if the homing action is not completed.

2. **Module** sets the serial number of modules at the right of the PLC. The first one is number 1, the second one is number 2 and so on. Whatever modules at the right of the PLC must be numbered. The maximum number is 32. The instruction is exclusive to the PU modules at the right of the PLC and is not applicable to the PU modules at the right of the remote module. If the specified module is not a PU module, the error flag **Error** will change to ON.
3. **Axis** sets the output axis number for the specified PU module. The setting values 1~4 represent the axis1~axis4 output of the specified PU module respectively. If the PU module has no corresponding axis number for output, the error flag **Error** will change to ON.
4. **Mode** sets a homing mode. The explanation of modes is shown in the following table.

Mode value	Function description	Use matching input points (set up in HWCONFIG)	Remark
0	Clear the current position to 0.	None	
1	Homing on the home switch; after homing is done, the axis stops in the negative movement direction.	DOG	DOG point is specified in HWCONFIG, positive home switch or negative home switch.
2	Homing on the home switch; after homing is done, the axis stops in the positive movement direction.		
3	After the execution of Mode 1 completes, seek the number of Z phases.	DOG and Z phase input	Use DPUCONF instruction to set up the number of Z phases.
4	After the execution of Mode 2 completes, seek the number of Z phases.		
5	After the execution of Mode 1 completes, output the offset position.	DOG	Use DPUCONF instruction to output the offset position.
6	After the execution of Mode 2 completes, output the offset position.		
7	After the execution of Mode 1 completes, seek the number of Z phases and then output the offset position.	DOG and Z phase input	Use DPUCONF instruction to set up the number of Z phases and then to output the offset position.
8	After the execution of Mode 1 completes, seek the number of Z phases and then output the offset position.		
255	Modify the current output position for the axis.	None	Use the setting value of <b>TarSpeed</b>
Other	Reserved		

Note 1: The specified homing behavior may not be realized if the input points for the selected mode are not used together with the settings in HWCONFIG.

Note 2: Mode 1~4

FW V1.02.00: after the execution of this instruction, the current output position of the axis will not be cleared to zero. You need to use the instruction PUSTAT to clear it.

FW V1.02.10 or later: after the execution of this instruction, the current output position of the axis will be cleared to zero automatically.

Note 3: Mode 5~8

V1.02.00: after the execution of this instruction, the current output position of the axis will not be cleared to zero. You need to use Mode 255 to modify the current output position to clear it.

V1.02.10 or later: after the execution of this instruction, the current output position of the axis will be cleared to zero automatically.

5. **TarSpeed** sets the maximum output frequency for the homing when the mode value is set from 1 to 8. The setting value is a signed 32-bit value. The negative and positive signs indicate the initial direction of homing. The corresponding values in TarSpeed for the modules AS02/04PU are listed below.

Module Name	TarSpeed Setting Range when the mode is between 1 to 8.
AS02PU	-200,000 (-200K) ~ 200,000 (200K)
AS04PU	-100,000 (-100K) ~ 100,000 (100K)

If the mode is 255, the value in TarSpeed is updated as the current output position of the PU module.

6. **JogSpeed** is the jog frequency for reaching the home position. The setting value is a signed 16 bit value within the range of 1~10,000 (Hz).
7. When the specified operation is complete during the execution of the instruction, the **Done** flag changes to ON. The **Done** flag need to be cleared manually. The instruction sets the completion flag to ON only when the output is completed.
8. If any error occurs as the instruction is in process of the output, the **Error** flag changes to ON. Refer to the error codes that **ErrCode** shows for the trouble shooting.
9. The error codes that **ErrCode** shows are listed in the following table.

Error code	Description
16#1400	The module does not support the function.
16#1401	The data stored in the module is illegal or exceeds the allowed range.
16#1402	There is no response from the module; communication timeout occurs.

16#1403	There is no such output axis number in the PU module.
16#1404	The output frequency of the PU module is illegal.
16#1405	The output axis specified by the PU module is outputting data. It is not allowed to specify the output repeatedly.
16#1406	PU module stops Output pulse when the positive limit is reached.
16#1407	PU module stops Output pulse when the negative limit is reached.

**Programming Example:** Refer to the description of DPUDRI instruction (API 1405) for more information.

API	Instruction			Operand							Description						
1408	D	PUJOG		Module - ErrCode							PU module jog output						

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
Module								●					○	○		
Axis								●					○	○		
JogSpeed								●					○	○		
Busy		●	●	●				●								
Error		●	●	●				●								
ErrCode								●								

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
Module		●				●							
Axis		●				●							
JogSpeed			●				●						
Busy	●												
Error	●												
ErrCode		●				●							

Pulse Instruction	16-bit instruction	32-bit instruction
—	—	AS

## Symbol

DPUJOG	
En	
Module	Busy
Axis	Error
JogSpeed	ErrCode

**Module** : Module number

**Axis** : Output axis number

**JogSpeed** : Jog output frequency

**Busy** : Output in execution

**Error** : Error flag

**ErrCode** : Error code

## Explanation

- This instruction is available for PLC with FW V1.08.00 or later. For ISPSOft, we recommend using software version 3.12 and above. When En setting is set to ON, this instruction would be effective. Once the setting changes to OFF, Output pulse would decelerate until it stops.
- Module** sets the serial number of modules at the right of the PLC. The first one is number 1, the second one is number 2 and so on. Whatever modules at the right of the PLC must be numbered. The maximum number is 32. The instruction is exclusive to the PU modules at the right of the PLC and is not applicable to the PU modules at the right of the remote module. If the specified module is not a PU module, the error flag **Error** will change to ON.


- Axis** sets the output axis number for the specified PU module. The setting values 1~4 represent the axis1~axis4 output of the specified PU module respectively. If the PU module has no corresponding axis number for output, the error flag **Error** will change to ON.
- JogSpeed** sets the jog output frequency. The setting value is a signed 32 bit value. When the value is greater than 0, the output will go in the positive direction (and the direction output point is off). When the value is less than 0, the output will go in the negative direction (and the direction output point is on). When the value is 0, the output will stop. The value of JogSpeed can be modified while performing outputs, and the setting range is shown as follows.

Module Name	JogSpeed Setting Range
AS02PU	-200,000 (-200K) ~ 200,000 (200K)
AS04PU	-100,000 (-100K) ~ 100,000 (100K)

- If any error occurs as the instruction is in process of the output, the **Error** flag changes to ON. Refer to the error codes that **ErrCode** shows for the trouble shooting.
- The error codes that **ErrCode** shows are listed in the following table.

Error code	Description
16#1400	The module does not support the function.
16#1401	The data stored in the module is illegal or exceeds the allowed range.
16#1402	There is no response from the module; communication timeout occurs.
16#1403	There is no such output axis number in the PU module.
16#1404	The output frequency of the PU module is illegal.
16#1405	The output axis specified by the PU module is outputting data. It is not allowed to specify the output repeatedly.
16#1406	PU module stops Output pulse when the positive limit is reached.
16#1407	PU module stops Output pulse when the negative limit is reached.


- See the output timing diagram as below. (Jog\_in is the switch to start the instruction **En** and the Busy flag is the **Busy** flag.)



- After the PUJOG instruction is disabled and the **Busy** flag is off, other output control can be carried out.

**Programming Example**

1. Configure parameters of AS02PU module in HWCONFIG. Set "Pulse Y0.0+ Direction 0.1" for the output point. Parameters of axis 1 are set as default.
2. When M0=ON, execute DPUJOG on axis 1 to perform jog outputs. Pulses would be output from Y0.0 at 1kHz frequency. The direction would be positive if Y0.1=OFF.
3. When the instruction is being executed, M1 would change to ON.



API	Instruction			Operand							Description					
1409	D	PUMPG		Module ~ ErrCode							PU module MPG output					

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
Module								●					○	○		
Axis								●					○	○		
InMode								●					○	○		
InPulse								●								
InSpeed								●								
Rate								●								○
OPulse								●								
OSpeed								●								
Error		●	●	●				●								
ErrCode								●								

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
Module		●				●							
Axis		●				●							
InMode		●				●							
InPulse			●				●						
InSpeed			●				●						
Rate									●				
OPulse			●				●						
OSpeed			●				●						
Error	●												
ErrCode		●				●							

Pulse Instruction	16-bit instruction	32-bit instruction
—	—	AS

6

## Symbol

DPUMPG	
En	
Module	OPulse
Axis	OSpeed
InMode	Error
InPulse	ErrCode
InSpeed	
Rate	

<b>Module</b>	: Module number
<b>Axis</b>	: Output axis number
<b>InMode</b>	: Encoder input mode and frequency multiplication for counting
<b>InPulse</b>	: Number of pulses which have been input
<b>InSpeed</b>	: Detected input frequency
<b>Rate</b>	: Input/output rate (floating point number)
<b>OPulse</b>	: Number of pulses which have been output
<b>OSpeed</b>	: Frequency at which pulses are being output
<b>Error</b>	: Error flag
<b>ErrCode</b>	: Error code

## Explanation

- This instruction is available for PLC with FW V1.08.20 or later. For ISPSOft, we recommend using software version 3.12 and above.
- The PUMPG instruction is only applicable to AS02PU module and the firmware for the module must be V1.04.00 or above. When En setting is set to ON, this instruction would be effective. Once the setting changes to OFF, Output pulse would be stopped immediately.
- Module** sets the serial number of modules at the right of the PLC. The first one is number 1, the second one is number 2 and so on. Whatever modules at the right of the PLC must be numbered. The maximum number is 32. The instruction is exclusive to the PU modules at the right of the PLC and is not applicable to the PU modules at the right of the remote module. If the specified module is not a PU module, the error flag **Error** will change to ON.
- Axis** sets the output axis number for the specified PU module. The setting values 1~4 represent the axis1~axis4 output of the specified PU module respectively. If the PU module has no corresponding axis number for output, the error flag **Error** will change to ON.
- InMode** sets the input mode of the encoder source and the frequency multiplication for counting.

See the explanation of **InMode** value in the following table.

Value	Input Modes
	Input mode; set as the following values, otherwise the module will use the defaults to run.
16#0000	Fourfold frequency A/B phase input (default). Phase A leads phase B, indicating counting in the positive direction. Phase B leads phase A, indicating counting in the negative direction.
16#0001	Onefold frequency A/B phase input. Phase A leads phase B, indicating counting in the positive direction. Phase B leads phase A, indicating counting in the negative direction.
16#0002	Twofold frequency A/B phase input. Phase A leads phase B, indicating counting in the positive direction.

	Phase B leads phase A, indicating counting in the negative direction.
16#0003	Reserved
16#0004	Fourfold frequency A/B phase input Phase A leads phase B, indicating counting in the positive direction. Phase B leads phase A, indicating counting in the negative direction.
16#0005	Pulse + directional input (A+/A-: pulse input; B+/B-: directional input) Phase B ON: counting in the negative direction Phase B OFF: counting in the positive direction Phase A: counting is started by rising-edge triggered.
16#0006	Pulse + directional input (A+/A-: pulse input; B+/B-: directional input) Phase B ON: counting in the positive direction Phase B OFF: counting in the negative direction Phase A: counting is started by rising-edge triggered.
16#0007	Single phase pulse input (A+/A-: pulse input) Phase A: counting is started by rising-edge triggered.
Others	Reserved

6. **InPulse** displays the number of already input pulses, which is a signed 32-bit value. Every time the instruction is started, the PU module will automatically clear the value to 0 and then starts counting.

7. **InSpeed** displays the already detected input frequency which is a 32-bit value. The basic time for the frequency detection is 20ms. Therefore, the detected input frequency is 0 if there is no counting value within 20ms. If there is a counting value within 20ms, the output starts at the minimum frequency of 50Hz. Even if **OSpeed** value is lower than 50Hz through the **Rate**-value-based conversion, the output is still conducted at 50Hz.

8. **Rate** is the input / output rate and the value is a floating point number. The number of actual output pulses and frequency are respectively equal to the input pulse number and frequency multiplied by the rate value.

For example: The input frequency is 100Hz and rate is 0.5. So the output frequency is  $100 \times 0.5 = 50\text{Hz}$ . If the maximum output frequency after conversion exceeds 100KHz, the output frequency is limited to 100KHz.

Note: The long-time maximum frequency output may lead to the fact that as the MPG has stopped running, the number of outputs is still increased and the output need keep going until it is complete.

9. **OPulse** shows the number of pulses which have been output. **OSpeed** displays the frequency at which the output is being conducted. They are signed 32-bit values.

10. When the **DPUMPG** instruction is disabled, check the frequency at which the output is being conducted and see if it has reached 0. If the instruction is disabled before the frequency reaches 0, the PU module will stop the output immediately and the output of the pulses which are counted based on the conversion rate will not continue any more.

11. The error codes that **ErrCode** shows are listed in the following table.

Error code	Description
16#1400	The module does not support the function.
16#1401	The data stored in the module is illegal or exceeds the allowed range.
16#1402	There is no response from the module; communication timeout occurs.
16#1403	There is no such output axis number in the PU module.
16#1404	The output frequency of the PU module is illegal.
16#1405	The output axis specified by the PU module is outputting data. It is not allowed to specify the output repeatedly.
16#1406	PU module stops Output pulse when the positive limit is reached.
16#1407	PU module stops Output pulse when the negative limit is reached.

12. When the DPUMPG instruction is enabled or disabled, the PLC will have to notify the module to enable or disable the high-speed counter function. Thus the instruction can not be used with API1410 DPUCNT together. Otherwise it may occur that the two instructions enable or disable the counting of the module with each other.

API	Instruction			Operand							Description			
1410	D	PUCNT		Module ~ ErrCode							High-speed counter function of PU module			

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	“\$”	F
Module								●					○	○		
InMode								●					○	○		
Period								●					○	○		
ZeroS	●	●	●	●				●								
InPulse								●								
InSpeed								●								
Error		●	●	●				●								
ErrCode								●								

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
Module		●				●							
InMode		●				●							
Period		●				●							
ZeroS	●												
InPulse			●				●						
InSpeed			●				●						
Error	●												
ErrCode			●				●						

Pulse Instruction	16-bit instruction	32-bit instruction
—	—	AS

Symbol

DPUCNT	
En	
Module	InPulse
InMode	InSpeed
Period	Error
ZeroS	ErrCode

- Module** : Module number
- InMode** : Encoder input mode and frequency multiplication for counting
- Period** : Period time for capturing the frequency
- ZeroS** : Clear the counter to 0
- InPulse** : Number of pulses which have been input
- InSpeed** : Number of pulses per cycle
- Error** : Error flag
- ErrCode** : Error code

## Explanation

1. This instruction is available for PLC with FW V1.08.00 or later. For ISPSOft, we recommend using software version 3.12 and above.
2. The DPUCNT instruction supports AS02PU module only. When En setting is set to ON, this instruction would be effective. Once the setting changes to OFF, the counting would be stopped immediately.
3. **Module** sets the serial number of modules at the right of the PLC. The first one is number 1, the second one is number 2 and so on. Whatever modules at the right of the PLC must be numbered. The maximum number is 32. The instruction is exclusive to the PU modules at the right of the PLC and is not applicable to the PU modules at the right of the remote module. If the specified module is not a PU module, the error flag **Error** will change to ON.
4. **InMode** sets the input mode of the encoder source and the frequency multiplication for counting.

See the explanation of **InMode** value in the following table.

Note: Phase A leads phase B, indicating counting in the positive direction.

Phase B leads phase A, indicating counting in the negative direction

Value	Input Modes Input mode; set as the following values, otherwise the module will use the defaults to run.
16#0000	Reserved
16#0001	Onfold frequency A/B phase input
16#0002	Twofold frequency A/B phase input
16#0003	Reserved
16#0004	Fourfold frequency A/B phase input (default)
16#0005	Pulse + directional input (A+/A-: pulse input; B+/B-: directional input) Phase B ON: counting in the negative direction Phase B OFF: counting in the positive direction Phase A: counting is started by rising-edge triggered.
16#0006	Pulse + directional input (A+/A-: pulse input; B+/B-: directional input) Phase B ON: counting in the positive direction Phase B OFF: counting in the negative direction Phase A: counting is started by rising-edge triggered.
16#0007	Single phase pulse input (A+/A-: pulse input) Phase A: counting is started by rising-edge triggered.
Others	Reserved

5. **Period** is the setting value of a cycle time for capturing the frequency within the range of 10ms ~ 1000ms. If the setting value exceeds the range, the maximum value or minimum value will be automatically taken as the setting value by the PLC.


6. **InPulse** is the number of already input pulses, which is a signed 32-bit value. The counting value is a latched value. If the value need be cleared to 0, just set **ZeroS** from OFF to ON while the instruction is running.
7. **InSpeed** displays the counting value for every **Period** time, which is a signed 32-bit value. If you need convert it into the value with the unit of Hz, use the calculation formula for conversion by yourself.
8. The error codes that **ErrCode** shows are listed in the following table.

Error code	Description
16#1400	The module does not support the function.
16#1401	The data stored in the module is illegal or exceeds the allowed range.
16#1402	There is no response from the module; communication timeout occurs.
16#1406	The PU module does not support the counting function.

9. When the DPUCNT instruction is enabled or disabled, the PLC will have to notify the module to enable or disable the high-speed counter function. Thus the instruction can not be used with API1409 DPUMPG together. Otherwise it may occur that the two instructions enable or disable the counting of the module with each other.

**Programming Example**

1. When M0=ON, PUCNT would be executed and **InMode** is set to Twofold frequency A/B phase input.
2. When M1=ON, the counted number of pulses on axis 1 in **InPulse** would be cleared.
3. When the number of pulses is 100 and the input frequency is 10Hz, the values in **InPulse** and **InSpeed** will be seen as 200 pulses and 20Hz.



API	Instruction			Operand								Description					
1415	D	LCCAL		Group, Module ~ ErrCode								LC module channel calibration					

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
Group								●					○	○		
Module								●					○	○		
ChNo								●					○	○		
Trigger	●	●	●	●				●								
TPoint								●					○	○		
TWeight								●								
CPoint								●								
Done		●	●	●				●								
ADone		●	●	●				●								
Error		●	●	●				●								
ErrCode								●								

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
Group		●				●							
Module		●				●							
ChNo		●				●							
Trigger	●												
TPoint		●				●							
TWeight									●				
CPoint		●				●							
Done	●												
ADone	●												
Error	●												
ErrCode		●				●							

Pulse Instruction	16-bit instruction	32-bit instruction
—	—	AS

## Symbol

LCCAL	
En	
Group	CPoint
Module	Done
ChNo	ADone
Trigger	Error
TPoint	ErrCode
TWeight	

<b>Group</b>	: Group number
<b>Module</b>	: Module number
<b>ChNo</b>	: Channel number
<b>Trigger</b>	: Trigger the calibration
<b>TPoint</b>	: Number of all calibration points
<b>TWeight</b>	: Calibration weight value
<b>CPoint</b>	: Number of the point for which the calibration has been completed.
<b>Done</b>	: Single-calibration-completed flag
<b>ADone</b>	: All-calibration-completed flag
<b>Error</b>	: Error flag
<b>ErrCode</b>	: Error code

## Explanation


1. This instruction is available for PLC with FW V1.08.00 or later and ISPSOft V3.09 or later.
2. The LCCAL instruction supports AS02LC module only. Before the instruction is used, you should get to know the configuration position of current module from HWCONFIG.
3. **Group** is the group number of the specified LC module connected to the right of the PLC or the remote module. The number of the PLC is 0, the number of the first remote module is 1 and so on. The maximum group number is 15. If the specified module is not a LC module, the **Error** flag will change to ON.
4. **Module** sets the serial number of modules at the right of the PLC. The first one is number 1, the second one is number 2 and so on. Whatever modules at the right of the PLC must be numbered. The maximum number is 32. If the specified module is not a LC module, the error flag **Error** will change to ON.
5. **ChNo** is a channel number of the specified LC module. If the input value is not a channel number of the LC module, the error flag **Error** will change to ON.
6. **Trigger** is the command of triggering the single-point calibration. As **Trigger** changes from OFF to ON, the LC module will be notified for calibration. **Done** changes to ON when the calibration is done. If all-point calibration has been done, **ADone** will change to ON as well. Before the next calibration point is calibrated, you need observe that **Done** has changed to ON and then set **Trigger** to OFF. Then the instruction will clear the **Done** flag as **Trigger** changes from ON to OFF.
7. **TPoint** is the number of total points for calibration. After the instruction is started, the value can not be changed again since the **TPoint** value has been transmitted to the LC module for calibration as the instruction is started initially.
8. **TWeight** is the calibration weight value and it occupies two devices. If the **TPoint** is 3 and the starting device for **TWeight** is D200, here **TWeight** occupies 6 devices, D200~D205. The calibration weight value for the first **TPoint** is in D200 (Low Word) and D201 (High Word). The calibration weight value for the second **TPoint** is in D202 (Low Word) and D203 (High Word). The calibration weight value for the third **TPoint** is in D204 (Low Word) and D205

(High Word). Once the execution of this instruction started, the value of **TWeight** is sent to the LC module for calibration. You cannot change the value of **TWeight** after the instruction is executed. the value of the first point for calibration weight should be 0 (zero correction). If not, the Error flag will be ON.

9. Once **ADone** changes from OFF to ON, the entire calibration will be stopped. The calibration can be performed again if the LCCAL instruction is enabled again after disabled.
10. **CPoint** is the number of points which have been calibrated and can not be modified by users. When **CPoint** value  $\geq$  **TPoint** value, the calibration is considered to be completed and the **ADone** flag changes to ON.
11. When the LCCAL instruction is enabled initially, the **CPoint** value is automatically cleared to 0 and **Trigger**, **Done** and **ADone** change to OFF and the calibration is prepared. After **Trigger** is set from OFF to ON and the LC module completes the calibration, the value of **CPoint** will be automatically added by 1 and the **Done** flag changes to ON. You can observe current points for which the calibration has been completed via the value. For example, as the **CPoint** value is 2, it means that **Trigger** is triggered twice and the module has completed the 2-point calibration.
12. The error codes that **ErrCode** shows are listed in the following table.

Error code	Description
16#1410	Error in the LC group number or module number
16#1411	The LC module has no such channel number
16#1412	LC module writing error or communication timeout
16#1413	The LC module has completed the calibration. Disable the instruction and retrigger it.
16#1414	The first value for calibration weight is not 0.
16#1415	The calibration weight value is not a floating-point value.
16#1416	The value exceeds the measuring range.
16#1417	The value exceeds the weight limit.
16#1418	Calibration error

13. See the sequence diagram in a calibration example.




Explanation of the timing points in the above sequence diagram:


- ① → The LCCAL instruction is enabled and the **CPoint** value and the flags **Trigger**, **Done**, **ADone** and **Error** are all cleared automatically.
- ② → Trigger the calibration flag.
- ③ → The instruction finds a module number error and displays the error code of LC module number error
- ④ → Disable the LCCAL instruction.
- ⑤ → After a trigger, the LC module completes the single-point calibration and the **CPoint** value is added by 1 and the **Done** flag changes to ON.
- ⑥ → Clear the trigger signal flag **Trigger**.
- ⑦ → Subsequently, the **Done** flag is cleared by the instruction.
- ⑧ → After a trigger, the LC module completes the entire calibration and the **CPoint** value is added by 1 and both of the flags **Done** and **ADone** change to ON.

**Example**

When PLC runs, the value of the first point for calibration weight is 0 written in D0 and D1. The value of the second point for calibration weight is 500.0 written in D2 and D3.

- ① → When M0 switches to ON, you can use DLCCAL instruction to calibrate.
- ② → Make sure there is no load on the weighing platform. Set M50 to ON and then start zero correction (set the value of the first point to zero). When D100 = 1 and M100 is ON, you have the first point calibrated. M50 switches to OFF.
- ③ → Put a 500 g weight on the weighing platform, set M50 to ON and then start a 500 g calibration for the second point. When D100 = 2 and M101 is ON, you have the second point calibrated. M50 switches to OFF and M0 to OFF.





API	Instruction			Operand							Description						
1416	D	LCWEI		Group, Module ~ ErrCode							Reading weight value via LC module						

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
Group								●					○	○		
Module								●					○	○		
ChNo								●					○	○		
Stable								●					○	○		
ZeroS	●	●	●	●				●								
TareS	●	●	●	●				●								
TareW								●								
Weight								●								
Status								●								
Error		●	●	●				●								
ErrCode								●								

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
Group		●				●							
Module		●				●							
ChNo		●				●							
Stable		●				●							
ZeroS	●												
TareS	●												
TareW									●				
Weight									●				
Status		●				●							
Error	●												
ErrCode		●				●							

Pulse Instruction	16-bit instruction	32-bit instruction
—	—	AS

**Symbol**

- Group** : Group number
- Module** : Module number
- ChNo** : Channel number
- Stable** : Specify stable-weight range (0.0~100000.0)
- ZeroS** : Clear the weight to 0
- TareS** : Flag to set the tare weight

DLCWEI	
En	
Group	Weight
Module	Status
ChNo	Error
Stable	ErrCode
ZeroS	
TareS	
TareW	

**TareW** : Tare weight value

**Weight** : Present weight value

**Status** : Status code of LC module

**Error** : Error flag

**ErrCode** : Error code

## Explanation


1. This instruction is available for PLC with FW V1.06.00 or later and ISPSOft V3.08 or later.
2. The LCWEI instruction supports AS series LC module only. Before the instruction is used, you should get to know the configuration position of current module from HWCONFIG.
3. **Group** is the group number of the specified LC module connected to the right of the PLC or the remote module. The number of the PLC is 0, the number of the first remote module is 1 and so on. The maximum group number is 15. If the specified module is not a LC module, the **Error** flag will change to ON.
4. **Module** sets the serial number of modules at the right of the PLC. The first one is number 1, the second one is number 2 and so on. Whatever modules at the right of the PLC must be numbered. The maximum number is 32. If the specified module is not a LC module, the error flag **Error** will change to ON.
5. **ChNo** is a channel number of the specified LC module. If the input value is not a channel number of the LC module, the error flag **Error** will change to ON.
6. **Stable** sets a value within the stable-weight range. It is a raw data. The value can be set to a floating-point value within the range of 0.0~100000.0 and the maximum value or minimum value will be automatically taken as the setting if the setting value exceeds the range. The timing of making the parameter value valid is when the instruction is enabled for the first time. If the value in the LC module need be modified, disable the instruction first, set a new range value and then enable the instruction for a new setting.
7. After the LCWEI instruction is enabled, the specified channel will be automatically changed into the display mode of "net weight". If you need to know the gross weight (total weight), add **TareW** value and **Weight** value by yourself.
8. **ZeroS** is the flag to set the present weight to 0. When the **ZeroS** flag changes from OFF to ON, the values of **TareW** and **Weight** are cleared to 0.
9. **TareS** is the flag to set the tare weight. When **TareS** changes from OFF to ON, present **Weight** value is moved to **TareW** and the **Weight** value will be cleared to 0. When **TareS** changes from ON to OFF, **TareW** value will be moved back to the present **Weight** value and the **TareW** value will be cleared to 0.
10. **Weight** is the weight value measured by deducting the tare weight. You can observe if the **TareW** value exists or not in order to know whether the tare weight function has been enabled. When the **TareW** value is 0, it indicates that the tare weight has not been set.

11. **Status** is a commonly used status code for the instruction to integrate LC module. See the explanation of status values in the following table.

Value	0	1	2	3	4	5
Description	Weight measuring or no load	Weight is stable	Hardware fault/ calibration fault	In calibration	Weight exceeds the range	Module number error /channel number error

12. During the weight reading, **Status** will display corresponding error code and the **Error** flag changes to ON as an error occurs in the LC module. When the status returns to normal, the **Error** flag will be cleared automatically. For details on error status, refer to the explanation of status control buffers in the LC module manual.

13. See the sequence diagram of the weight-reading example.



Explanation of the timing points in the above sequence diagram:

- ① → Enable the LCWEI instruction.
- ② → After getting the command of clearing data to 0, the instruction will clear the values of **TareW**, **Weight** and **Status**.
- ③ → Put the measured stuff on the weighing platform. When the stable weight value is measured, the **Status** value becomes 1 and **Weight** displays the weight value.
- ④ → Setting **TareS** to ON, the **Weight** value moves to **TareW** and then the value of **Weight** is cleared.
- ⑤ → Setting **TareS** to OFF, the **TareW** value moves back to **Weight** and then the **TareW** value is cleared.
- ⑥ → Put another measured stuff on the weighing platform. At the moment, **Status** enters the status of weight measuring.
- ⑦ → Disable the LCWEI instruction. **TareW**, **Weight** and **Status** hold the last status values.


14. The error codes that **ErrCode** shows are listed in the following table.

Error code	Description
16#1410	Error in the LC group number or module number
16#1411	The LC module has no such channel number
16#1414	Error in data-writing or communication timeout on LC module

### Example

After calibration is done, you can use DLCWEI instruction to weigh.

1. Weighing: Leave a weight of 500 g on the weighing platform. When M1 switches to ON, the value in D204 shows 500.0.
2. Set up the tare weight
  - ① → Leave a packaging (100 g) on the weighing platform. The value in D204 shows 100.0.
  - ② → When M151 switches to ON, **Weight** value (D204) is moved to **TareW** value (D202). After moving, clear the weight value in D204.
  - ③ → D204 = 0.0 and D202 = 100.0. The setup of tare weight is complete.
3. Clear the tare weight
  - ① → When M151 switches to OFF, the **TareW** value (D202) is moved back to **Weight** value (D204). After moving, clear the **TareW** value in D202.
  - ② → D202 = 0.0 and D204 = 100.0. The setup of clearing the tare weight is complete.
4. Specify a stable-weight range (checking the stability)
  - ① → Before executing this instruction, you need to specify the stable-weight range. Here we set D200 = 10.0.
  - ② → Leave a 500 g weight on the weighing platform. When the measurement result is between 490 ~ 510 g, D210 =1 (the weight is stable).



API	Instruction			Operand							Description						
1417	D	MPID		Group, Module ~ Error							PID algorithm for RTD/TC module						

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
GROUP								●					○	○		
MODULE								●					○	○		
CH								●					○	○		
UPDATE	●	●	●	●				●								
PID_RUN	●	●	●	●				●								
SV								●					○	○		
PID_MODE								●					○	○		
PID_MAN	●	●	●	●				●								
MOUT_AUTO	●	●	●	●				●								
AUTO_DBW								●					○	○		
Kc_Kp								●								○
Ti_Ki								●								○
Td_Kd								●								○
Tf								●								○
PID_EQ	●	●	●	●				●								
PID_DE	●	●	●	●				●								
PID_DIR	●	●	●	●				●								
ERR_DBW								●								
ALPHA								●					○	○		
BETA								●					○	○		
MOUT								●								
BIAS								●					○	○		
CYCLE								●					○	○		
MV								●								
PV								●								
I_MV								●								
ERROR								●								

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
-----------	------	------	-------	-------	------	-----	------	------	------	-------	-----	-----	--------

Refer to the following data type descriptions

Pulse Instruction	16-bit instruction	32-bit instruction
—	—	AS

## Symbol

DMPID	
En	MV
GROUP	PV
MODULE	I_MV
CH	ERROR
UPDATE	
PID_RUN	
SV	
PID_MODE	
PID_MAN	
MOUT_AUTO	
AUTO_DBW	
Kc_Kp	
Ti_Ki	
Td_Kd	
Tf	
PID_EQ	
PID_DE	
PID_DIR	
ERR_DBW	
ALPHA	
BETA	
MOUT	
BIAS	
CYCLE	

<b>GROUP</b>	: Group number
<b>MODULE</b>	: Module number
<b>CH</b>	: Channel number
<b>UPDATE</b>	: Update PID parameters
<b>PID_RUN</b>	: Enable the PID algorithm
<b>SV</b>	: Target value (SV)
<b>PID_MODE</b>	: PID control mode
<b>PID_MAN</b>	: PID Auto/Manual mode
<b>MOUT_AUTO</b>	: Manual/Auto output value
<b>AUTO_DBW</b>	: Range within which the auto tuning is not working
<b>Kc_Kp</b>	: Proportional gain
<b>Ti_Ki</b>	: Integral coefficient (sec. or 1/sec)
<b>Td_Kd</b>	: Derivative coefficient (sec)
<b>Tf</b>	: Derivate-action time constant (sec)
<b>PID_EQ</b>	: PID formula types
<b>PID_DE</b>	: Calculation of the PID derivative error
<b>PID_DIR</b>	: PID forward/reverse direction (PID_DIR)
<b>ERR_DBW</b>	: Range within which the error value is counted as 0
<b>ALPHA</b>	: Initial value compensation of integral calculus (for heating up)
<b>BETA</b>	: Initial value compensation of integral calculus (for cooling down)
<b>MOUT</b>	: Manual output value (MOUT)
<b>BIAS</b>	: Feed forward output value
<b>CYCLE</b>	: Sampling time (CYCLE)
<b>MV</b>	: Output value (MV)
<b>PV</b>	: Process value (PV)
<b>I_MV</b>	: Accumulated integral value
<b>ERROR</b>	: Error code

**Explanation**

1. This instruction is available for PLC with FW V1.06.00 or later and can only support the right-side modules. For PLC with FW V1.08.00 or later, it can support remote right-side modules (AS00SCM-A with FW V2.06 or later) as well.
2. This instruction is available for AS04RTD-A (V1.04 or later), AS06RTD-A (V1.00 or later), AS04TC-A (V1.04 or later), and AS08TC-A (V1.00 or later).
3. The parameter settings are listed in the following table.

Operand	Data type	Function	Setting range	Description
<b>GROUP</b>	DWORD/DINT	Group number		The RTD/TC module group number that is connected to the right side of PLC directly or connected to the remote module that acts as PLC, e.g. the first connected module group is group number 1, the second connected module group is group number 2. Up to 15 module group can be connected and counted.
<b>MODULE</b>	DWORD/DINT	Module number		The module number that is connected to the right side of PLC directly or connected to the remote module that acts as PLC, e.g. the first connected module is module number 1, the second connected module is module number 2. Up to 32 modules can be connected and counted and each type of modules should be included in the count.
<b>CH</b>	DWORD/DINT	Channel number		Channel number for PID algorithm, e.g. channel 1 is number 1 for PID algorithm and channel 2 is number 2 for PID algorithm and so forth.
<b>UPDATE</b>	BOOL	Flags for updates of the PID-related parameters		After enabling this instruction, you can input a new parameter and set the UPDATE flag to TRUE to update the new setting and after updating, the flag is switched to FALSE automatically.

Operand	Data type	Function	Setting range	Description
<b>PID_RUN</b>	BOOL	Enabling the PID algorithm	True: use the PID algorithm. False: reset the output value (MV) to 0, and stop using the PID algorithm.	
<b>SV</b>	DWORD/DINT	Target value	-32768~32767	Target value
<b>PID_MODE</b>	DWORD/DINT	PID control mode	0: Automatic control When PID_MAN switches from True to False, invoke the output value (MV) in the automatic algorithm. 1: Auto tuning the parameters for the temperature control. After tuning is done, the system is in auto control mode (PID_MODE is set to 0) and fill in the appropriate parameters (Kc_Kp, Ti_Ki, Td_Kd, Tf, APPHA and BETA) Note: when the mode is set to 1, auto tuning the parameter, you cannot set up the value.	
<b>PID_MAN</b>	BOOL	PID A/M mode	True: Manual Output the MV according to MOUT. This setting has no effect when PID_MODE is set to 1. False: Automatic Output the MV according to the PID algorithm.	
<b>MOUT_AUTO</b>	BOOL	MOUT automatic change mode	True: Automatic MOUT value varies with the MV. False: Normal MOUT value does not vary with the MV.	
<b>AUTO_DBW</b>	DWORD/DINT	Range within which the auto tuning is not working	0~32000	Auto tuning NOT activated when

Operand	Data type	Function	Setting range	Description
				SV is in the range of $\pm$ dead band width
<b>Kc_Kp</b>	REAL	Calculated proportional coefficient (Kc or Kp, according to the settings in PID_EQ)	Range of positive single-precision floating-point numbers	If the P coefficient is less than 0, the Kc_Kp is 0. Independently, if Kc_Kp is 0, it is not controlled by P.
<b>Ti_Ki</b>	REAL	Integral coefficient (Ti or Ki, according to the settings in PID_EQ)	Range of positive single-precision floating-point numbers (unit: Ti = sec; Ki = 1/sec)	If the calculated coefficient I is less than 0, Ti_Ki is 0. If Ti_Ki is 0, it is not controlled by I.
<b>Td_Kd</b>	REAL	Derivative coefficient (Td or Kd, according to the settings in PID_EQ)	Range of positive single-precision floating-point numbers (unit: sec)	If the calculated coefficient D is less than 0, Td_Kd is 0. If Ti_Ki is 0, it is not controlled by D.
<b>Tf</b>	REAL	Derivate-action time constant	Range of positive single-precision floating-point numbers (unit: sec)	If the derivate-action time constant is less than 0, Tf is 0 and it is not controlled by the derivate-action time constant (derivative smoothing).
<b>PID_EQ</b>	BOOL	PID formula types	TRUE: dependent formula	

Operand	Data type	Function	Setting range	Description
			FALSE: independent formula	
<b>PID_DE</b>	BOOL	The calculation of the PID derivative error	<p>TRUE: use the variations in the PV to calculate the control value of the derivative (Derivative of the PV).</p> <p>FALSE: use the variations in the error (E) to calculate the control value of the derivative (derivative of the error).</p>	
<b>PID_DIR</b>	BOOL	PID forward/reverse direction	<p>TRUE: forward action; cooling down (E=PV-SV)</p> <p>FALSE: reverse action; heating up (E=SV-PV)</p>	
<b>ERR_DBW</b>	DWORD/DINT	Range within which the error value is counted as 0.	-32768~32767	<p>The error value (E) is the difference between the SV and the PV.</p> <p>When the ERR_DBW setting value is 0, the function is disabled; otherwise the CPU PLC checks whether the present error is less than the absolute value of ERR_DBW, and checks whether the present error meets the cross status condition.</p> <p>If the present</p>

Operand	Data type	Function	Setting range	Description
				error is less than the absolute value of ERR_DBW, and meets the cross status condition, the present error is counted as 0, and the PLC applies the PID algorithm ; otherwise the present error is brought into the PID algorithm.
<b>ALPHA</b>	DWORD/DINT	Integral gain of the initialization value (heating up)	0~100 Unit: 1%	Initial value compensation of integral calculus (for heating up)
<b>BETA</b>	DWORD/DINT	Integral gain of the initialization value (cooling down)	0~100 Unit: 1%	Initial value compensation of integral calculus (for cooling down)
<b>MOUT</b>	REAL	MV	0~1000 (unit: 0.1%)	When set to PID Manual (PID_MAN=True), the MV value is outputted as the value set manually for MOUNT.
<b>BIAS</b>	REAL	Feed forward output value	-32768~32767	Feed forward output value, used for the PID

Operand	Data type	Function	Setting range	Description
				feed forward.
<b>CYCLE</b>	DWORD/DINT	Sampling time (T <sub>s</sub> )	1~1000 (unit: 100 ms)	When the instruction is scanned, use the PID algorithm according to the sampling time, and refresh MV.
<b>MV</b>	REAL	MV output value	0.0~100.0 (unit: 1%)	MV output value
<b>PV</b>	DWORD/DINT/ REAL	Present value	Format is defined in HWCONFIG.	
<b>I_MV</b>	REAL	Accumulated integral value	Accumulated integral value is for reference. When the MV is out of the range of 0-100%, the accumulated integral value in I_MV stops changing.	
<b>ERROR</b>	DWORD/DINT	Error codes	16#0000 : instruction is being executed and is working normally 16#1400 : the module you are using does not support this instruction. 16#1401 : group number or module number setting error 16#1402 : the module you are using does not respond and communication time out 16#1403 : channel setting error 16#1404: PID function is ongoing during the communication, no repeatedly set ups.	


Note:


1. If the PID parameter exceeds the upper limit, only the maximum value can be written in the module, if the PID parameter is below the lower limit, only the minimum value can be written in the module.
2. When PID\_RUN switches from True to False, it clears the MV output value to 0. If you need to keep the last MV output value, you can switch the operand EN to False to close this instruction and the MV output value can be kept.

**Example**

1. You need to set up the parameters before executing DMPID. Switch the operand EN from False to True to execute this instruction and once the instruction is enabled, the parameters are applied to the modules. If you need to change parameters during execution, you can use the UPDATE flag to update the parameters (including **PID\_RUN ~ CYCLE**). After the parameters are updated, PLC clears the UPDATE flag.
2. When M0 is ON, the instruction is executed. When M2 is ON, the DMPID starts to process. When M2 is OFF, MV value is 0. And the value in MV is stored in D26. When M0 is OFF, the instruction is not executed. And the values in the instruction is not changed.
3. When the mode is set to 1, the system starts to auto tuning the parameters for the temperature control. After tuning is done, the system switches to auto control mode (PID\_MODE is set to 0) and fill in the appropriate parameters (Kc\_Kp, Ti\_Ki, Td\_Kd, Tf, ALPHA and BETA) to data devices. You can also use retentive devices to retain PID parameters.
4. You should convert the MV output value based on your needs within the range from 0.0 to 100.0. This example converts the MV output value to PWM output. Use floating point division instruction F/ to convert the MV value to Duty cycle ranging from 0% to 100%, and then use floating point multiplication F\* to multiply the Duty Cycle and the period value of PWM so as to get the width of output pulses.
5. Input the width and period of output pulses to GPWM parameters and PWM control can be performed in the designated Output pulse device.

$$\text{Duty cycle} = \frac{\text{Output pulse width}}{\text{Output pulse cycle}}$$



**PID formula:**

1. When the PID\_MODE is set to 0, the mode is set to auto:

- **Independent Formula & Derivative of E(PID\_EQ=False & PID\_DE=False)**

$$MV = K_p E + K_i \int_0^t E dt + K_d * \frac{dE}{dt} + BIAS \quad (E = SV - PV \text{ or } E = PV - SV)$$

- **Independent Formula & Derivative of PV(PID\_EQ=False & PID\_DE=True)**

$$MV = K_p E + K_i \int_0^t E dt - K_d * \frac{dPV}{dt} + BIAS \quad (E = SV - PV)$$

Or

$$MV = K_p E + K_i \int_0^t E dt + K_d * \frac{dPV}{dt} + BIAS \quad (E = PV - SV)$$

- **Dependent Formula & Derivative of E(PID\_EQ=True & PID\_DE=False)**

$$MV = K_c \left[ E + \frac{1}{T_i} \int_0^t E dt + T_d * \frac{dE}{dt} \right] + BIAS \quad (E = SV - PV \text{ or } E = PV - SV)$$

● **Dependent Formula & Derivative of PV(PID\_EQ=True & PID\_DE=True)**

$$MV = K_c \left[ E + \frac{1}{T_i} \int_0^t Edt - T_d * \frac{dE}{dt} \right] + BIAS \quad (E = SV - PV)$$


Or

$$MV = K_c \left[ E + \frac{1}{T_i} \int_0^t Edt + T_d * \frac{dE}{dt} \right] + BIAS \quad (E = PV - SV)$$


2. When you set the PID\_MODE to 1, auto tuning mode is enabled. When auto tuning is complete, the value becomes 0 and switches off the auto tuning mode automatically.

**PID Control Block Diagram:**

PID Block Diagram (Independent)




PID Block Diagram (Dependent)





**ERR\_DBW**

When the PV (present value) is in the range of **ERR\_DBW**, at the beginning, the present error is brought into the PID algorithm according to the normal processing, and then the CPU module checks whether the present error meets the cross status condition: PV (present value) goes beyond the SV (target value). Once the condition is met, the present error is counted as 0 when applying the PID algorithm. After the PV (present value) is out of the **ERR\_DBW** range, the present error is brought into the PID algorithm again. If PID\_DE is true, that means it uses the variations in the PV to calculate the control value of the derivative, and after the cross status condition is met, the PLC treats  $\Delta PV$  as 0 to apply the PID algorithm. ( $\Delta PV = \text{current PV} - \text{previous PV}$ ). In the following example, the present error is brought into the PID algorithm according to the normal processing in section A, and the present error or  $\Delta PV$  is counted as 0 to apply the PID algorithm in the section B.



**$\alpha$ ,  $\beta$  Value**

To reduce overshoot, you can use parameters of ALPHA or BETA in the beginning of the PID operation or while SV (target value) varies to compensate initial value of integral calculus (for heating up or cooling down). See the images below. Use ALPHA parameter to reduce overshoot while the temperature is climbing up. Use BETA parameter to reduce overshoot while the temperature is dropping.



**Formula of the output cycle:**

Set the output cycle according to the environment. If the environmental temperature changes not so aggressively, you can set a bigger output cycle.

- Output pulse width = MV (%) x output cycle


Execute the general pulse with modulation instruction (GPWM) to set Output pulse width and output cycle sampling time to manage the cycle.

**Example**

If the output cycle is 2000 ms, then the output value is 50% after the PID algorithm is implemented.

- Output pulse width = 50% x 2000 ms = 1000 ms

In other words, the GPWM instruction can be set to Output pulse width = 1000 and output cycle = 2000.

**Note**

1. When tuning the parameters Kc\_Kp, Ti\_Ki, and Td\_Kd (**PID\_MODE=0**), set the Kc\_Kp value first, and then set the Ti\_Ki and Td\_Kd values to 0. In a controlled environment, you can increase the values of Ti\_Ki (from smaller to bigger) and Td\_Kd (from bigger to smaller). When the value of Kc\_Kp is 1, the proportional gain is 100%. That is, the error values increase by a factor of one. When the proportional gain is less than 100%, the error values decrease. When the proportional gain is greater than 100%, the error values increase.
2. The parameters which have been automatically tuned are not necessarily suitable for every controlled environment. You can, therefore, further modify the automatically-tuned parameters, but it is recommended that you only modify the values of Ti\_Ki or Td\_Kd.
3. The operand CYCLE is to set the sampling time to use the PID algorithm and refresh MV.
4. When the number of the channel for measurement is changed, the time to refresh the measured value also changes. For example, the measured value is refreshed every 200 ms when there is only 1 channel for measurement. The measured value is refreshed every 800 ms when there are 4 channels for measurement. The Kc\_Kp, Ti\_Ki, Td\_Kd parameters may differ when the number of channel for measure is different.

API	Instruction			Operand							Description						
1418	D	HCCNT		Module ~ ErrCode							HC module counter						

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
Module								●					○	○		
ChNo								●					○	○		
Update		●	●	●				●								
Action								●					○	○		
Value							●	●					○	○		
CurCnt							●	●								
ST								●								
MT								●								
AStat								●								
RefCnt								●								
Dir		●	●	●				●								
CntStat								●								
Error		●	●	●				●								
ErrCode								●								

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
Module		●				●							
ChNo		●				●							
Update	●												
Action		●				●							
Value			●				●						
CurCnt			●				●						
ST			●				●						
MT			●				●						
AStat		●				●							
RefCnt		●				●							
Dir	●												
CntStat		●				●							
Error	●												
ErrCode		●				●							

Pulse Instruction	16-bit instruction	32-bit instruction
—	—	AS

**Symbol**

DHCCNT	
En	
Module	CurCnt
ChNo	ST
Update	MT
Action	AStat
Value	RefCnt
	Dir
	CntStat
	Error
	ErrCode

- Module** : Module number
- ChNo** : Channel number
- Update** : Parameter updating flag
- Action** : Actions for the counter to act
- Value** : New counting value / offset value
- CurCnt** : Current counter value
- ST** : Single-Turn data of an absolute type SSI encoder
- MT** : Multi-Turn data of an absolute type SSI encoder
- AStat** : Status data of an absolute type SSI encoder
- RefCnt** : Refreshing counter of an absolute type SSI encoder
- Dir** : Counting direction
- CntStat** : Counting status
- Error** : Error flag
- ErrCode** : Error code

**Explanation**

1. This instruction is for AS02HC-A only. You can start, stop the counter as well as set up and edit the counter value. This instruction is available for PLC with FW V1.08.or later and ISPSOft V3.10 or later.
2. Before executing this instruction, you need to put the setting values in **Action** and **Value**. Once **En** is triggered, the PLC scans the values in **Action** and **Value** immediately. If you need to edit the values in **Action** and **Value**, set new values in **Action** and **Value** and set the **Update** to ON. Once the values in **Action** and **Value** are updated, the **Update** switches to OFF.
3. **Module**: The module number that is connected to the right side of PLC directly or connected to the remote module that acts as PLC, e.g. the first connected module is module number 1, the second connected module is module number 2. Up to 32 modules can be connected and counted and each type of modules should be included in the count.
4. **ChNo**: Channel number for counter, channel 1 is number 1; channel 2 is number 2.
5. **Counter action modes and functions**

Action Mode	Function	Description
0	Remain unchanged	
1	Set up / change current counter value ( <b>CurCnt</b> )	Set up a new counter value in <b>Value</b> Note: If you are using SSI (serial synchronous interface) encoder and the setting of counter mode is in Absolute Position, the Action mode here is invalid.
2	Set the offset value in SSI encoder as the value in <b>Value</b>	When the setting of counter mode is in Absolute Position, you can set the counter offset value of the SSI encoder. If you set the offset value in <b>Value</b> , the current counter value ( <b>CurCnt</b> ) is the sum of

Action Mode	Function	Description
		<p>the encoder counter value + the value in <b>Value</b>.</p> <p>Note:</p> <ol style="list-style-type: none"> <li>1. Range of the value in <b>Value</b>: <math>-2^{(MT+ST\ Length-1)} \leq \mathbf{Value} &lt; 2^{(MT+ST\ Length-1)}</math>. If the value is set out of the range, it is invalid.</li> <li>2. If you are using SSI (serial synchronous interface) encoder and the setting of counter type is Ring Counter, the Action mode here is invalid.</li> <li>3. After downloading the HWCONFIG settings, the offset value is cleared to 0.</li> </ol>
3	Set / change the absolute position value of the SSI encoder	<p>When the setting of counter mode is in Absolute Position, the counter value of the SSI encoder will be offset and stored in <b>Value</b>. If you set the offset value in <b>Value</b>, the current counter value (<b>CurCnt</b>) is the value in <b>Value</b>. (<b>CurCnt</b> = <b>Value</b>)</p> <p>Note:</p> <ol style="list-style-type: none"> <li>1. Range of the value in <b>Value</b>: <math>0 \leq \mathbf{Value} &lt; 2^{(MT+ST\ Length)}</math>. If the value is set out of the range, it is invalid.</li> <li>2. If you are using SSI (serial synchronous interface) encoder and the setting of counter type is Ring Counter, the Action mode here is invalid. You can use <b>Action=1</b> to change the setting value.</li> <li>3. After downloading the HWCONFIG settings, the offset value is cleared to 0.</li> </ol>
4	Reset the current counter value ( <b>CurCnt</b> )	<ol style="list-style-type: none"> <li>1. Clear the value in <b>CurCnt</b> to 0.</li> <li>2. Clear the value in <b>CurNo</b> from DHCCMPT instruction.</li> <li>3. Clear the flags of <b>Match1</b> and <b>Match2</b> from DHCCMPT instruction.</li> </ol> <p>Note: If you are using SSI (serial synchronous interface) encoder and the setting of counter mode is in Absolute Position, the value in <b>CurCnt</b> can NOT be cleared to 0 but the value in <b>CurNo</b>, flags of <b>Match1</b> and <b>Match2</b> from DHCCMP instruction can be cleared.</p>
5	Reset the current counter value and the assigned Y output points from DHCCMP and DHCCMPT instructions.	<ol style="list-style-type: none"> <li>1. Clear the value in <b>CurCnt</b> to 0.</li> <li>2. Clear the value in <b>CurNo</b> from DHCCMPT instruction.</li> <li>3. Clear the flags of <b>Match1</b> and <b>Match2</b> from DHCCMPT instruction.</li> <li>4. Clear the assigned Y output points (ON→OFF) from DHCCMP and DHCCMPT instructions.</li> </ol>
6	Preset the current counter value ( <b>CurCnt</b> )	<ol style="list-style-type: none"> <li>1. Set the value in <b>CurCnt</b> as the value in <b>Value</b>.</li> <li>2. Clear the value in <b>CurNo</b> from DHCCMPT instruction. After preset, the DHCCMPT instruction performs the comparison from the top. If the first value is bigger than the first value to be compared in the table, the comparison stops. If this happens, you can use the Update flag (ON) from the DHCCMPT instruction to perform comparison again.</li> <li>3. Clear the flags of <b>Match1</b> and <b>Match2</b> from DHCCMPT instruction.</li> </ol> <p>Note: If you are using SSI (serial synchronous interface) encoder and the setting of counter mode is in Absolute Position, the value in <b>CurCnt</b> can NOT be changed but the value in <b>CurNo</b>, flags of <b>Match1</b> and <b>Match2</b> from DHCCMP instruction can be cleared.</p>
7	Preset the current counter value and clear the assigned Y output points from DHCCMP and DHCCMPT instructions.	<ol style="list-style-type: none"> <li>1. Set the value in <b>CurCnt</b> as the value in <b>Value</b>.</li> <li>2. Clear the value in <b>CurNo</b> from DHCCMPT instruction. After preset, the DHCCMPT instruction performs the comparison from the top. If the first value is bigger than the</li> </ol>

Action Mode	Function	Description
		first value to be compared in the table, the comparison stops. If this happens, you can use the Update flag (ON) from the DHCCMPT instruction to perform comparison again. 3. Clear the flags of <b>Match1</b> and <b>Match2</b> from DHCCMPT instruction. 4. Clear the assigned Y output points (ON→OFF) from DHCCMP and DHCCMPT instructions.

6. **CurCnt**: The current counter value of the appointed module channel.
7. **ST**: Single-Turn data of an absolute type SSI encoder. If the counter mode is in absolute position, the value of **ST** is an offset value. For the Ring counter, the value of **ST** is an original SSI figure. For an incremental encoder, the value of **ST** is 0.
8. **MT**: Multi-turn data of an absolute type SSI encoder. If the counter mode is in absolute position, the value of **MT** is an offset value. For the Ring counter, the value of **MT** is an original SSI figure. For an incremental encoder, the value of **MT** is 0.
9. **AStat**: Status data of an absolute type SSI encoder. For an incremental encoder, the value of **AStat** is 0.
10. **RefCnt**: Refreshing counter of an absolute type SSI encoder, within a maximum range of 16-bit. When one SSI data is captured, add one to the value of **RefCnt**. Once an overflow occurs, the refreshing counter starts counting from 0. For an incremental encoder, the value of **RefCnt** is 0.
11. **Dir**: Counting direction, when the value is ON, it goes in the positive direction; when the value is OFF, it goes in the negative direction.
12. **CntStat**: Counting status

Bit number	Status	Description	Remarks
15 ~ 11	Reserved		Reserved
10	SSI absolute position encoder experiencing zero crossing	0: normal 1: abnormal	In HWCONFIG you can set the option to detect or not to detect if the absolute position crossing zero point. (default: detection disabled) If the counter mode is in Absolute Position and you have set the offset, the detection starts after the value is offset. If the counter type is Ring Counter, the offset value will be reset to zero. The detection starts at the initial position of the SSI. Cause of the error: zero crossing Ways to clear the error: use the DHCCNT instruction to reset/preset or execute RESET by the Z phase.
9	SSI communication check	0: normal 1: abnormal	Cause of the error: abnormal communication for 5 times in a row Ways to clear the error: the communication comes back to normal
8	SSI parity check	0: normal 1: abnormal	Cause of the error: parity check failed Ways to clear the error: the next parity check pass
7	SSI data exceeding the set acceptable range	0: normal 1: abnormal	Cause of the error: SSI data exceeding the set acceptable range Ways to clear the error: when the SSI data stops exceeding the set acceptable range
6	Reserved	Reserved	



Bit number	Status	Description	Remarks
5	Ring counter - Overflow	0: normal 1: abnormal	In HWCONFIG you can set the option to detect or not to detect. (default: detection disabled) Cause of the error: when either overflow ( $>2^{31} - 1$ ) or underflow ( $<-2^{31}$ ) Ways to clear the error: use the DHCCNT instruction to reset/preset or execute RESET by the Z phase.
4	Ring counter - Underflow	0: normal 1: abnormal	
3	Linear counter – the value exceeds the upper limit	0: normal 1: abnormal	Cause of the error: the value of the linear counter exceeds the user-defined range Ways to clear the error: when the value of the linear counter is within the user-defined range Note: when the counting value exceeds the upper or lower limit, the value will keep as the value in upper/lower limit. After the values return to the acceptable range, the counting continues.
2	Linear counter – the value exceeds the lower limit	0: normal 1: abnormal	
1	Linear counter - Overflow	0: normal 1: abnormal	Cause of the error: even if the value of the linear counter exceeds the user-defined range, the hardware counter continues counting. But if the hardware counter counting is either overflow ( $>2^{31} - 1$ ) or underflow ( $<-2^{31}$ ), the counting stops. After clearing the error, the counting resumes. Ways to clear the error: use the DHCCNT instruction to reset/preset or execute RESET by the Z phase.
0	Linear counter - Underflow	0: normal 1: abnormal	

13. If you stopped executing the instruction, the channel values will stop updating.
14. Refer to the following table for more details when any of the Error flag is ON.

ErrCode	Description
16#1400	This function is NOT available for this module.
16#1401	The value is invalid or out of range.
16#1402	No response from the module. Communication timeout.
16#1403	HWCONFIG configuration error. Instruction stops.
16#1404	There is no such counting channel for the HC module.
16#1405	Input interface not selected. Instruction stops.
16#1406	Invalid value in <b>Action</b>
16#1410	One of the counting channel of the HC module is executing counting. Other channels cannot perform the same task at the same time.



**Example 1:** Setting / changing the current setting (Action = 1)

1. Set M0=ON, the counter starts counting.
2. In DHCCNT instruction, set the value in **Action** to 1 and the value in **Value** to 10000. When the **Update** flag M1 is ON, the value in **CurCnt** is updated to 10000.
3. After execution, the **Update** flag M1 clears to OFF automatically.





**Example 2:** Set the offset value in SSI encoder as the value in **Value** (Action = 2)

1. In HWCONFIG, set the channel 1 as SSI input and set the counter mode to absolute position.
2. Set M0=ON, the counter starts counting.
3. In DHCCNT instruction, set the value in **Action** to 2 and the value in **Value** to 500. Supposing the current counting value (**CurCnt**) is 2500, and when the **Update** flag M1 is ON, the value in **CurCnt** is updated to 3000.
4. After execution, the **Update** flag M1 clears to OFF automatically.





**Example 3:** Set / change the absolute position value of the SSI encoder (Action = 3)

1. In HWCONFIG, set the channel 1 as SSI input and set the counter mode to absolute position.
2. Set M0=ON, the counter starts counting.
3. In DHCCNT instruction, set the value in **Action** to 3 and the value in **Value** to 0. When the **Update** flag M1 is ON, the HC module counters the offset value automatically and the value in **CurCnt** is offset to 0.
4. After execution, the **Update** flag M1 clears to OFF automatically.



**Example 4:** Reset / preset the current counter value (Action = 4, 6)

1. Set M0=ON, the counter starts counting.
2. In DHCCNT instruction, set the value in **Action** to 4. When the **Update** flag M1 is ON, the value in **CurCnt** is reset to 0. After execution, the **Update** flag M1 clears to OFF automatically.
3. In DHCCNT instruction, set the value in **Action** to 6 and the value in **Value** to 10000. When the **Update** flag M1 is ON, the value in **CurCnt** is preset to 10000. After execution, the **Update** flag M1 clears to OFF automatically.



API	Instruction			Operand						Description					
1419	D	HCCAP		Module ~ ErrCode						HC module counter value captured					

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	“\$”	F
Module								●					○	○		
ChNo								●					○	○		
TrgSel								●					○	○		
Capt1							●	●								
Cmplt1		●	●	●				●								
Capt2							●	●								
Cmplt2		●	●	●				●								
Error		●	●	●				●								
ErrCode								●								

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
Module		●				●							
ChNo		●				●							
TrgSel		●				●							
Capt1			●				●						
Cmplt1	●												
Capt2			●				●						
Cmplt2	●												
Error	●												
ErrCode		●				●							

Pulse Instruction	16-bit instruction	32-bit instruction
—	—	AS

Symbol

DHCCAP	
En	
Module	Capt1
ChNo	Cmplt1
TrgSel	Capt2
	Cmplt2
	Error
	ErrCode

- Module** : Module number
- ChNo** : Channel number
- TrgSel** : Trigger selection
- Capt1** : Capture value 1
- Cmplt1** : Capture value 1 compete
- Capt2** : Capture value 2
- Cmplt2** : Capture value 2 compete
- Error** : Error flag
- ErrCode** : Error code

**Explanation**

1. This instruction is for AS02HC-A only. You can start, stop the counter as well as set up and edit the counter value. This instruction is available for PLC with FW V1.08.or later and ISPSOft V3.10 or later.
2. Use this instruction with DHCCNT instruction. When executing DHCCNT instruction, the counting starts. And you can use DHCCAP to capture the counter value. When DHCCNT stopped, the counter value stops updating. And the captured value stays the same.
3. Before executing this instruction, you need to set up **TrgSel**. Once **En** is activated, the PLC scans the values in **TrgSel** immediately. If you need to edit the values in **TrgSel**, set new values in **TrgSel** and stop the instruction and then execute the instruction again.
4. **Module**: The module number that is connected to the right side of PLC directly or connected to the remote module that acts as PLC, e.g. the first connected module is module number 1, the second connected module is module number 2. Up to 32 modules can be connected and counted and each type of modules should be included in the count.
5. **ChNo**: Channel number for counter, channel 1 is number 1; channel 2 is number 2.
6. **TrgSel**: Trigger modes and functions

TrgSel	Function	Description	
0	Triggered by the Z phase input points of the appointed channel	ChNo	Trigger Source
		1	CH1 Z phase
		2	CH2 Z phase
You need to set the setting value in Z Phase input of the appointed channel to <b>Capture</b> in HWCONFIG to work with this trigger mode.			
1	Triggered by the other channel's comparing output instruction (Match1 / Match 2 of DHCCMP instruction)	<p>Supposing you execute DHCCAP instruction on channel 2 and set <b>TrgSel</b> = 1, and use channel 1 for the execution of DHCCMP. When <b>Match 1 / Match 2</b> is OFF → ON on channel 1, the channel 2 is triggered to capture the current value and stores it in <b>Capt 1</b> or <b>Capt 2</b>.</p> <p>Note: Even if you have set the setting value in Z Phase input of the appointed channel to <b>Capture</b> in HWCONFIG, when <b>TrgSel</b> = 1, this capture function of external input point is invalid.</p>	



7. Capture the current counter value and store it in **Capt 1** or **Capt 2**. When **TrgSel** = 0, it captures the counter value when the Z-phase input point is rising-edge triggered and stores the value in **Capt1** and it captures the counter value when the Z-phase input point is falling-edge triggered and stores the value in **Capt2**. When **TrgSel** = 1, it captures the counter value when **Match 1** is OFF → ON in the other channel and store the captured value in **Capt1** it captures the counter value when **Match 2** is OFF → ON in the other channel and store the captured value in **Capt2**.

8. Flags of **Cmplt1** and **Cmplt2** are indicators to see if the captures in **Capt1** and **Capt2** are complete. When **Cmplt1/Cmplt2** is OFF → ON , it indicates the values in **Cmplt1/Cmplt2** are updated. You can clear the flag to OFF. Even if you did not clear the **Cmplt** flags to OFF, the captured values can still be updated.
9. If **En** ON → OFF, it indicates the capture function is disabled. The values in **Capt1** and **Capt2** will not be updated. The flags of **Cmplt1** and **Cmplt2** will be cleared off.
10. Refer to the following table for more details when any of the Error flag is ON.

ErrCode	Description
16#1400	This function is NOT available for this module.
16#1401	The value is invalid or out of range.
16#1402	No response from the module. Communication timeout.
16#1403	HWCONFIG configuration error. Instruction stops.
16#1404	There is no such counting channel for the HC module.
16#1405	Input interface not selected. Instruction stops.
16#1407	Invalid value in <b>TrgSel</b>
16#1411	One of the counting channel of the HC module is executing capturing. Other channels cannot perform the same task at the same time.

**Example 1:** Capture the counter value when the Z phase input point is triggered.


1. You need to set the setting value in Z phase of the Channel 1 to **Capture** in HWCONFIG to work with this trigger mode.
2. Set the value in **TrgSel** to 0 for DHCCAP instruction. When M0 = ON, DHCCAP instruction starts to wait for the Z phase input point to be rising-edge or falling-edge triggered.
3. When the Z phase input point of channel 1 is rising-edge triggered, it captures the counter value 1800 and stores the value in **Capt1**. And the flag of **Cmplt1** is OFF → ON.
4. When the Z phase input point of channel 1 is falling-edge triggered, it captures the counter value 6000 and stores the value in **Capt2**. And the flag of **Cmplt2** is OFF → ON.
5. The **Cmplt** flag is not cleared to OFF. New captured value is still updated in **Capt1** and **Capt2**. Here you can see the new captured value 8500 is updated in **Capt1**, when the Z phase input point of channel 1 is falling-edge triggered.
6. The Z phase input point of channel 1 is falling-edge triggered again, it captures the counter value 11000 and stores the value in **Capt2**. And the flag of **Cmplt2** is OFF → ON.





\* 1: Cmpl1 is not cleared to OFF, the captured value still updates in Capt 1.  
 \* 2: Cmpl2 is cleared to OFF, the captured value still updates in Capt 2.

**Example 2:** Capture the counter value by executing DHCCMP instruction and when **Match 1/ Match 2** is OFF → ON in the other channel.

1. Supposing you execute DHCCAP instruction on channel 2 and set **TrgSel = 1**, and use channel 1 for the execution of DHCCMP. When **Match 1/ Match 2** is OFF → ON on channel 1, the channel 2 is triggered to capture the current value and stores it in **Capt1** or **Capt2**. Even if you have set the setting value in Z phase of the appointed channel to **Capture** in HWCONFIG, when **TrgSel = 1**, this capture function of Z phase input point is invalid.
2. The **Comp 1 (Match 1)** is OFF → ON on channel 2, new captured value 2000 on channel 1 is updated in **Capt1** and **Cmplt 1** is OFF → ON.
3. The **Comp 2 (Match 2)** is OFF → ON on channel 2, new captured value 8000 on channel 1 is updated in **Capt2** and **Cmplt 2** is OFF → ON.
4. The **Cmplt** flag is not cleared to OFF. New captured value is still updated in **Capt1** and **Capt2**.
5. The external input point of channel 1 is falling-edge triggered again, it captures the counter value 11000 and stores the value in **Capt2**. And the flag of **Cmplt2** is OFF → ON.



6




API	Instruction			Operand							Description			
1420		HCDO		Module ~ ErrCode							HC module digital output point			

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	“\$”	F
Module								●					○	○		
Update		●	●	●				●								
DOdata								●					○	○		
DOstat								●								
Error		●	●	●				●								
ErrCode								●								

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
Module		●				●							
Update	●												
DOdata		●				●							
DOstat		●				●							
Error	●												
ErrCode		●				●							

Pulse Instruction	16-bit instruction	32-bit instruction
—	AS	—

6 Symbol



- Module** : Module number
- Update** : Channel number
- DOdata** : Digital output data
- DOstat** : Digital output state
- Error** : Error flag
- ErrCode** : Error code

Explanation

1. This instruction is for AS02HC-A only. You can start, stop the counter as well as set up and edit the counter value. This instruction is available for PLC with FW V1.08.or later and ISPSOft V3.10 or later.
2. Before executing this instruction, you need to set up **DOdata**. Once **En** is activated, the PLC scans the values in **DOdata** immediately. **DOdata** is the initial status of the output points Y0.0 ~ Y0.3. If you need to change the status of the output point, you need to set new values in **DOdata** and set the **Update** to ON. Once the values in **DOdata** is updated, the **Update** switches to OFF.
3. **Module**: The module number that is connected to the right side of PLC directly or connected to the remote module that acts as PLC, e.g. the first connected module is module number 1, the second connected module is module number 2. Up to 32 modules can be connected and counted and each type of modules should be included in the count.

4. **DOdata**: setting for the action of the output points

b15~b4	b3	b2	b1	b0
NA	Action of Y0.3	Action of Y0.2	Action of Y0.1	Action of Y0.0
NA	0 : OFF 1 : ON			

5. **DOstat**: setting for the state of the output points

b15~b4	b3	b2	b1	b0
NA	State of Y0.3	State of Y0.2	State of Y0.1	State of Y0.0
NA	0 : OFF 1 : ON			

6. **DOstat**: If you stopped executing the instruction, **DOstat** will stop updating.

7. Refer to the following table for more details when any of the Error flag is ON.


ErrCode	Description
16#1400	This function is NOT available for this module.
16#1401	The value is invalid or out of range.
16#1402	No response from the module. Communication timeout.
16#1403	HWCONFIG configuration error. Instruction stops.
16#1411	One of the output point of the HC module is executing output. Other channels cannot perform the same task at the same time. (DOstat can still be updated.)

8. When the instructions **DHCCMP** or **DHCCMPT** are being executed, you cannot change the output points via **DOdata** but **DOstat** can keep updating.

9. To set up the initial values for the output points of **DHCCMP**, you can start **HCDO** instruction first and then **DHCCMP** or **DHCCMPT** instruction. If you need to change the output points, you can stop **DHCCMP** or **DHCCMPT** instruction and then use **DOdata** of **HCDO** to update the actions of the output points.

**Programming Example:** Set the external output point

1. Firstly, determine the initial state of Y0.0~Y0.3. In this example, the state of Y0.0~Y0.3 is set to ON, therefore you should set the output point DOdata of HCDO instruction to 15 before switching M0 to ON.
2. When M0=ON, Y0.0~Y0.3 would be changed to ON immediately.
3. DOstat shows the current state of output point, which is 15 here. While M0=ON, the value of DOstat would be updated in realtime if the state of Y0.0~Y0.3 changes as a result of the control from DHCCMP or HCCMPT.



API	Instruction			Operand								Description					
1421	D	HCCMP		Module ~ ErrCode								HC module counter value in comparison for output					

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F	I
Module								●					○	○			
ChNo								●					○	○			
Update		●	●	●				●									
Comp1							●	●					○	○			
Action1								●					○	○			
Yno1								●					○	○			
Comp2							●	●					○	○			
Action2								●					○	○			
Yno2								●					○	○			
Match1		●	●	●				●									●
Match2		●	●	●				●									●
Error		●	●	●				●									
ErrCode								●									

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
Module		●				●							
ChNo		●				●							
Update	●												
Comp1			●				●						
Action1		●				●							
Yno1		●				●							
Comp2			●				●						
Action2		●				●							
Yno2		●				●							
Match1	●												
Match2	●												
Error	●												
ErrCode		●				●							

Pulse Instruction	16-bit instruction	32-bit instruction
-	-	AS

## Symbol

DHCCMP	
En	
Module	Match1
ChNo	Match2
Update	Error
Comp1	ErrCode
Action1	
Yno1	
Comp2	
Action2	
Yno2	

**Module** : Module number

**ChNo** : Channel number

**Update** : Parameter updating flag

**Comp1** : Compared value 1

**Action1** : Actions to take when the Comp1 is ON

**Yno1** : Number of output point to output when the Comp1 is ON

**Comp2** : Compared value 2

**Action2** : Actions to take when the Comp2 is ON

**Yno2** : Number of output point to output when the Comp2 is ON

**Match1** : When the value reaches the set value 1, this flag is ON.

**Match2** : When the value reaches the set value 2, this flag is ON.


**Error** : Error flag

**ErrCode** : Error code

## Explanation

1. This instruction is for AS02HC-A only. The counter value either by counting up or counting down met the set value is a **MATCH**. Once you have a **MATCH**, the system reacts accordingly to what you have set, including counter actions and which output point to output. This instruction is available for PLC with FW V1.08.or later and ISPSOft V3.10 or later.
2. Use this instruction with **DHCCNT** instruction. When executing **DHCCNT** instruction, the counting starts. And then you can use **DHCCMP** instruction to do the comparison.
3. Before executing this instruction, you need to set up **Comp1**, **Comp2**, **Action1**, **Action2**, **Yno1**, and **Yno2**. Once **En** is activated, the PLC scans the values in **Comp1**, **Comp2**, **Action1**, **Action2**, **Yno1**, and **Yno2** immediately.
4. You can edit the values in **Comp1**, **Comp2**, **Action1**, **Action2**, **Yno1**, and **Yno2** during operation. Set new values and set the **Update** to ON. Once the values are updated, the **Update**, **Match1** and **Match2** switch to OFF.
5. **Module**: The module number that is connected to the right side of PLC directly or connected to the remote module that acts as PLC, e.g. the first connected module is module number 1, the second connected module is module number 2. Up to 32 modules can be connected and counted and each type of modules should be included in the count.
6. **ChNo**: Channel number for counter, channel 1 is number 1; channel 2 is number 2.
7. **Comp 1** and **Comp 2** are the values for comparison (The value in **Comp 1** and **Comp 2** should be different.). If the counter value of **ChNo** met the set value, its corresponding flag **Match 1 / Match2** will be ON. The appointed output point by Yno1 and Yno2 reacts according to the settings for **Action**.

8. When the counter type is linear, the value in **Comp 1** and **Comp 2** should satisfy the following condition: the *smallest counter value* < **Comp** < *the largest counter value*. If you are using SSI (serial synchronous interface) encoder and the setting of counter mode is in Absolute Position. The value in **Comp 1** and **Comp 2** should satisfy the following condition:  $0 < \text{Comp} < 2^{(MT+ST\ Length)}$ .
9. The timing to be considered reaching the set value varies according to different settings on input interfaces in HWCONFIG, for example pulse input and SSI input.



If the input interface is pulse input, the timing to be considered to meet the set value is before the counting leaving the set value. Take Comp = 5 as an example, when the counting goes from 5 to 6 or from 5 to 4, the timing here is considered the set value reached.

If the input interface is SSI input, the timing to be considered reaching the set value is right before the counting touching the set value. Take Comp = 5 as an example, when the counting goes from 4 to 5 or from 6 to 5, the timing here is considered the set value reached.

10. If the counter value of **ChNo** met the set value, its corresponding flag **Match 1 / Match2** will be ON. The appointed output point by Yno1 and Yno2 reacts according to the settings for **Actions: Action 1** (for the appointed output point by Yno1) and **Action 2** (for the appointed output point by Yno2).

Action 1	Description	Action 2	Description	Remarks
0	No action	0	No action	
1	OFF	1	OFF	
2	ON	2	ON	
3	Toggle between ON /OFF	3	Toggle between ON /OFF	
4	OFF + clear the counter value of its channel	4	OFF + clear the counter value of its channel	When the counter value is cleared, the flags of Match 1 and Match 2 will also be cleared.
5	ON + clear the counter value of its channel	5	ON + clear the counter value of its channel	
6	Toggle between ON /OFF +	6	Toggle between ON /OFF +	

	clear the counter value of its channel		clear the counter value of its channel	
7	Clear the counter value of its channel	7	Clear the counter value of its channel	
8	Clear the counter value of its channel + OFF (appointed output points by both Yno1 & Yno2)	8	Clear the counter value of its channel + OFF (appointed output points by both Yno1 & Yno2)	

Note: there is a time difference between meeting the set value and for the action to take place. Up to 100 us of time difference can be expected.

11. Set the value in **Yno1** and **Yno2** to assign the output points Y0.0, Y0.1, Y0.2, and Y0.3. You can have two sets of values (**Yno1** and **Yno2**) to achieve two sets of comparisons. After this instruction starts to execute, you cannot use HCDO instruction to control the output points.

Yno1/Yno2	Appointed output points
0	Y0.0
1	Y0.1
2	Y0.2
3	Y0.3


12. The counter value either by counting up or counting down met the set value is a **MATCH**. The flags of **Match 1** and **Match 2** are the indicators. When the counter value met the set value, its corresponding **Match 1** or **Match 2** flag will be ON. Either one of the followings occurs, the flags of **Match 1** and **Match 2** will be cleared to OFF, when the PLC CPU stops, clears the counters, DHCCMP instruction switches from OFF to ON, or Update flag is set to ON.
13. The flags of **Match 1** and **Match 2** can be used for interrupt devices I, ranging from I400 to I431.  
Note: The frequency of the interrupt device I with the same numbering should not be higher than 800Hz.
14. If you stopped executing the instruction, its relative compared values and its output function will stop updating.
15. Refer to the following table for more details when any of the Error flag is ON.


ErrCode	Description
16#1400	This function is NOT available for this module.
16#1401	The value is invalid or out of range.
16#1402	No response from the module. Communication timeout.
16#1403	HWCONFIG configuration error. Instruction stops.
16#1404	There is no such counting channel for the HC module.

ErrCode	Description
16#1405	Input interface not selected. Instruction stops.
16#1406	Invalid value in <b>Action</b>
16#1409	Invalid value in <b>Yno</b>
16#1413	One of the counting channel of the HC module is executing output. Other channels cannot perform the same task at the same time.

**Example 1: Output from the output point Y when the counter value reached the set value.**


1. In HWCONFIG set the input interface of the channel 1 to pulse input or SSI input. And set the counter type to ring counter.
2. Set the value in **Comp 1** to 16#5000000, the value in **Action1** to 3, and the value in **Yno1** to 0; set the value in **Comp 2** to 16#D000000, the value in **Action2** to 3, and the value in **Yno2** to 1.
3. When M0 = ON, the counter starts counting and sets parameters for DHCCMP instruction and then waits for the counter value to meet the set value.
4. When the counter value reached **Comp 1**, the **Match 1** flag is ON. **Y0.0** is OFF→ON.
5. When the counter value reached **Comp 2**, the **Match 2** flag is ON. **Y0.1** is OFF→ON.
6. When the counter value reached **Comp 1** once again, **Y0.0** is ON→OFF. When the counter value reached **Comp 2** once again, **Y0.1** is ON→OFF.






**Example 2: Clear the counter value of its channel when the counter value reached the set value.**



1. Set the value in **Comp 1** to 2500, the value in **Action1** to 2, and the value in **Yno1** to 0; set the value in **Comp 2** to 5000, the value in **Action2** to 8, and the value in **Yno2** to 1.
2. When M0 = ON, the counter starts counting and sets parameters for DHCCMP instruction and then waits for the counter value to meet the set value.
3. When the counter value reached **Comp 1**, the **Match 1** flag is ON. **Y0.0** is OFF→ON.
4. When the counter value reached **Comp 2**, start the Action 2 = 8: clear the counter value of its channel, clear the flags of **Match 1 / Match 2** and **Y0.0 / Y0.1** to OFF.
5. When the counter value reached **Comp 1** once again, the **Match 1** flag is ON. **Y0.0** is OFF→ON.






**Example 3: Update the counter value of its channel when the counter value reached the set value.**

1. Set the value in **Comp 1** to 5000, the value in **Action1** to 3, and the value in **Yno1** to 0; set the value in **Comp 2** to 10000, the value in **Action2** to 3, and the value in **Yno2** to 1.
2. When **M0 = ON**, the counter starts counting and sets parameters for DHCCMP instruction and then waits for the counter value to meet the set value.
3. When the counter value reached **Comp 1**, the **Match 1** flag is ON. **Y0.0** is OFF → ON.
4. When the counter value reached **Comp 2**, the **Match 2** flag is ON. **Y0.1** is ON → OFF.
5. Set a new value for comparison. Set the value in **Comp 1** to 15000, the value in **Action1** to 3, and the value in **Yno1** to 0; set the value in **Comp 2** to 20000, the value in **Action2** to 6, and the value in **Yno2** to 1.
6. Set the **Update** flag to ON. Once the update is done, the flag is cleared to OFF automatically and the flags of **Match 1 / Match 2** will also be cleared.
7. When the counter value reached **Comp 1** once again. **Y0.0** is ON → OFF.
8. When the counter value reached **Comp 2** once again. **Y0.1** is ON → OFF and start the Action 2 = 6: Toggle between ON / OFF, clear the counter value of its channel, and the flags of **Match 1 / Match 2** will also be cleared.



**Example 4: Execute interrupts when the counter value reached the set value.**

1. DHCCMP instruction can be used for interrupt. Set the flags of **Match 1** and **Match 2** as interrupts of I400 and I401 respectively.
2. Set the value in **Comp 1** to 5000, the value in **Action1** to 3, and the value in **Yno1** to 0; set the value in **Comp 2** to 10000, the value in **Action2** to 3, and the value in **Yno2** to 1.
3. When M0 = ON, the counter starts counting and sets parameters for DHCCMP instruction and then waits for the counter value to meet the set value.
4. When the counter value reached **Comp 1**, I400 interrupt is executed and start the Action 1 = 3: Y0.0 toggles between ON /OFF.
5. When the counter value reached **Comp 2**, I401 interrupt is executed and start the Action 2 = 3: Y0.1 toggles between ON /OFF.



API	Instruction				Operand							Description					
1422	D	HCCMPT			Module ~ ErrCode							HC module counter value in group comparison for output					

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
Module								●					○	○		
ChNo								●					○	○		
Update		●	●	●				●								
CmpLen								●					○	○		
CompS							●	●								
ActionS								●								
YnoS								●								
InoS								●								
CurNo								●								
Error		●	●	●				●								
ErrCode								●								

Device	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
Module		●				●							
ChNo		●				●							
Update	●												
CmpLen		●				●							
CompS			●				●						
ActionS		●				●							
YnoS		●				●							
InoS		●				●							
CurNo		●				●							
Error	●												
ErrCode		●				●							

Pulse Instruction	16-bit instruction	32-bit instruction
-	-	AS

## Symbol

DHCCMPT	
En	
Module	CurNo
ChNo	Error
Update	ErrCode
CmpLen	
CompS	
ActionS	
YnoS	
InoS	

<b>Module</b>	: Module number
<b>ChNo</b>	: Channel number
<b>Update</b>	: Parameter updating flag
<b>CmpLen</b>	: Data length for comparison
<b>CompS</b>	: Compared value (32-bit)
<b>ActionS</b>	: Actions to take when the Compsis ON
<b>YnoS</b>	: Number of output point to output when the Compsis ON
<b>InoS</b>	: Number of interrupt to be executed when the Compsis ON
<b>CurNo</b>	: Current group number for comparison
<b>Error</b>	: Error flag
<b>ErrCode</b>	: Error code

## Explanation

1. This instruction is for AS02HC-A only. It is used for comparing the counter value in a cyclic manner and once the value is matched, the set action is taken. When the last group is done for comparison, set the counter value as the first compared value and the comparison goes back to the first group.
2. This instruction can only work for one direction. If you change the direction in the middle of instruction execution, the result may be incorrect. Up to 10 compared values can be set. You need to arrange the values (should be non-identical) in order, either ascending or descending. When in ascending order, the counting method is count-up and the values used should be positive integer numbers. When in descending order, the counting method is count-down and the values used should be negative integer numbers. When the counter value matched the compared value, the output points or the counter react according to your settings.
3. This instruction is available for PLC with FW V1.08.or later and ISPSOft V3.10 or later.
4. Use this instruction with **DHCCNT** instruction. When executing **DHCCNT** instruction, the counting starts. And then you can use **DHCCMPT** instruction to do the comparison.
5. Before executing this instruction, you need to set up **CmpLen**, **CompS**, **ActionS**, **YnoS** and **InoS**. Once **En** is activated, the PLC scans the values in **CmpLen**, **CompS**, **ActionS**, **YnoS** and **InoS** immediately.
6. You can edit the values in **CmpLen**, **CompS**, **ActionS**, **YnoS** and **InoS** during operation. Set new values and set the **Update** to ON. Once the values are updated, the flag of **Update** switches to OFF automatically.
7. **Module**: The module number that is connected to the right side of PLC directly or connected to the remote module that acts as PLC, e.g. the first connected module is module number 1, the second connected module is module number 2. Up to 32 modules can be connected and counted and each type of modules should be included in the count.
8. **ChNo**: Channel number for counter, channel 1 is number 1; channel 2 is number 2.
9. **CmpLen**: the data length for comparison in a cycle; the setting range is 2~10. When the setting value is out of the range, the system cannot execute the instruction and an error code appears.


10. **CompS** is where you store the values (in 32-bit integer format) for comparison. It takes several space of Dword in **CmpLen** consecutively. You need to arrange the values (should be non-identical) in order, either ascending or descending. When in ascending order, the counting method is count-up and the values used should be positive integer numbers. When in descending order, the counting method is count-down and the values used should be negative integer numbers. It is suggested to use array of Dword to declare.

When the counter type is linear, the value in **CompS** should satisfy the following condition: the *smallest counter value* < **CompS** < *the largest counter value*.

If you are using SSI (serial synchronous interface) encoder and the setting of counter mode is in Absolute Position.

The value in **CompS** should satisfy the following condition:  $0 < \mathbf{CompS} < 2^{(MT+ST \text{ Length})}$ .

11. The timing to be considered reaching the set value varies according to different settings on input interfaces in HWCONFIG, for example pulse input and SSI input.



If the input interface is pulse input, the timing to be considered to meet the set value is before the counting leaving the set value. Take **CompS** = 5 as an example, when the counting goes from 5 to 6 or from 5 to 4, the timing here is considered the set value reached.

If the input interface is SSI input, the timing to be considered reaching the set value is right before the counting touching the set value. Take Comp = 5 as an example, when the counting goes from 4 to 5 or from 6 to 5, the timing here is considered the set value reached.

12. If the counter value of **ChNo** met the set value, the appointed output point by YnoS reacts according to the settings for **ActionS**. The value in **ActionS** should be a 16-bit integer and takes several space of Word in **CmpLen** consecutively.

Action	Description	Remarks
0	No action	
1	OFF	
2	ON	
3	Toggle between ON /OFF	
4	OFF + clear the counter value of its channel	When the counter value is cleared, the value in <b>CurNo</b> is also cleared to zero.
5	ON + clear the counter value of its channel	
6	Toggle between ON /OFF + clear the counter value of its channel	
7	Clear the counter value of its channel	
8	Clear the counter value of its channel + OFF (appointed all output points by both YnoS)	

Note: there is a time difference between meeting the set value and for the action to take place. Up to 100 us of time difference can be expected.

13. The value in **YnoS** should be a 16-bit integer and takes several space of Word in **CmpLen** consecutively.

YnoS	Appointed output points
0	Y0.0
1	Y0.1
2	Y0.2
3	Y0.3

14. The value in **InoS** is the interrupt numbers. You can send specific interrupts to the PLC CPU. The allowable interrupt is ranging from I400 to I431. The value in **InoS** should be a 16-bit integer and would take several space of Word in **CmpLen** consecutively.

InoS	Action
0	No interrupt
4□□	□□ = 00~31; corresponding to I400~I431 (When the set value is met, the specific interrupt is requested by a PLC CPU.)

Note: The frequency of the interrupt device I with the same numbering should not be higher than 800Hz.

15. **CurNo** is the current group number. See the table below for reference. If the counter value is 200, the counted number is less than the value in D100, and the matched **CurNo** is 0. If the counter value is 1000, check the table below to find the value in D100 is also 1000 and the matched **CurNo** is 1.

16. **Comps**(supposing D100), **ActionS** (supposing D200), **YnoS** (supposing D300), and the value in **CmpLen** is 6.

<b>CurNo</b>	<b>CompS</b> Source value for comparison (32-bit)	<b>ActionS</b> To take when the value is met	<b>YnoS</b> (output point number)	<b>InoS</b> (interrupt number)
1	D100 = 1000	D200 = 2 (On)	D300 = 0 (Y0.0)	D400 = 400 (I400)
2	D102 = 2000	D201 = 2 (On)	D301 = 1 (Y0.1)	D401 = 401 (I401)
3	D104 = 3000	D202 = 3 (Toggle)	D302 = 0 (Y0.0)	D402 = 402 (I402)
4	D106 = 4500	D203 = 2 (On)	D303 = 2 (Y0.2)	D403 = 403 (I403)
5	D108 = 5500	D204 = 1 (Off)	D304 = 3 (Y0.3)	D404 = 404 (I404)
6	D110 = 6500	D205 = 1 (Off)	D305 = 1 (Y0.1)	D405 = 405 (I405)

17. Executing the instruction (**En OFF** → **ON**) and set the **Update** to **ON**. Once the values are updated, the instruction uses the updated values for comparison. The current number less than the corresponding value in **Comps** is set for comparison. For instance, if the current value is 3500 when the instruction is executed, the corresponding **CurNo** is 3 and the number 1~3 (counter value 3000 < current value 3500) are set for comparison. The action set is Y0.0 = **ON** + interrupt I400 request, Y0.1 = **ON** + interrupt I401 request, Y0.0 = toggle between **ON** and **OFF**) + interrupt I402 request, and the value in **CurNo** is 3.
18. If **En ON** → **OFF**, it indicates the comparison output function is disabled. The states of **CurNo** and **Output** stop updating. The counter continues to count but no comparison is made.
19. Refer to the following table for more details when any of the Error flag is **ON**.



<b>ErrCode</b>	<b>Description</b>
16#1400	This function is NOT available for this module.
16#1401	The value is invalid or out of range.
16#1402	No response from the module. Communication timeout.
16#1403	HWCONFIG configuration error. Instruction stops.
16#1404	There is no such counting channel for the HC module.
16#1405	Input interface not selected. Instruction stops.
16#1406	Invalid value in <b>Action</b>
16#1408	Incorrect order in the value of <b>CompS</b>
16#1409	Invalid value in <b>Yno</b>
16#140C	Invalid value in <b>CmpLen</b>
16#1413	One of the counting channel of the HC module is executing output. Other channels cannot perform the same task at the same time.
16#1416	Invalid value in <b>InoS</b>

**Example**

1. Set up the following parameters.

<b>CurNo</b>	<b>CompS</b> Source value for comparison (32-bit)	<b>ActionS</b> To take when the value is met	<b>YnoS</b> (output point number)	<b>InoS</b> (interrupt number)
1	D50 = 1000	D70 = 3 (Toggle)	D80 = 0 (Y0.0)	D90 = 400
2	D52 = 2000	D71 = 3 (Toggle)	D81 = 1 (Y0.1)	D91 = 401
3	D54 = 3000	D72 = 3 (Toggle)	D82 = 2 (Y0.2)	D92 = 402
4	D56 = 4000	D73 = 3 (Toggle)	D83 = 3 (Y0.3)	D93 = 403
5	D58 = 5000	D74 = 3 (Toggle)	D84 = 0 (Y0.0)	D94 = 404
6	D60 = 6000	D75 = 3 (Toggle)	D85 = 1 (Y0.1)	D95 = 405
7	D62 = 7000	D76 = 3 (Toggle)	D86 = 2 (Y0.2)	D96 = 406
8	D64 = 8000	D77 = 3 (Toggle)	D87 = 3 (Y0.3)	D97 = 407
9	D66 = 9000	D78 = 3 (Toggle)	D88 = 0 (Y0.0)	D98 = 408
10	D68 = 10000	D79 = 3 (Toggle)	D89 = 1 (Y0.1)	D99 = 409

2. Executing the instruction (**En OFF → ON**) and set the **Update** to ON. Once the values are updated, the instruction uses the updated values for comparison. The current counted number less than the corresponding value in **CompS** set for comparison. The starting current value is less than 1000, its corresponding **CurNo** is 0 and no action is taken.
3. When the counter value met 1000 (999→1000), its corresponding **CurNo** switches from 0 to 1 and **Y0.0** switches from OFF to ON, and I400 interrupt is executed. If the input interface is pulse, the comparison begins when the counter value is reaching 1001 (1000→1001).
4. When the counter value met 2000 (1999→2000), its corresponding **CurNo** switches from 1 to 2 and **Y0.1** switches from OFF to ON, and I401 interrupt is executed. If the input interface is pulse, the comparison begins when the counter value is reaching 2001 (2000→2001).
5. When the counter value met 3000 (2999→3000), its corresponding **CurNo** switches from 2 to 3 and **Y0.2** switches from OFF to ON, and I402 interrupt is executed. If the input interface is pulse, the comparison begins when the counter value is reaching 3001 (3000→3001).
6. Follow the same rule to do the comparison, until the **CurNo** is 10. After the last comparison is done, set the counter value to 1000 so that the **CurNo** can go back to 1.
7. If you are using the ring counter, when the counter value met 1000 again, the comparison starts again. The **CurNo** is 1, **Y0.0** switches from OFF to ON, and I400 interrupt is executed. And follow the same rule to do the comparison.



API	Instruction			Operand							Description					
1423	D	HCMEAS		Module ~ ErrCode							HC module measurements of frequency and revolution					

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	“\$”	F
Module								●					○	○		
ChNo								●					○	○		
Update		●	●	●				●								
Cnt/Rev								●					○	○		
Smpl								●					○	○		
Avg								●					○	○		
Freq								●								
RPM								●								
Error		●	●	●				●								
ErrCode								●								

Device	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
Module		●				●							
ChNo		●				●							
Update	●												
Cnt/Rev			●				●						
Smpl		●				●							
Avg		●				●							
Freq			●				●						
RPM			●				●						
Error	●												
ErrCode		●				●							

Pulse Instruction	16-bit instruction	32-bit instruction
-	-	AS

Symbol

DHCMEAS	
En	
Module	Freq
ChNo	RPM
Update	Error
Cnt/Rev	ErrCode
Smpl	
Avg	

- Module** : Module number
- ChNo** : Channel number
- Update** : Parameter updating flag
- Cnt/Rev** : Counted value of the encoder revolution for one time
- Smpl** : Sampling cycle
- Avg** : Average times
- Freq** : Measured frequency
- RPM** : Measured revolutions per minute (rpm)

**Error** : Error flag

**ErrCode** : Error code

### Explanation

1. This instruction is for AS02HC-A only. This instruction is available for PLC with FW V1.08.or later and ISPSOft V3.10 or later.
2. Use this instruction with **DHCCNT** instruction. When executing **DHCCNT** instruction, the counting starts. And then you can use **DHCCMP** instruction to do the comparison.
3. Before executing this instruction, you need to set up **Cnt/Rev**, **Smpl** and **Avg**. Once **En** is activated, the PLC scans the values in **Cnt/Rev**, **Smpl** and **Avg** immediately.
4. You can edit the values in **Cnt/Rev**, **Smpl** and **Avg** during operation. Set new values and set the **Update** to ON. Once the values are updated, the **Update** flag switches to OFF.
5. **Module**: The module number that is connected to the right side of PLC directly or connected to the remote module that acts as PLC, e.g. the first connected module is module number 1, the second connected module is module number 2. Up to 32 modules can be connected and counted and each type of modules should be included in the count.
6. **ChNo**: Channel number for counter, channel 1 is number 1; channel 2 is number 2.
7. **Cnt/Rev**: Counted value of the encoder revolution for one time, ranging from 1 to 4294967295 (H'00000001~H'FFFFFFFF).
8. **Smpl**: Sampling cycle, ranging from 1 to 1000, unit: ms. Different values set in **Smpl** and **Freq** for output and RPM for output may cause different resolutions.

$$\text{Resolution of Frequency} = 1000 \div \text{Smpl (unit: Hz)}$$

$$\text{Resolution of RPM} = 60000 \div \left( \text{Smpl} \times \frac{\text{Cnt}}{\text{Rev}} \right) \text{ (unit: rev/min)}$$

The start of sampling cycle and the current counted number (**CurCnt**) are two basic components for the calculation of revolution. Therefore you need to take the following factors that may affect the measurement results into account.

Encoder Type	Counter Type	Factors that affect the measurement results
Incremental Encoder	Ring counter	The difference between the counted values in the same sampling cycle exceeds the limit of $2^{31}$ .
	Linear counter	The difference between the counted values in the same sampling cycle exceeds the limit of $2^{31}$ or the counted value exceeds the upper/lower limit.
SSI encoder In Absolute Positon	Absolute Positon	The difference between the counted values in the same sampling cycle exceeds the limit of $2^{(\text{MT}+\text{ST Length})-1}$ .
	Ring Counter	The difference between the counted values in the same sampling cycle exceeds the limit of $2^{31}$ .

9. **Avg** is the average times and in the moving average of the measurement result, ranging from 1 to 10.

10. **Freq** is the measurement result of the average frequency; unit: Hz. The format is as below.

$$\text{Frequency (Hz)} = \frac{\text{CurCnt}(t + \mathbf{Smpl}) - \text{CurCnt}(t)}{\mathbf{Smpl}(\text{ms}) \times 10^{-3}}$$

11. **RPM** is the measurement result of the average revolution; unit: rev/min. The format is as below.

$$\text{Revolution (rev/min)} = \frac{(\text{CurCnt}(t + \mathbf{Smpl}) - \text{CurCnt}(t)) \times 60}{\mathbf{Cnt/Rev} \times \mathbf{Smpl}(\text{ms}) \times 10^{-3}}$$

12. If you stopped executing the instruction, its measuring function will stop. The values in **Freq** and **RPM** will not be updated.


13. Note that if you clear or change the counter value, the sampling measurement result of **Freq** and **RPM** in the cycle will be affected.

14. Refer to the following table for more details when any of the Error flag is ON.


ErrCode	Description
16#1400	This function is NOT available for this module.
16#1401	The value is invalid or out of range.
16#1402	No response from the module. Communication timeout.
16#1403	HWCONFIG configuration error. Instruction stops.
16#1404	There is no such counting channel for the HC module.
16#1405	Input interface not selected. Instruction stops.
16#140D	Invalid value in <b>Smpl</b>
16#140E	Invalid value in <b>Avg</b>
16#140F	Invalid value in <b>Cnt/Rev</b>
16#1415	One of the counting channel of the HC module is executing frequency measuring. Other channels cannot perform the same task at the same time.

**Programming Example 1: Incremental encoder**

The motor speed can be monitored by executing DHCMEAS instruction as the following procedure shown. The resolution of the encoder in this example is set to 1000 PPR.




1. Set the input interface of the channel 1 to pulse input or SSI input in HWCONFIG. And set the counter type to ring counter.
2. Set the value in **Cnt/Rev** to 1000, the value in **Smpl** to 1000 and the value in **Avg** to 10.
3. When M0 switches to ON, the counter would start to count and configure DHCMEAS parameters in module's settings at the same time for measuring frequencies and speed, which the results would be updated in the display of Freq and RPM every 1000ms.
4. While the motor is running and the encoder receives pulses of 5kHz, the results would be displayed as 5kHz in Freq and 300 rev/min in RPM. In this example, the encoder speed is the motor speed, so the motor here would be 300 rev/min.



**Programming Example2: Absolute SSI Encoder (27-bit)**

Continued with the previous example, now if changing the incremental encoder to the 13-bit absolute SSI encoder, the setting steps for DHCMEAS parameters are shown as follows.

1. Set the input interface of the channel 1 to SSI input in HWCONFIG
2. Set the value in **Cnt/Rev** to 8192, the value in **Smpl** to 1000 and the value in **Avg** to 10.
3. When M0 switches to ON, the counter would start to count and configure DHCMEAS parameters in module's settings at the same time for measuring frequencies and speed, which the results would be updated in the display of Freq and RPM every 1000ms.
4. While the motor is running and the speed of position changes of the absolute encoder with SSI is 4095 LSB/Sec, the results would be displayed as 4095kHz in Freq and 30 rev/min in RPM. In this example, the encoder speed is the motor speed, so the motor here would be 30 rev/min.



API	Instruction			Operand								Description					
1424	D	ADLOG		Listed as follows								Data log of analog input modules					

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
Group								●					○	○		
Module								●					○	○		
ChNo								●					○	○		
Mode								●					○	○		
Period								●					○	○		
Points								●					○	○		
PostTrg								●					○	○		
Datalog								●								
CurNo								●								
Cmplt		●	●	●				●								
Error		●	●	●				●								
ErrCode								●								

Data Type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
Group		●	●			●	●						
Module		●	●			●	●						
ChNo		●	●			●	●						
Mode		●	●			●	●						
Period		●	●			●	●						
Points		●	●			●	●						
PostTrg		●	●			●	●						
Datalog		●	●			●	●		●				
CurNo		●				●							
Cmplt	●												
Error	●												
ErrCode		●	●			●	●						

Pulse Instruction	16-bit instruction	32-bit instruction
-	AS	AS

ADLOG		DADLOG	
En		En	
Group	Datalog	Group	Datalog
Module	CurNo	Module	CurNo
ChNo	Cmplt	ChNo	Cmplt
Mode	Error	Mode	Error
Period	ErrCode	Period	ErrCode
Points		Points	
Postrig		Postrig	

- Group** : Group number
- Module** : Module number
- ChNo** : Channel number
- Mode** : Record mode
- Period** : Record period

- Points** : The total number of all records
- PostTrg** : The number of records after being triggered
- Datalog** : The device to store data logs
- CurNo** : The number of the accumulated log points
- Cmplt** : Completion flag of recording logs
- Error** : Error flag
- ErrCode** : Error code

**Explanation**

1. This instruction is for analog input modules (AS04AD-A, AS06XA-A, AS02ADH-A) to enable or disable the record function and send the record data to the designated Datalog devices. This instruction is available for PLC with FW V1.10.00 or later and ISPSOft V3.13 or later.
2. The description of record period and log points is specified in the following table. Refer to the description concerning Mode for more details.

Model	Record period	Number of records
AS04AD-A AS06XA-A	<u>Fixed period mode:</u> The setting range is from 1 to 100 and the time unit is fixed to 10ms.	A fixed number of 500
AS02ADH-A	<u>Fixed period mode, Fixed period + Trigger start mode, Fixed period + Trigger position assign mode:</u> The setting range is from 1 to 32000 and the options for time unit are 20us,40us, and 80us. (Note: The time unit is the sampling period set in HWCONFIG.)  <u>Point Logging mode:</u> A point would be recorded once detecting a triggering signal at the external input point not within a fixed period. The trigger timing for external input points is set in HWCONFIG. Trigger timing of channel1 is when rising edge or falling edge is detected at X0.0. Trigger timing of channel2 is when rising edge or falling edge is detected at X0.1.	The setting range is from 1 to 2000.

3. **Group** is used to specify the analog input module connected to the right side of PLC directly or connected to the remote module that acts as PLC, e.g. the PLC is number 0, the first remote module would be number 1 and so on. The maximum group number is 15.
4. **Module:** The module number that is connected to the right side of PLC directly or connected to the remote module that acts as PLC, e.g. the first connected module is module number 1, the second connected module is module number 2. Up to 32 modules can be connected and counted and each type of modules should be included in the count.
5. **ChNo:** The specified channel number. Channel1 would be numbered 1 and channel 2 is numbered 2.


6. **Mode:** Record mode. Modes supported by the corresponding models are listed as follows.

Models	Mode	Mode name	Description
AS04AD-A AS06XA-A	K0	Fixed period	Perform recording periodically.
AS02ADH-A	K0	Fixed period	Perform recording periodically.
	K1	Fixed period + Trigger start	Wait for trigger signal detected at external input points. After received, periodic recording would be performed.
	K2	Point logging	No fixed period for recording. One log point would be recorded each time a trigger signal is detected at the external input point.
	K3	Fixed period + Trigger position assign	You can specify the external trigger timing to record the data logs during the periods before and after the trigger timing.

- (1) Fixed period mode: Set **Mode**=0, the data recording would be performed according to the pre-defined record period when **EN** switches to ON. After the recording of a specified number of log points is complete, the **Cmplt** flag would be set to High automatically.

**Example:**

Set **Points** = 2000




- (2) Fixed period + Trigger start mode: Set **Mode**=1 and switch instruction **EN** to ON before the recording starts. When a trigger signal is detected at the external input point, start recording based on the pre-defined record period. And the **Cmplt** flag is set to **High** automatically when completed. Before the recording is complete, any operation at the external input points does NOT affect the proceeding of record. When the recording of log points is complete and the **Cmplt** flag is **High**, trigger the external input points again to start a new cycle of recording; the instruction EN does NOT required to be turned OFF and then ON again to start another new recording.


Record Channel	The signal source corresponding to the external input points (Set the timing for external input trigger in HWCONFIG )
Channel 1	X0.0 rising-edge or falling-edge triggered
Channel 2	X0.1 rising-edge or falling-edge triggered

**Example:**

Set **Points** = 2000, the trigger timing for the external input point is set to rising-edge triggered.



The feature of Fixed period + Trigger Start is similar to Fixed period. But the start timing of recording in Fixed period mode would be delayed as a result of PLC scan time and module communication time, which is shown in the following illustration. It is assumed that M0 is the device to control EN of ADLOG instruction. We can see when M0 switches from OFF to ON, the module does not start recording immediately but with a slight delay.




- (3) Point Logging mode: Set **Mode=2**, turn the instruction EN to ON before the recording starts. One log point would be recorded for each triggering at external input point until it reaches the pre-defined point number, **Cmplt** flag would set to High automatically. If you need to the recording to be continued after the **Cmplt** flag is set to High, execute the instruction again.

Record Channel	The signal source corresponding to the external input points (Set the timing for external input trigger in HWCONFIG )
Channel 1	X0.0 rising-edge or falling-edge triggered
Channel 2	X0.1 rising-edge or falling-edge triggered

**Example:**

Set **Points** = 2000, the trigger timing for external input point is set to rising-edge triggered.




- (4) Fixed period + Trigger position Assign mode: Set **Mode=3** and set parameters **Points** and **PostTrg** according to your requirements. This mode is to trigger at the external input point and record the pre-defined number of log points before and after the triggering occurs. When using EN to turn on this mode, AS02ADH-A would start waiting for signals to be triggered at external input. And the sampling would start right after, until it reaches the pre-defined point number, and then **Cmplt** flag would set to High automatically. The value in **CurNo** is 0 before triggered, and after triggered, the modules start to send the before-triggered data log to the PLC CPU . Therefore the value of **CurNo** would catch up to the number of accumulated log points.

Record Channel	The signal source corresponding to the external input points (Set the timing for external input trigger in HWCONFIG )
Channel 1	X0.0 rising-edge or falling-edge triggered
Channel 2	X0.1 rising-edge or falling-edge triggered

**Example**

Set **Mode=3**, **Points = 2000**, and **PostTrg = 1500** so the position of point 501 (**Points – PostTrg**) would be the first record after an external trigger signal is detected.



7. **Period** is set for the record period, which is detailed as follows:

Model	Setting Range for Period	Period Unit
AS04AD-A AS06XA-A	1~100	The unit is fixed to be 10ms, unchangeable.
AS02ADH-A	1~32000	The sampling period would need to be set in HWCONFIG with options of 20us, 40us, and 80us. If set " <b>Mode=2:Point Logging</b> ", the value of Period would be invalid.

8. **Points** is the number of total records which is only applicable for AS02ADH-A, and can set a maximum of 2000 records. For other models, the setting value is fixed to 500.


Model	Setting range for total records
AS04AD-A AS06XA-A	The value is fixed to be 500, other setting value is invalid.
AS02ADH-A	Configurable, the setting value ranges from 1 to 2000.

9. **PostTrg** is the number of log points recorded after Trigger occurs which should be applied with **Points**, to record the number of all records, including data before and after the triggering. **PostTrg** is only applicable for Fixed period + Trigger position assign mode (**Mode=3**) and invalid for other modes. Please note that the value of **PostTrg** should not be greater than the value in **Points** (the number of all records), or the value in **PostTrg** would be replaced with the value in **Points**. For example, if **Points = 100** and **PostTrg = 200**, the value in **PostTrg** would be seen as the value in **Points**, which is 100, since the value in **PostTrg** is greater than the value in **Points** (the number of all records). Therefore, only a number of 100 points would be recorded after the triggering occurs.

Model	Setting range for PostTrg value
AS02ADH-A	0 ~2000 point (Should not be greater than the value in <b>Points</b> )

**Example**

Set **Points** = 1000 and **PostTrg** = 700, and then there would be 1000 logs, including 300 pieces of data before triggering and 700 pieces of data after triggering.



10. **Datalog** is the device to store data logs. If selecting integral to be the format of output values of AD module, we suggest to use it with 16-bit ADLOG instruction. A space of 500 words would be occupied by using AS04AD-A or AS06XA-A, while a space ranging from 1 to 2000 words (based on the number of total records) could be occupied by using AS02ADH-A model. (if using 32-bits DADLOG instruction, the 16-bit data would be expanded to 32 bits which the data space is taken doubly.) If selecting floating point to be the format of output values of AD module, you must use it with 32-bit ADLOG instruction. A space of 1000 words would be occupied by using AS04AD-A or AS06XA-A, while a space ranging from 2 to 4000 words (based on the number of total records) could be occupied by using AS02ADH-A.
11. **CurNo** is the number of records which has been sent back to the PLC by the module. When the recording is in progress, the value of **CurNo** may not be able to be viewed in a consecutive order as a result of impacts from scan period.
12. **Cmplt**, the completion flag is used for indicating the logs recording is complete. When **Cmplt** switches from OFF to ON, it is indicated that all the log data has been sent to the designated **Datalog** device. When **EN** switches from OFF to ON, the **Cmplt** flag would be initialized to OFF automatically.
13. If you stop executing this instruction, the designated channel would stop updating the right side values.
14. Refer to the following table for more details when any of the Error flag is ON.

ErrCode	Description
16#1400	This function is NOT available for this module.
16#1401	The setting of group number or module number is incorrect.
16#1402	The input value of the module is illegal or out of range.
16#1403	There're no responses from the module. Communication timeout.
16#1404	The channel cannot be found in AD module.
16#1405	The channel designated by AD module is in progress of recording. Other channels cannot perform the same task at the same time.
16#1406	The data format of AD module and the instruction do not match with each other.
16#1407	The value in record mode is out of range.
16#1408	The value in record period is out of range.
16#1409	The number of all records ( <b>Points</b> ) is out of range.

API	Instruction			Operand								Description				
1425	D	ADPEAK		Listed as follows								Record peak values of analog input modules.				

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
Group								●					○	○		
Module								●					○	○		
ChNo								●					○	○		
MAX								●								
MIN								●								
Error		●	●	●				●								
ErrCode								●								

Data Type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
Group		●	●			●	●						
Module		●	●			●	●						
ChNo		●	●			●	●						
MAX		●	●			●	●		●				
MIN		●	●			●	●		●				
Error	●												
ErrCode		●				●							

Pulse Instruction	16-bit instruction	32-bit instruction
-	AS	AS

6

ADPEAK		DADPEAK	
En		En	
Group	MAX	Group	MAX
Module	MIN	Module	MIN
ChNo	Error	ChNo	Error
	ErrCode		ErrCode

- Group** : Group number
- Module** : Module number
- ChNo** : Channel number
- MAX** : Maximum
- MIN** : Minimum
- Error** : Error flags
- ErrCode** : Error codes

**Explanation**

1. ADPEAK is dedicated for analog input modules (AS04AD-A, AS08AD-B, AS08AD-C, AS06XA-A, AS02ADH-A) to enable and disable the recording of peak values. This instruction is available for PLC with FW V1.10.00 or later and ISPSOft V3.13 or later.
2. **Group** is used to specify the analog input module connected to the right side of PLC directly or connected to the remote module that acts as PLC, e.g. the PLC is number 0, the first remote module would be number 1 and so on. The maximum group number is 15.
3. **Module**: The module number that is connected to the right side of PLC directly or connected to the remote module that acts as PLC, e.g. the first connected module is module number 1, the second connected module is module number 2. Up to 32 modules can be connected and counted and each type of modules should be included in the count.
4. **ChNo**: The specified channel number. Channel1 would be numbered 1 and channel 2 is numbered 2.
5. **MAX** and **MIN** are respectively the maximum value and the minimum value. When EN switches from OFF to ON, the values of **MAX** and **MIN** would be initialized to a new measured value and start recording peak values. The values of **MAX** and **MIN** would be updated continuously while detecting maximum and minimum values. If selecting integral to be the format of output values of AD module, we suggest to use it with 16-bit ADPEAK instruction. If selecting floating point to be the format of output values of AD module, you must use it with 32-bit DADPEAK instruction.
6. If **En** switches from ON to OFF, the function of recording peak values would be disabled. Meanwhile, the values of **MAX** and **MIN** would be unchanged and would not be updated.
7. Refer to the following table for more details when any of the Error flag is ON

ErrCode	Description
16#1400	This function is NOT available for this module.
16#1401	The setting of group number or module number is incorrect.
16#1402	The input value of the module is illegal or out of range.
16#1403	There are no responses from the module. Communication timeout.
16#1404	The channel cannot be found in AD module.
16#1405	The channel designated by AD module is in progress of recording. Other channels cannot perform the same task at the same time.
16#1406	The data format of AD module and the instruction do not match with each other.

API	Instruction			Operand								Description					
1426		IOLINKR		Execute ~ DataRead								Read the parameter from the O-Link device					
Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	“\$”	F	
Group								●					○	○			
Module								●					○	○			
Port								●					○	○			
Index								●					○	○			
SubIndex								●					○	○			
DataType								●					○	○			
Done		●	●	●				●									
Error		●	●	●				●									
ErrCode								●									
ReadLen								●									
DataRead								●									

資料型態	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
Group		●				●							
Module		●				●							
Port		●				●							
Index		●				●							
SubIndex		●				●							
DataType		●				●							
Done	●												
Error	●												
ErrCode		●				●							
ReadLen		●				●							
DataRead		●				●							
Data Type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
Group		●				●							
Module		●				●							
Port		●				●							
Index		●				●							
SubIndex		●				●							
DataType		●				●							
Done	●												
Error	●												
ErrCode		●				●							
ReadLen		●				●							

<b>DataRead</b>		●				●							
-----------------	--	---	--	--	--	---	--	--	--	--	--	--	--

Pulse Instruction	16-bit instruction	32-bit instruction
-	AS	-

**Symbol**

IOLINKR	
En	
Group	Done
Module	Error
Port	ErrCode
Index	ReadLen
SubIndex	DataRead
DataType	

- Group** : Group number
- Module** : Module number
- Port** : Communication port number
- Index** : Index number of the parameter
- SubIndex** : Subindex number of the parameter
- DataType** : Data type
- ReadLen** : The length of the read data
- DataRead** : Data that is read
- Done** : Communication complete
- Error** : Error flag
- ErrCode** : Error code

**Explanation**

1. This instruction is available for PLC with FW V1.08.50 or later and ISPSOft V3.12 or later.
2. You can refer to the IO-Link device to learn more about the device parameters. You can also use this instruction to read the IO-Link device parameters.
3. There is no limit on the number of times you execute the instruction but only one instruction (IOLINKR or IOLINKW) can be executed at a time.
4. During communication, it takes at least 5 seconds for the IO-Link device to response. Do NOT stop or start another instruction during this time. After the communication with IO-Link is done, it is suggested to use the flags DONE or ERROR to stop or start the instruction.
5. **Group**: The group number of AS04SIL that is connected to the right side of PLC directly or connected to the remote module that acts as PLC, e.g. the first connected module is module number 1, the second connected module is number 2. Up to 15 modules can be connected. If the connected module is not AS04SIL, the Error flag switches to ON.
6. **Module**: The module number that is connected to the right side of PLC directly or connected to the remote module that acts as PLC, e.g. the first connected module is module number 1, the second connected module is module number 2. Up to 32 modules can be connected and counted and each type of modules should be included in the count. If the module is not AS04SIL, the Error flag switches to ON.
7. **Port**: The communication port number, ranging from 1 to 4. If the port number used is not the port for AS04SIL, the Error flag switches to ON.
8. **Index** is the index number that is read from the parameter of the IO-Link device.
9. **SubIndex** is the sub-index number that is read from the parameter of the IO-Link device. The sub-index number can be set from 0 to 255. If the value exceeds the setting range, the Error flag switches to ON.
10. **DateType** is the parameter data type of the IO-Link device. You need to set the correct datatype before executing this instruction.

If the setting value exceeds the setting range, the Error flag switches to ON.

Error Code	Data Type	Description
0x0000	BooleanT	Boolean; data length: 1 byte
0x0001	UIntegerT	Unsigned integer; data length: 1, 2, 4, 8 byte
0x0002	IntegerT	Signed integer; data length: 1, 2, 4, 8 byte
0x0003	Float32T	Floating-point; data length: 4 byte
0x0004	StringT	String; data length: 1~232 byte; Null (0x00) is seen as the ending character for the string.
0x0005	OctetStringT	Fixed length string, defined by the IODD fixed length; data length: 1~232 byte
0x0006	TimeT	Time; data length: 4 byte (Resolution: 1 second) + 4 Byte (Resolution: 2 <sup>-32</sup> second)
0x0007	TimeSpanT	Time; data length: 8 byte (Resolution: 2 <sup>-32</sup> second)
0x0008	ArrayT	A whole array that is read from the sub-index number 0
0x0009	RecordT	A whole record that is read from the sub-index number 0
Others	Reserved	Reserved


11. **DataRead** is the data read from the IO-Link device; unit: byte, arranged by high byte and low byte.
12. **ReadLen** is the data length of the data read from the IO-Link device; unit: byte.
13. **Done** is a communication complete flag. When this flag is ON, it indicates the parameter of the IO-Link device is read completely. The range of the read data (ReadData) will be used according to the data length (READLen).
14. **Error** is a communication error flag. When this flag is ON, it indicates an error occurs during the communication among the PLC CPU, AS04SIL and the IO-Link device. Refer to the following Error Codes for troubleshooting.
15. Refer to the following table for more details when any of the Error flag is ON.

Error Code	Description
0x8000	IO-Link device application error
0x8011	The main index does NOT exist.
0x8012	The sub-index does NOT exist.
0x8020	The function is currently NOT available.
0x8021	The function is currently NOT available – Local Control.
0x8022	The function is currently NOT available – Device Control.
0x8023	Access denied.
0x8030	The parameter exceeds the setting range.
0x8031	The parameter exceeds the upper limit.
0x8032	The parameter exceeds the lower limit.
0x8033	The parameter length overrun

0x8034	The parameter length underrun
0x8035	The function is NOT available.
0x8036	The function is currently NOT available.
0x8040	Invalid parameters set
0x8041	Inconsistent parameters set
0x8082	Application is NOT ready for use.
0x8101	The IO-Link device is NOT in IO-Link mode.
0x8102	The communication port is NOT connected to any IO-Link device.
0x8103	The connection to IO-Link device is establishing.
0x8104	Communication port number exceeds the setting range 1~4.
0x8105	The sub-index number of the parameter exceeds the setting range 0~255.
0x8106	The data to be read and written exceeds the setting range 1~232.
0x8107	Reserved
0x8108	Communication timeout; no response from IO-Link device for over 5000 ms.
0x8109	Incorrect AS04SIL module number or group number
0x810A	Internal communication error
0x810B	Execute more than two IO-Link read/write instructions on the same AS04SIL module.
0x810C	The starting address of the read/write device + the data length to read/write exceed the device setting range.
0x810D	The value of the parameter data type exceeds the setting range.
0x810E	The parameter data type and the read/write data length are inconsistent.


6

16. The communication process among the PLC CPU, AS04SIL and IO-Link device:




- A: The PLC CPU sends data to AS04SIL.
- B: AS04SIL sends data to the IO-Link device.
- C: the IO-Link Device is processing the request and send data to AS04SIL.
- D: The PLC CPU updates the status (DONE / ERROR) and receives the data.

17. Sequences of the EN, Done, and Error flags: when an error occurs during communication (scenario 1) and when the communication is complete (scenario 2).




**Example 1: Read the parameter of Application Specific Tag on the first device of the first communication port.**

1. Check HWCONFIG to learn the setting value in Application Specific Tag is "ABCDEFGH".




2. AS04SIL is the first module that installed on the right side of the PLC CPU. The setting value in **Group** is 0, and 1 in both **Module** and **Port**.
3. We learnt that its index is 24, its Sub-index is 0, and the data type is StringT from its IODD file or the IO-Link device manual. Set the setting values in Index to 24, in Sub-index to 0, in data type to 4 (StringT).
4. Start sending "to read" request when M0 is ON. When M10 (DONE) is ON, it indicates the device has responded and has complete reading. ReadLen (D40) is 32, and the data string is stored in DataRead (D50~D65). IO-Link device reads the data and stores it in accordance with the order of high byte and low byte.




Object	Identifiers	Device Name	Status	Data Type	Value (16bits)	Value (32bits)	Float	Radix	Comment...
		M1							
		M10							
		M20							
		D30			0000	00000000	0.0000	Hexadecimal	
		D40			32	32	0.0000	Signed Decima	
		D50			4241	44434241	781.0352	Hexadecimal	
		D51			4443	46454443	12625.0654	Hexadecimal	
		D52			4645	48474645	204057.0781	Hexadecimal	
		D53			4847	00004847	0.0000	Hexadecimal	
		D54			0000	00000000	0.0000	Hexadecimal	
		D55			0000	00000000	0.0000	Hexadecimal	
		D56			0000	00000000	0.0000	Hexadecimal	
		D57			0000	00000000	0.0000	Hexadecimal	
		D58			0000	00000000	0.0000	Hexadecimal	
		D59			0000	00000000	0.0000	Hexadecimal	
		D60			0000	00000000	0.0000	Hexadecimal	
		D61			0000	00000000	0.0000	Hexadecimal	
		D62			0000	00000000	0.0000	Hexadecimal	
		D63			0000	00000000	0.0000	Hexadecimal	
		D64			0000	00000000	0.0000	Hexadecimal	

**Example 2: Read the parameter of gain trim green channel on the first device of the second communication port.**

1. Check HWCONFIG to learn the setting value in gain trim green channel is "-63".




2. AS04SIL is the first module that installed on the right side of the PLC CPU. The setting value in **Group** is 0, 1 in **Module** and 2 in **Port**.
3. We learnt that its index is 72, its Sub-index is 0, and the data type is IntegerT from its IODD file or the IO-Link device manual. Set the setting values in Index to 72, in Sub-index to 0, in data type to 2 (IntegerT).
4. Start sending "to read" request when M0 is ON. When M10 (DONE) is ON, it indicates the device has responded and has complete reading. ReadLen (D40) is 1, and the data is stored in DataRead (D50 Low Byte). IO-Link device reads the data and stores it in accordance with the order of high byte and low byte.




Object	Identifiers	Device Name	Status	Data Type	Value (16bits)	Value (32bits)	Float	Radix	Comment...
		M1							
		M10							
		M20							
		D30			0000	00000000	0.0000	Hexadecimal	
		D40			1	1	0.0000	Signed Decima	
		D50			00C1	000000C1	0.0000	Hexadecimal	

**Example 3: Read the parameter of gain trim green channel on the first device of the second communication port.**

1. Check HWCONFIG to learn the setting value in Ambient temperature is 28.60551.



2. AS04SIL is the first module that installed on the right side of the PLC CPU. The setting value in **Group** is 0, 1 **Module** and 2 in **Port**.
3. We learnt that its index is 268, its Sub-index is 0, and the data type is Float32T from its IODD file or the IO-Link device manual. Set the setting values in Index to 268, in Sub-index to 0, in data type to 3 (Float32T).
4. Start sending “to read” request when M0 is ON. When M10 (DONE) is ON, it indicates the device has responded and has complete reading. ReadLen (D40) is 4, and the data is stored in DataRead (D50~D51). IO-Link device reads the data and stores it in accordance with the order of high byte and low byte.



Object	Identifiers	Device Name	Status	Data Type	Value (16bits)	Value (32bits)	Float	Radix	Comment...
		M1							
		M10							
		M20							
		D30			0	0	0.0000	Signed Decima	
		D40			4	4	0.0000	Signed Decima	
		D50			-26209	1105566111	28.7000	Signed Decima	
		D51			16869	16869	0.0000	Signed Decima	

API	Instruction			Operand							Description						
1427	IOLINKW			Execute ~ ErrCode							Write the parameter into the IO-Link device						
Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	“\$”	F	
Group								●					○	○			
Module								●					○	○			
Port								●					○	○			
Index								●					○	○			
SubIndex								●					○	○			
Data Type								●					○	○			
WriteLen								●					○	○			
DataWrite								●									
Done		●	●	●				●									
Error		●	●	●				●									
ErrCode								●									

Data Type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
Group		●				●							
Module		●				●							
Port		●				●							
Index		●				●							
SubIndex		●				●							
Data Type		●				●							
WriteLen		●				●							
DataWrite		●				●							
Done	●												
Error	●												
ErrCode		●				●							

Pulse Instruction	16-bit instruction	32-bit instruction
-	AS	-

## Symbol


IOLINKW	
En	
Group	Done
Module	Error
Port	ErrCode
Index	
SubIndex	
DataType	
WriteLen	
DataWrite	

<b>Group</b>	: Group number
<b>Module</b>	: Module number
<b>Port</b>	: Communication port number
<b>Index</b>	: Index number of the parameter
<b>SubIndex</b>	: Subindex number of the parameter
<b>DataType</b>	: Data type
<b>WriteLen</b>	: The length of the written data
<b>DataWrite</b>	: Data that is written
<b>Done</b>	: Communication complete
<b>Error</b>	: Error flag
<b>ErrCode</b>	: Error code

## Explanation


1. This instruction is available for PLC with FW V1.08.50 or later and ISPSOft V3.12 or later.
2. You can refer to the IODD file of the IO-Link device to learn more about the device parameters. You can also use this instruction to write the parameters into the IO-Link device.
3. There is no limit on the number of times you execute the instruction but only one instruction (IOLINKR or IOLINKW) can be executed at a time.
4. During communication, it takes at least 5 seconds for the IO-Link device to response. Do NOT stop or start another instruction during this time. After the communication with IO-Link is done, it is suggested to use the flags DONE or ERROR to stop or start the instruction.
5. **Group**: The group number of AS04SIL that is connected to the right side of PLC directly or connected to the remote module that acts as PLC, e.g. the first connected module is module number 1, the second connected module is number 2. Up to 15 modules can be connected. If the connected module is not AS04SIL, the Error flag switches to ON.
6. **Module**: The module number that is connected to the right side of PLC directly or connected to the remote module that acts as PLC, e.g. the first connected module is module number 1, the second connected module is module number 2. Up to 32 modules can be connected and counted and each type of modules should be included in the count. If the module is not AS04SIL, the Error flag switches to ON.
7. **Port**: The communication port number, ranging from 1 to 4. If the port number used is not the port for AS04SIL, the Error flag switches to ON.
8. **Index** is the parameter index number that is intended to write into the IO-Link device.

9. **SubIndex** is the parameter sub-index number that is intended to write into the IO-Link device. The sub-index number can be set from 0 to 255. If the value exceeds the setting range, the Error flag switches to ON.
10. **DateType** is the parameter data type of the IO-Link device. You need to set the correct datatype before executing this instruction. Refer to API1426 IOLINKR instruction for more information.
11. **DataWrite** is the data written into the IO-Link device; unit: byte, arranged by high byte and low byte.
12. **WriteLen** is the data length of the data to be written into the IO-Link device; unit: byte.
13. **Done** is a communication complete flag. When this flag is ON, it indicates the parameters have written into the IO-Link device completely.
14. **Error** is a communication error flag. When this flag is ON, it indicates an error occurs during the communication among the PLC CPU, AS04SIL and the IO-Link device. Refer to the **Error Codes** from API1426 IOLINKR instruction for troubleshooting.
18. The communication process among the PLC CPU, AS04SIL and IO-Link device:




- A: The PLC CPU sends data to AS04SIL.
- B: AS04SIL sends data to the IO-Link device.
- C: the IO-Link Device is processing the request and send data to AS04SIL.
- D: The PLC CPU updates the status (DONE / ERROR) and receives the data.

19. Sequences of the EN, Done, and Error flags: when an error occurs during communication (scenario 1) and when the communication is complete (scenario 1).




**Example 1: Write the parameter of Application Specific Tag into the first device of the first communication port.**

1. Check HWCONFIG to learn the setting value in Application Specific Tag is "ABCDEFGH".




2. AS04SIL is the first module that installed on the right side of the PLC CPU. The setting value in **Group** is 0, 1 in **Module** and 1 in **Port**.
3. We learnt that its index is 24, its Sub-index is 0, and the data type is StringT from its IO-Link device manual. Set the setting values in Index to 24, in Sub-index to 0, in data type to 4 (StringT).
4. Use the instruction \$MOV to write the string "IO-Link" into the data device, starting from D60.
5. Start sending "to write" request when M1 is ON. When M10 (DONE) is ON, it indicates the device has received the response and has complete writing. WriteLen is 32, and the data string is saved in DataWrite (D60~D75). IO-Link device writes the data into the data devices in accordance with the order of high byte and low byte.




Object	Identifiers	Device Name	Status	Data Type	Value (16bits)	Value (32bits)	Float	Radix	Comment...
		M1							
		M10							
		M20							
		D30			0000	00000000	0.0000	Hexadecimal	
		D60			4F49	4C2D4F49	45432100.0000	Hexadecimal	
		D61			4C2D	6E494C2D	15574644460718199940000	Hexadecimal	
		D62			6E49	006B6E49	0.0000	Hexadecimal	
		D63			006B	0000006B	0.0000	Hexadecimal	
		D64			0000	00000000	0.0000	Hexadecimal	
		D65			0000	00000000	0.0000	Hexadecimal	
		D66			0000	00000000	0.0000	Hexadecimal	
		D67			0000	00000000	0.0000	Hexadecimal	
		D68			0000	00000000	0.0000	Hexadecimal	
		D69			0000	00000000	0.0000	Hexadecimal	
		D70			0000	00000000	0.0000	Hexadecimal	
		D71			0000	00000000	0.0000	Hexadecimal	
		D72			0000	00000000	0.0000	Hexadecimal	
		D73			0000	00000000	0.0000	Hexadecimal	
		D74			0000	00000000	0.0000	Hexadecimal	

6. Check HWCONFIG to learn the setting value in Application Specific Tag is updated to "IO-Link".




**Example 2: Write the parameter of gain trim green channel into the first device of the second communication port.**

1. Check HWCONFIG to learn the setting value in gain trim green channel is "-63".



2. AS04SIL is the first module that installed on the right side of the PLC CPU. The setting value in **Group** is 0, 1 in **Module** and 2 in **Port**.
3. We learnt that its index is 72, its Sub-index is 0, and the data type is IntegerT from its IO-Link device manual. Set the setting values in Index to 72, in Sub-index to 0, in data type to 2 (IntegerT).
4. Use the instruction \$MOV to write 0xE2 (-30) into the data device, starting from D60.
5. Start sending "to write" request when M1 is ON. When M10 (DONE) is ON, it indicates the device has received the response and has complete writing. WriteLen is 1, and the data is saved in DataWrite (D60 Low byte). IO-Link device writes the data into the data devices in accordance with the order of high byte and low byte.



Object	Identifiers	Device Name	Status	Data Type	Value (16bits)	Value (32bits)	Float	Radix	Comment...
		M1							
		M10							
		M20							
		D30			0000	00000000	0.0000	Hexadecimal	
		D60			00E2	000000E2	0.0000	Hexadecimal	

7. Check HWCONFIG to learn the setting value in gain trim green channel is updated to "-30".

Name	Value	Unit
Conversion Time	100 (0)	
Trim Gain	use factory-programmed trim gains (false)	
gain trim green cha...	-30	

API	Instruction code			Operand								Function				
1430	MLPF			Group ~ ErrCode								Low-pass filter for analog input signals				


Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
Group								●					○	○		
Module								●					○	○		
ChNo								●					○	○		
Fcutoff								●					○	○		
Error		●	●	●				●								
ErrCode								●								

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
Group		●				●							
Module		●				●							
ChNo		●				●							
Fcutoff		●				●							
Error	●												
ErrCode		●				●							

Pulse instruction	16-bit instruction	32-bit instruction
-	AS	-

Symbol

6



- Group** : Group number
- Module** : Module number
- ChNo** : Channel number
- Fcutoff** : Cutoff frequency
- Error** : Error flag
- ErrCode** : Error code

**Explanation**

1. The instruction provides the function of a digital low-pass filter for analog input signals. And the instruction should be used along with ISPSOft V3.16 or later.

**The firmware versions of the required devices:**

Item	Model	Firmware	Remark
<b>AD function card</b>	AS-F2AD	V1.40 or later	PLC firmware V1.14 or later
<b>Extension modules</b>	AS04AD-A, AS08AD-A, AS06XA-A	V1.02 or later	PLC firmware version must be V1.14 or later. Besides the firmware of the connected PLC should be V1.14 or later, the firmware for AS00SCM-A must be V2.08 or later.
	AS02LC-A	V1.06 or later	
<b>PLC with built-in AD channels</b>	AS218	Firmware: V1.12 or later	

2. After enabling the MLPF instruction, the input value corresponding to the channel changes from the original average value to the result of the digital filter.
3. For the assigned device, if the MLPF instruction is enabled for any of its channels, the sampling times of all analog channels will be specified to their mandatory values and original sampling time setting will be invalid. If the MLPF instruction is disabled, then the sampling will be conducted according to original sampling time setting.

Model name	AS-F2AD	AS04AD-A, AS08AD-A, AS06XA-A	AS02LC-A	PLC built-in AD
Sampling time specified mandatorily	2 ms	2 ms	10 ms	2 ms

4. **Group** specifies the group number for the analog input modules connected to the right side of the PLC or the remote modules. The number of the PLC CPU is 0, the number of the first remote module is 1, and so forth. The maximum group number is 15.
5. **Module** specifies a module number. If the input channel is an analog input channel built in the PLC CPU, the value must be set to 0. If the input channel is an analog input channel of the AS-F2AD function card, set the operand to 33 or 34 according to the function card slot where the module is located.

Module	Description
0	PLC built-in analog input channels
1	The 1 <sup>st</sup> extension module number on the right of the PLC
2	The 2 <sup>nd</sup> extension module number on the right of the PLC
3 ~ 32	According to the above arrangement rule, a maximum of 32 extension modules can be connected on the right side of the PLC.
33	Function card slot 1
34	Function card slot 2


6. **ChNo** specifies the channel number for using the low-pass filter.

Module	ChNo	Description
0	1	Analog input channel 1 built in the PLC CPU
	2	Analog input channel 2 built in the PLC CPU
1	1	Input channel 1 of the 1 <sup>st</sup> extension module
	2 ~ 8	Input channels 2 ~ 8 of the 1 <sup>st</sup> extension module
2	1	Input channel 1 of the 2 <sup>nd</sup> extension module
	2 ~ 8	Input channels 2 ~ 8 of the 2 <sup>nd</sup> extension module
3 ~ 32		Follow the same rules as the previous ones shown above.
33	1	Analog input channel 1 of AS-F2AD in Function card slot 1
33	2	Analog input channel 2 of AS-F2AD in Function card slot 1
34	1	Analog input channel 1 of AS-F2AD in Function card slot 2
34	2	Analog input channel 2 of AS-F2AD in Function card slot 2

7. **Fcutoff** is the cut-off frequency of the low-pass filter; the setting range is as follows:

Model name	Range of Fcutoff value	Characteristic
AS-F2AD, AS218 (with built-in AI/AO channels), AS04AD-A, AS08AD-B, AS08AD-C, AS06XA-A	5~100, unit: Hz	<p>Magnitude (dB)</p> <p>Frequency</p> <p>-3 dB (Amplitude ratio: 0.707)</p> <p>Slope: -40dB/decade</p>
AS02LC-A	0: 5Hz 1: 10Hz 2: 20Hz 3: 50/60Hz (For the 50/60Hz waveform attenuation)	<p>LPF 5Hz, 10Hz and 20Hz correspond to to the magnitudes:</p> <p>Magnitude (dB)</p> <p>Frequency (Hz)</p> <p>— LPF 5Hz — LPF 10Hz — LPF 20Hz</p> <p>LPF 50/60Hz corresponds to the magnitude:</p>

6




- Before modifying any parameters during execution, you need to disable MLPF instruction first. After the modification is complete, enable the instruction again.
- Refer to the following table for the description of error codes (**ErrCode**) when the error flag **Error** is ON.


Error code	Description
0x1400	The function is not supported by the device.
0x1401	The group number or module number is not set properly.
0x1402	The channel does not exist in the module.
0x1403	<b>Fcutoff</b> value exceeds the set range.
0x1404	No response from the module and communication timeout
0x1405	The digital low-pass filter function for the specified channel has been enabled. Repeatedly specifying the same channel is forbidden.

**Example 1**

1. Take AS218 built-in analog input channel 1 as an example, set **Group = 0, Module = 0, ChNo = 1, Fcutoff = 10 (Hz)**.
2. The frequency of the digital low-pass filter corresponds to the magnitude as follows.




3. Input the signal for testing:  
 The 5Vdc + 60Hz sinusoidal wave is a blue waveform as below (peak-to-peak: 4V).  
 After the signal passes through the low-pass filter, a red waveform is output. It can be seen that the 60Hz sinusoidal wave is attenuated and what is left is the 5Vdc direct current in the curve.




**Example 2**

1. Take input channel 2 of the first AS02LC-A on the right side of the PLC CPU for example, set **Group = 0, Module = 1, ChNo = 2, Fcutoff = 3 (50/60Hz)**.
2. The frequency of the digital low-pass filter corresponds to the magnitude as follows.



3. Input the signal for testing:  
The load cell signal plus 50Hz sinusoidal noise is shown in the blue waveform below. After it passes through the low-pass filter (LPF), a red waveform is output and it can be seen that the 50Hz sinusoidal wave is significantly attenuated



## 6.16 Floating-point Number Instructions

### 6.16.1 List of Floating-point Number Instructions

The following table lists the Module instructions covered in this section.

API	Instruction code		Pulse instruction	Function
	16-bit	32-bit		
<b><u>1500</u></b>	–	FSIN	✓	Sine of a floating-point number
<b><u>1501</u></b>	–	FCOS	✓	Cosine of a floating-point number
<b><u>1502</u></b>	–	FTAN	✓	Tangent of a floating-point number
<b><u>1503</u></b>	–	FASIN	✓	Arcsine of a floating-point number
<b><u>1504</u></b>	–	FACOS	✓	Arccosine of a floating-point number
<b><u>1505</u></b>	–	FATAN	✓	Arctangent of a floating-point number
<b><u>1506</u></b>	–	FSINH	✓	Hyperbolic sine of a floating-point number
<b><u>1507</u></b>	–	FCOSH	✓	Hyperbolic cosine of a floating-point number
<b><u>1508</u></b>	–	FTANH	✓	Hyperbolic tangent of a floating-point number
<b><u>1509</u></b>	–	FRAD	✓	Converting degrees to radians
<b><u>1510</u></b>	–	FDEG	✓	Converting radians to the degrees
<b><u>1511</u></b>	SQR	DSQR	✓	Square root of a binary number
<b><u>1512</u></b>	–	FSQR	✓	Square root of a floating-point number
<b><u>1513</u></b>	–	FEXP	✓	Exponentiation of a floating-point number
<b><u>1514</u></b>	–	FLOG	✓	Logarithm of a floating-point number
<b><u>1515</u></b>	–	FLN	✓	Natural logarithm of a binary floating-point number
<b><u>1516</u></b>	–	FPOW	✓	Power of a floating-point number
<b><u>1517</u></b>	RAND	–	✓	Generating a random number

### 6.16.2 Explanation of Floating-point Number Instructions


API	Instruction code			Operand							Function						
1500		FSIN	P	<b>S, D</b>							Sine of a floating-point number						

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
<b>S</b>	●	●			●	●	●	●	●		○					○
<b>D</b>		●			●	●	●	●			○					

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
<b>S</b>									●				
<b>D</b>									●				

Pulse instruction	16-bit instruction	32-bit instruction
AS	-	AS


**Symbol**



**S** : Source value  
**D** : Sine value



**Explanation**

- This instruction finds the sine of the value in **S** and stores it in **D**. The state of SM695 determines whether the source value in **S** is in radians or degrees.
- If SM695 is OFF, the source value is **S** in radians  
 $\text{Radian} = \text{Degree} \times \pi / 180$ .
- If SM695 is ON, the source value in **S** is in degrees.  
 $\text{Degree} = \text{Radian} \times 180 / \pi$ . ( $0^\circ \leq \text{Degree} \leq 360^\circ$ )
- If the conversion result is zero, SM600 is ON.
- The following graph shows the relation between radian and sine values.



**Example**

When X0.0 is ON, the BIN instruction converts the binary-coded decimal value in X1.15–X1.0 into the binary value, and stores the conversion result in D0. The FLT instruction converts the binary value in D0 into a floating-point number, and stores the conversion result in (D11, D10). The FRAD instruction converts a floating-point number in (D11, D10) into radians, and stores the conversion result in (D21, D20). The FSIN instruction finds the sine of the radian value in (D21, D20), and stores it in (D31, D30). The sine value is a floating-point number.



**Additional remarks**

1. If the value in **S** exceeds the range of values that can be represented by floating-point numbers, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2013.
2. If SM695 is ON, and the value in S is not between 0–360, the instruction is not executed, SM0 is ON, and the error code is 16#2003.


API	Instruction code			Operand							Function					
1501		FCOS	P	S, D							Cosine of a floating-point number					

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
S	●	●			●	●	●	●	●		○					○
D		●			●	●	●	●			○					

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
S									●				
D									●				

Pulse instruction	16-bit instruction	32-bit instruction
AS	-	AS

**Symbol**




**S** : Source value

**D** : Cosine value



**Explanation**

- This instruction finds the cosine of the value in **S** and stores it in **D**. The state of SM695 determines whether the source value in **S** is in radians or degrees.
- If SM695 is OFF, the source value in **S** is in radians.  
 $\text{Radian} = \text{Degree} \times \pi / 180$ .
- If SM695 is ON, the source value in **S** is in degrees.  
 $\text{Degree} = \text{Radian} \times 180 / \pi$ . ( $0^\circ \leq \text{Degree} \leq 360^\circ$ )
- If the conversion result is zero, SM600 is ON.
- The following graph shows the relation between radians and cosine values.



**Example**

When X0.0 is ON, the BIN instruction converts the binary-coded decimal value in X1.15–X1.0 into the binary value, and stores the conversion result in D0. The FLT instruction converts the binary value in D0 into a floating-point number, and stores the conversion result in (D11, D10). The FRAD instruction converts a floating-point number in (D11, D10) into radians, and stores the conversion result in (D21, D20). The FCOS instruction finds the cosine of the radian value in (D21, D20) and stores it in (D31, D30). The cosine value is a floating-point number.



**Additional remarks**

1. If the value in **S** exceeds the range of values that can be represented by floating-point numbers, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2013.
2. If SM695 is ON, and the value in **S** is not between 1–360, the instruction is not executed, SM0 is ON, and the error code is 16#2003.


API	Instruction code			Operand						Function					
1502		FTAN	P	<b>S, D</b>						Tangent of a floating-point number					

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
<b>S</b>	●	●			●	●	●	●	●		○					○
<b>D</b>		●			●	●	●	●			○					

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
<b>S</b>									●				
<b>D</b>									●				

Pulse instruction	16-bit instruction	32-bit instruction
AS	-	AS

### Symbol



**S** : Source value


**D** : Tangent value

### Explanation

- This instruction finds the tangent of the value in **S** and stores it in **D**. The state of SM695 determines whether the source value in **S** is in radians or in degrees.
- If SM695 is OFF, the source value in **S** is in radians.  

$$\text{Radian} = \text{Degree} \times \pi / 180.$$
- If SM695 is ON, the source value in **S** is in degrees.  



$$\text{Degree} = \text{Radian} \times 180 / \pi. (0^\circ \leq \text{Degree} \leq 360^\circ)$$
- If the conversion result is zero, SM600 is ON.
- The following graph shows the relation between radians and tangent values.



**Example**

When X0.0 is ON, the BIN instruction converts the binary-coded decimal value in X1.15–X1.0 into the binary value, and stores the conversion result in D0. The FLT instruction converts the binary value in D0 into the floating-point number, and stores the conversion result in (D11, D10). The FRAD instruction converts the floating-point number in (D11, D10) into radians, and stores the conversion result in (D21, D20). The FTAN instruction finds the tangent of the radian value in (D21, D20) and stores it in (D31, D30). The tangent value is a floating-point number.

6



**Additional remarks**

1. If the value in **S** exceeds the range of values that can be represented by floating-point numbers, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2013.
2. If SM695 is ON, and the value in S is not between 0–360, the instruction is not executed, SM0 is ON, and the error code is 16#2003.


API	Instruction code			Operand							Function				
1503		FASIN	P	S, D							Arcsine of a floating-point number				

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
S	●	●			●	●	●	●	●		○					○
D		●			●	●	●	●			○					

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
S									●				
D									●				

Pulse instruction	16-bit instruction	32-bit instruction
AS	-	AS

Symbol



S : Source value


D : Arcsine value

6

Explanation

- This instruction finds the arcsine of the value in S and stores it in D. Arcsine value=sin<sup>-1</sup>



The following graph shows the relation between sine and arcsine values.



- If the conversion result is zero, SM600 is ON.

**Example**

When X0.0 is ON, the instruction finds the arcsine of the floating-point number in (D1, D0) and stores it in (D11, D10). The FDEG instruction converts the arcsine value in (D11, D10) into degrees, and stores the conversion result in (D21, D20). The DINT instruction converts the degree value in (D21, D20) into the integer, and stores the conversion result in (D31, D30). The BCD instruction converts the integer in (D31, D30) into the binary-coded decimal value, and stores the conversion result in Y0.15–Y0.0.

**Additional remarks**

1. The floating-point number specified by the operand **S** must be between  $-1.0$  to  $1.0$ . If the floating-point number is not in that range, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2003.
2. If the value in **S** exceeds the range of values that can be represented by floating-point numbers, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2013.


API	Instruction code			Operand							Function				
1504		FACOS	P	S, D							Arccosine of a floating-point number				

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
S	●	●			●	●	●	●	●		○					○
D		●			●	●	●	●			○					

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
S									●				
D									●				

Pulse instruction	16-bit instruction	32-bit instruction
AS	-	AS

**Symbol**




**S** : Source value  
**D** : Arccosine value

**Explanation**

- This instruction finds the arccosine of the value in **S** and stores it in **D**. Arccosine value= $\cos^{-1}$



The following graph shows the relation between cosine and arccosine values.



- If the absolute value of the conversion result is larger than the value that can be represented by the maximum floating-point number, SM602 is ON.
- If the absolute value of the conversion result is less than the value that can be represented by the minimum floating-point number, SM601 is ON.
- If the conversion result is zero, SM600 is ON.

**Example**

When X0.0 is ON, the FACOS instruction finds the arccosine of the floating-point number in (D1, D0) and stores it in (D11, D10). The FDEG instruction converts the arccosine value in (D11, D10) into degrees, and stores the conversion result in (D21, D20). The DINT instruction converts the degrees value in (D21, D20) into an integer, and stores the conversion result in (D31, D30). The BCD instruction converts the integer in (D31, D30) into a binary-coded decimal value, and stores the conversion result in Y0.15–Y0.0.

**Additional remarks**

1. The floating-point number specified by the operand **S** must be between  $-1.0$  to  $1.0$ . If the floating-point number is not in the range, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2003.
2. If the value in **S** exceeds the range of values that can be represented by floating-point numbers, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2013.


API	Instruction code			Operand							Function				
1505		FATAN	P	S, D							Arctangent of a floating-point number				

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
S	●	●			●	●	●	●	●		○					○
D		●			●	●	●	●			○					

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
S									●				
D									●				

Pulse instruction	16-bit instruction	32-bit instruction
AS	-	AS

**Symbol**




**S** : Source value

**D** : Arctangent value

**Explanation**



1. This instruction finds the arctangent of the value in **S** and stores it in **D**. Arctangent value= $\tan^{-1}$
2. The following graph shows the relation between tangent and arctangent values.



3. If the conversion result is zero, SM600 is ON.

**Example**

When X0.0 is ON, the FATAN instruction finds the arctangent of the floating-point number in (D1, D0) and stores it in (D11, D10). The FDEG instruction converts the arctangent value in (D11, D10) is converted into degrees, and stores the conversion result in (D21, D20). The DINT instruction converts the degree in (D21, D20) into the integer, and stores the conversion result in (D31, D30). The BCD instruction converts the integer in (D31, D30) into the binary-coded decimal value, and stores the conversion result in Y0.15–Y0.0.

**Additional remarks**

If the value in **S** exceeds the range of values that can be represented by floating-point numbers, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2013.


API	Instruction code			Operand							Function					
1506		FSINH	P	S, D							Hyperbolic sine of a floating-point number					

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
S	●	●			●	●	●	●	●		○					○
D		●			●	●	●	●			○					

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
S									●				
D									●				

Pulse instruction	16-bit instruction	32-bit instruction
AS	-	AS

**Symbol**



**S :**


**D :**


**Explanation**

1. This instruction finds the hyperbolic sine of the value in **S** and stores it in **D**. Hyperbolic sine value= $(e^s - e^{-s})/2$ .
2. If the absolute value of the conversion result is larger than the value that can be represented by floating-point numbers, the value in **D** is 16#7F800000, and SM602 is ON.
3. If the absolute value of the conversion result is less than the value that can be represented by floating-point numbers, the value in **D** is 16#FF800000, and SM601 is ON.
4. If the conversion result is zero, SM600 is ON.

**Example**

1. When X0.0 is ON, the instruction finds the hyperbolic sine of the floating-point number in (D1, D0) and stores it in (D11, D10). The hyperbolic sine value in (D11, D10) is a floating-point number.





2. If the absolute value of the conversion result is larger than the value that can be represented by floating-point numbers, SM602 is ON.
3. If the absolute value of the conversion result is less than the value that can be represented by floating-point numbers, SM601 is ON.
4. If the conversion result is zero, SM600 is ON.

#### Additional remarks

If the value in **S** exceeds the range of values that can be represented by floating-point numbers, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2013.


API	Instruction code			Operand							Function			
1507		FCOSH	P	S, D							Hyperbolic cosine of a floating-point number			

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
S	●	●			●	●	●	●	●		○					○
D		●			●	●	●	●			○					

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
S									●				
D									●				

Pulse instruction	16-bit instruction	32-bit instruction
AS	-	AS

Symbol



S : Source value


D : Hyperbolic cosine value


Explanation

1. This instruction finds the hyperbolic cosine of the value in **S** and stores it in **D**. Hyperbolic cosine value= $(e^s+e^{-s})/2$ .
2. If the absolute value of the conversion result is larger than the value that can be represented by floating-point numbers, the value in **D** is 16#7F800000, and SM602 is ON.
3. If the absolute value of the conversion result is less than the value that can be represented by floating-point numbers, the value in **D** is 16#FF800000, and SM601 is ON.
4. If the conversion result is zero, SM600 is ON.

Example

1. When X0.0 is ON, the instruction finds the hyperbolic cosine of the floating-point number in (D1, D0) and stores it in (D11, D10). The hyperbolic cosine value in (D11, D10) is a floating-point number.





2. If the absolute value of the conversion result is larger than the value that can be represented by floating-point numbers, SM602 is ON.
3. If the absolute value of the conversion result is less than the value that can be represented by floating-point numbers, SM601 is ON.
4. If the conversion result is zero, SM600 is ON.

#### Additional remarks

If the value in **S** exceeds the range of values that can be represented by floating-point numbers, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2013.


API	Instruction code			Operand							Function				
1508		FTANH	P	S, D							Hyperbolic tangent of a floating-point number				

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
S	●	●			●	●	●	●	●		○					○
D		●			●	●	●	●			○					

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
S									●				
D									●				

Pulse instruction	16-bit instruction	32-bit instruction
AS	-	AS

**Symbol**




**S** : Source value  
**D** : Hyperbolic tangent value

**Explanation**

- This instruction finds the hyperbolic tangent of the value in **S** and stores it in **D**.  
 Hyperbolic tangent value =  $(e^s - e^{-s}) / (e^s + e^{-s})$ .
- If the conversion result is 0, SM600 is ON.

**Example**

- When X0.0 is ON, the instruction finds the hyperbolic tangent of the floating-point number in (D1, D0) and stores it in (D11, D10). The hyperbolic tangent value in (D11, D10) is a floating-point number.



- If the conversion result is zero, SM600 is ON.

**Additional remarks**

If the value in **S** exceeds the range of values that can be represented by floating-point numbers, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2013.


API	Instruction code			Operand							Function				
1509		FRAD	P	S, D							Converting degrees to radians				

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
S	●	●			●	●	●	●	●		○					○
D		●			●	●	●	●			○					

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
S									●				
D									●				

Pulse instruction	16-bit instruction	32-bit instruction
AS	-	AS

**Symbol**




**S** : Source value (in degrees)  
**D** : Conversion result (in radians)

**Explanation**

1. This instruction converts the degrees value in **S** into radians, and stores it in **D**.
2.  $\text{Radian} = \text{Degree} \times (\pi/180)$ .
3. If the conversion result is zero, SM600 is ON.

**Example**

When X0.0 is ON, the instruction converts the degree value in (D1, D0) to the radians value, and stores the conversion result in (D11, D10). The radian in (D11, D10) is a floating-point number.



**Additional remarks**

If the value in **S** exceeds the range of values that can be represented by floating-point numbers, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2013.


API	Instruction code			Operand							Function			
1510		FDEG	P	S, D							Converting radians to degrees			

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
S	●	●			●	●	●	●	●		○					○
D		●			●	●	●	●			○					

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
S									●				
D									●				

Pulse instruction	16-bit instruction	32-bit instruction
AS	-	AS

**Symbol**




**S** : Source value (in radians)  
**D** : Conversion result (in degrees)


**Explanation**

1. This instruction converts the radians value in **S** to degrees, and stores it in **D**.
2. Degree = Radian × (180/π).
3. If the absolute value of the conversion result is larger than the value that can be represented by floating-point numbers, the value in **D** is 16#7F7FFFFFFF.
4. If the absolute value of the conversion result is less than the value that can be represented by floating-point numbers, the value in **D** is 16#7F7FFFFFFF.
5. If the conversion result is zero, SM600 is ON.

**Example**

When X0.0 is ON, the instruction converts the radians values in (D1, D0) to the degree value, and stores the conversion result in (D11, D10). The degree in (D11, D10) is a floating-point number.



**Additional remarks**

If the value in **S** exceeds the range of values that can be represented by floating-point numbers, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2013.

API	Instruction code			Operand							Function					
1511	D	SQR	P	S, D							Square root of a binary number					

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
S	●	●			●	●	●	●	●		○	○	○	○		
D		●			●	●	●	●			○	○				

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
S		●	●			●	●				●	●	
		●	●			●	●				●	●	

Pulse instruction	16-bit instruction	32-bit instruction
AS	AS	AS

**Symbol**




**S** : Source value  
**D** : Device where the result is stored

**Explanation**

1. This instruction calculates the square root of the value in **S**, and stores the result in the device specified by **D**.
2. The operation result stored in **D** is an integer. If a floating-point number is rounded down to the nearest whole digit, SM601 is ON.
3. If the operation result stored in **D** is 0, SM600 is ON.
4. Only the 32-bit instructions can use the 32-bit counter, but not the device E.

**Example**

When X0.0 is ON, the instruction calculates the square root of the value in D0, and stores the result in D10.



**Additional remarks**

The value in **S** only can be a positive value. If the value in **S** is a negative value, an operation error occurs, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2003.


API	Instruction code			Operand							Function				
1512		FSQR	P	S, D							Square root of a floating-point number				

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
S	●	●			●	●	●	●	●		○					○
D		●			●	●	●	●			○					

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
S									●				
D									●				

Pulse instruction	16-bit instruction	32-bit instruction
AS	-	AS

**Symbol**




**S** : Source value  
**D** : Device where the result is stored

**Explanation**

- This instruction calculates the square root of the floating-point number in **S**, and stores the result in the device specified by **D**.
- If the operation result stored in **D** is 0, SM600 is ON.

**Example 1**

When X0.0 is ON, the instruction calculates the square root of the floating-point number in (D1, D0), and stores the result in (D11, D10).



**Additional remarks**

The value in **S** only can be a positive value. If the value in **S** is a negative value, an operation error occurs, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2003.


API	Instruction code			Operand							Function					
1513		FEXP	P	<b>S, D</b>							Exponentiation of a floating-point number					

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
<b>S</b>	●	●			●	●	●	●	●		○					○
<b>D</b>		●			●	●	●	●			○					

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
<b>S</b>									●				
<b>D</b>									●				

Pulse instruction	16-bit instruction	32-bit instruction
AS	-	AS

### Symbol



**S** : Source value (exponent)


**D** : Device where the operation result is stored

### Explanation

- This function calculates the value of the number  $e$  raised to the power in **S**. Exponentiation involves two numbers, the base  $e$  which represents 2.71828, and the exponent in **S**.
- $EXP[D+1, D]=[S+1, S]$ .
- The number in **S** can be a positive number or a negative number. The device specified by **D** should be a 32-bit register, and the number in the device specified by **S** should be a floating-point number.
- The value in the register specified by **D** is  $e^S$  ( $e$  is 2.71828, and **S** represents the source value).
- If the absolute value of the conversion result is larger than the value that can be represented by floating-point numbers, the value in the register specified by **D** is 16#7F800000, and SM602 is ON.
- If the operation result stored in **D** is 0, SM600 is ON.

### Example

- When X0.0 is ON, the DFLT instruction converts the value in (D1, D0) into a floating-point number, and stores the conversion result in (D11, D10).
- When X0.1 is ON, the FEXP instruction performs the exponentiation with the value in (D11, D10), and stores the floating-point number result in (D21, D20).




API	Instruction code			Operand						Function					
1514		FLOG	P	<b>S<sub>1</sub>, S<sub>2</sub>, D</b>						Logarithm of a floating-point number					

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
<b>S<sub>1</sub></b>	●	●			●	●	●	●	●		○					○
<b>S<sub>2</sub></b>	●	●			●	●	●	●	●		○					○
<b>D</b>		●			●	●	●	●			○					

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
<b>S<sub>1</sub></b>									●				
<b>S<sub>2</sub></b>									●				
<b>D</b>									●				

Pulse instruction	16-bit instruction	32-bit instruction
AS	-	AS

**Symbol**



- S<sub>1</sub>** : Base for the logarithm
- S<sub>2</sub>** : Source value
- D** : Device where the operation result is stored


**Explanation**

1. This instruction calculates the logarithm of the value in **S<sub>2</sub>** with respect to the value in **S<sub>1</sub>**, and stores the single-precision floating-point operation result in **D**.
2. The values in **S<sub>1</sub>** and **S<sub>2</sub>** only can be positive values.
3.  $S_1^D = S_2 \rightarrow D = \text{Log}_{S_1} S_2$
4. Example: suppose the values in **S<sub>1</sub>** and **S<sub>2</sub>** are 5 and 125 respectively. Find  $\log_5 125$  (log base 5 of the number 125).
5.  $S_1^D = S_2 \rightarrow 5^D = 125 \rightarrow D = \log_5 125 = 3$ .
6. If the operation result stored in **D** is 0, SM600 is ON.

**Example**

1. When X0.0 is ON, the DFLT instruction converts the values in (D1, D0) and (D3, D2) into the floating-point numbers, and stores the conversion results in (D11, D10) and (D13, D12) respectively.
2. When X0.1 is ON, the FLOG instruction calculates the logarithm of the floating-point number in (D13, D12) with

respect to the floating-point number in (D11, D10), and stores the operation result in (D21, D20).



**Additional remarks**

If the value in **S<sub>1</sub>** is less than or equal to 1, or if the value in **S<sub>2</sub>** is less or equal to 0, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2003.


API	Instruction code			Operand							Function					
1515		FLN	P	<b>S, D</b>							Natural logarithm of a binary floating-point number					

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
<b>S</b>	●	●			●	●	●	●	●		○					○
<b>D</b>		●			●	●	●	●			○					

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
<b>S</b>									●				
<b>D</b>									●				

Pulse instruction	16-bit instruction	32-bit instruction
AS	-	AS

**Symbol**




**S** : Source value  
**D** : Device where the operation result is stored

**Explanation**

1. This instruction calculates the natural logarithm of the operand **S** in a single-precision floating-point operation.
2. The value in **S** only can be a positive value.
3.  $e^D = S \rightarrow$  The value in **D** =  $\ln S$ .
4. If the operation result stored in **D** is 0, SM600 is ON.

**Example**

1. When X0.0 is ON, the DFLT instruction converts the value in (D1, D0) into the floating-point number, and stores the conversion result in (D11, D10).
2. When X0.1 is ON, the FLN instruction calculates the natural logarithm of the floating-point number in (D11, D10), and stores the operation result in (D21, D20).



**Additional remarks**

If the value in S is less than or equal to 0, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2003.

API	Instruction code			Operand						Function					
1516		FPOW	P	<b>S<sub>1</sub>, S<sub>2</sub>, D</b>						Power of a floating-point number					

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
<b>S<sub>1</sub></b>	●	●			●	●	●	●	●							○
<b>S<sub>2</sub></b>	●	●			●	●	●	●	●							○
<b>D</b>		●			●	●	●	●								

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
<b>S<sub>1</sub></b>									●				
<b>S<sub>2</sub></b>									●				
<b>D</b>									●				

Pulse instruction	16-bit instruction	32-bit instruction
AS	-	AS

### Symbol

FPOW		FPOWP	
En		En	
S <sub>1</sub>	D	S <sub>1</sub>	D
S <sub>2</sub>		S <sub>2</sub>	

**S<sub>1</sub>** : Source value

**S<sub>2</sub>** : Exponent value


**D** : Device where the operation result is stored

### Explanation

- This instruction raises the single-precision floating-point number in **S<sub>1</sub>** to the power of the value in **S<sub>2</sub>**, and stores the single-precision floating-point operation result in **D**.
- $D = \text{POW}[S_{1+1} \cdot S_1]^{[S_{2+1} \cdot S_2]}$
- For PLC with firmware V1.10.00 or previous versions, the value in **S<sub>1</sub>** only can be a positive number, but the value in **S<sub>2</sub>** can be either a positive or a negative number.
- For PLC with firmware V1.10.10 or later versions, if the value in **S<sub>1</sub>** is a positive number, the value in **S<sub>2</sub>** can be either a positive or a negative number. If the value in **S<sub>1</sub>** is a negative number, the value in **S<sub>2</sub>** should be an integer number either positive or negative.
- Suppose the values in **S<sub>1</sub>** and **S<sub>2</sub>** are 5 and 3 respectively:  $D = 5^3 = 125$ .
- If the absolute value of the operation result is larger than the value that can be represented by floating-point numbers, the value in **D** is 16#7F7FFFFF, and SM602 is ON.
- If the absolute value of the operation result is less than the value that can be represented by floating-point numbers, the value in **D** is 16#FF800000, and SM601 is ON.
- If the operation result stored in **D** is 0, SM600 is ON.

**Example**

1. When X0.0 is ON, the DFLT instruction converts the values in (D1, D0) and (D3, D2) into floating-point numbers, and stores the conversion results in (D11, D10) and (D13, D12) respectively.
2. When X0.1 is ON, the FPOW instruction raises the floating-point number in (D11, D10) to the power of the floating-point number in (D13, D12), and stores the operation result in (D21, D20).
3. When X0.2 is ON, the FBCD instruction converts the binary floating-point number in (D21, D20) into the binary-coded decimal floating-point number, and stores the conversion result in (D31, D30).

**Additional remarks**

1. For PLC with firmware V1.10.00 or previous versions, if the value in **S<sub>1</sub>** is less than 0, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2003.
2. For PLC with firmware V1.10.10 or later versions, if the value in **S<sub>1</sub>** is less than 0, and the value in **S<sub>2</sub>** is NOT an integer number, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2003.
3. If the value in **S<sub>1</sub>** is 0, and the value in **S<sub>2</sub>** is less than or equals to 0, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2003.


API	Instruction code			Operand						Function					
1517		RAND	P	<b>S<sub>1</sub>, S<sub>2</sub>, D</b>						Generating a random number					

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
S <sub>1</sub>	●	●			●	●		●	●		○	○	○	○		
S <sub>2</sub>	●	●			●	●		●	●		○	○	○	○		
D		●			●	●		●			○	○				

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
S <sub>1</sub>		●				●							
S <sub>2</sub>		●				●							
D		●				●							

Pulse instruction	16-bit instruction	32-bit instruction
AS	AS	-

**Symbol**




- S<sub>1</sub>** : Minimum value
- S<sub>2</sub>** : Maximum value
- D** : Device where the result is stored

**Explanation**

1. This instruction generates a random number between the minimum value in **S<sub>1</sub>** and the maximum value in **S<sub>2</sub>**, and then stores the result in **D**.
2. If the value in **S<sub>1</sub>** is larger than the value in **S<sub>2</sub>**, the instruction takes the values in **S<sub>1</sub>** and **S<sub>2</sub>** as the maximum value and the minimum value respectively.

**Example**

When X0.0 is ON, the instruction generates a random number between the minimum value in D0 and the maximum value in D10, and stores the result in D20.



**Additional remarks**

The values in **S<sub>1</sub>** and **S<sub>2</sub>** must be between 0–32767. If the value in **S<sub>1</sub>** or **S<sub>2</sub>** exceeds the range, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2003.

## 6.17 Real-time Clock Instructions

### 6.17.1 List of Real-time Clock Instructions

The following table lists the Real-time Clock instructions covered in this section.

API	Instruction code		Pulse instruction	Function
	16-bit	32-bit		
<b><u>1600</u></b>	TRD	–	✓	Reading the time
<b><u>1601</u></b>	TWR	–	✓	Writing the time
<b><u>1602</u></b>	T+	–	✓	Adding the time
<b><u>1603</u></b>	T-	–	✓	Subtracting the time
<b><u>1604</u></b>	HOUR	–	–	Running-time meter
<b><u>1605</u></b>	TCMP	–	✓	Comparing the time
<b><u>1606</u></b>	TZCP	–	✓	Time zone comparison
<b><u>1607</u></b>	DST	–	✓	Daylight saving time
<b><u>1608</u></b>	WWON	–	–	Setting up weekly working time setup

### 6.17.2 Explanation of Real-time Clock Instructions

API	Instruction code			Operand								Function			
1600		TRD	P	D								Reading the time			

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
D					●	●		●								

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
D		●				●							

Pulse instruction	16-bit instruction	32-bit instruction
AS	AS	-

**Symbol**




**D** : Device where the result is stored

**Explanation**

1. This instruction reads the current time from the built-in real time clock in the CPU module, and stores the current time in **D**.
2. The operand **D** occupies seven consecutive devices.
3. The built-in real-time clock provides the year, the week, the moth, the day, the minute, and the second. The data is stored in SR391–SR397.
4. The last two digits of the year number for A.D. are stored in SR391.

**Example**

When M0 is ON, the instruction reads the current time from the real-time clock into D0–D6. The value 1 in SR397 represents Monday, the value 2 represents Tuesday, and this continues to the value 7 represents Sunday.



Special data register	Item	Value		General data register	Item
SR391	Year (A.D.)	00-99	→	D0	Year (A.D.)
SR392	Month	1-12	→	D1	Month
SR393	Day	1-31	→	D2	Day
SR394	Hour	0-23	→	D3	Hour
SR395	Minute	0-59	→	D4	Minute
SR396	Second	0-59	→	D5	Second
SR397	Week	1-7	→	D6	Week

#### Additional remarks

1. If **D+6** exceeds the device range, the instruction is not executed, **SM0** is **ON**, and the error code in **SR0** is **16#2003**.
2. When **SM220** is **ON**, the real-time clock is calibrated within  $\pm 30$  seconds. If the value of the seconds read from the real-time clock is between **0–29**, the instruction clears the seconds value to zero. If the value of the seconds read from the real-time clock is between **30–59**, the instruction increments the value of the minute by one, and clears the seconds value to zero.


API	Instruction code			Operand							Function						
1601		TWR	P	<b>S</b>							Writing the time						

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	“\$”	F
<b>S</b>					●	●		●	●							

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
<b>S</b>		●				●							

Pulse instruction	16-bit instruction	32-bit instruction
AS	AS	-

**Symbol**



**S** : Data source


**Explanation**

1. This instruction adjusts the built-in real-time clock in the CPU module by writing the correct current time in **S** into the built-in real-time clock.
2. The operand **S** occupies seven consecutive devices. (Use 24 hour time format)
3. The instruction instantly writes the new setting time into the real-time clock in the PLC.
4. Make sure that when the instruction executes, the new setting time in **S** is consistent with the actual time.
5. It is suggested to use it as a pulse instruction. If the contact is normally open, the instruction is executed to write the time constantly. But the PLC only writes the time at the first scan. If the built-in real-time clock needs to be updated, you can close the contact for a scan time and then execute this instruction again to update the clock.

**Example**

When M0 is ON, the instruction writes the correct current time into the built-in real-time clock in the PLC.





**Additional remarks**

1. If the value in **S** exceeds the range, an operation error occurs, the instruction is not executed, SM is ON, and the error code in SR is 16#2003.
2. If **S+6** exceeds the device range, an operation error occurs, the instruction is not executed, SM is ON, and the error code in SR is 16#2003.
3. If you declare the operand **S** in ISPSOft, the data type is ARRAY [7] of WORD/INT.


API	Instruction code			Operand			Function			
1602		T+	P	S <sub>1</sub> , S <sub>2</sub> , D			Adding the time			

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
S <sub>1</sub>					●	●		●	●		○					
S <sub>2</sub>					●	●		●	●		○					
D					●	●		●								

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
S <sub>1</sub>		●				●							
S <sub>2</sub>		●				●							
D		●				●							

Pulse instruction	16-bit instruction	32-bit instruction
AS	AS	-

**Symbol**




- S<sub>1</sub> : Source device 1
- S<sub>2</sub> : Source device 2
- D : Device where the result is stored

**Explanation**

1. This instruction adds the value of the hour, the minute, and the second in the real-time clock specified by S<sub>2</sub> to the value of the hour, the minute, and the second in the real-time clock specified by S<sub>1</sub>, and then stores the sum in the register specified by D.
2. The operands S<sub>1</sub>, S<sub>2</sub>, and D each occupy three consecutive devices.
3. If the sum is larger than or equal to 24 hours, SM602 is ON, and the instruction subtracts 24 hours from the sum before storing the result in D.
4. If the sum is zero (zero hour zero minute zero second), SM600 is ON.

**Example**

When M0 is ON, the instruction adds the value of the hour, the minute, and the second in D10–D12 to the value of the hour, the minute, and the second in D0–D2, and stores the sum in D20–D22.



**Additional remarks**

1. If the value in **S<sub>1</sub>** or **S<sub>2</sub>** exceeds the range, an operation error occurs, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2003.
2. If **S<sub>1</sub>+2**, **S<sub>2</sub>+2**, or **D+2** exceeds the device range, an operation error occurs, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2003.
3. If you declare the operand **S<sub>1</sub>** in ISPSOft, the data type is ARRAY [3] of WORD/INT.
4. If you declare the operand **S<sub>2</sub>** in ISPSOft, the data type is ARRAY [3] of WORD/IN.
5. If you declare the operand **D** in ISPSOft, the data type is ARRAY [3] of WORD/INT.


API	Instruction code			Operand				Function			
1603		T-	P	<b>S<sub>1</sub>, S<sub>2</sub>, D</b>				Subtracting the time			

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
<b>S<sub>1</sub></b>					●	●		●	●		○					
<b>S<sub>2</sub></b>					●	●		●	●		○					
<b>D</b>					●	●		●								

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
<b>S<sub>1</sub></b>		●				●							
<b>S<sub>2</sub></b>		●				●							
<b>D</b>		●				●							

Pulse instruction	16-bit instruction	32-bit instruction
AS	AS	-

**Symbol**



- S<sub>1</sub>** : Source device 1
- S<sub>2</sub>** : Source device 2
- D** : Device where the result is stored

**Explanation**

- This instruction subtracts the value of the hour, the minute, and the second in the real-time clock specified by **S<sub>2</sub>** from the value of the hour, the minute, and the second in the real-time clock specified by **S<sub>1</sub>**, and stores the difference in the register specified by **D**.
- The operands **S<sub>1</sub>**, **S<sub>2</sub>**, and **D** all occupy three consecutive devices.
- If the difference is a negative, SM601 is ON, and the instruction adds 24 hours to the difference and then stores the result in **D**.
- If the difference is zero (zero hour zero minute zero second), SM600 is ON.



**Example**

- When M0 is ON, the instruction subtracts the value of the hour, the minute, and the second in D10–D12 from the value of the hour, the minute, and the second in D0–D2, and stores the difference in D20–D22.

D0 20 (Hour)		D10 14 (Hour)	-	D20 5 (Hour)
D1 20 (Minute)		D11 30 (Minute)		D21 49 (Minute)
D2 5 (Second)		D12 8 (Second)		D22 57 (Second)

20 hour 20 minute 50 second    14 hour 30 minute 8 second    5 hour 49 minute 57 second

2. If the difference is a negative, SM601 is ON.



**Additional remarks**

1. If the value in **S**<sub>1</sub> or **S**<sub>2</sub> exceeds the range, an operation error occurs, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2003.
2. If **S**<sub>1</sub>+2, **S**<sub>2</sub>+2, or **D**+2 exceeds the device range, an operation error occurs, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2003.
3. If you declare the operand **S**<sub>1</sub> in ISPSOft, the data type is ARRAY [3] of WORD/INT.
4. If you declare the operand **S**<sub>2</sub> in ISPSOft, the data type is ARRAY [3] of WORD/INT.
5. If you declare the operand **D** in ISPSOft, the data type is ARRAY [3] of WORD/INT.


API	Instruction code			Operand						Function					
1604		HOUR		S, D <sub>1</sub> , D <sub>2</sub>						Running-time meter					

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
S					●	●		●	●		○	○	○	○		
D <sub>1</sub>								●								
D <sub>2</sub>		●	●	●				●		○						

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
S		●				●							
D <sub>1</sub>		●				●							
D <sub>2</sub>	●												

Pulse instruction	16-bit instruction	32-bit instruction
-	AS	

**Symbol**



- S** : Time after which the output device is ON
- D<sub>1</sub>** : Current time
- D<sub>2</sub>** : Output device

**Explanation**

1. This instruction switches the output device specified by **D<sub>2</sub>** to ON after the amount of time in **S**.

2. **S**: The time after which the output device is ON (Unit: Hour)

The operand **S** used in the 16-bit instruction must be between 1–32,767.

3. **D<sub>1</sub>**: The current time (Unit: Hour). The value in **D<sub>1</sub>** must be between 0–32,767.

**D<sub>1</sub>+1**: The current time which is less than one hour (Unit: Second). The value in **D<sub>1</sub>+1** should be between 0–3,599.

**D<sub>1</sub>+2** is for system use only. The value in it cannot be altered when the instruction is executed; otherwise, an error occurs.

When the current time is 32,767 hour 3,599 second, the timer stops counting. After the values in **D<sub>1</sub>** and **D<sub>1</sub>+1** are cleared to 0, the timer starts to count again.


4. When the time for which the input contact has been ON reaches the setting time in **S**, the output device is ON. Before that the output device is not ON. This function allows you to manage the running time of the machine and maintenance.

5. After the output device is ON, the timer continues to count.

- When using on-line editing, reset the conditional contact to initialize the instruction.

### Example 1

When X0.0 is ON, the instruction timer starts to count. When the time for which X0.0 has been ON reaches 100 hours, Y0.0 is ON. The current time is recorded in D0, and the current time which is less than one hour is recorded in D1. D2 is for system use. The value in it cannot be altered; otherwise, an error occurs.



### Additional remarks

- When **S** is less than or equal to 0, the instruction is not executed, and the state of the output device is unchanged.
- If the value in **D1** is less than **0**, the state of the output device is unchanged.
- If **D1+2** exceeds the device range, an operation error occurs, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2003.
- If you declare the operand **D1** in ISPSOft, the data type is ARRAY [3] of WORD/INT.

API	Instruction code			Operand							Function						
1605		TCMP	P	<b>S<sub>1</sub>, S<sub>2</sub>, S<sub>3</sub>, S, D</b>							Comparing the time						

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	“\$”	F
<b>S<sub>1</sub></b>	●	●			●	●		●	●		○	○	○	○		
<b>S<sub>2</sub></b>	●	●			●	●		●	●		○	○	○	○		
<b>S<sub>3</sub></b>	●	●			●	●		●	●		○	○	○	○		
<b>S</b>					●	●		●								
<b>D</b>		●	●	●				●		○						

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
<b>S<sub>1</sub></b>		●				●							
<b>S<sub>2</sub></b>		●				●							
<b>S<sub>3</sub></b>		●				●							
<b>S</b>		●				●							
<b>D</b>	●												

Pulse instruction	16-bit instruction	32-bit instruction
AS	AS	-

### Symbol

TCMP		TCMPP	
En		En	
S <sub>1</sub>	D	S <sub>1</sub>	D
S <sub>2</sub>		S <sub>2</sub>	
S <sub>3</sub>		S <sub>3</sub>	
S		S	

- S<sub>1</sub>** : Hour for the setting time  
**S<sub>2</sub>** : Minute for the setting time  
**S<sub>3</sub>** : Second for the setting time  
**S** : Current time  
**D** : Comparison result


### Explanation

- This instruction compares the value of the hour, the minute, and the second specified by **S<sub>1</sub>–S<sub>3</sub>** with the value of the hour, the minute, and the second in the devices starting from the device specified by **S**, and stores the comparison result in **D**.
- The hour of the current time is in the device specified by **S**, and the value of the hour between 0–23. The minute of the current time is in the device specified by **S+1**, and the value of the minute must be between 0–59. The second of the current time is in the device specified by **S+2**, and the value of the second must be between 0–59.
- The operand **D** occupies three consecutive devices. The comparison result is stored in **D**, **D+1**, and **D+2**.
- In general, use the TRD instruction (API 1600) to read the current time from the real-time clock first, and then use the TCMP instruction to compare the time.
- If the setting time in **S<sub>1</sub>–S<sub>3</sub>** is larger than the current time in **S**, **D** is ON, **D+1** is OFF, and **D+2** is OFF.

6. If the setting time in **S<sub>1</sub>-S<sub>3</sub>** is equal to the current time in **S**, **D** is OFF, **D+1** is ON, and **D+2** is OFF.
7. If the setting time in **S<sub>1</sub>-S<sub>3</sub>** is less than the current time in **S**, **D** is OFF, **D+1** is OFF, and **D+2** is ON.

**Example**

1. When X0.0 is ON, the instruction compares the setting time 12 hour 20 minute 45 second with the current time in D20-D22, and stores the comparison result in M10-M12. When X0.0 switches from ON to OFF, the instruction is not executed, and the states of M10, M11, and M12 remain the same as they were before X0.0 switched to ON.
2. If you want to get the comparison result  $\geq$ ,  $\leq$ , or  $\neq$ , you can connect M10-M12 in series or in parallel.



**Additional remarks**

1. If **S+2** exceeds the device range, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2003.
2. If **D+2** exceeds the device range, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2003.
3. If the value in **S** exceeds the range, an operation error occurs, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2003.
4. If the values in **S<sub>1</sub>-S<sub>3</sub>** exceed the range, an operation error occurs, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2003.

5. If you declare the operand **S** in ISPSOft, the data type is ARRAY [3] of WORD.
6. If you declare the operand **D** in ISPSOft, the data type is ARRAY [3] of BOOL.


API	Instruction code			Operand							Function				
1606		TZCP	P	<b>S<sub>1</sub> · S<sub>2</sub> · S · D</b>							Time zone comparison				

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
<b>S<sub>1</sub></b>					●	●		●	●							
<b>S<sub>2</sub></b>					●	●		●	●							
<b>S</b>					●	●		●								
<b>D</b>		●	●	●				●								

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
<b>S<sub>1</sub></b>		●				●							
<b>S<sub>2</sub></b>		●				●							
<b>S</b>		●				●							
<b>D</b>	●												

Pulse instruction	16-bit instruction	32-bit instruction
AS	AS	-

**Symbol**



- S<sub>1</sub>** : Lower limit time
- S<sub>2</sub>** : Upper limit time
- S** : Current time
- D** : Comparison result

**Explanation**


1. This instruction compares the current time specified by **S** with the lower limit time specified by **S<sub>1</sub>**, and with the upper limit time specified by **S<sub>2</sub>**, and stores the comparison result in **D**.
2. The hour of the lower limit time is in the device specified by **S<sub>1</sub>**, the minute of the lower limit time is in the device specified by **S<sub>1</sub>+1**, and the second of the lower limit time is in the device specified by **S<sub>1</sub>+2**.
3. The hour of the upper limit time is in the device specified by **S<sub>2</sub>**, the minute of the upper limit time is in the device specified by **S<sub>2</sub>+1**, and the second of the upper limit time is in the device specified by **S<sub>2</sub>+2**.
4. The hour of the current time is in the device specified by **S**, the minute of the current time is in the device specified by **S+1**, and the second of the current time is in the device specified by **S+2**.
5. The time in the device specified by **S<sub>1</sub>** must be less than the time in the device specified by **S<sub>2</sub>**. If the time in the device specified by **S<sub>1</sub>** is larger than the time in the device specified by **S<sub>2</sub>**, the instruction takes the time in the device specified by **S<sub>1</sub>** as the upper limit time during the execution of the instruction.
6. In general, use the TRD instruction (API 1600) to read the current time from the real-time clock first, and then use

the TZCP instruction to compare the time.

- If the current time in the device specified by **S** is less than the lower limit time in the device specified by **S<sub>1</sub>**, and is less than the upper limit time in the device specified by **S<sub>2</sub>**, **D** is ON. If the current time in the device specified by **S** is larger than the lower limit time in the device specified by **S<sub>1</sub>**, and is larger than the upper limit time in the device specified by **S<sub>2</sub>**, **D+2** is ON; otherwise **D+1** is ON.

### Example

When X0.0 is ON, the TZCP instruction is executed. M10, M11, or M12 is ON. When X0.0 is OFF, the instruction is not executed, the state of M10, the state of M11, and the state of M12 remain the same as before X0.0 switched to ON.



### Additional remarks

- If **S<sub>1</sub>+2**, **S<sub>2</sub>+2**, **S+2**, or **D+2** exceeds the device range, the instruction is not executed, **SM0** is ON, and the error code in **SR0** is 16#2003.
- If the values in **S<sub>1</sub>**, **S<sub>2</sub>**, and **S** exceed the range, an operation error occurs, the instruction is not executed, **SM0** is ON, and the error code in **SR0** is 16#2003.
- If you declare the operand **S<sub>1</sub>** in ISPSOft, the data type is ARRAY [3] of WORD/INT.
- If you declare the operand **S<sub>2</sub>** in ISPSOft, the data type is ARRAY [3] of WORD/INT.
- If you declare the operand **S** in ISPSOft, the data type is ARRAY [3] of WORD/INT.
- If you declare the operand **D** in ISPSOft, the data type is ARRAY [3] of BOOL.

API	Instruction code			Operand							Function				
1607		DST	P	S, S <sub>1</sub> , S <sub>2</sub> , S <sub>3</sub> , S <sub>4</sub> , S <sub>5</sub> , D							Daylight saving time				


Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
S					●	●		●					○	○		
S <sub>1</sub>					●	●		●					○	○		
S <sub>2</sub>					●	●		●					○	○		
S <sub>3</sub>					●	●		●					○	○		
S <sub>4</sub>					●	●		●					○	○		
S <sub>5</sub>					●	●		●					○	○		
D		●	●	●				●								

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
S		●				●							
S <sub>1</sub>		●				●							
S <sub>2</sub>		●				●							
S <sub>3</sub>		●				●							
S <sub>4</sub>		●				●							
S <sub>5</sub>		●				●							
D	●												

Pulse instruction	16-bit instruction	32-bit instruction
AS	AS	-

6

Symbol



- S** : Daylight saving time function codes
- S<sub>1</sub>** : Month of the daylight saving start time
- S<sub>2</sub>** : Date of the daylight saving start time
- S<sub>3</sub>** : Month of the daylight saving end time
- S<sub>4</sub>** : Date of the daylight saving end time
- S<sub>5</sub>** : Change due to daylight saving time (minutes)
- D** : The state of the daylight saving function

**Explanation**

- Operands used in this instruction are described below:

**S**: Daylight saving time function codes

Firmware version before V1.04 (V1.04 excluded) supports the following function codes:

Function codes	Description
0	Disable daylight saving time
1	Enable daylight saving time mode 1
2	Read daylight saving time
3~	Reserved or viewed as reading daylight saving time

Firmware version after V1.04 (V1.04 included) supports the following function codes:

Function codes	Description
0	Disable daylight saving time
1	Enable daylight saving time mode 1
2	Read daylight saving time
3	Enable daylight saving time mode 1
4	Disable daylight saving time (set by the system)
5	Daylight saving time mode 1 enabled (set by the system)
7	Daylight saving time mode 2 enabled (set by the system)
6, 8~	Reserved or viewed as reading daylight saving time

Note 1: When the code in **S** is 4, 5 or 7, the execution of instruction is of no use.

Note 2: Read more for information on the various modes in the following sections.

**S**<sub>1</sub>: setting for the month to start daylight saving time

**S**<sub>2</sub>: setting for the date to start daylight saving time

**S**=1 (daylight saving time mode 1 enabled), **S**<sub>2</sub>: settings for the date to start daylight saving time

**S**=3 (daylight saving time mode 2 enabled), **S**<sub>2</sub>: settings for the week to start daylight saving time, **S**<sub>2</sub>+1: on which weekday of **S**<sub>2</sub>

**S**<sub>3</sub>: setting for the month to end daylight saving time

**S**<sub>4</sub>: settings for the date to end daylight saving time

**S**=1 (daylight saving time mode 1 enabled), **S**<sub>4</sub>: settings for the date to end daylight saving time

**S**=3 (daylight saving time mode 2 enabled), **S**<sub>4</sub>: settings for the week to end daylight saving time, **S**<sub>2+1</sub>: on which weekday of **S**<sub>4</sub>

**S**<sub>5</sub>: settings for the change due to daylight saving time; unit: minute

**D**: stores the state of the daylight saving time; when the value in **D** is OFF, daylight saving time is disabled. When the value in **D** is ON, daylight saving time is enabled.

2. Descriptions on the value in function code S for daylight saving time functions

D.S.T State	S Function Code	Description
Disabled	0	Disabled daylight saving time function
Enabled	1, 3	Enabled daylight saving time function
Read	2	Read the daylight saving time setting

• **Disabled daylight saving time function (refer to example 1 below)**

When the operand **S** is 0, the function of daylight saving time is disabled. When **S** is set to disable the daylight saving time, the values in **S**<sub>1</sub>–**S**<sub>5</sub> are irrelevant and the operand **D** shows the daylight saving time state as OFF.

• **Enabled daylight saving time function (refer to example 2 and 3)**

When the value in **S** is 1 or 3, daylight saving time function is enabled: **S**<sub>1</sub> and **S**<sub>2</sub>: setting for the month to start daylight saving time; **S**<sub>3</sub> and **S**<sub>4</sub>: setting for the month to end daylight saving time; **S**<sub>5</sub>: settings for the change due to daylight saving time; unit: minute; the operand **D** shows the daylight saving time state. When the function of daylight saving time is enabled and the system runs for the first time during the start time (**S**<sub>1</sub>, **S**<sub>2</sub>), the system time adds the value set in **S**<sub>5</sub> once. When the function of daylight saving time is disabled and the system runs for the first time during the end time (**S**<sub>3</sub>, **S**<sub>4</sub>), the system time subtracts the value set in **S**<sub>5</sub> once.

**Modes for daylight saving**

Mode	S Function Code	Rules	Available for
Mode 1	1	By month and date	V1.00 or later
Mode 2	3	By month and week	V1.04 or later

**Mode 1 (S=1): enabled by month and date (refer to example 2)**

Operand	Description
<b>S<sub>1</sub></b>	The month to start daylight saving time Range: 1-12
<b>S<sub>2</sub></b>	The date to start daylight saving time Range: 1-31
<b>S<sub>3</sub></b>	The month to end daylight saving time Range: 1-12
<b>S<sub>4</sub></b>	The date to end daylight saving time Range: 1-31
<b>S<sub>5</sub></b>	Time that changed due to daylight saving time; unit: minute Range: 1-1439 (within 1 day)

Note 1: If this function is enabled, the value in **D** is ON.

Note 2: If the date is set incorrectly, the daylight saving function cannot be enabled. The SM0 is ON, and the error code in SR0 is 16#200B. For example if a non-existed date is set, such as April 31, or the starting date is set smaller than the ending date in a calendar year, for example starting date is October 1 and ending date is April 01.

Note 3: If **S<sub>5</sub>** is set out of range, the daylight saving function cannot be enabled. The SM0 is ON, and the error code in SR0 is 16#200B.

**Mode 2 (S=3): enabled by week and weekday (refer to example 3)**

Operand	Description
<b>S<sub>1</sub></b>	The month to start daylight saving time Range: 1-12
<b>S<sub>2</sub></b> <b>S<sub>2+1</sub></b>	<b>S<sub>2</sub></b> : settings for the week to start daylight saving time; range: 1-4 <b>S<sub>2+1</sub></b> : on which weekday of the <b>S<sub>2</sub></b> ; range: 1-7 (Monday: 1, Tuesday: 2..., Sunday: 7)
<b>S<sub>3</sub></b>	The month to end daylight saving time Range: 1-12
<b>S<sub>4</sub></b> <b>S<sub>4+1</sub></b>	<b>S<sub>4</sub></b> : settings for the week to end daylight saving time; range: 1-4 <b>S<sub>4+1</sub></b> : on which weekday of the <b>S<sub>4</sub></b> ; range: 1-7 (Monday: 1, Tuesday: 2..., Sunday: 7)
<b>S<sub>5</sub></b>	Time that changed due to daylight saving time; unit: minute Range: 1-1439 (within 1 day)

Note 1: If this function is enabled, the value in **D** is ON.

Note 2: The setting range for **S<sub>2</sub>** and **S<sub>4</sub>** is 1— 4 or -1— -4. The value -1 indicates the last week of the month and -2 indicates the last 2<sup>nd</sup> week. If the value in **S<sub>2</sub>** is -2 and **S<sub>2+1</sub>** is 7, it indicates the last 2 Sunday of the month. If the date is set incorrectly, the daylight saving function cannot be enabled. The SM0 is ON, and the error code in SR0 is 16#200B.

Note 3: If the value in **S<sub>2+1</sub>** / **S<sub>4+1</sub>** is out of range, the default setting value is 7, indicating Sunday.

Note 4: If **S<sub>5</sub>** is set out of range, the daylight saving function cannot be enabled. The SM0 is ON, and the error code in SR0 is 16#200B.

Note 5: If the device for operand **S<sub>2</sub>** and **S<sub>4</sub>** is K or 16#, the values are not saved, the SM0 is ON, and the error code in SR0 is 16#2003.

- **Read the daylight saving time function (refer to example 1-3)**

When the operand **S** is 2, the function of daylight saving time is being read. **S<sub>1</sub>** and **S<sub>2</sub>**: setting for the month to start daylight saving time; **S<sub>3</sub>** and **S<sub>4</sub>**: setting for the month to end daylight saving time; **S<sub>5</sub>**: settings for the change due to daylight saving time; unit: minute. When **S** is set to read the state of the daylight saving function and the output state of **D** is ON, the PLC saves the setting values in the operands **S<sub>1</sub>**–**S<sub>5</sub>**. The device is set to **D** while **S** is set to read. If the device is set to K or 16#, the values are not saved, the SM0 is ON, and the error code in SR0 is 16#2003.

Devices with firmware version after V1.04 (V1.04 included) adds 4 to the function codes in **S**, after the daylight saving state is read. For example, after the daylight saving state is read, the function codes 0, 1, 3 become 4, 5 and 7.

When the DST state is OFF, the operand and descriptions are shown below.

Operand	Description
<b>S</b>	Before firmware V1.04 (V1.04 excluded), function code is fixed to 2. After firmware V1.04 (V1.04 included), function code is 4, indicating the DST state is OFF.
<b>S<sub>1</sub>- S<sub>5</sub></b>	Invalid operand
<b>D</b>	DST state is OFF.

When the DST state is ON and in mode 1, the operand and descriptions are shown below.

Operand	Description
<b>S</b>	Before firmware V1.04 (V1.04 excluded), function code is fixed to 2. After firmware V1.04 (V1.04 included), function code is 5, indicating the DST state is ON and in mode 1.
<b>S<sub>1</sub></b>	The month to start daylight saving time
<b>S<sub>2</sub></b>	The date to start daylight saving time
<b>S<sub>3</sub></b>	The month to end daylight saving time
<b>S<sub>4</sub></b>	The date to end daylight saving time
<b>S<sub>5</sub></b>	Time that changed due to daylight saving time; unit: minute

Operand	Description
D	The DST state is ON (enabled).

When the DST state is ON and in mode 2, the operand and descriptions are shown below.


Operand	Description
S	Function code is 7, indicating the DST state is ON and in mode 2.
S <sub>1</sub>	The month to start daylight saving time
S <sub>2</sub>	S <sub>2</sub> : settings for the week to start daylight saving time
S <sub>2+1</sub>	S <sub>2+1</sub> : on which weekday of the S <sub>2</sub>
S <sub>3</sub>	The month to end daylight saving time
S <sub>4</sub>	S <sub>4</sub> : settings for the week to end daylight saving time
S <sub>4+1</sub>	S <sub>4+1</sub> : on which weekday of the S <sub>4</sub>
S <sub>5</sub>	Time that changed due to daylight saving time; unit: minute
Operand	The DST state is ON (enabled).

- This instruction is to enable / disable the daylight saving time function. Whether the contact is normally open or close will not affect the daylight saving time setting. (refer to example 2 for more details on how to switch the contact M0 OFF=>ON) You can reset the daylight saving time by executing the instruction again. There is no need to disable and then enable this function to reset the daylight saving time.
- When setting the daylight saving time to start on April 1<sup>st</sup> and to end on September 1<sup>st</sup>, and the duration is 60 minutes; the real-time clock goes like below.

Daylight saving time function disabled	Daylight saving time function enabled
1 <sup>st</sup> March, 3 o'clock	1 <sup>st</sup> March, 3 o'clock
31 <sup>st</sup> March, 3 o'clock	31 <sup>st</sup> March, 3 o'clock
1 <sup>st</sup> April, 3 o'clock	1 <sup>st</sup> April, 4 o'clock
1 <sup>st</sup> May, 3 o'clock	1 <sup>st</sup> May, 4 o'clock
1 <sup>st</sup> June, 3 o'clock	1 <sup>st</sup> June, 4 o'clock
1 <sup>st</sup> July, 3 o'clock,	1 <sup>st</sup> July, 4 o'clock
1 <sup>st</sup> August, 3 o'clock	1 <sup>st</sup> August, 4 o'clock,
31 <sup>st</sup> August, 3 o'clock	31 <sup>st</sup> August, 4 o'clock
1 <sup>st</sup> September, 3 o'clock	1 <sup>st</sup> September, 3 o'clock

**Example 1**

Disable DST function and read the DST state.



Setting values and descriptions:

Device	Setting Value	Description
D0	0	Disable DST function
D1	X	Invalid operand
D2	X	Invalid operand
D11	X	Invalid operand
D12	X	Invalid operand
D20	X	Invalid operand

Enable contact M0

Y0.0=OFF, indicating DST function is disabled.

D100=K2, indicating DST state is being read.

Enable contact M1

Setting values and descriptions:


Device	Setting Value	Description
D100	2	Before firmware V1.04 (V1.04 excluded), function code is fixed to 2, indicating the DST state is being read.
	4	After firmware V1.04 (V1.04 included), function code is 4, indicating the DST state is OFF.
D101	X	Invalid operand
D102	X	Invalid operand
D111	X	Invalid operand

D112	X	Invalid operand
D120	X	Invalid operand
Y0.1	OFF	Node state is OFF.

**Example 2**

Enable DST function and read the DST state.

Set the DST to start on 1<sup>st</sup> April and to end on 3<sup>rd</sup> September and the duration is 60 minutes.



Setting values and descriptions:

Device	Setting Value	Description
D0	1	The DST state is ON and in mode 1.
D1	4	Starting month: April
D2	1	Starting date: the 1 <sup>st</sup>
D11	9	Ending month: September
D12	3	Ending date: the 3 <sup>rd</sup>
D20	60	Duration: 60 minutes

Enable contact M0

Y0.0=ON, indicating DST function is enabled.

The PLC system time adds 60 minutes when the date April 1st arrives, and subtracts 60 minutes when the date September 3rd arrives to end daylight saving time.

D100=K2, indicating DST state is being read.

Enable contact M1

Setting values and descriptions:

Device	Setting Value	Description
D100	2	Before firmware V1.04 (V1.04 excluded), function code is fixed to 2, indicating the DST state is being read.
	5	After firmware V1.04 (V1.04 included), function code is 5, indicating the DST state is ON and in mode 1.
D101	4	Starting month: April
D102	1	Starting date: the 1 <sup>st</sup>
D111	9	Ending month: September
D112	3	Ending date: the 3 <sup>rd</sup>
D120	60	Duration: 60 minutes
Y0.1	ON	Node state is ON.

Use the instruction DST or HWCONFIG in ISPSOft to read the daylight saving state. The HWCONFIG converts the result from week number to the corresponding dates and months automatically.

Enable the contact M0 OFF=>ON again; this act has no impact on the DST. The DST does not reset.

Setting values and descriptions:


Device	Setting Value	Description
D100	2	Before firmware V1.04 (V1.04 excluded), function code is fixed to 2, indicating the DST state is being read.
	5	After firmware V1.04 (V1.04 included), function code is 5, indicating the DST state is ON and in mode 1.
D101	4	Starting month: April
D102	1	Starting date: the 1 <sup>st</sup>
D111	9	Ending month: September
D112	3	Ending date: the 3 <sup>rd</sup>
D120	60	Duration: 60 minutes
Y0.1	ON	Node state is ON.

If the daylight saving time starts from 3 o'clock of 1<sup>st</sup> April, 60 minutes is added; the real-time clock shows 4 o'clock of 1<sup>st</sup> April. No matter how many times the contact M0 is disabled or enabled, the real-time clock keeps the same daylight saving time.

**Example 3**

Enable DST function and in mode 2.

Set the DST to start from the 2<sup>nd</sup> Wednesday of May and to end on 3<sup>rd</sup> Friday of September and the duration is 60 minutes.



Setting values and descriptions:

Device	Setting Value	Description
D0	3	The DST state is ON and in mode 2.
D1	5	Starting month: May
D2	2	Starting week number: the 2 <sup>nd</sup> week
D3	3	Starting day: Wednesday
D11	9	Ending month: September
D12	3	Ending week number: the 3 <sup>rd</sup> week
D13	5	Ending day: Friday
D20	60	Duration: 60 minutes

Enable contact M0

Y0.0=ON, indicating DST function is enabled.

For the year 2017, the 2<sup>nd</sup> Wednesday of May is 10<sup>th</sup> May and the 3<sup>rd</sup> Friday of September is 15<sup>th</sup> September. The PLC system time adds 60 minutes when the date May 10<sup>th</sup> arrives and subtracts 60 minutes when the date September 15<sup>th</sup> arrives to end daylight saving time.

D100=K2, indicating DST state is being read.

Enable contact M1

Setting values and descriptions:

Device	Setting Value	Description
D100	2	Before firmware V1.04 (V1.04 excluded), function code is fixed to 2, indicating the DST state is being read.
	7	After firmware V1.04 (V1.04 included), function code is 4, indicating the DST state is ON and in mode 2.
D101	5	Starting month: May
D102	2	Starting week number: the 2 <sup>nd</sup> week
D103	3	Starting day: Wednesday
D111	9	Ending month: September
D112	3	Ending week number: the 3 <sup>rd</sup> week
D113	5	Ending day: Friday
D120	60	Duration: 60 minutes
Y0.1	ON	Node state is ON.

Use the instruction DST or HWCONFIG in ISPSOft to read the daylight saving state. The HWCONFIG converts the result from week number to the corresponding dates and months automatically.


API	Instruction code			Operand							Function					
1608		WWON		<b>S<sub>1</sub>, S<sub>2</sub>, D</b>							Setting up weekly working time					

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
S <sub>1</sub>								○								
S <sub>2</sub>								○								
S <sub>3</sub>								○								
S <sub>4</sub>								○								
D		○	○	○												

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
S <sub>1</sub>		●				●							
S <sub>2</sub>		●				●							
S <sub>3</sub>		●				●							
S <sub>4</sub>		●				●							
D	●												

Pulse instruction	16-bit instruction	32-bit instruction
-	AS	-

**Symbol**



- S<sub>1</sub>** : The hour to start working (occupies 7 consecutive devices)
- S<sub>2</sub>** : The minute to start working (occupies 7 consecutive devices)
- S<sub>3</sub>** : The hour to stop working (occupies 7 consecutive devices)
- S<sub>4</sub>** : The minute to stop working (occupies 7 consecutive devices)
- D** : Output control

**Explanation**

- This instruction allows you to set the time to start working for the week. **S<sub>1</sub>–S<sub>1</sub>+6** allows you to set the time on Sunday / Monday / Tuesday / Wednesday / Thursday / Friday / Saturday respectively. This operand occupies 7 consecutive devices. You can use the variables in an ARRAY to declare the operands.
- S<sub>2</sub>–S<sub>2</sub>+6 S<sub>1</sub>–S<sub>1</sub>+6** allows you to set the minutes to start working on Sunday / Monday / Tuesday / Wednesday / Thursday / Friday / Saturday respectively. This operand occupies 7 consecutive devices. You can use the variables in an ARRAY to declare the operands.
- S<sub>3</sub>–S<sub>3</sub>+6** allows you to set the hour to stop working on Sunday / Monday / Tuesday / Wednesday / Thursday / Friday / Saturday respectively. This operand occupies 7 consecutive devices. You can use the variables in an ARRAY to declare the operands.
- S<sub>4</sub>–S<sub>4</sub>+6** allows you to set the minutes to stop working on Sunday / Monday / Tuesday / Wednesday / Thursday /

Friday / Saturday respectively. This operand occupies 7 consecutive devices. You can use the variables in an ARRAY to declare the operands.

- When the hour value in **S<sub>1</sub>** is larger than the value set in **S<sub>3</sub>**, it means the time to stop working is the next day. For example, when you set the time to start working at 18:00 on Monday and the time to stop working at 6:00, it means the time to stop working is at 6:00 Tuesday.

	Start working time				Stop working time						
Day	Start	Hour		Start	Minute		Stop	Hour		Stop	Minute
Sunday	<b>S<sub>1</sub></b>	24		<b>S<sub>2</sub></b>	00		<b>S<sub>3</sub></b>	24		<b>S<sub>4</sub></b>	00
Monday	<b>S<sub>1+1</sub></b>	18		<b>S<sub>2+1</sub></b>	00		<b>S<sub>3+1</sub></b>	06		<b>S<sub>4+1</sub></b>	00


- The setting value for the hour is between 0–23. When the setting value is out of range, this function is not enabled. The setting value for the minute is between 0–59. When the setting value is out of range, this function is enabled but uses 0 as the setting value.
- When it is required to set the work time to be more than 1 day, you can set the hour as 24, which means the system does not check the start working time and the stop working time. For example, to set the start working time to 8 am Monday and the stop working time to 8pm Tuesday, use **S<sub>1+1</sub>=8**, **S<sub>3+1</sub>=24**, **S<sub>1+2</sub> =24** and **S<sub>3+2</sub>=20**. See the formula in the following table.

	Start working time				Stop working time						
Day	Start	Hour		Start	Minute		Stop	Hour		Stop	Minute
Sunday	<b>S<sub>1</sub></b>	24		<b>S<sub>2</sub></b>	00		<b>S<sub>3</sub></b>	24		<b>S<sub>4</sub></b>	00
Monday	<b>S<sub>1+1</sub></b>	08		<b>S<sub>2+1</sub></b>	00		<b>S<sub>3+1</sub></b>	24		<b>S<sub>4+1</sub></b>	00
Tuesday	<b>S<sub>1+2</sub></b>	24		<b>S<sub>2+2</sub></b>	00		<b>S<sub>3+2</sub></b>	20		<b>S<sub>4+2</sub></b>	00

- This instruction should work with the real-time clock in the PLC. Before operating, make sure the PLC battery is securely installed and working correctly.
- There is no limit on the number of times you can execute the instruction but the output control device **D** cannot be used repeatedly. If you use the device **D** repeatedly, only the last output result from the WWON instruction is executed.
- If more than 1 set of work hours are needed, use the WWON instruction repeatedly as required. Note that you cannot use the output control device **D** repeatedly.

**Example 1**

Set a working time from 8:00 to 18:00 from Monday to Friday and no work on Saturday and Sunday.




The following table lists the settings for the device **D**.

Day	Start working time				Stop working time			
	Start	Hour	Start	Minute	Stop	Hour	Stop	Minute
Sunday	D0	24	D10	00	D20	24	D30	00
Monday	D1	08	D11	00	D21	18	D31	00
Tuesday	D2	08	D12	00	D22	18	D32	00
Wednesday	D3	08	D13	00	D23	18	D33	00
Thursday	D4	08	D14	00	D24	18	D34	00
Friday	D5	08	D15	00	D25	18	D35	00
Saturday	D6	24	D16	00	D26	24	D36	00

When M0 is ON, Y0.0 is ON from 8:00 to 18:00 from Monday to Friday; for other times the Y0.0 is OFF.

**Example 2**

Set a working time from 18:00 Monday to 08:00 Tuesday and from 18:00 Tuesday to 08:00 Wednesday. Follow this pattern to 08:00 Saturday and no work on Sunday.




The following table lists the settings for the device **D**.

Day	Start working time				Stop working time			
	Start	Hour	Start	Minute	Stop	Hour	Stop	Minute
Sunday	D0	24	D10	00	D20	24	D30	00
Monday	D1	18	D11	00	D21	08	D31	00
Tuesday	D2	18	D12	00	D22	08	D32	00
Wednesday	D3	18	D13	00	D23	08	D33	00
Thursday	D4	18	D14	00	D24	08	D34	00
Friday	D5	18	D15	00	D25	08	D35	00
Saturday	D6	24	D16	00	D26	24	D36	00

When M0 is ON, Y0.0 is ON from 18:00 to 8:00 the next day from Monday to Friday and for other times the Y0.0 is OFF.

**Example 3**

Set a working time from 08:00 to 12:00 and from 14:00 to 17:30 from Monday to Friday. No work on Saturday and Sunday.



The following table lists the settings in the morning for the device **D**.

Day	Start working time				Stop working time				
	Start	Hour	Minute	Stop	Hour	Minute	Stop	Minute	
Sunday	D0	24	00	D10	24	00	D20	24	00
Monday	D1	08	00	D11	12	00	D21	12	00
Tuesday	D2	08	00	D12	12	00	D22	12	00
Wednesday	D3	08	00	D13	12	00	D23	12	00
Thursday	D4	08	00	D14	12	00	D24	12	00
Friday	D5	08	00	D15	12	00	D25	12	00
Saturday	D6	24	00	D16	24	00	D26	24	00

The following table lists the settings in the afternoon for the device **D**.

Day	Start working time				Stop working time				
	Start	Hour	Minute	Stop	Hour	Minute	Stop	Minute	
Sunday	D40	24	00	D50	24	00	D60	24	00
Monday	D41	14	00	D51	17	00	D61	17	30
Tuesday	D42	14	00	D52	17	00	D62	17	30
Wednesday	D43	14	00	D53	17	00	D63	17	30
Thursday	D44	14	00	D54	17	00	D64	17	30
Friday	D45	14	00	D55	17	00	D65	17	30
Saturday	D46	24	00	D56	24	00	D66	24	00

When M0 is ON, Y0.0 is ON from 08:00 to 12:00 and 14:00 to 17:30 from Monday to Friday and for other times the Y0.0 is OFF.

## 6.18 Peripheral Instructions

### 6.18.1 List of Peripheral Instructions

The following table lists the Peripheral instructions covered in this section.

API	Instruction code		Pulse instruction	Function
	16-bit	32-bit		
<b><u>1700</u></b>	TKY	DTKY	–	Ten-key keypad
<b><u>1701</u></b>	HKY	DHKY	–	Sixteen-key keypad
<b><u>1702</u></b>	DSW	–	–	DIP switch
<b><u>1703</u></b>	ARWS	–	–	Arrow keys
<b><u>1704</u></b>	SEGL	–	–	Seven-segment display with latches

## 6.18.2 Explanation of Peripheral Instructions

API	Instruction code			Operand								Function			
1700	D	TKY		S, D <sub>1</sub> , D <sub>2</sub>								Ten-key keypad			

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
S	○															
D <sub>1</sub>					●	●	●	●								
D <sub>2</sub>		○	○	○				○								

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
S	●												
D <sub>1</sub>		●	●			●	●						
D <sub>2</sub>	●												

Pulse instruction	16-bit instruction	32-bit instruction
-	AS	AS

### Symbol

TKY		DTKY	
En		En	
S	D1	S	D1
	D2		D2


- S** : First input device  
**D<sub>1</sub>** : Device where the value is stored  
**D<sub>2</sub>** : Output signal

### Explanation

- The ten external inputs starting from the input specified by **S** represents 0–9 in the decimal system. They are connected to ten keys. You can enter a four-digit decimal value 0–9,999 (16-bit instruction) or an eight-digit decimal value 0–99,999,999 (32-bit instruction) by pressing the keys in order. The instruction stores the decimal value in **D<sub>1</sub>**, and stores the output signals in **D<sub>2</sub>**.
- The operand **S** occupies ten bits.
- The operand **D<sub>2</sub>** occupies eleven bits. Please do not change the states of the bits during the execution of the instruction.
- When the conditional contact is not enabled, the eleven bits starting from the bit specified by **D<sub>2</sub>** are OFF.
- When using on-line editing, please reset the conditional contact to initialize the instruction.
- You can use the 32-bit counter only when **D<sub>1</sub>** uses 32-bit instructions.


**Example**

1. The ten external inputs starting from X0.0 are connected to ten keys that represent 0–9 in the decimal system. When M0 is ON, the instruction stores the value that you enter as a binary value in D0, and stores the output signals in M10–M19.




Note: The digital input module AH16AM10N-5A is used in this example.

**6**



2. If the keys connected to X0.5, X0.3, X0.0, and X0.1 are pressed in the order shown in the timing chart, the instruction stores the result 5,301 in D0. The maximum value that can be stored in D0 is 9,999. If the value exceeds four digits, the first digit from the left overflows.
3. After the key connected to the X0.2 is pressed and before other keys are pressed, M12 is ON. The same applies to the other keys.

4. When a key connected to the input within the range between X0.0 and X0.9 is pressed, the corresponding output within the range between M10 and M19 is ON.
5. When one of the keys is pressed, M20 is ON.
6. When the conditional contact M0 is switched OFF, the value stored in D0 is unchanged; however, M10–M20 are switched OFF.



#### Additional remarks

1. If you declare the operand **S** in ISPSOft, the data type is ARRAY [10] of BOOL.
2. If you declare the operand **D<sub>2</sub>** in ISPSOft, the data type is ARRAY [11] of BOOL.

API	Instruction code			Operand							Function					
1701	D	HKY		<b>S<sub>1</sub>, S<sub>2</sub>, D<sub>1</sub>, D<sub>2</sub>, D<sub>3</sub></b>							Sixteen-key keypad					

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	“\$”	F
<b>S<sub>1</sub></b>	○															
<b>S<sub>2</sub></b>								●								
<b>D<sub>1</sub></b>		○														
<b>D<sub>2</sub></b>					●	●	●	●								
<b>D<sub>3</sub></b>		○	○	○				○								

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
<b>S<sub>1</sub></b>	●												
<b>S<sub>2</sub></b>		●				●							
<b>D<sub>1</sub></b>	●												
<b>D<sub>2</sub></b>		●	●			●	●						
<b>D<sub>3</sub></b>	●												

Pulse instruction	16-bit instruction	32-bit instruction
-	AS	AS

**Symbol**

HKY		DHKY	
En		En	
S1	D1	S1	D1
S2	D2	S2	D2
	D3		D3

- S<sub>1</sub>** : First input device
- S<sub>2</sub>** : For system use only
- D<sub>1</sub>** : First output device
- D<sub>2</sub>** : Device where the value is stored
- D<sub>3</sub>** : Output signal


**Explanation**

1. The four external inputs starting from the input specified by **S** are connected to the four external outputs starting from the output specified by **D<sub>1</sub>** to form a 16-key keypad. The instruction stores the value that you enter by pressing the keys in **D<sub>2</sub>**, and stores the output signals in **D<sub>3</sub>**. If you press several keys simultaneously, the value that is smaller is stored.
2. The value that you enter by pressing the keys is temporarily stored in **D<sub>2</sub>**. For the 16-bit HKY instruction, the maximum value that can be stored in **D<sub>2</sub>** is 9,999. If the value exceeds four digits, the first digit from the left overflows. For the 32-bit DHKY instruction, the maximum value that can be stored in **D<sub>2</sub>** is 9,999. If the value exceeds eight digits, the first digit from the left overflows.
3. After the instruction completes, SM692 is ON. That is, SM692 is ON for a scan cycle after the execution of the matrix scan is complete.

- You can use the 32-bit counter only when D<sub>2</sub> uses 32-bit instructions.


**Example**

- The four external inputs X0.0–X0.3 are connected to the four external outputs Y0.0–Y0.3 to form a 16-key keypad. When X1.0 is ON, the instruction stores the value that you enter as a binary value in D0, and stores the output signals in M0–M7.




The function of SM691:

- If SM691 is ON, the 16-bit instruction takes 0–F as hexadecimal values.
  - Numeric keys:




- If SM691 is OFF, the 16-bit instruction takes A–F as function keys.
  - Numeric keys:



■ Function keys:

- ◆ When A is pressed, M0 stays ON. When D is pressed, M0 switches OFF, and M3 stays ON.
- ◆ If several function keys are pressed, the key which is pressed first has priority.




2. Output signals:

- When a key within the range between A and F is pressed, M6 is ON.
- When a key within the range between 0 and 9 is pressed, M7 is ON.

3. When the conditional contact X1.0 switches to OFF, the value that was stored in D0 is unchanged. However, M0–M7 are switched OFF.

4. The external wiring:



Note: The transistor output module AH16AP11T-5A is used in this example.

**Additional remarks**

1. When this instruction is executed, a too long or a too short scan cycle time will cause the state of the switches to be read incorrectly. Use the following tips to solve the issue.
  - When the scan cycle is too short, the I/O may not be able to respond in time and cannot read the correct states of the inputs. You can set a fixed scan time to solve this issue.
  - When the scan cycle is too long, the switch may become slow to react. You can write this instruction to a timer interrupt task to set a fixed time to execute this instruction.
2. If you declare the operand **S** in ISPSOft, the data type is ARRAY [4] of BOOL.
3. If you declare the operand **D1** in ISPSOft, the data type is ARRAY [4] of BOOL.
4. If you declare the operand **D3** in ISPSOft, the data type is ARRAY [8] of BOOL.


API	Instruction code			Operand								Function					
1702		DSW		<b>S<sub>1</sub>, S<sub>2</sub>, D<sub>1</sub>, D<sub>2</sub>, n</b>								DIP switch					

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
<b>S<sub>1</sub></b>	○															
<b>S<sub>2</sub></b>								●								
<b>D<sub>1</sub></b>		○														
<b>D<sub>2</sub></b>					●	●		●								
<b>n</b>					●	●		●	●		○	○	○	○		

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
<b>S<sub>1</sub></b>	●												
<b>S<sub>2</sub></b>		●				●							
<b>D<sub>1</sub></b>	●												
<b>D<sub>2</sub></b>		●				●							
<b>n</b>		●				●							

Pulse instruction	16-bit instruction	32-bit instruction
-	AS	-

**Symbol**



- S<sub>1</sub>** : First input device
- S<sub>2</sub>** : For system use only
- D<sub>1</sub>** : First output device
- D<sub>2</sub>** : Device where the value is stored
- n** : Number of DIP switches


**Explanation**

1. The four or eight external inputs starting from the input specified by **S<sub>1</sub>** are connected to the four external outputs starting from the output specified by **D<sub>1</sub>** to form a four-digit DIP switch or two four-digit DIP switches. The instruction stores the value from the DIP switch in **D<sub>2</sub>**. Whether there is one four-digit DIP switch or two four-digit DIP switches depends on **n**.
2. If **n** is 1, the operand **D<sub>2</sub>** occupies one register. If **n** is 2, the operand **D<sub>2</sub>** occupies two registers.
3. **S<sub>2</sub>** and **S<sub>2</sub>+1**, are for system use only, and occupy two devices. Please do not alter the values in these devices.
4. After the instruction completes, SM694 is ON for a scan cycle.
5. When the conditional contact is not enabled, the four external outputs starting from the output specified by **D<sub>1</sub>** stay OFF.


6. When using on-line editing, please reset the conditional contact to initialize the instruction.

**Example**


1. X0.0–X0.3 are connected to Y0.0–Y0.3 to form the first DIP switch, and X0.4–X0.7 are connected to Y0.0–Y0.3 to form the second DIP switch. When X1.0 is ON, the instruction converts the value that you enter with the first DIP switch into the binary value, and stores the conversion result in D20. The instruction converts the value that you enter with the second DIP switch into the binary value, and stores the conversion result in D21.



2. When X1.0 is ON, Y0.0–Y0.3 are ON cyclically. After the instruction completes, SM694 is ON for a scan cycle.
3. The following graphic shows the outputs. Y0.0–Y0.3 must be transistors.



4. The following graphic shows the DIP switches.



Note: The transistor output module AH16AP11T-5A is used in this example.

**Additional remarks**

1. If **n** exceeds the range, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#200B.
2. If you declare the operand **D<sub>1</sub>** in ISPSOft, the data type is ARRAY [4] of BOOL.


API	Instruction code			Operand							Function				
1703		ARWS		<b>S<sub>1</sub>, S<sub>2</sub>, D<sub>1</sub>, D<sub>2</sub>, n</b>							Arrow keys				

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
<b>S<sub>1</sub></b>	○															
<b>S<sub>2</sub></b>								●								
<b>D<sub>1</sub></b>					●	●		●								
<b>D<sub>2</sub></b>		○														
<b>n</b>					●	●		●	●		○	○	○	○		

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
<b>S<sub>1</sub></b>	●												
<b>S<sub>2</sub></b>		●				●							
<b>D<sub>1</sub></b>		●				●							
<b>D<sub>2</sub></b>	●												
<b>n</b>		●				●							

Pulse instruction	16-bit instruction	32-bit instruction
-	AS	-

**Symbol**




- S<sub>1</sub>** : First input device
- S<sub>2</sub>** : For system use only
- D<sub>1</sub>** : Device where the setting value is stored
- D<sub>2</sub>** : First output device
- n** : Positive/Negative logic

**Explanation**

1. This instruction defines **S<sub>1</sub>** as the down arrow, **S<sub>1</sub>+1** as the up arrow, **S<sub>1</sub>+2** as the right arrow, and **S<sub>1</sub>+3** as the left arrow. The instruction stores the setting value in **D<sub>1</sub>**, and the value must be between 0–9,999.
2. The operand **S<sub>1</sub>** occupies four consecutive bit devices.
3. **S<sub>2</sub>** is for system use only. Please do not alter the value in it.
4. The operand **D<sub>2</sub>** occupies eight consecutive bit devices.
5. When the conditional contact is disabled, the eight bit devices starting from the bit device specified by **D<sub>2</sub>** stay OFF.
6. The operand **n** must be between 0–3.
7. When using on-line editing, please reset the conditional contact to initialize the instruction.

**Example**

1. The instruction defines X0.0 as the down arrow, X0.1 as the up arrow, X0.2 as the right arrow, and X0.3 as the left arrow. The instruction stores the setting value in D20, and the setting value must be between 0–9,999.
2. When X1.0 is ON, the digit in the place  $10^3$  is selected. If the left arrow is pressed, the places are selected in sequence ( $10^3 \rightarrow 10^0 \rightarrow 10^1 \rightarrow 10^2 \rightarrow 10^3 \rightarrow 10^0$ ).
3. If you press right arrow, the places are selected in sequence ( $10^3 \rightarrow 10^2 \rightarrow 10^1 \rightarrow 10^0 \rightarrow 10^3 \rightarrow 10^2$ ). The LED indicators for the corresponding places are connected to Y0.4–Y0.7. When the digits in the places are selected in sequence, the LED indicators are ON in sequence.
4. If you press the up arrow, the digit in the place selected changes ( $0 \rightarrow 1 \rightarrow 2 \rightarrow \dots \rightarrow 8 \rightarrow 9 \rightarrow 0 \rightarrow 1$ ). If you press the down arrow, the digit in the place selected changes ( $0 \rightarrow 9 \rightarrow 8 \rightarrow \dots \rightarrow 1 \rightarrow 0 \rightarrow 9$ ). The new digit is shown on seven-segment display.

**Additional remarks**

1. If **n** exceeds the range, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#200B.
2. If you declare the operand **S<sub>1</sub>** in ISPSOft, the data type is ARRAY [4] of BOOL.
3. If you declare the operand **D<sub>2</sub>** in ISPSOft, the data type is ARRAY [8] of BOOLL.

API	Instruction code			Operand							Function				
1704		SEGL		<b>S<sub>1</sub>, S<sub>2</sub>, D, n</b>							Seven-segment display with latches				

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
<b>S<sub>1</sub></b>	●	●			●	●		●	●		○	○				
<b>S<sub>2</sub></b>								●								
<b>D</b>		○														
<b>n</b>					●	●		●	●		○	○	○	○		

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
<b>S<sub>1</sub></b>		●				●							
<b>S<sub>2</sub></b>		●				●							
<b>D</b>	●												
<b>n</b>		●				●							

Pulse instruction	16-bit instruction	32-bit instruction
-	AS	-

**Symbol**



- S<sub>1</sub>** : Source device
- S<sub>2</sub>** : For system use only
- D** : First output device
- n** : Positive/Negative logic


**Explanation**

1. The eight external outputs starting from the output specified by **D** are connected to a four-digit seven-segment display; or the twelve external outputs starting from the output specified by **D** are connected to two four-digit seven-segment displays. Every place is equipped with a driver that converts a binary-coded decimal value into seven-segment data, and every driver is equipped with a latch that can be used to store state information.
2. The value in **S<sub>1</sub>** is the value to show on first seven-segment display, and the value in **S<sub>1</sub>+1** is the value to show on second seven-segment display.
3. **S<sub>2</sub>** is for system use only. Please do not alter the value in it.
4. The operand **n** must be between 0–7. Please refer to the Additional remark for more information.
5. Whether there is one four-digit seven-segment display or two four-digit seven-segment displays, and whether an output is a positive logic output or a negative logic output depends on **n**.
6. If there is one four-digit seven-segment display, eight outputs are occupied. If there are two four-digit seven-segment displays, twelve outputs are occupied.

7. When the instruction is executed, the outputs are ON cyclically. If the conditional contact switches from OFF to ON during the execution of the instruction, the outputs are ON cyclically again.
8. After the execution of the instruction is complete, SM693 is ON for a scan cycle.


### Example

1. When X1.0 is ON, the instruction is executed. Y0.0–Y0.4 form a circuit. The instruction converts the value in D10 into the binary-coded decimal value, and shows the conversion result on first seven-segment display. The instruction converts the value in D11 into the binary-coded decimal value, and shows the conversion result on second seven-segment display. If the value in D10 or D11 exceeds 9,999, an operation error occurs.



2. When X1.0 is ON, Y0.4–Y0.7 are ON cyclically. It takes twelve scan cycles for Y0.4–Y0.7 to be ON. After the instruction completes, SM693 is ON for a scan cycle.
3. If there is one four-digit seven-segment display, **n** is between 0–3.
  - Connect the pins 1, 2, 4, and 8 in parallel, then connect them to Y0.0–Y0.3 on the PLC, and connect the latches to Y0.4–Y0.7 on the PLC.
  - When X1.0 is ON, the instruction is executed. Y0.4–Y0.7 are ON cyclically, and the value in D10 is shown on seven-segment display.
4. If there are two four-digit seven-segment displays, **n** is between 4–7.
  - Connect the pins 1, 2, 4, and 8 in parallel, then connect them to Y0.8–Y0.11 on the PLC, and connect the latches to Y0.4–Y0.7 on the PLC.
  - The value in D10 is shown on first seven-segment display, and the value in D11 is shown on second seven-segment display. If the values in D10 and D11 are 1234 and 4321 respectively, 1234 is shown on second seven-segment display.

5. The wiring:



Note: The transistor output module AH16AN01T-5A is used in this example.

**Additional remarks**

- Whether an output is a positive output or a negative output, and whether there is one four-digit seven-segment display or two four-digit seven-segment displays depend on **n**.
- The outputs on the PLC should be NPN transistors whose collectors are open collectors. In addition, an output has to connect a pull-up resistor to the DC power supply (less than 30 VDC). Therefore, when an output is ON, a signal of low potential is output.
- The following table shows the negative logic.

6

Binary-coded decimal value				Output (Binary-coded decimal code)				Signal			
b <sub>3</sub>	b <sub>2</sub>	b <sub>1</sub>	b <sub>0</sub>	8	4	2	1	A	B	C	D
0	0	0	0	0	0	0	0	1	1	1	1
0	0	0	1	0	0	0	1	1	1	1	0
0	0	1	0	0	0	1	0	1	1	0	1
0	0	1	1	0	0	1	1	1	1	0	0
0	1	0	0	0	1	0	0	1	0	1	1
0	1	0	1	0	1	0	1	1	0	1	0
0	1	1	0	0	1	1	0	1	0	0	1
0	1	1	1	0	1	1	1	1	0	0	0
1	0	0	0	1	0	0	0	0	1	1	1
1	0	0	1	1	0	0	1	0	1	1	0

- The following table shows the positive logic.

Binary-coded decimal value				Output (Binary-coded decimal code)				Signal			
b <sub>3</sub>	b <sub>2</sub>	b <sub>1</sub>	b <sub>0</sub>	8	4	2	1	A	B	C	D
0	0	0	0	1	1	1	1	0	0	0	0
0	0	0	1	1	1	1	0	0	0	0	1
0	0	1	0	1	1	0	1	0	0	1	0
0	0	1	1	1	1	0	0	0	0	1	1
0	1	0	0	1	0	1	1	0	1	0	0
0	1	0	1	1	0	1	0	0	1	0	1
0	1	1	0	1	0	0	1	0	1	1	0
0	1	1	1	1	0	0	0	0	1	1	1
1	0	0	0	0	1	1	1	1	0	0	0
1	0	0	1	0	1	1	0	1	0	0	1

- The following table shows the latch.

Positive logic		Negative logic	
Latch	Signal	Latch	Signal
1	0	0	1

- The following table shows the setting value of the parameter n.


Number of seven-segment displays	One				Two			
	+		-		+		-	
Output (Binary-coded decimal code)	+		-		+		-	
Latch	+	-	+	-	+	-	+	-
n	0	1	2	3	4	5	6	7

'+' : Positive logic

'-' : Negative logic

- You can edit the parameters in n to modify the logics for the output transistor and the input of the seven-segment display.

- The following graphic shows the connection of the common-anode four-digit seven-segment display with IC 7447.



## 6.19 Communication Instructions

### 6.19.1 List of Communication Instructions

The following table lists the Communication instructions covered in this section.

API	Instruction code		Pulse instruction	Function
	16-bit	32-bit		
<b><u>1806</u></b>	LRC	–	–	Longitudinal parity check
<b><u>1807</u></b>	CRC	–	–	Cyclic Redundancy Check
<b><u>1808</u></b>	MODRW	–	–	Reading and Writing Modbus data
<b><u>1812</u></b>	COMRS	–	–	Sending and receiving communication data
<b><u>1813</u></b>	COMDF	–	✓	Setting the communication format for a serial communication port
<b><u>1814</u></b>	VFDRW	–	–	Serial communication instruction exclusively for Delta AC motor drives
<b><u>1815</u></b>	ASDRW	–	–	Serial communication instruction exclusively for Delta servo drives
<b><u>1816</u></b>	CCONF	–	✓	Setting the parameters in the data exchange table for a communication port
<b><u>1817</u></b>	MODRWE	–	–	Reading and writing Modbus data without using any flags
<b><u>1818</u></b>	DNETRW	–	–	Reading and writing DeviceNet communication data
<b><u>1819</u></b>	CANRS	–	–	User-defined CAN communication sending and receiving
<b><u>1820</u></b>	DMVSH	–	–	Enabling Delta DMV detection and communication
<b><u>1821</u></b>	DESO	–	–	Execute the appointed communication number of the data exchange table once

### 6.19.2 Explanation of Communication Instructions


API	Instruction code			Operand						Function					
1806		LRC		<b>S, n, D</b>						Longitudinal parity check					

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
<b>S</b>								●	●							
<b>n</b>								●	●				○	○		
<b>D</b>								●								

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
<b>S</b>		●				●							
<b>n</b>		●				●							
<b>D</b>		●				●							

Pulse instruction	16-bit instruction	32-bit instruction
-	AS	-

#### Symbol



- S** : First device to which the LRC is applied
- n** : Number of bytes
- D** : First device where the operation result is stored

#### Explanation

1. This instruction performs a longitudinal parity check on **n** bytes in the device specified by **S**. Please refer to the Additional remark for this instruction (below) for more information about the LRC check code.
2. The operand **n** must be an even number, and must be between 1–1000. If **n** is not in the range, an operation error occurs, the instruction is not executed, SM0 and SM1 are ON, and the error code in SR0 is 16#200B.
3. The 16-bit conversion mode: When SM606 is OFF, the instruction divides the hexadecimal data in the device specified by **S** into the high 8-bit data and the low 8-bit data. The instruction applies the LRC to every byte, and stores the operation result in the high 8-bit and the low 8-bit in the device specified by **D**. The number of bytes depends on **n**.
4. The 8-bit conversion mode: When SM606 is ON, the instruction divides the hexadecimal data in the device specified by **S** into the high 8-bit data (invalid data) and the low 8-bit data. The instruction applies the LRC to every byte, and stores the operation result in the low 8-bit in the two registers. The number of bytes depends on **n**. The values of the high 8 bits in the two registers are 0.

**Example**

- The PLC is connected to the VFD-S series AC motor drive (ASCII mode SM210 is OFF; 8-bit mode: SM606 is ON). The PLC sends the command, and reads the data in the six devices at the addresses starting from 16#2101 in the VFD-S series AC motor drive.


PLC⇒VFD-S

The PLC sends “ : 01 03 2101 0006 D4 CR LF”.

The PLC sends the data in the following table.

Register	Data		Description	
D100 Low 8 bits	‘ : ’	16#3A	STX	
D101 Low 8 bits	‘0’	16#30	ADR 1	AD (1, 0) is the station address of the AC motor drive.
D102 Low 8 bits	‘1’	16#31	ADR 0	
D103 Low 8 bits	‘0’	16#30	CMD 1	CMD (10) is the command code.
D104 Low 8 bits	‘3’	16#33	CMD 0	
D105 Low 8 bits	‘2’	16#32	Initial data address	
D106 Low 8 bits	‘1’	16#31		
D107 Low 8 bits	‘0’	16#30		
D108 Low 8 bits	‘1’	16#31		
D109 Low 8 bits	‘0’	16#30	Number of data (counted by the word)	
D110 Low 8 bits	‘0’	16#30		
D111 Low 8 bits	‘0’	16#30		
D112 Low 8 bits	‘6’	16#36		
D113 Low 8 bits	‘D’	16#44	LRC CHK 0	LRC CHK (01) is the error checking code.
D114 Low 8 bits	‘4’	16#34	LRC CHK 1	
D115 Low 8 bits	CR	16#0D	END	
D116 Low 8 bits	LF	16#0A		

LRC CHK (01) above is the error checking code. You can use the LRC instruction to calculate it (8-bit mode: SM606 is ON).



LRC check code:  $16\#01+16\#03+16\#21+16\#01+16\#00+16\#06=16\#2C$

The two's complement of  $16\#2C$  is  $16\#D4$ . 'D' ( $16\#44$ ) is stored in the low 8-bit in D113, and '4' ( $16\#34$ ) is stored in the low 8-bit in D114.

**Additional remarks**

1. The following table lists the format of the communication data in the ASCII mode.

<b>STX</b>	' : '	The start-of-text character is ' : ' ( $16\#3A$ ).
<b>Address Hi</b>	' 0 '	Communication address:
<b>Address Lo</b>	' 1 '	The 8-bit address is composed of two ASCII codes.
<b>Function Hi</b>	' 0 '	Function code:
<b>Function Lo</b>	' 3 '	The 8-bit function code is composed of two ASCII codes.
<b>DATA ( n-1 )</b> ..... <b>DATA 0</b>	' 2 '	Data: The $n \times 8$ -bit data is composed of $2n$ ASCII codes.
	' 1 '	
	' 0 '	
	' 2 '	
	' 0 '	
	' 0 '	
	' 0 '	
	' 2 '	
<b>LRC CHK Hi</b>	' D '	LRC check code:
<b>LRC CHK Lo</b>	' 7 '	The 8-bit check code is composed of two ASCII codes.
<b>END Hi</b>	CR	End-of-text character:
<b>END Lo</b>	LF	END Hi=CR ( $16\#0D$ ), END Lo=LF ( $16\#0A$ )

2. LRC check code: The instruction adds up the values starting from the communication address to the data, then the instruction calculates the two's complement of the sum that is the LRC check code.

Example  $16\#01+16\#03+16\#21+16\#02+16\#00+16\#02=16\#29$

The two's complement of  $16\#29$  is  $16\#D7$ .


API	Instruction code			Operand				Function						
1807		CRC		<b>S, n, D</b>				Cyclic Redundancy Check						

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
<b>S</b>								●	●							
<b>n</b>								●	●				○	○		
<b>D</b>								●								

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
<b>S</b>		●				●							
<b>n</b>		●				●							
<b>D</b>		●				●							

Pulse instruction	16-bit instruction	32-bit instruction
-	AS	-

### Symbol



**S** : First device to which the CRC is applied

**n** : Number of bytes

**D** : First device in which the operation result is stored

### Explanation

- This instruction performs a cyclic redundancy check on **n** bytes starting with the device specified by **S**. Please refer to the Additional remark for this instruction (below) for more information about the CRC check code.
- The operand **n** must be between 1–1000. If **n** is not in the range, an operation error occurs, the instruction is not executed, SM0 and SM1 are ON, and the error code in SR0 is 16#200B.
- The 16-bit conversion mode: When SM606 is OFF, the instruction divides the hexadecimal data in the device specified by **S** into the high 8-bit data and the low 8-bit data. The instruction applies the CRC to every byte, and the stores the operation result in the high 8-bit and the low 8-bit in the device specified by **D**. The number of bytes depends on **n**.
- The 8-bit conversion mode: When SM606 is ON, the instruction divides the hexadecimal data in the device specified by **S** into the high 8-bit data (invalid data) and the low 8-bit data. The instruction applies the CRC to every byte, and stores the operation result in the low 8-bit in the two registers. The number of bytes depends on **n**.

**Example**

- The PLC is connected to the VFD-S series AC motor drive (RTU mode SM210 is ON; 16-bit mode: SM606 is ON.). The value 16#12, to be written into the device at 16#2000 in the VFD-S series AC motor drive, is written into the device in the PLC first.


PLC⇒VFD-S

The PLC sends 01 06 2000 0012 02 07.

The PLC sends the data in the following table.

Register	Data	Description
D100 Low 8 bits	16#01	Address
D101 Low 8 bits	16#06	
D102 Low 8 bits	16#20	Data address
D103 Low 8 bits	16#00	
D104 Low 8 bits	16#00	Data
D105 Low 8 bits	16#12	
D106 Low 8 bits	16#02	CRC CHK 0
D107 Low 8 bits	16#07	CRC CHK 1

CRC CHK (01) above is the error checking code. You can calculate it with the CRC instruction (8-bit mode: SM606 is ON).



CRC check code: 16#02 is stored in the low 8-bit in D106, and 16#07 is stored in the low 8-bit in D107.

**Additional remarks**

1. The following table shows the format of the communication data in RTU mode.

<b>START</b>	Time interval
<b>Address</b>	Communication address: 8-bit binary address
<b>Function</b>	Function code: 8-bit binary code
<b>DATA ( n-1 )</b>	Data: n×8-bit data
.....	
<b>DATA 0</b>	
<b>CRC CHK Low</b>	CRC check code: The 16-bit check code is composed of two 8-bit binary codes.
<b>CRC CHK High</b>	
<b>END</b>	Time interval

2. CRC check code: The check code starts from the address to the data. The operation rule is shown in the following table.

- Step 1: Suppose the data in the 16-bit register (the register where the CRC check code is stored) is 16#FFFF.
- Step 2: The logical operator XOR takes the first 8-bit message and the low 8-bit data in the 16-bit register, and performs the logical exclusive OR operation on each pair of corresponding bits. The operation result is stored in the 16-bit register.
- Step 3: The values of the bits in the 16-bit registers are shifted by one bit to the right. The value of the highest bit becomes 0.
- Step 4: If the value of the right-most bit that is shifted to the right is 0, the data from step 3 is stored in the 16-bit register. Otherwise, the logical operator XOR takes 16#A001 and the data in the 16-bit register, and performs the logical exclusive OR operation on each pair of corresponding bits. The operation result is stored in the 16-bit register.
- Step 5: Repeat step 3 and step 4, and perform the operation on the 8-bit message.
- Step 6: Repeat step 2–5, and then get the next 8-bit message. Perform the operations on all messages. The final result in the 16-bit register is the CRC check code. Notice that the low 8-bit data in the 16-bit register is interchanged with the high 8-bit data in the 16-bit register before the CRC check code is put into the check code of the message.


API	Instruction code		Operand							Function						
1808		MODRW	<b>S<sub>1</sub>, S<sub>2</sub>, S<sub>3</sub>, S, n</b>							Reading and Writing Modbus data						

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	“\$”	F
S <sub>1</sub>								●	●				○	○		
S <sub>2</sub>								●	●				○	○		
S <sub>3</sub>								●	●				○	○		
S								●								
n								●	●				○	○		

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
S <sub>1</sub>		●				●							
S <sub>2</sub>		●				●							
S <sub>3</sub>		●				●							
S	●	●				●							
n		●				●							

Pulse instruction	16-bit instruction	32-bit instruction
-	AS	-

Symbol



- S<sub>1</sub> : Unit address
- S<sub>2</sub> : Function code
- S<sub>3</sub> : Device address
- S : Register for reading/writing the data
- n : Data length

Explanation

1. The operand S<sub>1</sub> must be between 0–254; 0 is the broadcasting mode.
2. S<sub>2</sub> is the function code.

The following table shows an example.

Function code	Description	Data length	Devices that support devices for slaves
16#01	PLC reads the data from several bit devices.	1-1600	X, Y, M, SM, S, T, C, HC
16#02	PLC reads the data from several bit devices.	1-1600	X, Y, M, SM, S, T, C, HC
16#03	PLC reads the data from several word devices.	1-100	X, Y, SR, D, T, C, HC, E

Function code	Description	Data length	Devices that support devices for slaves
16#04	PLC reads the data from several word devices.	1-100	X
16#05	PLC writes the state into a bit device.	1	Y, M, SM, S, T, C, HC
16#06	PLC writes the data into a word device.	1	Y, SR, D, T, C, HC, E
16#0F	PLC writes the states into several bit devices.	1-1600	Y, M, SM, S, T, C, HC
16#10	PLC writes the data into several word devices.	1-100	Y, SR, D, T, C, HC, E

The instruction supports only the function codes mentioned above, and cannot execute other function codes.

Please refer to the examples below.

- S<sub>3</sub>** is the device address. If the address is invalid for the designated communication device, the communication device responds with an error message. For example, the device address 16#8000 is invalid in the DVP-ES2.

- S** is the register involved in the reading/writing the data.

The data to be written into the external equipment is stored in the register in advance.

The data to be read from the external equipment is stored in the register.

- N** is the length of the data

For word-type communication function codes, the data length cannot exceed 100 words.

For bit-type (BOOL) communication function codes, the data length is between 1–1600 bits.

- The following table shows how the functions of **S<sub>3</sub>**, **S**, and **n** vary with the function code used.

Function code	S <sub>3</sub>	S	n
16#01	Address from where the data is read	Register where the data read is stored	Length of data read
16#02	Address from where the data is read	Register where the data read is stored	Length of data read
16#03	Address from where the data is read	Register where the data read is stored	Length of data read
16#04	Address from where the data is read	Register where the data read is stored	Length of data read
16#05	Address into where the	Status value written	No meaning


Function code	S <sub>3</sub>	S	n
	data is written		
16#06	Address into where the data is written	Register where the data written is stored	No meaning
16#0F	Address into where the data is written	Register where the data written is stored	Length of data written
16#10	Address into where the data is written	Register where the data written is stored	Length of data written

7. There is no limitation on the number of times you can use this instruction; however only one instruction can be executed on the same COM port at a time. You need to decide and use the sending flag for the COM to be used before executing this instruction. Otherwise, the data from 2 different communication COMs may be mixed up.
8. If a communication timeout occurs, the timeout flags are ON. After you solve the problem, you must reset timeout flags to OFF. When using this instruction, the timeout value cannot 0. Set the value between 100–32767ms; when the value is set to 0, it is processed as 200 ms.
9. In Modbus ASCII mode, you need to set up only the data (non-ASCII mode) for transmission. The instruction converts the non-ASCII mode to the ASCII mode, consisting of the head code (:), the converted ASCII code, checksum (LRC) and tail code (CRLF). The instruction stores the data received in ASCII character in the internal register. The PLC automatically converts the data into the hexadecimal value, and if the communication data is correct, stores the conversion result in **S**. and sets the completion flag SM to ON.
10. In Modbus RTU mode, you need to set up only the data for transmission. The instruction adds the checksum (CRC) and the stores the data received in ASCII character in the internal register. The PLC automatically converts the data into the hexadecimal value, and if the communication data is correct, stores the conversion result stored in **S**.
11. The instruction cannot be used in the ST programming language, interrupt tasks or function block which is called only once.

### Communication protocol setup example


1. The following examples use PLC communication port 1 and special registers to demonstrate how to setup a communication protocol.
2. You can set up the PLC communication port with HWCONFIG in ISPSOft, or with the relative special registers, or you can use the COMDF instruction (API 1813) to set up the communication. Please refer to the ISPSOft manual for setting it up in HWCONFIG. For communication register setups (SM, SR), please refer to section 6.19.3 for more details.

3. The communication setup for this example is RS485 ASCII, 9600, 8, E, 1 (SR209=16#0025).
4. Set the communication timeout to 3000ms (SR210=3000).
5. Set the communication mode to ASCII mode (SM210=OFF).
6. Enable the communication protocol (SM209=ON).



If you set up the communication port with the COMDF instruction (API 1813), you can ignore this step.


**6**



If you set up the communication port in ISPSOft - > HWCONFIG - > COM Port, you can ignore this step.

**Example 1**

- Function code 01 (16#01): the PLC reads the data from several bit devices that are not discrete input devices (16 pieces of data is read in this example). For function code 02, the operation is the same as for function code 01.



AS Series CPU module is connected to the DVP-ES2 Series PLC.

When SM96 and X0.0 are on, the AS Series CPU sends and receives the Y0–Y17 commands from the DVP-ES2.

When the address of Y0 is 16#0500, the states of Y0–Y17 in DVP-ES2 are listed in the following table.

Device	Y7	Y6	Y5	Y4	Y3	Y2	Y1	Y0
State	ON	ON	OFF	ON	OFF	OFF	ON	OFF
Value	D				2			
Device	Y17	Y16	Y15	Y14	Y13	Y12	Y11	Y10
State	OFF	OFF	OFF	OFF	OFF	ON	OFF	OFF
Value	0				4			

The following table lists the operands for the MODRW instruction.

Operand	Description	Device
S <sub>1</sub>	Unit address	16#0001
S <sub>2</sub>	Function code	16#0001
S <sub>3</sub>	Device address	16#0500
S	Register for reading and writing the data	D10.0
n	Data length	16

**ASCII mode**

You do not need to convert the ASCII codes and they are all expressed in 16# values.

- AS sends the communication command: “ : 01 01 05 00 00 10 E9 CR LF”.
- AS receives the communication command: “ : 01 01 02 D2 04 26 CR LF”.

**RTU mode**

- AS sends the communication command: “01 01 05 00 00 10 3D 0A”.
- AS receives the communication command: “01 01 02 D2 04 E4 9F”.

If the format is correct, SM100 is ON.


2. The response messages from the DVP-ES2 are stored in registers D10.0 to 10.15 (the data read is D10.15–D10.0=16#04D2).

Device	D10.7	D10.6	D10.5	D10.4	D10.3	D10.2	D10.1	D10.0
State	ON	ON	OFF	ON	OFF	OFF	ON	OFF
Value	D				2			
Device	D10.15	D10.14	D10.13	D10.12	D10.11	D10.10	D10.9	D10.8
State	OFF	OFF	OFF	OFF	OFF	ON	OFF	OFF
Value	0				4			

3. After the receiving the data sent back from the DVP-ES2, the PLC confirms the data format sent back from DVP-ES2 and determines if it is correct. If no error occurs in the format, the corresponding special flags SM100 are ON; if not SM102 is ON.

**Example 2**

- Function code 03 (16#03): the PLC reads the data from several bit devices that are not discrete input devices (eight pieces of data is read in this example). For function code 04, the operation is the same as for function code 03.



- AS Series CPU module is connected to the DVP-ES2 Series PLC.  
When SM96 and X0.0 are on, the AS Series CPU module sends and receives D32–D39 from the DVP-ES2.
- When the address of D32 is 16#1020, the values of D32–D39 in DVP-ES2 are listed in the following table.

Device	D32	D33	D34	D35	D36	D37	D38	D39
Value (16#)	1234	5678	1122	3344	5566	7788	99AA	BBCC

The following table lists the operands of the MODRW instruction.

Operand	Description	Device
<b>S<sub>1</sub></b>	Unit address	16#0001
<b>S<sub>2</sub></b>	Function code	16#0003
<b>S<sub>3</sub></b>	Device address (D32)	16#1020
<b>S</b>	Register involved for reading and writing the data	D10
<b>n</b>	Data length	8

**ASCII mode**

You do not need to convert the ASCII codes, and they are all expressed in 16# values.

- AS sends the communication command: “: 01 03 10 20 00 08 C4 CR LF”.
- AS receives the communication command: “: 01 03 10 12 34 56 78 11 22 33 44 55 66 77 88 99 AA BB CC AA CR LF”.

**RTU mode**

- AS sends the communication command: “01 03 10 20 00 08 41 06”.
- AS receives the communication command: “01 03 10 12 34 56 78 11 22 33 44 55 66 77 88 99 AA BB CC 90 FE”.

If the format is correct, SM100 is ON.


- The response messages from the DVP-ES2 is stored in registers D10 to D17.
- The following table lists the values in D10–D17.

Device	D10	D11	D12	D13	D14	D15	D16	D17
Value (16#)	1234	5678	1122	3344	5566	7788	99AA	BBCC

4. After the receiving the data sent back from the DVP-ES2, the PLC confirms the data format sent back from DVP-ES2 and determines if it is correct. If no error occurs in the format, the corresponding special flags SM100 are ON; if not SM102 is ON.

**Example 3**

- Function code 05 (16#05): the PLC writes the state into a bit device. The device is set to ON in this example.



- The AS Series CPU module is connected to the DVP-ES2 series PLC. D10.0 is ON and Y0 in the DVP-ES2 Series PLC is also ON. When SM96 and X0.0 are ON, the PLC can set the state of Y0.

The following table lists the operands for the MODRW instruction.

Operand	Description	Device
S <sub>1</sub>	Unit address	1
S <sub>2</sub>	Function code	16#0005
S <sub>3</sub>	Device address	16#0500
S	Register for reading and writing the data	D10.0
n	Data length (not used with this function code)	1

**ASCII mode**

The numbers below are only for reference. Instead of showing the values in the ASCII codes, here the expressions are shown in 16# values.

- AS sends the communication command: " : 01 05 05 00 FF 00 F6 CR LF"
- AS receives the communication command: " : 01 05 05 00 FF 00 F6 CR LF"

**RTU mode**


- AS sends the communication command: "01 05 05 00 FF 00 8C F6"
- AS receives the communication command: "01 05 05 00 FF 00 8C F6"

If the format is correct, SM100 is ON.

3. After receiving the data from the DVP-ES2, the PLC confirms the data format sent back from the DVP-ES2 and determines if it is correct. If no error occurs in the format, the corresponding special flags SM100 are ON; if not SM102 is ON.
4. When the DVP-ES2 receives this instruction, the Y0 is ON.
5. Since this function code writes data, the operand **n** is ignored.

**Example 4**

- Function code 06 (16#06): the PLC writes the state into a word device.



- AS Series CPU module is connected to the DVP-ES2 series PLC.
- Suppose D10 is 16#55AA (waiting to write data to the device T0 of the DVP-ES2).

When SM96 and X0.0 are ON, the PLC can write data to the T0 of the DVP-ES2 series PLC. The address of T0 is 16#0600.

The following table lists the operands for the MODRW instruction.

Operand	Description	Device
<b>S<sub>1</sub></b>	Unit address	1
<b>S<sub>2</sub></b>	Function code	16#0006
<b>S<sub>3</sub></b>	Device address of T0	16#0600
<b>S</b>	Register T0 for reading and writing the data	D10
<b>n</b>	Data length (not used with this function code)	0

**ASCII mode**

You do not need to convert the ASCII codes, and they are all expressed in 16# values.

- AS sends the communication command: “ : 01 06 06 00 55 AA F4 CR LF”
- AS receives the communication command: “ : 01 06 06 00 55 AA F4 CR LF”

**RTU mode**


- AS sends the communication command: “01 06 06 00 55 AA 36 6D”
- AS receives the communication command: “01 06 06 00 55 AA 36 6D”

If the format is correct, SM100 is ON.

4. After receiving the data from the DVP-ES2, the PLC confirms the data format sent back from the DVP-ES2 and determines if it is correct. If no error occurs in the format, the corresponding special flags SM100 are ON; if not SM102 is ON.
5. When the DVP-ES2 receives this instruction, it writes the data stored in the device D10 to the device T0 in the DVP-ES2.
6. Since this function code writes data, the operand **n** is ignored.

**Example 5**

- Function code 0F (16#0F): the PLC writes the states into several bit devices.



6

- AS Series CPU module is connected to the DVP-ES2 series PLC.
  - Suppose D10.15-D10.0=16#04D2 (waiting to write the state of Y0-Y17 of the DVP-ES2)

Device	D10.7	D10.6	D10.5	D10.4	D10.3	D10.2	D10.1	D10.0
State	ON	ON	OFF	ON	OFF	OFF	ON	OFF
Value	D				2			
Device	D10.15	D10.14	D10.13	D10.12	D10.11	D10.10	D10.9	D10.8
State	OFF	OFF	OFF	OFF	OFF	ON	OFF	OFF
Value	0				4			

When SM96 and X0.0 are ON, the PLC can set the state of Y0-Y17 in the DVP-ES2. The address of Y0 is 16#0500.

The following table lists the operands for the MODRW instruction.

Operand	Description	Device
S <sub>1</sub>	Unit address	1
S <sub>2</sub>	Function code	16#000F
S <sub>3</sub>	Device address of Y0	16#0500
S	Registers Y0–Y17 for reading and writing the data	D10.0
n	Data length	16

#### ASCII mode

You do not need to convert the ASCII codes, and they are all expressed in 16# values.

- AS sends the communication command: “ : 01 0F 0500 0010 02 D2 04 03 CR LF”
- AS receives the communication command: “ : 01 0F A0 00 00 10 40 CR LF”

#### RTU mode

- AS sends the communication command: “01 0F 05 00 00 10 02 D2 04 EA 43”
- AS receives the communication command: “01 0F A0 00 00 10 76 07”

If the format is correct, SM100 is ON.


3. After receiving the data sent back from the DVP-ES2, the PLC confirms the data format sent back from the DVP-ES2 and determines if it is correct. If no error occurs in the format, the corresponding special flags SM100 are ON; if not SM102 is ON.

Device	Y7	Y6	Y5	Y4	Y3	Y2	Y1	Y0
State	ON	ON	OFF	ON	OFF	OFF	ON	OFF
Value	D				2			
Device	Y17	Y16	Y15	Y14	Y13	Y12	Y11	Y10
State	OFF	OFF	OFF	OFF	OFF	ON	OFF	OFF
Value	0				4			

4. Since this function code writes data, the operand **n** is ignored.

**Example 6**

- Function code 10 (16#10): the PLC writes the states into several word devices.



- AS Series CPU module is connected to the DVP-ES2 series PLC.
- Suppose the values for D20–27 are listed in the following table (waiting to write data to the devices T0–7 of the DVP-ES2).

Device	D20	D21	D22	D23	D24	D25	D26	D27
Value (16#)	1234	5678	1122	3344	5566	7788	99AA	BBCC

When SM96 and X0.0 are ON, the PLC can write data to the T0–7 in the DVP-ES2 series PLC. The address of T0 is 16#0600.

The following table lists the operands of the MODRW instruction.

Operand	Description	Device
S <sub>1</sub>	Unit address	1
S <sub>2</sub>	Function code	16#0010
S <sub>3</sub>	Device address of T0	16#0600
S	Register T0–7 for reading and writing the data	D20
n	Data length (not used with this function code)	8

**ASCII mode**

You do not need to convert the ASCII codes, and they are all expressed in 16# values.

- AS sends the communication command: “ : 01 10 0600 00 08 10 1234 5678 1122 3344 5566 7788 99AA BBCC 8F CR LF”
- AS receives the communication command: “ : 01 10 06 00 00 08 E1 CR LF”

**RTU mode**

- AS sends the communication command: “01 10 06 00 00 08 10 1234 5678 1122 3344 5566 7788 99AA BBCC 0B 0C”
- AS receives the communication command: “01 10 06 00 00 08 C1 47”

If the format is correct, SM100 is ON.

5. After receiving the data sent back from the DVP-ES2, the PLC confirms the data format sent back from the DVP-ES2, and determines if it is correct. If no error occurs in the format, the corresponding special flags SM100 are ON; if not SM102 is ON. When the DVP-ES2 receives this instruction, it writes data stored in the devices D20–27 to the device T0–7 in the DVP-ES2.

Device	T0	T1	T2	T3	T4	T5	T6	T7
Value (16#)	1234	5678	1122	3344	5566	7788	99AA	BBCC

6. Since this function code writes data, the operand **n** is ignored.

**Additional remarks**

1. If the value in **S**<sub>1</sub> or **S**<sub>2</sub> exceeds the range, an operation error occurs, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2003.
2. If the device specified by **S** is not sufficient to contain the **n** pieces of data, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2003.
3. If **n** exceeds the range, an operation error occurs, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#200B.
4. If the function code specified by **S**<sub>2</sub> is related to bit devices, the device specified by **S** must be a bit device; otherwise, an operation error occurs, the instruction is not executed, and the error code in SR0 is 16#2003.
5. If the function code specified by **S**<sub>2</sub> is related to word devices, the device specified by **S** must be a word device; otherwise, an operation error occurs, the instruction is not executed, and the error code in SR0 is 16#2003.

6. If the communication command is 0x05 or 0x06, the value in **n** can be ignored. The length of the data is only one bit or one word.
7. The MODRW instruction is not executed if the sending flags SM96 and SM97 are not ON.
8. If a communication timeout occurs, the timeout flags SM104 and SM105 are ON, and the receiving flags SM98 and SM99 are OFF.
9. If an error occurs while receiving data, the error flags SM102 and SM103 are ON, and the receiving flags SM98 and SM99 are OFF.
10. If the function code specified by **S<sub>2</sub>** is related to word devices, the device in the external equipment with which the PLC communicates must be a word device. If the function code specified by **S<sub>2</sub>** is related to bit devices, the device in the external equipment with which the PLC communicates must be a bit device.
11. Please refer to section 6.19.3 for more details on communication register setups (SM, SR).



If **S<sub>2</sub>** is D100 and **S<sub>3</sub>** is 10, the instruction sends the values in the low bytes in D100–D109 through the communication port specified by **S<sub>1</sub>**.

4. No strings are sent if the setting value in **S<sub>3</sub>** is 0. The maximum number of characters that can be sent is 256 words.
5. **D<sub>1</sub>** is the length of the data that is received.

**D<sub>1+1</sub>–D<sub>1+n</sub>** are the devices to store the data that is received

If **D<sub>1</sub>** is D200, the value in **D<sub>2</sub>** is 3, and the value in **D<sub>2+1</sub>** is 16#0D0A, the instruction stores data received in the low bytes in the devices starting from D201 (the high bytes is unchanged) The instruction continues to receive data until it receives the consecutive stop characters 16#0D and 16#0A. The instruction writes the length of the data received to D200 after receiving 16#0D and 16#0A, and sets a completion flag to ON after the receiving data stops.

6. **D<sub>2</sub>** is the mode for receiving data

**D<sub>2+1</sub>** is the condition that ends receiving of data

**D<sub>2</sub>** and **D<sub>2+1</sub>** are described in the following table.

<b>D<sub>2</sub></b>	<b>Mode for receiving data</b>	<b>Setting value in D<sub>2+1</sub></b>	<b>Remark</b>
0	Not receiving communication data	Unused	After the sending of data is complete, set a completion flag to ON.
1	When the time after the last piece of data received exceeds the time set in <b>D<sub>2+1</sub></b> , the receiving of data is complete.	The setting value in <b>D<sub>2+1</sub></b> is time. The unit of measurement is 1 millisecond. The setting value in <b>D<sub>2+1</sub></b> is between 5–3000.	If the time that you set is greater than 3000 milliseconds, the value in <b>D<sub>2+1</sub></b> is 3000. If the time that you set is less than 5 milliseconds, the value in <b>D<sub>2+1</sub></b> is 5.
2	The data received ends with a specific character.	The setting value in <b>D<sub>2+1</sub></b> is a specific character.	If a specific character is 16#0A, the value in <b>D<sub>2+1</sub></b> is 16#000A.
3	The data received ends with two consecutive specific characters.	The setting value in <b>D<sub>2+1</sub></b> is two specific characters.	If two specific characters are 16#0D and 16#0A, the value in <b>D<sub>2+1</sub></b> is 16#0D0A.
4	The data received starts with a specific character. When the time after the last piece of data	A specific character is stored in the high byte in <b>D<sub>2+1</sub></b> , and the time is stored in the low byte in	If a start character is 16#3A, and time is 15 milliseconds, the value in <b>D<sub>2+1</sub></b> is 16#3A0F.

	is received exceeds the time set in $D_{2+1}$ , the receiving of data is complete.	$D_{2+1}$ . The time set in the low byte in $D_{2+1}$ is in the range of 5–255 milliseconds.	
5	The data received starts with a specific character, and ends with a specific character.	The setting value in $D_{2+1}$ is a specific start character, and a specific end character.	If a start character is 16#3A, and a stop character is 16#0A, the value in $D_{2+1}$ is 16#3A0A.
6	A specific quantity of data is received.	The setting value in $D_{2+1}$ is the length of the data to receive. The setting value is between 1–256.	If you want to receive 10 characters, set the value in $D_{2+1}$ to 10.
7	The data received ends with a specific character and generates communication interrupts.	The setting value in $D_{2+1}$ is a specific end character.	If an end character is 16#0A, the value in $D_{2+1}$ is 16#000A.
8	Set the quantity of data received and then generate communication interrupts.	The setting value in $D_{2+1}$ is the length of the data received. The setting value is between 1–256.	If you want to receive 10 characters, set the value in $D_{2+1}$ to 10.
9	The data received ends with a specific character or a specific quantity of data received; when either condition is met, the transmission is complete.	A specific end character is stored in the high byte in $D_{2+1}$ , and the time is stored in the low byte in $D_{2+1}$ . The time set in the low byte in $D_{2+1}$ must be between 1–255 milliseconds.	If an end character is 16#0A, and time is 15 milliseconds, the data length is 15 words, the value in $D_{2+1}$ is 16#0A0F.
Others	If the mode used is not supported, the instruction is not executed.		


7. Except for mode 6 and 8, when data received in  $D_2$  exceeds the maximum range of the received data length (256 words) and no ending character is received, the instruction stops executing and treats this operation as a receiving error.  $D_{1+0}$  is 0 and  $D_{1+1}$ – $D_{1+n}$  do not store the received data.
8. The interactions among the communication port, the related special auxiliary relays, and the related special data register are described in Section 6.19.3.

9. Timing diagrams

- Mode for receiving data: 0

When data is sent, you cannot cancel the sending of data. If the conditional contact preceding the instruction is not enabled, the data will still be sent, but the completion flag will not be set to ON after sending of the data is complete.


- Mode for receiving data: 1 or 4



Description:

- ① → Start/stop the execution of the instruction.
- ② → Time during which data is sent. The period of time in which data is sent is not measured.
- ③ → After the first character is received, the time that passes before the next character is received is measured. Whenever a character is received, the instruction clears the time measured. The completion flag is not be set to ON until the time measured is greater than the setting value in  $D_2+1$ .
- ④ → If the instruction is still enabled after you reset the completion flag or the communication flag, the next communication data is sent automatically when the instruction is scanned in the next cycle.
- ⑤ → When the PLC begins to receive data, it begins to measure the time that passes. It does not set the communication timeout to ON until the time measured exceeds the timeout period. It is suggested that you set the timeout period to be longer than the time set in  $D_2+1$ .

- Mode for receiving data: 2, 3, 5, 6, or 9.



Description:

- ① → Start/stop the execution of the instruction.
- ② → Time during which data is sent. The period of time in which data is sent is not measured.
- ③ → After the first character is received, the time that passes before the next character is received is measured. Whenever a character is received, the instruction clears the time measured. The communication timeout flag is not set to ON until the time measured exceeds the timeout period.
- ④ → If the instruction is still enabled after you reset a completion flag or a communication flag, the next communication data is sent automatically when the instruction is scanned in the next cycle.

10. Mode for sending data / Mode for receiving data

8-bit mode: The command that is edited is stored in the initial transmission device, and the command to be sent includes the head code and the tail code. The instruction divides the 16-bit data into the high 8-bit data and the low 8-bit data. The instruction ignores the high 8-bit data, and can send or receive the low 8-bit data can be sent or received. Take standard Modbus for example.

Sending the data: (PLC→external equipment)

D10 Low	D11Low	D12Low	D13Low	D14Low	D15 Low	D16Low
Head code		Initial transmission device: The low 8-bit data in D10			Tail code 1 Tail code 2	
Length=7						

Receiving the data: (External equipment→PLC)

D100Low	D101Low	D102Low	D103Low	D104Low	D105Low	D106Low
Head code	Initial reception device: The low 8-bit device in D100				Tail code 1 Tail code 2	
	Length=7					

16-bit mode: The command that is edited is stored in the initial transmission device, and the command to be sent includes the head code and the tail code. When SM106/SM107 is OFF, the instruction divides the 16-bit data into the high 8-bit data and the low 8-bit data.

Sending the data: (PLC→external equipment)

D10Low	D10High	D11Low	D11High	D12Low	D12High	D13Low
Head code	Initial transmission device: The low 8-bit data in D10				Tail code 1 Tail code 2	
	Length=7					

Receiving the data: (External equipment→PLC)

D100Low	D100High	D101Low	D101High	D102Low	D102High	D103Low
Head code	Initial reception device: The low 8-bit device in D100				Tail code 1 Tail code 2	
	Length=7					

The data that the PLC receives from the external equipment includes the head and the tail code; therefore, you have to be aware of the setting for the length.

11. When the mode is 7 or 8, the corresponding communication port and the interrupt number are listed in the following table.


Communication port number	COM1	COM2	Card1	Card2
Interruption number	I300	I302	I304	I306

12. The instruction cannot be used in the ST programming language, interrupt tasks or function block which is called only once.

The following examples use COM1 (RS485).

### Example 1


The mode in **D<sub>2</sub>** is 0 (not receiving communication data) and you set the mode for sending and receiving data to 8-bit mode (SM106=ON).



1. The length for the data to be sent: D20=4.
2. The contents for the data to be sent: D100=16#0031, D101=16#0032, D102=16#0033, D103=16#0034.
3. Set D10=16#0000 (sending data only, not receiving data).
4. Enable the contact X0.0.
5. The PLC sends 4 pieces of data.
6. Sending data: PLC→external equipment 31 32 33 34.
7. Since receiving data is not required, after the PLC sends out the data, the operation ends, and SM100=0.
8. To send more data, set the flag SM100 to OFF to start the operation again.

**Example 2**

The mode in **D<sub>2</sub>** is 1 (setting the timeout value to 5–3000 ms) and you set the mode for sending and receiving data to 16-bit mode (SM106=OFF).




1. The length for the data to be sent: D20=4.
2. The contents for the data to be sent: D100=16#3231, D101=16#3433.
3. Set D10=16#0001 (mode: 1), D11=300 (set the timeout value to 300 ms).
4. Enable the contact X0.0.
5. PLC sends 4 pieces of data.
6. Sending data: PLC→external equipment 31 32 33 34.
7. After the external equipment receives the data from the PLC, it sends 5 consecutive data to the PLC, each sent in less than 20 ms. External equipment→PLC 35 36 37 38 39.
8. D200=5 (number of data received), and the content of data received: D201=16#3635, D202=16#3837, D203=16#0039.
9. SM100=ON: reception of data is complete.
10. To send more data, set the flag SM100 to OFF to start the operation again.

NOTE: When the sending of data is complete, the receiving flag SM98 is ON, and then the PLC starts to receive data.

You set the timeout between each data reception in D11. When the interval time exceeds the set timeout and no data is received, SM100 is ON.

**Example 3**

The mode in **D<sub>2</sub>** is 2 (the data received ends with a specific character.) and you set the mode of sending and receiving data to 8-bit mode (SM106=ON).



1. Set the length of the data to be sent: D20=0, meaning the PLC will not send data but only receives data.
2. Set D10=16#0002 (mode: 2), D11=16#000A (the ending character is 16#0A).
3. Enable the contact X0.0.
4. The PLC waits to receive data from the external equipment. D20=0 means that the PLC does not send data to the external equipment.
5. The external equipment sends data to the PLC.

External equipment → PLC 31 32 33 34 35 0A.


6. D200=6 (number the data received), the content of data received: D201=16#0031, D202=16#0032, D203=16#0033, D204=16#0034, D205=16#0035, D206=16#000A
7. SM100=ON: reception of data is complete.
8. To send more data, set the flag SM100 to OFF to start the operation again.

**NOTE:** When the sending of data is complete, the receiving flag SM98 is ON and then the PLC starts receiving data until receiving the ending character (16#0A). When the reception of data is complete, SM100 is ON. If the communication timeout occurs but the ending character (16#0A) is still not received, the communication timeout flag SM104 is ON.

**Example 4**

The mode in **D<sub>2</sub>** is 3 (the data received ends with two specific characters.) and you set the mode for sending and receiving data to 16-bit mode (SM106=OFF).

This example uses a DVP-ES2 as the external equipment and writes H1234 to D100 in the DVP-ES2.



1. The length for the data to be sent: D20=17.
2. The contents for the data to be sent: D100=16#303A, D101=16#3031, D102=16#3136, D103=16#3630, D104=16#3134, D105=16#3332, D106=16#3334, D107=16#0D46, D108=16#000A.
3. Set D10=16#0003 (mode: 3), D11=16#0D0A (the ending characters are 16#0D and 16#0A).
4. Enable the contact X0.0.
5. The PLC sends 17 pieces of data.

Sending data: PLC→external equipment 3A 30 31 30 36 31 30 36 34 31 32 33 34 33 46 0D 0A

(ASCII code: 0106106412343FCRLF)

6. The external equipment receives the data from the PLC and the last 2 data are 16#0D and 16#0A.

External equipment → PLC 3A 30 31 30 36 31 30 36 34 31 32 33 34 33 46 0D 0A


(ASCII code: 0106106412343FCRLF)

7. D200=17 (number of the data received), and the content of the received data: D201=16#303A, D202=16#3031, D203=16#3136, D204=16#3630, D205=16#3134, D206=16#3332, D207=16#3334, D208=16#0D46, D209=16#000A.
8. SM100=ON: reception of data is complete.
9. To send more data, set the flag SM100 to OFF to start the operation again.

NOTE: When sending of data is complete, the receiving flag SM98 is ON and then the PLC starts receiving data until it receives the ending character (16#0D0A). When the reception of data is complete, SM100 is ON. If the communication timeout occurs but the ending character (16#0D0A) is still not received, the communication timeout flag SM104 is ON.

**Example 5**

The mode in **D<sub>2</sub>** is 4 (the data received starts with a specific character and you set the timeout value to 5–255 ms.) and you set the mode of sending and receiving data to 8-bit mode (SM106=ON).



1. The length for the data to be sent: D20=4.
2. The contents for the data to be sent: D100=16#0031, D101=16#0032, D102=16#0033, D103=16#0034.
3. Set D10=16#0004 (mode: 4), D11=16#3A0F (the starting character is 16#3A and set the time value to 16#0F, meaning 15ms).
4. Enable the contact X0.0.
5. The PLC sends 4 pieces of data.  
Sending data: PLC→external equipment 31 32 33 34
6. The external equipment receives data from the PLC and then sends 7 consecutive words to the PLC with an interval of 1 ms between each sending.  
External equipment → PLC 30 3A 35 36 37 38 39
7. D200=6 (number of the data received), and the content of the received data: D201=16#003A, D202=16#0035, D203=16#0036, D204=16#0037, D205=16#0038, D206=16#0039.
8. SM100=ON: reception of data is complete.
9. To send more data, set the flag SM100 to OFF to start the operation again.


**NOTE:** When the sending of data is complete, the receiving flag SM98 is ON and then the PLC is ready to receive data.

When the PLC receives the starting character 16#3A, it starts receiving data. The interval timeout between receiving each piece of data is set in D11. When the interval time exceeds the set timeout 16#0F (15 ms) and no data is coming in, SM100 is ON.

**Example 6**

The mode in **D<sub>2</sub>** is 5 (the data received starts and ends with a specific character) and you set the mode of sending and receiving data to 16-bit mode (SM106=OFF).

The example uses a DVP-ES2 as the external equipment and reads data from D100 in the DVP-ES2.



1. The length for the data to be sent: D20=17.
2. The contents for the data to be sent: D100=16#303A, D101=16#3031, D102=16#3133, D103=16#3630, D104=16#3034, D105=16#3030, D106=16#3831, D107=16#0D37, D108=16#000A
3. Set D10=16#0005 (mode: 5), D11=16#3A0A (the starting character is 16#3A and the ending character is 16#0A).
4. Enable the contact X0.0.
5. The PLC sends 17 pieces of data.


Sending data: PLC→external equipment 3A 30 31 30 36 31 30 36 34 31 32 33 34 33 46 0D 0A  
 (ASCII code: 0106106412343FCRLF)

6. The external equipment receives data from the PLC and the last 2 data are 16#0D and 16#0A.  
 External equipment → PLC 3A 30 31 30 36 31 30 36 34 31 32 33 34 33 46 0D 0A  
 (ASCII code: 0106106412343FCRLF)
7. D200=15 (number of the data received), and the content of the received data: D201=16#303A, D202=16#3031, D203=16#3033, D204=16#3132, D205=16#3332, D206=16#4234, D207=16#0D34, D208=16#000A.
8. SM100=ON: reception of data is complete.
9. To send more data, set the flag SM100 to OFF to start the operation again.

**NOTE:** When the data sending is complete, the receiving flag SM98 is ON and then the PLC is ready to receive data. When the PLC receives the starting character 16#3A, it starts receiving data until receiving the ending character 16#0A, and SM100 is ON. If the communication timeout occurs but the starting character 16#3A or the ending character 16#0A is still not received, the communication timeout flag SM104 is ON.

**Example 7**

The mode in **D<sub>2</sub>** is 6 (the received data length) and you set the mode of sending and receiving data to 8-bit mode (SM106=ON).



1. The length for the data to be sent: D20=4.
2. The contents for the data to be sent: D100=16#0031, D101=16#0032, D102=16#0033, D103=16#0034.
3. Set D10=16#0006 (mode: 6), D11=16#0008 (8 pieces of data to be received).
4. Enable the contact X0.0.
5. The PLC sends out 4 pieces of data.

Sending data: PLC → external equipment 31 32 33 34

6. The external equipment receives data from the PLC and then sends 8 consecutive data to the PLC.

External equipment → PLC 32 33 34 35 36 37 38 39


7. D200=8 (number of the data received), and the content of the received data: D201=16#0032, D202=16#0033, D203=16#0034, D204=16#0035, D205=16#0036, D206=16#0037, D207=16#0038, D208=16#0039.
8. SM100=ON: reception of data is complete.
9. To send more data, set the flag SM100 to OFF to start the operation again.

NOTE: When the data sending is complete, the receiving flag SM98 is ON and then the PLC is ready to receive data.

When receiving a set quantity of data, the SM100 is ON. If the communication timeout occurs but the set quantity of data is still not received, the communication timeout flag SM104 is ON.

**Example 8**

The mode in **D<sub>2</sub>** is 7 (the data received ends with a specific character and generates communication interrupts) and you set the mode of sending and receiving data to 8-bit mode (SM106=ON).



Communication interrupt programs:




1. Clear the interrupt: D30=0.
2. The length for the data to be sent: D20=4.
3. The contents for the data to be sent: D100=16#0031, D101=16#0032, D102=16#0033, D103=16#0034.
4. Set D10=16#0007 (mode: 7), D11=16#000A (16#0A is the ending character).
5. Enable the contact X0.0.
6. The PLC sends out 4 pieces of data.  
Sending data: PLC→external equipment 31 32 33 34
7. D30=0 (the programs in the interrupt are not executed).
8. The external equipment sends data to the PLC.  
External equipment → PLC 31 32 33 34 35 0A
9. D200=6 (number of the data received), and the content of the received data: D201=16#0031, D202=16#0032, D203=16#0033, D204=16#0034, D205=16#0035, D206=16#000A.
10. SM100=ON: reception of data is complete.
11. D30=1 (the interrupt is triggered and then INC D30 is executed).
12. To send more data, set the flag SM100 to OFF to start the operation again.

NOTE: When the data sending is complete, the receiving flag SM98 is ON and then the PLC is ready to receive data.

When receiving the set ending character (16#06), SM100 is ON. If the communication timeout occurs but the set ending character is still not received, the communication timeout flag SM104 is ON.

**Example 9**

The mode in **D<sub>2</sub>** is 8 (the set quantity of data is received and generates communication interrupts) and you set the mode of sending and receiving data to 8-bit mode (SM106=ON).



Communication interrupt programs:




1. Clear the interrupt: D30=0
2. The length for the data to be sent: D20=4.
3. The contents for the data to be sent: D100=16#0031, D101=16#0032, D102=16#0033, D103=16#0034.
4. Set D10=16#0008 (mode: 8), D11=16#0008 (8 pieces of data to be received).
5. Enable the contact X0.0.
6. The PLC sends out 4 pieces of data.  
Sending data: PLC→external equipment 31 32 33 34
7. D30=0 (the programs in the interrupt are not executed).
8. The external equipment receives data from the PLC and then sends 8 consecutive data to the PLC.
9. External equipment → PLC 32 33 34 35 36 37 38 39
10. D200=8 (number of the data received), and the content of the received data: D201=16#0032, D202=16#0033, D203=16#0034, D204=16#0035, D205=16#0036, D206=16#0037, D207=16#0038, D208=16#0039.
11. SM100=ON: reception of data is complete.
12. D30=1 (the interrupt is triggered and then the INC D30 is executed).
13. To send more data, set the flag SM100 to OFF to start the operation again.

NOTE: When the data sending is complete, the receiving flag SM98 is ON and then the PLC is ready to receive data.

When receiving the set quantity of data, SM100 is ON. If the communication timeout occurs but the set quantity of data is still not received, the communication timeout flag SM104 is ON.

**Example 10**

The mode in **D<sub>2</sub>** is 9 (the set ending character or the set quantity of data is received) and set the mode of sending data/mode of receiving data to 8-bit mode (SM106=ON).



1. The length for the data to be sent: D20=4.
2. The contents for the data to be sent: D100=16#0031, D101=16#0032, D102=16#0033, D103=16#0034.
3. Set D10=16#0009 (mode: 9), D11=16#0A0F (the ending character is 16#0A and the set data length is 16#0F).
4. Enable the contact X0.0.
5. The PLC sends out 4 pieces of data.  
Sending data: PLC→external equipment 31 32 33 34
6. The external equipment receives data from the PLC and then sends 15 pieces of data to the PLC.  
External equipment → PLC 31 32 33 34 35 0A 41 42 43 44 45 46 47 48 49
7. D200=6 (number of the data received), and the content of the received data: D201=16#0031, D202=16#0032, D203=16#0033, D204=16#0034, D205=16#0035, D206=16#000A.  
The PLC stops receiving data after the 6<sup>th</sup> piece of data is received.
8. SM100=ON: reception of data is complete.
9. To send more data, set the flag SM100 to OFF to start the operation again.

**NOTE:** When the data sending is complete, the receiving flag SM98 is ON and then the PLC is ready to receive data.

When receiving the set ending character or the set quantity of data, the SM100 is ON. If the communication timeout occurs but the set ending character or the set quantity of data is still not received, the communication timeout flag SM104 is ON.

**Additional remarks**

1. There is no limit on the number of times you can execute the COMRS communication instruction. However, each communication port can only be enabled by one communication instruction, and the later communication instructions that follow are not executed.
2. The instruction does not use checksum when you execute this instruction. If you need a checksum, use COMRS and another available instruction.
3. If the value in **D<sub>2</sub>** is 2, 3, 5, 6 or 9, it is suggested that you set a timeout period. After you set a timeout period, the instruction tries to send the data again if a stop character is not received.
4. The instruction does not automatically clear the value in **D<sub>1</sub>–D<sub>1</sub>+n** whenever the instruction is executed or the PLC begins to receive new communication data. You can know whether and how much data the PLC receives only after a completion flag switches from OFF to ON. If you want to clear the values in **D<sub>1</sub>–D<sub>1</sub>+n**, use the ZRST instruction (API 1206).
5. If the value in **S<sub>1</sub>** is out of range, the instruction is not executed.
6. If the number of devices starting from **S<sub>2</sub>** is not equal to the value in **S<sub>3</sub>**, the instruction is executed, SM0 is ON, and the error code in SR0 is 16#2003.
7. If the value in **D<sub>2</sub>** is not between 0–9, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#200B.
8. If the value in **D<sub>2</sub>** is 6, 8 or 9, and the number of devices starting from **D<sub>1</sub>** is not equal to the value in **D<sub>2</sub>+1**, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2003.
9. If the quantity of data received is greater than the number of devices starting from **D<sub>1</sub>**, the data that cannot be stored is ignored.
10. If a completion flag is ON, the PLC stops receiving data. If a communication port receives data when a completion flag is ON, the data is not received.
11. If the setting value in **S<sub>3</sub>** is not between 0–256, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#200B.
12. When the mode of **D<sub>2</sub>** is 6 or 8, the length of **D<sub>2</sub>+1** not between 1–256, the instruction is not executed. SM0 is ON, and the error code in SR0 is 16#200B.

API	Instruction code			Operand					Function				
1813	COMDF	P		<b>S<sub>1</sub>, S<sub>2</sub>, S<sub>3</sub>, S<sub>4</sub>, S<sub>5</sub>, D</b>					Setting the communication format for a serial communication port				

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
S <sub>1</sub>													○	○		
S <sub>2</sub>													○	○		
S <sub>3</sub>													○	○		
S <sub>4</sub>													○	○		
S <sub>5</sub>													○	○		
D													○	○		

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
S <sub>1</sub>													
S <sub>2</sub>													
S <sub>3</sub>													
S <sub>4</sub>													
S <sub>5</sub>													
D													

Pulse instruction	16-bit instruction	32-bit instruction
AS	AS	-

6

**Symbol**

COMDF	COMDFP
En	En
S <sub>1</sub>	S <sub>1</sub>
S <sub>2</sub>	S <sub>2</sub>
S <sub>3</sub>	S <sub>3</sub>
S <sub>4</sub>	S <sub>4</sub>
S <sub>5</sub>	S <sub>5</sub>
D	D

- S<sub>1</sub>** : Baud Rate (Unit:100 bps)
- S<sub>2</sub>** : Number of data bits
- S<sub>3</sub>** : Parity bit
- S<sub>4</sub>** : Number of end bits
- S<sub>5</sub>** : Modbus format selection
- D** : Communication port number

**Explanation**

1. This instruction provides a way to directly set the parameter values, instead of declaring variables.
2. **S<sub>1</sub>** sets the baud rate with the units 100 bps. For example, a value 96 indicates 9600 bps.
3. **S<sub>2</sub>** sets the number of data bits. The value 7 indicates 7 data bits and 8 indicates 8 data bits. If the value is not 7 or 8 in **S<sub>2</sub>**, the instruction uses the default value.


4. **S<sub>3</sub>** sets the parity bit. The value 0 indicates None (no parity bit). The value 1 indicates Odd bit checking. The value 2 corresponds to Even bit checking. If the value in **S<sub>3</sub>** is not 0, 1 or 2, the instruction uses the default value.
5. **S<sub>4</sub>** sets the number of end bits. The value 1 (preset) indicates 1 bit. The value 2 indicates 2 bits. If the value in **S<sub>4</sub>** is not 1 or 2, the instruction uses the default value.
6. **S<sub>5</sub>** sets the communication mode for Modbus communication. The value 0 indicates ASCII (default value). The value of 1 indicates RTU. If the value in **S<sub>5</sub>** is not 0 or 1, the instruction uses the default value.
7. **D** sets communication port number. The number for COM1 is 1, COM2 is 2, Card1 is 11 and Card2 is 12. If the setting value is out of the valid range, the instruction does not set the communication port format.
8. You can also directly set the communication port in HWCONFIG in ISPSOft (COM Port settings) or with the special registers. For more on in HWCONFIG, see the ISPSOft user manual. Refer to Section 6.19.3 for setting the communication-related SR and SM registers.
9. The communication at the actual communication port changes immediately after you change the setting of the instruction. If some communication is being carried out at the moment, it is forced to cancel. Additionally, the corresponding setting value in SM/SR changes accordingly. For details on SM/SR, refer to Section 6.19.3.
10. This instruction does not change any setting for the actual communication port when the communication format setting is the same as the previous setting.

### Example

1. This example uses the PLC COM1 port. Other PLC communication ports are similar in the way you set up the communication.
2. The contact for the start condition is X0.0.
3. Set the (RS485) communication format of PLC COM1 to 115200, 8, E and 1.
4. Set the (RS485) communication mode of PLC COM1 to ASCII.
5. The following table explains the COMDF operands for the example.

Operand	Description		Content value
<b>S<sub>1</sub></b>	Baud Rate	115200 bps	1152
<b>S<sub>2</sub></b>	Number of data bits	8	8
<b>S<sub>3</sub></b>	Parity bit	E	2
<b>S<sub>4</sub></b>	Number of end bits	1	1

<b>S5</b>	Mobdus format selection	ASCII	0
<b>D</b>	Communication port number	PLC COM1	1



API	Instruction code			Operand							Function						
1814		VFDRW		<b>S<sub>1</sub>, S<sub>2</sub>, S<sub>3</sub>, S</b>							Serial communication instruction exclusive for Delta AC motor drive						

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
<b>S<sub>1</sub></b>								●	●		○	○	○	○		
<b>S<sub>2</sub></b>								●	●		○	○	○	○		
<b>S<sub>3</sub></b>								●	●		○	○	○	○		
<b>S</b>								●								

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
<b>S<sub>1</sub></b>		●				●							
<b>S<sub>2</sub></b>		●				●							
<b>S<sub>3</sub></b>		●				●							
<b>S</b>		●				●							

Pulse instruction	16-bit instruction	32-bit instruction
-	AS	-

### Symbol

VFDRW
En
S1
S2
S3
S

- S<sub>1</sub>** : Communication port number
- S<sub>2</sub>** : VFD station address
- S<sub>3</sub>** : Function code
- S** : Source and received data

### Explanation


- S<sub>1</sub>** sets the communication port number. The number for COM1 is 1, COM2 is 2, Card1 is 11 and Card2 is 12. If the value exceeds the valid range, the instruction does not receive any communication data.
- S<sub>2</sub>** sets the station address for the VFD AC motor drive. 0 indicates that the instruction uses the broadcast mode. The range is between 0–254, and the instruction is not executed if this value is out of the valid range.

3. **S<sub>3</sub>** is the communication function code, and **S** is the source or received data as explained in the following table.

<b>S<sub>3</sub></b> function code	<b>S<sub>3</sub></b> function name	<b>S</b> source and received data	Remark
0	Reset due to abnormality	Unused	Any value can be stored in <b>S</b> .
1	Clockwise running command	Velocity value	Refer to AC motor drive user manual for the setting value and the unit.
2	Counterclockwise running command	Velocity value	
3	Stop	Unused	Any value can be stored in <b>S</b> .
4	Jog clockwise running command	Unused	Refer to AC motor drive user manual for setting the jog velocity.
5	Jog counterclockwise running command	Unused	
6	Reading the state	Received state values	Refer to AC motor drive user manual for the meaning of the state values of the 5 bit addresses H2100–H2104 for VFD.

6

4. The following chart shows the timing for sending and receiving data.



Description:


- ① → Start or stop the execution of the instruction.
  - ② → Transmitting data begins. During this time, the communication timeout time is not measured.
  - ③ → The reception flag is set. From the moment when the first character is received to the moment when the next character is received, the period of time is measured. Whenever a character is received, the measured time is cleared to 0. The instruction generates the communication timeout flag if the time measured is greater than the communication timeout setting value.
  - ④ → When receiving of data is complete, the instruction sets the completion flag. You must clear the flag before receiving more data.
  - ⑤ → The instruction is stopped for one cycle after the completion flag is set. Then the instruction can be started in the next cycle.
5. There is no limit to the number of times the instruction can be executed. The instruction can use only one communication port for the output and execution of one communication instruction each time. If receiving and sending data is complete, you must disable the instruction to correctly release the communication control.
  6. The instruction cannot be used in the ST programming language, interrupt tasks or function block which is called only once.

#### **Example of setting the communication protocol**

1. Set the PLC COM1 (RS485) port with station address 2 and the communication format in HWCONFIG with these values: ASCII, 115200, 7, N, 2.
2. Set the motor drive parameters using the panel on the Delta C2000 AC motor drive according to the following steps.
  - A. Set 09-00 to 1: the station address of the AC motor drive is set to 1.
  - B. Set 09-01 to 115.2: RS485 baud rate of the AC motor drive is 115200.
  - C. Set 09-04 to 1: RS485 communication format of the AC motor drive is 7, N, 2.
  - D. Set 09-20 to 1: the frequency instruction is input through RS485.
  - E. Set 09-21 to 2: the running instruction is input through RS485.

**Example**

Use the VFDRW instruction to control the velocity: make the VFD run forward at the frequency of 120Hz, then run in reverse at the frequency of 180Hz, and then stop running.



1. Connect AS COU to VFD.

Set D202=12000 initially. When M1 is ON, VFD starts to accelerate after receiving the clockwise running command, and runs clockwise at 120Hz.

2. Set D204=18000 initially. When M2 is ON, VFD starts to decelerate until it stops after receiving the counterclockwise running command, and runs counterclockwise at 180Hz.

3. When M3 is ON (at this time, the value in D206 is ignored), VFD decelerates to stop after receiving the stop command.
4. When M4 is ON, the instruction reads the values of H2100–H2104 of VFD and stores them in D220–224.

Device	D220	D221	D222	D223	D224
Content	Error code	VFD state	Frequency command	Output frequency	Output current

The state of the VFD:

Bit2=1 causes the VFD to execute the Jog command. Bit4–3=11B causes the VFD to run counterclockwise. The frequency command is 18000, and causes the VFD to run at 180Hz. For the definitions of the parameter addresses in the communication protocol, refer to the Delta AC Motor Drive user manual.

5. The reception completion flag SM100 is ON, and the values of M1–M5 are cleared to avoid interfering with the next communication command.

After receiving the data that the VFD sends back, the instruction checks the format of the data sent back from VFD. If the data format is correct, SM100 is ON; otherwise, SM102 is ON.

API	Instruction code			Operand					Function				
1815		ASDRW		<b>S<sub>1</sub>, S<sub>2</sub>, S<sub>3</sub>, S</b>					Serial communication instruction exclusive for Delta servo drive				

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
<b>S<sub>1</sub></b>								●	●		○	○	○	○		
<b>S<sub>2</sub></b>								●	●		○	○	○	○		
<b>S<sub>3</sub></b>								●	●		○	○	○	○		
<b>S</b>								●								

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
<b>S<sub>1</sub></b>		●				●							
<b>S<sub>2</sub></b>		●				●							
<b>S<sub>3</sub></b>		●				●							
<b>S</b>		●				●							

Pulse instruction	16-bit instruction	32-bit instruction
-	AS	-

**Symbol**

ASDRW
En
S <sub>1</sub>
S <sub>2</sub>
S <sub>3</sub>
S

- S<sub>1</sub>** : Communication port number
- S<sub>2</sub>** : Station address of the servo
- S<sub>3</sub>** : Function code
- S** : Source and received data

**Explanation**


1. **S<sub>1</sub>** sets the communication port number. The number for COM1 is 1, COM2 is 2, Card1 is 11 and Card2 is 12. If the value exceeds the valid range, the instruction does not receive any communication data.
2. **S<sub>2</sub>** sets the station address for the servo. 0 indicates that the instruction uses the broadcast mode. The range of the value is between 0–254. The instruction is not executed if the value is out of the valid range.
3. Refer to Delta Servo Operation manual for details on servo parameters.
4. **S<sub>3</sub>** is the communication function code, and **S** is the source or received data as explained in the following table.

<b>S<sub>3</sub> and S operands for the A, AB, A+, B Series</b>			
<b>S<sub>3</sub> function code</b>	<b>S<sub>3</sub> function name</b>	<b>S source or received data</b>	<b>Remark</b>
0	Reading the servo state value	Occupies 5 consecutive devices <b>S–S+4</b>	Reading the state value from P0-04–P0-08
1	Reading the servo register value	Occupies 8 consecutive devices <b>S–S+7</b>	Reading the value from the registers P0-09–P0-16
2	Writing the servo register value	Occupies 8 consecutive devices <b>S–S+7</b>	Writing the data in the registers P0-09–P0-16
3	Jog velocity input, clockwise running, counterclockwise running and stop	The range of velocity: 1–3000; 4999 (run clockwise) 4998 (run counterclockwise) 5000 (stop)	Writing the data into the registers P4-05
4	Servo ON/OFF	1: Servo On Any other value: Servo OFF	Writing the data into the registers P2-30
5	Velocity command	Valid range: -5000 to 5000	Writing the data into the registers P1-09–P1-11
6	Torque command	Valid range: -300 to 300	Writing the data into the registers P1-12–P1-14

<b>S<sub>3</sub> and S operands for the A2, B2 Series</b>			
<b>S<sub>3</sub> function code</b>	<b>S<sub>3</sub> function name</b>	<b>S source or received data</b>	<b>Remark</b>
16	Reading the servo state value	Occupies 10 consecutive devices <b>S–S+9</b>	Reading the state value from the registers P0-09–P0-13 (32-bit value)
17	Writing data into the servo register	Occupies 8 consecutive devices <b>S–S+7</b>	Writing the data into the registers P0-17–P0-20 (32-bit value)
18	Writing the mapping parameter value *1	Occupies 8 consecutive devices <b>S–S+7</b>	Writing the data into the registers P0-25–P0-28 (32-bit value)
19	Jog velocity input, run clockwise, run	Valid range of velocity: Valid range 1–5000;	Writing data into the registers P4-05

	counterclockwise, stop	4999 (run clockwise) 4998 (run counterclockwise) 0 (stop)	
20	Servo ON/OFF	1: Servo On Any other value: Servo OFF	Writing the data into the registers P2-30
21	Velocity command (3 sets)	Occupies 6 consecutive devices with the valid setting value range: -60000 to 60000	Writing data into the registers P1-09–P1-11 (32-bit value)
22	Torque command (3 sets)	Occupies 6 consecutive devices with the valid setting value range: -300 to 300	Writing the data into the registers P1-12–P1-14 (32-bit value)
23	Setting the mapping targets of servo parameters	Occupies 8 consecutive devices <b>S–S+7</b>	Writing the data into the registers P0-35–P0-38 (32-bit value)
*1: B2 series does not support function code 18 and 23.			

5. The following chart shows the timing for sending and receiving data.



Description:

① → Start or stop the execution of the instruction.

② → Transmitting data begins. During this period, the communication timeout time is not measured.

③ → The reception flag is set. From the moment when the first character is received to the moment when the next character is received, the period of time is measured. Whenever a character is received, the measured is cleared to 0. The instruction generates the communication timeout flag if the time measured is greater than the

communication timeout setting value.


- ④ → When receiving of data is complete, the instruction sets the completion flag. You must clear the flag before receiving more data.
  - ⑤ → The instruction is disabled for one cycle after the completion flag is set. Then the instruction can be started in the next cycle.
6. There is no limit to the number of times the instruction can be executed. The instruction can use only one communication port for the output and execution of one communication instruction each time. If receiving and sending data is complete, you must disable the instruction to correctly release the communication control.
  7. The instruction cannot be used in the ST programming language, interrupt tasks or function block which is called only once.

**Example of setting the communication protocol:**

1. Set the PLC COM1 (RS485) port in HWCONFIG with these values: ASCII, 115200, 8, E, 1
2. Set the servo parameters using the panel on the Delta ASDA-A2 servo according to the following steps.
  - A. Set P2-08 to 10 to restore the factory settings.
  - B. Cycle the power on the servo off and then back on.
  - C. Set P1-01 to 0001 (PR mode).
  - D. Set P3-00 to 2: the station address of the servo is set to 2.
  - E. Set P3-01 to 0205: the RS485 baud rate of the servo is set to 115200.
  - F. Set P3-02 to 0004: the RS485 communication format of the servo is set to 8, E, 1.
  - G. Cycle the power to the servo again after completing these settings.

**Example**

Use the ASDRW instruction to control the velocity: make the servo run to the relative position 5000000 PUU by accelerating for 400 ms to the speed 3000.0 r/min and then decelerating for 200 ms.



6



1. Connect the AS CPU to ASDA-A2.

Set D100=1 initially. When M1 is ON, ASDA-A2 is Servo ON.

2. Set the values in D200–D207 as in the following table, which are written to P0-35–P0-38 in the ASDA-A2. The values occupies 8 consecutive devices.

Device	D200	D201	D202	D203	D204	D205	D206	D207
Setting value (16#)	05140515		06020602		06030603		053C0507	

When M2 is ON, the values in D200–D207 are written to P0-35–P0-38 in the ASDA-A2.

The setting values of P0-35–P0-38 are set the mapping target for P0-25–P0-28. You can set the mapping target; refer to the Delta servo operation manual.

ASDA-A2	P0-35	P0-36	P0-37	P0-38
Setting value (16#)	0514 0515	0602 0602	0603 0603	053C 0507

Setting the value of P0-38 to 053C 0507 indicates that the mapping parameter target for P0-28 is P5-60 (16 bits) and P5-07 (16 bits).

ASDA-A2	P0-25	P0-26	P0-27	P0-28
Mapping parameter target	P5-20, P5-21	P6-02	P6-03	P5-60, P5-07
Parameter name	Acceleration/deceleration time1 Acceleration/deceleration time2	Path type1	Path1 data	Target velocity and PR command trigger

3. The following table shows the setting values in D220–D227.

Device	D220	D221	D222	D223	D224	D225	D226	D227
Setting value (16#)	0190 00C8		0000 1083		4C4B40		7530 0001	

When M3 is ON, the values in D220–D227 are written into P0-25–28 in the ASDA-A2.

ASDA-A2	P0-25	P0-26	P0-27	P0-28
Setting value (16#)	0190 00C8	0000 1083	4C4B40	7530 0001

The servo starts running with the parameters: acceleration time=0190 (400 ms), deceleration time=00C8 (200 ms), path type=1083, position command=4C4B40 (5000000 PUU), target velocity=7530 (3000.0 rpm) and PR command trigger =1.

- Set the values in D240-D247 as shown in the following table, to be written into P0-17–P0-20 in the ASDA-A2. The values occupy 8 consecutive devices.

Device	D240	D241	D242	D243	D244	D245	D246	D247
Setting value (10#)	41		0		0		0	

When M4 is ON, the values in D240–D247 are written into P0-17–20 in the ASDA-A2.

The setting values of P0-17–20 set the contents of P0-09–12.

You can set the contents to be displayed; refer to the Delta Servo Operation manual.

ASDA-A2	P0-17	P0-18	P0-19	P0-20
Setting value (10#)	41	0	0	0

Setting P0-17 to 41 indicates that the contents of P0-09 is the drive state.

ASDA-A2	P0-09	P0-10	P0-11	P0-12
Content	Drive state	Number of motor feedback pulses	Number of motor feedback pulses	Number of motor feedback pulses

- When M5 is set to ON, the values of P0-17- P0-20 of ASDA-A2 are read to D260-D267.

Device	D260	D262	D264	D266
Content	Drive state	Number of motor feedback pulses	Number of motor feedback pulses	Number of motor feedback pulses

When the drive state bit (Bit 4) is one, it indicates that the target position is reached.

Refer to Delta servo operation manual for the explanation for P0-46.

- When the reception completion flag SM100 is set to ON, the instruction clears the values of M1–M5 to avoid interfering with the next communication command.

After receiving the data that the ASDA-A2 sends back, the PLC checks the format of the data sent back from the ASDA-A2. If the data format is correct, SM100 is ON; otherwise, SM102 is ON if the data format is incorrect.

API	Instruction code			Operand							Function						
1816		CCONF	P	<b>S<sub>1</sub>-S<sub>11</sub></b>							Setting the parameters in the data exchange table for a communication port						

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
S <sub>1</sub>								●	●				○	○		
S <sub>2</sub>								●	●				○	○		
S <sub>3</sub>								●	●				○	○		
S <sub>4</sub>								●	●				○	○		
S <sub>5</sub>								●	●				○	○		
S <sub>6</sub>								●	●				○	○		
S <sub>7</sub>			●					●								
S <sub>8</sub>								●	●				○	○		
S <sub>9</sub>								●	●				○	○		
S <sub>10</sub>								●	●				○	○		
S <sub>11</sub>			●					●								

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
S <sub>1</sub> -S <sub>11</sub>	Refer to the explanation for the instruction.												

Pulse instruction	16-bit instruction	32-bit instruction
AS	AS	-

Symbol

CCONF	CCONFP
En	En
S1	S1
S2	S2
S3	S3
S4	S4
S5	S5
S6	S6
S7	S7
S8	S8
S9	S9
S10	S10
S11	S11

**S<sub>1</sub>-S<sub>11</sub>** : Refer to the explanation for the instruction.

## Explanation

1. The following table lists the names and descriptions of **S<sub>1</sub>–S<sub>11</sub>**.

Device	Name	Description	Data type	Remark
<b>S<sub>1</sub></b>	Communication port number	1=COM1, 2=COM2. 11=Function card 1, 12=Function card 2. PLC with FW V1.06.00 or later supports function card 1 and 2. Any other value, the instruction does not modify the operand.	WORD	
<b>S<sub>2</sub></b>	Item number in the data exchange table	Valid range: 1–32. If the value is out the range, the instruction does not modify the operand.	WORD	
<b>S<sub>3</sub></b>	The station address of the remote equipment	Valid range: 0 and 1–240. If the value is greater than 240, the instruction uses 240 as the value. If the value is less than or equal to 0, the original station address is not changed.	WORD	A negative number is processed as 0.
<b>S<sub>4</sub></b>	Function code for reading data	Supports 16#01, 02, 03, 04 and 17. If the value exceeds the valid range, the instruction does not modify the operand. If <b>S<sub>4</sub></b> =16#17, it is processed as 16#17.	WORD	
<b>S<sub>5</sub></b>	Reading the remote communication address	16#0000–16#FFFF	WORD	
<b>S<sub>6</sub></b>	Reading data length	Bit function code, 16#01, 02: Supports 1–256 bits; Word function code, 16#03, 04, 17: Supports 1–100 words. If the value is 0 or smaller than 0, it indicates do not read data. If the value is greater than the maximum, the instruction uses the maximum value.	WORD	
<b>S<sub>7</sub></b>	The local register for storing the data received	Bit function code: only M device can be selected. Word function code: only D device can be selected.	BOOL WORD	

Device	Name	Description	Data type	Remark
S <sub>8</sub>	Function code for writing data	Supports 16#05, 06, 0F, 10. If the value is out of the range, the instruction does not modify the operand.	WORD	
S <sub>9</sub>	Writing the remote communication address	16#0000–16#FFFF	WORD	
S <sub>10</sub>	Writing data length	Bit function code, 16#0F: Supports 1–256 bits; Word function code, 16#10: Supports 1–100 words. For function code 16#06, the value can only be 1. If the value is 0 or smaller than 0, it indicates do not read data. If the value is greater than the maximum, the instruction uses the maximum value.	WORD	
S <sub>11</sub>	The local register into which the remote data are written	Bit function code: only M can be selected. Word function code: only D can be selected.	BOOL WORD	

2. It is suggested that you use the pulse instruction.
3. See the details about the Modbus function codes in S<sub>4</sub> and S<sub>8</sub> below.

The command for the AS reads the data from several bit devices (which are not discrete input devices) is 1 (16#01).

The command for the AS reads the data from several bit devices (which are only discrete input devices) is 2 (16#02).

The command for the AS to read the data from several word devices (which are not input registers) is 3 (16#03).

The command for the AS to read the data from several word devices (which are only input registers) is 4 (16#04).

The command for the AS to write the state into a bit device is 5 (16#05).

The command for the AS to write the state into a word device is 6 (16#06).

The command for the AS to write the state into several bit devices is 15 (16#0F).

The command for the AS to write the data into several word devices is 16 (16#10).

The command for the AS to synchronously read from and to write the data into several word devices is 23 (16#17).

Only the function codes listed above are supported. Other function code setting values, such as 0, are invalid

(including communication address, length and the start register), and the instruction executes the data exchange function based on the original communication parameter settings.

4. When you select 16#17 (for reading and writing synchronously) in **S<sub>4</sub>** (the function code for reading), the operand **S<sub>8</sub>** (the function code for writing) is processed as invalid and 16#17 is automatically processed for writing data.
5. For PLC with FW V1.04.00 or previous versions: if you select 16#05 or 16#06 in **S<sub>8</sub>** (the function code for writing), the operand **S<sub>10</sub>** (the data length) is invalid and 16#05 or 16#06 indicates writing a piece of data.
6. The parameter values specified by the instruction are valid only while PLC is running. If you cycle the power on the PLC, the data in the data exchange table set in HWCONFIG are taken as default values. If you want to modify the values for parameters, use this instruction.
7. You can use the instruction to immediately set the parameters for the communication connection when the data exchange function is not running. The new communication parameters are not used until the next cycle if the data exchange function is running; however, the instruction changes the communication parameters for the connection number.

For example, while the data exchange function is running with the parameters set for connection 3, you can specify new the parameters for connection 3. The new parameters are not used until the next cycle when connection 3 starts.

8. The instruction only allows you to change the communication parameters. Refer to the following table for the flags to start and close the communication connection function if you use the PLC program to perform those functions.

When you set the automatic scan function through ISPSoft, the start/stop flag of the connection number automatically updates the start/stop state once after the data exchange function finishes executing the scan.

The following table describes the SM flags.

SM No.	Attribute	Explanation for COM1 data exchange parameters
SM750	R/W	Enables data exchange
SM752–SM783	R/W	Enables data exchange connections 1–32
SM784–SM815	R	Reading success for data exchange connections 1–32
SM816–SM847	R	Error flags for data exchange connections 1–32
SM No.	Attribute	Explanation for COM2 data exchange parameters
SM862	R/W	Enables data exchange
SM864–SM895	R/W	Enables data exchange connections 1–32
SM896–SM927	R	Reading success for data exchange connections 1–32
SM928–SM959	R	Error flags for data exchange connections 1–32

SM No.	Attribute	Explanation for Function Card 1 data exchange parameters
SM1710	R/W	Enables data exchange
SM1712 ~ SM1743	R/W	Enables data exchange connections 1–32
SM1744 ~ SM1775	R	Reading success for data exchange connections 1–32
SM1776 ~ SM1807	R	Error flags for data exchange connections 1–32
SM No.	Attribute	Explanation for Function Card 2 data exchange parameters
SM1822	R/W	Enables data exchange
SM1824 ~ SM1855	R/W	Enables data exchange connections 1–32
SM1856 ~ SM1887	R	Reading success for data exchange connections 1–32
SM1888 ~ SM1919	R	Error flags for data exchange connections 1–32

The PLC sets the flag to ON when the reading success flag indicates that receiving data is complete and the data checked are correct. If an error occurs in receiving data or a communication timeout occurs, the error flag is set to ON (refer to the error codes). The PLC does not reset any of the reading success or error flags to OFF in the data exchange since the reading success flag and error flag of every connection number are not ON simultaneously.

9. The following table describes the SR (only-read registers) in the data exchange function.

SR No.	Description
SR1335	Cycle of the actual connections 1–32 in the COM1 data exchange
SR1336	Cyclic connection number in the current COM1 data exchange
SR1340–SR1371	Error codes of the connections 1–32 in the COM1 data exchange
SR1375	Cycle of the actual connections 1–32 in the COM2 data exchange
SR1376	Cyclic connection number in the current COM2 data exchange
SR1380–SR1411	Error codes for connections 1–32 in the COM2 data exchange
SR1435	Cycle of the actual connections 1–32 in the Function Card 1 data exchange
SR1436	Cyclic connection number in the current Function Card 1 data exchange
SR1440 ~ SR1471	Error codes of the connections 1–32 in the Function Card 1 data exchange
SR1475	Cycle of the actual connections 1–32 in the Function Card 2 data exchange
SR1476	Cyclic connection number in the current Function Card 2 data exchange
SR1480 ~ SR1511	Error codes of the connections 1–32 in the Function Card 2 data exchange

10. The data exchange function does not provide a writing success flag. It is suggested that you refer to the connection number in the execution to judge whether the writing of data succeeds or not.

For example, when the executed connection number is 3 in SR1336, the successive communication actions are to read the communication data first, and then to write the communication data after reading is completed. The connection number is incremented to 4 after writing is completed.

11. If the reading data length value in **S<sub>6</sub>** and the initial device in **S<sub>7</sub>** are out of the range of the D or M device, the length value in **S<sub>6</sub>** is automatically set to be in the valid range. For example, if the length value in **S<sub>6</sub>** is 100 and the initial device of **S<sub>7</sub>** is M8182, the value in **S<sub>6</sub>** is set to 10 automatically.
12. In the following cases, the instruction is not executed and the parameter settings in HWCONFIG are not changed for the communication port, and SM0 is set to ON, and the error code in SR0 is 16#200B.
  - An input error occurs when the setting values in **S<sub>1</sub>**, **S<sub>2</sub>**, **S<sub>4</sub>** and **S<sub>8</sub>** are out of the specified range.
  - When **S<sub>4</sub>** or **S<sub>8</sub>** function code selects the bit type for reading or writing data, the local device for storing data **S<sub>7</sub>** or **S<sub>11</sub>** must select the M device. An input error occurs if the selection is not M.
  - When the **S<sub>4</sub>** or **S<sub>8</sub>** function code selects the word type for reading or writing data, the local device for storing data **S<sub>7</sub>** or **S<sub>11</sub>** must select the D device. An input error occurs if the selection is not D.

**Example: AS COM1 (RS485)**


1. For the data exchange between the AS Series CPU and the DVP-ES2 CPU, the following table shows the COM1 data exchange table in HWConfig in ISPSOft.

Item No.	Detection method	Remote station address	Local device		Remote device	Length	Function code	How to start
1	Specified connection	2	D50	←	D50	50	H03	Program control
			D100	→	D100	50	H10	
2	Specified connection	2	D150	←	D150	50	H03	Program control
			D200	→	D200	50	H10	

2. Before starting data exchange, suppose that the corresponding data between the AS Series CPU and the DVP-ES2 CPU are listed in the following table.

AS PLC (Master)	Content value	ES2 PLC (Slave)	Content value
D50-D99	0	D50-D99	1-50
D100-D149	100-149	D100-D149	0
D150-D199	0	D150-D199	150-199
D200-D249	200-249	D200-D249	0

3. The data exchange between the AS Series CPU and the DVP-ES2 CPU starts when X0.1 is ON.



4. After data exchange starts, the corresponding data between the AS Series CPU and the DVP-ES2 CPU change as shown in the following table.

AS PLC (Master)	Content value	ES2 PLC (Slave)	Content value
D50-D99	1-50	D50-D99	1-50
D100-D149	100-149	D100-D149	100-149
D150-D199	150-199	D150-D199	150-199
D200-D249	200-249	D200-D249	200-249

5. When X0.0 is ON, the COM1 data exchange table parameters in the AS Series CPU are modified as shown in the following table.

Item No.	Detection method	Remote station address	Local device		Remote device	Length	Function code	How to start
1	Specified connection	3	D5000	←	D500	1	H04	Program control
			D6000	→	D600	1	H06	
2	Specified connection	3	M100	←	M0	10	H01	Program control
			M110	→	M50	10	H0F	

6. Due to the change of COM1 data exchange table parameters, the corresponding data between the AS Series CPU and the DVP-ES2 CPU are modified as shown in the following table.

AS PLC (Master)	Content value	ES2 PLC (Slave)	Content value
D5000	3000	D500	3000
D6000	4000	D600	4000
M100-M109	ON	M0-M9	ON
M110-M119	OFF	M50-M59	OFF


API	Instruction code			Operand							Function						
1817		MODRWE		<b>S<sub>1</sub>, S<sub>2</sub>, S<sub>3</sub>, S<sub>4</sub>, S, n, D</b>							Reading and writing Modbus data without using any flags						

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
S <sub>1</sub>								●	●				○	○		
S <sub>2</sub>								●	●				○	○		
S <sub>3</sub>								●	●				○	○		
S <sub>4</sub>								●	●				○	○		
S								●								
n								●	●				○	○		
D		●	●	●				●								

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
S <sub>1</sub>		●				●							
S <sub>2</sub>		●				●							
S <sub>3</sub>		●				●							
S <sub>4</sub>		●				●							
S	●	●				●							
n		●				●							
D	●												

Pulse instruction	16-bit instruction	32-bit instruction
-	AS	-

Symbol



- S<sub>1</sub> : Communication port number
- S<sub>2</sub> : Unit address
- S<sub>3</sub> : Function code
- S<sub>4</sub> : Device address
- S : Register for reading and writing the data
- n : Data length
- D : Flag for completion of the reading and writing data

Explanation

- S<sub>1</sub> sets the serial number of a communication port. The number of COM1 is 1, COM2 is 2, Card1 is 11 and Card2 is 12. If the value exceeds the valid range, the instruction does not receive any communication data.
- Refer to the explanation of the MODRW instruction (API 1808) for the meaning of the operands S<sub>2</sub>, S<sub>3</sub>, S<sub>4</sub>, S and n.
- D sets the communication state flags when the instruction completes the communication, and the flags occupy 3 consecutive devices. You must reset the flags to OFF. The following table gives explanations of the flag states.

Operand	Description
D	Receiving data successful.
D +1	Error occurs in receiving data.
D +2	Reception timeout flag

NOTE: Only one flag is set to ON among the three state flags, and the corresponding special flags (SM) are also set to ON every time the communication is completed. Refer to Section 6.19.3 for the use of the special flags.

- The timing for sending the instruction begins when the instruction starts. You must disable the instruction for a scan cycle after communication is completed. The next communication instruction can be sent as soon as the instruction is restarted.
- The communication action and control sequence of the instruction are similar to MODRW instruction (API 1808). The only difference between the two instructions is that you can send the communication command without control over the flag for sending data.
- The instruction cannot be used in the ST programming language, interrupt tasks or function block which is called only once.

### Example

You can compare the MODRW program and MODRWE program, for example, by using the PLC COM1 and function code 03 to read eight pieces of data from D20 in the DVP-ES2. The same is true for other PLC communication ports. Refer to the MODRW instruction (API 1808) and the following example for the use of other function codes.


- The device address of D20 in the DVP-ES2 CPU (16#1020) and the content values in D20–D27 are shown in the following table.

Device	D20	D21	D22	D23	D24	D25	D26	D27
Value (16#)	1234	5678	1122	3344	5566	7788	99AA	BBCC

- The AS Series PLC reads the content values from D20–D27 in the DVP-ES2 CPU through communication.

## Method 1: Using MODRW instruction

The data in D20-D27 of the DVP-ES2 are read when SM96 is ON and X0.0 is ON.



The following table explains the MODRW operands.

Operand	Description	Device
<b>S<sub>1</sub></b>	Unit address	16#0001
<b>S<sub>2</sub></b>	Function code	16#0003
<b>S<sub>3</sub></b>	Reading the device address of D20	16#1020
<b>S</b>	First register for storing the data read	D10
<b>n</b>	Reading the data length	8

The communication response between the AS Series CPU and the DVP-ES2 depends on the mode.

**ASCII mode:** You do not need to convert the ASCII codes, and they are expressed in 16# values.

- AS sends the communication command: "01 03 10 20 00 08 C4 CR LF"
- AS receives the communication command: "01 03 10 12 34 56 78 11 22 33 44 55 66 77 88 99 AA BB CC AA CR LF"

**RTU mode**


- AS sends the communication command: “ 01 03 10 20 00 08 41 06”
- AS receives the communication command: “01 03 10 12 34 56 78 11 22 33 44 55 66 77 88 99 AA BB CC 90 FE”

SM100 is ON if there is no error in the data.

After the receiving of the data sent from the DVP-ES2, the PLC confirms the data format sent back from the DVP-ES2. If there are no errors in the format, SM100 is ON; otherwise, SM102 is ON. SM104 is ON if there is no response.

Method 2: Using MODRWE instruction

The data in D20-D27 of the DVP-ES2 are read when X0.0 is ON.



The following table explains the MODRWE operands.

Operand	Description	Device
S1	Communication port number	16#0001
S2	Unit address	16#0001
S3	Function code	16#0003
S4	Reading the device address of D20	16#1020
S	First register for storing the data read	D10
n	Reading the data length	8
D	Flag for completion of reading and writing data	M0

The communication response between the AS series CPU and the DVP-ES2 depends on the mode.

**ASCII mode:** You do not need to convert the ASCII codes, and they are expressed in 16# values.

- AS sends the communication command: "01 03 10 20 00 08 C4 CR LF"
- AS receives the communication command: "01 03 10 12 34 56 78 11 22 33 44 55 66 77 88 99 AA BB CC AA CR LF"

**RTU mode**

- AS sends the communication command: "01 03 10 20 00 08 41 06"
- AS receives the communication command: "01 03 10 12 34 56 78 11 22 33 44 55 66 77 88 99 AA BB CC 90 FE"

M0 is ON when there is no error in the data.

After the receiving of the data sent from the DVP-ES2, the PLC confirms the data format sent from DVP-ES2. If there is no error in the format, M0 is ON; otherwise, M1 is ON. M2 is ON if there is no response. The corresponding special flags SM100, SM102 and SM104 are ON as well.

3. The following table lists the content values in D10–D17 of AS CPU.

Device	D10	D11	D12	D13	D14	D15	D16	D17
Value (16#)	1234	5678	1122	3344	5566	7788	99AA	BBCC

**Additional remarks**

1. If you declare the operand in IPSSoft, the data type is ARRAY [3] of BOOL.
2. If **D+2** exceeds the device range, the instruction is not executed, SM0 is ON and the error code in SR0 is 16#2003.

API	Instruction			Operand								Description					
1818		DNETRW			S <sub>1</sub> , S <sub>2</sub> , S <sub>3</sub> , S <sub>4</sub> , S <sub>5</sub> , S <sub>6</sub> , S <sub>7</sub> , S <sub>8</sub> , S <sub>9</sub> , S <sub>10</sub> , D <sub>1</sub> , D <sub>2</sub> , D <sub>3</sub> , D <sub>4</sub> , D <sub>5</sub>								Reading and writing DeviceNet communication data				

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
S <sub>1</sub>								●	●				○	○		
S <sub>2</sub>								●	●				○	○		
S <sub>3</sub>								●	●				○	○		
S <sub>4</sub>								●	●				○	○		
S <sub>5</sub>								●	●				○	○		
S <sub>6</sub>								●	●				○	○		
S <sub>7</sub>								●	●				○	○		
S <sub>8</sub>								●								
S <sub>9</sub>								●	●				○	○		
S <sub>10</sub>								●	●				○	○		
D <sub>1</sub>		●	●	●												
D <sub>2</sub>		●	●	●												
D <sub>3</sub>								●								
D <sub>4</sub>								●								
D <sub>5</sub>								●								

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
S <sub>1</sub>		●				●							
S <sub>2</sub>		●				●							
S <sub>3</sub>		●				●							
S <sub>4</sub>		●				●							
S <sub>5</sub>		●				●							
S <sub>6</sub>		●				●							
S <sub>7</sub>		●				●							
S <sub>8</sub>		●				●							
S <sub>9</sub>		●				●							
S <sub>10</sub>		●				●							
D <sub>1</sub>	●												
D <sub>2</sub>	●												
D <sub>3</sub>		●				●							
D <sub>4</sub>		●				●							
D <sub>5</sub>		●				●							

Pulse Instruction	16-bit instruction	32-bit instruction
—	AS	—

## Symbol

DNETRW	
En	
S1	D1
S2	D2
S3	D3
S4	D4
S5	D5
S6	
S7	
S8	
S9	
S10	

- S<sub>1</sub>** : Number of the module sending the DeviceNet communication
- S<sub>2</sub>** : DeviceNet MAC ID
- S<sub>3</sub>** : Service Code
- S<sub>4</sub>** : Class ID
- S<sub>5</sub>** : Instance ID
- S<sub>6</sub>** : Attribute ID
- S<sub>7</sub>** : Written-data length
- S<sub>8</sub>** : Device for storing written data
- S<sub>9</sub>** : Communication timeout time
- S<sub>10</sub>** : Number of times of retransmission
- D<sub>1</sub>** : Completion flag
- D<sub>2</sub>** : Error flag
- D<sub>3</sub>** : Error code
- D<sub>4</sub>** : Read-data length
- D<sub>5</sub>** : Device for storing read data

## Explanation

- S<sub>1</sub>** is the serial number of the module at the right of the PLC. The first one is number 1, the second one is number 2 and so on. Whatever modules at the right of the PLC must be numbered. The setting range is 1~32. If the setting value (<1 or >32) exceeds the range, the instruction will run at the minimum value or maximum value.
- S<sub>2</sub>** is the DeviceNet Mac ID within the range: 0~63. It can be the Mac ID of the slave which the master is to read and write as well as the Mac ID of the master which means to read and write the data in the master.
- S<sub>3</sub>** is the DeviceNet service code.

Service code	Description
0x01	Read all attributes (Get_Attribute_All)
0x02	Set all attributes (Set_Attribute_All)
0x0E	Read one single attribute (Get_Attribute_Single)
0x10	Set one single attribute (Set_Attribute_Single)


- S<sub>4</sub>**, **S<sub>5</sub>** and **S<sub>6</sub>** are respectively class ID, instance ID and attribute ID for specifying the parameter path in the EPATH of the DeviceNet protocol.

5. **S<sub>7</sub>** is the length of written data with the unit of byte.
6. **S<sub>8</sub>** is the starting address of the devices where written data are stored in the order from low bit to high bit.
7. **S<sub>9</sub>** is the communication timeout time. The range of the setting value is 1~100 and the unit is 0.1s (second).
8. **S<sub>10</sub>** is the number of retransmission times and the range is 0~3. When the communication timeout occurs, the communication will be transmitted again.
9. **D<sub>3</sub>** displays the read or write error code.

Error code		Description
Code 1 (High Byte)	Code 2 (Low Byte)	
XX	FF	Not conform with DeviceNet standard
20	01	The target slave does not exist.
20	02	Making the connection with the slave failed.
20	03	Sending the explicit message failed.
16	00	Communication timeout

10. **D<sub>4</sub>** is the read data length with the unit of byte.
11. **D<sub>5</sub>** is the starting address of the devices where read data are stored in the order from low bit to high bit.
12. **D<sub>1</sub>** is the communication completion flag and **D<sub>2</sub>** is the error flag. See the detailed communication sending procedure and sequence diagram.

- ① The DNETRW instruction is enabled for the first time and the command will be sent out immediately if the instruction is not be occupied by other DeviceNet communication.
- ② The command is being sent.
- ③ The data sending is completed and the completion flag or error flag changes to On according to the response.
- ④ The next message is ready to be sent out. The next command is sent out right after the completion flag or error flag is cleared.
- ⑤ The command sending is completed and the DNETRW instruction is disabled.



13. The instruction cannot be used in the ST programming language, interrupt tasks or function block which is called only once.



3. **S<sub>1</sub>** sets the communication mode. See the following modes that the instruction supports. If the setting value is incorrect, the error flag **D<sub>3</sub>** changes to On and the error code SR659 is set to 1.

Communication code		Setting value of S <sub>1</sub>	Communication format	Description
High 8 bits	Low 8 bits			
0	0	16#0000	2.0A 11-bit ID	Master mode. The master will wait to receive the response message after sending out the communication data.
	1	16#0001		Master mode. After sending the broadcast command, the master will enter the mode of receiving messages from multiple slaves until the receiving timeout occurs or the quantity of messages received is up to 100.
	2	16#0002		Slave mode. The slave receives a message first and then sends back the response message.
	3	16#0003		Slave mode. The slave only receives messages.
1	0	16#0100	2.0B 29-bit ID	Master mode. The master will wait to receive the response message after sending out a message.
	1	16#0101		Master mode. After sending the broadcast command, the master will enter the mode of receiving messages from multiple slaves until the receiving timeout occurs or the quantity of messages received is up to 100.
	2	16#0102		Slave mode. The slave receives a message first and then sends back the response message.
	3	16#0103		Slave mode. The slave only receives messages.

4. **S<sub>2</sub>** is the ID of the transmitted message. According to 2.0A or 2.0B protocol, the transmitted data automatically occupies D buffer registers.

When 2.0A is selected, **S<sub>2</sub>** is 11 bits of ID code with the following data transmission format.

<b>S<sub>2</sub> No.</b>	<b>S<sub>2</sub></b>
Description	Msg. ID

When 2.0B is selected, **S<sub>2</sub>** (Lo-word) and **S<sub>2</sub>+1** (Hi-word) are both 29 bits of ID code.

<b>S<sub>2</sub> No.</b>	<b>S<sub>2</sub></b>	<b>S<sub>2</sub>+1</b>
Description	Msg. ID (Lo-word)	Msg. ID (Hi-word)

- S<sub>3</sub>** is the length of the transmitted message. The setting value should be in the range of 0~8 with the unit of byte (8bits). If the setting value (<0 or >8) exceeds the range, the instruction will run at the minimum value 0 or the maximum 8. If the length of the transmitted message is 0, the communication mode will automatically change into the slave mode to receive messages without sending out any data. The mode can be used to monitor the communication packet.
- S<sub>4</sub>** is the starting device where transmitted data are stored and only the following 8 bits of data are used.

For example, 4 messages are transmitted with D10 as the starting device. See the data transmission sequence as below.

<b>S<sub>4</sub> No.</b>	D10	D11	D12	D13
Description	Data1	Data2	Data3	Data4

- If **S<sub>1</sub>** is the master mode in which the master will wait to receive data after sending data or the slave mode, the received data will be directly stored in the device specified by **D<sub>1</sub>**. D100 is specified by **D<sub>1</sub>** Here See the stored content format.

2.0A mode setting:

<b>D<sub>1</sub> No.</b>	D100	D101	D102 ~ D109 (Lower 8 bits)
Description	Msg. ID	Data Length	Data1 ~ Data8

2.0B mode setting

<b>D<sub>1</sub> No.</b>	D100	D101	D102	D103 ~ D110 (Lower 8 bits)
Description	Msg. ID (Lo-word)	Msg. ID (Hi-word)	Data Length	Data1 ~ Data8

Note: If the Msg. ID to be received need be specified at the stage of receiving data, set the value of **D<sub>1</sub>/ D<sub>1</sub>+1** beforehand based on the 2.0A/2.0B mode. If the Msg. ID is not specified, please clear the value of **D<sub>1</sub>/ D<sub>1</sub>+1** to 0 before receiving data.

- If **S<sub>1</sub>** is the master broadcast mode, the received data will be stored in the device specified by **D<sub>1</sub>**. D100 is specified by **D<sub>1</sub>** here. See the storage format as below.

Selecting 2.0A mode: (Here is the introduction of receiving data from 2 slaves. For other data, please increase the Device number specified by **D<sub>1</sub>**)

Response sequence		Data from the first slave			Data from the second slave		Data from the third slave
<b>D<sub>1</sub> No.</b>	D100	D101	D102	D103 ~ D110 (Lower 8 bits)	D111	D112~D120	D121~130
Description	Receiving Packet number	Msg. ID	Data Length	Data1 ~ Data8	Msg. ID	Length, Data	ID, Length, Data

Selecting 2.0B mode: (Here is the introduction of receiving data from 2 slaves. For other data, increase the number of **D<sub>1</sub>**)

Response sequence	Data from the first slave					Data from the second slave
<b>D<sub>1</sub></b> No.	D100	D101	D102	D103	D104 ~ D111 (Lower 8 bits)	D112~D122
Description	Receiving Packet number	Msg. ID (Lo-word)	Msg. ID (Hi-word)	Data Length	Data1 ~ Data8	ID, Length, Data

9. **D<sub>2</sub>** and **D<sub>3</sub>** are the receiving-completed flag and error flag respectively. The two flags will judge if the data receiving is completed or an error occurs based on the current communication state when the instruction is scanned. If the data receiving is completed or an error occurs, the flags will change to On. The two flags will be cleared and change to Off automatically every time the instruction is enabled.
10. When the instruction is set to the master mode, using the receiving timeout setting in HWCONFIG is recommended. So **D<sub>3</sub>** will change to On and the error code 2 will be recorded in SR659 if the communication packet has not been received fully within the specified period of time.

If the receiving timeout time is set to 0, it indicates that the communication timeout is not limited and the status can be applied to the slave mode.

**Note:** The communication control right can not be released until the instruction is disabled by manual when the method in which there is no limit to the communication timeout is adopted.

11. There is no limit to the number of times of using the instruction. But only one CAN communication command is allowed to be sent every time. If one command is being sent or received currently, the next CANRS instruction can not be enabled.
12. Here is the CAN BUS format and every bit of content for Msg. ID is explained as below.

As 2.0A protocol is selected and the value of **S<sub>2</sub>** is 16#0123, the Msg. ID content is shown in the following table.

Bit No.	15 ~ 11	10 ~ 8	7 ~ 4	3 ~ 0
<b>S<sub>2</sub></b> value (16bits)	-	1	2	3


As 2.0B protocol is selected, the value of **S<sub>2</sub>** is set to 16#1234 (Lo-word) and **S<sub>2</sub>+1** is 16#0567 (Hi-word), the Msg. ID content is shown in the following table.

Bit No.	31 ~ 29	28	27 ~ 24	23 ~ 20	19 ~ 16	15 ~ 0
<b>S<sub>2</sub></b> value (32bits)	-	0	5	6	7	1234

13. If the operand **D<sub>1</sub>** is declared in a variable, using the Word-type matrix is recommended.

14. See CANRS communication sequence diagram and explanation.

- ①: The CANRS instruction is enabled. If no other CANRS instruction occupies the control right, the flags **D<sub>2</sub>** and **D<sub>3</sub>** are cleared and then the data are sent out right away.
- ②: The data sending is completed and meanwhile the data receiving starts. After the receiving is completed, the completion flag **D<sub>2</sub>** changes to On.
- ③: The instruction sends data again after you clear the flag **D<sub>2</sub>**.
- ④: As the receiving timeout occurs, **D<sub>3</sub>** changes to On.
- ⑤: If an error is found, you can disable the instruction. Alternatively, you can have the instruction resend data after clearing the flag **D<sub>3</sub>**.



6

**Example 1**

**Master Mode**

Using the CANRS instruction, the 6-byte data in D10~D15 are transmitted to the slave and the response data from the slave are stored in the devices starting from D100. M100 changes to On when the sending and receiving are over.

See the explanation of relevant parameters.

Master mode_MsgID=2	
Communication mode	0= master mode, waits to receive the response from the slave after sending out data.
Communication ID	The MsgID of the sent message D0=1
Sent-data length	6 BYTE
Starting device where sent data are stored	D10

Starting device where received data are stored	D100 for storing MsgID, D101 for storing the number of received packets D102..... for storing received data
Communication completion flag	M100
Communication error flag	M101

1. As M1 is on, set the MsgID of the sent message to 1 and MsgID of the received message to 2. Then the data sending begins.


A. Sending the data in D10~D15 (6 bytes) to the slave is performed.

Device	D10~D15
Content	H0A (Defined by users)

B. The received response data from the slave are stored in D100~D109. M100 changes to On as the receiving is done.

Device	D100	D101	D102~D109
Content	2	8	H0B

2. Master programming example



**Example 2**

**Slave Mode**

Using the CANRS instruction, the received data from the master are stored in the devices starting from D120 and the 8-byte data in D20~D27 are sent back. M110 changes to On when the sending and receiving are over.

See the explanation of relevant parameters.

Slave mode_MsgID=1	
Communication mode	2= Slave mode, sends data after receiving data.
Communication ID	MsgID of the sent message, D0=2
Sent-data length	8 BYTE
Starting device where sent data are stored	D20
Starting device where received data are stored	D120 for storing MsgID D121 for storing the number of received packets D122.... for storing received data
Communication completion flag	M110
Communication error flag	M111

1. As M1 is on, set the MsgID of the sent message to 2 and MsgID of the received message to 1 and then wait to receive data.


A. The received 6-byte data from the master are placed in D120~D127.

Device	D120	D121	D122~D127
Content	1	6	H0A

B. Then the 8-byte data in D20~D27 start to be sent back to the master. M110 changes to On as the data sending is done.

Device	D10~D15
Content	H0B (Defined by users)

2. Slave programming example



API	Instruction	Operand	Description
1820	DMVSH	Mode ~ ErrCode	Enabling Delta DMV detection and communication

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
Mode								●					○	○		
Start1		●	●	●				●								
Start2		●	●	●				●								
Ready	●															
ComNo								●					○	○		
Id_lp								●					○	○		
Address								●					○	○		
Length								●					○	○		
Shoot1		●														
Shoot2		●														
RdData								●								
Ok		●	●	●				●								
Err		●	●	●				●								
ErrCode								●								

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
Mode		●											
Start1	●												
Start2	●												
Ready	●												
ComNo		●				●							
Id_lp		●				●							
Address		●				●							
Length		●				●							
Shoot1	●												
Shoot2	●												
RdData		●				●							
Ok	●												
Err	●												
ErrCode		●				●							

Pulse Instruction	16-bit instruction	32-bit instruction
-	AS	-

## Symbol

DMVSH	
En	
Mode	Shoot1
Start1	Shoot2
Start2	RdData
Ready	Ok
ComNo	Err
Id_Ip	ErrCode
Address	
Length	

<b>Mode</b>	:	The triggering and receiving method
<b>Start1</b>	:	Trigger signal for starting set1
<b>Start2</b>	:	Trigger signal for starting set2
<b>Ready</b>	:	Completion signal of when receiving response data from DMV is complete
<b>ComNo</b>	:	A serial port or network communication port for the PLC to send or receive data
<b>Id_Ip</b>	:	Serial communication station address or network IP of DMV
<b>Address</b>	:	Starting device where DMV data to be read are stored
<b>Length</b>	:	Length of the data to be read
<b>Shoot1</b>	:	Output signal when PLC notifies DMV to enable the detection of set1
<b>Shoot2</b>	:	Output signal when PLC notifies DMV to enable the detection of set2
<b>RdData</b>	:	Starting device where the data that the PLC receives from the DMV are stored
<b>Ok</b>	:	Communication success flag
<b>Err</b>	:	Communication error flag
<b>ErrCode</b>	:	Communication error code

## Explanation

1. The DMVSH instruction is applicable to AS series PLC with the firmware of V1.06.00 and later.
2. **Mode** sets the method through which the PLC triggers DMV including DMV1000 and DMV2000 and the receiving method. There are 2 modes: 0 and 1 for option. If the setting exceeds the range, PLC will automatically run in mode 0.
3. Please refer to following example explanation for the function of **Start1**, **Start2**, **Ready**, **Shoot1**, **Shoot2**, **RdData** and **Ok** and the process of detection triggering.
4. **ComNo** sets a communication port number of the PLC. The number 1 represents COM1, number 2 represents COM2, number 11 represents Card1, number 12 represents Card2 and number 4 represents Ethernet port. If the setting is not one of the numbers mentioned above or represents the communication port that the PLC does not support, the error flag **Err** will change to On and the error code 16#0001 will show up.

5. **Id\_Ip** sets the communication station address (Mac ID) of the slave DMV or network IP. **Address** is the communication address where DMV detection result is read. **Length** is the length of the read detection data.
6. See the explanation of the values of **ErrCode** in the table below.


Error code	Description	Correction
16#0001	The specified communication port is incorrect.	Specify a new communication port number.
16#0002	DMV response fault	Check the communication address
16#0003	No response from DMV	Check if the cable is connected properly or DMV has been enabled.
16#0004	Waiting for the response from DMV; DMV detection cannot be enabled repeatedly.	Modify the timing of enabling DMV detection.

**Example 1**

**Mode=0**

Only set1 is used to trigger the DMV detection and receiving of DMV response data.

See the sequence control diagram below.



Explanation of the timings:

- ① The DMVSH instruction is enabled.
- ② Set Start1 to On to notify the instruction to send the output signal **Shoot1** (ON for about 10ms) and notify DMV to enable the detection function.
- ③ After DMV receives the trigger message, **Ready** is set from On to Off.
- ④ **Shoot1** is cleared to Off automatically by the PLC.


- ⑤ After DMV detection is finished, **Ready** is set from Off to On. The PLC starts to judge if **Ready** is on after waiting for 1.5 times the input filtering time. The PLC receives the message that **Ready** changes from Off to On and sends a read command via Modbus 0x03.
- ⑥ The **Ok** flag is set to On after the PLC receives the communication data sent back from DMV. At the moment, the already received data can be processed.
- ⑦ The **Start1** and **Ok** flags can be cleared to Off by manual.
- ⑧ If the detection need be retrIGGERED to execute, directly set **Start1** to On to start the next-round DMV detection. (Return to step 2 to continue.)

### Example 2

Mode = 1

Set1 and set2 are used to trigger the DMV detection separately. But the communication data reading command can not be sent until both **Readys** change to On. (The example is applicable to the two-camera DMV1000 detection.)

See the sequence control diagram below.



- ① The DMVSH instruction is enabled.
- ② Set **Start1** to On to notify the instruction to send the output signal **Shoot1** (which is on for about 10ms) and notify DMV to enable the detection function of the first camera.
- ③ After DMV receives the trigger message, **Ready** is set from On to Off.
- ④ **Shoot1** is cleared to Off automatically by the PLC.
- ⑤ Set **Start2** to On to notify the instruction to send the output signal **Shoot2** (which is on for about 10ms) and notify DMV to enable the detection function of the second camera.
- ⑥ **Shoot2** is cleared to Off automatically by the PLC.
- ⑦ After DMV detection is finished, **Ready** is set from Off to On and the two detections are complete. Then the PLC sends a read command via Modbus 0x03.
- ⑧ The **Ok** flag is set to On after the PLC receives the communication data sent back from DMV. At the moment, the already received data can be processed.
- ⑨ The **Start1**, **Start2** and **Ok** flags can be cleared to Off by manual. If the detection need be retrigged to execute, return to step 2 to proceed.

API	Instruction			Operand					Description				
1821		DESO		ComNo ~ ErrCode					Execute the appointed communication number of the data exchange table once				

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	“\$”	F
ComNo								●					○	○		
ListNo								●					○	○		
OK		●	●	●				●								
Error		●	●	●				●								
ErrCode								●								

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
ComNo		●				●							
ListNo		●				●							
OK	●												
Error	●												
ErrCode		●				●							

Pulse Instruction	16-bit instruction	32-bit instruction
-	AS	-

**Symbol**



- ComNo** : Communication port for data exchange
- ListNo** : Communication number of the data exchange table
- OK** : Completion flag
- Error** : Error flag
- ErrCode** : Error code

**Explanation**

- This instruction is available for PLC with FW V1.08.20 or later and ISPSOft V3.09.07 or later.
- Make sure the data exchange table of the PLC CPU is already created before executing this instruction. If not, the Error flag switches to ON and ErrCode is recorded as 1.

3. **ComNo** is the communication port for data exchange.

Communication Port	COM1	COM2	Ethernet	Card1	Card2
Number in decimal format	1	2	3 PLC CPU FW V1.12 or later	11	12

4. **ListNo** is the communication number of the data exchange table.

1	1	D100	<<	D0	1
		D200	>>	D0	1
2	1	D300	<<	D0	1
		D400	>>	D0	1


5. When the instruction is enabled, only the appointed communication number of the data exchange table will be executed. When the communication is done and the slave device reponses with OK, the OK flag will be ON. The corresponding SM of the communication number will be ON and the Error Code is recorded as 0.
6. Before executing this instruction, the system checks if the communication number to be executed is in cyclic communication mode. If yes, this instruction will not be executed. The Error flag is ON. Error Code is recorded as 2.
7. Refer to the following table for more details when any of the Error flag is ON.

Error Code	Description
0	No error or the transmission is complete.
1	The data exchange table or the communication number does NOT exist.
2	The connection of the data exchange table is started; do NOT start another connection again.
3	No response from the slaves.
4	Slave responds with a communication error.
5	The same communication port is in use.
6	The communication port does NOT exist or the communication card (AS-F232/422/485) is NOT installed. .
7	The communication number of the data exchange table exceeds the setting rang (1~32).

8. The communication timeout is set in the data exchange table.
9. This instruction is suggested for applications where the slave device is better not to receive or be sent with communication requests regularly. Since only one communication will be opened during the instruction execution, you need to close the instrucion to start another communication if the same communicaitron port is being used.
10. There is no limit on the number of times you execute the instruction but only one communication can be established for each communication port. If you execute the insturcion again when the same comunicaiton port is being used, the Error flag will be ON and the Error Code is recorded as 5.

**Example:**

When M0 is ON, the instruction starts to execute the number four communication of the data exchange table in COM1.



**The data exchange table of COM1**

	Enable	Remote Station Address	Local Address	Direction	Remote Address	Quantity
1	<input type="checkbox"/>	1	D400	←	D0	10
			D0	→	D0	10
2	<input type="checkbox"/>	1	D410	←	D10	10
			D10	→	D10	10
3	<input type="checkbox"/>	1	D420	←	D20	10
			D20	→	D20	10
4	<input checked="" type="checkbox"/>	1	D430	←	D30	10
			D30	→	D30	10
5	<input type="checkbox"/>	1	D440	←	D40	10
			D40	→	D40	10

### 6.19.3 Descriptions of the Communication-related Flags and Registers

#### Communication-related flags (SM)

Flag				Description	Action
COM1	COM2	Card 1	Card 2		
SM96	SM97	SM76	SM77	<p>Data sending request flag</p> <p>If you want to use the instruction to send and receive data, you must use the pulse instruction to set the flag to ON. When the instruction is executed, the PLC sends and receives the data. After sending the data, the system automatically resets the flag to OFF.</p>	You set the flag to ON, and the system automatically resets it to OFF.
SM98	SM99	SM78	SM79	<p>When the flag is ON, the PLC is waiting to receive the data.</p>	The system automatically sets the flag to ON and resets it to OFF.
SM100	SM101	SM80	SM81	<p>Reception complete flag</p> <p>After receiving the data, the system automatically sets the flag to ON. When the flag is ON, the data received can be processed. After processing the data received, you must to reset flags to OFF.</p>	The system automatically sets the flag to ON, and you reset it to OFF.
SM102	SM103	SM82	SM83	<p>Data receiving error flag</p> <p>An error occurs during receiving data using the data receiving instruction.</p>	The system automatically sets the flag to ON, and you reset it to OFF.
SM104	SM105	SM84	SM85	<p>Communication timeout error flag</p> <p>If you set the communication timeout (in SR) and no data is received after the timeout period, the flag is ON. After the problem is solved, you must reset the flag to OFF.</p>	The system automatically sets the flag to ON, and you reset it to OFF.
SM106	SM107	SM86	SM87	<p>The choice between the 8-bit processing mode and the 16-bit processing mode</p> <p>ON: 8-bit processing mode</p> <p>OFF: 16-bit processing mode</p>	You set the flag to ON and reset it to OFF.

Flag				Description	Action
COM1	COM2	Card 1	Card 2		
SM210	SM212	-	-	<p>Communication mode</p> <p>ON: RTU mode</p> <p>OFF: ASCII mode</p> <p>You can set this value in HWCONFIG in ISPSOft.</p> <p>Not available for Card1 and Card 2.</p>	You set the flag to ON and reset it to OFF.
SM209	SM211	SM90	SM91	<p>Communication protocol changed flag</p> <p>The communication protocol changes in accordance with the setting values in SR. If the flag is set to ON, the communication protocol changes in accordance with the setting values in SR and then the system automatically resets the flag to OFF.</p> <p>NOTE: this change does not affect the parameters that you set in HWCONFIG. When the PLC is powered-on again, the PLC operates according to the communication protocol set in HWCONFIG.</p>	You set the flag to ON and reset it to OFF.

NOTE: the above flags are non-latching types.

## Communication-related registers (SR)

Special data register				Description
COM1	COM2	Card 1	Card 2	
SR201	SR202	SR176	SR178	Communication port address
SR209	SR212	SR177	SR179	Communication protocol For details, please refer to the following table to set up the communication format for a serial communication port.
SR210	SR213	SR182	SR183	Communication timeout, unit: ms Suppose the setting value is larger than 0. When the PLC executes the communication instruction and is in the receiving state, but no data is received after the timeout period or the intervening time between two characters exceeds the setting value, the timeout flag is ON. You can set the register to 0 to disable communication timeout monitoring. See the MODRW instruction set between 100–32767 (ms).

## Setting the communication format for a serial communication port

b0	Data length			7 (value=0)		8 (value=1)	
	b2-b1	Parity bits			00	:	None
01					:	Odd	
10					:	Even	
b3	stop bits			1 bit (value=0)		2 bits (value=1)	
b7-b4	0001	(16#1)	:	4800			
	0010	(16#2)	:	9600			
	0011	(16#3)	:	19200			
	0100	(16#4)	:	38400			
	0101	(16#5)	:	57600			
	0110	(16#6)	:	115200			
	0111	(16#7)	:	230400		Not available for RS-232	
	1000	(16#8)	:	500000		Not available for RS-232	
	1001	(16#9)	:	921000		Not available for RS-232	
1111	(16#F)	:	Self-defined*1				
b8-b15	Undefined (reserved)						

\*1: You can set the baud rate in HWCONFIG in ISPSOft.

The data transmission speed is listed in the following table.

Baud rate (bps)	RTU timeout timer (ms)	Baud rate (bps)	RTU timeout timer (ms)
4800	9	115200	1
9600	5	230400	1
19200	3	-	-
38400	2	-	-
57600	1	-	-

## 6.20 Other Instructions

### 6.20.1 List of Other Instructions

The following table lists the Other Instructions covered in this section.

API	Instruction code		Pulse instruction	Function
	16-bit	32-bit		
<b><u>1900</u></b>	WDT	–	✓	Watchdog timer
<b><u>1901</u></b>	DELAY	–	✓	Delaying the execution of the program
<b><u>1902</u></b>	GPWM	–	–	General pulse width modulation
<b><u>1904</u></b>	EPUSH	–	✓	Storing the contents of the index registers
<b><u>1905</u></b>	EPOP	–	✓	Reading data into the index registers
<b><u>1906</u></b>	INFO	–	✓	Reading the system data

### 6.20.2 Explanation of Other Instructions

API	Instruction code		Operand	Function
1900	WDT	P	—	Watchdog timer


Pulse instruction	16-bit instruction	32-bit instruction
AS	AS	—

**Symbol**



**Explanation**


1. This instruction resets the watchdog timer to monitor the operation of the AS Series PLC system.
2. If the program scanning time in the PLC exceeds 200 milliseconds, the error LED indicator is ON, and the PLC stops running.
3. The watchdog timer acts in the following cases.
  - The system is behaving abnormally.
  - Program execution takes too much time, and therefore the scan time is longer than the watchdog timer setting value. There are two way you can improve the situation.
    - (a) Use the WDT instruction to reset the watchdog timer.



- (a) Refer to the ISPSOft User Manual for more information about changing the watchdog timer setting value.

**Example**

Suppose the program scanning time is 300 milliseconds. After the program is divided into two parts, and you insert the instruction WDT between these two parts, the time it takes to scan either the first part of the program or the second part of the program must be less than 200 milliseconds.



API	Instruction code			Operand							Function					
1901		DELAY	P	<b>S</b>							Delaying the execution of the program					

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
<b>S</b>	●	●			●	●		●	●		○	○	○	○		

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
<b>S</b>		●				●							

Pulse instruction	16-bit instruction	32-bit instruction
AS	AS	—

**Symbol**




**Explanation**


This instruction delays the execution of the program following the DELAY instruction for a period of time specified in **S**.

The unit of **S** is 0.1 milliseconds. (ranging from 1 to 1000)

**Example**

When X0.0 is ON, the instruction delays the execution of the program following the DELAY instruction for two milliseconds. That is, Y0.0 is ON and the states of Y0.0–Y0.15 are refreshed two milliseconds after the DELAY instruction is executed.



**Additional remarks**

1. If **S** is less than 0, there is no delay.
2. If **S** is larger than 1000, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2003.
3. You can adjust the delay according to the actual conditions of your equipment.
4. The delay can be larger than **S** due to communication or other influences.


API	Instruction code			Operand							Function				
1902		GPWM		<b>S<sub>1</sub>, S<sub>2</sub>, D</b>							General pulse width modulation				

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
<b>S<sub>1</sub></b>	●	●			●	●		●			○	○				
<b>S<sub>2</sub></b>		●			●	●		●								
<b>D</b>		●	●	●				●								

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
<b>S<sub>1</sub></b>		●				●							
<b>S<sub>2</sub></b>		●				●							
<b>D</b>	●												

Pulse instruction	16-bit instruction	32-bit instruction
—	AS	—

**Symbol**




- S<sub>1</sub>** : Pulse width
- S<sub>2</sub>** : Pulse cycle
- D** : Output device

**Explanation**

1. This instruction outputs every pulse with a width specified by **S<sub>1</sub>** and with a cycle specified by **S<sub>2</sub>** from the device specified by **D**.
2. The pulse width specified by **S<sub>1</sub>** is t. t must be between 0–3276 milliseconds.
3. The pulse cycle specified by **S<sub>2</sub>** is T. T must be between 1–32767 milliseconds, and **S<sub>1</sub>** should be less than **S<sub>2</sub>**.
4. The **S<sub>2</sub>+1** and **S<sub>2</sub>+2** parameters are for system use. Please do not change them.
5. If **S<sub>1</sub>** is less than 0, there is no pulse output. If **S<sub>1</sub>** is larger than **S<sub>2</sub>**, the output device stays ON.
6. You can change **S<sub>1</sub>** and **S<sub>2</sub>** during the execution of this instruction.
7. If the conditional contact is not enabled, there is no pulse output.
8. When using on-line editing, please reset the conditional contact to initialize the instruction.

**Example**

When the program is executed, the values in D0 and D2 are 1000 and 2000 respectively. When X0.0 is ON, the device Y0.0 outputs the pulses illustrated below. When X0.0 is OFF, Y0.0 is OFF.



#### Additional remarks

1. The instruction counts by the scan cycle. Therefore, the maximum error is one scan cycle. Besides, **S<sub>1</sub>**, **S<sub>2</sub>**, and (**S<sub>2</sub>-S<sub>1</sub>**) should be larger than the scan cycle; otherwise, an error occurs when the GPWM instruction is executed.
2. If you use the instruction in a function block or an interrupt task, an inaccurate pulse output occurs.
3. If you declare the operand **S<sub>2</sub>** in ISPSOft, the data type is ARRAY [3] of WORD/INT.


API	Instruction code			Operand							Function				
1904		EPUSH	P	<b>D</b>							Storing the contents of the index registers				

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
<b>D</b>								●								

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
<b>D</b>		●				●							

Pulse instruction	16-bit instruction	32-bit instruction
AS	AS	—


**Symbol**



**D** : Device to store the value in the index registers

**Explanation**

1. This instruction stores the values in E0–E9 in the devices specified by **D**. The valid range for **D** is between 0–99. The instruction is not executed for values that exceed the range.
2. The instruction uses sixteen devices, and the last six devices are for system use. If you execute the instruction and the number of times the data is stored is n (the value in **D**), the instruction stores data in E0–E9 in **D**+(16\*n+1)–**D**+(16\*n+16), and increments the value in **D** to n+1.
3. The storage for the device D is 1601 (16x100+1).
4. This instruction uses a pulse instruction to interact with the stack, pushing a value onto the stack. Therefore, you must reset the contact before the next operation.
5. When you use this instruction with the EPOP instruction (API 1905), the value stored last in the device specified by **D** is read first, following the LIFO (last in first out) principle.




**Example**

Suppose the value in D0 is 0.

When X0.0 is ON for the first time, the instruction transmits the data in E0–E9 to D1–D10 and increments the value in D0 to 1.

When X0.0 switches from OFF to ON for the second time, the instruction transmits the data in E0–E9 to D17–D26, and increments the value in D0 to 2.

When X0.0 switches from OFF to ON for the  $n^{\text{th}}$  time, the instruction transmits the data in E0–E9 to  $(n*16)+1-(n*16)+10$ .

**Additional remarks**

1. If the value in **D** is not between 0–99, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2003.
2. If the range of devices is not sufficient for  $D+((\text{the value in } D)+1)*16-1$ , the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2003.


API	Instruction code			Operand							Function					
1905		EPOP	P	<b>D</b>							Reading the data into the index registers					

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	“\$”	F
<b>D</b>								●								

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
<b>D</b>		●				●							

Pulse instruction	16-bit instruction	32-bit instruction
AS	AS	—


**Symbol**



**D** : Device from which the value is read


**Explanation**

1. This instruction reads the values in the devices specified by **D** into E0–E9, and decrements the value in **D** by one. The valid value for **D** is between 1–100. The instruction does not execute values that exceed the range.
2. The instruction involves sixteen devices, and the last six devices are for system use. If you execute the instruction and the number of times the data is stored is n (the value in **D**), the instruction stores the data in E0–E9 in **D**+16\*(n-1)+1–**D**+16\*(n-1)+10, and decrements the value in **D** to n-1.
3. This instruction uses a pulse instruction to interact with the stack, taking the TOP VALUE from the stack and assigning it to the specified variable; therefore, you must reset the contact before the next operation.
4. The value that the instruction stores last in the device specified by **D** is read first, following the LIFO (last in first out) principle.



**Example**

When X0.0 is ON, the MOV instruction sets the value in D0 is set to 0, and the EPUSH instruction transmits the values in E0–E9 to D1–D10. After the execution of FB0 is complete, the EPOP instruction reads the values in D1–D9 into E0–E9.

**Additional remarks**

1. If the value in **D** is not in the range 0–100, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2003.
2. If the range of device is not sufficient for  $D + ((\text{the value in } D) * 16 - 1)$ , the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2003.

API	Instruction			Operand							Description			
1906		INFO	P	<b>S, D</b>							Reading the system data			

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
<b>S</b>													○			
<b>D</b>								●								

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
<b>S</b>		●				●							
<b>D</b>		●				●							

Pulse Instruction	16-bit instruction	32-bit instruction
AS	AS	—

**Symbol**

**S** : System-data reading code



**D** : Starting device where the read system data are stored

**Explanation**

- S** is the system information reading code and the codes are listed in the following table.

S code No.	Description	Number of consecutive <b>D</b> devices (Number of Words)	Remark	Supported version
0	Reads the serial number of the product	9	ASCII code	V1.04 and later
1	Reads Ethernet Mac ID	3	Hex value	V1.04 and later
2	Reads already-power-on time	2	32-bit value, unit: minutes	V1.04 and later
others	Reserved	0	The instruction is not executed.	

2. If the product serial no. is AS332T-AW16360001, the reading code of the instruction is 0 and the read data are stored in the devices starting from D0, the product serial no. is stored in the order as below.

D0	D1	D2	D3	D4	D5	D6	D7	D8
16#5341	16#3333	16#5432	16#412D	16#3157	16#3336	16#3036	16#3030	16#0031
'SA'	'33'	'T2'	'A-'	'1W'	'36'	'06'	'00'	'1'

3. If Mac ID is 16#123456789ABC, the reading code of the instruction is 1 and the read data are stored in the devices starting from D10, the Mac ID data are stored in the order as below.

D10	D11	D12
16#1234	16#5678	16#9ABC

4. If the already-power-on time is 70000 minutes (16#00011170), the reading code of the instruction is 2 and the read data are stored in the devices starting from D20, the already-power-on time data are stored in the order as below.

D20	D21
16#1170	16#0001

5. Only the first-time execution of the INFO instruction is effective when the conditional contact is met. Therefore, it is recommended to use the pulse instruction INFOP. If the INFO instruction is used with the normally-open contact together, the instruction will be automatically executed only once.

**Additional remark:**

If **D** is declared in a variable and the code is 0, 1 and 2, they can be declared respectively in ARRAY [9], [3], [2] of WORD.

## 6.21 String Processing Instructions

### 6.21.1 List of String Processing Instructions

The following table lists the String Processing instructions covered in this section.

API	Instruction code		Pulse instruction	Function
	16-bit	32-bit		
<b><u>2100</u></b>	BINDA	DBINDA	✓	Converting a signed decimal number into an ASCII code
<b><u>2101</u></b>	BINHA	DBINHA	✓	Converting a binary hexadecimal number into an hexadecimal ASCII code
<b><u>2102</u></b>	BCDDA	DBCDDA	✓	Converting a binary-coded decimal number into an ASCII code
<b><u>2103</u></b>	DABIN	DDABIN	✓	Converting a signed decimal ASCII code into a signed decimal binary number
<b><u>2104</u></b>	HABIN	DHABIN	✓	Converting a hexadecimal ASCII code into a hexadecimal binary number
<b><u>2105</u></b>	DABCD	DDABCD	✓	Converting an ASCII code into a binary-coded decimal number
<b><u>2106</u></b>	\$LEN	–	✓	Calculating the length of a string
<b><u>2109</u></b>	\$FSTR	–	✓	Converting a floating-point number into a string
<b><u>2110</u></b>	\$FVAL	–	✓	Converting a string into a floating-point number
<b><u>2111</u></b>	\$RIGHT	–	✓	Retrieving characters from a string starting from the right
<b><u>2112</u></b>	\$LEFT	–	✓	Retrieving characters from a string starting from the left
<b><u>2113</u></b>	\$MIDR	–	✓	Retrieving a part of a string
<b><u>2115</u></b>	\$SER	–	✓	Searching a string
<b><u>2116</u></b>	\$RPLC	–	✓	Replacing the characters in a string
<b><u>2117</u></b>	\$DEL	–	✓	Deleting the characters in a string
<b><u>2118</u></b>	\$CLR	–	✓	Clearing a string
<b><u>2119</u></b>	\$INS	–	✓	Inserting a string
<b><u>2122</u></b>	SPLIT	–	✓	Splitting a string
<b><u>2123</u></b>	MERGE	–	✓	Merging strings

### 6.2.1.2 Explanation of String Processing Instructions


API	Instruction code			Operand								Function			
2100	D	BINDA	P	S, D								Converting a signed decimal number into an ASCII code			

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	“\$”	F
S	●	●			●	●	●	●	●		○	○	○	○		
D		●			●	●		●								

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
S		●	●			●	●						
D		●				●							

Pulse instruction	16-bit instruction	32-bit instruction
AS	AS	AS

**Symbol**




**S** : Source value

**D** : Device where the conversion result is stored


**Explanation**

1. This instruction converts the signed decimal binary number in **S** into an ASCII code, and stores the conversion result in **D**.
2. The instruction supports SM690 to control the ending character.
3. For 16-bit instructions, the value in **S** must be a binary number and between -32768 to 32767. The operand **D** occupies four word devices. The instruction converts the data is converted as follows.




If SM690 is OFF, the instruction stores the ending character 16#0000 in **D+2**. If SM690 is ON, the value in **D+2** is unchanged without the ending character.

If the value in **S** is a positive value, the instruction stores only the value but not the sign character in **D**. If the value in **S** is a negative value, the instruction stores the “-” sign character in **D** (16#2D). For example, if the value in **S** is -12345 and SM690 is OFF, the conversion result is as follows.




4. For 32-bit instructions, the value in **S** must be a binary number between -2147483648 to 2147483647. The operand **D** occupies six word devices. The data is converted as follows.




If SM690 is OFF, the instruction stores the ending character 16#0000 in **D+4**. If SM690 is ON, the value in **D+4** is unchanged without the ending character.

In addition, if the value in **S** is a positive value, the instruction stores only the value but not the sign character in **D**. If the value in **S** is a negative value, the instruction stores the “-” sign character in **D** (16#2D). For example, if the value in **S** is -12345678, and SM690 is OFF, the conversion result is as follows.




**Example 1**

Suppose the value in L0 is 5126 and SM690 is OFF. When the instruction executes, the values are D0=16#3135, D1=16#3632, D2=16#0000.



**Example 2**

Suppose the value in D10 is -3842563 and SM690 is OFF. When the instruction is executed, the values are D0=16#332D, D1=16#3438, D2=16#3532, D3=16#3336, D4=16#0000.



**Additional remarks**

1. If value in the device **D** is not sufficient for the conversion, SM0 is ON, and the error code in SR0 is 16#2003.
2. For 16-bit instructions, if you declare the operand **D** in ISPSOft, the data type is ARRAY [4] of WORD/INT.
3. For 32-bit instructions, if you declare the operand **D** in ISPSOft, the data type is ARRAY [6] of WORD/INT.

API	Instruction code			Operand							Function				
2101	D	BINHA	P	S, D							Converting a binary hexadecimal number into a hexadecimal ASCII code				

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
S	●	●			●	●	●	●	●		○	○	○	○		
D		●			●	●		●								

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
S		●	●			●	●						
D		●				●							

Pulse instruction	16-bit instruction	32-bit instruction
AS	AS	AS

**Symbol**




**S** : Source value  
**D** : Device where the conversion result is stored

**6**

**Explanation**


- This instruction converts the hexadecimal binary number in **S** an ASCII code, and stores the conversion result in **D**.
- The instruction supports SM690 to control the ending character.
- For 16-bit instructions, the value in **S** must be between 16#0000–16#FFFF, and should be a four-digit binary number. The operand **D** occupies three word devices.

If SM690 is OFF, 16#0000 is stored in **D**+2. If SM690 is ON, the value in **D**+2 is unchanged. For example, if the value in **S** is 16#02A6 and SM690 is OFF, the conversion result is as follows.




- For 32-bit instructions, the value in **S** must be between 16#00000000–16#FFFFFFFF, and should be an eight-digit binary number. The operand **D** occupies five word devices.

If SM690 is OFF, 16#0000 is stored in **D**+4. If SM690 is ON, the value in **D**+4 is unchanged. For example, if the value in **S** is 16#03AC625E and SM690 is OFF, the conversion result is as follows.




**Example 1**


Suppose the value in D10 is 16#9C06 and SM690 is OFF. When the instruction executes, the values are D0=16#4339, D1=16#3630, D2=16#0000.



**Example 2**

Suppose the value in D10 is 16#7B3C581F and SM690 is OFF. When the instruction executes, the values are D0=16#4237, D1=16#4333, D2=16#3835, D3=16#4631, D4=16#0000.



**Additional remarks**

1. For 16-bit instructions, if **D**+2 exceeds the device range, SM0 is ON, and the error code in SR0 is 16#2003.
2. For 32-bit instructions, if **D**+4 exceeds the device range, SM0 is ON, and the error code in SR0 is 16#2003.
3. For 16-bit instructions, if you declare the operand **D** in ISPSOft, the data type is ARRAY [3] of WORD/INT.
4. For 32-bit instructions, if you declare the operand **D** in ISPSOft, the data type is ARRAY [5] of WORD/INT.


API	Instruction code			Operand							Function					
2102	D	BCDDA	P	<b>S, D</b>							Converting a binary-coded decimal number into an ASCII code					

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	“\$”	F
<b>S</b>	●	●			●	●	●	●	●		○	○	○	○		
<b>D</b>		●			●	●		●								

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
<b>S</b>		●	●			●	●						
<b>D</b>		●				●							

Pulse instruction	16-bit instruction	32-bit instruction
AS	AS	AS

**Symbol**




**S** : Source value

**D** : Device where the conversion result is stored


**Explanation**

- This instruction converts a binary-coded decimal number in **S** into an ASCII code, and stores the conversion result in **D**.
- The instruction supports SM690 to control the ending character.
- The binary-coded decimal value in **S** used in the 16-bit instruction must be between 0–9999, and should be a four-digit binary-coded decimal value. The operand **D** occupies three word devices. The data is converted as follows.



If SM690 is OFF, the instruction stores the ending character 16#0000 in **D**+2. If SM690 is ON, the value in **D**+2 is unchanged without the ending character.


- For 32-bit instructions, the binary-coded decimal value in **S** must be between 0–99999999, and should be an eight-digit binary-coded decimal value. The operand **D** occupies five word devices. The data is converted as follows.



- If SM690 is OFF, the instruction stores the ending character 16#0000 in D+5. If SM690 is ON, the value in D+5 is unchanged without the ending character.
- Even if the first digit of binary-coded decimal value in S is 0, the instruction converts it into an ASCII code 0 (16#30).


**Example 1**

Suppose the binary-coded decimal value in D10 is 1295 and SM690 is OFF. When the instruction executes, the values are D0=16#3231, D1=16#3539, D2=16#0000.



**Example 2**

Suppose the binary-coded decimal value in D10 is 00578352 and SM690 is OFF. When the instruction executes, the values are D0=16#3030, D1=16#3735, D2=16#3338, D3=16#3235, D4=16#0000.



**Additional remarks**

1. For 16-bit instructions, if the value in **S** is not between 0–9999, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#200D. The binary-coded decimal value is represented by the hexadecimal number, but one of digits is not within the range between 0 and 9.
2. For 32-bit instructions, if the value in **S** is not between 0–99999999, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#200D. The binary-coded decimal value is represented by the hexadecimal number, but one of digits is not within the range between 0 and 9.
3. For 16-bit instructions, if **D+2** exceeds the device range, SM0 is ON, and the error code in SR0 is 16#2003.
4. For 32-bit instructions, if **D+4** exceeds the device range, SM0 is ON, and the error code in SR0 is 16#2003.
5. For 16-bit instructions, if you declare the operand **D** in ISPSOft, the data type is ARRAY [3] of WORD/INT.
6. For 32-bit instructions, if you declare the operand **D** in ISPSOft, the data type is ARRAY [5] of WORD/INT.

API	Instruction code			Operand							Function					
2103	D	DABIN	P	S, D							Converting a signed decimal ASCII code into a signed decimal binary number					

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
S		●			●	●		●	●						○	
D		●			●	●	●	●			○	○				

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
S		●				●							●
D		●	●			●	●						

Pulse instruction	16-bit instruction	32-bit instruction
AS	AS	AS

**Symbol**

DABIN	DABINP
En	En
S	S
D	D


DDABIN	DDABINP
En	En
S	S
D	D

**S** : Source value


**D** : Device where the conversion result is stored

**Explanation**


1. This instruction converts the signed decimal ASCII code in **S** into a signed decimal binary number, and stores the conversion result in **D**.
2. For 16-bit instructions, the operand **S** occupies three word devices, and the decimal ASCII code in **S** must be between -32768 to 32767. If the value in **S** is a string and does not include the ending character 16#00, the conversion can be up to 5 digits (excluding the sign).




3. If the first character is " " (a space), the sign is a positive sign. If the first character is "-", the sign is a negative sign. Take the string "2345" for example.



4. For 32-bit instructions, the operand **S** occupies six word devices, and the decimal ASCII code in **S** must be between -2147483648 to 2147483647. If the value in **S** is a string and does not include the ending character 16#00, the conversion can be up to 10 digits (sign excluded).





5. If the first character is " " (a space), the sign is a positive sign. If the first character is "-", the sign is a negative sign. Take the string "-234567890" for example.



6. If the first digit of the string in the device **S** is blank (16#20) + sign (16#2B), the value in **S** is processed as 0. For the second digit, if the number is not 0–9, the instruction treats it as the end of a string and no error message will be shown. For example if the word order is 16#20→16#31→16#32→16#2B, the conversion result is 12.
7. For 16-bit instructions, the string range in the device **S** is 1–6 (positive or negative signs included) and for 32-bit instruction the range is 1–11 (positive negative signs included).
8. Only the 32-bit instructions can use the 32-bit counter, but not the device E.



**Example 1**

Suppose the values are D20=16#302D, D21=16#3433, D22=16#0035. When the instruction executes, the value is D0=-345.




**Example 2**

Suppose the values are D20=16#322D, D21=16#3433, D22=16#3635, D23=16#2037, D24=16#0000, D25=16#0000. When the instruction executes, the value is D0=-234567.



**Example 3**

Suppose the string value in **S** is 12. When the instruction executes, the value is D0=12.

**Additional remarks**

1. If the value of the first word in **S** is an ending character (16#00), the value is processed as 0 (16#30).
2. If the value of the first digit in **S** is 16#20 (blank) or 16#2B (+) or 16#2D (-) and the second digit is 16#00, the value in **S** is processed as 0 (16#30).
3. Even if the first digit of binary-coded decimal value in **S** is 0, it is converted into the ASCII code 0 (16#30).
4. The value of the first digit in **S** only supports ASCII codes, 16#30–16#39 (0–9), 16#200 (blank), 16#2D (negative sign), 16#2B (positive sign), 16#00 (ending character). If the value of the first digit in **S** is not ASCII code, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2003.
5. Except the first digit, if the value of other digits in **S** are not ASCII codes, 16#30–16#39 or 16#00, the value in **S** is processed as 16#00.
6. If the value in **S** exceeds the device range, SM0 is ON, and the error code in SR0 is 16#2003. The instruction is not executed.
7. For 16-bit instructions, if you declare the operand **S** in ISPSOft, the data type is ARRAY [3] of WORD/INT.
8. For 32-bit instructions, if you declare the operand **S** in ISPSOft, the data type is ARRAY [6] of WORD/INT.

API	Instruction code			Operand						Function					
2104	D	HABIN	P	<b>S, D</b>						Converting a hexadecimal ASCII code into a hexadecimal binary number					

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	“\$”	F
<b>S</b>		●			●	●		●	●						○	
<b>D</b>		●			●	●	●	●			○	○				

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
<b>S</b>		●				●							●
<b>D</b>		●	●			●	●						

Pulse instruction	16-bit instruction	32-bit instruction
AS	AS	AS

**Symbol**




**S** : Source value

**D** : Device where the conversion result is stored


**6**

**Explanation**

1. This instruction converts a hexadecimal ASCII code in **S** into a hexadecimal binary number, and stores the conversion result in **D**.
2. For 16-bit instructions, the operand **S** occupies two word devices. If the value in **S** is a string and does not include the ending character 16#00, the conversion can be up to 4 digits (sign excluded). The hexadecimal ASCII code in **S** must be between 0000–FFFF. If **S** is a string, the string must be between “0”–“FFFF”.





3. For 32-bit instructions, the operand **S** occupies four word devices. If the value in **S** is a string and does not include the ending character 16#00, the conversion can be up to 8 digits (sign excluded). The hexadecimal ASCII code in **S** must be between 00000000–FFFFFFFF. If **S** is a string, the string must be between “0”–“FFFFFFFF”.



4. The valid string range in the device **S** for 16-bit instruction is 1–4 and for 32-bit instruction it is 1–8.


**Example 1**


Suppose the values are D20=16#3641, D21=16#4633 (ASCII 16#A63F). When the instruction executes, the value is D0=-22977.



**Example 2**


Suppose the values are D20=16#4634, D21=16#3244, D22=16#3738, D23=16#3035 (ASCII 16#4FD28750). When the instruction executes, the value is (D1, D0)=16#4FD28750.







**Example 3**

Suppose the string value in **S** is A. When the instruction executes, the value is D20=16#A=10.



**Example 4**

Suppose the values are D20=16#3641, D21=16#4600 (ASCII 16#00A6). When the instruction executes, the value is D0=166.



**Additional remarks**

1. If the ASCII code in **S** is not between 16#30–16#39 (“0”–“9”), or between 16#41–16#46 (“A”–“F”), the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2003.
2. For 16-bit instructions, if you declare the operand **S** in ISPSOft, the data type is ARRAY [2] of WORD/INT.
3. For 32-bit instructions, if you declare the operand **S** in ISPSOft, the data type is ARRAY [4] of WORD/INT.


API	Instruction code			Operand							Function				
2105	D	DABCD	P	S, D							Converting an ASCII code into a binary-coded decimal number				

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
S		●			●	●		●	●						○	
D		●			●	●	●	●			○	○				

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
S		●				●							●
D		●	●			●	●						

Pulse instruction	16-bit instruction	32-bit instruction
AS	AS	AS

**Symbol**




**S** : Source value

**D** : Device where the conversion result is stored


**Explanation**

- This instruction converts the ASCII code in **S** into a binary-coded decimal number, and stores the conversion result in **D**.
- For 16-bit instructions, the operand **S** occupies two word devices, and the ASCII code in **S** must be between 0000–9999. If **S** is a string, the string must be between "0"–"9999".



- For 32-bit instructions, the operand **S** occupies four word devices, and the ASCII code in **S** must be between 0000000–99999999. If **S** is a string, the string must be between "0"–"99999999".







4. If the value in **S** is 16#20 the value is processed as 16#30. If the value in **S** is 16#00, the value is processed as an ending character.
5. For 16-bit instructions, if **S** is a string, the number of characters contained in the string must be between 1–4. For 32-bit instructions, if **S** is a string, the number of characters contained in the string must be between 1–8.



**Example 1**

Suppose the values are D20=16#3820, D21=16#3637 (ASCII 876). When the instruction executes, the instruction converts the value into Y0=16#876.




**Example 2**

Suppose the values are D20=16#3738, D21=16#3536, D22=16#3334, D23=16#3132 (ASCII 87654321). When the instruction executes, the value is (D11, D10)= 16#87654321.




**Example 3**

Suppose the string value in S is 1. When the instruction executes, the value is D20=16#0001.



**Example 4**

Suppose the string value in S is 1234. When the instruction executes, the value is (D21, D20)= 16#00001234.



**Additional remarks**

1. If the ASCII code in **S** is not ASCII codes 16#30–16#39, 16#20, or 16#00, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2003.
2. If **S** is a string and the number of characters contained in the string exceeds the range, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2003.
3. For 16-bit instructions, if you declare the operand **S** in ISPSOft, the data type is ARRAY [2] of WORD/INT.
4. For 32-bit instructions, if you declare the operand **S** in ISPSOft, the data type is ARRAY [4] of WORD/INT.

API	Instruction code			Operand								Function				
2106		\$LEN	P	S, D								Calculating the length of a string				

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
S	●	●			●	●		●								
D		●			●	●		●			○	○				

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
S		●				●							●
D		●				●							

Pulse instruction	16-bit instruction	32-bit instruction
AS	AS	-

Symbol




S : String

D : Length of the string

6

Explanation

1. This instruction calculates the length of the string in **S**, exclusive of the ending character (16#00), and stores the length of the string in **D**.
2. The value stored in **D** must be between 0–32767. If it exceeds this range, the value in **D** is processed as 32767.



If the data in **S-S+4** is ABCDEFGHI, the calculation result is as follows.




API	Instruction code			Operand							Function					
2109		\$FSTR	P	<b>S<sub>1</sub>, S<sub>2</sub>, D</b>							Converting a floating-point number into a string					

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
<b>S<sub>1</sub></b>	●	●			●	●		●	●							○
<b>S<sub>2</sub></b>	●	●			●	●		●	●							
<b>D</b>		●			●	●		●								

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
<b>S<sub>1</sub></b>									●				
<b>S<sub>2</sub></b>		●				●							
<b>D</b>		●				●							

Pulse instruction	16-bit instruction	32-bit instruction
AS	AS	-

**Symbol**




- S<sub>1</sub>** : Source value
- S<sub>2</sub>** : First device where the format is stored
- D** : First device where the conversion result is stored

**6**

**Explanation**

- This instruction converts the floating-point number in **S<sub>1</sub>** into a string in accordance with the format setting value in **S<sub>2</sub>**, and stores the conversion result in **D**.
- This instruction converts the floating-point number in **S<sub>1</sub>** into a string and appends the ending character 16#00 to the end of the string, and then stores the conversion result in **D**.



3. The conversion result varies with the setting of **S<sub>2</sub>**.
4. The value in **S<sub>2+1</sub>** must be between  $2 \leq S_{2+1} \leq 20$ ; the sign (+,-) and the digits in an integer or decimal number are included but the decimal point in a decimal number and the exponent number are not included.

Operand	Description
<b>S<sub>2</sub></b>	0: Decimal format 1: Exponential
<b>S<sub>2+1</sub></b>	Number of character

5. If the value in **S<sub>1</sub>** is a positive number, the first ASCII code can be stored in **D**; if the value in **S<sub>1</sub>** is a negative number, the sign 16#2D (-) is stored first and then the second ASCII is stored.
6. Decimal format (**S<sub>2</sub>=0**)

After conversion, the floating-point string in the device D.



- The value in **S<sub>2+1</sub>** must be between  $2 \leq S_{2+1} \leq 20$ ; the sign (+,-) and the digits in an integer or decimal number are included but the decimal point in a decimal number and the exponent number are not included.
- Example 1

Suppose the number of characters is eight. Two floating-point numbers examples are -1.2345678 and 123456. The calculation is as follows.

D number	Floating-point number -1.2345678		Floating-point number 123456	
	High byte	Low byte	High byte	Low byte
<b>D</b>	16#31 (1)	16#2D (-)	16#32 (2)	16#31 (1)
<b>D + 1</b>	16#32 (2)	16#2E (.)	16#34 (4)	16#33 (3)
<b>D + 2</b>	16#34 (4)	16#33 (3)	16#36 (6)	16#35 (5)
<b>D + 3</b>	16#36 (6)	16#35 (5)	16#00 ending character	
<b>D + 4</b>	16#00 ending character	16#38 (8)		

After the conversion, if the floating-point number is stored in **S<sub>2+1</sub>** but if the length exceeds the value in **S<sub>2+1</sub>**, the instruction rounds off the digits in the decimal number. The floating-point string does not have to fill all of **S<sub>2+1</sub>**.

- Example 2

After the conversion, if the floating-point number is stored in **S<sub>2</sub>+1**, the instruction uses the exponential format to convert. For example, the number of characters is five digits and the floating-point number is 1234567, the conversion result is 1.2346E+06.

D number	Floating-point number 1234567	
D	16#2E (.)	16#31 (1)
D + 1	16#33 (3)	16#32 (2)
D + 2	16#36 (6)	16#34 (4)
D + 3	16#2B (+)	16#45 (E)
D + 4	16#32 (6)	16#30 (0)
D + 5	16#0000 ending character	

- Example 3

After the conversion, if the floating-point number is stored in **S<sub>2</sub>+1**, the instruction uses the exponential format to convert. For example, the number of characters is two digits and the floating-point number is 0.00012345, the conversion result is 1.2E-04.

D number	Floating-point number 0.00012345	
D	16#2E (.)	16#31 (1)
D + 1	16#45 (E)	16#32 (2)
D + 2	16#30 (0)	16#2D (-)
D + 3	16#00 ending character	16#34 (4)

- Example 4

After the conversion, if the absolute value of the floating-point number is  $\leq 10^{-5}$ , the instruction uses the exponential format to convert. For example, the number of characters is four digits and the floating-point number is 0.00001234, the conversion result is 1.234E-05.

D number	Floating-point number 0.00001234	
D	16#2E (.)	16#31 (1)
D + 1	16#33 (3)	16#32 (2)
D + 2	16#45 (E)	16#34 (4)
D + 3	16#30 (0)	16#2D (-)
D + 4	16#00 ending character	16#35 (5)

### 7. Exponential format ( $S_2=1$ )

After conversion,  
the floating-point string  
in the device D.



- The value in  $S_2+1$  must be between  $2 \leq S_2+1 \leq 20$ ; the sign (+,-) and the digits in an integer and decimal number are included but the decimal point in the decimal number and the exponent number are not included. After calculation, the length adds the exponents (four digits) and the decimal point of the decimal number.
- The number of character in the area for the integer is one digit.
- The number of character in the area for the exponent is four characters.

If the exponent is a positive number, the instruction adds 16#2B (+) in the area for exponent in **D**. If the exponent is a negative number, the instruction adds 16#2D (-) in the area for exponent in **D**. The number of character in the area for the exponent is two digits. If there is only one digit in the conversion result, the instruction adds 16#30 (0) as the first digit of the area for the exponent.

- Example

Suppose the number of characters is eight. Two floating-point numbers examples are -123.456789 and 123456. The calculation is as follows.

D number	Floating-point number -123.456789		Floating-point number 12345	
	High byte	Low byte	High byte	Low byte
D	16#31 (1)	16#2D (-)	16#2E (.)	16#31 (1)
D + 1	16#32 (2)	16#2E (.)	16#33 (3)	16#32 (2)
D + 2	16#34 (4)	16#33 (3)	16#35 (5)	16#34 (4)
D + 3	16#36 (6)	16#35 (5)	16#2B (+)	16#45 (E)
D + 4	16#45 (E)	16#38 (8)	16#34 (4)	16#30 (0)
D + 5	16#30 (0)	16#2B (+)	16#00 ending character	
D + 6	16#00 ending character	16#32 (2)		

After the conversion, if the floating-point number is stored in **S<sub>2</sub>+1**, and the instruction rounds off the extra digits.


The conversion result of the string length for the floating number -123.456789 in eight characters is 13 (the ending character excluded).

The conversion result of the string length for the floating number 12345 in eight characters is 10 (the ending character excluded).

The floating-point string does not have to fill all the characters.

**Example 1**


The floating-point number in (D1, D0= 12.3456) is converted into the decimal format in a string (D4=0, D5=8).



D10	16#32 ( 2 )	16#31 ( 1 )
D11	16#33 ( 3 )	16#2E ( . )
D12	16#35 ( 5 )	16#34 ( 4 )
D13	16#00 ending character	16#36 ( 6 )

**Example 2**

The floating-point number in (D1, D0 = 0.0012345678) is converted into the exponential format in a string (D4=1, D5=8).



D10	16#2E (.)	16#31 (1)
D11	16#33 (3)	16#30 (2)
D12	16#35 (5)	16#34 (4)
D13	16#37 (7)	16#36 (6)
D14	16#45 (E)	16#38 (8)
D15	16#30 (0)	16#2D (-)
D16	16#00 ending character	16#33 (3)

**Additional remarks**

1. If the value in **S1** exceeds the range of values that can be represented by floating-point numbers, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2013.
2. If the value in **S2** is neither 0 nor 1, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2003.
3. If the value in **S2+1** is not in between  $2 \leq S2+1 \leq 20$ , the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2003.
4. If you declare the operand **S2** in ISPSOft, the data type is ARRAY [2] of WORD/INT.


API	Instruction code			Operand							Function		
2110		\$FVAL	P	<b>S, D</b>							Converting a string into a floating-point number		

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
<b>S</b>	●	●			●	●		●	●						○	
<b>D</b>		●			●	●		●								

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
<b>S</b>		●				●							●
<b>D</b>									●				

Pulse instruction	16-bit instruction	32-bit instruction
AS	AS	-

**Symbol**




**S** : Source value

**D** : Device where the conversion result is stored

**Explanation**

- This instruction converts a string in **S** into a floating-point number, and stores the conversion result in **D**.



- Refer to the following sections for the ASCII code usage.
- For decimal or exponential formats, the maximum length for the floating-point string (**m**) is 24 characters (excluding the ending character 16#00) and the maximum length of **n** is 13 characters.

2. The format of the value in **S** can be decimal or exponential. The instruction automatically determines the format according to the value in **S**.

- Decimal format: the length for the floating-point string is nine; the ending character 16#00 is not included.

	High byte	Low byte	
<b>S</b>	16#31 (1)	16#32 (2)	
<b>S + 1</b>	16#32 (2)	16#2E (.)	
<b>S + 2</b>	16#34 (4)	16#33 (3)	⇒
<b>S + 3</b>	16#36 (6)	16#35 (5)	
<b>S + 4</b>	16#00 ending character	16#37 (7)	

<b>D</b> 21.234567
-----------------------

OR

	High byte	Low byte	
<b>S</b>	16#31 (1)	16#2D (-)	
<b>S + 1</b>	16#32 (2)	16#2E (.)	
<b>S + 2</b>	16#34 (4)	16#33 (3)	⇒
<b>S + 3</b>	16#36 (6)	16#35 (5)	
<b>S + 4</b>	16#00 ending character	16#38 (8)	

<b>D</b> -1.234568
-----------------------


- Exponential format: the length for the floating-point string is 9; the ending character 16#00 is not included.

	High byte	Low byte	
<b>S</b>	16#31 (1)	16#2D (-)	
<b>S + 1</b>	16#32 (2)	16#2E (.)	
<b>S + 2</b>	16#45 (E)	16#33 (3)	⇒
<b>S + 3</b>	16#30 (0)	16#2B (+)	
<b>S + 4</b>	16#00 ending character	16#32 (3)	

<b>D</b> -1230
-------------------


3. If the sign code in **S** is 16#20, 16#30, or 16#2B, then the conversion result is a positive value. If the sign code in **S**<sub>1</sub> is 16#2D, then the conversion result is a negative value.

**Example 1**



D0	16#31 (1)	16#32 (2)	
D1	16#32 (2)	16#2E (.)	( D11 · D10 )
D2	16#34 (4)	16#33 (3)	⇒ 21.234567
D3	16#36 (6)	16#35 (5)	
D4	16#00 ending character	16#37 (7)	

**Example 2**



D0	16#31 (1)	16#2D (-)	
D1	16#32 (2)	16#2E (.)	( D101 · D100 )
D2	16#45 (E)	16#33 (3)	⇒ -1230
D3	16#30 (0)	16#2B (+)	
D4	16#00 ending character	16#32 (3)	

**Additional remarks**

1. If the length of the string in **S** exceeds 25 bytes and does not end with 16#00, SM0 is ON, and the error code in SR0 is 16#2003.
2. There are some rules for the value in **S**. If the value in **S** does not follow the rules, the instruction is not executed, SM0 is ON and the error code in SR0 is 16#2003.

The first ASCII code: signs 16#2B(+), 16#2D(-), blank 16#20, and numbers 16#30(0)–16#39(9) are allowed.

If the first ASCII code is a sign or a blank, the second ASCII code must be a number.

The second ASCII code can be in either decimal or exponential format.

- Decimal format:



The decimal point “.” (16#2E), can only occur once and there must be numbers before and after the decimal point.

- Exponential format:



The decimal point “.” (16#2E), can only occur once and there must be numbers before and after the decimal point.

There must be a number before the exponent.

Integers: only numbers “0” (16#30)–“9” (16#39) are allowed.

Decimals: only numbers “0” (16#30)–“9” (16#39) are allowed.

Exponents: The format for a four digit ASCII code is as below.



There must be an “E” (16#45) or “e” (16#65) and it can only occur once.

There must be a sign “+”(16#2B) or “-” (16#2D) and it can only occur once.

There must be two digits; numbers “0” (16#30)–“9”(16#39).

3. If the string in **S** is out of range, the instruction is not executed, SM is ON, and the error code in SR0 is 16#2003.
  - If the first character in the string is a number "0"–"9" (16#30–16#39), the valid range for a floating-point string is 1–24. The minimum length for the string is one.
  - If the first character in the string is a blank (16#20) or a sign ("+"(16#2B) or "-" (16#2D)), the valid range for a floating-point string is 2–24. The minimum length for the string is two ("+1").
4. If the conversion result exceeds the range of values that can be represented by floating-point numbers, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2013.


API	Instruction code			Operand							Function					
2111		\$RIGHT	P	<b>S, n, D</b>							Retrieving characters from a string beginning from the right.					

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
<b>S</b>	●	●			●	●		●	●						○	
<b>n</b>	●	●			●	●		●	●		○	○	○	○		
<b>D</b>		●			●	●		●								

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
<b>S</b>		●				●							●
<b>n</b>		●				●							
<b>D</b>		●				●							

Pulse instruction	16-bit instruction	32-bit instruction
AS	AS	-

**Symbol**




**S** : String

**n** : Number of characters to be retrieved


**D** : Device where the characters retrieved are stored

**Explanation**

1. This instruction retrieves **n** characters from the string in **S** from the right, and stores the retrieved characters in **D**.  
When the data type of **S** (source value) is string, the maximum length for the value in **S** is 31 characters. When the data type of **S** (source value) is not string, the maximum length for the value in **S** is 255 characters.
2. If **n** is 0, the value in **D** is 0. The maximum length for **n** is 255 characters. .




If the data in **S** is ABCDEF12345 and **n** is 5, the instruction retrieves five characters in the string in **S** from the right. The conversion result is as follows.



6

Example



**Additional remarks**

1. If the operand **S** is not a string (\$) but a device with a string, the string in **S** can be up to 256 characters (16#00 ending character included). If the string in **S** does not end with 16#00, SM0 is ON, and the error code in SR0 is 16#200E.
2. If **n** is less than 0, it is processed as 0. If **n** is greater than the length of the string in **S**, it is processed as the length of the string is **S**.
3. If **D** is not sufficient to contain **n** characters, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2003.


API	Instruction code			Operand							Function					
2112		\$LEFT	P	<b>S, n, D</b>							Retrieving characters from a string beginning from the left.					

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
<b>S</b>	●	●			●	●		●	●						○	
<b>n</b>	●	●			●	●		●	●		○	○	○	○		
<b>D</b>		●			●	●		●								

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
<b>S</b>		●				●							●
<b>n</b>		●				●							
<b>D</b>		●				●							

Pulse instruction	16-bit instruction	32-bit instruction
AS	AS	-

**Symbol**




**S** : String

**n** : Number of characters to retrieve


**D** : Device where the characters retrieved are stored

**Explanation**

- This instruction retrieves **n** characters from the string in **S** starting from the left, and stores the retrieved characters in **D**. When **S** is a string device, the maximum length for the value in **S** is 31 characters; when the **S** is not a string device, the maximum length for the value in **S** is 255 characters.
- If **n** is 0, the value in **D** is 0.




If the data in **S** is ABCDEF12345 and **n** is 7, the instruction retrieves seven characters in the string in **S** from the left. The conversion result is as follows.



**Example**

When M0 is ON, the instruction retrieves the six characters starting from the character in D100, and stores them in D10.



**Additional remarks**

1. If the operand **S** is not a string (\$) but a device with a string, the string in **S** can be up to 256 characters(16#00 ending character included). If the string in **S** does not end with 16#00, SM0 is ON, and the error code in SR0 is 16#200E.
2. If **n** is less than 0, it is processed as 0. If **n** is greater than the length of the string in **S**, it is processed as the length of the string is **S**.
3. If **D** is not sufficient to contain **n** characters, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2003.


API	Instruction code			Operand								Function				
2113		\$MIDR	P	<b>S<sub>1</sub>, S<sub>2</sub>, D</b>								Retrieving a part of a string				

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
<b>S<sub>1</sub></b>	●	●			●	●		●	●						○	
<b>S<sub>2</sub></b>	●	●			●	●		●	●		○					
<b>D</b>		●			●	●		●								

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
<b>S<sub>1</sub></b>		●				●							●
<b>S<sub>2</sub></b>		●				●							
<b>D</b>		●				●							

Pulse instruction	16-bit instruction	32-bit instruction
AS	AS	-


**Symbol**




- S<sub>1</sub>** : String
- S<sub>2</sub>** : Part of the string to be retrieved
- D** : Device where the characters retrieved are stored

**6 Explanation**


- Suppose the values in **S<sub>2</sub>** and **S<sub>2</sub>+1** are n and m respectively. This instruction retrieves m characters starting from the n<sup>th</sup> character in the string in **S<sub>1</sub>**, and stores them in **D**.




- If the data in **S<sub>1</sub>** is ABCDEFGHIJK, the value in **S<sub>2</sub>** is 3, and the value in **S<sub>2</sub>+1** is 7, the instruction retrieves the seven characters starting from the third characters in the string from the left. The conversion result is as follows.



- If the value of **S<sub>2</sub>** is **S<sub>2</sub> ≤ 0**, **S<sub>2</sub>+1 < -1** or **S<sub>2</sub>+1 = 0**, the instruction is not executed.
- If the value in **S<sub>2</sub>+1** is -1, the instruction retrieves the characters in **S<sub>1</sub>** starting from the character indicated by the value in **S<sub>2</sub>** to the last character in **S<sub>1</sub>**.
- If the data in **S<sub>1</sub>** is ABCDEFGHIJK, the value in **S<sub>2</sub>** is 5, and the value in **S<sub>2</sub>+1** is -1, the conversion result is as follows.



**Example**



**Additional remarks**

1. If the operand **S<sub>1</sub>** is not a string (\$) but a device with a string, the string in **S<sub>1</sub>** can be up to 256 characters (16#00 ending character included). If the string in **S<sub>1</sub>** does not end with 16#00, SM0 is ON, and the error code in SR0 is 16#200E.
2. If the value of **S<sub>2</sub>** is **S<sub>2</sub> ≤ 0** or **S<sub>2</sub>+1 < -1**, SM0 is ON, and the error code in SR0 is 16#2003.
3. If the value in **S<sub>2</sub>** or **S<sub>2</sub> + S<sub>2</sub>+1** is larger than the length of the string in **S<sub>1</sub>**, SM0 is ON, and the error code in SR0 is 16#2003.
4. If the value in **S<sub>2</sub>+1** is larger than the number of characters that can be retrieved from the string in **S<sub>1</sub>**, SM0 is ON, and the error code in SR0 is 16#2003.
5. If **D** is not sufficient to contain **S<sub>2</sub>+1** characters, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2003.
6. if you declare the operand **S<sub>2</sub>** in ISPSOft, the data type is ARRAY [2] of WORD/INT.


API	Instruction code			Operand							Function					
2115		\$SER	P	<b>S<sub>1</sub>, S<sub>2</sub>, n, D</b>							Searching a string					

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
S <sub>1</sub>	●	●			●	●		●	●						○	
S <sub>2</sub>	●	●			●	●		●	●						○	
n	●	●			●	●		●	●		○	○	○	○		
D		●			●	●		●			○	○				

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
S <sub>1</sub>		●				●							●
S <sub>2</sub>		●				●							●
n		●				●							
D		●				●							

Pulse instruction	16-bit instruction	32-bit instruction
AS	AS	-


**Symbol**





- S<sub>1</sub> : String to be searched
- S<sub>2</sub> : String to be searched for
- n : n<sup>th</sup> character in S<sub>2</sub> where the search begins
- D : Search result

**Explanation**

- This instruction searches the string in S<sub>2</sub> from the n<sup>th</sup> character for the string in S<sub>1</sub>, and stores the search result in D.
- When the n<sup>th</sup> character exceeds the length of the string in S<sub>2</sub>, or S<sub>1</sub>>S<sub>2</sub>, D is 0.
- Suppose the string in S<sub>2</sub> is "ABCDEFGHJK", the string in S<sub>1</sub> is "EFGH", and n is 3. The search begins from the third character in S<sub>2</sub>, and the value in D is 5.



**Example**



**Additional remarks**

1. If the operand **S<sub>1</sub>** is not a string (\$) but a device with a string, the string in **S<sub>1</sub>** can be up to 256 characters(16#00 ending character included). If the string in **S<sub>1</sub>** does not end with 16#00, SM0 is ON, and the error code in SR0 is 16#200E.
2. If the operand **S<sub>1</sub>** is not a string (\$) but a device with a string, the string in **S<sub>2</sub>** can be up to 256 characters(16#00 ending character included). If the string in **S<sub>1</sub>** does not end with 16#00, SM0 is ON, and the error code in SR0 is 16#200E.
3. If **n** is less than or equal to 0, SM0 is ON, and the error code in SR0 is 16#2003.


API	Instruction code			Operand							Function					
2116		\$RPLC	P	<b>S<sub>1</sub>, S<sub>2</sub>, S<sub>3</sub>, S<sub>4</sub>, D</b>							Replacing the characters in a string					

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
S <sub>1</sub>	●	●			●	●		●	●						○	
S <sub>2</sub>	●	●			●	●		●	●						○	
S <sub>3</sub>	●	●			●	●		●	●		○	○	○	○		
S <sub>4</sub>	●	●			●	●		●	●		○	○	○	○		
D		●			●	●		●								

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
S <sub>1</sub>		●				●							●
S <sub>2</sub>		●				●							●
S <sub>3</sub>		●				●							
S <sub>4</sub>		●				●							
D		●				●							

Pulse instruction	16-bit instruction	32-bit instruction
AS	AS	-


**Symbol**



- S<sub>1</sub> : String to be searched and matching characters replaced
- S<sub>2</sub> : New string
- S<sub>3</sub> : Number of characters in S<sub>1</sub> to be replaced
- S<sub>4</sub> : The string S<sub>2</sub> replaces the characters in S<sub>1</sub> starting from the character indicated by the value in S<sub>4</sub>.
- D : Device where the result is stored

**Explanation**


1. This instruction replaces the characters in S<sub>1</sub> with the characters in S<sub>2</sub>, starting from the character in S<sub>1</sub> that matches the character in S<sub>4</sub>. The number of characters that are replaced is indicated by the value in S<sub>3</sub>, and the instruction stores the result in D.
2. For example, the instruction replaces the four characters starting from the sixth character in the string "1234567890" with "MN", and the result is "12345MN0".



3. If the string in **S<sub>2</sub>** is 16#00, the instruction deletes the matching characters.
4. If the value in **S<sub>3</sub>** is larger than the number of characters that the instruction can replace in the string in **S<sub>1</sub>**, the instruction replaces the characters in **S<sub>1</sub>** starting from the character indicated by the value in **S<sub>4</sub>** to the last character in **S<sub>1</sub>**.
5. If the value in **S<sub>3</sub>** is equal to 0, the instruction is not executed.

**Example**

When M0 is ON, the data in D0–D7 is “1234ABAB1234AB”, and the data in D10–D11 is “CDEF”. When the \$RPLC instruction executes, the instruction replaces the characters in D0–D7 starting from the character indicated by the value in D51 with the characters in D10–D11. The number of characters to replace is indicated by the value in D50, and the instruction stores the result in D20–D27.



If the values in D50 and D51 are 3 and 4 respectively, the execution result is as follows.

	b15	b8 b7	b0	
D0	16#32(2)	16#31(1)		D20
D1	16#34(4)	16#33(3)		D21
D2	16#42(B)	16#41(A)		D22
D3	16#42(B)	16#41(A)		D23
D4	16#32(2)	16#31(1)		D24
D5	16#34(4)	16#33(3)		D25
D6	16#42(B)	16#41(A)		D26
D7	Ignored	16#00		D27

D10	16#44(D)	16#43(C)	
D11	16#45(F)	16#45(E)	
D12	Ignored	16#00	

D50	3	Number of characters which are replaced
D51	4	Character which is replaced

If the values in D50 and D51 are 4 and 4 respectively, the execution result is as follows.

	b15	b8 b7	b0	
D0	16#32(2)	16#31(1)		D20
D1	16#34(4)	16#33(3)		D21
D2	16#42(B)	16#41(A)		D22
D3	16#42(B)	16#41(A)		D23
D4	16#32(2)	16#31(1)		D24
D5	16#34(4)	16#33(3)		D25
D6	16#42(B)	16#41(A)		D26
D7	Ignored	16#00		D27

⇨ After the instruction is executed

	b15	b8 b7	b0	
D0	16#32(2)	16#31(1)		D20
D1	16#43(C)	16#33(3)		D21
D2	16#45(E)	16#44(D)		D22
D3	16#42(B)	16#46(F)		D23
D4	16#32(2)	16#31(1)		D24
D5	16#34(4)	16#33(3)		D25
D6	16#42(B)	16#41(A)		D26
D7	16#0000			D27


  

D10	16#44(D)	16#43(C)	
D11	16#45(F)	16#45(E)	
D12	Ignored	16#00	


  

D50	4	Number of characters which are replaced
D51	4	Character which is replaced

If the values in D50 and D51 are 20 and 4 respectively, the execution result is as follows.



If the values in D50, D51, and D10 are 3, 4, and 16#00 respectively, the execution result is as follows. The three characters in D0-D7 starting from the fourth character are deleted.



**Additional remarks**

1. If the string in **S<sub>1</sub>** does not end with 16#00, SM0 is ON, and the error code in SR0 is 16#200E.
2. If the string in **S<sub>2</sub>** does not end with 16#00, SM0 is ON, and the error code in SR0 is 16#200E.
3. If the value in **S<sub>3</sub>** < 0 or **S<sub>4</sub>** <= 0 or the value in **S<sub>4</sub>** is larger than the length of the string in **S<sub>1</sub>**, SM0 is ON, and the error code in SR0 is 16#2003.
4. If the value in the string (16#00 the ending character included) in **S<sub>1</sub>** after the replacement is larger than 256, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2003.


API	Instruction code			Operand								Function				
2117		\$DEL	P	<b>S<sub>1</sub>, S<sub>2</sub>, S<sub>3</sub>, D</b>								Deleting the characters in a string				

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
S <sub>1</sub>	●	●			●	●		●	●						○	
S <sub>2</sub>	●	●			●	●		●	●		○	○	○	○		
S <sub>3</sub>	●	●			●	●		●	●		○	○	○	○		
D		●			●	●		●								

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
S <sub>1</sub>		●				●							●
S <sub>2</sub>		●				●							
S <sub>3</sub>		●				●							
D		●				●							

Pulse instruction	16-bit instruction	32-bit instruction
AS	AS	-


**Symbol**




- S<sub>1</sub> : String
- S<sub>2</sub> : Number of characters to be deleted
- S<sub>3</sub> : Characters in S<sub>1</sub> are deleted starting from the character indicated by the value in S<sub>3</sub>.
- D : Device where the execution result is stored

**Explanation**

- This instruction deletes the characters in S<sub>1</sub> starting from the character indicated by the value in S<sub>3</sub>. The number of characters that are deleted is indicated by the value in S<sub>2</sub>, and the instruction stores the result in D.
- For example, the instruction deletes the four characters starting from the third character in the string "1234567890" in S<sub>1</sub>, and stores the result "127890" in D.




- If the value in **S<sub>2</sub>** is larger than the number of characters which can be deleted in the string in **S<sub>1</sub>**, the instruction deletes the characters in **S<sub>1</sub>** starting from the character indicated by the value in **S<sub>3</sub>** to the last character in **S<sub>1</sub>**, and stores 16#00 in **D**.




- If the value in **S<sub>2</sub>** is equal to 0, the instruction is not executed.

**Example**


When M0 is ON, the data in D0–D3 is “1234567”. When the \$DEL instruction executes, it deletes the characters in D0–D3 starting from the character indicated by the value in D11. The number of characters to delete is indicated by the value in D10, and the instruction stores the result in D20–D23.




If the values in D10 and D11 are 3 and 4 respectively, the execution result is as follows.



If the values in D10 and D11 are 5 and 4 respectively, the execution result is as follows. Note that the number of characters to delete exceeds the range, the instruction deletes the characters in D0–D3 starting from the fourth character to the last character.



If the values in D10 and D11 are 5 and 1 respectively, the execution result is as follows.



**Additional remarks**

1. If the string in **S<sub>1</sub>** does not end with 16#00, SM0 is ON, and the error code in SR0 is 16#200E.
2. If the value in **S<sub>2</sub>** is less than 0, the value in **S<sub>3</sub>** is less than or equal to 0, or the value in **S<sub>3</sub>** is larger than the length of the string in **S<sub>1</sub>**, SM0 is ON, and the error code in SR0 is 16#2003.

API	Instruction code			Operand							Function						
2118		\$CLR	P	<b>S</b>							Clearing a string						
Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F	
<b>S</b>		●			●	●		●									
Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING				
<b>S</b>		●				●											
				Pulse instruction	16-bit instruction				32-bit instruction								
				AS	AS				-								


**Symbol**



**S** : String to be cleared


**Explanation**

- This instruction clears the string in **S**. If the string in **S** does not end with 16#00, the instruction clears up to 255 characters.



**Example**

The instruction clears the string in D0 as illustrated below.




API	Instruction code			Operand							Function				
2119		\$INS	P	<b>S<sub>1</sub>, S<sub>2</sub>, S<sub>3</sub>, D</b>							Inserting a string				

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
S <sub>1</sub>	●	●			●	●		●	●						○	
S <sub>2</sub>	●	●			●	●		●	●						○	
S <sub>3</sub>	●	●			●	●		●	●		○	○	○	○		
D		●			●	●		●								

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
S <sub>1</sub>		●				●							●
S <sub>2</sub>		●				●							●
S <sub>3</sub>		●				●							
D		●				●							

Pulse instruction	16-bit instruction	32-bit instruction
AS	AS	-


**Symbol**



- S<sub>1</sub> : String
- S<sub>2</sub> : String to be inserted
- S<sub>3</sub> : The string S<sub>2</sub> is inserted into S<sub>1</sub> after the character indicated by the value in S<sub>3</sub>.
- D : Device in which the execution result is stored


**Explanation**

- This instruction inserts the string in S<sub>2</sub> into the string in S<sub>1</sub> after the character indicated by the value in S<sub>3</sub>, and stores the result in D.
- If the string in either S<sub>1</sub> or S<sub>2</sub> is a null string, the instruction stores the other string (S<sub>1</sub> or S<sub>2</sub>) that is not a null string in D.
- If the strings in S<sub>1</sub> and S<sub>2</sub> are null strings, the instruction stores 16#0000 in D.



**Example**

When M0 is ON, the data in D0–D3 is “1234567”, and the data in D10 is “AB”. When the \$INS instruction executes, it inserts “AB” into the string in D0–D3 after the character indicated by the value in D30, and stores the result in D20–D24.



If the value in D30 is 1, the execution result is as follows.

	b15	b8 b7	b0	
D0	16#32(2)	16#31(1)		D20
D1	16#34(4)	16#33(3)		D21
D2	16#36(6)	16#35(5)		D22
D3	16#00	16#37(7)		D23
D10	16#42(B)	16#41(A)		D24
D11	Ignored	16#00		
D30	1			

➡ After the instruction is executed

	b15	b8 b7	b0	
	16#41(A)	16#31(1)		D20
	16#32(2)	16#42(B)		D21
	16#34(4)	16#33(3)		D22
	16#36(6)	16#35(5)		D23
	16#00	16#37(7)		D24

If the value in D30 is 0, the execution result is as follows.

	b15	b8 b7	b0	
D0	16#32(2)	16#31(1)		D20
D1	16#34(4)	16#33(3)		D21
D2	16#36(6)	16#35(5)		D22
D3	16#00	16#37(7)		D23
D10	16#42(B)	16#41(A)		D24
D11	Ignored	16#00		
D30	0			

➡ After execution

	b15	b8 b7	b0	
	16#42(B)	16#41(A)		D20
	16#32(2)	16#31(1)		D21
	16#34(4)	16#33(3)		D22
	16#36(6)	16#35(5)		D23
	16#00	16#37(7)		D24

**Additional remarks**

1. If the string in **S<sub>1</sub>** does not end with 16#00, SM0 is ON, and the error code in SR0 is 16#200E.
2. If the string in **S<sub>2</sub>** does not end with 16#00, SM0 is ON, and the error code in SR0 is 16#200E.
3. If the value in **S<sub>3</sub>** is less than 0, or if the value in **S<sub>3</sub>** is larger than the length of the string in **S<sub>1</sub>**, SM0 is ON, and the error code in SR0 is 16#2003.
4. If the inserted value in the string (16#00 the ending character included) in **S<sub>1</sub>** is larger than 256, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2003.

API	Instruction code			Operand							Function					
2122		SPLIT	P	$S_1 \cdot S_2 \cdot S_3 \cdot S_4 \cdot D_1 \cdot D_2$							Splitting a string					

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
S <sub>1</sub>								●	●							
S <sub>2</sub>								●					○	○	○	
S <sub>3</sub>								●					○	○	○	
S <sub>4</sub>								●					○	○		
D <sub>1</sub>								●								
D <sub>2</sub>								●								

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
S <sub>1</sub>		●				●							
S <sub>2</sub>		●				●							●
S <sub>3</sub>		●				●							●
S <sub>4</sub>		●				●							
D <sub>1</sub>		●				●							
D <sub>2</sub>		●				●							

Pulse instruction	16-bit instruction	32-bit
AS	AS	-

**Symbol**

SPLIT		SPLITP	
En		En	
S1	D1	S1	D1
S2	D2	S2	D2
S3		S3	
S4		S4	

- S<sub>1</sub> : String
- S<sub>2</sub> : Splitter
- S<sub>3</sub> : Designated ending character of a splitter
- S<sub>4</sub> : Storing Length for a string after a splitter
- D<sub>1</sub> : Device in which the string after a splitter is stored
- D<sub>2</sub> : Device in which the quantity of split strings is stored

**Explanation**

1. This instruction is only available for firmware version 1.04 or later.
2. S<sub>1</sub> is the string source. For characters in a string, only the characters before an ending character or the value in S<sub>3</sub> will be used as a valid string.
3. S<sub>2</sub> is the splitter that separates strings. S<sub>3</sub> is a designated ending character of a splitter. Only values in the lower 8-byte are valid for S<sub>2</sub> and S<sub>3</sub>. However, if you input a value other than the value in the lower 8-byte, PLC does not send any error message. When S<sub>2</sub> and S<sub>3</sub> use D devices to store values, only use lower 8-byte for values in ASCII format. Values in S<sub>2</sub> and S<sub>3</sub> can be a constant number, an ASCII or a string.
4. S<sub>4</sub> is the storing length for a string after a splitter; unit: WORD. The ending characters, such as 16#00 and 16#0000

should be included in the length. The maximum WORDs a string can contain is **S<sub>4</sub>** and a WORD equals to 2 bytes. An ending character 16#00 takes a byte. For example, if **S<sub>4</sub>** is 2, the maximum WORDs a string can contain is 2 WORDs and 2 WORDs equals to 4 bytes. And that means a string can contain 3 characters and 1 ending character (16#00). The setting range for **S<sub>4</sub>** is 1-100. (If the input value is out of the range, the value will be seen as the minimum or the maximum during operation and PLC does not send any error message.)

5. **D<sub>2</sub>** is the sum of all the split strings.
6. The result of **D<sub>1</sub>~ D<sub>1</sub>+ S<sub>4</sub> \*D<sub>2</sub>-1** is the D devices that are occupied.

For example, if **D<sub>2</sub>** is 3, that means the 1<sup>st</sup> string will be stored from **D<sub>1</sub>+0** and the 2<sup>nd</sup> string will be stored in **D<sub>1</sub>+ S<sub>4</sub>** and the 3<sup>rd</sup> string will be stored in **D<sub>1</sub>+ S<sub>4</sub> x2**.


7. The instruction looks for a string for a length defined in **S<sub>4</sub>** (WORD) till there is an ending character or a splitter. Add 1 to the value in **D<sub>2</sub>**. Whenever one string is found,
8. Up to 256 characters can be stored in **S<sub>1</sub>** and up to 20 sets of strings can be stored in **D<sub>2</sub>**. When any of the limitation is reached even when there is no ending character, the splitting stops.

**Example**

Use “,” as a splitter to split a string “abcd,1234,5.67,8910;ef” and use “;” as an ending character that stored in D0-D11. And store the results in the register starting from D100 in a unit of 10 WORDs.

6

Note: the string to be split does not include the characters “”.



**Explanation**

- The results of this example D0~D11="abcd,1234,5.67,89103;edf".

Device	Value	String
D0	16#6261	"ba"
D1	16#6463	"dc"
D2	16#312C	"1,"
D3	16#3332	32
D4	16#2C34	“,4”
D5	16#2E35	“.5”
D6	16#3736	“76”
D7	16#382C	“8,”
D8	16#3139	“19”
D9	16#3330	“30”
D10	16#453B	“e,”
D11	16#4644	“fd”

- Starting contact is M0
- The quantity of split strings D200=4
- The split strings are as below.

1 <sup>st</sup> set: D100~D109 are occupied; D100-D101="abcd"	D100	D101	D102	D103	D104	D105	D106	D107	D108	D109
HEX	6261	6463	0000	0000	0000	0000	0000	0000	0000	0000
String	"ba"	"dc"	16#0000	-	-	-	-	-	-	-
2 <sup>nd</sup> set: D110~D119 are occupied; D110~D111="1234"	D110	D111	D112	D113	D114	D115	D116	D117	D118	D119
HEX	3231	3433	0000	0000	0000	0000	0000	0000	0000	0000
String	"21"	"43"	16#0000	-	-	-	-	-	-	-

3<sup>rd</sup> set: D120~D129 are occupied; D120~D121="5.67"

Device	D120	D121	D122	D123	D124	D125	D126	D127	D128	D129
HEX	2E35	3736	0000	0000	0000	0000	0000	0000	0000	0000
String	".5"	"76"	16#0000	-	-	-	-	-	-	-

4<sup>th</sup> set: D130~D139 are occupied, D130~D131="89103"

Device	D130	D131	D132	D133	D134	D135	D136	D137	D138	D139
HEX	3938	3031	0033	0000	0000	0000	0000	0000	0000	0000
String	"98"	"01"	Upper: 3" Lower: 16#00	-	-	-	-	-	-	-

**Additional remarks**

- Up to 256 characters can be stored in **S<sub>1</sub>** if there is no ending character (16#00) or splitter, the instruction will execute on the 256 characters. SM0 will not be ON.
- Ending character 16#00 or 16#0000 will be added in a string after it is split (**D<sub>1</sub>**). See the example above.
- Ending character 16#00 or 16#0000 will be added in a string after it is split (**D<sub>1</sub>**) even when there is no string behind the split string.

API	Instruction code			Operand								Function					
2123		MERGE	P	$S_1 \cdot S_2 \cdot S_3 \cdot D_1 \cdot D_2$								Merging strings					

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
S <sub>1</sub>								●	●						○	
S <sub>2</sub>								●	●						○	
S <sub>3</sub>								●					○	○	○	
D <sub>1</sub>								●								
D <sub>2</sub>								●								

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
S <sub>1</sub>		●				●							●
S <sub>2</sub>		●				●							●
S <sub>3</sub>		●				●							●
D <sub>1</sub>		●				●							
D <sub>2</sub>		●				●							

Pulse instruction	16-bit instruction	32-bit
AS	AS	-

**Symbol**

MERGE		MERGEP	
En		En	
S1	D1	S1	D1
S2	D2	S2	D2
S3		S3	

S<sub>1</sub> : String source 1

S<sub>2</sub> : String source 2

S<sub>3</sub> : Splitter

D<sub>1</sub> : Device in which the merged string is stored

D<sub>2</sub> : Device in which the quantity of merged strings is stored


**Explanation**

- This instruction is only available for firmware version 1.04 or later.
- S<sub>1</sub> and S<sub>2</sub> are the string source 1 and 2 respectively. S<sub>3</sub> is the splitter that separates strings. Only values in the lower 8-byte are valid for S<sub>3</sub>. S<sub>1</sub> merges S<sub>2</sub> directly, when S<sub>3</sub> is 0 (16#00). S<sub>1</sub> adds the splitter and then merges S<sub>2</sub>, when S<sub>3</sub> is not 0.
- D<sub>1</sub> is where to store a merged string. The merging order is string 1 + splitter + string 2 + ending character 0 (16#00). You can self-define an ending character. This self-defined ending character will be added before the official one, 0 (16#00).
- If the values in S<sub>1</sub>, S<sub>2</sub>, S<sub>3</sub> are all 0, D<sub>1</sub> is 16#0000.
- D<sub>2</sub> is the sum of all the merged strings (ending character 16#00 excluded). The accumulated length for the string is the length of string 1 or the length of string 1 + splitter + the length of string 2.

- If the string sources for **S<sub>1</sub>** and **S<sub>2</sub>** are both 0 or when strings are merged, the length for the merged string is up to 255 words (ending character 16#00 excluded). For example, there are 250 words in String 1 and 100 words in String 2. After they are merged, the length for the merged string is 250 words from String 1 + splitter \*1 + first 4 words from String 2.

**Example**

Use “,” as a splitter to split a string and use “;” as an ending character and then merge 3 strings “abcd”, “1234” and “5.67”.



And store the results “abcd,1234,5.67;” D100=15, in the register starting from D0-D7.

**6**

**Explanation**

- Starting contact is M0
- The 1<sup>st</sup> program: merge the 1<sup>st</sup> string “abcd” and 2<sup>nd</sup> string “1234” together and put a splitter “,” in between and then store the result in the registers starting from D0.

The merged result: D0~D4= “abcd,1234”; the quantity of merged strings: D100=9

Device	D0	D1	D2	D3	D4
HEX	6261	6463	312C	3332	0034
String	“ba”	“dc”	“1,”	“32”	Upper 8-byte: 16#00 ; lower 8-byte: 4

- The 2<sup>nd</sup> program: merge the 1<sup>st</sup> string D0=“abcd,1234” and 2<sup>nd</sup> string “5.67” together and put a splitter “,” in between and then store the result in the registers starting from D0.

The merged result: D0~D7= “abcd,1234,5.67”; the quantity of merged strings: D100=14

Device	D0	D1	D2	D3	D4	D5	D6	D7
HEX	6261	6463	312C	3332	2C34	2E35	3736	0000
String	“ba”	“dc”	“1,”	“32”	“,4”	“.5”	“76”	16#0000

4. The 3<sup>rd</sup> program: merge the 1<sup>st</sup> string D0="abcd,1234,5.67" and 2<sup>nd</sup> string "," together and put a splitter "0" in between (merge the string 1 and 2 directly) and then store the result in the registers starting from D0.

The merged result: D0~D7= "abcd,1234,5.67;"; the quantity of merged strings: D100=15.

Device	D0	D1	D2	D3	D4	D5	D6	D7
HEX	6261	6463	312C	3332	2C34	2E35	3736	003B
String	"ba"	"dc"	"1,"	"32"	","4"	".5"	"76"	Upper 8-byte: 16#00 ; lower 8-byte: ";"

#### Additional remarks

1. If the string in **S**<sub>1</sub> does not end with 16#00, SM0 is ON, and the error code in SR0 is 16#200E.
2. If the string in **S**<sub>2</sub> does not end with 16#00, SM0 is ON, and the error code in SR0 is 16#200E.
3. If  $D_1 + (D_2+1)/2 - 1$  exceeds the device range, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2003.
4. Ending character 16#00 or 16#0000 will be added behind the merged string. See the examples above.

## 6.22 Ethernet Instructions

### 6.22.1 List of Ethernet Instructions

The following table lists the String Processing instructions covered in this section.

API	Instruction code		Pulse instruction	Function
	16-bit	32-bit		
<u>2200</u>	SOPEN	–	✓	Opening a socket
<u>2201</u>	SSEND	–	✓	Sending data through a socket
<u>2203</u>	SCLOSE	–	✓	Closing a socket
<u>2204</u>	MSEND	–	✓	Sending an email
<u>2206</u>	INTOA	–	✓	Converting an integer IP address into a string IP address
<u>2207</u>	IATON	–	✓	Converting a string IP address into an integer IP address
<u>2208</u>	EIPRW	–	–	Reading and writing EtherNet/IP data
<u>2209</u>	SCONF	–	✓	Setting the TCP/UDP Socket parameters
<u>2210</u>	MCONF	–	✓	Reading and writing Modbus TCP data
<u>2211</u>	EMCONF1	–	✓	Setting email server parameter values
<u>2212</u>	EMCONF2	–	✓	Setting email address
<u>2214</u>	MQTT_Connect	–	–	Establishing a MQTT connection
<u>2215</u>	MQTT_Publish	–	–	Publishing a MQTT message
<u>2216</u>	MQTT_Subscribe	–	–	Subscribing to a MQTT topic

## 6.22.2 Explanation of Ethernet Instructions

API	Instruction code			Operand								Function				
2200		SOPEN	P	$S_1, S_2, S_3$								Opening a socket				

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
$S_1$	●	●			●	●		●	●			○	○	○		
$S_2$	●	●			●	●		●	●			○	○	○		
$S_3$	●	●			●	●		●	●			○	○	○		

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
$S_1$		●				●							
$S_2$		●				●							
$S_3$		●				●							

Pulse instruction	16-bit instruction	32-bit instruction
AS	AS	-

### Symbol

SOPEN		SOPENP	
En		En	
$S_1$		$S_1$	
$S_2$		$S_2$	
$S_3$		$S_3$	

- $S_1$  : Socket mode  
 $S_2$  : Socket number  
 $S_3$  : Communication mode

### Explanation

- This instruction opens a socket. Set  $S_1$  to 1 to open a TCP socket, and set  $S_1$  to 0 to open a UDP socket.
- $S_2$  is the socket number. It should correspond to the Ethernet socket number set in the advanced settings; up to 4 can be set.
- The AS Series PLC functions as a client and sends a TCP connection ( $S_1 = 1$ ) request to the server if  $S_3$  is 1 or 3 (available for V1.06.30 or later), and the AS Series PLC functions as a sever and waits for a TCP connection ( $S_1 = 1$ ) request from the client if  $S_3$  is 0 or 2 (available for V1.06.30 or later).
- To start a UDP connection ( $S_1 = 0$ ), set  $S_3$  to 0~3.
- The operand  $S_1$  must be either 0 or 1 (default: 0); the operand  $S_2$  must be between 1~4 (default: 1); the operand  $S_3$  must be either 0 or 1 (default: 0). If exceeding the range, error code H'2003 shows on the PLC.
- Before using the instruction, set the following setting in HWCONFIG in ISPSOft.
  - PLC Parameter Setting → Ethernet-Basic → Setting IP address and netmask address
  - PLC Parameter Setting → Ethernet-Advanced → Socket → Enable Socket Function

- PLC Parameter Setting → Ethernet-Advanced → Socket → TCP/UDP Socket Connection and Setting sockets to be used
7. Refer to the SCONF instructions (API 2209) for more on the TCP and UDP Socket parameters.
  8. If you need to send several data separately, you can use this new functionality: **S<sub>3</sub>** = 2 or 3 (available for V1.06.30 or later). The first device in the receiving destination is stored with the length of the data to be received, and the data to be received is stored from the second device and on. If you need to receive another data, you can clear the value in the first device and start another data transmission.
  9. When the TCP Socket (**S<sub>1</sub>** = 1) is opened, use the following settings for **S<sub>3</sub>**, the Socket IP and communication ports.

Start Mode	S <sub>3</sub>	Remote IP	Local Communication Port	Remote Communication Port	Description
Client	1 or 3	Specific IP address	Not equal to 0	Not equal to 0	Specifies IP address, local and remote communication port
		Specific IP address	Not equal to 0	0	Specifies IP address, but not local communication port
		Any value	0	Any value	Illegal; when PLC CPU is in Client mode, the Server communication port and IP address should be appointed.
		0.0.0.0	Any value	Any value	
Server	0 or 2	Specific IP address	0	Not equal to 0	Specifies IP address, but not remote communication port
		Specific IP address	Not equal to 0	Not equal to 0	Specifies IP address and local communication port
		0.0.0.0	0	Not equal to 0	Not specify IP address and local communication port
		0.0.0.0	Not equal to 0	Not equal to 0	Not specify IP address, but to specify remote communication port
		Any value	Any value	0	Illegal; when PLC CPU is in Server, the Server communication port should be appointed.

Note: New modes 2 and 3 are available for V1.06.30 or later. New modes use the first device in the receiving destination to store the length of the data to be received. You can use the value here to determine if the receiving is complete. For modes 0 and 1, no length of data will be recorded.

10. If data is sent through a TCP socket, and no error occurs after the instruction is executed, the socket starts to establish the connection with the remote device and the flag for starting connection is ON. If the connection is made successfully, the flag for successful connection is ON, and the flag for starting connection is OFF. If an error occurs, the error flag is ON.

TCP Socket Number	Connection Started	Data Received	Data Sent	Connection Starting	Connection Closed	Data Sending	Error Flag
1	SM1270	SM1271	SM1272	SM1273	SM1274	SM1275	SM1277
2	SM1278	SM1279	SM1280	SM1281	SM1282	SM1283	SM1285
3	SM1286	SM1287	SM1288	SM1289	SM1290	SM1291	SM1293
4	SM1294	SM1295	SM1296	SM1297	SM1298	SM1299	SM1301

11. If data is transmitted through a UDP socket, and no error occurs after the instruction is executed, the flag for started connection is ON. If an error occurs, the error flag is ON.

UDP Socket Number	Connection Started	Data Received	Data Sending	Connection Closed	Error Flag
1	SM1334	SM1335	SM1336	SM1337	SM1338
2	SM1339	SM1340	SM1341	SM1342	SM1343
3	SM1344	SM1345	SM1346	SM1347	SM1348
4	SM1349	SM1350	SM1351	SM1352	SM1353

12. If data is transmitted through a TCP Socket in Server mode or through a UDP Socket, it is not allowed to use the following communication port number for AS series PLC.

Socket Type	Communication Port Number	Communication Protocol
TCP	80	HTTP
TCP	502	MODBUS TCP
TCP	44818	EtherNet/IP
UDP	68	DHCP/BOOTP
UDP	2222	EtherNet/IP
UDP	44818	EtherNet/IP
UDP	20006	Self-defined protocol for AS series

13. In general, the pulse SOPENP instruction is used.

**Example 1 (S<sub>3</sub> = 1)**

1. This example illustrates how to establish a TCP connection between a computer as server and an AS Series PLC as client.



2. ISPSOft → HWCONFIG (Ethernet-Basic)

Ethernet Configuration	
IP Address Mode	Static
IP Address	192.168.1.111
Netmask Address	255.255.255.0
Gateway Address	192.168.1.1

**6**


3. a) ISPSOft → HWCONFIG (Ethernet-Advanced → Socket → 1<sup>st</sup> TCP Socket Connection)  
 b) SCONF instruction

1 <sup>st</sup> TCP Socket Connection	
Remote IP	192.168.1.110
Remote Port	3201
Local Port	3200
Send Data Address	D1000
The defined length of data to be sent <sup>#1</sup>	200
Receive Data Address	D2000
The defined length of data to be received <sup>#1</sup>	200
Keep Alive Timer	10

<sup>#1</sup>: This data length is defined by settings in SCONF instruction; for V1.06.20 or previous versions: 512 bytes are available and for V1.06.30 or later versions: 4096 bytes are available.


4. First, set the parameters related to TCP Socket1 in HWCONFIG in ISPSOft or in the SCONF instruction.


5. Establishing a connection (Network 1): When M0 is ON, the system checks whether the socket is closed (SM1274 = ON), NOT connected (SM1270 = OFF), or NOT being connected (SM1273 = OFF). If the socket is not closed, has not been connected, and is not being connected, the system performs the connection procedure. Once the socket is connected (SM1270 = ON), M0 is switched to OFF.
6. Sending data (Network 3): When M1 is ON, the system checks whether the socket has been connected (SM1270 = ON), and no data is being sent yet (SM1275 = OFF). If the socket has been connected and no data is being sent, the system starts to send the data. If the socket has not been connected, the system does not execute the instruction. After the data has been sent (SM1272 = ON), M1 is switched to OFF.
7. Receiving data (Network 4): When M2 is ON, the system checks whether the socket has been connected and the flag (SM1271) for data received is ON. If the socket has been connected and the flag for data received is ON, then the data has already been received. But that does NOT necessary mean it has reached its maximum length of receiving. After the data has been received (SM1271 = ON), M2 and SM1271 are switched to OFF.
8. Closing a connection (Network 5): When M3 is ON, the system checks whether the socket has been connected. If the socket has been connected (SM1270 = ON), and the connection is not yet closed (SM1274 = OFF), the system is going to close the connection. If the socket has not been connected, the system does not execute the instruction. After the connection is closed (SM1274 = ON), M3 is switched to OFF.



**Example 2 (S<sub>3</sub> = 0)**

1. This example illustrates how to establish a UDP connection between a computer and an AS Series PLC.
  - a) ISPSOft → HWCONFIG (Ethernet-Advanced → Socket → 1<sup>st</sup> UDP Socket Connection)
  - b) SCONF instruction
  - c) Refer to point 3 in Example 1 for setting up the connection.
2. Establishing a connection (Network 1): When M0 is ON, the system checks if the socket is closed (SM1334 = OFF) and then the system performs the connection procedure. Once the socket is connected (SM1334 = ON), M0 is switched to OFF.
3. Sending data (Network 3): When M1 is ON, the system checks if the socket has been connected (SM1334 = ON), and then the system starts to send the data. After the data has been sent, M1 is switched to OFF.
4. Receiving data (Network 4): When M2 is ON, the system checks if the socket has been connected and the flag (SM1335) for data received is ON. If so, the data has already been received. But that does NOT necessary mean it has reached its maximum length of receiving. After the data has been received (SM1335 = ON), M2 and SM1335 are switched to OFF.
5. Closing a connection (Network 5): When M3 is ON, the system checks if the socket to be closed has been connected (SM1334 = ON), and if the connection is not yet closed (SM1337 = OFF). If so, the system is going to close the connection. If the socket has not been connected, the system does not execute the instruction. After the connection is closed, M3 is switched to OFF.





**Example 3 (S<sub>3</sub> = 2)**

1. This example illustrates how a Server receives data of 2K bytes from a TCP connection in mode **S<sub>3</sub> = 2**.
2. SCONF instruction

1 <sup>st</sup> TCP Socket Connection	
Remote IP	192.168.1.106
Remote Port	0
Local Port	2020
Send Data Address	D10000
The defined length of data to be sent <sup>#1</sup>	4096
Receive Data Address	D15000
The defined length of data to be received <sup>#1</sup>	4096
Keep Alive Timer	30

<sup>#1</sup>: This data length is defined by settings in SCONF instruction; for V1.06.20 or previous versions: 512 bytes are available and for V1.06.30 or later versions: 4096 bytes are available.

3. When PLC CPU is from STOP to RUN, execute SCONF instruction. Refer to API 2209 SCONF for setting up the socket.
4. Establishing a connection (Network 3); When M0 is ON, the system checks if the socket is closed (SM1274 = ON), NOT connected (SM1270 = OFF), or NOT being connected (SM1273 = OFF). If the socket is not closed, has not been connected, and is not being connected, the system performs the connection procedure. Once the socket is connected (SM1270 = ON), M0 is switched to OFF.

5. The connection to remote Client (IP = 192.168.1.106) is connected and sending 2K bytes of data.
6. Open the Monitor Table and start monitoring the starting device where the data length of the received data is stored.




If 2K bytes of data is received, you can see the value in D15000 is 2000. If you need to start another data transmission, you can set the value in D15000 to 0 to start another data length count.

7. Closing a connection (Network 5): When M3 is ON, the system checks if the socket has been connected. If the socket has been connected (SM1270 = ON), the system is going to close the connection. If the socket has not been connected, the system does not execute the instruction. After the connection is closed, M3 is switched to OFF.


Network 1

Set TCP Client IP




Network 2

Set Sconfig



Network 3

Create TCP Connecton



Network 4



Network 5

Close TCP connection



6

**Additional remarks**

- The following table lists TCP connection errors.

<b>Error Code (SR180)</b>	<b>Error Flag</b>	<b>Description</b>
16#2003	SM0	<b>S<sub>1</sub></b> , <b>S<sub>2</sub></b> , or <b>S<sub>3</sub></b> exceeds the range
16#600C	SM1109	Local socket not used
16#600D	SM1100	Ethernet network not connected
16#6200	TCP Socket error flag	Illegal IP address
16#6201	TCP Socket error flag	Illegal TCP Socket communication mode setting
16#6202	TCP Socket error flag	Illegal TCP Socket mode setting
16#6203	TCP Socket error flag	Illegal address for sending data
16#6204	TCP Socket error flag	Length of sent data exceeds the range
16#6205	TCP Socket error flag	Source data device exceeds the range
16#6206	TCP Socket error flag	Illegal address for receiving data
16#6207	TCP Socket error flag	Length of received data exceeds the range
16#6208	TCP Socket error flag	Target data device exceeds the range
16#6212	TCP Socket error flag	TCP Socket communication timeout
16#6213	TCP Socket error flag	Size of data received larger than dataset
16#6214	TCP Socket error flag	TCP Socket connection rejected by remote equipment
16#6215	TCP Socket error flag	TCP Socket not connected
16#6217	TCP Socket error flag	TCP Socket connection triggered
16#6218	TCP Socket error flag	Sending data through TCP Socket triggered
16#621A	TCP Socket error flag	Disabling TCP Socket connection triggered

2. The following table explains UDP connection errors.

Error Code (SR180)	Error Flag	Description
16#2003	SM0	S <sub>1</sub> , S <sub>2</sub> , or S <sub>3</sub> exceeds the range
16#600C	SM1109	Local socket used
16#600D	SM1100	Ethernet network not connected
16#6209	UDP Socket error flag	Illegal IP address
16#620A	UDP Socket error flag	Illegal communication mode
16#620C	UDP Socket error flag	Illegal address for sending data
16#620D	UDP Socket error flag	Length of sent data exceeds the range
16#620E	UDP Socket error flag	Source data device exceeds the range
16#620F	UDP Socket error flag	Illegal address for receiving data
16#6210	UDP Socket error flag	Length of data received exceeds the range
16#6211	UDP Socket error flag	Target data device exceeds the range
16#6213	UDP Socket error flag	Size of data received larger than dataset
16#6215	UDP Socket error flag	UDP Socket not connected
16#6217	UDP Socket error flag	UDP Socket connection triggered
16#6218	UDP Socket error flag	Sending of data through UDP Socket triggered
16#621A	UDP Socket error flag	Disabling UDP Socket connection triggered

3. When the client and server are both AS Series PLC and the communication timeout settings are set the same, the server automatically cuts the connection if a timeout occurs on the server first. In this case, the error flag on the client is not ON. On the other hand, if a timeout occurs on the client first, the error flag on the client is ON and the connection is cut.

API	Instruction code			Operand							Function						
2201		SSEND	P	<b>S<sub>1</sub>, S<sub>2</sub></b>							Sending data through a socket						

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	“\$”	F
<b>S<sub>1</sub></b>	●	●			●	●		●	●			○	○	○		
<b>S<sub>2</sub></b>	●	●			●	●		●	●			○	○	○		

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
<b>S<sub>1</sub></b>		●				●							
<b>S<sub>2</sub></b>		●				●							

Pulse instruction	16-bit instruction	32-bit instruction
AS	AS	-

### Symbol

SSEND		SSENDP	
En		En	
S1		S1	
S2		S2	

**S<sub>1</sub>** : Socket mode

**S<sub>2</sub>** : Socket number

### Explanation

- This instruction sends data through the socket specified by **S<sub>1</sub>**. Set **S<sub>1</sub>** to 1 to open a TCP socket, and set **S<sub>1</sub>** to 0 to open a UDP socket.
- S<sub>2</sub>** is the socket number. It should correspond to the Ethernet socket number; up to 4 can be set.
- The operand **S<sub>1</sub>** must be either 0 or 1 (default: 0); the operand **S<sub>2</sub>** must be between 1–4 (default: 1). If exceeding the range, error code H'2003 shows on the PLC.
- Before using this instruction, use the SOPEN instruction (API 2200) to open the socket. If the flag for the successful connection of the TCP socket is ON, or the flag for started connection of the UDP socket is ON, use this instruction.
- If data is sent through a TCP socket, and no error occurs after the instruction is executed, the data is sent, and the flag for sending data is ON. If data is sent successfully, the flag for sent data is ON, and the flag for sending data is OFF. If an error occurs, the error flag is ON.

TCP Socket Number	Data Sending	Data Sent	Error Flag
1	SM1275	SM1272	SM1277
2	SM1283	SM1280	SM1285
3	SM1291	SM1288	SM1293
4	SM1299	SM1296	SM1301

6. If data is sent through a UDP socket, and no error occurs after the instruction is executed, the flag for sent data is ON. If an error occurs, the error flag is ON.

UDP Socket Number	Data Sending	Error Flag
1	SM1336	SM1338
2	SM1341	SM1343
3	SM1346	SM1348
4	SM1351	SM1353

7. In general, the SSENDP pulse instruction is used.

### Example

Refer to the example in the SOPEN instructions (API 2200).

### Additional remarks

1. The following table explains TCP connection errors.

Error Code	Error Flag	Description
16#2003	SM0	S <sub>1</sub> or S <sub>2</sub> exceeds the range
16#600D	SM1100	Ethernet network not connected
16#6202	TCP Socket error flag	Illegal TCP Socket mode setting
16#6203	TCP Socket error flag	Illegal address for sending data
16#6204	TCP Socket error flag	Length of sent data exceeds the range
16#6205	TCP Socket error flag	Source data device exceeds the range
16#6212	TCP Socket error flag	TCP Socket connection timeout
16#6214	TCP Socket error flag	TCP Socket connection rejected by remote equipment
16#6215	TCP Socket error flag	TCP Socket not connected
16#6218	TCP Socket error flag	Sending of data triggered

2. The following table explains UDP connection errors.

Error Code	Error Flag	Description
16#2003	SM0	<b>S</b> <sub>1</sub> or <b>S</b> <sub>2</sub> exceeds the range
16#600D	SM1100	Ethernet network not connected
16#620A	UDP Socket error flag	Illegal UDP Socket communication mode setting
16#620C	UDP Socket error flag	Illegal address for sending data
16#620D	UDP Socket error flag	Length of sent data exceeds the range
16#620E	UDP Socket error flag	Source data device exceeds the range
16#6218	UDP Socket error flag	Sending of data triggered

API	Instruction code			Operand							Function					
2203		SCLOSE	P	<b>S<sub>1</sub>, S<sub>2</sub></b>							Closing a socket					

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
<b>S<sub>1</sub></b>	●	●			●	●		●	●			○	○	○		
<b>S<sub>2</sub></b>	●	●			●	●		●	●			○	○	○		

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
<b>S<sub>1</sub></b>		●				●							
<b>S<sub>2</sub></b>		●				●							

Pulse instruction	16-bit instruction	32-bit instruction
AS	AS	-

**Symbol**

SCLOSE	SCLOSEP
En	En
S1	S1
S2	S2

**S<sub>1</sub>** : Socket mode

**S<sub>2</sub>** : Socket number

**Explanation**

1. This instruction closes the socket specified by **S<sub>1</sub>**. Set **S<sub>1</sub>** to 0 to close TCP socket, and set **S<sub>1</sub>** to 1 to close UDP socket.
2. **S<sub>2</sub>** is the socket number. It should correspond to the Ethernet socket number; up to 4 can be set.
3. The operand **S<sub>1</sub>** must be either 0 or 1 (default: 0); the operand **S<sub>2</sub>** must be between 1–4 (default: 1). If exceeding the range, error code H'2003 shows on the PLC.
4. Before closing the socket, make sure that the socket is connected or else the instruction is not executed.
5. If the client closes a TCP socket, the server continues to be connected to the local communication port (the flag for successful connection is ON). If the server closes a TCP socket, the server is no longer connected to the local communication port after the instruction is executed. When a TCP socket is closed, the corresponding flags are OFF.
6. After the instruction is executed to close a UDP socket, the corresponding flags are OFF.
7. If a TCP socket is closed, and no error occurs after the instruction is executed, the connection with the remote device starts to close and the flag for closing connection is ON. If the connection is closed successfully, the flag for closing connection is OFF. If an error occurs, the error flag is ON.

TCP Socket Number	Connection Closed	Error Flag
1	SM1274	SM1277
2	SM1282	SM1285
3	SM1290	SM1293
4	SM1298	SM1301

8. If a UDP socket is closed, and no error occurs after the instruction is executed, the flag for started connection is OFF. If an error occurs, the error flag is ON.

UDP Socket Number	Error Flag
1	SM1338
2	SM1343
3	SM1348
4	SM1353

9. In general, the pulse SCLOSEP instruction is used.

### Example

Refer to the example for the SOPEN instruction (API 2200).

### Additional remarks

1. The following table lists the TCP connection errors.

Error Code	Error Flag	Description
16#2003	SM0	<b>S<sub>1</sub></b> or <b>S<sub>2</sub></b> exceeds the range
16#600D	SM1100	Ethernet network not connected
16#6212	TCP Socket error flag	TCP Socket communication timeout
16#6214	TCP Socket error flag	TCP Socket connection rejected by remote device
16#621A	TCP Socket error flag	Disabling TCP Socket connection triggered

2. The following table explains UDP connection errors.

Error Code	Error Flag	Description
16#2003	SM0	<b>S<sub>1</sub></b> or <b>S<sub>2</sub></b> exceeds the range
16#600D	SM1100	Ethernet network not connected
16#621A	UDP Socket error flag	Disabling UDP Socket connection triggered

API	Instruction code			Operand							Function				
2204		MSEND	P	S <sub>1</sub> , S <sub>2</sub> , S <sub>3</sub> , D							Sending an email				

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
S <sub>1</sub>	●	●			●	●		●	●			○	○	○		
S <sub>2</sub>	●	●			●	●		●	●							
S <sub>3</sub>	●	●			●	●		●	●							
D	●	●	●	●				●								

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
S <sub>1</sub>		●				●							
S <sub>2</sub>		●				●							
S <sub>3</sub>		●				●							
D	●												

Pulse instruction	16-bit instruction	32-bit instruction
AS	AS	-

Symbol

MSEND		MSENDP	
En		En	
S1	D	S1	D
S2		S2	
S3		S3	

- S<sub>1</sub> : Remote email number
- S<sub>2</sub> : Email subject
- S<sub>3</sub> : Email body
- D : Completion of the instruction

Explanation

1. This instruction creates and sends an email by setting S<sub>1</sub>, S<sub>2</sub>, and S<sub>3</sub>.
2. Before using the instruction, set the following values in ISPSOft.
  - PLC Parameter Setting → Ethernet-Basic → Setting IP address and netmask address
  - PLC Parameter Setting → Ethernet-Advanced → Email → Setting SMTP server, port, local email address, and SMTP subject
  - PLC Parameter Setting → Ethernet-Advanced → Email and Trigger Configuration → Setting email address
  - If account identification is required: PLC Parameter Setting → Ethernet-Advanced → Email → Setting user name and password


3. The email is set as follows.

Operand	Description	Setting Range
S <sub>1</sub>	Remote email number	The value in S <sub>1</sub> must be between 1–15. Set Bit 0–bit 3 in ISPSOft to indicate the remote email addresses. You can set up to four email addresses in ISPSOft. Bit 0 corresponds to email 1, bit 1 corresponds to email 2, and so on. If you want to send an email, you must set the corresponding bit in ISPSOft.
S <sub>2</sub>	Email subject	Size of email subject: up to 16 words
S <sub>3</sub>	Email body	Size of email body: up to 64 words
D	Completion of the instruction	After the execution of the instruction is complete, the bit is ON. If the execution of the instruction is abnormal, the next bit (D+1) is ON.

4. In general, the MSENDP pulse instruction is used.

**Example**

Suppose the value in D0 is 00000101. When X0.0 is ON, the email is sent to email numbers 1 and 3. After the communication with the SMTP sever is complete, M20 is ON. If no error occurs during the communication, M21 is OFF and Y0.0 is ON.



**Additional remarks**

1. For the length of the string in **S<sub>2</sub>** or **S<sub>3</sub>**, the system captures the data with the end of 16#00. If the length of the string is larger than the maximum value (with 16#00 as the end), the length of the string in **S<sub>2</sub>** or **S<sub>3</sub>** is processed as the maximum value.
2. If you declare the operand **D** in ISPSOft, the data type is ARRAY [2] of WORD/INT.
3. Reserve one word between **S<sub>2</sub>** and **S<sub>3</sub>** for the interrupt character.
4. The following table explains errors in the execution of the email instruction.

Error Code	Error Flag	Description
16#2003	SM0	1. <b>D+1</b> exceeds device range 2. <b>S<sub>1</sub></b> <1 or <b>S<sub>1</sub></b> >15
16#600D	SM1100	Ethernet network not connected
16#6100	D+1	Communication conflicts
16#6107	D+1	Email communication timeout
16#6108	D+1	Error in password authentication of SMTP server account
16#6111	D+1	Invalid remote email address


API	Instruction code			Operand								Function					
2206		INTOA	P	<b>S, D</b>								Converting an integer IP address into a string IP address					

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
<b>S</b>								●	●							
<b>D</b>								●								

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
<b>S</b>		●				●							
<b>D</b>		●				●							

Pulse instruction	16-bit instruction	32-bit instruction
AS	AS	-

**Symbol**




**S** : Source value  
**D** : Conversion result

**Explanation**

1. This instruction converts the IP address in **S** and **S**+1 into a string IP address, and stores the conversion result in **D**.
2. The operand **D** occupies eight consecutive devices.

**Example**



**Additional remarks**

1. If you declare the operand **S** in ISPSOft, the data type is ARRAY [2] of WORD/INT.
2. If you declare the operand **D** in ISPSOft, the data type is ARRAY [8] of WORD/INT.


API	Instruction code			Operand								Function			
2207		IATON	P	S, D								Converting a string IP address into an integer IP address			

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
S								●	●						○	
D								●								

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
S		●				●							●
D		●				●							

Pulse instruction	16-bit instruction	32-bit instruction
AS	AS	-


Symbol



**S** : Source value  
**D** : Conversion result


Explanation

- This instruction converts the string IP address in **S** into an integer IP address, and stores the conversion result in **D** and **D+1**.
- The operand **S** occupies eight consecutive devices.




- There are 1–3 characters in every section of the string IP address in **S**. These sections are separated by "." (16#2E). For example, you can enter "192.168.0.1" instead of "192.168.000.001".
- The value of each section of the string IP address in **S** must be between 0–255.

**Example 1**



**Example 2**



**Additional remarks**

1. If the string in **S** does not end with 16#00, SM0 is ON, and the error code in SR0 is 16#200E.
2. In the string in **S**, except for the code representing the decimal point, the binary codes must be between 16#30–16#39 or the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2003.
3. If there are not three decimal points “.” in the string in **S**, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2003.
4. If the value of any section of the string IP address in **S** is not between 0–255, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2003.
5. The number of characters in any section of the string IP address in **S** must be between 1–3 or the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2003.

6. If you declare the operand **S** in ISPSOft, the data type is ARRAY [8] of WORD/INT.
7. If you declare the operand **D** in ISPSOft, the data type is ARRAY [2] of WORD/INT.


API	Instruction code			Operand								Function					
2208		EIPRW		<b>S<sub>1</sub>-S<sub>7</sub>, n, S, D<sub>1</sub>, D<sub>2</sub></b>								Reading and writing EtherNet/IP data					

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
S <sub>1</sub>								●	●							
S <sub>2</sub>								●	●				○	○		
S <sub>3</sub>								●	●				○	○		
S <sub>4</sub>								●	●				○	○		
S <sub>5</sub>								●	●				○	○		
S <sub>6</sub>	●	●	●	●												
S <sub>7</sub>								●	●				○	○		
n								●	●				○	○		
S								●								
D <sub>1</sub>								●								
D <sub>2</sub>								●								

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
S <sub>1</sub> -D <sub>2</sub>	Refer to Explanation in the instruction.												

Pulse instruction	16-bit instruction	32-bit instruction
-	AS	-

Symbol



**S<sub>1</sub>-S<sub>7</sub>, n, S** : See Explanation below.

**D<sub>1</sub>-D<sub>2</sub>** : See Explanation below.

**Explanation**

1. This instruction reads and writes EtherNet/IP data. The following table lists the names and explanations of **S<sub>1</sub>–S<sub>7</sub>**, **n**, **S** and **D<sub>1</sub>–D<sub>2</sub>**.


Operand	Name	Description	Data Type	Remarks
<b>S<sub>1</sub></b>	IP address	The first two sections of the IP address occupy the first word and the remaining two sections of the IP address occupy the second word. For example, if the IP address is 192.168.1.5, <b>S<sub>1</sub></b> =16#C0A8 and <b>S<sub>1</sub>+1</b> =16#0105.	WORD[2]	Occupies two consecutive words
<b>S<sub>2</sub></b>	Connection mode	0: UCMM	WORD	
<b>S<sub>3</sub></b>	Function code (Service code)	Range: 16#0000–00FF. If the function code exceeds the range, the instruction is not executed.	WORD	
<b>S<sub>4</sub></b>	Class ID	Refer to EtherNet/IP protocol.	WORD	
<b>S<sub>5</sub></b>	Instance ID	Refer to EtherNet/IP protocol.	WORD	
<b>S<sub>6</sub></b>	Attribute ID switch	ON: Enable; OFF: Disable	BOOL	
<b>S<sub>7</sub></b>	Attribute ID	Refer to EtherNet/IP protocol.	WORD	
<b>n</b>	Length of read and write data	Size of the data to be written or read; unit: byte; maximum: 200 bytes	WORD	
<b>S</b>	Register for the read/write data	Source register for the sent data or where the received data is stored	WORD[n]	
<b>D<sub>1</sub></b>	Communication status	0: Communication not triggered 1: Communication in process 2: Communication completed without errors 3: Communication error 4: Error in parameter setting	WORD	
<b>D<sub>2</sub></b>	Error code	Major error code and extended error code	WORD[2]	Occupies two consecutive words

2. When you enable this instruction for the first time, it sends the communication command. If the number of connected slaves reaches the upper limit, the communication status value in **D1** is 3, and the communication command is not sent. The error code shows 16#6306 in **D2[1]**.
3. When the parameter exceeds the range, the instruction is not executed and the communication status value in **D1** is 4.
4. This instruction should work with rising-edge trigger. If it is repeatedly triggered, the error code shows 16#02 in **D2[0]**. Wait till the execution of the instruction is complete before starting another instruction.

**Example 1**

The instruction reads the vendor code of the device at 192.168.1.5 and stores the value in D100. It sets the EtherNet/IP Object parameters as shown below.


- (1) Class ID = 1
- (2) Instance ID = 1
- (3) Attribute ID = 1



**Example 2**

The maximum frequency (01-00) of the AC motor drive (at 192.168.1.6) is set to 60.00Hz. The EtherNet/IP Object parameters are set as shown below.

- (1) Class ID = 16#0300
- (2) Instance ID = 16#0001
- (3) Attribute ID = 16#0000



**Additional remarks**

- 1. If you declare the operand **S<sub>1</sub>** in ISPSOft, the data type is ARRAY [2] of WORD.
- 2. If you declare the operand **S** in ISPSOft, the data type is ARRAY [n] of WORD, where **n** is the size of the read/written data.
- 3. If you declare the operand **D<sub>2</sub>** in ISPSOft, the data type is ARRAY [2] of WORD.

4. The following table explains the error codes in **D<sub>2</sub> [0]**.

Status Code	Description	What to Do
16#00	Connection successful	
16#01	Connection error	Ensure the EDS file of the slave is correct.
16#02	Connected devices unavailable	<ol style="list-style-type: none"> <li>1. Ensure the number of devices connected to the master does not exceed the limit.</li> <li>2. Ensure the number of devices connected to the slave does not exceed the limit.</li> <li>3. The instruction is triggered repeatedly. Wait till the execution of the instruction is complete before starting another instruction.</li> </ol>
16#03	Error in parameter	Ensure the read/written data in <b>S</b> is correct.
16#04	Path error	Ensure the settings are correct for Class ID ( <b>S<sub>4</sub></b> ), Instance ID ( <b>S<sub>5</sub></b> ), and Attribute ID ( <b>S<sub>7</sub></b> ).
16#05	Destination path does not exist	Ensure the settings are correct for Class ID ( <b>S<sub>4</sub></b> ), Instance ID ( <b>S<sub>5</sub></b> ), and Attribute ID ( <b>S<sub>7</sub></b> ).
16#07	Connection broken	<ol style="list-style-type: none"> <li>1. Ensure the Ethernet port of the slave device is connected properly.</li> <li>2. Ensure the keep alive timer setting is correct for the slave device.</li> </ol>
16#08	Service code not supported	Ensure the function code ( <b>S<sub>3</sub></b> ) is correct.
16#09	Invalid attribute value	Ensure both the registers involved in reading/writing data and their contents are correct.
16#0A	Error in attribute list	Ensure the slave device object attribute allows PLC to perform the Get_Attribute_List and Set_Attribute_List functions.
16#0B	Transmission conflicts	Ensure the service setting is repeated.
16#0C	Object status conflicts	Ensure the Owner IO connection is established.
16#0D	Object existed	Ensure the slave supports the defined object. The service does not need to execute if the defined object is supported.
16#0E	Attribute not writable	Ensure the object attribute supports the write function.

Status Code	Description	What to Do
16#0F	No privilege to perform service code	Ensure the slave device is allowed to perform the service code.
16#10	Device cannot currently perform service	Ensure the Owner IO connection is established.
16#11	Size of response data too large	Ensure the length of data in the object attribute does not exceed the limit (100 words).
16#12	Data access sequence error when tag is accessed	Ensure the data length and the data type are correct.
16#13	Transmitted data too short	Ensure the length ( <b>n</b> ) of read/written data is correct.
16#14	Attribute value unsupported	Ensure the Attribute ID switch ( <b>S<sub>6</sub></b> ) and Attribute ID ( <b>S<sub>7</sub></b> ) are correct.
16#15	Transmitted data are too long	Ensure the read/written data length ( <b>n</b> ) is correct.
16#16	Object does not exist	Ensure the Class ID ( <b>S<sub>4</sub></b> ) is correct.
16#17	Data access sequence error when tag is accessed	<ol style="list-style-type: none"> <li>1. Ensure the Ethernet network connection is correct.</li> <li>2. Ensure no packets are lost in the Ethernet communication.</li> </ol>
16#18	Attribute value not stored	Ensure no error state on the slave device occurred.
16#19	Attribute value storage error	Ensure no hardware error on the slave device occurred.
16#1A	Router error: length of request packet exceeds limit	Ensure the read/written data length ( <b>n</b> ) does not exceed the limit of the router.
16#1B	Router error: length of response packet exceeds limit	Ensure the read/written data length ( <b>n</b> ) does not exceed the limit of the router.
16#1F	User-defined object access error	Refer to the definition of the slave device error.
16#20	Illegal parameter value	Ensure the read/written value in <b>S</b> is correct.

5. The following table explains the error codes in **D<sub>2</sub> [0]**.

Error Code	Error Flag	Description
16#2003	SM0 / D <sub>1</sub>	1. Value in <b>S<sub>1</sub></b> , <b>S<sub>2</sub></b> , <b>S<sub>3</sub></b> , or <b>S<sub>6</sub></b> exceeds the range 2. <b>S+n</b> out of range of the device address
16#200B	SM0	Operand <b>n</b> out of range
16#600D	SM1100	Ethernet network not connected
16#6301	D <sub>1</sub>	Connection with remote device broken
16#6302	D <sub>1</sub>	Remote device response timeout
16#6303	D <sub>1</sub>	Illegal IP address
16#6304	D <sub>1</sub>	Error in response command service code
16#6305	D <sub>1</sub>	Error in response command length
16#6306	D <sub>1</sub>	Communication conflicts

API	Instruction code			Operand							Function					
2209		SCONF	P	<b>S<sub>1</sub>-S<sub>10</sub></b>							Setting the TCP/UDP Socket parameters					

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
S <sub>1</sub>								●	●				○	○		
S <sub>2</sub>								●	●				○	○		
S <sub>3</sub>								●	●				○	○		
S <sub>4</sub>								●	●				○	○		
S <sub>5</sub>								●	●				○	○		
S <sub>6</sub>								●	●				○	○		
S <sub>7</sub>								●	●				○	○		
S <sub>8</sub>								●	●				○	○		
S <sub>9</sub>								●	●				○	○		
S <sub>10</sub>								●	●				○	○		

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
<b>S<sub>1</sub>-S<sub>10</sub></b>	Refer to Explanation in the instruction.												

Pulse instruction	16-bit instruction	32-bit instruction
AS	AS	-

Symbol

SCONF		SCONFP	
En		En	
S1		S1	
S2		S2	
S3		S3	
S4		S4	
S5		S5	
S6		S6	
S7		S7	
S8		S8	
S9		S9	
S10		S10	

**S<sub>1</sub>-S<sub>10</sub>** : See Explanation below

Explanation

- This instruction sets the TCP/UDP Socket parameters. The following table lists the names and explanations of **S<sub>1</sub>-S<sub>10</sub>**.

Operand	Name	Description	Data Type	Remarks
<b>S<sub>1</sub></b>	TCP/UDP selection	0: TCP, 1: UDP	WORD	
<b>S<sub>2</sub></b>	Socket number	Range: 1-4	WORD	

Operand	Name	Description	Data Type	Remarks
<b>S<sub>3</sub></b>	Remote IP address	The first two sections of the IP address occupy the first word and the remaining two sections of the IP address occupy the second word. For example, if the IP address is 192.168.1.5, <b>S<sub>3</sub></b> =16#C0A8 and <b>S<sub>3</sub>+1</b> =16#0105.	WORD[2]	Occupies two consecutive words
<b>S<sub>4</sub></b>	Remote port	Range: 0–65535; 0 indicates any port	WORD	
<b>S<sub>5</sub></b>	Local port	Range: 0–65535; 0 indicates any port	WORD	
<b>S<sub>6</sub></b>	Register where sent data comes from	Specifies the number of a D device. Range: 0–29999. Example: The setting value 100 means <b>S<sub>7</sub></b> bytes of data are sent from the registers starting at D100 (from the low byte to the high byte).	WORD	
<b>S<sub>7</sub></b>	Size of sent data	Maximum: 512 bytes For PLC with FW V1.06.30 or later; maximum: 4096 bytes	WORD	
<b>S<sub>8</sub></b>	Register where received data is stored	Specifies the number of a D device. Range: 0–29999. Example: The setting value 200 means <b>S<sub>9</sub></b> bytes of data are received and stored in the registers starting at D200 (from the low byte to the high byte).	WORD	
<b>S<sub>9</sub></b>	Size of received data	Maximum: 512 bytes For PLC with FW V1.06.30 or later; maximum: 4096 bytes	WORD	
<b>S<sub>10</sub></b>	Connection time	Range: 1–30000, unit: second	WORD	Applicable to TCP mode only

2. In general, the SCONFP pulse instruction is used.
3. The Socket parameters uses the setting values in HWCONFIG by default. Use the SCONFP instruction when the parameters need to be changed during communication.
4. If you set the parameters while the socket is communicating, the settings do not take effect until the communication is complete. The setting should be changed after the socket is no longer in use.
5. If any one of the parameters is out of range, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2003.

API	Instruction code			Operand							Function					
2210		MCONF	P	S <sub>1</sub> -S <sub>11</sub>							Reading/Writing Modbus TCP data					

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
S <sub>1</sub>								●	●				○	○		
S <sub>2</sub>								●	●							
S <sub>3</sub>								●	●				○	○		
S <sub>4</sub>								●	●				○	○		
S <sub>5</sub>								●	●				○	○		
S <sub>6</sub>								●	●				○	○		
S <sub>7</sub>			●					●								
S <sub>8</sub>								●	●				○	○		
S <sub>9</sub>								●	●				○	○		
S <sub>10</sub>								●	●				○	○		
S <sub>11</sub>			●					●								

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
S <sub>1</sub> -S <sub>11</sub>	Refer to Explanation in the instruction.												

Pulse instruction	16-bit instruction	32-bit instruction
AS	AS	-

Symbol

MCONF		MCONF	
En		En	
S1		S1	
S2		S2	
S3		S3	
S4		S4	
S5		S5	
S6		S6	
S7		S7	
S8		S8	
S9		S9	
S10		S10	
S11		S11	

S<sub>1</sub>-S<sub>11</sub> : See Explanation below

## Explanation

1. This instruction reads and writes Modbus TCP data. The following table lists the names and explanations of **S<sub>1</sub>**–**S<sub>11</sub>**.

Operand	Name	Description	Data Type	Remarks
<b>S<sub>1</sub></b>	Data Exchange Table No.	Modbus TCP data exchange table number, range: 1–32	WORD	
<b>S<sub>2</sub></b>	Remote IP address	The first two sections of the IP address occupy the first word and the remaining two sections of the IP address occupy the second word. For example, if the IP address is 192.168.1.5, <b>S<sub>2</sub></b> =16#C0A8 and <b>S<sub>2</sub>+1</b> =16#0105.	WORD[2]	Occupies two consecutive words
<b>S<sub>3</sub></b>	Station address of remote slave	Range: 0–255. If the setting exceeds the range, the value in the low byte is used automatically.	WORD	
<b>S<sub>4</sub></b>	Read function code	Range: 16#01, 02, 03, 04, and 17. If the function code is out of range, incoming parameters, including address and data length, are not modified.	WORD	
<b>S<sub>5</sub></b>	Read remote communication address	16#0000–16#FFFF	WORD	
<b>S<sub>6</sub></b>	Read data length	Function code 16#01-02 for reading Bit device, ranging from 1 to 256 Function code 16#03-04 for reading Word device, ranging from 1 to 100 When the setting value is 0 or less than 0, this function is not enabled. If the setting value is bigger than the maximum value, it will be seen as the maximum value.	WORD	
<b>S<sub>7</sub></b>	Local register where received data is stored	Function code for reading data in Bit device; M device only Function code for reading data in Word device; D device only	BOOL WORD	

Operand	Name	Description	Data Type	Remarks
<b>S<sub>8</sub></b>	Write function code	Range: 16#05, 06, 0F, and 10. If the function code is out of range, outgoing parameters, including address and data length, are not modified.	WORD	
<b>S<sub>9</sub></b>	Write remote communication address	Range:16#0000–16#FFFF	WORD	
<b>S<sub>10</sub></b>	Write data length	Function code 16#0F for writing Bit device, ranging from 1 to 256; the value in function code 16#05 can only be 1; for PLC with FW V1.06.20 or later: 0 can be used in 16#05 Function code 16#10 for writing Word device, ranging from 1 to 100; the value in function code 16#06 can only be 1; for PLC with FW V1.06.20 or later: 0 can be used in 16#05 When the setting value is 0 or less than 0, this function is not enabled. If the setting value is bigger than the maximum value, it will be seen as the maximum value.	WORD	
<b>S<sub>11</sub></b>	Local register where remote data is written	Function code for writing data in Bit device; M device only Function code for writing data in Word device; D device only	BOOL WORD	

- In general, use the MCONFP pulse instruction.
- The following points explain the Modbus communication function codes in **S<sub>4</sub>** and **S<sub>8</sub>**.

When the AS Series PLC reads the data from multiple bit devices (not discrete input devices), the function code sent is 1 (16#01).

When AS Series PLC reads the data from multiple bit devices (only discrete input devices), the function code sent is 2 (16#02).

When the AS Series PLC reads the data from multiple word devices (not input registers), the function code sent is 3 (16#03).

When the AS Series PLC reads the data from multiple word devices (only input registers), the function code sent is 4 (16#04).

When the AS Series PLC writes the status to one bit device, the function code sent is 5 (16#05).

When the AS Series PLC writes the data to one word device, the function code sent is 6 (16#06).

When the AS Series PLC writes the status to multiple bit devices, the function code sent is 15 (16#0F).

When the AS Series PLC writes the data to multiple word devices, the function code sent is 16 (16#10).

When the AS Series PLC writes the data to multiple word devices, the function code sent is 23 (16#17).

At present, the AS Series PLC only supports the function codes listed above.

4. The parameters in the instruction are valid only while PLC is running. When PLC is powered back on after being powered off, it takes the settings from the data exchange table by default. If you need to change some parameters during data exchange, this instruction modifies those parameters.
5. If the specified socket is already communicating, the new parameters become effective after the current communication is complete.
6. When any parameter is not within the valid range, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#200B.
7. The AS Series PLC does not support the Modbus TCP communication instruction or anything similar to the instruction ETHRW DVP series PLC. If you use the PLC program for Ethernet Modbus TCP communication control, enable "Program control" mode in the data exchange table first and use the SM numbers from the following table.

SM Number	Attribute	Explanation of Ethernet Data Exchange Parameters
SM1167	R/W	Flag to enable data exchange
SM1168–SM1199	R/W	Flag to enable data exchange connections 1–32
SM1200–SM1231	R	Success flag for data exchange connections 1–32
SM1232–SM1263	R	Error flag for data exchange connections 1–32

When data is received successfully, the success flag is ON. When there is an error receiving data, the error flag is ON. The success flag and the error flag of any one connection socket are never switched to ON at the same time.

8. The following table explains the (read-only) SR numbers used in data exchange.

SR Number	Explanation
SR1120–SR1151	Indicates the actual communication times for connections 1–32.
SR1152–SR1183	Indicate the communication error codes for connections 1–32.

The following table defines the error codes in SR1152–SR1183.

Error Code	Explanation
16#00XX	Remote device response error
16#F000	Ethernet network not connected
16#F001	Remote device response timeout
16#F003	TCP connection timeout
16#F007	Response command error
16#F009	Connection with remote device disconnected

API	Instruction			Operand							Description						
2211		EMCONF1	P	Server ~ Passw							Setting email server parameter values						

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
Server								●	●						○	
Port								●	●				○	○		
LMail								●	●						○	
Sub								●	●						○	
Verify								●	●				○	○		
User								●	●						○	
Passw								●	●						○	

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
	Refer to following instruction explanation												

Pulse Instruction	16-bit instruction	32-bit instruction
AS	AS	-

**Symbol**

**Server~Passw** : Refer to following explanation

EMCONF1	EMCONF1P
En	En
Server	Server
Port	Port
LMail	LMail
Sub	Sub
Verify	Verify
User	User
Passw	Passw


## Explanation

- This instruction is available for PLC with FW V1.06.00.
- See the operand name, use explanation and data type in the following table.

Operand	Name	Explanation	Data type	Remark
<b>Server</b>	Email server	<b>Server +0</b> : Data length, unit: bytes (0 or 4; 0: no modification) <b>Server +1~ Server +2</b> : data (Data are placed from the lower 8 bits.) For example: 192.168.0.1, D0 = 16#0004, D1= 16#0001, D2= 16#C0A8;	WORD[N]	Refer to <b>Server +0</b> for address occupation.  3 consecutive words at most can be occupied.
		Up to 15 words can be used in one string; every section in one string can contain 1-3 words, and use a dot "." to separate each string, for example 192.168.0.1	String	
<b>Port</b>	Communication port	Range: 1~65535, 0: no modification	WORD	
<b>LMail</b>	Local email address	<b>LMail +0</b> : data length, unit: bytes (range: 0~63, 0: no modification.) <b>LMail +1~ LMail +32</b> : data (Data are placed from the lower 8 bits.) For example: ex@deltaww.com D0 = 16#000E, D1 = 16#7865, D2 = 16#6440, D3 = 16#6C65, D4 = 16#6174, D5 = 16#7777, D6 = 16#2E63, D7 = 16#6D6F	WORD[N]	Refer to <b>LMail +0</b> for address occupation. 33 consecutive words at most can be occupied.
		Up to 63 words can be used in one string	String	
<b>Sub</b>	Email subject	<b>Sub +0</b> : data length, unit: bytes (range: 0~31, 0: no modification.) <b>Sub +1~ Sub +16</b> : data content (Data are placed from the lower 8 bits.) For example: Sub 0 = 16#0003, D1 = 16#7553, D2 = 16#0062	WORD[N]	Refer to <b>Sub +0</b> for address occupation. 17 consecutive words at most can be occupied.
		Up to 31 words can be used in one string	String	
<b>Verify</b>	Enable/ disable verification	0: no modification, 1: Disable verification, 2: Enable verification	WORD	

Operand	Name	Explanation	Data type	Remark
<b>User</b>	User name	<b>User +0</b> : data length, unit: bytes (range: 0~31, 0: no modification.) <b>User +1~ User +16</b> : data content (Data are placed from the lower 8 bits.) For example: User D0 = 16#0004, D1 = 16#7355, D2 = 16#7265	WORD[N]	Refer to <b>User +0</b> for address occupation. 17 consecutive words at most can be occupied.
		Up to 31 words can be used in one string	String	
<b>Passw</b>	Password	<b>Passw +0</b> : data length, unit: bytes (range: 0~20, 0: no modification.) <b>Passw +1~ Passw +10</b> : data content (Data are placed from the lower 8 bits.) For example: Passw D0 = 16#0005, D1 = 16#5061, D2 = 16#7373, D3 = 16#0077	WORD[N]	Refer to <b>Passw +0</b> for address occupation. 11 consecutive words at most can be occupied.
		Up to 20 words can be used in one string	String	

You can set up the email related settings in ISPSOft > HWCONFIG > Device Setting > Ethernet Port Advance Setting > Email. And from here you can also check the parameters which are set through instructions. But only the settings that are set in ISPSOft are retainable after power-off.



API	Instruction			Operand							Description					
2212	EMCONF2	P		<b>Index, Mail</b>							Setting email address					

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	“\$”	F
<b>Index</b>								●	●				○	○		
<b>Mail</b>								●	●						●	

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
	Refer to following instruction explanation												

Pulse Instruction	16-bit instruction	32-bit instruction
AS	AS	-

**Symbol**

EMCONF2	EMCONF2P
En	En
Index	Index
Mail	Mail

**Index, Mail** : Refer to following explanation

**Explanation**

- This instruction is available for PLC with FW V1.06.00.
- See the operand name, use explanation and data type in the following table.

Operand	Name	Explanation	Data type	Remark
<b>Index</b>	Mail address number	<b>Index:</b> The mail address number to be modified (Range: 0~4, 0: Not modify the mail address.)	WORD	
<b>Mail</b>	Mail address	<b>Mail +0:</b> the data length of <b>Index</b> value with the unit of bytes (range: 0~63, 0: Not modify the mail address.) <b>Mail +1~ Mail +32:</b> The data content of <b>Index</b> (Data are placed from the lower 8 bits.) For example: ex@deltaww.com D0 = 16#000E, D1 = 16#7865, D2 = 16#6440, D3 = 16#6C65, D4 = 16#6174, D5 = 16#7777, D6 = 16#632E, D7 = 16#6D6F	WORD[N]	Refer to <b>Mail +0</b> for address occupation. 33 consecutive words at most can be occupied.
		Up to 63 words can be used in one string	String	

You can set up the email related settings in ISPSOft > HWCONFIG > Device Setting > Ethernet Port Advance Setting > Email. And from here you can also check the parameters which are set through instructions. But only the settings that are set in ISPSOft are retainable after power-off.

Device Setting

Options Data Exchange -COM1 Data Exchange -COM2 Data Exchange -Ethernet Data Exchange -FEN02 Data Exchange -Function Card1 Data Exchange -Function Card2

AS332T-A

- System settings
  - COM1 Port Setting
  - COM2 Port Setting
  - Ethernet Port Basic Setting
  - Ethernet Port Advanced
    - IP Filter
    - NTP
    - Email
      - 1st Trigger Setting
      - 1st Trigger Recipient
      - 2nd Trigger Setting
      - 2nd Trigger Recipient
      - 3rd Trigger Setting
      - 3rd Trigger Recipient
      - 4th Trigger Setting
      - 4th Trigger Recipient

Email

Parameter name	Value	Unit	Default	Minimum	Maximum
Email Function Enable	<input checked="" type="checkbox"/>		<input type="checkbox"/>	-	-
SMTP Server	1.1.1.1		1.1.1.1	1.1.1.1	223.255.255.255
Port	25		25	1	65535
Local Email				-	-
Mail Subject				-	-
Account Identification	<input type="checkbox"/>		<input type="checkbox"/>	-	-
User name	...			-	-
Password				-	-
1st Remote Address	mail1@deltaww.com			-	-
2nd Remote Address	mail2@deltaww.com			-	-
3rd Remote Address	mail3@deltaww.com			-	-
4th Remote Address	mail4@deltaww.com			-	-

Default Import Export

OK

API	Instruction		Operand				Function					
2214	MQTT_Connect		<b>Execute ~ Status</b>				Establishing a MQTT connection					

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
Execute	●	●	●	●				●		●	●					
SID								●	●		●		●			
BrokerNum								●	●		●		●			
ClientID								●	●		●				●	
CleanSession	●	●	●	●				●		●	●					
WillTopic								●	●		●				●	
WillMessage								●	●		●				●	
WillRetain	●	●	●	●				●		●	●					
WillQos								●	●		●		●			
WillFlag	●	●	●	●				●		●	●					
KeepAlive								●	●		●		●			
Status								●			●					

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
Execute ~ Status	Refer to the following instruction explanation.												

Pulse Instruction	16-bit instruction	32-bit instruction
-	AS	-

6

Symbol

MQTT_Connect
En
Execute      Status
SID
BrokerN~
ClientID
CleanSes~
WillTopic
WillMes~
WillReta~
WillQos
WillFlag
KeepAli~

**Execute ~ Status** : See the instruction explanation below.

**Explanation**

1. This instruction is available for ISPSOft V3.16 or later and AS300 PLC with firmware V1.12 or later when the AS-FFTP01 function card is installed on the PLC.
2. Refer to the function descriptions on AS-FFTP01 in AS Series Module Manual or the instruction example below and set up MQTT parameters for AS-FFTP01 in HWCONFIG before use.
3. Operand names and descriptions are shown in the following table.


Operand	Name	Description	Data Type	Remarks
<b>Execute</b>	Execute	<ul style="list-style-type: none"> <li>● When <b>Execute</b> changes to ON, create a connection.</li> <li>● When <b>Execute</b> changes to OFF, create a disconnection.</li> </ul>	BOOL	
<b>SID</b>	Slot number	Fixed value: 34 (Representing the function card AS-FFTP01)	WORD	
<b>BrokerNum</b>	Server (Broker) ID	Fixed value: 1	WORD	
<b>ClientID</b>	Client name	The data is arranged in the order from the high byte to the low byte. The maximum length is 20 characters and the string terminator (16#00) is a must at the end.	WORD	See Explanation of <b>Client ID</b> below.
<b>CleanSession</b>	Clean Session	<ul style="list-style-type: none"> <li>● ON: The server will clear session data after disconnection.</li> <li>● OFF: The server will keep session data after disconnection.</li> </ul>	BOOL	See <b>Session</b> description below.
<b>WillTopic</b>	Will message topic	The data is arranged in the order from the high byte to the low byte. The maximum length is 100 characters and the string terminator (16#00) is a must at the end.	WORD	See Explanation of <b>Will Message</b> below.

Operand	Name	Description	Data Type	Remarks
<b>WillMessage</b>	Will message	The data is arranged in the order from the high byte to the low byte. The maximum length is 100 characters and the string terminator (16#00) is a must at the end.	WORD	
<b>WillRetain</b>	Retain Will message	Set whether Will message is retained on the server or not.	BOOL	
<b>WillQos</b>	Service quality for Will message	Set the quality of service (Qos) for Will message. Setting range: 0, 1	WORD	
<b>WillFlag</b>	Will message flag	<ul style="list-style-type: none"> <li>● ON: Enable Will message function</li> <li>● OFF: Disable Will message function</li> </ul>		
<b>KeepAlive</b>	Time of keeping connection alive	<p>When the idle time exceeds 1.5 times of this setting value (unit: second), the connection will be closed.</p> <ul style="list-style-type: none"> <li>● Setting range: 0~65535.</li> <li>● Suggested value: 60.</li> <li>● When the setting value is 0, the connection will not be closed, whether the idle time exceeding 1.5 times of the set value or not.</li> </ul> <p>The actual connection time is determined by the server account setting. Refer to the developer guide of the server platform for operation.</p>	DWORD	
<b>Status</b>	State	<ul style="list-style-type: none"> <li>● Status[0] Status code 0: Not connected /disconnected 1: Connected 2: Connecting/disconnecting 4: An error occurs and the error code will show up.</li> <li>● Status[1] Error code See the error code description below.</li> </ul>	WORD[2]	Two consecutive words are occupied. See <b>Timing diagrams</b> below for the timing to update.


4. Before starting **MQTT\_Publish** or **MQTT\_Subscribe**, make sure that the connection has been successfully established. You can use the status code of **MQTT\_Connect** to see if **MQTT\_Publish** or **MQTT\_Subscribe** can be started or not. For details, refer to the operation examples in **MQTT\_Publish** (API2215) and **MQTT\_Subscribe** (API2216).
5. Explanation of **Client ID**
  - (1) Use a unique name for the client as its Client ID, which is used by the server for identification. A Client ID should be a string and its content is limited to numbers and letters.
  - (2) When **ClientID** is set to 0, **CleanSession** must be set to ON.
6. **Session** description
  - (1) **Clean Session**: Indicates that the messages from the client will be deleted by the server after disconnection, and the previous sessions will be removed. It is recommended for the scenarios where messages are constantly being published or where loss of messages is acceptable.
  - (2) **Persistent Session**: Indicates that after disconnection, the server will retain the session, including uncompleted messaging. Once the connection is re-established, all subscriptions will be automatically resumed and stored messages will be automatically delivered. It is recommended for the scenarios where subscribers cannot lose messages and subscriber's messages must be stored.
  - (3) The actual messages and contents in a session are determined by the server account. Refer to the developer guide of the server platform for setup.
7. Explanation of **Will Message**
  - (1) The **Will Message** covers the parameters **WillTopic**, **WillMessage**, **WillRetain**, **WillQos** and **WillFlag**.
  - (2) To start the **Will Message** function, you need to set up the above parameters, set **WillFlag** to ON and then establish the connection. When the device is abnormally disconnected (the server receives no disconnection command but detects that the connection is interrupted), the server will send the Will message to other devices that have subscribed to the topic of the Will message.
  - (3) The characteristics of **WillTopic** and **WillMessage** are the same as those of general messages publishing. Refer to **Topic** and **Message** in **MQTT\_Publish** (API2215) for details.
  - (4) The characteristic of **WillRetain** is the same as that of general messages retaining. Refer to **Retain** in **MQTT\_Publish** (API2215) for details.
  - (5) The characteristic of **WillQos** is the same as Qos (Quality of Service) of general messages. Refer to **Qos** in **MQTT\_Publish** (API2215) for details.
  - (6) When **WillFlag** is set to FALSE, **WillRetain** must be set to OFF and **WillQos** must be set to 0.

8. Timing diagrams


(1) Normally connected and disconnected



(2) Disconnected during communication



(3) Failed to establish a connection



9. The error codes and explanation are shown in the following table:

(For **MQTT\_Connect** (API2214), **MQTT\_Publish** (API2215) and **MQTT\_Subscribe** (API2216))

Error Code	Explanation	Solution
0x2200	<b>SID</b> is out of range.	Modify the value of the input variable <b>SID</b> .
0x2201	Function card 2 is not AS-FFTP01.	Check if the card type of function card 2 is correct.
0x2202	<b>BrokerNum</b> is out of range.	Modify the value of the input variable <b>BrokerNum</b> .

Error Code	Explanation	Solution
0x2207	MQTT relevant instructions are being executed for communication.	Check the execution order of MQTT instructions; wait for the execution to complete ( <b>Status[0]</b> = 0, 1 or 4) and then have the next MQTT instruction executed.
0x2208	Timeout occurs in the communication between PLC and AS-FFTP01.	Adjust the setting of communication timeout in HWCONFIG for function card 2.
0x2209	AS-FFTP01 is busy.	Try again later.
0x220A	AS-FFTP01 is not ready (SM172 OFF).	Export the system log file through <b>System diagnostic</b> of the AS-FFTP01 webpage and contact the factory for analysis.
0x220B	The string length of <b>Topic</b> is out of range.	Modify the string length of the input variable <b>Topic</b> .
0x220C	The string length of <b>Message</b> is out of range.	Modify the string length of the input variable <b>Message</b> .
0x220D	<b>Qos</b> is out of range.	Modify the value of the input variable <b>Qos</b> .
0x8001	At least one parameter is invalid.	Check if all parameters of the API instruction conform to the usage specification.
0x8002	Buffer area is full.	The size of received packets exceeds 1024 bytes.
0x8003	Failed to send MQTT packets.	Check if the Ethernet network is normal.
0x8004	Failed to receive MQTT packets.	Check if the Ethernet network is normal.
0x8005	An invalid packet is received from the server.	<ul style="list-style-type: none"> <li>• Check if the operation status of the server is normal.</li> <li>• Export the system log file through <b>System diagnostic</b> of the AS-FFTP01 webpage and contact the factory for analysis.</li> </ul>
0x8006	The server refused a CONNECT or SUBSCRIBE.	Check if the operation status of the server is normal.
0x8008	An illegal state recorded	Export the system log file through System diagnostic of the AS-FFTP01 web page and contact the factory for analysis.
0x8009	The received packet is not consistent with what is recorded.	Use <b>MQTT_Connect</b> to disconnect and then reconnect if the connection status is unstable.
0x800A	PINGRESP timeout	<ul style="list-style-type: none"> <li>• Check if the Ethernet network is normal.</li> <li>• Check if the server is running normally.</li> </ul>


Error Code	Explanation	Solution
0x800B	Failed to establish TLS connection	<ul style="list-style-type: none"> <li>• Check if the Ethernet network is normal.</li> <li>• Check if the Endpoint address of the server is correct.</li> <li>• Check if the imported root certificate, device certificate and private key are correct.</li> <li>• Check if the server is still working.</li> <li>• Check if the network firewall setting allows the use of communication port 8883.</li> </ul>
0x800C	Failed to establish MQTT connection	Check the network status and re-execute the <b>MQTT_Connect</b> to establish the connection.
0x800D	Missing data in server endpoint address, root certificate, device certificate or private key	Go to MQTT User Setting in HWCONFIG for setting up the server endpoint address, root certificate, device certificate and private key and then downloading them.
0x800E	Subscription topic is empty.	Subscription topic cannot be empty.
0x800F	Number of subscribed topic reached the maximum.	After cancelling the subscription of the unrequired topics, trigger the Subscribe function again.
0x8010	QoS 2 is not supported.	Modify QoS level to 1 or 0.
0x8011	The topic is already subscribed to.	The same topic cannot be subscribed twice.

### Example


1. Refer to the function descriptions on AS-FFTP01 in the AS Series Module Manual for the setup on MQTT server endpoint address, key certificate and device certificate in HWCONFIG and then download the parameters for the AS-FFTP01 function card.
2. Parameters setting and descriptions

Parameter	Setting	Description
<b>SID</b>	34	Fixed parameter values
<b>BrokerNum</b>	1	
<b>ClientID</b>	"AS300"	The server will connect the session to Client ID: "AS300".
<b>CleanSession</b>	OFF	The session is not cleared and the subscription content from the last connection is retained after the connection is re-established.
<b>WillTopic</b>	"Status"	<ul style="list-style-type: none"> <li>• The clients who have subscribed to the topic "Status" of Will message will receive the message "AS300 is off-line" when the communication is lost.</li> </ul>
<b>WillMessage</b>	"\$AS300 is off-line\$"	

Parameter	Setting	Description
		<ul style="list-style-type: none"> <li>Double quotation marks should be included when sending string characters. You need to add a \$ before the double quotation marks (" ") to identify the double quotes as string characters, i.e., "\$AS300 is off-line".</li> </ul>
<b>WillRetain</b>	OFF	The server will not keep the Will message.
<b>WillQos</b>	1	Will message uses the level 1 QoS for communication and subscribers will receive Will message at least once.
<b>WillFlag</b>	ON	Will message function is enabled.
<b>KeepAlive</b>	10	When the disconnection time is over 15 seconds (1.5 times <b>KeepAlive</b> value), the server will actively close the connection and subscribers who have subscribed to the topic of Will message will receive the Will message.



3. Trigger to execute the instruction: Set **En** and **Execute** to ON in sequence, when Status[0] = 1, it indicates that the connection is completed.



4. Publish and Subscribe: **Status[0] = 1** can be set as the condition for **En** of **MQTT\_Publish** (API2215) and **MQTT\_Subscribe** (API2216). The Publish and Subscribe functions can be enabled only after the connection is established. Refer to **MQTT\_Publish** (API2215) and **MQTT\_Subscribe** (API2216). for parameters setting and operation examples.
5. When **Execute** is set to OFF, AS-FFTP01 will send a "disconnect" request. When **Status[0] = 0**, it indicates that the disconnection is executed. That is the standard process for a disconnection.
6. When AS-FFTP01 is disconnected from the server without warning, the clients who have subscribed to the topic "Status" will receive the message "AS300 is off-line".

API	Instruction				Operand								Function				
2215	MQTT_Publish				Execute ~ ErrCode								Publishing a MQTT message				

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
Execute	●	●	●	●				●		●	●					
SID								●	●		●		●			
BrokerNum								●	●		●		●			
Topic								●	●		●				●	
Message								●	●		●				●	
Size								●	●		●		●			
Qos								●	●		●		●			
Retain	●	●	●	●				●		●	●					
Dup	●	●	●	●				●		●	●					
Done		●	●	●				●		●	●					
Busy		●	●	●				●		●	●					
Error		●	●	●				●		●	●					
ErrCode								●			●					

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
Execute ~ ErrCode	Refer to following instruction explanation.												

Pulse Instruction	16-bit instruction	32-bit instruction
-	AS	-

Symbol

MQTT_Publish
En
Execute
Done
SID
Busy
BrokerNum
Error
Topic
ErrCode
Message
Size
Qos
Retain
Dup

**Execute ~ ErrCode** : See instruction explanation below.

**Explanation**

1. This instruction is available for ISPSOft V3.16 or later and AS300 PLC with firmware V1.12 or later when the AS-FFTP01 function card is installed on the PLC.
2. Refer to the function descriptions on AS-FFTP01 in AS Series Module Manual or the instruction example below and set up MQTT parameters for AS-FFTP01 in HWCONFIG before use.
3. Before starting **MQTT\_Publish**, make sure that the connection has been successfully established. You can use the status code of **MQTT\_Connect** to see if **MQTT\_Publish** can be started or not. For details, refer to the operation examples below.
4. Operand names and descriptions are shown in the following table.

Operand	Name	Description	Data Type	Remarks
<b>Execute</b>	Execute	<ul style="list-style-type: none"> <li>● When <b>Execute</b> changes to ON, start <b>MQTT_Publish</b></li> </ul>	BOOL	
<b>SID</b>	Slot number	Fixed value: 34 (Representing the function card AS-FFTP01)	WORD	
<b>BrokerNum</b>	Server (Broker) ID	Fixed value:1	WORD	
<b>Topic</b>	Topic	<ul style="list-style-type: none"> <li>● The maximum length is 100 characters including the string terminator (16#00).</li> <li>● The topic content cannot be empty.</li> </ul>	STRING[100]	
<b>Message</b>	Message	<ul style="list-style-type: none"> <li>● The maximum length is 256 characters including the string terminator (16#00)</li> </ul> Data arrangement description: <ul style="list-style-type: none"> <li>● Size = 0: From low byte to high byte</li> <li>● Size ≠ 0: From high byte to low byte</li> </ul>	WORD[128]	
<b>Size</b>	Message data length	<ul style="list-style-type: none"> <li>● 0: indicates that the type of message data is String, which is determined by the terminator (16#00).</li> <li>● 1-256: indicates that the type of the message data is the original data in hexadecimal system.</li> </ul>	WORD	

Operand	Name	Description	Data Type	Remarks
<b>Qos</b>	Quality of Service	Quality of service of the message, Setting range: 0, 1	WORD	See <b>Qos</b> explanation below.
<b>Retain</b>	Retain	Set whether the message is to be retained on the server or not.	BOOL	See <b>Retain</b> function explanation below.
<b>Dup</b>	DUP flag	Users can make a mark to indicate if the published message is a duplicate message or not. Generally, it is set to OFF. When <b>QoS</b> is set to 0, <b>Dup</b> must be set to OFF. <ul style="list-style-type: none"> <li>● OFF: The message is published for the first time.</li> <li>● ON: The message is marked as a duplicate message.</li> </ul>	BOOL	
<b>Done</b>	Completed	Communication is completed.	BOOL	
<b>Busy</b>	Busy	Communication is busy.	BOOL	
<b>Error</b>	Error	An error occurs and an error code shows up.	BOOL	
<b>ErrCode</b>	Error code	For error codes, refer to <b>MQTT_Connect</b> (API2214).	WORD	

#### 5. **QoS** (Quality of Service)

QoS is a symmetric communication agreement. Publishers and subscribers can set their own QoS levels and different QoS levels determine different transmissions or receptions. AS-FFTP01 supports QoS of level 1 and 2.


- (1) QoS=0: It does not guarantee that the message will be received. Whether the message will be received or not depends on the network state.
  - The publisher sends a message only once.
  - The subscriber does not reply whether the message is received or not.
  - When publishing a message with **QoS** set to 0, **Dup** must be set to OFF.
- (2) QoS=1: It guarantees that the message will be received at least once.
  - The subscriber will reply with an acknowledgement packet (PUBACK Packet) after receiving the message.

- The publisher and the server will retain the message until the acknowledgement packet is received from the subscriber.
- Message Resend: If the subscriber does not receive the message after the message is published, the message will be automatically resent if the session is not cleared (**CleanSession** set to OFF) when the connection is reestablished successfully.

6. **Retain** function.

- (1) When the published message is retained (**Retain = ON**), the server will save the message and its QoS data and deliver the last retained message to all new subscribers of the topic in the future.
- (2) When the published message is retained (**Retain = ON**), the server will NOT save the message and the retained messages which have been saved will NOT be removed or replaced.

7. Timing diagram




**Example**

1. Refer to **MQTT\_Connect** (API2214).to establish the connection.
2. Parameters setting and descriptions


Parameter	Setting	Description
<b>SID</b>	34	Fixed parameter values
<b>BrokerNum</b>	1	
<b>Topic</b>	"MyTopic"	<ul style="list-style-type: none"> <li>● The clients who have subscribed to the topic "MyTopic" will receive the message "Hello from AS-FFTP01".</li> <li>● Double quotation marks should be included when sending string characters. You need to add a \$ before the double quotation marks (" ") to identify the double quotes as string characters.</li> </ul>
<b>Message</b>	"\$"Hello from AS-FFTP01.\$""	

Parameter	Setting	Description
<b>Size</b>	0	The setting value 0 means to send the string message.
<b>Qos</b>	1	It guarantees that the message is to be received at least once.
<b>Retain</b>	OFF	The message will NOT be retained.
<b>Dup</b>	OFF	The message is NOT marked as a duplicate message.



3. Trigger to execute the instruction

When **Status[0]** = 1 of **MQTT\_Connect**, **En** is ON; it indicates the connection is established. Once **En** is ON, you can execute **MQTT\_Publish**. After **Execute** is set to ON, publishing data is completed and **Done** is ON.




4. To send a string message (**Size** = 0), the low-byte data will be transmitted first, and then the high-byte data will be transmitted. See the example of data transmission shown below.

M_P_message[0]		WORD	H"	leH"	ASCII	▼
M_P_message[1]		WORD	le	olle	ASCII	▼
M_P_message[2]		WORD	ol	f ol	ASCII	▼
M_P_message[3]		WORD	f	orf	ASCII	▼
M_P_message[4]		WORD	or	mor	ASCII	▼
M_P_message[5]		WORD	m	S.A m	ASCII	▼
M_P_message[6]		WORD	SA	F-SA	ASCII	▼
M_P_message[7]		WORD	F-	TF-	ASCII	▼
M_P_message[8]		WORD	TF	0PTF	ASCII	▼
M_P_message[9]		WORD	0P	.10P	ASCII	▼
M_P_message[10]		WORD	.1	*".1	ASCII	▼
M_P_message[11]		WORD	**	***"	ASCII	▼
M_P_message[12]		WORD	**	****	ASCII	▼

The clients who have subscribed to the topic "MyTopic" will receive the message "Hello from AS-FFTP01". Take the data received with **MQTT\_Subscribe** as an example shown below.

M_S_R_message[1]		WORD	"H	el"H	ASCII	▼
M_S_R_message[2]		WORD	el	loel	ASCII	▼
M_S_R_message[3]		WORD	lo	flo	ASCII	▼
M_S_R_message[4]		WORD	f	ro f	ASCII	▼
M_S_R_message[5]		WORD	ro	m ro	ASCII	▼
M_S_R_message[6]		WORD	m	ASm	ASCII	▼
M_S_R_message[7]		WORD	AS	-FAS	ASCII	▼
M_S_R_message[8]		WORD	-F	FT-F	ASCII	▼
M_S_R_message[9]		WORD	FT	POFT	ASCII	▼
M_S_R_message[10]		WORD	P0	1.P0	ASCII	▼
M_S_R_message[11]		WORD	1.	"*1	ASCII	▼
M_S_R_message[12]		WORD	**	***"	ASCII	▼

5. Even if the subscriber is disconnected at the time of the message being published and fails to receive the message, as long as the subscriber's QoS level is 1, the message "Hello from AS-FFTP01." will be resent to the subscriber, if the session is not cleared (**CleanSession** is set to OFF) after the connection is resumed.
6. If **Retain** is set to ON, the message "Hello from AS-FFTP01." will be received by the new subscribers of the topic "MyTopic" once they are connected.
7. To transmit a non-string message (**Size** ≠ 0), the high-byte data will be transmitted first, and then the low-byte data. You can specify the data length in **M\_P\_size**. Modify the above example to publish 9 bytes starting from D600, and compare the original data with the data received via **MQTT\_Subscribe**, as the example shown below.



	D600		0011	22330011
	D601		2233	44552233
	D602		4455	66774455
	D603		6677	88006677
	D604		8800	00008800
M_S_R_message[0]		WORD	9	1114121
M_S_R_message[1]		WORD	0011	22330011
M_S_R_message[2]		WORD	2233	44552233
M_S_R_message[3]		WORD	4455	66774455
M_S_R_message[4]		WORD	6677	88006677
M_S_R_message[5]		WORD	8800	00008800
M_S_R_message[6]		WORD	0000	00000000


API	Instruction		Operand				Function					
2216	MQTT_Subscribe		<b>Execute ~ RecvTopic</b>				Subscribing to a MQTT topic					

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	“\$”	F
<b>Execute</b>	●	●	●	●				●		●	●					
<b>SID</b>								●	●		●		●			
<b>BrokerNum</b>								●	●		●		●			
<b>Topic</b>								●	●		●				●	
<b>Qos</b>								●	●		●		●			
<b>Status</b>								●			●					
<b>Message</b>								●			●					
<b>RecvTopic</b>								●			●					

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
<b>Execute ~ RecvTopic</b>	Refer to following instruction explanation.												

Pulse Instruction	16-bit instruction	32-bit instruction
-	AS	-

Symbol



**Execute ~ RecvTopic** : See instruction explanation below.

Explanation

1. This instruction is available for ISPSOft V3.16 or later and AS300 PLC with firmware V1.12 or later when the AS-FFTP01 function card is installed on the PLC.
2. Refer to the function descriptions on AS-FFTP01 in AS Series Module Manual or the instruction example below and set up MQTT parameters for AS-FFTP01 in HWCONFIG before use.


3. Before starting **MQTT\_Subscribe**, make sure that the connection has been successfully established. You can use the status code of **MQTT\_Connect** to see if **MQTT\_Subscribe** can be started or not. For details, refer to the operation examples below.
4. Operand names and descriptions are shown in the following table.

Operand	Name	Description	Data Type	Remarks
<b>Execute</b>	Execute	<ul style="list-style-type: none"> <li>When <b>Execute</b> changes to ON, start <b>MQTT_Subscribe</b>.</li> <li>When <b>Execute</b> changes to OFF, stop <b>MQTT_Subscribe</b>.</li> </ul>	BOOL	
<b>SID</b>	Slot number	Fixed value: 34 (Representing the function card AS-FFTP01)	WORD	
<b>BrokerNum</b>	Server (Broker) ID	Fixed value 1	WORD	
<b>Topic</b>	Topic	<ul style="list-style-type: none"> <li>The maximum length is 100 characters. The terminator (16#00) is a must at the end of the string.</li> <li>The topic content cannot be empty.</li> </ul>	STRING[100]	
<b>Qos</b>	Quality of Service	Quality of service of the message, Setting range: 0, 1	WORD	Refer to Qos explanation in <b>MQTT_Publish</b> (API2215).
<b>Status</b>	State	<ul style="list-style-type: none"> <li>Status[0]: Status code 0: Unsubscribed 1: Subscribed 3: Received a new message 4: Subscribing/unsubscribing 8: An error occurs and an error code will show up.</li> <li>Status[1]: Error code See the error code description in <b>MQTT_Connect</b> (API 2214).</li> </ul>	WORD[2]	Two consecutive words are occupied. See <b>Timing diagrams</b> below for update timing.
<b>Message</b>	Message	<ul style="list-style-type: none"> <li>Message[0]: Size of the received message;</li> </ul>	WORD[129]	


Operand	Name	Description	Data Type	Remarks
		<ul style="list-style-type: none"><li>● Message[1]: Content of the received message; A maximum of 256 characters; The data is arranged in the order from the high byte to the low byte, and the terminator (16#00) is placed at the end.</li></ul>		
<b>RcvTopic</b>	Received topic	<p>When subscribing to multiple topics at the same time, it is necessary to identify the topic of each message source.</p> <ul style="list-style-type: none"><li>● RcvTopic[0]: Size of the topic of the message source;</li><li>● RcvTopic[1]: Content of the received topic; A maximum of 100 characters. The data is arranged in the order from the high byte to the low byte, and the terminator (16#00) is placed at the end.</li></ul>	WORD[51]	

Timing diagrams

(1) Subscribed, received and unsubscribed




(2) Failed to subscribe



Example

1. Refer to **MQTT\_Connect** (API2214) to establish the connection.
2. Parameters setting and descriptions

Parameter	Setting	Description
<b>SID</b>	34	Fixed parameter values
<b>BrokerNum</b>	1	
<b>Topic</b>	"MyTopic"	The topic to be subscribed to
<b>Qos</b>	1	It guarantees that the message is to be received at least once.



3. Trigger to execute the instruction

When **Status[0] = 1** of **MQTT\_Connect**, **En** is ON; it indicates the connection is established. Once **En** is ON, you can execute **MQTT\_Subscribe**. After **Execute** is set to ON, the subscription is successful and **Status[0] = 1**



4. Receive data

After the publisher sends a message to "MyTopic" (refer to the example in **MQTT\_Publish** (API2215)), the function card AS-FFTP01 will receive the message "Hello from AS-FFTP01.". The data lengths of the topic and the message are stored in byte in Message[0] and RecvTopic[0], and the topic name and the message contents are stored in Message[1] and RecvTopic[1] by order.



MQTT	M_S_R_topic[0]		WORD	7	Signed Decimal	▼
MQTT	M_S_R_topic[1]		WORD	My	ASCII	▼
MQTT	M_S_R_topic[2]		WORD	To	ASCII	▼
MQTT	M_S_R_topic[3]		WORD	pi	ASCII	▼
MQTT	M_S_R_topic[4]		WORD	c*	ASCII	▼
MQTT	M_S_R_topic[5]		WORD	**	ASCII	▼
MQTT	M_S_R_message[0]		WORD	23	Signed Decimal	▼
MQTT	M_S_R_message[1]		WORD	"H	ASCII	▼
MQTT	M_S_R_message[2]		WORD	el	ASCII	▼
MQTT	M_S_R_message[3]		WORD	lo	ASCII	▼
MQTT	M_S_R_message[4]		WORD	f	ASCII	▼
MQTT	M_S_R_message[5]		WORD	ro	ASCII	▼
MQTT	M_S_R_message[6]		WORD	m	ASCII	▼
MQTT	M_S_R_message[7]		WORD	AS	ASCII	▼
MQTT	M_S_R_message[8]		WORD	-F	ASCII	▼
MQTT	M_S_R_message[9]		WORD	FT	ASCII	▼
MQTT	M_S_R_message[10]		WORD	P0	ASCII	▼
MQTT	M_S_R_message[11]		WORD	1.	ASCII	▼
MQTT	M_S_R_message[12]		WORD	**	ASCII	▼

5. Unsubscribe: When **Execute** is set to OFF, an Unsubscribe packet for the topic specified by **Topic** will be sent to the server. When **Status[0]** is 0, the topic is unsubscribed successfully.
6. If you did NOT execute the Unsubscribe function, even if the connection stops or the PLC enters STOP state, you can still receive the message of the topic previously subscribed to, after the connection is re-established, the PLC returns to RUN state and **CleanSession** is set to OFF. If you execute the **MQTT\_Subscribe** again when the connection loss occurs, you will receive the error code 16#8011, which tells you that the topic has already been subscribed to.
7. When the QoS level for the message of the topic subscribed to is 1, the message will be received at least once after the connection loss occurs. Make sure the session is retained (**CleanSession** set to OFF) when the connection is re-established, and the QoS level of the published message is 1 as well; the message will be redelivered.

## 6.23 Memory Card / File Register Instructions

### 6.23.1 List of Memory Card / File Register Instructions

The following table lists the Memory Card / File Register instructions covered in this section.

API	Instruction code		Pulse instruction	Function
	16-bit	32-bit		
<b><u>2300</u></b>	MWRIT	–	✓	Writing data from the PLC into the memory card
<b><u>2301</u></b>	MREAD	–	✓	Reading data from the memory card into the PLC
<b><u>2302</u></b>	MTWRIT	–	✓	Writing a string into the memory card
<b><u>2303</u></b>	MEMW	–	✓	Writing data into the file register
<b><u>2304</u></b>	MDEL	–	✓	Deleting files on the memory card
<b><u>2305</u></b>	Record_Trigger	–	–	Recording and writing data into a file

### 6.23.2 Explanation of Memory Card / File Register Instructions


API	Instruction code			Operand	Function
2300	MWRIT	P		<b>C, S, S<sub>1</sub>, S<sub>2</sub>, S<sub>3</sub>, S<sub>4</sub></b>	Writing data from the PLC into the memory card

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
<b>C</b>								●	●				○	○		
<b>S</b>								●	●							
<b>S<sub>1</sub></b>								●	●				○	○		
<b>S<sub>2</sub></b>								●	●				○	○		
<b>S<sub>3</sub></b>								●	●						○	
<b>S<sub>4</sub></b>								●	●				○	○		

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
<b>C</b>		●											
<b>S</b>		●											
<b>S<sub>1</sub></b>			●										
<b>S<sub>2</sub></b>		●											
<b>S<sub>3</sub></b>													●
<b>S<sub>4</sub></b>			●										

Pulse instruction	16-bit instruction	32-bit instruction
AS	AS	-

#### Symbol




- C** : Control parameter
- S** : Data source
- S<sub>1</sub>** : Data length
- S<sub>2</sub>** : Line advance
- S<sub>3</sub>** : File name
- S<sub>4</sub>** : Data address in the file

#### Explanation

1. This instruction writes data from the PLC to the memory card. The operands are described as follows.

- **C**: The control parameter



Item	Code	Description
File format	0	Binary value
		Default value
		The file name extension is .dmd.
		The unit of the value is a word.
	1	The values are separated by a comma.
		The unit of the value is a word.
		The file name extension is .cvs.
		Use ASCII codes..
		The value that is stored is a hexadecimal format.
	2	The values are separated by a comma.
		The unit of the value is a double word.
		The file name extension is .cvs.
		Use ASCII codes.
		The value that is stored is a hexadecimal format.
	3	The values are separated by a tab.
		The unit of the value is a word.
		The file name extension is .txt.
		Use ASCII codes.
		The value that is stored is a hexadecimal format.
	4	The values are separated by a tab.
		The unit of the value is a double word.
		The file name extension is .txt.
		Use ASCII codes.
		The value that is stored is a hexadecimal format.
5	The values are not separated by any mark.	
	The unit of the value is a word.	
	The file name extension is .txt.	
	Use ASCII codes.	
	The value that is stored is a hexadecimal format.	
6	The values are not separated by any mark.	


Item	Code	Description	
		The unit of the value is a double word.	
		The file name extension is .txt.	
		Use ASCII codes.	
		The value that is stored is a hexadecimal format.	
	7	The values are separated by a comma. (V1.04.00 or later supports )	
		The unit of the value is a Word.	
		The file name extension is.csv.	
		Use ASCII codes.	
		The value that is stored is a decimal format.	
		Function option	0
If the file does not exist, it is created automatically.			
1	Overwriting The data that is written into the memory card replaces the values in the file starting from the value indicated by the value in <b>S4</b> .		
	If the file does not exist, it is created automatically.		
	Reserved		-

- **S**: The data source
- **S<sub>1</sub>**: The length of the data that the instruction writes into the file

If the value in **S<sub>1</sub>** is 0, the instruction does not write any data into the file.

Item	Description
Value unit	If the file format is 0, 1, 3, 5, or 7, the unit of the value is a word. If the file format is 2, 4, or 6, the unit of the value is a double word.
Parameter unit	Double word
Length of the data	The devices where the instruction stores the data cannot exceed the device range, and the size of the data that the instruction writes into the file cannot be more than four gigabytes. Refer to Chapter 2 for more information about devices.

- **S<sub>2</sub>**: The line advance; the value in **S<sub>2</sub>** must be between 0–256.
- AS CPU firmware version 1.04.00 or later supports using string (less than 9 characters) in the file name **S<sub>3</sub>**. Firmware version 1.08.30 or later supports up to 200 characters (16#00 included) in the file name **S<sub>3</sub>**.
- **S<sub>3</sub>–S<sub>3</sub>+4**: **S<sub>3</sub>** occupies five devices. The file name contains a maximum of nine characters, including 16#00. If the string does not end with 16#00, an error occurs. When the instruction reads the ending character, it stops reading, and checks if the file name is legal. The characters in the file name can be A–Z, a–z, and 0–9. The file name extension depends on the file format. The file that the instruction creates is in the default folder. If the file name is “Test1”, the instruction writes the characters into the devices as follows.



- The default folder path:

Model name	Folder path
AS300 Series	PLC CARD\AS300\UserProg
AS200 Series	PLC CARD\AS200\UserProg

- **S<sub>4</sub>**: The value in the file that the instruction overwrites is indicated by the value in **S<sub>4</sub>**.

Item	Description
Value unit	If the file format is 0, 1, 3, 5 or 7, the unit of the value is a word. If the file format is 2, 4, or 6, the unit of the value is a double word. (refer to operand C)
Parameter unit	Double word.
Usage	If the function option is 0, <b>S<sub>4</sub></b> is not used.
	If the function option is 1, the instruction replaces the values in the file with the data to be written into the memory card starting from the value indicated by the value in <b>S<sub>4</sub></b> .
	The value in <b>S<sub>4</sub></b> must indicate a value in the file.
	If the value in <b>S<sub>4</sub></b> is 0, the instruction overwrites the data in the file starting at the first value in the file.

2. Instruction flags:

Flag	Description
SM450	ON: the memory card is in the CPU module.
SM451	State of the write protection switch on the memory card ON: the memory card is write protected. OFF: the memory card is not write protected.
SM452	The data is being written from the PLC to the memory card, or the data is being read from the memory card to the PLC.
SM453	ON: an error occurs during the operation of the memory card. If the flag is ON, you must reset it to OFF. The error code is stored in SR453.


### 3. Related error codes (SR453):

Error code	Description
16#005E	An error occurs when the memory card is initialized.
16#005F	The path is incorrect, or the file does not exist.
16#0060	The default folder cannot be created.
16#0061	The memory space is insufficient.
16#0062	The memory card is write protected.
16#0063	An error occurs when the data is written into the file.
16#0064	The data cannot be read from the memory card.
16#0065	The file is a read-only file.

4. If the format of the target file on the memory card is 0, the format of the source file in the PLC must also be 0. Otherwise, the instruction cannot read the data, and SM453 is ON. The same applies to the other file formats.

### Example

SM450 is ON when you insert the memory card into the CPU module; SM452 is ON when the MWRIT instruction executes; SM452 is OFF when the MWRIT instruction completes. You cannot use MWRITP (the pulse instruction) continuously. Executing this pulse instruction to write data into the memory card continuously may exceed the writing limitation and may lead to memory card damage.



Operand	Setting value	Description
D0	16#0011	The file into which the data is written The file format: The values are separated by a comma. The unit of the value is a word. The file name extension is .csv. Use ASCII codes.
D1	-	The data that is written into the file
D10, D11	16#00000030	The size of the data that is written into the file is 48 words.
D300	16#000A	Ten values are written into every line.
D20	D20=16#6554 D21=16#7473 D22=16#0031	The file name is "Test1".
D30, D31	16#00000000	The data that is written into the memory card replaces the values in the file starting from the first value.

**Additional remarks**

1. If the value in **C** exceeds the range, an operation error occurs, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2003.
2. If the value in **S<sub>1</sub>** exceeds the range, an operation error occurs, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2003.
3. If the value in **S<sub>2</sub>** exceeds the range, an operation error occurs, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2003.
4. If the value in **S<sub>3</sub>** exceeds the range, an operation error occurs, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2003.

API	Instruction code			Operand							Function						
2301		MREAD	P	<b>C, S, S<sub>1</sub>, S<sub>2</sub>, S<sub>3</sub>, D</b>							Reading data from the memory card into the PLC						

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
<b>C</b>								●	●				○	○		
<b>S</b>								●	●						○	
<b>S<sub>1</sub></b>								●	●				○	○		
<b>S<sub>2</sub></b>								●	●				○	○		
<b>S<sub>3</sub></b>								●	●				○	○		
<b>D</b>								●								

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
<b>C</b>		●											
<b>S</b>													●
<b>S<sub>1</sub></b>			●										
<b>S<sub>2</sub></b>		●											
<b>S<sub>3</sub></b>			●										
<b>D</b>		●											

Pulse instruction	16-bit instruction	32-bit instruction
AS	AS	-

**Symbol**

**C** : Control parameter


**S** : File name

**S<sub>1</sub>** : Data address in the file

**S<sub>2</sub>** : Reserved

**S<sub>3</sub>** : Data length


**D** : Data destination



**Explanation**

1. This instruction reads data from the memory card into the PLC. The operands are described as follows.

- **C**: The control parameter



Item	Code	Description
File format	0	Binary value
		The default value is 0.
		The file name extension is .dmd.
		The unit of the value is a word.
	1	The values are separated by a comma.
		The unit of the value is a word.
		The file name extension is .cvs.
		Use ASCII codes.
		The value that is stored is a hexadecimal value.
	2	The values are separated by a comma.
		The unit of the value is a double word.
		The file name extension is .cvs.
		Use ASCII codes.
		The value that is stored is a hexadecimal value.
	3	The values are separated by a tab.
		The unit of the value is a word.
		The file name extension is .txt.
		Use ASCII codes.
		The value that is stored is a hexadecimal value.
	4	The values are separated by a tab.
		The unit of the value is a double word.
		The file name extension is .txt.
		Use ASCII codes.
		The value that is stored is a hexadecimal value.
5	The values are not separated by any mark.	
	The unit of the value is a word.	
	The file name extension is .txt.	
	Use ASCII codes.	
	The value that is stored is a hexadecimal value.	
6	The values are not separated by any mark.	
	The unit of the value is a double word.	

Item	Code	Description	
		The file name extension is .txt.	
		Use ASCII codes.	
		The value that is stored is a hexadecimal value.	
	7		The values are separated by a comma. (V1.04.00 or later supports )
			The unit of the value is a Word.
			The file name extension is.csv.
			Use ASCII codes.
		The value that is stored is a decimal format.	
Function option	0	The values in the file starting from the value indicated by the value in <b>S<sub>1</sub></b> are read. The default value is 0.	
	1	The number of values is stored in <b>D</b> and <b>D+1</b> . If the file format is 0, 1, 3, or 5, the unit of the value is a word. If the file format is 2, 4, or 6, the unit of the value is a double word.	
Reserved	-	The values of bit 8–bit 15 are 0.	

- AS CPU firmware version 1.04.00 or later supports using string (less than 9 characters) in the file name **S**.
- S–S+4**: **S** occupies five devices. The file name contains a maximum of nine characters, including 16#00. If the string does not end with 16#00, an error occurs. When the instruction reads the ending character, the instruction stops reading characters, and checks if the file name is legal. The characters in a file name can be A–Z, a–z, and 0–9. The file name extension depends on the file format. The file that the instruction creates is in the default folder. If the file name is “Test1”, the instruction writes the characters into the devices as follows.

	ASCII Code			ASCII Code		
S	'e'	'T'	→	S	16#65	16#54
S+1	't'	's'		S+1	16#74	16#73
S+2	NUL	'1'		S+2	16#00	16#31

- The default folder path:

Model name	Folder path
AS300 Series	PLC CARD\AS300\UserProg
AS200 Series	PLC CARD\AS200\UserProg

- S<sub>1</sub>**: The value in the file that the instruction reads is indicated by the value in **S<sub>1</sub>**.

Item	Description
Value unit	Refer to operand C for its file format. If the file format is 0, 1, 3, 5 or 7, the unit of the value is a word. If the file format is 2, 4, or 6, the unit of the value is a double word.
Parameter unit	The parameter unit is a double word.
Usage	The value in <b>S<sub>1</sub></b> must indicate a value in the file. If the value in <b>S<sub>1</sub></b> is 0, the instruction reads from the first value in the file.

- **S<sub>3</sub>**: The length of the data that the instruction reads from the file

The devices in which the instruction stores the data cannot exceed the device range. If the value in **S<sub>3</sub>** is larger than the number of values in the file, the length of the data read from the file is the number of values in the file. The unit **S<sub>3</sub>** is a double word.

AS CPU firmware version 1.08.30 or later supports up to 200 characters (16#00 included) in the file name **S<sub>3</sub>**.

- **D**: The initial device where the data is stored.

2. Instruction flags:

Flag	Description
SM450	ON: the memory card is in the CPU module
SM451	The write protection switch on the memory card ON: the memory card is write protected. OFF: the memory card is not write protected.
SM452	The data is being written from the PLC to the memory card, or the data is being read from the memory card into the PLC.
SM453	ON: an error occurs during the operation of the memory card. If the flag is ON, you must reset it to OFF. The error code is stored in SR453.

3. Related error codes (SR453):


Error code	Description
16#005E	An error occurs when the memory card is initialized.
16#005F	The path is incorrect, or the file does not exist.
16#0060	The default folder cannot be created.
16#0061	The memory space is insufficient.

Error code	Description
16#0062	The memory card is write protected.
16#0063	An error occurs when the data is written into the file.
16#0064	The data cannot be read from the memory card.

- If the format of the target file into which the instruction writes data is 0, the format of the file from which the instruction reads data must also be 0. Otherwise, the instruction cannot read the data, and SM453 is ON. The same applies to the other file formats.

**Example**

SM450 is ON when the memory card is inserted into the CPU module; SM452 is ON when the MREAD instruction executes; SM452 is OFF when the MREAD instruction completes.



Operand	Setting value	Description
D0	16#0011	The file from which the data is read The file format: The values are separated by a comma. The unit of the value is a word. The file name extension is .csv. Use ASCII codes.
D300	D300=16#6554 D301=16#7473 D302=16#0031	The file name is "Test1".
D10, D11	16#00000000	The values in the file starting from the first value are read.
D1	16#000A	Ten values are read from every line.
D30, D31	16#00000020	The size of the data that is read from the file is 32 words.
D20	-	The data that is read is stored in D20.

**Additional remarks**

1. If the value in **C** exceeds the range, an operation error occurs, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2003.
2. If the value in **S<sub>2</sub>** exceeds the range, an operation error occurs, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2003.
3. If the value in **S<sub>3</sub>** exceeds the range, an operation error occurs, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2003.
4. If the value in **D** exceeds the range, an operation error occurs, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2003.

API	Instruction code			Operand							Function						
2302		MTWRIT	P	<b>C, S, S<sub>1</sub>, S<sub>2</sub>, S<sub>3</sub></b>							Writing a string into the memory card						

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
<b>C</b>								●	●				○	○		
<b>S</b>								●	●							
<b>S<sub>1</sub></b>								●	●				○	○		
<b>S<sub>2</sub></b>								●	●				○	○		
<b>S<sub>3</sub></b>								●	●						○	

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
<b>C</b>		●											
<b>S</b>		●											
<b>S<sub>1</sub></b>		●											
<b>S<sub>2</sub></b>		●											
<b>S<sub>3</sub></b>													●

Pulse instruction	16-bit instruction	32-bit instruction
AS	AS	-

**Symbol**

**C** : Control parameter

MTWRIT
En
C
S
S <sub>1</sub>
S <sub>2</sub>
S <sub>3</sub>

MTWRITP
En
C
S
S <sub>1</sub>
S <sub>2</sub>
S <sub>3</sub>

**S** : Data source

**S<sub>1</sub>** : Data length

**S<sub>2</sub>** : Separation mark

**S<sub>3</sub>** : File name

**Explanation**

1. This instruction writes a string into the memory card. The operands are described as follows.

- **C**: The control parameter

Parameter value	Description
0 (Appending)	If the file exists, the data that is written into the memory card is appended after the last byte in the file.
	If the file does not exist, it is created automatically.
	If the file exists, the new data that is written to the memory card replaces the old data in the

1	file. The size of the file is the size of the new data.
(Overwriting)	If the file does not exist, it is created automatically.

- **S:** The data source

If the string that the instruction writes into the file is “12345”, the instruction stores the characters in the devices as follows. The basic unit is a byte, and so the instruction stores the first character in the low byte in D300. The instruction stores the second character in the high byte in D300. The same applies to other characters. The instruction stores “16#00” in the high byte in D300+2, and indicates the end of the string.

S300		S300+1		S300+2		
byte 2	byte 1	byte 4	byte 3	byte 6	byte 5	
16#32	16#31	16#34	16#33	16#00	16#35	

- **S<sub>1</sub>:** The length of the data that is written into the memory card

The basic unit is a byte. The devices where the instruction stores the data cannot exceed the device range, and the length of the data that the instruction writes into the memory card cannot be more than 255 bytes.

- **S<sub>2</sub>:** The separation mark

If the value in **S<sub>1</sub>** is N, the instruction writes the value in **S<sub>2</sub>** into the memory card as follows.

<b>S<sub>2</sub> Operand</b>		<b>Description</b>
<b>High byte</b>	<b>Low byte</b>	
16#00	16#00 or Not 16#00	The N-byte data is written into the file.
Not 16#00	16#00	The N+1-byte data is written into the file. The value in the high byte in <b>S<sub>2</sub></b> is the value in the N+1 <sup>st</sup> byte.
Not 16#00	Not 16#00	The N+2-byte data is written into the file. The value in the high byte in <b>S<sub>2</sub></b> is the value in the seventh byte, and the value in low byte in <b>S<sub>2</sub></b> is the value in the N+2 <sup>th</sup> byte.

- AS CPU firmware version 1.04.00 or later supports using string (less than 9 characters) in the file name **S<sub>3</sub>**. Firmware version 1.08.30 or later supports up to 200 characters (16#00 included) in the file name **S<sub>3</sub>**.
- **S<sub>3</sub>–S<sub>3</sub>+4:** **S<sub>3</sub>** occupies five devices. The file name contains a maximum of nine characters, including 16#00. If the string does not end with 16#00, an error occurs. When the instruction reads the ending character, the instruction stops reading characters, and checks if the file name is legal. The characters in the file name can be A–Z, a–z, and 0–9. The file name extension depends on the file format. The file that the instruction creates is in the default folder. If the file name is “Test1”, the instruction writes characters into the devices as follows.

		ASCII Code			
S3	'e'	'T'	S3	16#65	16#54
S3+1	't'	's'	S3+1	16#74	16#73
S3+2	NUL	'1'	S3+2	16#00	16#31

- The default folder path:

Model name	Folder path
AS300 Series	PLC CARD\AS300\UserProg
AS200 Series	PLC CARD\AS200\UserProg

## 2. Instruction flags


Flag	Description
SM450	ON: the memory card is in the CPU module.
SM451	The write protection switch on the memory card ON: the memory card is write protected. OFF: the memory card is not write protected.
SM452	The data is being written from the PLC into the memory card, or the data is being read from the memory card into the PLC.
SM453	ON: an error occurs during the operation of the memory card. If the flag is ON, you must reset it to OFF. The error code is stored in SR453.

## 3. Related error codes (SR453):

Error code	Description
16#005E	An error occurs when the memory card is initialized.
16#005F	The path is incorrect, or the file does not exist.
16#0060	The default folder cannot be created.
16#0061	The memory space is insufficient.
16#0062	The memory card is write protected.
16#0063	An error occurs when the data is written into the file.
16#0064	The data cannot be read from the memory card.
16#0065	The file is a read-only file.

**Example:**

SM450 is ON when the memory card is inserted into the CPU module; SM452 is ON when the MTWRIT instruction executes; SM452 is OFF when the MTWRIT instruction completes.



Operand	Setting value	Description
D0	16#0001	The file into which the data is written The file format: The unit of the character is a byte. The file name extension is .txt. Use ASCII codes. The data in D300 is written to the file.
D300	-	The data that is written to the file
D10	16#000A	The size of the string that is written to the file is 10 bytes.
D1	16#0A00	After the data is written to the file, the separation mark is appended after the last byte in the file.
D30	D30=16#6554 D31=16#7473 D32=16#0031	The file name is "Test1".

**Additional remarks**

1. If the value in **C** exceeds the range, an operation error occurs, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2003.
2. If the value in **S<sub>1</sub>** exceeds the range, an operation error occurs, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2003.
3. If the value in **S<sub>3</sub>** exceeds the range, an operation error occurs, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2003.


API	Instruction code			Operand							Function						
2303		MEMW	P	S, D, n							Writing data into the file register						

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
S	●	●			●	●		●								
D									●							
n	●	●			●	●		●				●	○	○		

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
S		●											
D		●											
n		●											

Pulse instruction	16-bit instruction	32-bit instruction
AS	AS	-

**Symbol**



**S** : The first address of the data source

**D** : The first address where the data is stored

**n** : Data length

**Explanation**

- This instruction writes data into the file register. The description of the operands is as follows.
  - S**: The initial address of the data source; it is suggested that you declare an array type variable.
  - D**: The initial address where the instruction stores data. It is suggested that you assign an address for the file register and declare an array type variable.
  - n**: The length of the data that the instruction writes into the file register, between 1–2048. If the value exceeds the range, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#200B.
  - If the device **S** or **D** exceeds the allowed range, SM0 is ON, and the error code in SR0 is 16#2003.
- Since it takes 60–120 ms for the instruction to write the data, it is suggested that you use this instruction when the PLC is idle. For example, when there is no external interrupt task, no high-speed output, or any immediate events for the PLC to process.
- The instruction writes only when the contact switches from OFF to ON and writes only once.  
NOTE: You can write into this file register a maximum of 100,000 times.

API	Instruction code			Operand							Function				
2304		MDEL	P	ctrl, fname							Deleting files on the memory card				

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
ctrl								●					○	○		
fname								●	●						○	

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
ctrl		●				●							
fname													●

Pulse instruction	16-bit instruction	32-bit instruction
AS	AS	-

**Symbol**

MDEL
En
ctrl
fname

MDELP
En
ctrl
fname


**ctrl** : Control parameter

**fname** : Data source

**Explanation**

1. This instruction writes data from the PLC to the memory card. The operands are described as follows.

- **ctrl**: The control parameter



Item	Code	Description
File format	0	The file name extension is .dmd.
	1, 2, 7	The file name extension is .cvs.
	3, 4, 5, 6	The file name extension is .txt.
Reserved	-	The values of bit 8–bit 15 are 0.

- You can use strings (less than 9 characters) in the in **fname** (file name).
- **fname** occupies five devices. The file name contains a maximum of nine characters, including 16#00. If the string does not end with 16#00, an error occurs. When the instruction reads the ending character, it stops reading, and checks if the file name is legal. The characters in the file name can be A–Z, a–z, and 0–9. The file name extension depends on the file format. The file that the instruction creates is in the default folder. If the file name is "Test1", the instruction writes the characters into the devices as follows.

		ASCII Code			
S3	'e'	'T'	S3	16#65	16#54
S3+1	't'	's'	S3+1	16#74	16#73
S3+2	NUL	'1'	S3+2	16#00	16#31

- The default folder path:

Model name	Folder path
AS300 Series	PLC CARD\AS300\UserProg
AS200 Series	PLC CARD\AS200\UserProg

- AS CPU firmware version 1.08.30 or later supports up to 200 characters (16#00 included) in the file name **S<sub>3</sub>**.

## 2. Instruction flags:


Flag	Description
SM450	ON: the memory card is in the CPU module.
SM451	State of the write protection switch on the memory card ON: the memory card is write protected. OFF: the memory card is not write protected.
SM452	The data is being written from the PLC to the memory card, or the data is being read from the memory card to the PLC.
SM453	ON: an error occurs during the operation of the memory card. If the flag is ON, you must reset it to OFF. The error code is stored in SR453.

## 3. Related error codes (SR453):

Error code	Description
16#005E	An error occurs when the memory card is initialized.
16#005F	The path is incorrect, or the file does not exist.
16#0060	The default folder cannot be created.
16#0061	The memory space is insufficient.
16#0062	The memory card is write protected.
16#0063	An error occurs when the data is written into the file.

**Example**

SM450 is ON when you insert the memory card into the CPU module; SM452 is ON when this instruction executes; SM452 is OFF when this instruction completes.



Operand	Setting value	Description
D0	16#0001	The file name extension is .cvs.
D20	D20=16#6554 D21=16#7473 D22=16#0031	The file name is "Test1".

**Additional remarks**

6

1. If the value in **ctrl** exceeds the range, an operation error occurs, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2003.
2. If the value in **fname** exceeds the range, an operation error occurs, the instruction is not executed, SM0 is ON, and the error code in SR0 is 16#2003.

API	Instruction code		Operand							Function						
2305	Record_Trigger		Execute ~ ErrCode							Recording and writing data into a file						

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
Execute	●	●	●	●	●	●	●	●		●	●					
SID	●	●			●	●	●	●	●		●		●			
Tb_num	●	●			●	●	●	●	●		●		●			
W_mode	●	●	●	●	●	●	●	●		●	●					
Done		●	●	●	●	●	●	●		●	●					
Busy		●	●	●	●	●	●	●		●	●					
Error		●	●	●	●	●	●	●		●	●					
ErrCode		●			●	●	●	●			●					

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
Execute	●												
SID		●				●							
Tb_num		●				●							
W_mode	●												
Done	●												
Busy	●												
Error	●												
ErrCode		●				●							

Pulse Instruction	16-bit instruction	32-bit instruction
-	AS	-

**Symbol**

Record_Trigger	
En	
Execute	Done
SID	Busy
Tb_num	Error
W_mode	ErrCode

**Execute ~ W\_mode** : Refer to instruction explanation below.

**Done ~ ErrCode** : Refer to instruction explanation below.

**Explanation**

1. This instruction is available only for ISPSOft V3.16 or later.
2. This instruction is available for AS300 PLC with firmware V1.12 or later when the AS-FFTP01 function card is installed on the PLC. Before use, refer to the function description on AS-FFTP01 in AS Series Module Manual or the example below to complete the setting of the log parameters for AS-FFTP01 in HWCONFIG.
3. Set Log Mode to Program Control first in HWCONFIG before using the instruction.

Relevant parameters setting is described as follows.

Log mode	Log cycle	Parameter Setting
PLC Run	Use the Log Cycle in HWCONFIG	Use the parameters in HWCONFIG
Always Enable		
Program Control	"Execute" is triggered by users	Log cycles, including Second, Minute, Hour, Date and Month are not supported in the following settings "New File Creating Timing", "New File Creating Parameter" and "Save to SD Card Timing".

4. Operand names and descriptions are shown in the following table.


Operand	Name	Description	Data Type	Remarks
Execute	Execute	When <b>Execute</b> changes to ON, start recording.	BOOL	
SID	Slot ID	Fixed value: 34 (Representing the function card AS-FFTP01)	WORD	
Tb_num	Table number	Specify which table number (1 to 4) from HWCONFIG to record.	WORD	
W_mode	Write mode	Before <b>Execute</b> changes to ON, it is required to have the Mode set. <ul style="list-style-type: none"> <li>OFF: After <b>Execute</b> is set to ON, the data is written into the buffer area first. The data in the buffer area will be written into a file only after the conditions set in HWCONFIG are met.</li> <li>ON: After <b>Execute</b> is set to ON, the data is written into the buffer area first. The data in the buffer area will be directly written to a file.</li> </ul>	BOOL	
Done	Completion flag	Execution completion flag <ul style="list-style-type: none"> <li>OFF: Not executed/ incomplete</li> <li>ON: Done successfully</li> </ul>	BOOL	
Busy	Busy flag	Execution busy flag <ul style="list-style-type: none"> <li>OFF: Not executing</li> <li>ON: Executing</li> </ul>	BOOL	
Error	Error flag	Error flag <ul style="list-style-type: none"> <li>OFF: No error</li> <li>ON: An error occurred</li> </ul>	BOOL	
ErrCode	Error code	Refer to the error code description below.	WORD	

## 5. Error codes and descriptions

Error code	Description
16#220B	The setting value of <b>Tb_num</b> is out of range.
16#0001	The number of subdirectories has reached the upper limit (500), and no more subdirectory can be created.
16#0002	No SD card is installed. Check and re-insert the SD card.
16#0003	Failed to write data into a file.
16#0004	Failed to record data.
16#0005	Incorrect log mode. Set Log Mode to "Program Control" in HWCONFIG.
16#0006	Parameter setting error

**Example**

- Using FTP Client software to check if the SD card can be read correctly. For the FTP setting, refer to the function description on AS-FFTP01 in Chapter 10 from AS Series Module Manual.
- Make sure that the time zone setting (HWCONFIG -> Ethernet Port Advanced Setting -> NTP -> Time Zone) and the RTC setting (ISPSOft -> Tools-> Set RTC) for the AS300 PLC are set correctly.
- Go to HWCONFIG -> AS-FFTP01 for parameters setting



- On the Table 1 page, filling in the parameter name, register type, register address, data type and etc. Fields 1 and 2 are fixed for displaying date and time, and the self-defined fields start from ID 3. In this example, the data stored in two data registers are in the formats of integer and floating point respectively.

Column Id	Column Name	Register Type	Register Address	Data Type	Decimal Places
1	Date				
2	Time				
3	VFD Frequency	D	2103	INT16	0
4	Temperature	D	0	Float	2

(2) Set the Log Mode to Program Control and ignore the Log Cycle parameter here.

Log Mode						
Name	Setting Value	Unit	Default	Minimum	Maximum	
Log Mode	Program Control		Program Control	-	-	
Log Cycle	100	0.1 sec	100	5	1200	

(3) Set Parent Directory Name, Subdirectory Name and File Name on the File Name page.

The data will be saved in: SD card/Delta/MyLog\_date/Device\_log\_date\_time.csv

File Name						
Name	Setting Value	Unit	Default	Minimum	Maximum	
Parent directory Name (SD Card/)	Delta			-	-	
Subdirectory Name	MyLog		LOG1	-	-	
Automatically Appended Subdirectory Name	Date		Disable	-	-	
File Name (.csv)	Device_log		log1	-	-	
Automatically Appended File Name	Data + Time		Disable	-	-	

(4) On the Parameter Settings page, set up the following parameters “New File Creating Timing”, “New File Creating Parameter”, “Save to SD Card Timing” and “Save to SD Card Parameter”.

Parameter Settings						
Name	Setting Value	Unit	Default	Minimum	Maximum	
New Directory Creating Timing	Automatically create a new dire...		Automatically create a ...	-	-	
New Directory Creating Parameter	1		1	1	31	
New File Creating Timing	Set maximum records of creat...		Overwrite existing file	-	-	
New File Creating Parameter	10	Count	100	1	10000	
Save to SD Card Timing	Count		Count	-	-	
Save to SD Card Parameter	5	Count	100	1	500	

Each trigger records one piece of data. A maximum of 10 records will be stored in one file. Triggered for 5 times indicates 5 pieces of data will be written in one file. Another 5 triggers generate another 5 pieces of data and the data will be written in the same file. That is to say, two files will be generated automatically after the 15<sup>th</sup> record is done.


6

4. Explanation of parameters

Parameter	Setting value	Description
<b>SID</b>	34	Fixed value
<b>Tb_num</b>	1	Specify which table number (1 to 4) from HWCONFIG to record.
<b>W_mode</b>	OFF	

5. Trigger to execute the instruction


After **Execute** is set to ON, the data is written to the buffer area and if the data is successfully written to the buffer area, **Done** is ON. Before performing a second trigger, you need to set **Execute** to OFF and then to start another execution. Every time **Execute** changes from OFF to ON, a new recording starts.



## 6. W\_mode:

- (1) If **W\_mode** is set to ON, the current data in the buffer area will be directly written to the file when **Execute** is set to ON, which can be used for applications that the log cannot be lost for important events or the log must be saved immediately for device abnormality occurs.
- (2) If **W\_mode** is set to OFF, the current data in the buffer area will be written into a file only after the conditions set in HWCONFIG are met after **Execute** changes to ON. When **Execute** is ON for the 3<sup>rd</sup> time, there will be 3 records of data in the buffer area and they have not yet been saved to a file. After that if **W\_mode** is set to ON before the 4<sup>th</sup> trigger is performed, the 4<sup>th</sup> record and previous 3 records (which is 4 records in total) will be directly saved to a file in the SD card after **Execute** is set to ON for the 4<sup>th</sup> time.

7. After the 15<sup>th</sup> trigger is performed manually in this example, two files are generated and all records are saved in .csv format. The first 10 records are saved in the first file and the last 5 records are kept in the second file. The log files can be transferred to the computer via FTP Client.



Remote site: /Delta/MyLog\_20220425

Directory structure:

- /
  - Delta
    - MyLog\_20220425
    - System Volume Information

Filename	Filesize	Filetype	Last modified	Permissions	Owner/G...
..					
Device_log_20220425_184031_0000.csv	406	Microso...	4/25/2022 6:40:00 P...	-rwxrwxrwx	0 0
Device_log_20220425_183434_0000.csv	775	Microso...	4/25/2022 6:39:00 P...	-rwxrwxrwx	0 0

8. The following picture shows the content of the first file which is opened. The first row shows titles. Follow the operations in step 3 above to set up parameters on the Table 1 page. The Date and Time in columns A and B are fixed. The data in registers are recorded in the rows starting from the second row.

	A	B	C	D	E
1	Date	Time	VFD frequency	Temperature	
2	2022/4/25	18:34:12	5723	20.97	
3	2022/4/25	18:34:16	3128	21	
4	2022/4/25	18:34:28	3631	20.97	
5	2022/4/25	18:34:30	5407	20.97	
6	2022/4/25	18:34:34	4754	20.97	
7	2022/4/25	18:39:24	2220	21.12	
8	2022/4/25	18:39:28	4114	21.16	
9	2022/4/25	18:39:31	5604	21.16	
10	2022/4/25	18:39:33	5061	21.16	
11	2022/4/25	18:39:42	372	21.09	
12					

## 6.24 Task Control Instructions

### 6.24.1 List of Task Control Instructions

The following table lists the Task Control instructions covered in this section.

API	Instruction code		Pulse instruction	Function
	16-bit	32-bit		
<u>2400</u>	TKON	–	✓	Enabling a cyclic task
<u>2401</u>	TKOFF	–	✓	Disabling a cyclic task

## 6.24.2 Explanation of Task Control Instructions


API	Instruction code			Operand								Function				
2400		TKON	P	<b>S</b>								Enabling a cyclic task				

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	“\$”	F
<b>S</b>	●	●						●	●		○	○	○			

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
<b>S</b>		●				●							

Pulse instruction	16-bit instruction	32-bit instruction
AS	AS	-

### Symbol



**S** : Task number

### Explanation

1. This instruction enables the cyclic task specified by **S**.
2. When the PLC runs, the execution of the cyclic tasks depends on the setting of the cyclic tasks in ISPSOft.
3. The operand **S** must be between 0-31.
4. Refer to the ISPSOft User Manual for more information about creating and enabling tasks.

### Example


When the PLC runs, cyclic task (0) is enabled. When the TKON instruction in cyclic task (0) executes, it enables cyclic task (1), and Y0.0 is ON.

You create cyclic tasks in ISPSOft, and you define their default enabled/disabled state in ISPSOft. Cyclic task (0) is enabled when the PLC runs, and cyclic task (1) is not enabled when the PLC runs.

Cyclic task (1) is enabled by the TKON instruction in cyclic task (0).



Cyclic task (1) is executed.



**Additional remarks**

Refer to the ISPSOft User Manual for more information on tasks.


API	Instruction code			Operand							Function						
2401		TKOFF	P	<b>S</b>							Disabling a cyclic task						

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
<b>S</b>	●	●						●	●		○	○	○			

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
<b>S</b>		●				●							

Pulse instruction	16-bit instruction	32-bit instruction
AS	AS	-

**Symbol**



**S** : Task number

**Explanation**

1. This instruction disables the cyclic task specified by **S**.
2. When the PLC runs, the execution of the cyclic tasks depends on the setting of the cyclic tasks in ISPSOft.
3. The operand **S** must be between 0-31.
4. Refer to the ISPSOft User Manual for more information about creating and enabling tasks.


**Example**

When the PLC runs, cyclic task (0) and cyclic task (1) are enabled. When the TKOFF instruction in cyclic task (0) executes, it disables cyclic task (1), and Y0.0 is OFF.

You create cyclic tasks in ISPSOft and you define their default enabled/disabled state in ISPSOft. Cyclic task (0) and cyclic task (1) are enabled when the PLC runs, and cyclic task (1) is disabled when the TKOFF instruction in cyclic task (0) executes. Cyclic task (1) is disabled by the execution of the TKOFF instruction in cyclic task (0).



Cyclic task (1) is not executed.



**Additional remarks**

Refer to the ISPSOft User Manual for more information on tasks.

## 6.25 SFC Instructions

### 6.25.1 List of SFC Instructions

The following table lists the SFC (Sequential Function chart) instructions covered in this section.

API	Instruction code		Pulse instruction	Function
	16-bit	32-bit		
<b><u>2500</u></b>	SFCRUN	–	–	SFC Run
<b><u>2501</u></b>	SFCPSE	–	–	SFC Pause
<b><u>2502</u></b>	SFCSTP	–	–	SFC Stop

### 6.25.2 Explanation of Task Control Instructions


API	Instruction code			Operand								Function				
2500		SFCRUN		<b>S<sub>1</sub>, S<sub>2</sub>, S<sub>3</sub></b>								SFC Run				

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	“\$”	F
<b>S<sub>1</sub></b>																
<b>S<sub>2</sub></b>								●					○	○		
<b>S<sub>3</sub></b>																

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
<b>S<sub>1</sub></b>													
<b>S<sub>2</sub></b>		●				●							
<b>S<sub>3</sub></b>													

Pulse instruction	16-bit instruction	32-bit instruction
-	AS	-

**Symbol**



- S<sub>1</sub>** : Name of the SFC POU
- S<sub>2</sub>** : Function code
- S<sub>3</sub>** : Device address

**Explanation**

1. This instruction runs the SFC (Sequential Function Chart) program specified by **S<sub>1</sub>** according to the function code in **S<sub>2</sub>**.
2. The instruction runs the SFC POU (Program Organization Unit) specified by **S<sub>1</sub>** only when the PLC is scanning the SFC POU.
3. The operands are described as follows.
  - **S<sub>1</sub>** defines the name of the SFC POU.
  - When the designated SFC POU of **S<sub>1</sub>** executes, the instruction clears the parameters (such as SFC/STEP/ACTION/TRANSITION) for the SFC program when **S<sub>2</sub>**=0 or 1, and the SFC execution starts according to the value specified in **S<sub>2</sub>**.
  - IF **S<sub>2</sub>**=0, the system executes the SFC POU from the initial step.
  - IF **S<sub>2</sub>**=1, the system executes the SFC POU from the designated step in **S<sub>3</sub>**.

- If  $S_2=2$ , the instruction does NOT clear the status and the parameters (such as SFC/STEP/ACTION/TRANSITION) for the SFC and the system starts executing from where it paused.
  - $S_3$  designates where to start (which step) in the SFC program in  $S_1$ .
4. The range of  $S_2$  is between 0–2. If it is out of range, it is evaluated as 0.
  5. When the state of the SFC POU is RUN, executing this instruction is invalid.


### Example

Set up one LD (ladder) POU and specify its POU name as “Main”, and then set up two SFC POUs with the names of “TestSFC1” and “TestSFC2”.

1. When the PLC executes the Main program (RUN), TestSFC1 and TestSFC2 execute the SFCSTP instruction (API 2502), and the two SFC POUs stop executing.
2. When M0 switches from OFF to ON, TestSFC1/ TestSFC2 POU execute the SFCRUN\* instruction. See below for the contents of the TestSFC1 and TestSFC2 for execution details. When  $S_2=0$ , the SFC status and parameters are cleared and begin to execute from STEP 1. When  $S_2=1$ , the SFC status and parameters are cleared and begin to execute from the designated STEP in  $S_3$ .
3. When M1 switches from OFF to ON, TestSFC1 POU pauses. When  $S_2=1$ , all the SFC executing actions and outputs are cleared, and the system runs the final scan.
4. When M2 switches from OFF to ON, TestSFC1 POU executes. When  $S_2=1$ , the SFT status and parameters are cleared, and the system begins to execute from STEP 2.
5. When M3 switches from OFF to ON, TestSFC2 POU pauses. When  $S_2=0$ , all the SFC executing actions and outputs are kept, and the system does not run the final scan.
6. When M4 switches from OFF to ON, TestSFC1 POU executes. When  $S_2=2$ , the SFC status and parameters are and the SFC begins to execute from where it paused.


\*SFCRUN activates the SFC POU at the next scan.

Main POU




6

TestSFC1 POU



TestSFC2 POU



**Additional remarks**

Refer to the ISPSOft User Manual for more information on Sequential Function Charts.


API	Instruction code			Operand								Function			
2501		SFCPSE		<b>S<sub>1</sub> · S<sub>2</sub></b>								SFC Pause			

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
<b>S<sub>1</sub></b>																
<b>S<sub>2</sub></b>								●					○	○		

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
<b>S<sub>1</sub></b>													
<b>S<sub>2</sub></b>		●				●							

Pulse instruction	16-bit instruction	32-bit instruction
-	AS	-

**Symbol**



**S<sub>1</sub>** : Name of the SFC POU

**S<sub>2</sub>** : Function code

**Explanation**

1. This instruction pauses the SFC POU specified by **S<sub>1</sub>** according to the function code in **S<sub>2</sub>**.
2. The instruction can pause the SFC POU specified by **S<sub>1</sub>** only when the PLC is scanning the SFC POU.
3. When paused, the SFC status and parameters (such as SFC/STEP/ACTION/TRANSITION) are stored.
4. The operands are described as follows.
  - **S<sub>1</sub>** defines the name of the SFC POU.
  - When **S<sub>2</sub>**=0, the instruction preserves all the executing actions of the SFC and the outputs, and the system does not run the final scan.
  - When **S<sub>2</sub>**=1, the instruction clears all the executing actions and the outputs of the SFC POU, and the system runs the final scan..
5. The range of **S<sub>2</sub>** is 0–1. When it is out of range, it is processed as 0.
6. When the state of the SFC POU is PAUSE/STOP, executing this instruction is invalid.

**Example**

Refer to the SFCRUN (API 2500) programming example for more information.

**Additional remarks**

Refer to the ISPSOft User Manual for more information on SFCs.


API	Instruction code			Operand							Function			
2502		SFCSTP		<b>S</b>							SFC Stop			

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
<b>S</b>																

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
<b>S<sub>1</sub></b>													

Pulse instruction	16-bit instruction	32-bit instruction
-	AS	-

**Symbol**



**S** : Name of the SFC POU

**Explanation**

1. This instruction stops the SFC POU specified by **S**.
2. This instruction stops the SFC POU specified by **S<sub>1</sub>** only when the PLC is scanning the SFC POU.
3. When stopping, the instruction clears the SFC status and parameters, and the system runs the final scan.
4. When the state of the SFC POU is STOP, executing this instruction is invalid.

**Example**

Refer to the SFCRUN (API 2500) programming example for more information.

**Additional remarks**

Refer to the ISPSOft User Manual for more information on SFCs.

## 6.26 High-speed Output Instructions

### 6.26.1 List of High-speed Output Instructions

The following table lists the High-speed Output instructions covered in this section.

API	Instruction code		Pulse instruction	Function	Even-numbered axis <sup>*1</sup>	Odd-numbered axis <sup>*2</sup>
	16-bit	32-bit				
<b><u>2700</u></b>	–	DPLSY	–	High-speed pulse output (without ramp-up/down process)	V	V
<b><u>2701</u></b>	–	DPLSR	–	High-speed pulse output (with ramp-up/down process)	V	V
<b><u>2702</u></b>	PWM	DPWM	–	Pulse width modulation	V	V
<b><u>2703</u></b>	JOG	DJOG	–	JOG output	V	V
<b><u>2704</u></b>	–	DZRN	–	Zero return	V	–
<b><u>2705</u></b>	–	DPLSV	–	Adjustable pulse output	V	V
<b><u>2706</u></b>	–	DDRVI	–	Relative position control	V	V
<b><u>2707</u></b>	–	DDRVA	–	Absolute position control	V	V
<b><u>2708</u></b>	CSFO	–	–	Catch speed and proportional output	V	–
<b><u>2709</u></b>	–	DDRVM	–	Mark alignment positioning	V	–
<b><u>2710</u></b>	–	DPPMR	–	2-Axis relative-coordinate point-to-point synchronized motion	V	–
<b><u>2711</u></b>	–	DPPMA	–	2-Axis absolute-coordinate point-to-point synchronized motion	V	–
<b><u>2712</u></b>	–	DCICR	–	2-Axis relative-position clockwise arc interpolation	V	–
<b><u>2713</u></b>	–	DCICA	–	2-Axis absolute-position clockwise arc interpolation	V	–
<b><u>2714</u></b>	–	DCICCR	–	2-Axis relative-position counterclockwise arc interpolation	V	–
<b><u>2715</u></b>	–	DCICCA	–	2-Axis absolute-position counterclockwise arc interpolation	V	–
<b><u>2716</u></b>	–	DCCMR	–	Relative-position circle drawing	V	–
<b><u>2717</u></b>	–	DCCMA	–	Absolute-position circle drawing	V	–
<b><u>2718</u></b>	TPO	–	–	Position planning table controls the output	V	–
<b><u>2719</u></b>	–	DTPWS	✓	Setting single-axis output parameters in the position planning table	V	–
<b><u>2720</u></b>	–	DTPWL	✓	Setting linear interpolation parameters in the position planning table	V	–

API	Instruction code		Pulse instruction	Function	Even-numbered axis <sup>*1</sup>	Odd-numbered axis <sup>*2</sup>
	16-bit	32-bit				
<u>2721</u>	–	DTPWC	✓	Setting arc interpolation parameters in the position planning table	V	–
<u>2723</u>	–	DPPGB	–	Point to point go back and forth	V	–
<u>2724</u>	–	DZRN2	–	Zero return 2 (directional output can be defined)	V	V

## NOTE:

\*1: Even-numbered axes include Y0.0, Y0.2, Y0.4, Y0.6, Y0.8, and Y0.10.

\*2: Odd-numbered axes include Y0.1, Y0.3, Y0.5, Y0.7, Y0.9, and Y0.11.

### 6.26.2 Explanation of High-speed Output Instructions


API	Instruction			Operand								Description				
2700	D	PLSY		<b>S<sub>1</sub>, S<sub>2</sub>, D</b>								High-speed pulse output (without ramp-up/down process)				

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
<b>S<sub>1</sub></b>							●	●	●		○		○	○		
<b>S<sub>2</sub></b>							●	●	●		○		○	○		
<b>D</b>		○														

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
<b>S<sub>1</sub></b>			●				●						
<b>S<sub>2</sub></b>			●				●						
<b>D</b>	●												

Pulse Instruction	16-bit instruction	32-bit instruction
—	—	AS

**Symbol**



- S<sub>1</sub>** : Pulse output frequency
- S<sub>2</sub>** : Number of pulses to output
- D** : Pulse output device

**Explanation**

- This instruction specifies the pulse output (**S<sub>1</sub>**, **S<sub>2</sub>**) for the device specified in **D** with no ramp up or ramp down when the frequency changes. **S<sub>1</sub>** specifies the pulse output frequency range: for line driver output models, the range is between 0–4MHz; for open collector output models, the range is between 0 Hz–200 kHz. The unit of the output frequency is 1 Hz. The error rate for 200 kHz is about 0.02% and for 100 kHz it is about 0.01%. The error rate decreases with decreasing frequency. For example, if the output frequency setting is 199990 Hz, the actual output is 199960 Hz. If the output frequency setting is 99999 Hz, the actual output is 99990 Hz. If the output frequency is out of the valid range, the PLC automatically processes it as the maximum or minimum pulse output frequency.
- You can change the output frequency specified by **S<sub>1</sub>** during the execution of the instruction without using the ramp up/down process. The time to change the frequency is when the PLC is scanning the instruction and the instruction has completed output of a full pulse.
- S<sub>2</sub>** specified the number of output pulses. The range is between 0–2,147,483,647. When you set the number of output pulses to 0, then the number of pulses is not restricted and pulses are output constantly until the instruction is disabled. When the number of output pulses is set to less than 0, no pulses are output.
- After the instruction starts to output pulses, the number of output pulses specified by **S<sub>2</sub>** cannot be changed.

5. **D** only allows Y0.0–Y0.11 as the output devices. After the instruction is executed, its output function becomes the high-speed output, and the basic instruction output point control is invalid. It is suggested that you do not use the general output function after using the high-speed output function in the program.
6. The ratio of Duty-OFF Time and Duty-ON Time for the pulse output is 1:1.
7. There is no limit to how many times you can use the instruction a program. But only one output instruction that uses the same output point can be executed in the same scan cycle. When several high-speed pulse output instructions start the same output point in the program, the PLC first performs the output based on the instruction that is executed first.
8. After every high-speed output instruction for every output point is executed, other instruction occupying the same output point can not start until the high-speed output instruction in execution is disabled.
9. When the high-speed output instruction is executed in an interrupt program or is not in the main process, it is suggested that you use the instruction with the auto-reset function when output is completed and the PLC updates the output state in the END instruction.
10. After the stop flag is set, the PLC stops the output and clears the busy flag only after executing the start instruction a second time and outputting a full pulse. The PLC continues to output pulses when the stop flag is reset and the previously stopped pulse output is not finished. You set and reset the stop flag is set in the program.
11. The high-speed output points and corresponding SM/SR are listed in the following table.

Output point number	Attribute <sup>#2</sup>	Y0.0	Y0.1	Y0.2	Y0.3	Y0.4	Y0.5
Busy flag	R	SM460	SM472	SM480	SM492	SM500	SM512
Completion flag <sup>#3</sup>	R/W	SM461	SM473	SM481	SM493	SM501	SM513
Stop flag	R/W	SM463	SM474	SM483	SM494	SM503	SM514
Output completion auto-reset <sup>#4</sup>	R/W	SM470	SM475	SM490	SM495	SM510	SM515
Present output position <sup>#1</sup> (32-bit)	R/W	SR460	SR474	SR480	SR494	SR500	SR514
		SR461	SR475	SR481	SR495	SR501	SR515
Output point number	Attribute <sup>#2</sup>	Y0.6	Y0.7	Y0.8	Y0.9	Y0.10	Y0.11
Busy flag	R	SM520	SM532	SM540	SM552	SM560	SM572
Completion flag <sup>#3</sup>	R/W	SM521	SM533	SM541	SM553	SM561	SM573
Stop flag	R/W	SM523	SM534	SM543	SM554	SM563	SM574

Output point number	Attribute <sup>#2</sup>	Y0.0	Y0.1	Y0.2	Y0.3	Y0.4	Y0.5
Output completion auto-reset <sup>#4</sup>	R/W	SM530	SM535	SM550	SM555	SM570	SM575
Present output position <sup>#1</sup> (32-bit)	R/W	SR520	SR534	SR540	SR554	SR560	SR574
		SR521	SR535	SR541	SR555	SR561	SR575

Notes:

#1: All present output positions are latched when power is off.


#2: R means Read-only registers, and the data in the registers cannot be modified. R/W means the data in the registers can be read and written.

#3: It is suggested that you clear the completion flag. If the completion flag is not cleared, it is cleared automatically when the high-speed output instruction is executed the next time.

#4: You set the output completion auto-reset flag. The PLC clears the flag automatically after the output is completed.

**Example 1**


1. When X0.0 is ON, Y0.0 outputs 200 pulses at 1kHz. SM461 is ON when the pulse output is completed and then Y0.12 is ON.
2. When X0.0 is OFF, Y0.0 stops the output. It restarts the pulse output when X0.0 switches to ON again.




**Example 2**



External interrupt input X0.0



External interrupt input X0.1



**Explanation**

1. Y0.0 outputs 1000 pulses when X0.0 receives one external interrupt signal. Y0.2 outputs 1000 pulses when X0.1 receives one external interrupt signal.
2. When the external interrupt input X triggers the pulse output from Y, the interval time between the Y pulse output completion and the next external interrupt input X trigger must be one or more PLC scan cycles.

**Example 3 (ST program)**

```
0001 IF M0 THEN
0002     DPLSY(1000,1000,Y0.0);
0003     M1 := TRUE;
0004 ELSIF M1 AND SM461 THEN
0005     SM470 := TRUE;
0006     M1 := FALSE;
0007 END_IF;
```

**Explanation**

1. When M0 is ON, Y0.0 outputs 1000 pulses at 1kHz. When M1 is ON, it indicates Y0.0 is used for high-speed pulse output.
2. When the pulse output is completed, SM461 is ON. And if M1 is also ON, it triggers SM470 (output completion auto-reset for Y0.0) to be ON and Y0.0 is free and ready to be used again.
3. When M0 switches from OFF to ON, the pulse output is restarted.
4. When there are more than two high-speed output instructions in a program, do not use the variable name, M1, repeatedly.
5. It is suggested not to use ST language in a program if there is any chance the outputting needed to be stopped.


API	Instruction			Operand								Description				
2701	D	PLSR		<b>S<sub>1</sub>, S<sub>2</sub>, S<sub>3</sub>, D</b>								High-speed pulse output (with ramp-up/down process)				

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	“\$”	F
<b>S<sub>1</sub></b>							●	●	●		○		○	○		
<b>S<sub>2</sub></b>							●	●	●		○		○	○		
<b>S<sub>3</sub></b>							●	●	●		○		○	○		
<b>D</b>		○														

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
<b>S<sub>1</sub></b>			●				●						
<b>S<sub>2</sub></b>			●				●						
<b>S<sub>3</sub></b>			●				●						
<b>D</b>	●												

Pulse Instruction	16-bit instruction	32-bit instruction
—	—	AS

**Symbol**




- S<sub>1</sub>** : Target output frequency
- S<sub>2</sub>** : Number of output pulses
- S<sub>3</sub>** : Ramp-up/ down time
- D** : Pulse output device

**Explanation**

1. This instruction specifies the pulse output (**S<sub>1</sub>**, **S<sub>2</sub>**) for the device specified in **D** with ramp up or ramp down in the frequency change. **S<sub>1</sub>** specifies the pulse output frequency as 4 MHz for line driver output models and the pulse output frequency between 0 Hz–200 kHz for the open collector output models. The unit of the output frequency is 1 Hz. The tolerable error rate for 200 kHz is about 0.02% and for 100 kHz it is about 0.01%. The error rate decreases with decreasing frequency. For example, if the output frequency setting is 199990 Hz, the actual output is 199960 Hz. If the output frequency setting is 99999 Hz, the actual output is 99990 Hz. If the output frequency is out of the valid range, the PLC automatically processes it as the maximum or minimum pulse output frequency.
2. After the instruction is executed, you can change the target output frequency specified by **S<sub>1</sub>** and the PLC performs the ramp up or ramp down process according to the ramp up or ramp down time setting **S<sub>3</sub>**. The time to change the frequency is when the PLC is scanning the instruction and the instruction has completed output of a full pulse.
3. **S<sub>2</sub>** is the number of output pulses. The range is between 0–2,147,483,647. When you set the number of pulses to 0, then the number of pulses is not restricted and pulses are output continuously until the instruction is disabled.

4. After the instruction starts to output pulses, the number of output pulses that **S<sub>2</sub>** specifies cannot be changed.
5. **S<sub>3</sub>** sets the ramp-up or ramp down time with the unit of 1ms. The value is effective when the instruction is executed for the first time. If the target frequency specified by **S<sub>1</sub>** is modified in the ramp-up process, the ramp up or ramp down time is reloaded for execution. But if the target frequency is modified when the output enters the ramp-down process, the instruction ignores the change.
6. **D** only allows Y0.0–Y0.11 as the pulse output devices. After the instruction is executed, its output function becomes the high-speed output, and the general instruction output point control is invalid. It is suggested that you do not use the general output function after using the high-speed output function in the program.
7. The target output frequency **S<sub>1</sub>**, number of output pulses **S<sub>2</sub>** and ramp up/down time **S<sub>3</sub>** are illustrated in the following graphic.




8. The ratio of Duty-OFF Time and Duty-ON Time for the pulse output is 1:1.
9. There is no limit to how many times you can use the instruction a program. But only one output instruction that uses the same output point can be executed in the same scan cycle. When several high-speed pulse output instructions start the same output point in the program, the PLC first performs the output based on the instruction that is executed first.
10. After the high-speed output instruction for one output point is enabled, other instructions that occupy the same output point can not start until the high-speed output instruction in execution is disabled.
11. When the high-speed output instruction is executed in an interrupt program or is not in the main program, it is suggested that you use the instruction with the auto-reset function when the output is completed and the PLC updates the output state in the END instruction.
12. After the stop flag is set, PLC performs the ramp-down stop; or it immediately stops the output only after the start instruction is executed a second time and outputs a full pulse.
13. Refer to the PLSY instruction (API 2700) for an explanation of the high-speed output points and corresponding SM/SR.
14. Refer to Example 3 from the PLSY instruction (API 2700) for programming in ST language.

15. When the target output frequency is reached, you can change the set target output frequency. The frequencies for ramp up and ramp down are already set, if you change the set target output frequency during the instruction execution, the frequency goes either ramping up or ramping down. If more than one target output frequencies are set, it is suggested to set the last new target frequency the same as the original target frequency to avoid abrupt change when it needs to come to a stop.


See the example below. The blue line indicates the original target frequency and the red line indicates new target frequency.

- Situation A: ramping up




- ① Number of output pulses
- ② Ramp up time
- ③ The first target frequency
- ④ Position to change to the new target frequency
- ⑤ New target frequency

- Situation B: ramping down



- ① Number of output pulses
- ② Ramp up time
- ③ The first target frequency
- ④ Position to change to the new target frequency
- ⑤ New target frequency
- ⑥ Ramp down time

- Suggested design: it is suggested to set the last new target frequency the same as the original target frequency to avoid abrupt change when it needs to come to a stop.



- ① Number of output pulses
- ② Ramp up time
- ③ The first target frequency
- ④ Position to change to the first new target frequency
- ⑤ Position to change to the second new target frequency
- ⑥ Ramp down time
- ⑦ Position to change to the third new target frequency
- ⑧ Position to change to the original set target frequency and then start ramping down to stop.


API	Instruction			Operand								Description				
2702	D	PWM		S <sub>1</sub> , S <sub>2</sub> , D								Pulse width modulation				

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
S <sub>1</sub>	●	●			●	●	●	●	●		○		○	○		
S <sub>2</sub>	●	●			●	●	●	●	●		○		○	○		
D		○														

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
S <sub>1</sub>		●	●			●	●						
S <sub>2</sub>		●	●			●	●						
D	●												

Pulse Instruction	16-bit instruction	32-bit instruction
—	AS	AS

Symbol



S<sub>1</sub> : Pulse output width

S<sub>2</sub> : Pulse output cycle


D : Pulse output device

Explanation

- This instruction specifies the pulse output width. The 16-bit instruction uses 100 us as the output unit, while the 32-bit instruction uses 1 us as the output unit.

Output instruction	PWM	DPWM
Range of pulse output width S <sub>1</sub>	0–30000	0–60000
Range of pulse output cycle S <sub>2</sub>	0–30000	0–60000

- S<sub>1</sub> (pulse output width--Duty ON) is defined as t, S<sub>2</sub> (pulse output cycle time--Cycle time) is T as shown below. It is recommended that S<sub>1</sub> ≤ S<sub>2</sub>.



3. **D** only allows Y0.0–Y0.11 as the pulse output device.
4. There is no limit to how many times you can use the instruction a program. But only one output instruction that uses the same output point can be executed in the same scan cycle. When several high-speed pulse output instructions start the same output point in the program, the PLC first performs the output based on the instruction that is executed first.
5. If  $S_1 \leq 0$  or  $S_2 \leq 0$ , it is processed as 0 (the pulse output is OFF). If  $S_1 > S_2$ , it is processed as  $S_1 = S_2$ . When  $S_1 = S_2$  and  $S_2$  is not 0, the pulse output is always ON.
6. You can modify the pulse output width  $S_1$  and pulse output cycle  $S_2$  when the PWM instruction is executed.
7. The relevant special registers SR are listed in the following table.


Output point number	Attribute	Y0.0	Y0.1	Y0.2	Y0.3	Y0.4	Y0.5
Present output position <sup>#1</sup> (32-bit)	R/W	SR460	SR474	SR480	SR494	SR500	SR514
		SR461	SR475	SR481	SR495	SR501	SR515
Output point number	Attribute	Y0.6	Y0.7	Y0.8	Y0.9	Y0.10	Y0.11
Present output position <sup>#1</sup> (32-bit)	R/W	SR520	SR534	SR540	SR554	SR560	SR574
		SR521	SR535	SR541	SR555	SR561	SR575

#1: All present output positions are latched when power is off.

8. Refer to Example 3 from the DJOG instruction (API 2703) for programming in ST language.

**Example**

When X0.0 is ON, Y0.1 outputs the following pulses. When X0.0 switches to OFF, Y0.1 output changes to OFF.



API	Instruction			Operand								Description				
2703	D	JOG		<b>S<sub>1</sub>, S<sub>2</sub>, S<sub>3</sub>, D<sub>1</sub>, D<sub>2</sub></b>								JOG output				

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
<b>S<sub>1</sub></b>					●	●	●	●	●		○		○	○		
<b>S<sub>2</sub></b>					●	●	●	●	●		○		○	○		
<b>S<sub>3</sub></b>					●	●	●	●	●		○		○	○		
<b>D<sub>1</sub></b>		○														
<b>D<sub>2</sub></b>		○	○													

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
<b>S<sub>1</sub></b>		●	●			●	●						
<b>S<sub>2</sub></b>		●	●			●	●						
<b>S<sub>3</sub></b>		●	●			●	●						
<b>D<sub>1</sub></b>	●												
<b>D<sub>2</sub></b>	●												

Pulse Instruction	16-bit instruction	32-bit instruction
—	AS	AS

**Symbol**

JOG	
En	
S1	D1
S2	D2
S3	

DJOG	
En	
S1	D1
S2	D2
S3	

- S<sub>1</sub>** : Ramp-up time
- S<sub>2</sub>** : Target output frequency
- S<sub>3</sub>** : Ramp-down time
- D<sub>1</sub>** : Pulse output device
- D<sub>2</sub>** : Auxiliary output device

**Explanation**

- This instruction specifies the JOG output (**S<sub>1</sub>**, **S<sub>2</sub>**, **S<sub>3</sub>**) for the devices specified in **D<sub>1</sub>** and **D<sub>2</sub>**. **S<sub>1</sub>** is the ramp-up time with the unit of 10 ms. For Example, the value 10 means the ramp-up time is 100 ms. After the instruction is executed, the output frequency can be divided by ten, and it speeds up once every 10ms. It reaches the JOG target frequency specified by **S<sub>2</sub>** at the ramp-up time **S<sub>1</sub>**.
- When the instruction is disabled, its output frequency ramps down once every 10ms based on the ramp-down time in **S<sub>3</sub>**. The output does not stop until reaching the ramp-down time. If you set the ramp-down time to 0, the output stops immediately.

3. The range of the ramp-up time  $S_1$  and the ramp-down time  $S_3$  is between 0–3000 (0–30 seconds). If the setting value is out of range, the PLC processes it as the minimum or maximum output value. The ramp-up time and ramp-down time are affected by the scan time. If you require accurate ramp-up or ramp-down time, it is recommended that you use an output instruction with specified ramp up or ramp down time such as the DDRVI instruction (API 2706).
4. The range of the target output frequency  $S_2$  is between -200 kHz to 200 kHz. If the setting value is out of the range, the PLC processes it as the minimum or maximum output value. A positive number for the output frequency indicates forward output. A negative number for the output frequency indicates reverse output.
5.  $D_1$  allows only Y0.0–Y0.11 for the output point. For the auxiliary output point specified by  $D_2$ , refer to the output points in the following table. If you choose other output points or the M device, the value in SR indicating the output mode is invalid and the Pulse+direction mode is valid by default.  $D_2$  is a direction output point.

$D_1$  selects the even output point number.

Output point for $D_1$	Y0.0	Y0.2	Y0.4	Y0.6	Y0.8	Y0.10
Direction output point for $D_2$	Y0.1	Y0.3	Y0.5	Y0.7	Y0.9	Y0.11
Busy flag	SM460	SM480	SM500	SM520	SM540	SM560
Output mode	SR462	SR482	SR502	SR522	SR542	SR562
Present output position	SR460	SR480	SR500	SR520	SR540	SR560
	SR461	SR481	SR501	SR521	SR541	SR561
Backlash compensation	SR478	SR498	SR518	SR538	SR558	SR578

$D_1$  selects the odd output point number.

Output point for $D_1$	Y0.1	Y0.3	Y0.5	Y0.7	Y0.9	Y0.11
Direction output point for $D_2$	Y1.0 or above or any M device (BOOL)					
Busy flag	SM472	SM492	SM512	SM532	SM552	SM572
Present output position	SR474	SR494	SR514	SR534	SR554	SR574
	SR475	SR495	SR515	SR535	SR555	SR575
Backlash compensation	SR479	SR499	SR519	SR539	SR559	SR579

- When the value is 0 in SR462, SR482, SR502, SR522, SR542, and SR562, it indicates the Pulse+direction output mode. When the value is 1 in SR462, SR482, SR502, SR522, SR542, and SR562, it indicates the A/B phase output mode.


Note: you can select the output mode only when **D<sub>1</sub>** uses an even output point and **D<sub>2</sub>** uses a recommended direction output point.

- When the direction outputs are not using the default outputs to output, you can refer to the table below for setting up the outputting time that pulse outputting goes first before direction outputting does. So that you can be sure the outputting only happens when switching to the direction outputs. The unit for SR is millisecond and the range is 0-20 ms. Default is 0, indicating inactive.

Output point for <b>D<sub>1</sub></b>	Y0.0	Y0.1	Y0.2	Y0.3	Y0.4	Y0.5
SR number	SR640	SR641	SR642	SR643	SR644	SR645
Output point for <b>D<sub>1</sub></b>	Y0.6	Y0.7	Y0.8	Y0.9	Y0.10	Y0.11
SR number	SR646	SR647	SR648	SR649	SR650	SR651


Note: the time source here is from PLC scan time. (available for firmware version 1.02.20 or later)

- When the output begins, the Busy flag SM is ON. When the output is completed, the Busy flag is automatically reset to OFF and the Completion flag is not ON.
- The following graph shows the output timing diagram. For the Busy flag in the following graph, refer to the Busy flag axis.



- You can modify the target output frequency during instruction execution but you can NOT change the ramp-up or ramp-down time. When the new target frequency is greater than the previous one, the instruction uses the ramp-up slope. When the new frequency is less than the previous one, the instruction uses the ramp-down slope.
- The instruction sets the ramp-up/down slope through conversion of the set time and target frequency when the instruction is executed. The slope does not change with the changing target frequency in the output process. For example, the original target output frequency is 1 kHz and then it is modified to 2 kHz. The actual ramp-down time

is different from the original time. The dotted line is the ramp-up and ramp down timing diagram after the target frequency is modified.



12. If there is any change on the frequency during ramp up or ramp down, the change can only be carried out after the original frequency completes outputting. For example, if the new target frequency is 100 Hz and the ramp-up timing is set at 100 (1 second), after the original frequency completes outputting, the new target frequency 100 Hz will be outputted next. (Even though the target frequency changes every 10 ms but if the pulse does NOT complete outputting, the change can NOT be applied.)

#### Example (ST program):

It is suggested to use ladder diagrams as the programming language in this instruction. If you need to use structured texts, you need to use the output completion auto-reset flag as well for the PLC to know the output point is free and ready to be used again when the output completes. Taking Y0.0 as the output point, the program should be written as below. See the following example.

```

0001 IF M0 THEN
0002     DJOG (1000, 5000, 100, Y0.0, Y0.1);
0003     M1 := TRUE;
0004 ELSIF (NOT M0) AND M1 THEN
0005     SM470 := TRUE;
0006     M1 := FALSE;
0007 END IF;

```


API	Instruction			Operand								Description				
2704	D	ZRN		<b>S<sub>1</sub>, S<sub>2</sub>, S<sub>3</sub>, S<sub>4</sub>, D</b>								Zero return				

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
<b>S<sub>1</sub></b>							●	●	●		○		○	○		
<b>S<sub>2</sub></b>							●	●	●		○		○	○		
<b>S<sub>3</sub></b>							●	●	●		○		○	○		
<b>S<sub>4</sub></b>	○															
<b>D</b>		○														

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
<b>S<sub>1</sub></b>			●				●						
<b>S<sub>2</sub></b>			●				●						
<b>S<sub>3</sub></b>			●				●						
<b>S<sub>4</sub></b>	●												
<b>D</b>	●												

Pulse Instruction	16-bit instruction	32-bit instruction
—	—	AS

Symbol



- S<sub>1</sub>** : Target frequency for zero return
- S<sub>2</sub>** : JOG frequency for DOG
- S<sub>3</sub>** : Zero return mode
- S<sub>4</sub>** : Input device for DOG
- D** : Pulse output device

Explanation


- This instruction causes the machine to return to the zero point. The range of the target frequency for zero return **S<sub>1</sub>** is between 1 Hz–200 kHz. The JOG frequency **S<sub>2</sub>** should be less than the target frequency **S<sub>1</sub>**. The JOG frequency **S<sub>2</sub>** is the start frequency. If **S<sub>1</sub>** is less than **S<sub>2</sub>**, **S<sub>1</sub>** is automatically revised processed as equal to **S<sub>2</sub>**.
- The input point for **S<sub>4</sub>** and output point for **D** must match. Do not change them during instruction execution. The input point for **S<sub>4</sub>** is suggested to use the 16 high-speed input points X0.0–X0.15. They will not be affected by PLC instruction scan time. If you use X1.0 successive input points or M devices (firmware V1.02.10 or above is required), they will be affected by the PLC instruction scan time. Refer to the following table for the selection of **D** output point and direction output point. If **D** is not the preset Pulse+direction output (default: 0), change the mode to A/B phase output by setting SR to 1.

Axis number	Axis 1	Axis 2	Axis 3	Axis 4	Axis 5	Axis 6
Input point for <b>S<sub>4</sub></b>	Can be any one of the input points X0.0–X0.15. But the same input point cannot be selected for different axis output. If the DOG point shakes or the switch bounces, set the input point filter time in HWCONFIG.					
Output point for <b>D</b>	Y0.0	Y0.2	Y0.4	Y0.6	Y0.8	Y0.10
Direction output point	Y0.1	Y0.3	Y0.5	Y0.7	Y0.9	Y0.11
Output mode	SR462	SR482	SR502	SR522	SR542	SR562
Busy flag	SM460	SM480	SM500	SM520	SM540	SM560
Completion flag	SM461	SM481	SM501	SM521	SM541	SM561
Present output position	SR460	SR480	SR500	SR520	SR540	SR560
	SR461	SR481	SR501	SR521	SR541	SR561

3. Use **S<sub>3</sub>** to select the zero return mode. The function code is set by the two high and low 16-bit parameters. See the following table for details.

<b>S<sub>3</sub>: select the zero return mode</b>				
High 16-bit	Low 16-bit			
b31~b16	b15~b6	b5	b4	b3~b0
Number of pulses for motion	reserved	Direction setting*1	Setting DOG signal	Mode setting 0~15 (F)
Number of Z phases		0: in the negative direction 1: in the positive direction	0: contact A 1: contact B	

Note 1: This function is only available for firmware version 1.04.30 or later. See the diagram below for mode setting.



4. Use **S<sub>3</sub>** to select the zero return mode. The function code is set by the two high and low 16-bit parameters. See the following table for details.

Functions	Code		Explanation
	High 16-bit	Low 16-bit	
Leaves the zero point in the negative direction and then stops (Mode 0)	0	0	When the instruction is executed, the search for the zero point is in the negative direction with the target frequency. When the zero point is ON (the zero point signal changes from OFF to ON), the frequency is decreased to the JOG speed and the motion in the negative direction continues, and does not stop until the zero point signal changes from ON to OFF.
Leaves the zero point in the positive direction and then stops (Mode 1)	0	1	When the instruction is executed, the search for the zero point is in the negative direction with the target frequency. When the zero point is ON (the zero point signal changes from OFF to ON), the frequency decreases to 0 immediately, and then the motion is in the positive direction at the JOG speed, and does not stop until the zero point signal changes from ON to OFF.
Mode 0 Moves again after returning to the zero point	Number of pulses for motion	2	Returning to the zero point is the same as that for the low 16-bit code. After the zero point is ON, the motion continues according to the number of specified pulses. When the high 16-bit code is a positive number, the search is in the positive direction. A negative value means that the search is in the negative direction.
Mode 0 Searches Z phase after returning to the zero point (Z phase input point is set in HWCONFIG )	Number of Z phases	3	Returning to the zero point is the same as that for the low 16-bit code. After returning to the zero point, the motion continues according to the number of Z phases. When the high 16-bit code is a positive number, the search is in the positive direction. A negative value indicates that the search is in the negative direction. Suppose you specified that the rising-edge trigger of X0.1 as the condition for the Z phase input in HWCONFIG. The counting is performed once whenever the rising-edge trigger for X0.1 occurs.
Mode 0 Outputs the clear signal after returning to the zero point. (Output clear point is set in HWCONFIG )	Number of pulses for motion or number of Z phases	4+0=4 4+1=5 4+2=6 4+3=7 (bit 2=ON)	Choosing a value between 4–7 means selecting the functions codes 0–3 respectively, and the specified output point sends an ON signal that is about 20ms wide when the function execution completes. The range of the output point is Y0.12–Y0.15 and Y1.0–Y1.15. For example, if you specify Y1.12 as the output point in HWCONFIG, it indicates Y1.12 is for the output of clear signals.
Leaves the zero point in the positive direction and then stops	0	8+0=8 8+1=9	The operation for zero point return is the same as that for code 1 (mode 1).

(Mode 1)		(bit 3=ON)	
Mode 1 outputs the number of pulses after returning to the zero point	Number of pulses for motion	8+2=10 (bit 3=ON)	The operation for zero point return is the same as that for low 16-bit code 1. After returning to the zero point, the motion continues in accordance with the number of specified pulses. When the value of the high 16-bit code is a positive number, the motion is in the positive direction. A negative number indicates that the motion is in the negative direction.
Mode 1 Searches for Z phase after returning to the zero point (Z phase input point is set in HWCONFIG )	Number of Z phases	8+3=11 (bit 3=ON)	The operation for zero point return is the same as that for low 16-bit code 1. After returning to the zero point, the motion continues in accordance with the number of Z phases to seek. When the value of the high 16-bit code is a positive number, the motion is in the positive direction. A negative number indicates that the motion is in the negative direction. If the rising edge trigger for X0.1 is the condition for Z phase input, counting is performed once when the rising-edge trigger for X0.1 occurs.
Mode 1 Outputs the clear signal after returning to the zero point (Output clear point is set in HWCONFIG )	0 or number of pulses or number of Z phases	12–15 (bit 3=bit 2=ON)	After returning to the zero point in mode 1, the 20ms-width clear signal is output.
DOG point is B point		+16 (bit 4=ON)	When in the low 16-bit code, bit 4 is ON, it means the zero point is ON as the DOG point changes from ON to OFF and the zero point is left as the DOG point changes from OFF to ON.

5. The execution sequence is based on the value of the low 16-bit code in the table above, and described below.
- The direction of DOG signal is determined by the value of bit 5.
  - The DOG signal is determined by the value of bit 4.
  - Mode 0 or mode 1 for the zero point return, selected according to the value of bit 3.
  - The operation of the zero point return is performed according to the values of bit 1 and bit 0.
  - The operation of the clear signal specified by bit 2 is performed.
6. Set the input point and the rising edge trigger condition in HWCONFIG, when the position control system needs positive and negative limit input points. Note that the limit input points must not be the same as the zero point or Z phase input points.


For firmware V1.10 or previous versions, when the zero return motion is in process and the limit point check function is activated, the limit alarm flag is not set to ON once the limit point is reached. For firmware V1.12 or later, the limit alarm flag will automatically set to ON for a reminder, and then you can decide the follow-up operation based on the alarm flag. (Note: After the limit alarm flag is ON, it must be cleared by yourself.)

7. The Completion flag is set to ON after the instruction finishes performing the specified function. For example, for function code 6, the PLC sets the Completion flag to ON only when the Z phase seeking completes.
8. After the DZRN instruction is executed, an interrupt service program is not executed till the DZRN instruction is disabled, if the specified input point for the zero point is the same as that for the external input interrupt in the program.
9. When the limit switch is specified in HWCONFIG, and there is an external input interrupt service program, the interrupt program will be executed at the same time.
10. The instruction cannot be used in the ST programming language, interrupt tasks or function block which is called only once. Firmware V1.12 or later supports the ST programming language. For details, refer to the description in the example.

The steps for performing the functions are as below

Function code 0:


- ① The DZRN function is executed and the search for the zero point is in the negative direction with the target frequency.
- ② After the DOG signal is received, the output frequency decreases to the JOG frequency. The output continues in the negative direction and does not stop until the zero point signal changes from ON to OFF.
- ③ The output stops when the signal changes from ON to OFF and the axis moves away from the DOG signal.



Function code 1:


- ① The DZRN function is executed and the search for the zero point is in the negative direction with the target frequency.
- ② After the DOG signal is received, the output is in the positive direction with the JOG frequency after the output frequency decreases, and the motion direction reverses. The output does not stop until the zero point signal changes from ON to OFF.

③ The axis moves away from the DOG signal and PLC stops when the signal changes from ON to OFF.




Function code 2:

- ① The DZR function is executed and the search for the zero point is in the negative direction with the target frequency.
- ② After the DOG signal is received, the output decreases the frequency to the JOG frequency and continues in the negative direction.
- ③ When the DOG signal is left and the signal changes from ON to OFF, the specified number of pulses are output.
- ④ The first pulse output starts.
- ⑤ When the 100th pulse output completes, the PLC stops and the Completion flag is ON.




Function code 3:

- ① DZRN function is executed and the search for the zero point is in the negative direction with the target frequency.
- ② After the DOG signal is received, the output frequency decreases to the JOG frequency and the motion continues in the negative direction.
- ③ The motion goes on according to the number of Z phases when the signal changes from ON to OFF after the axis moves away from the DOG signal.
- ④ The first Z phase pulse
- ⑤ The motion stops after the 2<sup>nd</sup> Z phase completes and the Completion flag is ON.



Function code 4:


- ① Executed DZRN and the search for the zero point is in the negative direction with the target frequency.
- ② After the DOG signal is received, the output frequency decreases to the JOG frequency and continues in the negative direction. The output does not stop until the zero point signal changes from ON to OFF.
- ③ After the axis moves away from the DOG signal, the output stops when the signal changes from ON to OFF and the clear signal is be ON for about 20 milliseconds.



Function code 0+ the negative limit function enabling:


You set the negative limit input point in HWCONFIG, and then download the setting to the PLC. The PLC automatically calculates the negative limit function when the instruction is executed.

- ① DZRN function is executed and the search for the zero point is in the negative direction with the target frequency.
- ② After the negative limit switch is ON, the motion stops and then goes in the positive direction after reversing direction.
- ③ The motion continues in the positive direction after leaving the negative limit switch.
- ④ The output frequency ramps down after receiving the DOG signal. The reverse output is performed with the JOG frequency after reversing direction.
- ⑤ The output stops when the signal changes from ON to OFF after the axis moves away from the DOG signal.



**Example 1**

When M0 is ON, outputting the pulse from Y0.0 with a frequency of 20 kHz to search for the zero point in the negative direction. When the DOG signal is received and X0.4 is ON, it keeps moving in the negative direction with the JOG frequency of 1 kHz. The output stops immediately after X0.4 changes from ON to OFF.



**Explanation**


**S<sub>3</sub>** is set to 0.

High 16-bit [0000] is to disable the function to move a number of pulses or to search for Z phases.

Low 16-bit [0000] is Mode 0; when the DOG signal is received, the axis moves in the negative direction; after the axis moves away from the DOG signal, it stops immediately.

**Example 2**

When M0 is ON, outputting the pulse from Y0.0 with a frequency of 20 kHz to search for the zero point in the negative direction. When the DOG signal is received and X0.4 is ON, the PLC decreases the frequency to the JOG frequency of 1 kHz and keeps moving in the positive direction with the JOG frequency of 1 kHz. When X0.4 is OFF, the PLC starts to seek the Z phase pulse in the positive direction. When X0.5 receives two pulses, the PLC stops and Y1.4 outputs a 20ms-width pulse.




**Explanation**

1. If you specify the rising-edge trigger at X0.5 as the condition for Z phase input in HWCONFIG, the count is incremented once whenever the rising-edge trigger at X0.5 occurs.
2. Y1.4 is specified as the output point for outputting the clear signal in HWCONFIG.
3. **S<sub>3</sub>** is set as 16#FE0C000E.  
High 16-bit [0002] is to search for the Z phase twice, once the axis moves away from the DOG signal.

Low 16-bit [0007] is Mode 7; when the DOG signal is received, the axis moves in the negative direction; after the axis moves away from the DOG signal, and found the Z phase, a clear signal is outputted (20ms).

**Example 3**

When M0 is ON, outputting the pulse from Y0.0 with a frequency of 20 kHz to search for the zero point in the negative direction. When the DOG signal is received and X0.4 is ON, the PLC decreases the frequency to the JOG frequency of 1 kHz and keeps moving in the positive direction with the JOG frequency of 1 kHz. When X0.4 is OFF, the axis starts to move after 500 pulse output completes in the negative direction. Y1.4 outputs a 20ms-width pulse and then stops outputting.

**Explanation**

1. Y1.4 is specified as the output point for outputting the clear signal in HWCONFIG.
2. **S<sub>3</sub>** is set as 16#FE0C000E.  
High 16-bit [FE0C=-500] once the axis moves away from the DOG signal. The axis starts to move after 500 pulse output completes in the negative direction.  
  
Low 16-bit [000E] is Mode 14; when the DOG signal is received, the axis moves in the positive direction; after the axis moves away from the DOG signal, a clear signal is outputted (20ms).

**Example 4 (in ST programming language)**

Generally, it is suggested to use the ladder diagram language to edit the program when using this instruction. If you use ST language (which is only available for firmware V1.12 or later), you must wait until the zero-return motion is completed (SM461 completion flag is ON) and then disable the instruction. Besides, you must use the auto reset flag together to notify the PLC to release the high-speed output control right.

Taking Y0.0 output for example, the program writing is shown in the figure below

```

0001 IF M0 THEN
0002     DZRN (1000,100,0,X0.0,Y0.0);
0003     M1:=TRUE;
0004 ELSIF M1 AND SM461 THEN
0005     SM470 := TRUE;
0006     M1 := FALSE;
0007 END_IF;

```


API	Instruction			Operand							Description			
2705	D	PLSV		S, D <sub>1</sub> , D <sub>2</sub>							Adjustable pulse output			

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
S							●	●	●		○		○	○		
D <sub>1</sub>		○														
D <sub>2</sub>		○	○													

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
S			●				●						
D <sub>1</sub>	●												
D <sub>2</sub>	●												

Pulse Instruction	16-bit instruction	32-bit instruction
—	—	AS

Symbol



- S : Pulse output frequency
- D<sub>1</sub> : Pulse output device
- D<sub>2</sub> : Pulse direction output device

Explanation

- This instruction adjusts the pulse output frequency and direction (S) for the devices specified in D and D<sub>2</sub>. S specifies the pulse output frequency: for line driver output models, the range is between -4 MHz to +4 MHz; for open collector output models, the range is between -200 kHz to +200 kHz. The minus sign and plus sign indicate the positive direction and negative pulse direction. You can change the pulse output frequency during the pulse output; but if the new frequency is different from the previous frequency in direction, the instruction stops the output, and one cycle later it outputs the target frequency again in the new direction.
- Refer to the following table for the selection of pulse output devices for D<sub>1</sub> and D<sub>2</sub>. When the output mode for D<sub>1</sub> and D<sub>2</sub> is not the default Pulse+direction output (0 is the default value), modify the mode by setting SR to 1, which changes the mode to A/B phase output.

Axis number	Axis 1	Axis 2	Axis 3	Axis 4	Axis 5	Axis 6
Output point for D <sub>1</sub>	Y0.0	Y0.2	Y0.4	Y0.6	Y0.8	Y0.10
Direction output point for D <sub>2</sub>	Y0.1	Y0.3	Y0.5	Y0.7	Y0.9	Y0.11
Output mode	SR462	SR482	SR502	SR522	SR542	SR562
Busy flag	SM460	SM480	SM500	SM520	SM540	SM560

Output present register	SR460	SR480	SR500	SR520	SR540	SR560
	SR461	SR481	SR501	SR521	SR541	SR561

- The output point for the pulse direction output device **D<sub>2</sub>** is affected by the scan cycle if it is not the recommended output point in the table above.
- The pulse direction output device **D<sub>2</sub>** changes its own state according to the minus or plus sign in **S**. **D<sub>2</sub>** is OFF if **S** is plus (+) and **D<sub>2</sub>** is ON if **S** is minus (-).
- There is no ramp-up or ramp-down setting in the instruction. The instruction does not perform a ramp-up operation at the beginning or ramp-down at stopping. If you want the ramp-up and ramp-down function, use the DRAMP instruction (API 0703) for increasing and decreasing the pulse output frequency.
- While the instruction is executing the pulse output, the output immediately stops if the drive condition changes to OFF.
- When the direction outputs are not using the default outputs to output, you can refer to the table below for setting up the time for directional outputting goes first before pulse outputting. So that you can be sure the outputting only happens when switching to the direction outputs. The unit for SR is millisecond and the range is 0-20 ms. Default is 0, indicating inactive.


Output point for <b>D<sub>1</sub></b>	Y0.0	Y0.1	Y0.2	Y0.3	Y0.4	Y0.5
SR number	SR640	SR641	SR642	SR643	SR644	SR645
Output point for <b>D<sub>1</sub></b>	Y0.6	Y0.7	Y0.8	Y0.9	Y0.10	Y0.11
SR number	SR646	SR647	SR648	SR649	SR650	SR651

Note: the time source here is from PLC scan time. (available for firmware version 1.02.20 or later)

- Refer to Example 3 from the DJOG instruction (API 2703) for programming in ST language.

**Example**

When M10 is ON, Y0.0 outputs the pulse at 20 kHz. Y0.1 = OFF means the positive direction for the pulse output.



API	Instruction			Operand								Description				
2706	D	DRVI		<b>S<sub>1</sub>, S<sub>2</sub>, D<sub>1</sub>, D<sub>2</sub></b>								Relative Position control				

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
<b>S<sub>1</sub></b>							●	●	●		○		○	○		
<b>S<sub>2</sub></b>							●	●	●		○		○	○		
<b>D<sub>1</sub></b>		○														
<b>D<sub>2</sub></b>		○	○													

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
<b>S<sub>1</sub></b>			●				●						
<b>S<sub>2</sub></b>			●				●						
<b>D<sub>1</sub></b>	●												
<b>D<sub>2</sub></b>	●												

Pulse Instruction	16-bit instruction	32-bit instruction
—	—	AS

**Symbol**

DDRVI	
En	
S1	D1
S2	D2

- S<sub>1</sub>** : Number of output pulses (relative positioning)
- S<sub>2</sub>** : Pulse output frequency
- D<sub>1</sub>** : Pulse output device
- D<sub>2</sub>** : Pulse direction output device

**Explanation**

- This instruction specifies the output pulse setting for relative positioning. **S<sub>1</sub>** is the number of output pulses (relative positioning). The range is between -2,147,483,648 to +2,147,483,647, and the +/- signs indicate the positive and negative pulse directions. When the instruction is executed and **S<sub>1</sub>** is 0, it indicates not outputting and output completion flag not be set to ON. If 0 is a possible output number in your program, it is suggested to add more conditions in your program to rule out this possibility.
- S<sub>2</sub>** is the pulse output frequency, and the range is between 0 Hz–200 kHz for open collector output models and 0–4 MHz for line driver output models. If the value in **S<sub>2</sub>** is less than the Start/end frequency (Hz) set in SR (refer to the SR table below for more details), PLC operates according to the values set in SR.
- Refer to the following table for the selection of pulse output devices for **D<sub>1</sub>** and **D<sub>2</sub>**. When the output mode for **D<sub>1</sub>** and **D<sub>2</sub>** is not the default Pulse+direction output (0 is the default value), modify the mode by setting SR to 1, which changes the mode into A/B phase output.

Axis number	Axis 1	Axis 2	Axis 3	Axis 4	Axis 5	Axis 6
Output point for <b>D<sub>1</sub></b>	Y0.0	Y0.2	Y0.4	Y0.6	Y0.8	Y0.10
Direction output point for <b>D<sub>2</sub></b>	Y0.1	Y0.3	Y0.5	Y0.7	Y0.9	Y0.11
Output mode	SR462	SR482	SR502	SR522	SR542	SR562

DDRVI and DDRVA support the output devices for **D<sub>1</sub>** which can be the odd points as shown in the following table. Only the Pulse+direction output mode is supported. It is not recommended that you use the input points Y0.0, Y0.2–Y0.10 as the high-speed output points.

Axis number	Axis 7	Axis 8	Axis 9	Axis 10	Axis 11	Axis 12
Output point for <b>D<sub>1</sub></b>	Y0.1	Y0.3	Y0.5	Y0.7	Y0.9	Y0.11
Direction output point for <b>D<sub>2</sub></b>	Y1.0 or above or any M device (BOOL)					

- The output point for the pulse direction output device **D<sub>2</sub>** is affected by the scan cycle if it is not the recommended output point in the table above.
- When **D<sub>2</sub>** uses the output mode Pulse+direction and **S<sub>1</sub>** has a minus sign, **D<sub>2</sub>** is ON. When **S<sub>1</sub>** has a plus sign, **D<sub>2</sub>** is OFF. **D<sub>2</sub>** is not OFF immediately after the pulse output in the negative direction is completed. **D<sub>2</sub>** switches to OFF when the contact for the execution of the instruction is OFF.
- For the instruction execution, you must use the parameters such as the start/end frequency and ramp-up/down time. Refer to the following table for SM/SR corresponding to the axes.

The following table applies when **D<sub>1</sub>** selects the even output points as the output devices.

Output point for <b>D<sub>1</sub></b>	Y0.0	Y0.2	Y0.4	Y0.6	Y0.8	Y0.10
Busy flag	SM460	SM480	SM500	SM520	SM540	SM560
Completion flag	SM461	SM481	SM501	SM521	SM541	SM561
Reversing the output direction	SM462	SM482	SM502	SM522	SM542	SM562
Stop flag	SM463	SM483	SM503	SM523	SM543	SM563
Enabling fixed slope ramp-up/down	SM469	SM489	SM509	SM529	SM549	SM569
Output completion auto-reset	SM470	SM490	SM510	SM530	SM550	SM570

Executing an interrupt program when pulse output ends	SM471	SM491	SM511	SM531	SM551	SM571
Corresponding interrupt I number	I500	I501	I502	I503	I504	I505
The output immediately stops when the instruction is disabled or stops	SM476	SM496	SM516	SM536	SM556	SM576
Present output position	SR460 SR461	SR480 SR481	SR500 SR501	SR520 SR521	SR540 SR541	SR560 SR561
Start/end frequency (Hz)	SR463	SR483	SR503	SR523	SR543	SR563
Ramp-up time (ms)	SR464	SR484	SR504	SR524	SR544	SR564
Ramp-down time (ms)	SR465	SR485	SR505	SR525	SR545	SR565
Target frequency of the fixed slope	SR472 SR473	SR492 SR493	SR512 SR513	SR532 SR533	SR552 SR553	SR572 SR573
Present output frequency	SR610 SR611	SR612 SR613	SR614 SR615	SR616 SR617	SR618 SR619	SR620 SR621

The following table applies when **D<sub>1</sub>** selects the odd output points as the output devices.

Output point for <b>D<sub>1</sub></b>	Y0.1	Y0.3	Y0.5	Y0.7	Y0.9	Y0.11
Busy flag	SM472	SM492	SM512	SM532	SM552	SM572
Completion flag	SM473	SM493	SM513	SM533	SM553	SM573
Output stop flag	SM474	SM494	SM514	SM534	SM554	SM574
Output completion auto-reset	SM475	SM495	SM515	SM535	SM555	SM575
The output immediately stops when the instruction is disabled or stops	SM477	SM497	SM517	SM537	SM557	SM577
Present output position	SR474 SR475	SR494 SR495	SR514 SR515	SR534 SR535	SR554 SR555	SR574 SR575

Start/end frequency(Hz)	SR476	SR496	SR516	SR536	SR556	SR576
Ramp-up/down time (ms)	SR477	SR497	SR517	SR537	SR557	SR577

Some flags, such as fixed slope ramp-up/down, and executing an interrupt program when pulse output ends, are not supported by the odd output points.

If the output is ongoing, the preset output is the ramp-down stop when the instruction is disabled or stops temporarily. If the output must be stopped immediately, set the immediately stop flag to ON.

7. For PLC with FW V1.06.00 or later, added new SR652, SR653 for displaying number of pulse in ramp-up area and new SR654, SR655 for displaying number of pulse in ramp-down area.

Refer to the following table for Attribute, Factory default and latched values of SM/SR corresponding to the axes.

Item	Attribute	Stop→Run	Run→Stop	Power ON	Factory default	Latched
Busy flag	R	OFF	OFF	OFF	OFF	N
Completion flag	R / W	OFF	OFF	OFF	OFF	N
Stop flag	R / W	OFF	OFF	OFF	OFF	N
Output completion auto-reset	R / W	OFF	OFF	OFF	OFF	N
Enabling fixed slope ramp-up/down	R / W	OFF	OFF	OFF	OFF	N
Executing an interrupt program when pulse output ends	R / W	OFF	OFF	OFF	OFF	N
The output immediately stops when the instruction is disabled or stops	R / W	OFF	OFF	OFF	OFF	N
Present output position	R / Wd	No change	No change	No change	0	Y
Start/end frequency(Hz)	R / Wd	No change	No change	No change	200	Y
Ramp-up time (ms)	R / Wd	No change	No change	No change	200	Y

Ramp-down time (ms)	R / Wd	No change	No change	No change	200	Y
Target frequency of the fixed slope	R / Wd	No change	No change	No change	0	Y
Present output frequency	R	0	0	0	0	N

Note: R mean the device is readable. W means the device is writable. Wd means the device is writable any time except when performing the high-speed output.


8. After output completion auto-reset is enabled, the flag is automatically reset to OFF when the output completes. You must set the flag to ON again if the auto-reset function is needed for the next output operation. It is suggested that you use the rising-edge or falling-edge to trigger the flag every time. The function is usually used when the output DDRVI instruction cannot be scanned and executed by PLC program after DDRVI is executed. For example, when the instruction is executed in an interrupt program.
9. If you use the Completion flag to set the I interrupt function, the flag is automatically reset to OFF when the output completes and the interrupt program starts. You must set the flag to ON again for the next output in which the interrupt occurs. It is suggested that you use the rising-edge or falling-edge to trigger the flag every time.
10. When the direction outputs are not using the default outputs to output, you can refer to the table below for setting up the time for directional outputting goes first before pulse outputting. So that you can be sure the outputting only happens when switching to the direction outputs. The unit for SR is millisecond and the range is 0-20 ms. Default is 0, indicating inactive.

Output point for <b>D<sub>1</sub></b>	Y0.0	Y0.1	Y0.2	Y0.3	Y0.4	Y0.5
SR number	SR640	SR641	SR642	SR643	SR644	SR645
Output point for <b>D<sub>1</sub></b>	Y0.6	Y0.7	Y0.8	Y0.9	Y0.10	Y0.11
SR number	SR646	SR647	SR648	SR649	SR650	SR651


Note: the time source here is from PLC scan time. (available for firmware version 1.02.20 or later)

**Example 1**

When M10 is ON, Y0.0 outputs 20,000 pulses at 2 kHz (relative positioning). Y0.1 = OFF means the positive direction.


**Additional remarks**

- The following graph explains the relative positioning by specifying the travel distance from the current position with the +/- signs.



- Setting the ramp up/down and the items for relative positioning


- Y0.0 output curve diagram



- You can create several DRVI instructions using the same output point in the program. The PLC can start only one DRVI instruction when executing the program. For example, when one instruction starts Y0.0 for output, then other instructions that also use Y0.0 for output are not executed. The instruction that starts the output point first uses the point first.
- After the instruction is executed, any modification of the parameters is not accepted until the instruction is disabled.

3. Ramp-up and ramp-down for fixed slopes

a) The following graph shows the Y0.0 output curve diagram.




- b) Start the fixed slope flag SM469 and write the target frequency of the fixed slope into SR472.
- c) The new slope takes the place of the original slope and the DDRVI instruction performs the positioning as shown above.
- d) The general slope is determined by the start/end frequency, target frequency, and ramp up and down time.  
  
The fixed slope is determined by the start/end frequency, target frequency of the fixed slope, and ramp up and down time.
- e) When the target frequency of the fixed slope is less than the target frequency, the fixed slope function is not started.

6

4. Stop flag and immediately stop flag

a) The following graphic shows the output diagram based on example 1.



b) Ramp-down stop


- ① When M10 is ON, the DDRVI instruction is executed and starts to output pulses, and SM460, the Busy flag is ON.
- ② When the instruction is disabled (M10 is OFF) or the stop flag SM463 is ON, the state of the immediately stop flag SM476 is confirmed.
- ③ If the immediately stop flag SM476 is OFF, the output ramps down to stop and then the Busy flag SM460 is OFF.
- ④ If M10 is not OFF and the stop flag SM463 is not ON after the instruction is executed, Y0.0 stops the output after 20,000 pulses.

c) Immediately stop

- ① When M10 is ON, the DDRVI instruction is executed and starts to output pulses, and SM460, the Busy flag is ON.
- ② If the instruction is disabled (M10 is OFF) or the stop flag SM463 is ON, the state of the immediately stop flag SM476 is confirmed.
- ③ If the immediately stop flag SM476 is ON, the output stops immediately and the Busy flag SM460 is OFF.

5. Hardware limit function

a) The following graphic shows the output curve diagram of axis 1 (Y0.0/Y0.1).



b) Operation of the positive limit

- ① Positive limit input point X0.6 is set in HWCONFIG and downloaded to the PLC. When SM464 is set to ON, the positive limit function starts.

① DDRVI outputs 20,000 pulses in the positive direction. **Note:** the instruction does not output in the positive direction if the positive limit point is ON when the function starts.

② When the limit input point X0.6 is triggered by the external mechanism and is ON, the condition for the hardware positive limit function is met.

③ DDRVI instruction stops the output immediately and the positive limit alarm SM465 is ON.

④ If the condition for the hardware limit function is not met, Y0.0 stops the output after 20,000 pulses.

c) Operation of the negative limit

① Negative limit input point X0.7 is set in HWCONFIG and is downloaded to PLC. When SM466 is set to ON, the negative limit function starts.

② DDRVI outputs 20,000 pulses in the negative direction. **Note:** the instruction does not output in the negative direction if the negative limit point is ON when the function starts.

③ When the limit input point X0.7 is triggered by the external mechanism and is ON, the condition for the hardware negative limit function is met.

④ DDRVI instruction stops the output immediately and the negative limit alarm SM467 is ON.

⑤ If the condition for the hardware limit function is not met, Y0.0 stops the output after -20,000 pulses.


d) SM flags related to the limit function

Axis number	Axis 1	Axis 2	Axis 3	Axis 4	Axis 5	Axis 6
Enabling the hardware positive limit	SM464	SM484	SM504	SM524	SM544	SM564
Positive limit alarm flag	SM465	SM485	SM505	SM525	SM545	SM565
Enabling the hardware negative limit	SM466	SM486	SM506	SM526	SM546	SM566
Negative limit alarm flag	SM467	SM487	SM507	SM527	SM547	SM567

Note: The limit point alarm flag and is set or reset automatically by the PLC according to the state of the start flag.

6. Software limit function

a) The following diagram shows the output curve diagram of axis 1 (Y0.0/Y0.1).



b) Operation of the positive limit


① Positive software limit position is set in HWCONFIG (by setting SR580=11,000 for example). After downloading the setting to the PLC, it means the positive limit function starts.

② DDRVI starts to output 20,000 pulses in the positive direction. **Note:** the instruction does not output in the positive direction if the positive limit is exceeded when the function starts.

③ When the current position SR460 > the limit position SR580, it means that the condition for the software limit function is met.

④ DDRVI instruction stops the output immediately and the positive limit alarm SM465 is ON.

⑤ If the condition for the limit function is not met, Y0.0 stops the output after 20,000 pulses.



c) Operation of the negative limit

- ① Negative software limit position is set in HWCONFIG (by setting SR582 = -11,000 for example). After downloading the setting to the PLC, the negative limit function starts.
- ① DDRVI starts to output 20,000 pulses in the negative direction. **Note:** the instruction does not output in the negative direction if the negative limit is exceeded when the function starts.
- ② When the current position SR460 < the limit position SR582, the condition for the software negative limit function is met.
- ③ DDRVI instruction stops the output immediately and the negative limit alarm SM467 is ON.
- ④ If the condition for the software limit function is not met, Y0.0 stops the output after -20,000 pulses.

d) Rising-edge trigger

Limit function	Contact A	Contact B
Types	Rising-edge trigger	Falling-edgetrigger
Descriptions	 <p>When started: from low to high and maintains at high</p>	 <p>When started: from high to low and maintains at low</p>

e) SR related to the limit function

Axis number	Axis 1	Axis 2	Axis 3	Axis 4	Axis 5	Axis 6
Positive software limit position	SR580	SR584	SR588	SR592	SR596	SR600
	SR581	SR585	SR589	SR593	SR597	SR601
Negative software limit position	SR582	SR586	SR590	SR594	SR598	SR602
	SR583	SR587	SR591	SR595	SR599	SR603

Positive output limit: the output stops immediately if the current position is greater than the positive limit position.

Negative output limit: the output stops immediately if the current position is less than the negative limit position.

When the positive and negative limits are both 0, the software limit function cannot start. Since the software limit function checks the output position when the output instruction is scanned, stopping the output is affected by the PLC scan. To quickly stop the output in real time, use the external input point as the limit point.

## 7. ST Example

```

0001 IF M0 THEN
0002     DDRVI (1000,1000,Y0.0,Y0.1);
0003     M1 := TRUE;
0004 ELSIF M1 AND SM461 THEN
0005     SM470 := TRUE;
0006     M1 := FALSE;
0007 END_IF;


```

## Explanation


- 7.1 When M0 is ON, Y0.0 outputs 1000 pulses at 1 kHz.
- 7.2 When the pulse output completes, SM461 is ON and SM470=ON is triggered.
- 7.3 The pulse output restarts when M0 changes from OFF to ON again
- 7.4 When there are more than two high-speed output instructions in a program, do not use the variable name, M1, repeatedly.
- 7.5 It is suggested not to use ST language in a program if there is any chance the outputting needed to be stopped.

## 8. Function block example


Main program



Function block 1



Function block 2



**Explanation**

When M0 is ON, Y0.0 outputs 10000 pulse at 1kHz. Y0.1 = OFF means the pulse output direction is positive.


- 9. Be sure to refer to PLSR instruction (API2701) for more details on changing target frequency during outputting. Remember if there is any change on the target frequency, the change can only be carried out after the original target frequency completes outputting.
- 10. Changing the target position during outputting:
  - 10.1 This function is only available for firmware version 1.02.30 or later. You cannot change outputting direction even after the target position is changed. For example, if the original output target position is in the positive direction, after the target position is changed, it still outputs in the positive direction.
  - 10.2 After you set the change flag, the changing happens when the instruction is being scanned. And after it is changed, the change flag is cleared off. But if the target position is set incorrectly, the change flag keeps ON.
  - 10.3 Refer to the following table for the corresponding outputs and change flag SM.

Output point	Y0.0	Y0.1	Y0.2	Y0.3	Y0.4	Y0.5
SM number	SM478	SM479	SM498	SM499	SM518	SM519
Output point	Y0.6	Y0.7	Y0.8	Y0.9	Y0.10	Y0.11
SM number	SM538	SM539	SM558	SM559	SM578	SM579

- 10.4 This changing target position function is available for DDRVI and DDRVA instructions. When the instruction DDRVI is used and a change flag is set, the change will be executed. Even if the output number is 0, the operation will be carried out and stop outputting. When the instruction DDRVA is used, if the changed target position is the same as the previous one, this change will not be performed.
- 10.5 Three situations may occur, when changing target position during output.


Situation A: changing timing occurs during outputting in the ramp-down area.

- ① original target position when started (blue)
- ② new number of output pulse  $\geq$  remaining number of output pulse, its outputting curve (red).
- ③ new number of output pulse  $<$  remaining number of output pulse, its outputting curve (green).




Situation B: changing timing occurs during outputting in the target frequency area.

- ① original target position during initial start (blue)
- ① new number of output pulse  $\geq$  number of output pulse in ramp-down area, its outputting curve (red).
- ② new number of output pulse  $<$  number of output pulse in ramp-down area, its outputting curve (green)



Situation C: changing timing occurs during outputting in the ramp-up area.

- ① original target position during initial start (blue)
- ① new number of output pulse  $\geq$  number of output pulse in ramp-down area, its outputting curve (red).
- ② new number of output pulse  $<$  number of output pulse in ramp-down area, its outputting curve (green)




API	Instruction			Operand								Description				
2707	D	DRVA		<b>S<sub>1</sub>, S<sub>2</sub>, D<sub>1</sub>, D<sub>2</sub></b>								Absolute position control				

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
<b>S<sub>1</sub></b>							●	●	●		○		○	○		
<b>S<sub>2</sub></b>							●	●	●		○		○	○		
<b>D<sub>1</sub></b>		○														
<b>D<sub>2</sub></b>		○	○													

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
<b>S<sub>1</sub></b>			●				●						
<b>S<sub>2</sub></b>			●				●						
<b>D<sub>1</sub></b>	●												
<b>D<sub>2</sub></b>	●												

Pulse Instruction	16-bit instruction	32-bit instruction
—	—	AS

**Symbol**




- S<sub>1</sub>** : Number of output pulses (absolute positioning)
- S<sub>2</sub>** : Pulse output frequency
- D<sub>1</sub>** : Pulse output device
- D<sub>2</sub>** : Pulse direction output device

**Explanation**


1. This instruction specifies the output pulse setting for absolute positioning. **S<sub>1</sub>** is the number of output pulses (absolute positioning). The range is between -2,147,483,648 to +2,147,483,647, and +/- signs indicate the positive and negative pulse directions. When the instruction is executed, it checks the current position with **S<sub>1</sub>**. If **S<sub>1</sub>** is 0, it indicates not outputting and output completion flag not be set to ON. If 0 is a possible output number in your program, it is suggested to add more conditions in your program to rule out this possibility.
2. **S<sub>2</sub>** is the pulse output frequency and the range is between 0 Hz–4 MHz for the line driver output models and 0 Hz–200 kHz for the open collector output models. If the value in **S<sub>2</sub>** is less than the Start/end frequency (Hz) set in SR (refer to the SR table of DRV1 instruction for more details), PLC operates according to the values set in SR.
3. Absolute positioning means that the instruction outputs pulses to move from current position until the specified target position is reached. For example, the number of output pulses at current position is 100 and the number of pulses at the target position **S<sub>1</sub>** is set to 1000. So the number of the actual output pulses is 1000-100=900.
4. Refer to the DDRV1 instruction (API 2706) for more explanation.

**Example**

If the value of the present output position SR460 (32-bit) is 100 and M10 is ON, then the DDRVA instruction causes Y0.0 to output pulses at 2 kHz until the value in SR460 becomes 20,000 (absolute positioning). Y0.1 = OFF means the positive direction.

**Additional remarks**

1. The following graph shows absolute positioning: the way of specifying the distance from the center (zero point).



API	Instruction			Operand							Description				
2708		CSFO		<b>S<sub>1</sub>, S<sub>2</sub>, S<sub>3</sub>, S<sub>4</sub>, S<sub>5</sub>, D<sub>1</sub>, D<sub>2</sub></b>							Catch speed and proportional output				


Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
S <sub>1</sub>	○															
S <sub>2</sub>								●								
S <sub>3</sub>								●								
S <sub>4</sub>								●								
S <sub>5</sub>								●								
D <sub>1</sub>		○														
D <sub>2</sub>								●								

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
S <sub>1</sub>	●												
S <sub>2</sub>			●				●						
S <sub>3</sub>			●				●						
S <sub>4</sub>		●											
S <sub>5</sub>		●											
D <sub>1</sub>	●												
D <sub>2</sub>			●				●						

Pulse Instruction	16-bit instruction	32-bit instruction
-	AS	-

6

**Symbol**



- S<sub>1</sub> : Signal input device
- S<sub>2</sub> : Number of input pulses
- S<sub>3</sub> : Pulse input frequency
- S<sub>4</sub> : Denominator (output frequency) for the proportion of the input frequency and output frequency
- S<sub>5</sub> : Numerator (input frequency) for the proportion of the input frequency and output frequency
- D<sub>1</sub> : Pulse output device
- D<sub>2</sub> : Pulse output frequency

**Explanation**

- This instruction specifies the catch speed and proportional output. S<sub>1</sub> can only specify X0.0, X0.2, X0.4, X0.6, X0.8 and X0.10 as the input points, and the operand occupies two consecutive input points. You cannot execute the instruction if the input points are the points specified for S<sub>1</sub> above. After you select the input points, the high-speed counter is automatically specified. If there is a DCNT instruction (API 1004) with the same high-speed counter in

the program, the PLC first executes the instruction that starts the counter first. The input points and corresponding high-speed counters are shown in the following table.

Group number	1	2	3	4	5	6
<b>S<sub>1+0</sub></b> input point (Phase A)	X0.0	X0.2	X0.4	X0.6	X0.8	X0.10
<b>S<sub>1+1</sub></b> input point (Phase B)	X0.1	X0.3	X0.5	X0.7	X0.9	X0.11
High-speed counter number	HC202	HC206	HC210	HC214	HC218	HC222
Flag for reversing input direction	SM270	SM271	SM272	SM273	SM274	SM275

- If the high-speed counters for the instruction can use only the phase A/B input mode, set the flag for reversing the input direction to ON when MPG is connected but has not rotated yet, and the PLC input point is ON. Set the function to detect the state of PLC run cycle to OFF.
- S<sub>2</sub>** is the number of input pulses. Use a 32-bit variable to declare the parameter.
- S<sub>3</sub>** is the frequency of input pulses. Use a 32-bit variable to declare the parameter with the unit of 1 Hz.
- S<sub>4</sub>** is the denominator (output frequency) for the proportion of the input frequency and output frequency. **S<sub>5</sub>** is the numerator (input frequency) for the proportion of the input frequency and output frequency. The range of **S<sub>4</sub>** and **S<sub>5</sub>** is between 1–255. If the setting value exceeds the range, the instruction is processed as the maximum or minimum value. For example, if input frequency: output frequency= 5:3, the denominator output frequency is K3 and the numerator input frequency is K5. If the input frequency: output frequency=1:2, the denominator output frequency is K2 and the numerator input frequency is K1.
- D<sub>1</sub>** can only specify Y0.0, Y0.2, Y0.4, Y0.6, Y0.8 and Y0.10 as the output points and occupies two consecutive output points.

The output points and corresponding output mode SR are shown in the following table.

Output axis number	1	2	3	4	5	6
<b>D<sub>1+0</sub></b> output point	Y0.0	Y0.2	Y0.4	Y0.6	Y0.8	Y0.10
<b>D<sub>1+1</sub></b> output point	Y0.1	Y0.3	Y0.5	Y0.7	Y0.9	Y0.11
Output mode	SR462	SR482	SR502	SR522	SR542	SR562

- D<sub>2</sub>** is the frequency of the output pulses. Use a 32-bit variable to declare the parameter with the unit of 1 Hz.


8. There is no limit to the number of times you can use this instruction; but the high-speed input and output points cannot be used by other instructions when this instruction is executed. Otherwise, the instruction cannot be executed.
9. The instruction cannot be used in the ST programming language, interrupt tasks or function block which is called only once.

### Notes

1. The PLC calculates the input pulse frequency based on the input pulse width (ON) in the positive half cycle. If the proportion of the pulse width for ON:pulse width for OFF is not 1:1, the PLC takes the ON width as the standard for conversion by default.
2. The input pulse=ON means the input point LED is on. When using the MPG but it has not rotated yet, you can check if the input point LED is OFF and the flag for reversing the input direction is activated .
3. For PLC with FW V1.04.70 (V1.04.70 included) or later, the minimum pulse frequency for input and output is 50 Hz. If the actual input pulse is 10 Hz and the value in **S<sub>3</sub>** shows 10 Hz. But since the minimum pulse frequency for output is 50 Hz, the instruction uses 50 Hz instead of 10 Hz to calculate. For the ratio 1:2, after conversion, the output pulse is 100 Hz. For the ratio 2:1, after conversion, the output pulse is 50 Hz instead of 25 or 5 Hz.
4. You can modify values in **S<sub>4</sub>** or **S<sub>5</sub>** during the execution of this instruction. But you need to re-execute this instruction to actualize this modification. Otherwise the value in **S<sub>2</sub>** is not accurate enough to be used for calculating the current output position of SR.
5. After conversion, if the output pulse frequency exceeds the maximum limit, the error code is recorded as 16#2030 in Error Log File in ISPSoft and SM29 is ON. SR29 is the axis number. This function is available for PLC with FW V1.06.20 (V1.06.20 included) or later.
6. If the input pulse is 0 Hz and lasts for more than 2 seconds, PLC stops outputting automatically and the error code is recorded as 16#2031 in Error Log File in ISPSoft and SM29 is ON. SR29 is the axis number. This function is available for PLC with FW V1.06.20 (V1.06.20 included) or later.


### Example 1

X0.0/X0.1 input pulses for detecting the MPG. When M0 is ON, the setting values of **S<sub>4</sub>** and **S<sub>5</sub>** are both 1 (D4=1 and D5=1). When the input frequency is 10 Hz (D2, D3=10) and the number of pulses is 10 (D0, D1=10), the output axis (Y0.0/Y0.1) outputs 10 pulses (SR460, SR461=10) at 10Hz (D10, D11=10).



**Example 2**

When M0 is ON, the setting values of S4 and S5 are 3 and 5 (D4=3, D5=5) respectively. When the input frequency of the MPG is 500 Hz (D2, D3=500) and the number of pulses is 2500 (D0, D1=2500), the output axis (Y0.0/Y0.1) outputs 1500 pulses (SR460, SR461=1500) at 300 Hz (D10, D11=300).



API	Instruction			Operand								Description				
2709	D	DRVM		S <sub>1</sub> , S <sub>2</sub> , S <sub>3</sub> , S <sub>4</sub> , S <sub>5</sub> , S <sub>6</sub> , D <sub>1</sub> , D <sub>2</sub>								Mark alignment positioning				


Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
S <sub>1</sub>								●	●				○	○		
S <sub>2</sub>								●	●				○	○		
S <sub>3</sub>	○		○													
S <sub>4</sub>								●	●				○	○		
S <sub>5</sub>								●	●				○	○		
S <sub>6</sub>								●	●				○	○		
D <sub>1</sub>		○														
D <sub>2</sub>		○	○													

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
S <sub>1</sub>			●				●						
S <sub>2</sub>			●				●						
S <sub>3</sub>	●												
S <sub>4</sub>			●				●						
S <sub>5</sub>			●				●						
S <sub>6</sub>			●				●						
D <sub>1</sub>	●												
D <sub>2</sub>	●												

6

Pulse Instruction	16-bit instruction	32-bit instruction
—	—	AS

Symbol



- S<sub>1</sub> : Target number of output pulses
- S<sub>2</sub> : Target output frequency
- S<sub>3</sub> : Input point number for receiving the external interrupt signal
- S<sub>4</sub> : The number of output pulses at the end for the fore mask section
- S<sub>5</sub> : The number of output pulses at the beginning for the rear mask section
- S<sub>6</sub> : The number of output pulses in the ramp-down process after the interrupt signal is received
- D<sub>1</sub> : Pulse output device
- D<sub>2</sub> : Direction pulse output device

**Explanation**

1. This instruction performs mark alignment positioning. When the value of **S<sub>1</sub>** is 0, it indicates the output is a maximum 32-bit value (with a sign) and the output does not perform the ramp-down stop until receiving the mark signal.

If the value of **S<sub>1</sub>** is not 0 and the external interrupt does not occur, the target number output pulses are output. The range of **S<sub>1</sub>** is between -2,147,483,648 to +2,147,483,647, and the +/- sign means the positive or negative direction.

2. When the value of **S<sub>2</sub>** is less than or equal to 0, the output is not enabled. If the output frequency is greater than the maximum frequency, the PLC processes it as the maximum output frequency.
3. **S<sub>3</sub>** can specify the M or X device as the input point. The input source signal is affected by the scan cycle if the selected input point is not in X0.0–X0.15 in the PLC.
4. You must use the instruction by combining the input point number and the external interrupt program to achieve the real-time ramp-down output. For the rising-edge or falling-edge trigger for the external interrupt, select the triggers in the external interrupt program in ISPSOft.
  - A. Using the external interrupt (e.g. I0xx, I1xx): when the external interrupt occurs, the ramp-down stop is performed after the mark signal is received. No operation is performed if the external interrupt is not enabled.
  - B. Without using the external interrupt (I0xx, I1xx): When the instruction is executed, the ramp-down stop is performed after the mark signal is received if the rising edge occurs at X point or M device. It is affected by the scan time.
5. The number of output pulses in the fore mask section is between 1–**S<sub>4</sub>**. When the setting value for **S<sub>4</sub>** is 0, it means the fore- mask section function is disabled. When the number of pulses to be masked exceeds the value of **S<sub>1</sub>**, the instruction takes the target number of output pulses **S<sub>1</sub>** as the number to be masked. If the external input trigger occurs within the number of output pulses to be masked, the external input interrupt is automatically invalid.
6. The number of output pulses in the rear mask section is between **S<sub>5</sub>** and **S<sub>1</sub>**. When **S<sub>5</sub>** = 0 or **S<sub>5</sub>** >= **S<sub>1</sub>**, the rear mask section function is disabled. When the external input trigger occurs in the masked sections, the external input interrupt is automatically invalid. When **S<sub>4</sub>** > **S<sub>5</sub>**, it indicates the external input interrupt is invalid in the output process.
7. If the fore and rear mask sections are both set and **S<sub>4</sub>** < **S<sub>5</sub>**, the valid input interrupt occurs in the section between **S<sub>4</sub>**+1 and **S<sub>5</sub>**-1.
8. For PLC with FW V1.04.00 (V1.04.00 included) or previous versions:

<b>S<sub>6</sub></b> : the number of output pulses in the ramp-down	Description
If <b>S<sub>6</sub></b> is set to 0 after the mark signal is received	the ramp-down stop is performed based on the ramp-down time

If $S_6 = -1$ or $< 0$ after the mark signal is received	the output immediately stops
If the setting value of $S_6$ is not enough to achieve the ramp-down stop within the ramp-down time,	The instruction limits the target frequency and performs the ramp-down stop in accordance with the set ramp-down time
If $S_6$ is greater than the number of pulses output within the ramp-down time,	The instruction outputs the number of redundant pulses with the same output frequency when the interrupt is triggered, and then performs the ramp-down process


9. For PLC with FW V1.06.00 (V1.06.00 included) or later: If  $S_6$  is set to 0 after the mark signal is received, it means that the ramp-down stop is performed based on the ramp-down time. If  $S_6$  is set to -1 after the mark signal is received, it means that the output immediately stops. If  $S_6$  is set to  $>0$  after the mark signal is received and if the setting value of  $S_6$  is not enough to achieve the ramp-down stop within the ramp-down time, the instruction limits the target frequency and performs the ramp-down stop in accordance with the set ramp-down time. If  $S_6$  is greater than the number of pulses output within the ramp-down time, the instruction outputs the number of redundant pulses with the same output frequency when the interrupt is triggered, and then performs the ramp-down process.

$S_6$ : the number of output pulses in the ramp-down	Description
If $S_6 = > 0$ after the mark signal is received If the setting value of $S_6$ is not enough to achieve the ramp-down stop within the ramp-down time,	The instruction limits the target frequency and performs the ramp-down stop in accordance with the set ramp-down time
If $S_6 = > 0$ after the mark signal is received If $S_6$ is greater than the number of pulses output within the ramp-down time,	The instruction outputs the number of redundant pulses with the same output frequency when the interrupt is triggered, and then performs the ramp-down process
If $S_6$ is set to 0 after the mark signal is received	The ramp-down stop is performed based on the ramp-down time
If $S_6 = -1$ after the mark signal is received	The output immediately stops
If $S_6 = < -1$ after the mark signal is received If the setting value of $S_6$ is not enough to achieve the ramp-down stop within the ramp-down time,	The instruction does NOT limit the target frequency and after outputting the number of output pulses, the output stops immediately
If $S_6 = < -1$ after the mark signal is received	The instruction outputs the number of redundant pulses with the same output frequency when the


<p>If <math>S_6</math> is greater than the number of pulses output within the ramp-down time,</p>	<p>Interrupt is triggered, and then performs the ramp-down process</p>
---	--

- Added new SR652, SR653 for displaying number of pulse in ramp-up area and new SR654, SR655 for displaying number of pulse in ramp-down area.

10. If the output has entered the ramp-down process when the external input interrupt trigger occurs, the instruction completes the output of the number of pulses specified by  $S_6$ .
11. See the following timing diagram about the output, interrupt trigger, mask and relevant flags. For the completion flag, refer to the Completion flag SM for the axes in DDRVI instruction (API 2706).




12. The target frequency  $S_2$  of the instruction can be modified in the process of the pulse output. Since the number of output pulses in the ramp-down section has been set when the instruction is executed, the timing diagram for changing the frequency is shown as the following dashed line.



13. Refer to the DDRVI instruction (API 2706) for the selection of pulse output devices for  $D_1$  and  $D_2$ . The output points for  $D_1$  can only be even-numbered such as Y0.0, Y0.2 or Y0.10. If the output points are not the recommended ones, the direction output  $D_2$  is affected by the scan cycle.

- The instruction cannot be used in the ST programming language, interrupt tasks or function block which is called only once.

**Example 1**



X0.4 external interrupt program

**Notes**

- When M0 changes from OFF to ON, Y0.0 starts to output pulses. After outputting more than 30,000 pulses, the external interrupt is detected on X0.4. The value in D0 increases by 1 and the pulse output stops after 15,000 pulses ( $S_6 = 15,000$ ). If the interrupt does not occur, the output does not stop until 100,000 pulses are output.
- If the number of output pulses is between 1–30,000, they are in the fore mask section. The external interrupt occurs at X0.4 at the moment and the instruction does not perform the ramp-down stop operation.
- If the number of output pulses is between 70,000–100,000, they are in the rear mask section. The external interrupt occurs at X0.4 at the moment and the instruction still does not perform the ramp-down stop operation.
- When the pulse output completes, SM461 is ON and M0 is reset.

**Additional remarks**

1. The alignment mark function and mask function:

① When DDRVM is executed, the pulse output starts.


② When the interrupt occurs for the mark alignment, the ramp-down process starts and the output stops after the number of the pulses specified by  $S_6$ .

③ When the interrupt for the mark alignment does not occur or has no effect, DDRVM stops outputting the pulses after the target number of pulses specified by  $S_1$ .

$S_4$ : The number of output pulses in the fore mask section. If the interrupt occurs in this section, the interrupt is ineffective for the mark alignment.

$S_5$ : The number of output pulses in the rear mask section. If the interrupt occurs in this section, the interrupt is ineffective for the mark alignment.


$S_2$ : The target output frequency



2. The mark alignment function is enabled in the ramp-up and target frequency and ramp-down sections. (Horizontal coordinate (x axis) represents TIME and vertical coordinate (y axis) represents PULSE.)

When the mark alignment function is not enabled, set  $S_1 = 100,000$ ; the output stops after 100,000 pulses.


- Green line: signal of mark alignment
- Blue line: the actual output speed



Case 1: when the mark alignment occurs in the ramp-up section

- Green line: signal of mark alignment
- Blue line: the actual output speed


The operation of the mark alignment (green line: OFF -> ON) begins when the number of pulses is 3000. The target frequency of 10 kHz cannot be reached even if  $S_6$  is 15,000.



Case 2: when the mark alignment occurs in the ramp-up section

- Green line: signal of mark alignment
- Blue line: the actual output speed


The operation of the mark alignment (green line: OFF -> ON) begins when the number of pulses is 6000. The target frequency of 10 kHz can be reached if  $S_6$  is 15,000.



When the mark alignment occurs in the target frequency section

- Green line: signal of mark alignment
- Blue line: the actual output speed

The operation of the mark alignment (green line: OFF -> ON) begins when the number of pulses is 50,000. Set  $S_6 = 15,000$ ; the output stops after 15,000 pulses.




Case 1: when the mark alignment occurs in the ramp-down section

- Green line: signal of mark alignment
- Blue line: the actual output speed

The operation of the mark alignment (green line: OFF -> ON) begins when the number of pulses is 95,000.


Set  $S_6 = 15,000$ ; the output stops after 15,000 pulses at the current speed.



Case 2: when the mark alignment occurs in the ramp-down section

- Green line: signal of mark alignment
- Blue line: the actual output speed

The operation of the mark alignment (green line: OFF -> ON) begins when the number of pulses is 95,000. After the mark alignment, set  $S_6$  to -1, the output stops immediately.




API	Instruction			Operand								Description				
2710	D	PPMR		<b>S<sub>1</sub>, S<sub>2</sub>, S<sub>3</sub>, D<sub>1</sub>, D<sub>2</sub></b>								2-Axis relative-coordinate point-to-point synchronized motion				

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	“\$”	F
<b>S<sub>1</sub></b>							●	●	●		○		○	○		
<b>S<sub>2</sub></b>							●	●	●		○		○	○		
<b>S<sub>3</sub></b>							●	●	●		○		○	○		
<b>D<sub>1</sub></b>		○														
<b>D<sub>2</sub></b>		○														

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
<b>S<sub>1</sub></b>			●				●						
<b>S<sub>2</sub></b>			●				●						
<b>S<sub>3</sub></b>			●				●						
<b>D<sub>1</sub></b>	●												
<b>D<sub>2</sub></b>	●												

Pulse Instruction	16-bit instruction	32-bit instruction
—	—	AS

**Symbol**



- S<sub>1</sub>** : Number of output pulses for the X axis
- S<sub>2</sub>** : Number of output pulses for the Y axis
- S<sub>3</sub>** : Maximum point-to-point output frequency
- D<sub>1</sub>** : Pulse output device for the X axis
- D<sub>2</sub>** : Pulse output device for the Y axis

**Explanation**

1. This instruction performs 2-axis relative-coordinate point-to-point synchronized motion. **S<sub>1</sub>** and **S<sub>2</sub>** specify the number of output pulses (relative positioning) for the X and Y axes. The range is between: -2,147,483,648 to +2,147,483,647, and the +/- sign indicates the positive/negative direction.
2. **S<sub>3</sub>** specifies the maximum point to point output frequency. The range is between 1 Hz–200 kHz.
3. For firmware V1.08.70 or later, you can change the target frequency during execution of the instruction. After the original target frequency completes outputting, new target frequency can be used. And the ramp up and ramp down time from the original target frequency to the new target frequency is calculated according to the interval frequency and interval time since the instruction is enabled. Refer to DPLSR instruction for the details on the actual movement in the ramp down section that is between the new target frequency and the next target frequency.

4. **D<sub>1</sub>** and **D<sub>2</sub>** are the output devices for the X and Y axes respectively. You can designate the following six axes for output but you cannot change the fixed direction output points. The direction signal: OFF means in positive direction and ON is in negative direction. If you do not use the preset Pulse+direction output mode (default: 0), change the output mode by setting SR to 1.

Axis number	Axis 1	Axis 2	Axis 3	Axis 4	Axis 5	Axis 6
<b>Output points for D<sub>1</sub> and D<sub>2</sub></b>	Y0.0	Y0.2	Y0.4	Y0.6	Y0.8	Y0.10
<b>Fixed direction output point</b>	Y0.1	Y0.3	Y0.5	Y0.7	Y0.9	Y0.11
<b>Output mode</b>	SR462	SR482	SR502	SR522	SR542	SR562


5. The PLC assigns the value of **S<sub>3</sub>** to the X or Y axis depending on which outputs the largest number of pulses. If the numbers of pulses output for the two axes are excessively different, so that no proper output frequency can be calculated through the numbers of their output pulses, the PLC automatically decreases the maximum point to point frequency and without any error message appearing.
6. The instruction uses the parameters such as the start and end frequencies and ramp-up and ramp-down times for the axes the instruction executes. Instead of the originally configured parameters for the axes, the X axis parameters are taken as the reference source. For example, when the X axis selects axis 1 and the Y axis selects axis 3 for the output, axis 1 parameters become the parameter sources for the start frequency and ramp up and ramp-down time.
7. The following table shows the flags for the axes and the corresponding SM/SR.

Axis number	Axis 1	Axis 2	Axis 3	Axis 4	Axis 5	Axis 6
<b>Busy flag</b>	SM460	SM480	SM500	SM520	SM540	SM560
<b>Completion flag</b>	SM461	SM481	SM501	SM521	SM541	SM561
<b>Present output position</b>	SR460 SR461	SR480 SR481	SR500 SR501	SR520 SR521	SR540 SR541	SR560 SR561
<b>Start/end frequency</b>	SR463	SR483	SR503	SR523	SR543	SR563
<b>Ramp-up time</b>	SR464	SR484	SR504	SR524	SR544	SR564
<b>Ramp-down time</b>	SR465	SR485	SR505	SR525	SR545	SR565

8. There is no limit to how many times you can use the instruction in a program. But during the execution of the instruction, it cannot execute the output (if the Y axis output is being used) until the Y axis completes its output and is released.
9. When the 2-axis synchronized pulse output completes, the corresponding Completion flags for the two axes is set. Since the same timing for the completion of the 2-axis synchronized pulse output cannot be ensured every time, the program should check the Completion flags of both axes before executing the next user program.


**Example (Ladder diagrams)**


1. Draw a rhombus as shown below.



2. Steps:

- Set the coordinates of four points (0, 0), (-27000, -27000), (0, -55000), (27000, -27000) as in the figure above. Calculate the relative coordinates of the four points and obtain (-27000, -27000), (27000, -28000), (27000, 28000), and (-27000, 27000). Place them in the 32-bit registers (D200, D202), (D204, D206), (D208, D210), (D212, D214).
- RUN the program in the PLC. Set M0 to ON to start the 2-axis line drawing.





### 3. Operation:

When PLC runs the program and M0 is ON, the PLC starts the first point-to-point motion at 100 kHz. D0 increments by 1 whenever a point-to-point motion is completed and the second point-to-point motion starts to execute automatically. The operation pattern repeats until the fourth point-to-point motion completes.

#### Example 2 (ST program)

```

0001 IF M0 THEN
0002     DPPMR (1000,1000,1000,Y0.0,Y0.2);
0003     M1 := TRUE;
0004 ELSIF M1 AND SM461 AND SM481 THEN
0005     SM470 := TRUE;
0006     SM490 := TRUE;
0007     M1 := FALSE;
0008 END_IF;

```

**Explanation**

1. When M0 is ON, Y0.0 and Y0.2 outputs 1000 pulses at 1kHz simultaneously. When M1 is ON, it indicates Y0.0 and Y0.2 are used for high-speed pulse output.
2. When the Y0.0 pulse output is completed, SM461 is ON. When the Y0.2 pulse output is completed, SM481 is ON. And if M1 is also ON, it triggers SM470 (output completion auto-reset for Y0.0) and SM490 (output completion auto-reset for Y0.2) to be ON. Y0.0 and Y0.2 are free and ready to be used again and M1 is cleared to OFF.
3. When M0 switches from OFF to ON, the pulse output is restarted.
4. When there are more than two high-speed output instructions in a program, do not use the variable name, M1, repeatedly.
5. It is suggested not to use ST language in a program if there is any chance the outputting needed to be stopped.


API	Instruction			Operand							Description			
2711	D	PPMA		<b>S<sub>1</sub>, S<sub>2</sub>, S<sub>3</sub>, D<sub>1</sub>, D<sub>2</sub></b>							2-Axis absolute-coordinate point-to-point synchronized motion			

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
<b>S<sub>1</sub></b>							●	●	●		○		○	○		
<b>S<sub>2</sub></b>							●	●	●		○		○	○		
<b>S<sub>3</sub></b>							●	●	●		○		○	○		
<b>D<sub>1</sub></b>		○														
<b>D<sub>2</sub></b>		○														

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
<b>S<sub>1</sub></b>			●				●						
<b>S<sub>2</sub></b>			●				●						
<b>S<sub>3</sub></b>			●				●						
<b>D<sub>1</sub></b>	●												
<b>D<sub>2</sub></b>	●												

Pulse Instruction	16-bit instruction	32-bit instruction
—	—	AS

**Symbol**




- S<sub>1</sub>** : Number of output pulses for the X axis
- S<sub>2</sub>** : Number of output pulses for the Y axis
- S<sub>3</sub>** : Maximum point-to-point output frequency
- D<sub>1</sub>** : Pulse output device for the X axis
- D<sub>2</sub>** : Pulse output device for the Y axis

**Explanation**

1. This instruction performs 2-axis absolute-coordinate point-to-point synchronized motion. **S<sub>1</sub>** and **S<sub>2</sub>** specify the number of output pulses (absolute positioning) for the X and Y axes.
2. For more information, refer to the DPPMR instruction (API 2710).


**Example**


1. Draw a rhombus as in the figure below.



2. Steps:

- Set the four coordinates (-27000, -27000), (0, -55000), (27000, -27000) and (0, 0) as in the figure above. Place them in the 32-bit registers (D200, D202), (D204, D206), (D208, D210), (D212, D214).
- RUN the program in the PLC. Set M0 to ON to start the 2-axis line drawing.





3. Operation:

6

When PLC runs the program and M0 is ON, the PLC starts the first point-to-point motion at 100 kHz. D0 increments by 1 whenever a point-to-point motion completes and the second point-to-point motion starts to execute automatically. The operation pattern repeats until the fourth point-to-point motion completes.


API	Instruction			Operand								Description				
2712	D	CICR		<b>S<sub>1</sub>, S<sub>2</sub>, S<sub>3</sub>, S<sub>4</sub>, S<sub>5</sub>, D<sub>1</sub>, D<sub>2</sub></b>								2-Axis relative-position clockwise arc interpolation				

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
<b>S<sub>1</sub></b>							●	●	●		○		○	○		
<b>S<sub>2</sub></b>							●	●	●		○		○	○		
<b>S<sub>3</sub></b>							●	●	●		○		○	○		●
<b>S<sub>4</sub></b>							●	●	●		○		○	○		
<b>S<sub>5</sub></b>							●	●	●		○		○	○		
<b>D<sub>1</sub></b>		○														
<b>D<sub>2</sub></b>		○														

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
<b>S<sub>1</sub></b>			●				●						
<b>S<sub>2</sub></b>			●				●						
<b>S<sub>3</sub></b>			●				●		●				
<b>S<sub>4</sub></b>			●				●						
<b>S<sub>5</sub></b>			●				●						
<b>D<sub>1</sub></b>	●												
<b>D<sub>2</sub></b>	●												

Pulse Instruction	16-bit instruction	32-bit instruction
—	—	AS

**Symbol**



- S<sub>1</sub>** : X axis target coordinate (relative positioning)
- S<sub>2</sub>** : Y axis target coordinate (relative positioning)
- S<sub>3</sub>** : The shift of the center or the central angle
- S<sub>4</sub>** : Target reference frequency
- S<sub>5</sub>** : Function selection
- D<sub>1</sub>** : Pulse output device for the X axis
- D<sub>2</sub>** : Pulse output device for the Y axis

**Explanation**

1. **S<sub>1</sub>**, **S<sub>2</sub>** and **S<sub>3</sub>** respectively designate the X axis target coordinate, Y axis target coordinate (relative position) and the shift of the center or a central angle of a circle. Refer to the following clockwise arc operation for details.
2. **D<sub>1</sub>** and **D<sub>2</sub>** are the pulse output devices for the X and Y axes respectively. Refer to the DPPMR instruction (API 2710) for the selection of output points and output modes for the axes.


3. **S<sub>4</sub>** sets the target frequency for the reference. The target reference frequency is used for the prior calculation when the PLC plans the travel path for the arc after the instruction is executed. But if the estimated calculation process cannot achieve the arc travel path, the output frequency is automatically decreased to fulfill the synchronized arc drawing function.
4. **S<sub>5</sub>** is the setting value for function selection. See the descriptions below.

Setting value in <b>S<sub>5</sub></b>	<b>S<sub>3</sub></b> : The shift of the center or central angle	Description
0	Shift of the center (32-bit integer type)	The arc resolution uses a 10° arc as the basic angle for motion.
1	Shift of the center (32-bit integer type)	The arc resolution uses a 5° arc as the basic angle for motion.
2	Shift of the center (32-bit integer type)	The arc resolution uses a 1° arc as the basic angle for motion. (FW V1.04.60 or later)
10	Shift of central angle (floating point type)	The arc resolution uses a 10° arc as the basic angle for motion. (FW V1.04.40 or later)
11	Shift of central angle (floating point type)	The arc resolution uses a 5° arc as the basic angle for motion. (FW V1.04.40 or later)
12	Shift of central angle (floating point type)	The arc resolution uses a 1° arc as the basic angle for motion. (FW V1.04.60 or later)
20	Invalid	The arc resolution uses a 10° arc as the basic angle for motion to create a 90 degree arc of an ellipse and to end at a point where X and Y axes target coordinates specified. (FW V1.10.10 or later)
21	Invalid	The arc resolution uses a 5° arc as the basic angle for motion to create a 90 degree arc of an ellipse and to end at a point where X and Y axes target coordinates specified. (FW V1.10.10 or later)
22	Invalid	The arc resolution uses a 1° arc as the basic angle for motion to create a 90 degree arc of an ellipse and to end at a point where X and Y axes target coordinates specified. (FW V1.10.10 or later)
Other	Shift of the center (32-bit integer type)	Seen as setting value in <b>S<sub>5</sub></b> is 0 The arc resolution uses a 10° arc as the basic angle for motion.

5. Refer to Example 2 of the DPPMR instruction for more details on ST language programming.



### Drawing a clockwise arc (for Setting values 0~12 in $S_5$ )

1. Define the four quadrants (QI, QII, QIII and QIV) of a coordinate system as in the graph below. Point A indicates the current coordinates on the X and Y axes.




2. Point B is the target coordinates specified by  $S_1$  and  $S_2$ . Point O is the center of a circle enclosing both point A and point B.
3. For PLC with FW V1.04.59 or previous versions,  $S_3$  is the distance to shift the center point O. For PLC with FW V1.04.60 or later,  $S_3$  can also be the distance to shift the center point or central angle, if it is defined as the central angle, it is the included angle of AOB.
4. The point A represents the origin of the axes X and Y in a plane. The target point B can be in Quadrant I, II, III, IV of the plane. Use the target point B to connect to the point A to draw a line and then use the setting values (shift the center point or central angle) in  $S_3$  to define an arc travel path.


The figures below show 2 arc-travel path examples (solid lines) when the point B is in Quadrant I and IV with different setting values in  $S_3$  (shift the center point). (r: radius)



5. The figures below show 2 arc-travel path examples (solid lines) when the point B is in Quadrant I and IV with different setting values in  $S_3$  (shift the central angle). ( $r$ : radius)




$S_3 \leq 180.0$




$S_3 > 180.0$

6. The figures below show 2 arc-travel path examples (solid lines) when the point B is in Quadrant II and III with different setting values in  $S_3$  (shift the center point). ( $r$ : radius)




$S_3 \geq 0$




$S_3 < 0$

7. The figures below show 2 arc-travel path examples (solid lines) when the point B is in Quadrant II and III with different setting values in  $S_3$  (shift the central angle). ( $r$ : radius)



$S_3 \leq 180.0$




$S_3 > 180.0$


8. When the point B is at a point where the value in X axis is 0 and the value is  $\geq$  in Y axis, the point B is in Quadrant I. While if the point B is at a point where the value in X axis is 0 and the value is  $< 0$  in Y axis, the point B is in Quadrant III.

**Drawing a 90 degree clockwise arc (for Setting values 20–22 in S<sub>5</sub>) for AS Series CPU FW V1.10.10 or later**

1. Define the four quadrants (QI, QII, QIII and QIV) of a coordinate system as in the graph below.




2. Use the values in  $S_1$  (X axis target coordinate) and in  $S_2$  (Y axis target coordinate) to identify the target position in one of the following four quadrants.



3. Since the distances between the starting positions and the target positions in the X and Y axes are not the same, and the travel path will be formed by a 90 degree arc of an ellipse. This function is useful for applications that draw elliptical arcs.

**Example**


1. Draw a DELTA LOGO as the figure below.




2. Steps: divide the logo into three parts.

- For an ellipse: use the DCICR instruction for the relative-position clockwise arc interpolation.
- The absolute coordinates of the ellipse: P1 (39930, -9982) , P2 (-9982, 39930) , P3 (73206, 123119) and P4 (123119, 73206) .
- Taking (39930, -9982) as the starting point, yields these relative coordinates: (-49912, 49912) , (83188, 83189) , (49913, -49913) and (-83189, -83188) .

6





When the PLC runs the program and M1 is ON, the PLC starts drawing the first segment of the arc. D1 increments by one when a segment of arc is completed and the second segment of the arc starts to automatically execute. This operation pattern repeats until the fourth segment of arc is completed.


When D1=1, using DCICR, the PLC draws the first-segment arc from P1 to P2 with the shift of the center of the circle: 18825 and arc resolution: 5.

When D1=2, using DCICR, the PLC draws the second-segment arc from P2 to P3 with the shift of the center of the circle: 110295 and arc resolution: 5.

When D1=3, using DCICR, the PLC draws the third-segment arc from P3 to P4 with the shift of the center of the circle: 18825 and arc resolution: 5.


When D1=4, using DCICR, PLC draws the fourth-segment arc from P4 to P1 with the shift of the center of the circle: 110295 and arc resolution: 5.

- For a circle = use DCCMR instruction (API 2716) for the relative-position circle drawing.
- The absolute coordinates of the circle: P5 (86213, 15435) and P6 (103048, 37425) . Taking (86213, 15435) as the starting point, yields the relative coordinates for the center of the circle as (16835, 21990) .




When the PLC runs the program and M2 is ON, the PLC starts to draw the relative-position circle with the target reference frequency of 20 kHz.

- For a delta, use DPPMA (API 2711) for the absolute-position 2-axis synchronized motion.
- Absolute coordinates of the delta= starting point P7 (-80360, 23641), P8 (208552, -23641) and P9 (62096, 206884).



6



When the PLC runs the program and M0 is ON, the PLC starts drawing the first segment of the 2-axis synchronized motion at 50 kHz. D1 increments by one when a segment of the 2-axis synchronized motion completes and the second segment of 2-axis synchronized motion starts to automatically execute. The operation pattern repeats until the third segment of 2-axis synchronized motion completes.

When D1=1, the PLC starts to draw the line from P7 to P8 with the DPPMA instruction.

When D1=2, the PLC starts to draw the line from P8 to P9 with the DPPMA instruction.

When D1=3, the PLC starts to draw the line from P9 to P7 with the DPPMA instruction.

API	Instruction			Operand								Description				
2713	D	CICA		<b>S<sub>1</sub>, S<sub>2</sub>, S<sub>3</sub>, S<sub>4</sub>, S<sub>5</sub>, D<sub>1</sub>, D<sub>2</sub></b>								2-Axis absolute-position clockwise arc interpolation				

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
<b>S<sub>1</sub></b>							●	●	●		○		○	○		
<b>S<sub>2</sub></b>							●	●	●		○		○	○		
<b>S<sub>3</sub></b>							●	●	●		○		○	○		○
<b>S<sub>4</sub></b>							●	●	●		○		○	○		
<b>S<sub>5</sub></b>							●	●	●		○		○	○		
<b>D<sub>1</sub></b>		○														
<b>D<sub>2</sub></b>		○														

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
<b>S<sub>1</sub></b>			●				●						
<b>S<sub>2</sub></b>			●				●						
<b>S<sub>3</sub></b>			●				●		●				
<b>S<sub>4</sub></b>			●				●						
<b>S<sub>5</sub></b>			●				●						
<b>D<sub>1</sub></b>	●												
<b>D<sub>2</sub></b>	●												

Pulse Instruction	16-bit instruction	32-bit instruction
—	—	AS

6

Symbol

DCICA	
En	
S1	D1
S2	D2
S3	
S4	
S5	

- S<sub>1</sub>** : X axis target coordinate (absolute positioning)
- S<sub>2</sub>** : Y axis target coordinate (absolute positioning)
- S<sub>3</sub>** : The shift of the center or the central angle
- S<sub>4</sub>** : Target reference frequency
- S<sub>5</sub>** : Function
- D<sub>1</sub>** : Pulse output device for the X axis
- D<sub>2</sub>** : Pulse output device for the Y axis

Explanation

- This instruction performs 2-axis absolute-position clockwise arc interpolation. **S<sub>1</sub>** and **S<sub>2</sub>** respectively designate the X- and Y-axis target coordinates. For more explanation, refer to DCICR instruction (API 2712).
- Refer to Example 2 from the DPPMR instruction (API 2710) for programming in ST language.


API	Instruction			Operand								Description					
2714	D	CICCR		<b>S<sub>1</sub>, S<sub>2</sub>, S<sub>3</sub>, S<sub>4</sub>, S<sub>5</sub>, D<sub>1</sub>, D<sub>2</sub></b>								2-Axis relative-position counterclockwise arc interpolation					

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
S <sub>1</sub>							●	●	●		○		○	○		
S <sub>2</sub>							●	●	●		○		○	○		
S <sub>3</sub>							●	●	●		○		○	○		○
S <sub>4</sub>							●	●	●		○		○	○		
S <sub>5</sub>							●	●	●		○		○	○		
D <sub>1</sub>		○														
D <sub>2</sub>		○														

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
S <sub>1</sub>			●				●						
S <sub>2</sub>			●				●						
S <sub>3</sub>			●				●		●				
S <sub>4</sub>			●				●						
S <sub>5</sub>			●				●						
D <sub>1</sub>	●												
D <sub>2</sub>	●												

Pulse Instruction	16-bit instruction	32-bit instruction
—	—	AS

Symbol



- S<sub>1</sub> : X axis target coordinate (relative positioning)
- S<sub>2</sub> : Y axis target coordinate (relative positioning)
- S<sub>3</sub> : The shift of the center or the central angle
- S<sub>4</sub> : Target reference frequency
- S<sub>5</sub> : Function
- D<sub>1</sub> : Pulse output device for the X axis
- D<sub>2</sub> : Pulse output device for the Y axis

## Explanation

1. This instruction performs 2-axis relative-position clockwise arc interpolation. **S<sub>1</sub>**, **S<sub>2</sub>** and **S<sub>3</sub>** respectively designate the target coordinate on X axis, target coordinate on Y axis, and the shift of the center of a circle. Refer to the following operation for drawing the counterclockwise arc for details.
2. **D<sub>1</sub>** and **D<sub>2</sub>** are the output devices for the X and Y axes respectively. Refer to the DPPMR instruction (API 2710) for the selection of output points and output mode for the axes.
3. **S<sub>4</sub>** sets the target frequency for the reference. The target reference frequency is used for the prior calculation when the PLC plans the travel path for the arc, after the instruction is executed. If the estimated calculation process cannot achieve the planned arc travel path, the output frequency is automatically decreased so as to fulfill the synchronized arc drawing function.
4. **S<sub>5</sub>** is the setting value for function selection. See the descriptions below.


Setting value in <b>S<sub>5</sub></b>	<b>S<sub>3</sub></b> : The shift of the center or central angle	Description
0	Shift of the center (32-bit integer type)	The arc resolution uses a 10° arc as the basic angle for motion.
1	Shift of the center (32-bit integer type)	The arc resolution uses a 5° arc as the basic angle for motion.
2	Shift of the center (32-bit integer type)	The arc resolution uses a 1° arc as the basic angle for motion. (FW V1.04.60 or later)
10	Shift of central angle (floating point type)	The arc resolution uses a 10° arc as the basic angle for motion. (FW V1.04.40 or later)
11	Shift of central angle (floating point type)	The arc resolution uses a 5° arc as the basic angle for motion. (FW V1.04.40 or later)
12	Shift of central angle (floating point type)	The arc resolution uses a 1° arc as the basic angle for motion. (FW V1.04.60 or later)
20	Invalid	The arc resolution uses a 10° arc as the basic angle for motion to create a 90 degree arc of an ellipse and to end at a point where X and Y axes target coordinates specified. (FW V1.10.10 or later)
21	Invalid	The arc resolution uses a 5° arc as the basic angle for motion to create a 90 degree arc of an ellipse and to end at a point where X and Y axes target coordinates specified. (FW V1.10.10 or later)
22	Invalid	The arc resolution uses a 1° arc as the basic angle for motion to create a 90

		degree arc of an ellipse and to end at a point where X and Y axes target coordinates specified. (FW V1.10.10 or later)
Other	Shift of the center (32-bit integer type)	Seen as setting value in $S_5$ is 0 The arc resolution uses a $10^\circ$ arc as the basic angle for motion.

- Refer to Example 2 from the DPPMR instruction (API 2710) for programming in ST language.


**Drawing the counterclockwise arc (for Setting values 0~12 in  $S_5$ )**

- Define the four quadrants (QI, QII, QIII and QIV) of a coordinate system as below. Point A indicates the current coordinates on X and Y axes.




- Point B is the target coordinates specified by  $S_1$  and  $S_2$ . Point O is the center of a circle containing points A and B.
- For PLC with FW V1.04.59 or previous versions,  $S_3$  is the distance to shift the center point O. For PLC with FW V1.04.60 or later,  $S_3$  can also be the distance to shift the center point or central angle, if it is defined as the central angle, it is the included angle of AOB.
- The point A represents the origin of the axes X and Y in a plane. The target point B can be in Quadrant I, II, III, IV of the plane. Use the target point B to connect to the point A to draw a line and then use the setting values (shift the center point or the central angle) in  $S_3$  to define an arc travel path.


The figures below show 2 arc-travel path examples (solid lines) when the point B is in Quadrant I and IV with different setting values in  $S_3$  (shift the center point). (r: radius)



5. The figures below show 2 arc-travel path examples (solid lines) when the point B is in Quadrant I and IV with different setting values in  $S_3$  (shift the central angle). ( $r$ : radius)




$S_3 \leq 180.0$




$S_3 > 180.0$

6. The figures below show 2 arc-travel path examples (solid lines) when the point B is in Quadrant II and III with different setting values in  $S_3$  (shift the center point). ( $r$ : radius)




$S_3 \geq 0$




$S_3 < 0$

7. The figures below show 2 arc-travel path examples (solid lines) when the point B is in Quadrant II and III with different setting values in  $S_3$  (shift the central angle). ( $r$ : radius)



$S_3 \leq 180.0$




$S_3 > 180.0$


8. When the point B is at a point where the value in X axis is 0 and the value is  $\geq$  in Y axis, the point B is in Quadrant I. While if the point B is at a point where the value in X axis is 0 and the value is  $< 0$  in Y axis, the point B is in Quadrant III.

**Drawing a 90 degree counterclockwise arc (for Setting values 20~22 in S<sub>5</sub>) for AS Series CPU FW V1.10.10 or later**

1. Define the four quadrants (QI, QII, QIII and QIV) of a coordinate system as in the graph below.




2. Use the values in **S<sub>1</sub>** (X axis target coordinate) and in **S<sub>2</sub>** (Y axis target coordinate) to identify the target position in one of the following four quadrants.



3. Since the distances between the starting positions and the target positions in the X and Y axes are not the same, and the travel path will be formed by a 90 degree arc of an ellipse. This function is useful for applications that draw elliptical arcs.

**Example**


1. Draw a DELTA LOGO as the figure below.




2. Steps: divide the logo into three parts.

- For an ellipse: use the DCICCR instruction (API 2712) for the relative-position counterclockwise arc interpolation.
- The absolute coordinates of the ellipse: P1(39930, -9982), P4 (123119, 73206), P3 (73206, 123119) and P2 (-9982, 39930)
- Taking (39930, -9982) as the start point, the obtained relative coordinates: (83189, 83188), (-49913, 49913), (-83188, -83189) and (49912, -49912).

6





When the PLC runs the program and M1 is ON, the PLC starts drawing the first segment of the clockwise arc at 50kHz. D1 increments by 1 when a segment of arc is completed and the second segment of arc starts to automatically execute. The operation pattern repeats until the fourth segment of arc is completed.

When D1=1, using DCICCR, the PLC draws the first-segment arc from P1 to P4 with the shift of the center of the circle: -110295 and arc resolution: 5.

When D1=2, using DCICCR, the PLC draws the second-segment arc from P4 to P3 with the shift of the center of the circle: -18825 and arc resolution: 5.

When D1=3, using DCICCR, the PLC draws the third-segment arc from P3 to P2 with the shift of the center of the circle: -110295 and arc resolution: 5.

When D1=4, using DCICCR, the PLC draws the fourth-segment arc from P2 to P1 with the shift of the center of the circle: -18825 and arc resolution: 5.

- A circle = use DCCMR instruction (API 2716) for the relative-position circle drawing. Refer to the example in API 2712 DCICR for detailed operation.
- A delta = use DPPMA (APIU 2711) for the absolute-position 2-axis synchronized motion. Refer to the example in DCICR (API 2712) for more information.


API	Instruction			Operand								Description				
2715	D	CICCA		<b>S<sub>1</sub>, S<sub>2</sub>, S<sub>3</sub>, S<sub>4</sub>, S<sub>5</sub>, D<sub>1</sub>, D<sub>2</sub></b>								2-Axis absolute-position counterclockwise arc interpolation				

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
<b>S<sub>1</sub></b>							●	●	●		○		○	○		
<b>S<sub>2</sub></b>							●	●	●		○		○	○		
<b>S<sub>3</sub></b>							●	●	●		○		○	○		○
<b>S<sub>4</sub></b>							●	●	●		○		○	○		
<b>S<sub>5</sub></b>							●	●	●		○		○	○		
<b>D<sub>1</sub></b>		○														
<b>D<sub>2</sub></b>		○														

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
<b>S<sub>1</sub></b>			●				●						
<b>S<sub>2</sub></b>			●				●						
<b>S<sub>3</sub></b>			●				●		●				
<b>S<sub>4</sub></b>			●				●						
<b>S<sub>5</sub></b>			●				●						
<b>D<sub>1</sub></b>	●												
<b>D<sub>2</sub></b>	●												

Pulse Instruction	16-bit instruction	32-bit instruction
—	—	AS

**Symbol**



- S<sub>1</sub>** : X axis target coordinate (absolute positioning)
- S<sub>2</sub>** : Y axis target coordinate (absolute positioning)
- S<sub>3</sub>** : The shift of the center or the central angle
- S<sub>4</sub>** : Target reference frequency
- S<sub>5</sub>** : Function
- D<sub>1</sub>** : Pulse output device for the X axis
- D<sub>2</sub>** : Pulse output device for the Y axis

**Explanation**

- S<sub>1</sub>** and **S<sub>2</sub>** respectively designate the target coordinate on the X axis and the target coordinate on the Y axis. For an explanation of the instruction, refer to DCICCR instruction (API 2714).
- Refer to Example 2 from the DPPMR instruction (API 2710) for programming in ST language.

API	Instruction			Operand								Description				
2716	D	CCMR		<b>S<sub>1</sub>, S<sub>2</sub>, S<sub>3</sub>, S<sub>4</sub>, D<sub>1</sub>, D<sub>2</sub></b>								Relative-position circle drawing				

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
<b>S<sub>1</sub></b>							●	●	●		○		○	○		
<b>S<sub>2</sub></b>							●	●	●		○		○	○		
<b>S<sub>3</sub></b>							●	●	●		○		○	○		
<b>S<sub>4</sub></b>							●	●	●		○		○	○		
<b>D<sub>1</sub></b>		○														
<b>D<sub>2</sub></b>		○														

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
<b>S<sub>1</sub></b>			●				●						
<b>S<sub>2</sub></b>			●				●						
<b>S<sub>3</sub></b>			●				●						
<b>S<sub>4</sub></b>			●				●						
<b>D<sub>1</sub></b>	●												
<b>D<sub>2</sub></b>	●												

Pulse Instruction	16-bit instruction	32-bit instruction
—	—	AS

**Symbol**

DCCMR	
En	
S1	D1
S2	D2
S3	
S4	

- S<sub>1</sub>** : X axis coordinate of the center (relative positioning)
- S<sub>2</sub>** : Y axis coordinate of the center (relative positioning)
- S<sub>3</sub>** : Function selection
- S<sub>4</sub>** : Target reference frequency
- D<sub>1</sub>** : Pulse output device for the X axis
- D<sub>2</sub>** : Pulse output device for the Y axis

**Explanation**



1. This instruction draws a circle based on relative positioning. **S<sub>1</sub>** and **S<sub>2</sub>** are respectively the X and Y axis coordinates of the center of a circle (relative position).
2. **S<sub>3</sub>** is the setting value for function selection. See the descriptions below.

<b>S<sub>3</sub></b> : Function Selection	Descriptions
0	The arc resolution uses a 10° arc as the basic angle for clockwise motion.
1	The arc resolution uses a 5° arc as the basic angle for clockwise motion.
2	The arc resolution uses a 10° arc as the basic angle for counterclockwise motion.
3	The arc resolution uses a 5° arc as the basic angle for counterclockwise motion.
4	The arc resolution uses a 1° arc as the basic angle for clockwise motion. (FW V1.04.60 or later)
5	The arc resolution uses a 1° arc as the basic angle for counterclockwise motion. (FW V1.04.60 or later)
Other	Seen as setting value in <b>S<sub>3</sub></b> is 0  The arc resolution uses a 1° arc as the basic angle for clockwise motion.



3. **D<sub>1</sub>** and **D<sub>2</sub>** are the pulse output devices for the X and Y axes respectively. Refer to DPPMR instruction (API 2710) for the selection of output points and output mode for the axes.
4. **S<sub>4</sub>** sets the target frequency for the reference. The target reference frequency is used for the prior calculation when the PLC plans the travel path for the arc after the instruction is executed. But if the calculation process which is estimated cannot achieve the planned arc travel path, the output frequency is automatically decreased to fulfill the synchronized arc drawing function.
5. When the X axis coordinate of the center point **O=0**, point **O** is defined as the point staying in QI of point **A** if Y axis target coordinate  $\geq 0$ . Whereas, if Y axis target coordinate  $< 0$ , point **B** is defined as the point staying in QIII of point **A**.
6. Refer to Example 2 from the DPPMR instruction (API 2710) for programming in ST language.

**The clockwise circle drawing:**

Point A is the present position and point O is the target center, r is the radius of the circle as the figures below.




**The counterclockwise circle drawing:**




**Example**

1. Taking (40000, 50000) as the center O and (10000, 10000) as point A, draw a circle as shown below.



2. Steps:

- The calculated relative coordinates of point O: (30000, 40000)
- The coordinates of point A is the present position; SR460=10000 and SR480=10000
- S<sub>3</sub>=1 and the clockwise circle drawing is performed with a 5° as the basic motion angle.
- When the PLC runs the program and M0 is set to ON, the relative-position circle drawing starts.



3. Operation:

- When the PLC runs the program and M0 is ON, the PLC starts to draw the circle in the clockwise direction at 100 kHz.
- When the circle drawing completes, SM461 and SM481 are ON.


API	Instruction			Operand								Description				
2717	D	CCMA		<b>S<sub>1</sub>, S<sub>2</sub>, S<sub>3</sub>, S<sub>4</sub>, D<sub>1</sub>, D<sub>2</sub></b>								The absolute-position circle drawing				

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
<b>S<sub>1</sub></b>							●	●	●		○		○	○		
<b>S<sub>2</sub></b>							●	●	●		○		○	○		
<b>S<sub>3</sub></b>							●	●	●		○		○	○		
<b>S<sub>4</sub></b>							●	●	●		○		○	○		
<b>D<sub>1</sub></b>		○														
<b>D<sub>2</sub></b>		○														

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
<b>S<sub>1</sub></b>			●				●						
<b>S<sub>2</sub></b>			●				●						
<b>S<sub>3</sub></b>			●				●						
<b>S<sub>4</sub></b>			●				●						
<b>D<sub>1</sub></b>	●												
<b>D<sub>2</sub></b>	●												

Pulse Instruction	16-bit instruction	32-bit instruction
—	—	AS

**Symbol**




- S<sub>1</sub>** : X axis coordinate of the center (absolute positioning)
- S<sub>2</sub>** : Y axis coordinate of the center (absolute positioning)
- S<sub>3</sub>** : Function selection
- S<sub>4</sub>** : Target frequency
- D<sub>1</sub>** : Pulse output device for the X axis
- D<sub>2</sub>** : Pulse output device for the Y axis

**Explanation**

1. **S<sub>1</sub>** and **S<sub>2</sub>** are respectively the X and Y axis coordinates of the center of a circle (absolute positioning). For more information, refer to the DCCMR instruction (API 2716).
2. Refer to Example 2 from the DPPMR instruction (API 2710) for programming in ST language.


**Example**

1. Taking (40000, 50000) as the center O and (10000, 10000) as point A, draw a circle as shown below.



3. Steps:

- Set the absolute X coordinate and Y coordinate (40000, 50000) in the instruction
- Point A is the present position, SR460=10000 and SR480=10000
- S<sub>3</sub> is 1 and the clockwise circle is drawn with 5° as the basic motion angle.
- When the PLC runs the program and M0 is ON, the absolute-position circle drawing starts.



4. Operation:

- When the PLC runs the program and M0 is ON, the PLC starts to draw the circle in the clockwise direction at 100 kHz.
- When the circle drawing completes, SM461 and SM481 are ON.


API	Instruction		Operand				Description
2718	TPO		<b>S, D<sub>1</sub>, D<sub>2</sub></b>				Position planning table controls the output

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
<b>S</b>								●				○	○	○		
<b>D<sub>1</sub></b>								●								
<b>D<sub>2</sub></b>		●	●	●				●								

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
<b>S</b>		●				●							
<b>D<sub>1</sub></b>		●				●							
<b>D<sub>2</sub></b>	●												

Pulse Instruction	16-bit instruction	32-bit instruction
—	AS	-

**Symbol**



- S** : The first output number in the position planning table
- D<sub>1</sub>** : The output number that is being output
- D<sub>2</sub>** : Switch flag at the end of the consecutive-number output


**Explanation:**

- This instruction uses the position planning table to control the output. **S** is the number listed in the position planning table. If the number does not exist in the table, the instruction is not executed, SM0 is ON and the error code is SR0=16#2027.

No.	Axis No.	Output	ABS/REL mode	Target position	Target speed	Bias speed(Vbi...	Acceleratio
1	Axis 1	Pulse	Reletive	1000000	100000	1000	3000

- S** is the first output number when PLC runs. Refer to the value in **D<sub>1</sub>** if there are consecutive-number outputs during the output.
- When one single number or the first one of consecutive numbers is output, the switch flag **D<sub>2</sub>** is set to OFF. When the consecutive-number output reaches the output number to be switched to, **D<sub>2</sub>** is ON for a scan cycle and then is ON again until the last number output is completed.

The example and timing diagram for the flag state switching are shown below.




4. The switch flag **D<sub>2</sub>** is affected by the PLC scan time. If the time for switching to the next output number is shorter than the scan time, the flag for switching to the output number may not reset to OFF.
5. The instruction cannot be used in the ST programming language, interrupt tasks or function block which is called only once.
6. If using the function Single-axis multi-segment motion and the firmware is below V1.07.10, you cannot use the stop flag during output. If you need to stop outputting, use this instruction instead.
7. For firmware V1.08.00 or later, you can use the stop flag during output to stop the output. If you use the stop flag and this instruction, it will stop output after this segment is done outputting. For example, supposing the segments are 1, 2 and 3 for output in a consecutive order and you use the stop flag while outputting segment 2. The system will complete outputting segment 2 and then after you switch the stop flag to OFF, the execution of this instruction will resume in the segment 3.
8. If using the function Single-axis point-to-point motion to output, and using the stop flag during the output, this instruction will stop execution and resume execution and output the remainings after the stop flag is OFF.
9. If using the function 2-axis arc interpolation, and using the stop flag during the output, this instruction will stop execution after one basic unit of arc interpolation (1 degree) and this instruction resumes execution after the stop flag is OFF, and output the remainings.
10. For firmware V1.12.10 or later, it is supported to stop the ongoing output sequence and start a new one during the execution of TPO instruction. When the relevant SM changes to ON, the PLC CPU will act according to the settings in the relevant SR to output a specific number of segment or the next segment on the positioning table. Two scenarios:
  - A. If the relevant SM changes to ON and the value in SR1291-SR1296 is valid, the PLC CPU will act accordingly to output a specific number of segment on the positioning table. After that, the PLC CPU clears the relevant SM and SR.
  - B. If the relevant SM changes to ON but the value in SR1291-SR1296 is 0 or NOT a valid value or the positioning table does NOT exist, the PLC CPU will stop outputting. After you clear the relevant SM, the PLC CPU will continue outputting the next segment on the positioning table.

The corresponding axis, SM and SR numbers

Axis for output	Flag to stop the ongoing output sequency	Specific number of segment
Axis 1 (Y0.0/Y0.1)	SM591	SR1291
Axis 2 (Y0.2/Y0.3)	SM592	SR1292
Axis 3 (Y0.4/Y0.5)	SM593	SR1293
Axis 4 (Y0.6/Y0.7)	SM594	SR1294
Axis 5 (Y0.8/Y0.9)	SM595	SR1295
Axis 6 (Y0.10/Y0.11)	SM596	SR1296

**Example 1:**

1. Enable the mechanical unit conversion function




2. Set the position planning table and download the parameters

The target position is 2000 (Unit:mm). After converting in the position planing table, 400,000 output pulses are downloaded and saved in the PLC.

No.	Axis ...	ABS/REL mode	Target position	Target speed(Hz)	Bias speed(Vbi...	Acceleration ti...
1	Axis 1	Relative	2000	100000	200	200

When M0 is ON, Y0.0 outputs 400,000 pulses at 100kHz. After the output completes, M100 is ON.




**Example 2: Use global symbol or D device in Target Position**

1. Use D device in Target Position of the position planning table and download the parameters.

The unit for D60 in PLC is pulse by default. If you need to use D devices in Target position and in the mechanical unit, you need to convert the mechanical unit to pulse.

No.	Axis ...	ABS/REL mode	Target position	Target speed(Hz)	Bias speed(Vbi...	Acceleration ti...
1	Axis 1	Relative(Symbol/Address)	D60	100000	200	200

- When M0 is ON, and D60 is 400,000. Y0.0 outputs 400,000 pulses at 100kHz. After the output completes, M100 is ON.



Note: the unit is pulse, when you use global symbols, D devices, or instructions including DTPWS, DTPWL, and DTPWC to input values in in Target Postion.

- If global symbols are used in Target Position
  - You need to assign an address for the global symbol.

Global Symbols				
Global Symbols				
Class	Identifiers	Address	Type...	Initial Value (Activ...
VAR	Target_Axis1	D60	DWORD	N/A

B. Use global symbols in Target Position of the planning table.

Single-axis point-to-point motion		Single-axis multi-segment motion		2-axis linear interpolation		2-axis arc interpolation	
No.	Axis ...	ABS/REL mode	Target position	Target speed(Hz)	Bias speed(Vbi...	Acceleration ti...	
1	Axis 1	Relative(Symbol/Address)	Target axis1	100000	200	200	

**Example 3: Use abort symbol and completion flag**

- Set up the positioning planning table as shown below.

Single-axis point-to-point motion		Single-axis multi-segment motion		2-axis linear interpolation		2-axis arc interpolation			
No.	Axis ...	ABS/REL mode	Target position	Target speed(Hz)	ACC/DEC time(ms)	Abort signal(I/M)	Completion action	Completion flag(I/M)	No. of next segment
3	Axis 1	Relative	10000	5000	300	M100	Go to next segment		4
4	Axis 1	Relative	15000	8000	100		Completion	M777	---

- Abort signal: When No. 3 stops the outputting abruptly, M100 is ON and the system starts to output No. 4 immediately.

The abort symbol is applicable for the following conditions: external interrupts, high-speed comparison interrupts and M devices (M0~8191).

- Completion flag: When No. 4 completes the outputting, M777 is ON. When the execution of this positioning planning table is complete, the system calls for an interrupt or starts a M device.

You can use the interupt numbers I510~519 and M device (M0~M8191) in the positioning planning table.


Note: If you use interrupts instead of M devices, PLC scan cycle is not affected.

**Example 4: Single-axis multi-segment motion**

1. Set up the positioning planning table as shown below.


Single-axis point-to-point motion		Single-axis multi-segment motion		2-axis linear interpolation		2-axis arc interpolation	
No.	Axis ...	ABS/REL mode	Target position	Target speed(Hz)	ACC/DEC time(...)	Abort signal(I/...	Completion acti...
1	Axis 1	Relative	200000	50000	200		Go to next segmer
2	Axis 1	Relative	400000	100000	200		Go to next segmer
3	Axis 1	Relative	600000	150000	200		Go to next segmer

2. When M0 is ON, Y0.0 outputs No.1 to No. 3 consecutively. After the output is done, M100 is ON.



1. Stop flag and immediately stop flag

- a) The following graphic shows the output diagram based on example 4.



- b) Ramp-down stop

- ① When M0 is ON, the TPO instruction is executed and starts to output No. 1 segment.
- ② When the stop flag SM463 is ON during the output of No.2 segment, the state of the immediately stop flag SM476 is confirmed.
- ③ If the immediately stop flag SM476 is OFF, the output ramps down to stop, according to the SR465 ramp-down time in axis 1, till the it drops to the lowest 1000 Hz frequency.
- ④ Output at the lowest 100Hz frequency and till the No. 2 output is complete and stopped. (pulse = 600 K)
- ⑤ After the stop flag SM463 switches to OFF, the execution of TPO instrucion starts outputting No.3 segment till the output is complete. (pulse = 1200 K)

c) Immediately stop

- ① When M0 is ON, the TPO instruction is executed and starts to output No. 1 segment.
- ② When the stop flag SM463 is ON during the output of No.2 segment, the state of the immediately stop flag SM476 is confirmed.
- ③ If the immediately stop flag SM476 is ON, the output stops after the No. 2 output is complete.  
(pulse = 600 K).
- ④ After the stop flag SM463 switches to OFF, the execution of TPO instruction starts outputting No.3 segment till the output is complete. (pulse = 1200 K)

API	Instruction			Operand								Description				
2719	D	TPWS	P	<b>S<sub>1</sub>, S<sub>2</sub>, S<sub>3</sub></b>								Setting single-axis output parameters in the position planning table				

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
<b>S<sub>1</sub></b>								●	●				○	○		
<b>S<sub>2</sub></b>								●	●				○	○		
<b>S<sub>3</sub></b>								●	●				○	○		

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
<b>S<sub>1</sub></b>			●				●						
<b>S<sub>2</sub></b>			●				●						
<b>S<sub>3</sub></b>			●				●						

Pulse Instruction	16-bit instruction	32-bit instruction
AS	-	AS

**Symbol**


DTPWS	
En	
S1	
S2	
S3	

DTPWSP	
En	
S1	
S2	
S3	

- S<sub>1</sub>** : A number listed in the position planning table
- S<sub>2</sub>** : Target position
- S<sub>3</sub>** : Target speed

**Explanation**

- This instruction sets the single-axis output parameters in the position planning table. **S<sub>1</sub>** is the number listed in the position planning table. If the number does not exist in the table, or the number is not under Single-axis point-to-point motion, or under Single-axis multi-segment motion, the instruction is not executed, SM0 is ON and the error code is SR0=16#2027.



- S<sub>2</sub>** is the target position (must be a 32-bit integer). If you use the mechanical unit conversion when editing the position planning table in ISPSOFT, use the conversion instruction for modification first.
- S<sub>3</sub>** is the target speed. The range is between 1–200,000Hz.  
 Note1: The maximum speed of the output axis Y0 and Y2 is 4 MHz for AS324MT.  
 Note2: if the setting value is out of the range, the instruction automatically changes the setting into the minimum or maximum value.
- When the instruction is executed to modify the parameters for the single axis which is outputting pulses, the modified parameters are kept in the table and are not effective until the next output starts.
- The parameters modified by the instruction can only be modified while the PLC is running. The last written parameter is not saved when the power turns OFF. The table that you edit in ISPSOFT and download to the PLC is processed as the default position planning table when the power is ON.

6. This instruction does NOT modify the acceleration or deceleration time. If you need to modify the time for acceleration or deceleration, you can set SM585 flag to ON. And then modify the acceleration and deceleration time set in SR to change the acceleration time in single-axis point-to-point motion and single-axis multi-segment motion or the deceleration time in single-axis point-to-point motion. Re-execute this instruction to actualize this modification. This function is available for PLC with FW V1.06.00.
7. While the TPO instruction is being executed, please be aware of the timing of modifying parameters via this instruction. It is suggested to avoid modifying the used number for the output that is being performed or is to be performed soon.

Example 1: Change the parameters of Axis 3 of Number 5 during execution in Single-axis point-to-point motion.

Single-axis point-to-point motion   Single-axis multi-segment motion   2-axis linear interpolation   2-axis arc interpolation										
No.	Axis ...	ABS/REL mode	Target position	Target speed(Hz)	Bias speed(Vbias)(Hz)	Acceleration time(Tacc)(ms)	Deceleration time(Tdec)(ms)	Completion action	Completion flag(I/M)	No. of next segment
1	Axis 2	Relative	1000	1000	100	100	200	Go to next segment		2
5	Axis 3	Relative	2000	2000	50	50	100	Completion		--

- 1) Use DMOV instruction to define new target position and target speed.
- 2) Use MOV instruction to define the start/end frequency in SR503, acceleration time in SR504 and deceleration time in SR505 for Axis 3. After that the relative parameters in single-axis point-to-point motion are updated.
- 3) Set the flag SM585 to ON.
- 4) Re-execute DTPWS instrucion to actualize the modification.
- 5) After that, SM585 switches to OFF automatically.

Example 2: Change the parameters of Axis 3 of Number 2 during execution in Single-axis multi-segment motion.

Single-axis point-to-point motion   Single-axis multi-segment motion   2-axis linear interpolation   2-axis arc interpolation										
No.	Axis ...	ABS/REL mode	Target position	Target speed(Hz)	ACC/DEC time(ms)	Abort signal(I/M)	Completion action	Completion flag(I/M)	No. of next segment	
2	Axis 3	Relative	1000	1000	100		Go to next segment		2	
3	Axis 3	Relative	2000	2000	50		Go to next segment		3	
4	Axis 3	Relative	1500	1500	2000		Completion	M100	--	

- 1) Use DMOV instruction to define new target position and target speed.
- 2) Use MOV instruction to define the acceleration time in SR504. After that the relative parameters in single-axis multi-segment motion are updated.
- 3) Set the flag SM585 to ON.
- 4) Re-execute DTPWS instrucion to actualize the modification.
- 5) After that, SM585 switches to OFF automatically.

API	Instruction			Operand								Description				
2720	D	TPWL	P	<b>S<sub>1</sub>, S<sub>2</sub>, S<sub>3</sub>, S<sub>4</sub></b>								Setting linear interpolation parameters in the position planning table				

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
<b>S<sub>1</sub></b>								●	●				○	○		
<b>S<sub>2</sub></b>								●	●				○	○		
<b>S<sub>3</sub></b>								●	●				○	○		
<b>S<sub>4</sub></b>								●	●				○	○		

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
<b>S<sub>1</sub></b>			●				●						
<b>S<sub>2</sub></b>			●				●						
<b>S<sub>3</sub></b>			●				●						
<b>S<sub>4</sub></b>			●				●						

Pulse Instruction	16-bit instruction	32-bit instruction
AS	-	AS

**Symbol**

DTPWL	DTPWLP
En	En
S1	S1
S2	S2
S3	S3
S4	S4

- S<sub>1</sub>** : A number listed in the position planning table
- S<sub>2</sub>** : Target position of the X axis
- S<sub>3</sub>** : Target position of the Y axis
- S<sub>4</sub>** : Target speed

**Explanation**

- This instruction sets the 2-axis linear interpolation parameters in the position planning table. **S<sub>1</sub>** is the number listed in the position planning table. If the number does not exist in the table or the output of the number does not belong to the 2-axis linear interpolation, the instruction is not executed, SM0 is ON and the error code is SR0=16#2027.

No.	Coord.	Axis No.	Output	ABS/REL mode	Target position	Target speed	ACC/DEC time
1	X	Axis 1	Pulse/Dir	Absolute	1000	50000	100
T1	Y	Axis 2	Pulse/Dir		-1000		

- S<sub>2</sub>** and **S<sub>3</sub>** are respectively the target positions of the X and Y axes, which can only be 32-bit integers. If you use the mechanical unit conversion when editing the position planning table in ISPSOft, use the conversion instruction for modification first.

3. **S<sub>4</sub>** is the target speed. The range is between 1–200,000Hz. (Note: if the setting value is out of the range, the instruction automatically changes the setting into the minimum or maximum value.)
4. When the instruction executes the linear interpolation, the target frequency **S<sub>4</sub>** automatically corresponds to the output of the axis which is farthest from its target position. If X axis and Y axis cannot simultaneous reach the target positions, the PLC automatically decelerates the frequency to make the two axes reach the target positions simultaneously.
5. When the instruction is executed to modify parameters for the two axes (either of which is outputting), the modified parameters of the two axes are kept in the table and are not effective until the next 2-axis output starts.
6. The parameters modified by the instruction can be modified only while the PLC is running. The last written parameter is not saved when the power turns OFF. The table that you edit in ISPSOft and download to the PLC is processed as the default position planning table when the power is ON.
7. To modify the acceleration/deceleration time, you should modify the acceleration/deceleration time in SR that the specified output axis of X axis corresponds to, set the flag SM585 to ON, and then execute this instruction. When changing relevant parameters is complete, SM585 will be automatically cleared and change to OFF.  
For example, if Y0.0 output axis is designated for X axis, you should modify the value in SR464 (acceleration time of Y0.0 output) to modify the acceleration/deceleration time. For details on operation steps, please refer to Example 1 of the TPWS instruction.

Note:

- The acceleration and deceleration time is only for the PLC operation of the 2-axis synchronized motion. If the simultaneous arrival to the target positions cannot be achieved after calculation, the PLC will automatically execute the instruction with the most proper acceleration/deceleration time and no error information will occur.
  - The function is available for PLC firmware version V1.12.00 and later.
8. While the TPO instruction is being executed, please be aware of the timing of modifying parameters via this instruction. It is suggested to avoid modifying the used number for the output that is being performed or is to be performed soon.

API	Instruction			Operand					Description				
2721	D	TPWC	P	<b>S<sub>1</sub>, S<sub>2</sub>, S<sub>3</sub>, S<sub>4</sub>, S<sub>5</sub></b>					Setting arc interpolation parameters in the position planning table				

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
<b>S<sub>1</sub></b>								●	●				○	○		
<b>S<sub>2</sub></b>								●	●				○	○		
<b>S<sub>3</sub></b>								●	●				○	○		
<b>S<sub>4</sub></b>								●	●				○	○		
<b>S<sub>5</sub></b>								●	●				○	○		

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
<b>S<sub>1</sub></b>			●				●						
<b>S<sub>2</sub></b>			●				●						
<b>S<sub>3</sub></b>			●				●						
<b>S<sub>4</sub></b>			●				●						
<b>S<sub>5</sub></b>			●				●						

Pulse Instruction	16-bit instruction	32-bit instruction
AS	-	AS

**Symbol**

DTPWC
En
S1
S2
S3
S4
S5

**S<sub>1</sub>** : A number listed in the position planning table

**S<sub>2</sub>** : X axis target position

**S<sub>3</sub>** : Y axis target position

**S<sub>4</sub>** : The shift of the center

DTPWCP
En
S1
S2
S3
S4
S5

**S<sub>5</sub>** : Target speed

**Explanation**

1. This instruction sets the 2-axis arc interpolation parameters in the position planning table. **S<sub>1</sub>** is the number listed in the position planning table. If the number does not exist in the table, or the output of the number does not belong to the 2-axis arc interpolation, the instruction is not executed, SM0 is ON and the error code is SR0=16#2027.

Single-axis point-to-point motion   Single-axis multi-segment motion   2-axis linear interpolation   2-axis arc interpolation							
No.	Coord.	Axis No.	Output	ABS/REL mode	Target position	Target speed	Center shift value
1	X	Axis 1	Pulse/Dir	Absolute	100000	15000	-50000
T1	Y	Axis 2	Pulse/Dir	Absolute	100000	15000	-50000

2. **S<sub>2</sub>** and **S<sub>3</sub>** are respectively the target position on the X and Y axes. **S<sub>4</sub>** is the distance to shift the center. The three parameters can only be 32-bit integers. If you use the mechanical unit conversion when editing the position planning table in ISPSOft, use the conversion instruction for modification first.
3. **S<sub>5</sub>** is the target speed. The range is between 1–200,000 Hz. It is the reference speed for the actual output. The PLC automatically decelerates the speed if the 2-axis synchronized output cannot be achieved.
4. When the instruction is executed to modify parameters for the two axes (either of which is outputting), the modified parameters of the two axes are kept in the table and are not effective until the next 2-axis output starts.
5. The parameters modified by the instruction can be modified only while the PLC is running. The last written parameter is not saved when the power turns OFF. The table that you edit in ISPSOft and downloaded to the PLC is processed as the default position planning table when the power is ON.
6. This instruction does not support changing the clockwise or counterclockwise motion direction. For direction change, add or modify the output parameters for arc interpolation in the position planning table in ISPSOft.
7. While the TPO instruction is being executed, please be aware of the timing of modifying parameters via this instruction. It is suggested to avoid modifying the used number for the output that is being performed or is to be performed soon.


API	Instruction			Operand								Description				
2723	D	PPGB		<b>S<sub>1</sub>, S<sub>2</sub>, S<sub>3</sub>, S<sub>4</sub>, D<sub>1</sub>, D<sub>2</sub></b>								Point-to-point go back and forth				

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
<b>S<sub>1</sub></b>								●								
<b>S<sub>2</sub></b>								●								
<b>S<sub>3</sub></b>								●								
<b>S<sub>4</sub></b>								●								
<b>D<sub>1</sub></b>		○														
<b>D<sub>2</sub></b>			●													

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
<b>S<sub>1</sub></b>			●				●						
<b>S<sub>2</sub></b>			●				●						
<b>S<sub>3</sub></b>			●				●						
<b>S<sub>4</sub></b>									●				
<b>D<sub>1</sub></b>	●												
<b>D<sub>2</sub></b>	●												

Pulse Instruction	16-bit instruction	32-bit instruction
—	-	AS


**Symbol**



- S<sub>1</sub>** : Relative target position A
- S<sub>2</sub>** : Relative target position B
- S<sub>3</sub>** : Target speed
- S<sub>4</sub>** : Target speed ratio adjusted value (floating point value)
- D<sub>1</sub>** : Pulse output device
- D<sub>2</sub>** : Target speed can change indicator

**Explanation**

- This high speed output instruction specifies a movement going back and forth between two target positions that are converted from the two relative target positions specified by **S<sub>1</sub>** and **S<sub>2</sub>**. This instruction is applicable for machines such as warping machines in the textile industry, and winding & binding machines in the cable industry.
- When the instruction starts the output, the relative positions **S<sub>1</sub>** and **S<sub>2</sub>** must be specified first so that the instruction can make the calculation for switching to the next output. After the instruction is executed, you can modify the target positions to execute, but you cannot change the outputting target positions.



① DPPGB instruction is executed. When  $S_1$  is 30,000 and  $S_2$  is -30,000, the motion goes toward the target position  $A1=30,000$ .

② If the pulse position  $>15,000$ , the relative positions are modified into  $S_1:20,000$  and  $S_2:-20,000$ , and the target position is momentarily  $A1=30,000$ . The target positions obtained through calculation are  $B1=10,000(A1+ S_2)$  and  $A2=30,000(B1+ S_1)$ , since the outputting target positions cannot be modified.


3.  $S_3$  is the target speed (must be a 32-bit integer), and  $S_4$  is the target speed ratio adjusted value (must be a floating point number). The actual speed is the result of multiplying the values in  $S_3$  and  $S_4$  and then rounding down the calculation result to a 32-bit integer. The acceptable input speed range is 1–200 kHz. When values are out of range, the PLC automatically processes the value as the minimum or the maximum of the operation range. The ratio formula for the actual target speed is  $S_3 \times S_4$ . For instance, if target speed is 1 kHz, the adjusted floating point is 1.2345 and the actual value is 1234 Hz.
4. When the instruction is outputting, the target speed and the adjusted ratio can be modified, and the result is updated to the actual output speed once the instruction is scanned. But it is suggested that you do not change the target speed too much in case the calculated deceleration is affected.
5. The output points for  $D_1$  can only be Y0.0, Y0.2, Y0.4, Y0.6, Y0.8 and Y0.10, and it occupies 2 consecutive output points. The output sets and the output special register modes are listed in the following table.

Output axis number	1	2	3	4	5	6
$D_1+0$ output points	Y0.0	Y0.2	Y0.4	Y0.6	Y0.8	Y0.10
$D_1+1$ output points	Y0.1	Y0.3	Y0.5	Y0.7	Y0.9	Y0.11
Output modes	SR462	SR482	SR502	SR522	SR542	SR562

6.  $D_2$  is the flag indicating the target speed and the adjusted ratio that you can change. When this flag is ON, the executing target speed can be modified. When the flag switches from ON to OFF, it is now decelerating and the current target speed will be processed as the target speed for the next output.


- There is no limit on the number of times you can execute this instruction, but during execution, the designated high speed axis cannot be occupied by any other instruction, and the other instruction is not executed.


The following graphic shows the output timing diagram.



**Example**

When M0 is ON, the DPPGB instruction starts to move back and forth between the target positions that are calculated from the two relative target positions specified by  $S_1$  and  $S_2$ , at the actual target speed of 8500 Hz ( $5000 \times 1.7$ ). Y0.0 is the output point. Y0.1=OFF means the positive direction.






6

### Explanation

1. After the instruction starts the output, modify the relative target positions A for **S<sub>1</sub>** and B for **S<sub>2</sub>**.

a) The Y0.0 output graph:



b) Explanation:

① When **S<sub>1</sub>**:30,000, **S<sub>2</sub>**:-30,000 and M0 enables the DPPGB instruction, the motion goes toward the position **A1**=30,000.

② When **D0**=1 and the position: number of pulses in SR460 >15,000, the relative positions are changed to **S<sub>1</sub>**:26,000 and **S<sub>2</sub>**:-28,000.

At the moment, the target position is **A1**=30,000 since the outputting target position cannot be modified. The calculated target positions are **B1**=2,000(**A1**-28,000), **A2**=28,000(**B1**+26,000).

③ When **D0**=2 and the position: number of pulses in SR460 >15,000, the relative positions are changed to **S<sub>1</sub>**:22,000 and **S<sub>2</sub>**:-24,000.

At this time, the target position is **A2**=28,000 since the outputting target position cannot be modified.

The calculated target positions are **B2**=4,000(**A2**-24,000), **A3**=26,000(**B2**+22,000).

④ When **D0**=3 and the position: number of pulses in SR460 >15,000, the relative positions are changed to **S<sub>1</sub>**:18,000 and **S<sub>2</sub>**:-20,000.

The calculated target positions are **B3**=6,000(**A3**-20,000), **A4**=24,000(**B3**+18,000).

⑤ When **D0**=4 and the position: number of pulses in SR460 >15,000, the relative positions are changed to **S<sub>1</sub>**:30,000 and **S<sub>2</sub>**:-24,000.

The calculated target positions are **B4**=0(**A4**-24,000) and **A1**=30,000(**B4**+30,000).

Step	S <sub>1</sub> : Relative position	S <sub>2</sub> : Relative position	Target position B	Target position A
①	30,000	-30,000	-	A1=30,000
②	26,000	-28,000	B1=2,000	A2=28,000
③	22,000	-24,000	B2=4,000	A3=26,000
④	18,000	-20,000	B3=6,000	A4=24,000
⑤	30,000	-24,000	B4=0	A1=30,000


API	Instruction			Operand								Description			
2724	D	ZRN2		TFreq, JFreq, Mode, DOG, NL, Pulse, Dir								Zero return 2 (directional output can be defined)			

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	“\$”	F
TFreq							●	●	●		○		○	○		
JFreq							●	●	●		○		○	○		
Mode							●	●	●		○		○	○		
DOG	○		○													
NL	○		○													
Pulse		○														
Dir		○	○													

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
TFreq			●				●						
JFreq			●				●						
Mode			●				●						
DOG	●												
NL	●												
Pulse	●												
Dir	●												

Pulse Instruction	16-bit instruction	32-bit instruction
—	—	AS

Symbol



- TFreq** : Target frequency for zero return
- JFreq** : JOG frequency for DOG
- Mode** : Zero return mode
- DOG** : Input device for DOG
- NL** : Input device for Negative Limit point
- Pulse** : Pulse output device
- Dir** : Output direction device

**Explanation**

1. This instruction is available for PLC with FW V1.04.90 (V1.04.90 included) or later.
2. This instruction causes the machine to return to the zero point. The range of the target frequency (**TFreq**) for zero return is between 1 Hz–200 kHz. The JOG frequency (**JFreq**) should be less than the target frequency (**TFreq**). The JOG frequency (**JFreq**) is the start frequency. If the target frequency (**TFreq**) is less than (**JFreq**), the target frequency (**TFreq**) is automatically revised processed as equal to (**JFreq**).
3. Do not change the operands **DOG**, **NL**, **Pulse**, or **Dir** during instruction execution. The input point for **DOG** and **NL** is suggested to use the 16 high-speed input points X0.0–X0.15. They will not be affected by PLC instruction scan time. If you use X1.0 successive input points or M devices, they will be affected by the PLC instruction scan time.
4. See the below descriptions for **DOG**, **NL** and **Dir**.

<b>DOG point</b>	You can use X or M device but do NOT choose the same input point for different axes. When the DOG point uses X0.0–X0.15 for inputs, go to HWCONFIG to set up the filtering time for the inputs if the switch starts to rattle.
<b>NL point</b>	You can use X or M device but do NOT choose the same input point for different axes.
<b>Dir contact</b>	You can use Y or M device.

For firmware V1.10 or earlier, when the zero return is in process and the limit point check function is activated, the limit alarm flag is not set to ON once the limit point is reached. For firmware V1.12 or later, the limit alarm flag will automatically set to ON for a reminder, and then you can decide the follow-up operation based on the alarm flag. (After the alarm flag is ON, it must be cleared by yourself.)

Note: DZRN2 does not support the positive limit function.

5. See the below SR and SM table for pulse outputting.

<b>Pulse output points</b>	<b>Y0.0</b>	<b>Y0.2</b>	<b>Y0.4</b>	<b>Y0.6</b>	<b>Y0.8</b>	<b>Y0.10</b>
Setting up the time for directional outputting goes first before pulse outputting (unit: 1 ms)	SR640	SR642	SR644	SR646	SR648	SR650
Busy flag	SM460	SM480	SM500	SM520	SM540	SM560
Completion flag	SM461	SM481	SM501	SM521	SM541	SM561
Present output position	SR460 SR461	SR480 SR481	SR500 SR501	SR520 SR521	SR540 SR541	SR560 SR561

Pulse output points	Y0.1	Y0.3	Y0.5	Y0.7	Y0.9	Y0.11
Setting up the time for directional outputting goes first before pulse outputting (unit: 1 ms)	SR641	SR643	SR645	SR647	SR649	SR651
Busy flag	SM472	SM492	SM512	SM532	SM552	SM572
Completion flag	SM473	SM493	SM513	SM533	SM553	SM573
Present output position	SR474	SR494	SR514	SR534	SR554	SR574
	SR475	SR495	SR515	SR535	SR555	SR575

6. Select the zero return mode. The function code is set by the two high and low 16-bit parameters. See the following table for details.

Select the zero return mode					
High 16-bit		Low 16-bit			
b31~b16	b15~b6	b6	b5	b4	b3~b0
Number of pulses for motion	reserved	Setting DOG signal mask 0: disabled 1: enabled	Setting NL signal 0: contact A 1: contact B	Setting DOG signal 0: contact A 1: contact B	Mode setting 0~2; 8~10

7. The function code is set by the two high and low 16-bit parameters. See the following table for details.

Functions	Code		Description
	High 16-bit	Low 16-bit	
Leaves the zero point in the negative direction and then stops (Mode 0)	0	0	When the instruction is executed, the search for the zero point is in the negative direction with the target frequency. When the zero point is ON (the zero point signal changes from OFF to ON), the frequency is decreased to the JOG speed and the motion in the negative direction continues, and does not stop until the zero point signal changes from ON to OFF.
Leaves the zero point in the positive direction and then stops (Mode 1)	0	1	When the instruction is executed, the search for the zero point is in the negative direction with the target frequency. When the zero point is ON (the zero point signal changes from OFF to ON), the frequency decreases to 0 immediately, and then the motion is in the positive direction at the JOG speed, and does not stop until the zero point signal changes from ON to OFF.
Mode 0 Moves again	Number of	2	Returning to the zero point is the same as that for

Functions	Code		Description
	High 16-bit	Low 16-bit	
after returning to the zero point	pulses for motion		the low 16-bit code. After the zero point is ON, the motion continues according to the number of specified pulses. When the high 16-bit code is a positive number, the search is in the positive direction. A negative value means that the search is in the negative direction.
Leaves the zero point in the positive direction and then stops (Mode 1)	0	8+0=8 8+1=9 (bit3=ON)	Refer to mode 1. The operation for zero point return is the same as that for code 1 (mode 1).
Mode 1 outputs the number of pulses after returning to the zero point	Number of pulses for motion	8+2=10 (bit3=ON)	The operation for zero point return is the same as that for low 16-bit code 1. After returning to the zero point, the motion continues in accordance with the number of specified pulses. When the value of the high 16-bit code is a positive number, the motion is in the positive direction. A negative number indicates that the motion is in the negative direction.
DOG point is B point		+16 (bit4=ON)	When in the low 16-bit code, bit 4 is ON, it means the zero point is ON as the DOG point changes from ON to OFF and the zero point is left as the DOG point changes from OFF to ON.
NL point is B point		+32 (bit5=ON)	When in the low 16-bit code, bit 5 is ON, it means the zero point is ON as the NL point changes from ON to OFF and the zero point is left as the DOG point changes from OFF to ON.

8. The execution sequence is based on the value of the low 16-bit code in the table above, and described below.

→The direction of DOG signal is determined by the value of bit 5.

→ The NL negative limit and DOG signal are determined by the value of bit 5 and bit 4.

→ Mode 0 or mode 1 for the zero point return, selected according to the value of bit 3.

→ The operation of the zero point return is performed according to the values of bit 1 and bit 0.

The DOG signal mask function is only available for firmware V1.12. or later. When the mask function is enabled (setting bit6 to 1), **Mode+1** is the number of DOG signals to be masked. When the value is less than or equal to 0, the DOG point mask function is regarded as disabled.


Task section is determined by the number of output pulses (regardless of the direction positive or negative) after the DZRN2 instruction is executed. Since the start position for the search for the zero position may be different each time, the setting of the mask section may lead to the case that the zero position is missed. So be sure to evaluate whether to set the mask function or set the negative limit function based on the actual application.

For example, set **Mode** to D0=64 (bit6 set to 1) and set D2=120000 (the number of pulses to be masked). After DZRN2 is executed, the DOG signals for the number of output pulses less than 120,000 will all be masked and thus the DOG signals are not functioning.

9. The Completion flag is set to ON after the instruction finishes performing the specified function. For example, for function code 2, the PLC sets the Completion flag to ON only when the specified number of pulses completes outputting.
10. After the DZRN2 instruction is executed, an interrupt service program is not executed till the DZRN2 instruction is disabled, if the specified input point for the zero point is the same as that for the external input interrupt in the program.
11. It is not suggested to use the instruction in the ST programming language, interrupt tasks or function block which is called only once. Firmware V1.12 or later supports the ST programming language. For details, refer to the description in the example.
12. The steps for performing the functions are as below


Function code 0:

- ① The DZRN2 function is executed and the search for the zero point is in the negative direction with the target frequency (**TFreq**).
- ② After the DOG signal is received, the output frequency decreases to the JOG frequency (**JFreq**). The output continues in the negative direction and does not stop until the zero point signal changes from ON to OFF.
- ③ The output stops when the signal changes from ON to OFF and the axis moves away from the DOG signal.




Function code 1:

- ① The DZRN2 function is executed and the search for the zero point is in the negative direction with the target frequency (**TFreq**).
- ② After the DOG signal is received, the output is in the positive direction with the JOG frequency (**JFreq**) after the output frequency decreases, and the motion direction reverses. The output does not stop until the zero point signal changes from ON to OFF.
- ③ The axis moves away from the DOG signal and PLC stops when the signal changes from ON to OFF.




Function code 2:

- ① The DZR2 function is executed and the search for the zero point is in the negative direction with the target frequency (**TFreq**).
- ② After the DOG signal is received, the output decreases the frequency to the JOG frequency (**JFreq**) and continues in the negative direction.
- ③ When the DOG signal is left and the signal changes from ON to OFF, the specified number of pulses are output.
- ④ The first pulse output starts.
- ⑤ When the 100th pulse output completes, the PLC stops and the Completion flag is ON.



**Example 1**

When M0 is ON, outputting the pulse from Y0.0 with a frequency of 20 kHz to search for the zero point in the negative direction. When the DOG signal is received and X0.4 is ON, it keeps moving in the negative direction with the JOG frequency of 1 kHz. The output stops immediately after X0.4 changes from ON to OFF.

**Explanation**

**Mode** is set to 0.

High 16-bit [0000] is to disable the function to move a number of pulses..

Low 16-bit [0000] is Mode 0; when the DOG signal is received, the axis moves in the negative direction; after the axis moves away from the DOG signal, it stops immediately.

**Example 2 (in ST programming language)**

Generally, it is suggested to use the ladder diagram language for editing the program when using this instruction. If you use ST language (which is available for firmware V1.12 or later), you must wait until the zero-return motion is completed (SM461 completion flag is ON) and then disable the instruction. Besides, you must use the auto reset flag together to notify the PLC to release the high-speed output control right.

Taking Y0.0 output for example, the program writing is shown in the figure below

```

0001 IF M0 THEN
0002     DZRN2 (1000,100,0,X0.0,X1.0,Y0.0,Y0.1);
0003     M1:=TRUE;
0004 ELSIF M1 AND SM461 THEN
0005     SM470 := TRUE;
0006     M1 := FALSE;
0007 END_IF;

```

## 6.27 Delta CANopen and EtherCAT Communication Instructions

### 6.27.1 List of Communication Instructions

The following table lists the High-speed Output instructions covered in this section.

API	Instruction code		Pulse instruction	Function	Delta specific		EtherCAT	
	16-bit	32-bit			Servo	Inverter	Servo	Inverter
<b>2800</b>	INITC	–	–	Initializing the servo for CANopen communication	V	V	–	–
<b>2801</b>	ASDON	–	–	Servo-ON and Servo-OFF	V	V	V	V
<b>2802</b>	CASD	–	–	Setting the acceleration time and deceleration time for a servo	V	V	V	V
<b>2803</b>	–	DDRVIC	–	Servo relative position control	V	–	V	–
<b>2804</b>	–	DDRVAC	–	Servo absolute position control	V	–	V	–
<b>2805</b>	–	DPLSVC	–	Servo speed control	V	V	V	V
<b>2806</b>	ZRNC	DZRNC	–	Servo homing	V	–	V	–
<b>2807</b>	COPRW	–	–	Reading and writing CANopen communication data	V	V	–	–
<b>2808</b>	COPWL	DCOPWL	–	Writing multiple CANopen parameter values	V	V	–	–
<b>2809</b>	RSTD	–	–	Sending Reset or NMT command	V	V	V	V
<b>2810</b>	ZRNM	–	–	Setting the homing mode for Delta servo	V	–	V	–
<b>2811</b>	EMER	–	–	Reading Emergency message	V	V	V	V
<b>2812</b>	–	DCSFOC	–	Controlling the tracking function of a servo via communication	V	–	V	–
<b>2813</b>	ECAMD	–	–	Downloading E-CAM chart to the Slave	V	–	–	–
<b>2814</b>	–	DECAMS	–	E-CAM parameter setting and planning	V	–	–	–
<b>2815</b>	ECAMA	–	–	Activating E-CAM control and displaying the status	V	–	–	–
<b>2816</b>	ECAMC	–	–	Modifying the starting address for E-CAM chart and the E-CAM chart length in the servo	V	–	–	–
<b>2817</b>	–	DTQC	–	Torque control	V	V	V	–
<b>2818</b>	–	DTQLC	–	Speed of torque control	V	V	V	–

API	Instruction code		Pulse instruction	Function	Delta specific		EtherCAT	
	16-bit	32-bit			Servo	Inverter	Servo	Inverter
<b><u>2820</u></b>	INITEC	–	–	Initializing the slaves for EtherCAT communication	–	–	V	V
<b><u>2821</u></b>	ECATRW		–	Reading and writing EtherCAT SDO data	–	–	V	V
<b><u>2822</u></b>	MOTST	–	–	Reading Motion state of an EtherCAT slave	–	–	V	V
<b><u>2823</u></b>	ECATST	–	–	Reading the state of an EtherCAT slave	–	–	V	V

### 6.27.2 Explanation of CANopen and EtherCAT Communication Instructions


API	Instruction			Operand							Description			
2800		INITC		<b>S</b>							Initializing the servo for CANopen communication			

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
<b>S</b>													○	○		

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
<b>S</b>		●											

Pulse Instruction	16-bit instruction	32-bit instruction
—	AS	—

**Symbol**



**S** : Number of station to be initialized

**Explanation**


- Before executing the instruction, if the PLC CPU is AS300, be sure to select **Delta Special Driver & AS Remote Mode** as the working mode for function card 2 in the hardware configuration software (HWCONFIG) in ISPSOft. If the PLC CPU is AS200 or AS100, make sure the working mode for the built-in CAN communication port is selected to Delta Serve Drives in HWCONFIG.
- The servo range of **S** is 1–8. When the input value is greater than 8, PLC will automatically process 8 as the value of **S** for the initialization. The node ID must start at 1 and the following addresses cannot be skipped or reserved.
- When the PLC firmware is V1.02.00 or later, **S** ranging from 21 to 28 is added for inverters. For the input value that is not in the range of 21 to 28, this instruction will not be executed. Same rule applies to the servo; the node ID must start at 21 and the following address should be in consecutive order.
- When setting the number of station to be initialized to 5, this instruction initializes node ID from 1 to 5. And when setting the number of station to be initialized to 23, this instruction initializes node ID from 21 to 23. When there are 5 servo systems and 3 inverters that need to be initialized, you need to execute this instruction twice. One is INITC 5 for 5 servo systems and the other is INITC 23 for 3 inverters.
- When you execute this instruction (SM1686 = OFF) on servos (**S** is 1–8), SM1681 is set to OFF and the states of servo 1 to 8 are reset to uninitialized. SM1681 is set to ON when the initializations on servo 1 to 8 are complete.

SM1683 is set to OFF and **S** is 21–28, the states of servo 21 to 28 are reset to uninitialized. SM1683 is set to ON when the initializations on servo 21 to 28 are complete.

Note: The initialization flags are used for notifying if the initialization is done or not. After that if you use parameters in this instruction, these two flags are used as completion flags for the execution of the instruction.

6. SM1682 is set to ON when an error occurs during communication. In addition, SR658 retains the ID number in which the error occurs and SR659 retains the error code. (The flag and code here are especially for Delta CANOpen Communication Instructions.)
7. For firmware V1.06.40 or later, a new functional SM1686 is added for initializing only one specified slave. For example if you set SM1686 to OFF and execute INITC 3 indicates the slaves 1, 2 and 3 will be initialized. After that if you set SM1686 to ON, execute INITC 6 indicates only the slave 6 will be initialized. And then together you will have slaves 1, 2, 3, and 6 initialized.  
Note: if you need to initialize multiple slaves and single slave, you need to set SM1686 to OFF first to have multiple slaves initialized and then set SM1686 to ON for single initializations, but not the other way around.
8. If a heartbeat error (SR0 = 0x1900~0x191C; last 2 codes are the slave ID) occurs after the initialization is complete and the SM1684 is OFF (default, indicating when one goes down, all the servos are OFF), the initialization complete flags SM1681 & SM1683 will be cleared to OFF and related actions on other slaves will also be paused. After all the troubles are cleared, you need to initialize every slave to restart the operation. PLC will turn the error LED off after PLC confirms the initialization is complete. This error will be recorded in the error log.
9. If each node ID is working independently and the communication is working properly, you can set the SM1684 to ON (indicating when one goes down, only the defective servo is OFF) to notify PLC to record the specific error on the error log and other slaves can keep working.
10. You need to set the node ID and speed of the servos manually and turn the servos off and then on again to activate the new parameters.
11. This instruction should not be used in the Structured Texts programming language, or interrupt programs or FB programs that only be called once.

Initialization and operation process chart



Example of Communication with Delta servo ASD-A2M

- Before using the Delta CANopen instruction, mount an AS-FCOPM card in the AS Series PLC (slot 2 only) and be sure to select **Delta Special Driver & AS Remote Mode** as the working mode for the AS-FCOPM card 2 in the configuration software (HWCONFIG in ISPSoft). Set the baud rate to 125 kbps, 250 kbps, 500 kbps, or 1000 kbps.

6




Figure 1 Function card 2 setting





Figure 2 Working mode selection


2. Connect the AS Series PLC to an ASDA series with a CANopen communication cable as shown in the figure below. (Switch the 120  $\Omega$  terminal resistor ON in the AS-FCOPM card to enable the terminal resistor.)



3. Follow the steps below for the basic settings on the panel of the ASD-A2.
  - a. Set the servo parameter P2-08 to 10 to restore the factory settings.
  - b. Power the servo off and back on again.
  - c. Set P1-01 to 0001 (PR mode).
  - d. Set P3-01 to 0400 and the baud rate of the servo for CANopen communication to 1.0 Mbps. The baud rate must be the same as that of the PLC.
  - e. Set a node ID for every servo, based on the number of servos. Set P3-00 of each servo to 1, 2, and 3 in order. You can set a maximum of eight servos.
  - f. Power the servo off and back on again.
  - g. Begin operation after the basic setting is complete.

4. Download the sample program and set M0 to ON (default: SM1686 = OFF). The instruction initializes the servos at node ID 1–3. When SM1681 is ON, the initialization is complete. When the servo enters CANopen mode successfully, Co-Ld information is displayed.

**Ladder diagram:**



**Structured Texts programming language:**

```

0001 IF M0 = TRUE AND SM1681 = FALSE THEN
0002     INITC (3) ;
0003 END_IF ;
0004 IF M0 = TRUE AND SM1681 = TRUE THEN
0005     M0 := FALSE ;
0006 END_IF ;
    
```

5. The following list shows the settings to initialize a servo drive in the AS Series.
  - a. Set P2-30 (auxiliary function) to 5 to indicate that the servo does not need to store the settings in EEPROM permanently. This can prolong the servo life span.
  - b. Reset P6-02 (PATH#1) to 0 and P6-06 (PATH#3) to 0. This indicates that PATH#1 & #3 in PR mode are both cleared.
  - c. Set P3-06 (SDI source) to 16#0100. This indicates that DI1–DI8 are controlled by the hardware, EDI9 is controlled by the software, and EDI10–EDI14 are controlled by the hardware.
  - d. Reset P4-07 (SDI status controlled manually) to 0.
  - e. Set P2-36 (EDI9) to 16#0101. This indicates that the function of EDI9 is set to Servo ON.
  - f. Set P0-17 (CM1A) to 1. This indicates that the mapping parameter is the pulse command output register CMD\_O.
  - g. Set P0-18 (CM2A) to 64. This indicates that the mapping parameter is the pulse command register CMD\_E.
  - h. Set P5-20–P5-35 (acceleration time) to 1. This indicates that the acceleration time is 1 ms.
  - i. Set P5-60–P5-75 (target speed) to 1. This indicates that the target speed is 0.1 rpm.
  - j. Set PDO1 to correspond to P5-07 (PR command), P0-01 (Fault code), P0-46 (state of DO point) and P4-07 (state of DI point)

- k. Set PDO2 to correspond to P0-09 (CM1 state: CMD\_O) and P0-10 (CM2 state: CMD\_E).
- l. Set PDO3 to correspond to P0-11 (CM3 state: state of current torque)
- m. Available for PLC with FW V1.04.00 or later: set time for the heartbeat and the PLC scan overtime to 200ms (default). When a communication overtime occurs, PLC will send error message (error LED flashing slowly; refer to error code for more details) and the servo turns off automatically.
- n. If SM1685 is ON, PDO3 reads self-defined parameters from servo drive P0-12 and stores the data in SR791-SR806. You need to set up the P0-20 (CM4A) before executing. 2 SRs are reserved for every servo drive ID and you can define their data types.

Note: PLC with firmware V1.04.10 or later supports states of current torque (PD03) and DI point (PD01). PLC with firmware V.104.60 or later supports reading self-defined parameters (PD03)

6. Do not use the COPRW instruction (API 2807) to modify the servo parameters of the eight items A, B, F, G, J, K and N above after initialization.
7. When you use an absolute-type servo, use the COPRW communication instruction to write 16#0100 to P3-12, which writes the relevant absolute-type servo parameters to EEPROM at the moment the servo powers off.
8. Set the relevant DI signal configuration parameters manually or with the COPRW instruction to modify the hardware DI signal setting of ASD-A2. Use COPRW to modify the configuration after execution of the INITC instruction is complete and before the servo is enabled.
9. When the initialization is complete, the servo is in the PR mode. Do not make any communication control on servo P5-18.
10. For more details on the servo parameters, refer to the Delta Servo Operation manual.


#### Example of Communication with Delta Inverter

1. Manually set the inverter parameter P09-36 (ranging from 21 to 28), P09-37 (communication baud rate default is 1MHz) and P09-40 to standard CANopen protocol (default).
2. Manually set the source of frequency command P00-20 to 6 and source of the operation command P00-21 to 3, and have them controlled by CANopen communication.
3. The following list shows the settings to initialize an inverter in the AS Series.
  - A. Set PDO mapping area: the operation frequencies, current state, and states of torque and DI point correspond to PLC SRs.
  - B. Set time for the heartbeat and the PLC scan overtime to 200ms (default). When a communication overtime

occurs, PLC will send error message (error LED flashing slowly; refer to error code for more details) and the servo turns off automatically.

- For more details on the servo parameters, refer to the Delta Inverter Operation manual.

**Example**



- When M0 changes from OFF to ON, the INITC instruction starts to initialize the inverter at node ID 21, until SM1683 is ON. When SM1683 is ON, it indicates the initialization is complete.

**Additional Remarks:**

The following table shows special flags (SM) and registers (SR) related to initialization.

Flag	R/W	ID. 1	ID. 2	ID. 3	ID. 4	ID. 5	ID. 6	ID. 7	ID. 8
Enable specific function	R/W	The flag in HWCONFIG is set to ON when the PLC is from Stop to Run.							
Initialization and communication complete (INITC and CASD)	R	SM1681							
CANopen communication error	R	SM1682							
Single slave initialization (for firmware V1.06.40 or later)	R/W	SM1686 = OFF (default; multiple slaves initialization) SM1686 = ON (single slave initialization)							
ID number which is with a communication error	R	SR658							
Communication error code	R	SR659							

Note1: After the axis starts to output, PLC clears the corresponding completion flag.

The following table shows the Delta special drier CANopen error codes. (error code in SR659)

Error Code	Cause
0x0002	The slave does not respond to the SDO message.
0x0003	An error occurs in the message received by the slave. This error often occurs when the settings of the COPRW instruction are invalid causing the slave not to receive the complete message.

0x0004	The slave PDO message is not received.
0x0005	An error occurs while using the instruction operand.
0x0006	One of the stations is being used when the INITC instruction is executed.
0x0007	Slave node ID exceeds acceptable range of the instruction INITC
0x0008	A slave cannot be reset; check if the communication cable is connected and if the communication of the slave is working properly.

When you use Delta Special Driver & AS Remote mode / Delta Special Driver & CANopen DS301 and execute INITC instruction, the refreshing time of PDO data exchange among stations 1 to 15 and 21 to 28 is shown below. For example, when the baud rate is 1M, PDO data exchange refreshing time is 10 ms X 5 times = 50 ms.

Baud rate (bps)	1M	500K	250K	125K	50K
Preset time to synchronize (ms) <sup>#1</sup>	10	15	30	60	80
Preset number of synchronization times <sup>#2</sup>	5	5	5	5	5

#1: If you use Delta Special Driver & CANopen DS301 mode, you can use CANopen Builder software to edit the time to synchronize for the slaves. But the edited time can only be greater than the time shown in the table above. If you set the time lesser than the time shown above, the system ignores the editing and runs according to the time shown above.

#2: If you use Delta Special Driver & CANopen DS301 mode, you can use CANopen Builder software to edit the number of synchronization times for the preset number of synchronization times in the table of DS301. For the preset number of synchronization times, it is not editable.

When you use Delta Special Driver & AS Remote mode / Delta Special Driver & CANopen DS301 and execute COPPRW instruction (SDO communication), the communication timeout is shown below.

Baud rate (bps)	1M	500K	250K	125K	50K
Communication timeout (ms) <sup>#1</sup>	100	100	200	400	500

When the mode is CANopen DS301, you can set the time of the COPPRW timeout in the CANopen communication setting option from HWCONFIG; default timeout is 100 ms.

API	Instruction			Operand								Description				
2801		ASDON		<b>S<sub>1</sub>, S<sub>2</sub></b>								Servo-ON and Servo-OFF				

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
<b>S<sub>1</sub></b>	●	●			●	●		●	●		○	○	○	○		
<b>S<sub>2</sub></b>													○	○		

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
<b>S<sub>1</sub></b>		●				●							
<b>S<sub>2</sub></b>		●				●							

Pulse instruction	16-bit instruction	32-bit instruction
—	AS	—

**Symbol**



**S<sub>1</sub>** : Node ID of the servo

**S<sub>2</sub>** : Servo ON and Servo OFF

**Explanation**

1. ECAT communication is available for the PLC with firmware V1.14.00 or later and ISPSOft V3.16 or later, and the AS-FECAT function card must be installed on the PLC.
2. For CAN communication, the INITC instruction must be complete before this instruction is executed. For ECAT communication, the INITEC instruction must be complete before this instruction is executed.
3. For CAN communication, the range of **S<sub>1</sub>** is 1–8 (for servo) and 21-28 (for inverter). There will be no execution when the input value is out of the range. For ECAT communication, the range of **S<sub>1</sub>** is 1–16. There will be no execution when the input value is out of the range. Use INITEC instruction to set up the ID number and device type.
4. The range of **S<sub>1</sub>** (for servo) is 1–8 (for CAN communication) and 1-16 (for ECAT communication) and **S<sub>2</sub>** is a non-zero value, the servo is enabled (Servo-ON). If **S<sub>2</sub>** is 0, the servo is disabled (Servo-OFF).
5. The range of **S<sub>1</sub>** (for inverter) is 21–28 (for CAN communication) and 1-16 (for ECAT communication). When **S<sub>2</sub>** is 1, it indicates it is in inverter speed mode. When **S<sub>2</sub>** is 2, it indicates it is in inverter torque mode. When **S<sub>2</sub>** is 0, it indicates it stops operating. Since control modes (speed mode and torque mode) for inverters can be switched directly, the operation can keep going. Before switching control modes, make sure all the inverter parameters are set.


6. Table of the last 2 points:


Drive type	Range of S <sub>1</sub>	Descriptions of S <sub>2</sub>
Servo	1-8 (CAN) 1-16 (ECAT)	1 = SERVO-ON 0 = SERVO-OFF
Inverter	21-28 (CAN) 1-16 (ECAT)	0 = stop operating 1 = Speed mode 2 = Torque mode

- For CAN communication, every servo (1-8) has a flag (SM1651–M1658) for displaying its state. For ECAT communication, every node ID of servo (1-16) has a flag (SM1651–M1658, SM1621-SM1628) for displaying its state. You can read the actual servo state from the flag. When the flag is ON, the servo is Servo-ON. When the flag is OFF, the servo is Servo-OFF.
- For CAN communication, every inverter (21-28) has a flag (SM1621–M1628) for displaying its state. For ECAT communication, every node ID of inverter (1-16) has a flag (SM1651–M1658, SM1621-SM1628) for displaying its state. You can read the actual inverter state from the flag. When the flag is ON, the inverter is ON. When the flag is OFF, the inverter is OFF.
- SM1682 is ON if an error occurs during communication. In addition, SR658 retains the ID number in which the error occurs and SR659 retains the error code.

#### Example 1 (Ladder diagram):

- When M0 changes from OFF to ON, the INITC instruction starts to initialize the servos at node ID 1–3, until SM1681 is ON.
- When M1 changes from OFF to ON, the ASDON instruction starts to enable the servo at node ID 2. When SM1652 is ON, it indicates Servo-ON.
- When M2 changes from OFF to ON, the ASDON instruction starts to disable the servo at node ID 2. When SM1652 is OFF, it indicates Servo-OFF.




**Example 2 (Structured Texts programming language):**

```


0001 IF M1 THEN
0002   ASDON(2,1);
0003 END_IF;
0004 IF M1 AND SM1652 THEN
0005   SM1582 := TRUE;
0006   M1 := FALSE;
0007 END_IF;
0008
0009 IF M2 THEN
0010   ASDON(2,0);
0011 END_IF;
0012 IF M2 AND (not SM1652) THEN
0013   SM1582 := TRUE;
0014   M2 := FALSE;
0015 END_IF;

```

1. When M1 changes from OFF to ON, this instruction starts to enable the servo at node ID 2. When SM1652 is ON, it indicates Servo-ON.
2. Make sure M1 and SM1652 are both ON and then set the auto return communication control right flag SM1582 to ON for node ID 2. This will free the communication control right and the node ID 2 can receive and execute other communication instructions.
3. When M2 changes from OFF to ON, this instruction starts to disable the servo at node ID 2. When SM1652 is OFF, it indicates Servo-OFF.
4. Make sure M2 is ON and SM1652 is OFF and then set the auto return communication control right flag SM1582 to ON for node ID 2. This will free the communication control right and the node ID 2 can receive and execute other communication instructions.

**Example 3 (communication with Delta inverters):**

- 1. When M0 changes from OFF to ON, this instruction starts to initialize the node ID 21. When SM1683 is ON, it indicates the initialization is complete.
- 2. When M2 changes from OFF to ON, this instruction starts to set the control mode at the node ID 21. When SM1621 is ON, it indicates the inverter is in operation.




API	Instruction			Operand							Description				
2802		CASD		<b>S<sub>1</sub> , S<sub>2</sub> , S<sub>3</sub></b>							Setting the acceleration time and deceleration time for a servo				

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
<b>S<sub>1</sub></b>	●	●			●	●		●	●		○	○	○	○		
<b>S<sub>2</sub></b>	●	●			●	●		●	●		○	○	○	○		
<b>S<sub>3</sub></b>	●	●			●	●		●	●		○	○	○	○		

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
<b>S<sub>1</sub></b>		●				●							
<b>S<sub>2</sub></b>		●				●							
<b>S<sub>3</sub></b>		●				●							

Pulse instruction	16-bit instruction	32-bit instruction
—	AS	—

**Symbol**



- S<sub>1</sub>** : Node ID of the servo
- S<sub>2</sub>** : Acceleration time (ms)
- S<sub>3</sub>** : Deceleration time (ms)

**Explanation**

- ECAT communication is available for the PLC with firmware V1.14.00 or later and ISPSOft V3.16 or later, and the AS-FECAT function card must be installed on the PLC.
- For CAN communication, the INITC instruction must be complete before this instruction is executed. For ECAT communication, the INITEC instruction must be complete before this instruction is executed.
- For CAN communication, the range of **S<sub>1</sub>** is 1–8 (for servo) and 21-28 (for inverter). There will be no execution when the input value is out of the range. For ECAT communication, the range of **S<sub>1</sub>** is 1–16. There will be no execution when the input value is out of the range. Use INITEC instruction to set up the ID number and device type.
- Table to describe **S<sub>2</sub>** and **S<sub>3</sub>**

Drive type	Range of <b>S<sub>1</sub></b>	Range of <b>S<sub>2</sub></b> and <b>S<sub>3</sub></b>	Descriptions of <b>S<sub>2</sub></b> and <b>S<sub>3</sub></b>
Servo	1-8 (CAN) 1-16 (ECAT)	1-32767 (ms)	<b>S<sub>2</sub></b> : Acceleration time is the period of time during which the servo spins up from 0 to 3000.0 rpm.

			<b>S<sub>3</sub></b> : Deceleration time is the period of time during which the servo spins down from 3000.0 rpm to 0.
Inverter	21-28 (CAN communication) 1-16 (ECAT communication)	100-32700 (ms) The input value should be multiplied by 100.	<b>S<sub>2</sub></b> : Acceleration time is the period of time during which the inverter spins up from 0.0Hz to the highest operation frequency. <b>S<sub>3</sub></b> : Deceleration time is the period of time during which the servo spins down from the highest operation frequency to 0.


- For CAN communication, when you execute this instruction and the range of **S<sub>1</sub>** is 1–8 (for servo), SM1681 is set to OFF (parameters are being editing). When the servo responds to the received command, SM1681 is ON (parameters are set successfully). When you execute this instruction and the range of **S<sub>1</sub>** is 21–28 (for inverter), SM1683 is set to OFF (parameters are being editing). When the inverter responds to the received command, SM1683 is ON (parameters are set successfully). For ECAT communication, when you execute this instruction and the range of **S<sub>1</sub>** is 1–16, SM1681 is set to OFF (parameters are being editing). When the servo / inverter responds to the received command, SM1681 is ON (parameters are set successfully).
- SM1682 is set to ON when an error occurs during communication. In addition, SR658 retains the ID number in which the error occurs and SR659 retains the error code.


**Example 1 (communication with Delta ASD-A2M)**

- When M0 changes from OFF to ON, the INITC instruction initializes the servos at node ID 1–3, until SM1681 is ON.
- When M1 changes from OFF to ON and the target speed of the servo at node ID 2 is 3000 rpm, the CASD instruction sets the acceleration time of servo 2 to 3000 ms and the deceleration time to 9000 ms.
- If the target speed of servo 2 is 1000 rpm, the acceleration time and deceleration time are shown below.

Acceleration time:  $[3000 \text{ ms} / 3000 \text{ rpm}] \times 1000 \text{ rpm} = 1000 \text{ ms}$


Deceleration time:  $[9000 \text{ ms} / 3000 \text{ rpm}] \times 1000 \text{ rpm} = 3000 \text{ ms}$





**Example 2 (communication with Delta inverters)**

1. When M0 changes from OFF to ON, this instruction starts to initialize the node ID 21. When SM1683 is ON, it indicates the initialization is complete.
2. When M1 changes from OFF to ON, this instruction starts to set the acceleration time to 2000 ms and deceleration time to 3000 ms at the node ID 21.




API	Instruction			Operand								Description			
2803	D	DRVIC		<b>S<sub>1</sub>, S<sub>2</sub>, S<sub>3</sub></b>								Servo relative position control			

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	“\$”	F
<b>S<sub>1</sub></b>								●					○	○		
<b>S<sub>2</sub></b>								●	●				○	○		
<b>S<sub>3</sub></b>								●	●				○	○		

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
<b>S<sub>1</sub></b>			●				●						
<b>S<sub>2</sub></b>			●				●						
<b>S<sub>3</sub></b>			●				●						

Pulse instruction	16-bit instruction	32-bit instruction
—	—	AS

**Symbol**



- S<sub>1</sub>** : Node ID of servo
- S<sub>2</sub>** : Relative target position
- S<sub>3</sub>** : Target speed

**Explanation**

- ECAT communication is available for the PLC with firmware V1.14.00 or later and ISPSOft V3.16 or later, and the AS-FECAT function card must be installed on the PLC.
- For CAN communication, the INITC and ASDON (servo ON) instructions must be complete before this instruction is executed. For ECAT communication, the INITEC and ASDON (servo ON) instructions must be complete before this instruction is executed.
- For CAN communication, the range of **S<sub>1</sub>** is 1–8. There will be no execution when the input value is out of the range. For ECAT communication, the range of **S<sub>1</sub>** is 1–16. There will be no execution when the input value is out of the range or if the device of the assigned ID is not a servo.
- The range of **S<sub>2</sub>** is -2147483648 to +2147483647. The +/- sign indicates the forward / reverse direction. The target position is a relative position.
- The unit of the value of **S<sub>3</sub>** is 0.1 rpm. The range is 1–60000, which indicates 0.1–6000.0 rpm.

- When the target position is reached, the corresponding completion flags of axes SM1631–SM1638 for CAN node ID 1-8 and the corresponding completion flags of axes SM1631–SM1638, SM1921–SM1928 for ECAT node ID 1-16 are ON. After the axis starts to output, PLC clears the corresponding completion flag. If the positioning is required for several times on the same output axis, you need to clear the corresponding completion flags by yourself to save time and avoid confusions.
- Refer to the following table for the corresponding SM and SR of the axes.
- SM1682 is ON when an error occurs during communication. In addition, SR658 retains the ID number in which the error occurs and SR659 retains the error code.
- This instruction uses SDO (Service Data Object) of CANopen protocol to communicate. Since only one SDO communication can be sent for a time, do NOT use this instruction for outputting positioning in various axis synchronized motion.
- For PLC CPU with firmware V1.12.10 or later, it is supported to modify the target speed and the target position during instruction execution.

Target speed modification: the servo will act according to the acceleration and deceleration time.

If the new target speed is 0, the servo will go decelerating and then to a stop.

If the new target speed is changed from 0 to any number other than 0, the servo will resume whatever the movement was.

Target position modification:


For the movement in a negative direction, the target position is not allowed to change.

For the relative positioning, when the new target position is 0, the servo will go decelerating and then to a stop immediately and the positioning is seen as achieved.

### Example 1 (Ladder diagram):

- When M0 changes from OFF to ON, the INITC instruction starts to initialize the servos at node ID1–3, until SM1681 is ON.
- When M1 changes from OFF to ON, the ASDON instruction starts to enable the servo at node ID2. When SM1652 is ON, it indicates Servo-ON.
- When M2 changes from OFF to ON, servo 2 moves to the relative position 100000 PUU at 100.0 rpm.

The finish flag SM1632 is ON when the target position is reached.



Example 2 (Structured Texts programming language):

```

0001 IF M2 THEN
0002     DDRVIC (2, 100000, 1000);
0003 END_IF;
0004 IF M2 AND SM1632 THEN
0005     SM1582 := TRUE;
0006     M2 := FALSE;
0007 END_IF;

```

1. When M2 changes from OFF to ON, servo 2 moves to the relative position 100000 PUU at 100.0 rpm.

The finish flag SM1632 is ON when the target position is reached.

2. Make sure M2 and SM1632 are both ON and then set the auto return communication control right flag SM1582 to ON for node ID2. This will free the communication control right and the node ID2 can receive and execute other communication instructions.

**Explanation of special flags (SM) and registers (SR) for Delta special CANopen communication instructions**

The following table shows special flags (SM) and registers (SR) related to Delta special CANopen communication.

Flag	R/W	ID. 1	ID. 2	ID. 3	ID. 4	ID. 5	ID. 6	ID. 7	ID. 8
Enable specific function	R/W	The flag in HWCONFIG is set to ON when the PLC changes from Stop to Run.							
Servo Initialization and communication complete (INITC and CASD)	R	SM1681							
CANopen communication error	R	SM1682							
Single slave initialization (for firmware V1.06.40 or later)	R/W	SM1686 = OFF (default; multiple slaves initialization) SM1686 = ON (single slave initialization)							
Positioning complete	R/W#1	SM1631	SM1632	SM1633	SM1634	SM1635	SM1636	SM1637	SM1638
Stop	R/W	SM1641	SM1642	SM1643	SM1644	SM1645	SM1646	SM1647	SM1648
Servo-ON	R	SM1651	SM1652	SM1653	SM1654	SM1655	SM1656	SM1657	SM1658
Go-back/go-forth enabled Only DDRVAC is supported.	R/W	SM1661	SM1662	SM1663	SM1664	SM1665	SM1666	SM1667	SM1668
Go-back/go-forth direction indicator Only DDRVAC is supported.	R	SM1671	SM1672	SM1673	SM1674	SM1675	SM1676	SM1677	SM1678
Auto return communication control right	R/W	SM1581	SM1582	SM1583	SM1584	SM1585	SM1586	SM1587	SM1588
Heartbeat error code	R	SM1691	SM1692	SM1693	SM1694	SM1695	SM1696	SM1697	SM1698
Heartbeat error handling	R/W	SM1684 = OFF (default; when one goes down, all the servos are OFF.) SM1684 = ON (when one goes down, only the defective servo is OFF.)							
ID number with a communication error	R	SR658							
Communication error code	R	SR659							

Note1: After the axis starts to output, PLC clears the corresponding completion flag.

The following table shows how Delta servo parameters of axes correspond to special flags and registers in the CANopen communication.

Servo Parameter Name (Number)	R/W	ID. 1	ID. 2	ID. 3	ID. 4	ID. 5	ID. 6	ID. 7	ID. 8
PR command (P5-07)	R	SR661	SR662	SR663	SR664	SR665	SR666	SR667	SR668
Alarm code (P0-01) (hexadecimal)	R	SR671	SR672	SR673	SR674	SR675	SR676	SR677	SR678
DO state (P0-46)	R	SR681	SR682	SR683	SR684	SR685	SR686	SR687	SR688
Servo command position CMD_O (P0-09)	R	SR691	SR693	SR695	SR697	SR699	SR701	SR703	SR705
		SR692	SR694	SR696	SR698	SR700	SR702	SR704	SR706
Servo target position CMD_E (P0-10)	R	SR711	SR713	SR715	SR717	SR719	SR721	SR723	SR725

		SR712	SR714	SR716	SR718	SR720	SR722	SR724	SR726
DI state (P4-07)	R	SR731	SR732	SR733	SR734	SR735	SR736	SR737	SR738
Current torque (unit: 0.1%)	R	SR741	SR742	SR743	SR744	SR745	SR746	SR747	SR748
Self-defined (P0-12) * Work with SM1685 Enable/Disable	R	SR791 SR792	SR793 SR794	SR795 SR796	SR797 SR798	SR799 SR800	SR801 SR802	SR803 SR804	SR805 SR806
Positioning completion range setting	R/W	SR811	SR812	SR813	SR814	SR815	SR816	SR817	SR818

\*For example, if a servo real position is requested, set the servo values in P0-20, enable SM1685 and then the servo real position can be read in SR791-SR806. For more details, refer to Delta High Resolution AC Servo Drive for Network Communication Applications ASDA-A2 Series User Manual.

The following table shows how Delta inverter parameters of axes correspond to special flags and registers in the CANopen communication.

Description		ID. 21	ID. 22	ID. 23	ID. 24	ID. 25	ID. 26	ID. 27	ID. 28
Inverter INITC and CASD communication completion flag	R	SM1683							
Inverter starting up flag	R	SM1621	SM1622	SM1623	SM1624	SM1625	SM1626	SM1627	SM1628
Inverter Heartbeat error flag	R	SM1611	SM1612	SM1613	SM1614	SM1615	SM1616	SM1617	SM1618
Auto-reset the communication control	R/W	SM1601	SM1602	SM1603	SM1604	SM1605	SM1606	SM1607	SM1608
Inverter status (Index 6041H-00H)	R	SR751	SR752	SR753	SR754	SR755	SR756	SR757	SR758
Inverter current velocity (Index 6043H-00H)	R	SR761	SR762	SR763	SR764	SR765	SR766	SR767	SR768
Inverter current torque (unit: 0.1%) (Index 2021H-0CH)	R	SR771	SR772	SR773	SR774	SR775	SR776	SR777	SR778
Inverter digital input status (Index 2022H-11H)	R	SR781	SR782	SR783	SR784	SR785	SR786	SR787	SR788

The following table shows the CANopen communication error codes of Delta servos and inverters. (error code in SR659)

Error Code	Cause
0x0002	The slave does not respond to the SDO message.
0x0003	An error occurs in the message received by the slave. This error often occurs when the settings of the COPRW instruction are invalid causing the slave not to receive the complete message.
0x0004	The slave PDO message is not received.
0x0005	An error occurs while using the instruction operand.
0x0006	One of the stations is being used when the INITC instruction is executed.

0x0007	Slave node ID exceeds acceptable range of the instruction INITC
0x0008	A slave cannot be reset; check if the communication cable is connected and if the communication of the slave is working properly.

- The following table shows special flags (SM) and registers (SR) related to ECAT communication.

Flag	R/W	ID. 1 to ID. 16
Initialization and communication complete (INITC and CASD)	R	SM1681
Communication error	R	SM1682
Connection loss handling	R/W	SM1684 = OFF (default; when one goes down, all the drives are OFF.) SM1684 = ON (when one goes down, only the defective drive is OFF.)
ECAT SDO abort code (32-bit)	R/W	SR656 SR657
ID number with a communication error	R/W	SR658
Communication error code	R/W	SR659

Function	R/W	ID. 1	ID. 2	ID. 3	ID. 4	ID. 5	ID. 6	ID. 7	ID. 8
Servo positioning complete <sup>#1</sup>	R/W	SM1631	SM1632	SM1633	SM1634	SM1635	SM1636	SM1637	SM1638
Servo stop	R/W	SM1641	SM1642	SM1643	SM1644	SM1645	SM1646	SM1647	SM1648
Servo-ON, inverter-ON	R	SM1651	SM1652	SM1653	SM1654	SM1655	SM1656	SM1657	SM1658
Go-back/go-forth enabled Only DDRVAC is supported.	R/W	SM1661	SM1662	SM1663	SM1664	SM1665	SM1666	SM1667	SM1668
Go-back/go-forth direction indicator Only DDRVAC is supported.	R	SM1671	SM1672	SM1673	SM1674	SM1675	SM1676	SM1677	SM1678
Auto return communication control right. Only DDRVAC is supported.	R/W	SM1581	SM1582	SM1583	SM1584	SM1585	SM1586	SM1587	SM1588
Connection loss error code <sup>#2</sup>	R/W	SM1691	SM1692	SM1693	SM1694	SM1695	SM1696	SM1697	SM1698

Function	R/W	ID. 9	ID. 10	ID. 11	ID. 12	ID. 13	ID. 14	ID. 15	ID. 16
Servo Positioning complete <sup>#1</sup>	R/W	SM1921	SM1922	SM1923	SM1924	SM1925	SM1926	SM1927	SM1928
Servo Stop	R/W	SM1931	SM1932	SM1933	SM1934	SM1935	SM1936	SM1937	SM1938
Servo-ON, inverter-ON	R	SM1621	SM1622	SM1623	SM1624	SM1625	SM1626	SM1627	SM1628
Go-back/go-forth enabled Only DDRVAC is supported.	R/W	SM1941	SM1942	SM1943	SM1944	SM1945	SM1946	SM1947	SM1948
Go-back/go-forth direction indicator Only DDRVAC is supported.	R	SM1951	SM1952	SM1953	SM1954	SM1955	SM1956	SM1957	SM1958
Auto return communication control right. Only DDRVAC is supported.	R/W	SM1601	SM1602	SM1603	SM1604	SM1605	SM1606	SM1607	SM1608
Connection loss error code <sup>#2</sup>	R/W	SM1611	SM1612	SM1613	SM1614	SM1615	SM1616	SM1617	SM1618

#1: The timing for the servo positioning completion flag to be cleared to off automatically is when the outputting of the axis is enabled. If you need to use positioning instructions on a certain axis for several times in a row, you need to clear the servo positioning completion flag by yourself. If you do not clear the servo positioning completion flag and then use the positioning instruction again and again, it is possible that before the next positioning instruction is executed, a servo positioning completion flag is detected and then the execution of positioning instruction will be stopped.

# 2: Since the heartbeat is not available for ECAT communication, working counter (WKC) is used as a way to determine whether the connection of a slave is lost or not.

- The following table shows special flags (SM) and registers (SR) related to Servo ECAT communications.

Parameter Name (Number)	R/W	ID. 1	ID. 2	ID. 3	ID. 4	ID. 5	ID. 6	ID. 7	ID. 8
Servo PR command (P5-07) / Inverter status (index 6041H-00H)	R	SR661	SR662	SR663	SR664	SR665	SR666	SR667	SR668
Servo Alarm code (P0-01)	R	SR671	SR672	SR673	SR674	SR675	SR676	SR677	SR678
Servo DO state (P0-46)	R	SR681	SR682	SR683	SR684	SR685	SR686	SR687	SR688
Servo command position CMD_O (P0-09)	R	SR691	SR693	SR695	SR697	SR699	SR701	SR703	SR705
		SR692	SR694	SR696	SR698	SR700	SR702	SR704	SR706
Servo target position CMD_E (P0-10)	R	SR711	SR713	SR715	SR717	SR719	SR721	SR723	SR725
		SR712	SR714	SR716	SR718	SR720	SR722	SR724	SR726
Servo DI state (P4-07)	R	SR731	SR732	SR733	SR734	SR735	SR736	SR737	SR738
Current torque (P0-11)	R	SR741	SR742	SR743	SR744	SR745	SR746	SR747	SR748
Servo Self-defined (P0-12)	R	SR791	SR793	SR795	SR797	SR799	SR801	SR803	SR805
		SR792	SR794	SR796	SR798	SR800	SR802	SR804	SR806
Positioning completion range setting	R/W	SR811	SR812	SR813	SR814	SR815	SR816	SR817	SR818

Parameter Name (Number)	R/W	ID. 9	ID. 10	ID. 11	ID. 12	ID. 13	ID. 14	ID. 15	ID. 16
Servo PR command (P5-07) / Inverter status (index 6041H-00H)	R	SR751	SR752	SR753	SR754	SR755	SR756	SR757	SR758
Servo Alarm code (P0-01)	R	SR761	SR762	SR763	SR764	SR765	SR766	SR767	SR768
Servo DO state (P0-46)	R	SR1191	SR1192	SR1193	SR1194	SR1195	SR1196	SR1197	SR1198
Servo command position CMD_O (P0-09)	R	SR1201	SR1203	SR1205	SR1207	SR1209	SR1211	SR1213	SR1215
		SR1202	SR1204	SR1206	SR1208	SR1210	SR1212	SR1214	SR1216
Servo target position CMD_E (P0-10)	R	SR1221	SR1223	SR1225	SR1227	SR1229	SR1231	SR1233	SR1235
		SR1222	SR1224	SR1226	SR1228	SR1230	SR1232	SR1234	SR1236
Servo DI state (P4-07)	R	SR781	SR782	SR783	SR784	SR785	SR786	SR787	SR788
Current torque (P0-11)	R	SR771	SR772	SR773	SR774	SR775	SR776	SR777	SR778
Servo Self-defined (P0-12)	R	SR1241	SR1243	SR1245	SR1247	SR1249	SR1251	SR1253	SR1255
		SR1242	SR1244	SR1246	SR1248	SR1250	SR1252	SR1254	SR1256
Positioning completion range setting	R/W	SR1261	SR1262	SR1263	SR1264	SR1265	SR1266	SR1267	SR1268

The following table shows the ECAT communication error codes of Delta servos and inverters. (error code in SR659)

Error Code	Cause
0x0002	The slave does not respond to the SDO message.
0x0003	An error occurs in the message received by the slave. This error often occurs when the settings of the COPRW instruction are invalid causing the slave not to receive the complete message.
0x0004	The slave PDO message is not received.
0x0005	An error occurs while using the instruction operand.
0x0006	One of the stations is being used when the INITC instruction is executed.
0x0007	Slave node ID exceeds acceptable range of the instruction INITC
0x0008	A slave cannot be reset; check if the communication cable is connected and if the communication of the slave is working properly.
0x0009	AS-FECAT does NOT respond.
0x000A	More than four slaves are managed by DCSOFC instruction simultaneously.


API	Instruction			Operand								Description			
2804	D	DRVAC		<b>S<sub>1</sub>, S<sub>2</sub>, S<sub>3</sub></b>								Servo absolute position control			

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	“\$”	F
<b>S<sub>1</sub></b>								●					○	○		
<b>S<sub>2</sub></b>								●	●				○	○		
<b>S<sub>3</sub></b>								●	●				○	○		

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
<b>S<sub>1</sub></b>			●				●						
<b>S<sub>2</sub></b>			●				●						
<b>S<sub>3</sub></b>			●				●						

Pulse instruction	16-bit instruction	32-bit instruction
—	—	AS

**Symbol**



**S<sub>1</sub>** : Node ID of servo

**S<sub>2</sub>** : Absolute target position

**S<sub>3</sub>** : Target speed


**Explanation**

1. ECAT communication is available for the PLC with firmware V1.14.00 or later and ISPSOft V3.16 or later, and the AS-FECAT function card must be installed on the PLC.
2. For CAN communication, the INITC and ASDON (servo ON) instructions must be complete before this instruction is executed. For ECAT communication, the INITEC and ASDON (servo ON) instructions must be complete before this instruction is executed.
3. For CAN communication, the range of **S<sub>1</sub>** is 1–8. There will be no execution when the input value is out of the range. For ECAT communication, the range of **S<sub>1</sub>** is 1–16. There will be no execution when the input value is out of the range or if the device of the assigned ID is not a servo.
4. The range of **S<sub>2</sub>** is -2147483648 to +2147483647. The +/- sign indicates the forward / reverse direction. The target position is an absolute position.
5. Refer to the DRVIC instruction (API 2803) for additional information and examples.

**Example 1**

1. When M0 changes from OFF to ON, the INITC instruction starts to initialize the servos at node ID1–3, until SM1681 is ON.
2. When M1 changes from OFF to ON, the ASDON instruction starts to enable the servo at node ID2. When SM1652 is ON, it indicates Servo-ON.
3. When M2 changes from OFF to ON, servo 2 moves from the current position to the absolute position 100,000 PUU at 100.0 rpm.

The finish flag SM1632 is ON when the target position is reached.




6

**Example 2**

- 1. Add one line to the program in Example 1. When the PLC runs and SM1662 is ON, the function is enabled for servo 2 to go back and forth.



- 2. As the figure shows below, the servo moves from its current position (20,000) to the absolute target position (100,000) after M2 is ON. After that, it goes back and forth between the absolute position 100,000 and 0. The direction indication flag SM1672 is ON when the servo goes toward the target position for the first time after Servo-ON. After that, the flag repeats the state, changing from ON to OFF.
- 3. You can modify the target position at any time in the motion, but the new target position is only valid for the next back and forth cycle.




API	Instruction			Operand							Description			
2805	D	PLSVC		S <sub>1</sub> , S <sub>2</sub>							Servo speed control			

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
S <sub>1</sub>								●					○	○		
S <sub>2</sub>								●	●				○	○		

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
S <sub>1</sub>			●				●						
S <sub>2</sub>			●				●						

Pulse instruction	16-bit instruction	32-bit instruction
—	—	AS

**Symbol**



**S<sub>1</sub>** : Node ID of a servo

**S<sub>2</sub>** Target speed

**Explanation**


1. ECAT communication is available for the PLC with firmware V1.14.00 or later and ISPSOft V3.16 or later, and the AS-FECAT function card must be installed on the PLC.
2. For CAN communication, the INITC and ASDON (servo ON) instructions must be complete before this instruction is executed. For ECAT communication, the INITEC and ASDON (servo ON) instructions must be complete before this instruction is executed.
3. For CAN communication, the range of **S<sub>1</sub>** is 1–8. There will be no execution when the input value is out of the range. For ECAT communication, the range of **S<sub>1</sub>** is 1–16. There will be no execution when the input value is out of the range.
4. Table to describe S<sub>2</sub>

Servo type	Range of S <sub>1</sub>	Range of S <sub>2</sub>	Descriptions of S <sub>2</sub>
Servo	1-8 (CAN) 1-16 (ECAT)	-60000 - 60000 (0.1rpm)	The +/- sign indicates the forward / reverse direction. For example, when inputting 6005 in S <sub>2</sub> , the value is 600.5rpm.
Inverter	21-28 (CAN) 1-16 (ECAT)	-32768 - 32767 (1rpm)	The +/- sign indicates the forward / reverse direction. For example, when inputting 605 in S <sub>2</sub> , the value is 605rpm.

- 5. For corresponding SM and SR of the axes, refer to the DRVIC instruction (API 2803).
- 6. SM1682 is set to ON when an error occurs during communication. In addition, SR658 retains the number of the axis in which the error occurs and SR659 retains the error code.


**Example 1 (communication with Delta servo systems)**

- 1. When M0 changes from OFF to ON, the INITC instruction starts to initialize the servos at node ID 1–3, until SM1681 is ON.
- 2. When M1 changes from OFF to ON, the ASDON instruction starts to enable the servo at node ID 2. When SM1652 is ON, it indicates Servo-ON.
- 3. When M2 changes from OFF to ON, servo 2 moves at 100.0 rpm until M2 is OFF.



**Example 2 (communication with Delta inverters)**

1. When M0 changes from OFF to ON, this instruction starts to initialize the node ID 21. When SM1683 is ON, it indicates the initialization is complete.
2. When M1 changes from OFF to ON, this instruction starts to set the acceleration time and deceleration time at the node ID 21.
3. When M2 changes from OFF to ON, this instruction starts to set the control mode at the node ID 21.
4. When M3 changes from OFF to ON, the inverter moves at 2500rpm until M3 goes OFF.



6


API	Instruction			Operand								Description				
2806	D	ZRNC		<b>S<sub>1</sub>, S<sub>2</sub>, S<sub>3</sub></b>								Servo homing				

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	“\$”	F
<b>S<sub>1</sub></b>								●					○	○		
<b>S<sub>2</sub></b>								●	●				○	○		
<b>S<sub>3</sub></b>								●	●				○	○		

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
<b>S<sub>1</sub></b>		●				●							
<b>S<sub>2</sub></b>		●	●			●							
<b>S<sub>3</sub></b>		●	●			●							

Pulse instruction	16-bit instruction	32-bit instruction
—	AS	AS

**Symbol**



- S<sub>1</sub>** : Node ID of servo
- S<sub>2</sub>** : The 1<sup>st</sup> – segment speed
- S<sub>3</sub>** : The 2<sup>nd</sup> – segment speed

**Explanation**


1. ECAT communication is available for the PLC with firmware V1.14.00 or later and ISPSOft V3.16 or later, and the AS-FECAT function card must be installed on the PLC.
2. For CAN communication, the INITC and ASDON (servo ON) instructions must be complete before this instruction is executed. For ECAT communication, the INITEC and ASDON (servo ON) instructions must be complete before this instruction is executed. It is suggested to use ZRNM (API 2810) to set all the axes of servo to the homing mode.
3. For CAN communication, the range of **S<sub>1</sub>** is 1–8. There will be no execution when the input value is out of the range. For ECAT communication, the range of **S<sub>1</sub>** is 1–16. There will be no execution when the input value is out of the range or if the device of the assigned ID is not a servo.
4. The range of **S<sub>2</sub>** is 1–20000. Unit: 0.1 rpm (servo drive parameter P5-05); if you need to use linear motor drive and the first section exceeds 32767, you need to use DZRNC instruction instead (only available for PLC FW V1.04 or later).
5. The range of **S<sub>3</sub>** is 1–5000. Unit: 0.1 rpm (servo drive parameter P5-06)
6. When the servo returns to the home position, the corresponding finish flags of the axes are ON. Refer to the DRVIC instruction (API 2803) for explanations of special flags (SM) and registers (SR).


- SM1682 is set to ON when an error occurs during communication. In addition, SR658 retains the number of the axis in which the error occurs and SR659 retains the error code.

**Example**

- When M0 changes from OFF to ON, the INITC instruction starts to initialize servo 1, until SM1681 is ON.
- When M1 changes from OFF to ON, the acceleration time (10000) and deceleration time (20000) of servo 1 are set by using the CASD instruction (API 2802). When SM1651 is ON, it indicates Servo-ON.
- When M2 changes from OFF to ON,
  - 2-byte data is written to P5-04 in servo 1. When D100 = 5 and the data is written, M100 is ON.
  - 4-byte data is written to P6-00 in servo 1. When D102 = 0 and the data is written, M101 is ON.
  - 4-byte data is written to P6-01 in servo 1. When D104 = 0 and the data is written, M102 is ON.

P5-04 sets the homing mode.  
P6-00 and P6-01 are the homing definitions.
- When M3 changes from OFF to ON, the homing function is enabled for servo 1.





API	Instruction		Operand										Description			
2807		COPRW	<b>S<sub>1</sub>, S<sub>2</sub>, S<sub>3</sub>, S<sub>4</sub>, S<sub>5</sub>, D</b>										Reading and writing CANopen communication data			


Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
<b>S<sub>1</sub></b>								●					○	○		
<b>S<sub>2</sub></b>								●	●				○	○		
<b>S<sub>3</sub></b>								●	●				○	○		
<b>S<sub>4</sub></b>								●	●				○	○		
<b>S<sub>5</sub></b>								●								
<b>D</b>		●	●	●				●								

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
<b>S<sub>1</sub></b>		●				●							
<b>S<sub>2</sub></b>		●				●							
<b>S<sub>3</sub></b>		●				●							
<b>S<sub>4</sub></b>		●				●							
<b>S<sub>5</sub></b>		●				●							
<b>D</b>	●												

Pulse instruction	16-bit instruction	32-bit instruction
—	AS	—

6

Symbol



- S<sub>1</sub>** : Node ID of servo or slave
- S<sub>2</sub>** : Request code
- S<sub>3</sub>** : Index
- S<sub>4</sub>** : Sub-index
- S<sub>5</sub>** : Read/write device
- D** : Communication completion flag

Explanation

- This instruction reads and writes CANopen communication data to the servo at the address specified in **S<sub>1</sub>**. The range of **S<sub>1</sub>** is 1–127. If the value is out of range (<1 or >127), the minimum or maximum value is automatically processed by the instruction as the value of **S<sub>1</sub>**.
- S<sub>2</sub>** can only specify four types of request codes, as shown in the following table. If you set the request code wrong, it does NOT execute; SM1682 is ON and SR659 is 16#0005.

<b>S<sub>2</sub></b> <b>(only available for values of lower 8-bit)</b>	<b>Description</b>
16#0023	Writing the 4-byte data; Expedited SDO
16#002B	Writing the 2-byte data; Expedited SDO
16#002F	Writing the 1-byte data; Expedited SDO
16#0040	Reading the data. The data length is contained in the SDO response message; Expedited SDO
16#0021	Data and its length are specified by S <sub>5</sub> ; Normal SDO
16#0041	Reading the data and store the read data and its length in S <sub>5</sub> ; Normal SDO

- For **S<sub>3</sub>** and **S<sub>4</sub>**, refer to the object dictionary in the Delta servo / inverter operation manual or the object dictionary from a third-party device that complies with CANopen DS301.
- You should execute the COPRW instruction only after the INITC instruction is complete in case the parameters are overwritten by the INITC instruction. Use the COPRW instruction for CANopen SDO communication. If the node ID of a slave exceeds the range 1–8 or 21-28, you can use the COPRW instruction to set, read, and write slave-related parameters.

When you use Delta Special Driver & AS Remote mode / Delta Special Driver & CANopen DS301 and execute COPRW instruction (SDO communication), the communication timeout is shown below.

Baud rate (bps)	1M	500K	250K	125K	50K
Communication timeout (ms) <sup>#1</sup>	100	100	200	400	500

When the mode is CANopen DS301, you can set the time of the COPRW timeout in the CANopen communication setting option from HWCONFIG; default timeout is 100 ms.


- SM1682 is set to ON when an error occurs during communication. In addition, SR658 retains the ID number in which the error occurs and SR659 retains the error code. Refer to DRVIC instruction for details.

**Note:** When you use the COPRW instruction, you must edit the process for dealing with communication errors in order to avoid invalid communication occurring as a result of unexpected communication errors.


- The diagram below shows the timing of the COPRW instruction.

- ① When you enable the COPRW instruction for the first time, the instruction sends the command code immediately if no other CANopen communication is using it.
- ② The instruction sends the command code.
- ③ The code has been sent and the finish flag is set to ON.

- ④ You modify the next data to be sent out. The next command code is sent out immediately after the finish flag is set to OFF.
- ⑤ The code has been sent and the COPRW instruction is disabled.



- 7. The COPRW instruction only supports the **Delta Special Driver & AS Remote Mode** and **CANopen DS301** in the hardware configuration setting (HWCONFIG in ISPSOft).



- 8. Most of the parameters in Delta ASDA-A2 are displayed in the decimal format. You can convert the parameters into index addresses, see the example below. 0 is a fixed value for the sub index address.

Example: The index address of PX-YY=0x2000 + (X << 8) + YY

$$P2-10 = 0x2000 + (0x0002 \ll 8) + 0x000A = 0x220A$$

$$P5-04 = 0x2000 + (0x0005 \ll 8) + 0x0004 = 0x2504$$

$$P1-44 = 0x2000 + (0x0001 \ll 8) + 0x002C = 0x212C$$

9. Most of the parameters in Delta inverter are also displayed in the decimal format. Use the following formula to convert the parameters.

Example: The index address of PXX-YY=0x2000 + XX (hexadecimal);

The sub index address is YY+1 (hexadecimal)


The index address of P10-15 = 0x2000 + 0x000A = 0x200A

The sub index address is 0x0F+1= 0x10

10. Since this instruction uses SDO (Service Data Objects) and the communication mode is one transmission (one sending/one receiving) at a time, and the communication right is shared with the high-speed output instructions. When writing PLC programs, bear the followings in mind.
- \* It is suggested NOT to use 2 COPRW instructions or communication at a time in one scan cycle.
  - \* It is suggested NOT to use this instruction in a function block. Because when this instruction is written in a function block, there will be 2 POU in the PLC program and when the function block is called, 2 instructions will be enabled at the same time.
11. The request codes for normal SDO are 16#0021 and 16#0041, available for PLC CPU with firmware V1.04.80 or later.
12. When the request code is 16#0021,  $S_5$  is the data length ("n" byte) to write into the slave.  $S_{5+1} \sim S_{5+(n+1)/2}$  is the data to write into the slave. For example, if  $S_5$  is specified as D100 and the value in  $S_5$  is 16. This instruction sends data in D101 ~ D108 to the slave in the following order, lower 8-bit in D101, upper 8-bit in D101, lower 8-bit in D102, upper 8-bit in D102 and so forth.
13. When the request code is 16#0041, when received responses from the slave, this instruction stores the data length ("n" byte) in  $S_5$  and data in  $S_{5+1} \sim S_{5+(n+1)/2}$ . For example, if received 15 bytes of data length, D100 is 15 and store the data Byte[0], Byte[1].. Byte[14] in the following order, lower 8-bit in D101, upper 8-bit in D101, lower 8-bit in D102, upper 8-bit in D102 and so forth.
14. The maximum data length is 255 bytes. To prevent too many Normal SDO transmissions, if the data length exceeds 255 bytes, PLC only sends or receives 255 bytes.

**Example (using Expedited SDO)**

1. When M0 changes from OFF to ON, the INITC instruction starts to initialize the servos at node ID 1–3, until SM1681 is ON.
2. When M1 changes from OFF to ON, the PLC writes the 2-byte data ( $S_2=16\#002B$ ) in D100 to P5-04 ( $S_3=16\#2504$ ) of servo 3, using the COPRW instruction. When the writing is complete, M100 is ON.
3. When M2 changes from OFF to ON, the PLC reads the value of P4-07 ( $S_3=16\#2407$ ) of servo 3 and stores the value ( $S_2=16\#0040$ ) in D106. When the reading is complete, M106 is ON.



6

API	Instruction			Operand								Description			
2808	D	COPWL		<b>S<sub>1</sub>, S<sub>2</sub>, S<sub>3</sub>, D</b>								Writing multiple CANopen parameter values			

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	“\$”	F
<b>S<sub>1</sub></b>								●					○	○		
<b>S<sub>2</sub></b>								●	●							
<b>S<sub>3</sub></b>								●					○	○		
<b>D</b>		●	●	●				●								

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
<b>S<sub>1</sub></b>		●				●							
<b>S<sub>2</sub></b>		●	●			●	●						
<b>S<sub>3</sub></b>		●				●							
<b>D</b>	●												

Pulse Instruction	16-bit instruction	32-bit instruction
—	AS	AS

### Symbol

COPWL		DCOPWL	
En		En	
S <sub>1</sub>	D	S <sub>1</sub>	D
S <sub>2</sub>		S <sub>2</sub>	
S <sub>3</sub>		S <sub>3</sub>	

- S<sub>1</sub>** : Node ID (Mac ID)  
**S<sub>2</sub>** : Starting source device where written data are stored  
**S<sub>3</sub>** : Number of messages to consecutively write data  
**D** : Communication completion flag

### Explanation

- S<sub>1</sub>** sets the node ID within the range of 1~127. If the setting value exceeds the range (< 1 or >127), the instruction will automatically send data at the minimum or maximum value respectively.
- S<sub>2</sub>** is the starting source device where written data are stored and **S<sub>3</sub>** is the number of messages to consecutively write data. E.g., **S<sub>2</sub>** specifies D10 as the starting device and the number of messages to consecutively write data is 3. Here is the detailed explanation in the following table.

Instruction name	Message No.	Index address	Subindex address	Written source data
COPWL (Writes 16-bit values)	1	D10	D11	D12
	2	D13	D14	D15
	3	D16	D17	D18
DCOPWL (Writes 32-bit values)	1	D10	D11	D12, D13
	2	D14	D15	D16, D17
	3	D18	D19	D20, D21


The value of **S<sub>3</sub>** is in the range of 1~100.

3. For the index addresses and subindex addresses of Delta servo and AC motor drive, refer to the explanation of the COPRW instruction. In principle, the parameter values of Delta servo and AC motor drive are both 16-bit or 32-bit values including floating point numbers. If you need write an 8-bit value, use the COPRW instruction.
4. **D** is the communication completion flag. **D** will turn on after the sending of multiple communication messages is complete.

See the detailed sending process and sequence diagram below.

- ① The COPWL instruction is enabled and starts to send data.
- ② After the COPWL instruction sends one piece of message, the next PLC instruction continues to execute.
- ③ As the COPWL instruction is scanned once again and the prior message has been received by the slave, the COPWL instruction sends the next message.
- ④ When the last written-data sending is done, the instruction will set the completion flag to ON.
- ⑤ When the completion flag turns on, the COPWL instruction need be disabled by manual so that the subsequent COPWL or COPRW instruction can continue to work.

Note: When you disable the instruction, the completion flag will be automatically cleared accordingly.



Note: The sequence diagram above shows the sending of 3 pieces of written data.


5. After the instruction is enabled, wait until the writing is complete and then disable the instruction. If there is a communication error in the execution, shoot the trouble and then re-enable the instruction to write all data.

**Example**

1. When M1 = OFF → ON, data are written in D device.

Instruction name	Data No.	Index address	Subindex address	Written data source
DCOPWL (Writes 32-bit values)	1	D50 = 16#212C (E-gear ratio numerator)	D51 = 0	D52, D53 = 77777777
	2	D54 = 16#212D (E-gear ratio denominator)	D55 = 0	D56, D57 = 88888888

2. When M1 = OFF → ON, the instruction writes a 32-bit value for P1-44 of the servo whose node ID is 2 and the written value 77777777 is stored in D52. The instruction writes a 32-bit value for P1-45 and the written value 88888888 is stored in D56. As the writing is complete, M201 turns on.




API	Instruction			Operand							Description			
2809		RSTD		Node, Para, Ok, Err							Sending Reset or NMT command			

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
Node								●					○	○		
Para								●					○	○		
Ok		●	●	●												
Err		●	●	●												

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
Node		●											
Para		●											
Ok	●												
Err	●												

Pulse Instruction	16-bit instruction	32-bit instruction
—	AS	—

**Symbol**



- Node** : Node ID which is reset
- Para** : Setting value of the parameter
- Ok** : The reset completion flag
- Err** : The reset error flag

**Explanation**

1. Only the PLC firmware of V1.04.10 and later and the ISPSOft software of V3.03.08 and later support the instruction. ECAT communication is available for the PLC with firmware V1.14.00 or later and ISPSOft V3.16 or later, and the AS-FECAT function card must be installed on the PLC.
2. For CAN communication, before the RSTD instruction is used in Delta special instruction mode, make sure that all Delta servos / inverters have been initialized via the INITC instruction and they once worked normally.
3. For ECAT communication, before the RSTD instruction is used in Delta special instruction mode, make sure that all Delta servos / inverters have been initialized via the INITEC instruction and they once worked normally.
4. For CAN communication, when used in CANopen DS301 mode, the RSTD instruction works as the NMT communication function and can switch network states via the **Para** parameter.
5. For CAN communication, when CAN communication port is specified to work in Delta special driver mode, the value of **Node** can be 0 (for the broadcast function) and 1~8 which are for servo node ID only and 21~28 for node

ID of AC motor drives only. When the node ID exceeds the range, the PLC will not perform the reset action and the **Err** flag turns on. (Refer to the explanation of SR659 for error codes)

6. For CAN communication, when CAN communication port is specified to work in CANopen DS301 mode, the value of **Node** is in the range of 1~64 and 0 (for the broadcast function). When the value exceeds the range, the PLC will not perform the NMT communication and the **Err** flag turns on. (Refer to the explanation of SR659 for error codes)
7. For ECAT communication, the value of **Node** can be 0 (for the broadcast function) and 1~16 which are for servo / inverter node ID. When the node ID exceeds the range, the PLC will not perform the reset action and the **Err** flag turns on. (Refer to the explanation of SR659 for error codes)
8. The setting value of **Para** is only applicable to CANopen DS301 mode. The parameter is meaningless if the instruction is used in Delta special driver mode and AS remote mode. The settings for **Para** (NMT service code) are listed in the following table. If the setting value is not one of the values in the table, the **Err** flag turns on.

NMT service code	16#01	16#02	16#80	16#81	16#82
Function description	Start the slave	Stop the slave	Enter the pre-operational state	Reset the application layer	Reset the communication

9. The RSTD instruction can implement the command action on only one drive or slave every time. If multiple RSTD instructions are enabled simultaneously, the PLC will automatically take priority to perform the instruction which is enabled earlier.
10. The RSTD instruction is executed to send the command when it is enabled. If the instruction is disabled before the **Ok** flag is on, the PLC will not set the **Ok** flag to ON.
11. Apart from notifying the specified drive to clear the error state, the instruction would also re-check if relevant communication parameter values are correct and re-set correct communication parameter values.

For example, due to the disconnection of the slave of node ID 2, the entire system stops running. After the trouble is solved, the slave of node ID 2 can return to the state of being controllable by using the RSTD instruction to reset the slave of node ID 2 only. So the time of re-initializing all drives are saved.

12. If the slave responds by sending back any communication command fault to the PLC during the communication, the RSTD instruction will turn the **Err** flag on and stop the upcoming actions. (Refer to explanation of SR659 for error codes.)


API	Instruction			Operand								Description			
2810		ZRNM		<b>Node, Mode, Ok, Err</b>								Setting the homing mode for Delta servo			

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	“\$”	F
<b>Node</b>								●					○	○		
<b>Mode</b>								●					○	○		
<b>Ok</b>		●	●	●												
<b>Err</b>		●	●	●												

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
<b>Node</b>		●											
<b>Mode</b>		●											
<b>Ok</b>	●												
<b>Err</b>	●												

Pulse Instruction	16-bit instruction	32-bit instruction
—	AS	—

**Symbol**



- Node** : Specified node ID
- Mode** : Homing mode code
- Ok** : Completion flag
- Err** : Error flag

**Explanation**

1. Only the PLC firmware of V1.04.10 and later and the ISPSOft software of V3.03.08 and later support the instruction. ECAT communication is available for the PLC with firmware V1.14.00 or later and ISPSOft V3.16 or later, and the AS-FECAT function card must be installed on the PLC.
2. Make sure that all Delta drives have been initialized before executing the reset instruction.
3. For CAN communication, the value of **Node** is in the range of 1~8 (exclusive for servo node IDs) or in the range of 1~16 for ECAT communication. If the setting value exceeds the range or if the device of the assigned ID is not a servo, the PLC will not perform the action of the homing mode and set the **Err** flag to ON. (Refer to explanation of SR659 for error codes.)
4. The ZRNM instruction can set the homing mode of only one drive every time. If multiple instructions are enabled simultaneously, the PLC will take priority to perform the instruction which is enabled earlier.
5. The ZRNM instruction is executed to send the command when it is enabled. If the instruction is disabled or will NOT be scanned again before the **Ok** flag is on, the PLC will NOT be able to set the **Ok** flag or Err flag to ON.

6. This instruction will only be triggered once when the EN contact is switched from OFF to ON. It is suggested to use this instruction in the ladder programming. If using this instruction in SFC or ST programming, when the EN contact is OFF, it can NOT be scanned.
7. **Mode** sets a homing mode. If the setting value exceeds the range, the PLC will still send the command and the server itself will decide whether to receive the command or not. The setting mode is the homing mode that ASDA servo parameter P5-04 corresponds to.

The setting value of Delta servo homing mode is a hex value. The value is defined as the format of 0xWZYX. See the explanation of respective codes as below.

Homing mode code	Range	Function and code description	Remark
W	0 ~ 1	Select the final position where the servo stops. 0 = The servo leaves the home position, decelerates and stops and then automatically returns to the actual home position. 1 = After leaving the home position, decelerating and stopping, the servo will not perform any action any more.	
Z	0 ~ 1	Handling mechanism when the limit is encountered. 0 = Output stops. 1 = Output is conducted in the reverse direction.	
Y	0 ~ 2	Z pulse signal setting (used for X code 0~8 ) 0 =Look for Z pulse when coming back. Do not look for Z phase when going forward. 1 =Go forward to Z pulse. Do not look for Z pulse when coming back. 2 =Do not look for Z pulse. Z pulse signal handling method (applicable to X code: 9~A) 0 =Look for Z pulse when coming back. 1 =Do not look for Z pulse both when coming back and going forward.	
X	0 ~ A	Homing method: 0~8 0 = Homing in the forward direction; <b>PL</b> is the home position. 1 = Homing in the reverse direction; <b>NL</b> is the home position. 2 = Homing in the forward direction; <b>ORGP</b> : OFF > ON, as the home position. 3 = Homing in the reverse direction; <b>ORGP</b> : OFF > ON, as the	

		<p>home position.</p> <p>4 = Homing in the forward direction; look for Z pulse and regard it as the home position.</p> <p>5 = Homing in the reverse direction; look for Z pulse and regard it as the home position.</p> <p>6 = Homing in the forward direction; <b>ORGP</b>: ON &gt; OFF, as the home position.</p> <p>7 = Homing in the reverse direction; <b>ORGP</b>: ON &gt; OFF, as the home position.</p> <p>8 = Current position is the home position.</p> <p>Homing method: 9~A</p> <p>9 = Homing in the forward direction; the collision point is the home position.</p> <p>A = Homing in the reverse direction; the collision point is the home position.</p>	
--	--	---	--


API	Instruction			Operand								Description			
2811	EMER			Node, Dest, Len, Ok, Err								Reading Emergency message			

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	“\$”	F
Node								●					○	○		
Dest								●								
Len								●								
Ok		●	●	●												
Err		●	●	●												

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
Node		●											
Dest		●											
Len		●											
Ok	●												
Err	●												

Pulse Instruction	16-bit instruction	32-bit instruction
—	AS	—

**Symbol**



- Node** : Specified node ID
- Dest** : Target device for storing data
- Len** : Total number of 4 words of data which have been read
- Ok** : Completion flag
- Err** : Error flag

**Explanation**

1. Only the PLC firmware of V1.04.10 and later and the ISPSOft software of V3.03.08 and later support the instruction. ECAT communication is available for the PLC with firmware V1.14.00 or later and ISPSOft V3.16 or later, and the AS-FECAT function card must be installed on the PLC.
2. The EMER instruction is applicable to CANOpen DS301 mode, Delta special mode and ECAT communication.
3. After receiving the Emergency message from the slave **Node**, the PLC will automatically store the data in the specified storage device and set the **Ok** flag to ON.
4. It is recommended that the **Node** value should be specified from the slave node IDs which have already existed. If the value is not one existing node ID or the slave has been disconnected, the PLC will not be able to receive any message, set the **Err** flag to ON and show error code of communication timeout. (Refer to explanation of SR659

for error codes.)

5. The way the EMER instruction reads Emergency messages is the same as Emergency communication method in AS operation manual. Please just select one communication method from them when reading Emergency messages.
6. The EMER instruction can read 5 Emergency messages at most. Every time the reading is successful, the **Ok** flag turns on and **Len** displays the total number of messages which are read. You can judge how many consecutive words are occupied by **Dest** based on the length. Every message uses 4 words. The data are stored in the order from lower 8 bits to higher 8 bits. The storage format is shown as below. (E.g. **Dest** is D10, **Len** is 2 which is the number of messages stored in D5.)

D device no.	Value
D5	2

D device no.	Higher 8 bits	Lower 8 bits
D10	The second byte in the first message	The first byte in the first message
D11	The forth byte in the first message	The third byte in the first message
D12	The sixth byte in the first message	The fifth byte in the first message
D13	The eighth byte in the first message	The seventh byte in the first message
D14	The second byte in the second message	The first byte in the second message
D15	The forth byte in the second message	The third byte in the second message
D16	The sixth byte in the second message	The fifth byte in the second message
D17	The eighth byte in the second message	The seventh byte in the second message


API	Instruction			Operand								Description				
2812	D	CSFOC		Xno ~ OutSpd								Controlling the tracking function of a servo via communication				

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	“\$”	F
Xno	○															
InCnt								●								
InSpd								●								
Gear								●								●
Axis								●					●	●		
OutCnt								●								
OutSpd								●								

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
Xno	●												
InCnt			●				●						
InSpd			●				●						
Gear									●				
Axis		●											
OutCnt			●				●						
OutSpd			●				●						

Pulse Instruction	16-bit instruction	32-bit instruction
—	—	AS

Symbol



- Xno** : Signal input device
- InCnt** : Number of input pulses
- InSpd** : Pulse input frequency
- Gear** : Proportion of the input frequency and output frequency (floating-point value)
- Axis** : CANopen node ID of Delta servo
- OutCnt** : Number of output pulses (unit: per user unit (PUU))
- OutSpd** : Pulse output frequency

**Explanation**

1. For CAN communication, the PLC firmware of V1.06 and later and the ISPSOft software of V3.07 and later support the instruction. ECAT communication is available for the PLC with firmware V1.14.00 or later and ISPSOft V3.16 or later, and the AS-FECAT function card must be installed on the PLC.
2. For CAN communication, the INITC and ASDON (servo ON) instructions must be complete before this instruction is executed. For ECAT communication, the INITEC and ASDON (servo ON) instructions must be complete before this instruction is executed.
3. **Xno** can only specify X0.0, X0.2, X0.4, X0.6, X0.8 and X0.10 as the input points, and the operand occupies two consecutive input points. You cannot execute the instruction if the input points are the points specified for **Xno** above. After you select the input points, the high-speed counter is automatically specified. If there is a DCNT instruction (API 1004) or CSFO instruction (API 2708) with the same high-speed counter in the program, the PLC first executes the instruction that starts the counter first. The input points and corresponding high-speed counters are shown in the following table.

Group number	1	2	3	4	5	6
<b>Xno+0</b> input point (Phase A)	X0.0	X0.2	X0.4	X0.6	X0.8	X0.10
<b>Xno+1</b> input point (Phase B)	X0.1	X0.3	X0.5	X0.7	X0.9	X0.11
High-speed counter number	HC202	HC206	HC210	HC214	HC218	HC222
Flag for reversing input direction	SM270	SM271	SM272	SM273	SM274	SM275

4. If the high-speed counters for the instruction can use only the phase A/B input mode, set the flag for reversing the input direction to ON when MPG is connected but has not rotated yet, and the PLC input point is ON. Set the function to detect the state of PLC run cycle to OFF.
5. **InCnt** is the number of input pulses. Use a 32-bit variable to declare the parameter.
6. **InSpd** is the frequency of input pulses. Use a 32-bit variable to declare the parameter with the unit of 1 Hz.
7. **Gear** is the proportion of the input frequency and output frequency (floating-point value). The formula is that output frequency equals to the result of input frequency multiplying Gear. For instance, if Gear is 2.5 and the input frequency is 50, the output is 125 (50\*2.5). Note: the output count and the output frequency are rounded down to the nearest whole digit when outputting.

8. **Axis** is the node ID, ranging from 1 to 8 for CAN communication and it should be within the node ID that is initiated by the INITC instruction. For ECAT communication, the node ID ranges from 1 to 16 and it should be within the node ID that is initiated by the INITEC instruction and the device of the assigned ID should be a servo.
9. **OutCnt** is the number of output pulses. Use a 32-bit variable to declare the parameter with the unit of PUU.
10. **OutSpd** is the frequency of the output pulses. Use a 32-bit variable to declare the parameter with the unit of 1 Hz.
11. There is no limit to the number of times you can use this instruction. Several instructions can use one group of input points as its source of input count. But you need to clear the value in the input counter before execution of this instruction; especially when you are using one input and several outputs. And this instruction executes according to the axis number to record information about its input and output. The same axis can be used for several times but you must not output the same axis at the same time. If you use the same axis to output for several times, PLC outputs the first starting one and then the second one. For ECAT communication, up to four slaves can be controlled simultaneously. If exceeding the limit, this instruction is NOT executed and SM0 is ON, the error code stores in SR0 is 16#2003.
12. The instruction cannot be used in the ST programming language, interrupt tasks or function block which is called only once.


#### Note

1. The PLC calculates the input pulse frequency based on the input pulse width (ON) in the positive half cycle. If the proportion of the pulse width for ON:pulse width for OFF is not 1:1, the PLC takes the ON width as the standard for conversion by default.
2. The input pulse=ON means the input point LED is on. When using the MPG but it has not rotated yet, you can check if the input point LED is OFF and the flag for reversing the input direction is activated .
3. There is a 20 ms time difference in CANopen / ECAT communication when executing this instruction. If this worries you, use CSFO instruction instead, controlling the servo by the pulse output.

#### Example

- When M0 switches from OFF to ON, PLC starts to execute this instruction to initialize servo node ID 1 and 2 until SM1681 is ON.
- When M1 switches from OFF to ON, PLC starts to execute this instruction to start servo node ID 1 and when the servo is started, SM1651 is ON, meaning Servo-ON.
- When M2 switches from OFF to ON, PLC starts to execute this instruction to start servo node ID 1 and when the servo is started, SM1652 is ON, meaning Servo-ON.

- When M3 switches from OFF to ON, input points X0.0 and X0.1 connect to the MPG to control 2 servos. The proportions for the 1<sup>st</sup> servo is 1 and for the 2<sup>nd</sup> servo is 2.



6


API	Instruction			Operand								Description			
2813	ECAMD			Slave ~ ErrCode								Downloading E-CAM chart to the Slave			

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
Slave								●					○	○		
Source								●	●				○	○		
Len								●					○	○		
CAddr								●					○	○		
Done		●	●	●												
Err		●	●	●												
ErrCode								●								

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
Slave		●				●							
Source		●				●							
Len		●				●							
CAddr		●				●							
Done	●												
Err	●												
ErrCode		●				●							

Pulse Instruction	16-bit instruction	32-bit instruction
—	AS	—

Symbol



- Slave** : Servo slave station number
- Source** : From which E-CAM chart to start downloading
- Len** : The length of the E-CAM chart
- CAddr** : From which address to start storing E-CAM chart in the servo
- Done** : Downloading complete flag

Explanation

- For execution of this instruction, you need to use PLC FW V1.06 or later and ISPSOft V3.07 or later.
- Slave** is where you store the downloaded E-CAM chart; the supported slave station ranges from 1 to 8. After the downloading is complete, the **DONE** flag is ON. If the slave station number you are using is out of the supported range, the instruction is NOT executed. And the **Err** (error) flag is ON.

3. **Source** is where you specify from which E-CAM chart to start downloading; the supported E-CAM chart length is from 1 to 16. If the E-CAM chart number you are using is out of the supported length, the instruction is NOT executed. And the **Err** (error) flag is ON. You can also use the PLC data register number to specify from which E-CAM chart to start downloading to the servo and it takes **Len+1** as its downloading length. After the setting is done, the system starts to read from the specified data register number (device number) to a length of **Len +1** (32-bit) consecutively to the servo. If the **Source** is D10 and the **Len** is 10, the system starts to read from D10 to a length of 10+1, starting from D10/D11, D12/D13 to D30/D31 to the servo.
4. **Len** is the E-CAM chart length for downloading; its setting range is from 1 to 720. If the length you are using is out of the supported range, the instruction is NOT executed. And the **Err** (error) flag is ON. The servo supports up to 800; if the **Len+1** exceeds 800, PLC stops downloading and the **Err** (error) flag is ON.
5. **CAddr** is the starting address where to store the E-CAM chart in the servo; the supported setting range is from 0 to 798. If the starting address you are using is out of the supported range, the instruction is NOT executed. And the **Err** (error) flag is ON.
6. If the supported 16 E-CAM charts are not sufficient, you can choose to download the E-CAM charts to the PLC file register while editing in the E-CAM Editor.
7. You can make use of the 1<sup>st</sup> ~ 800<sup>th</sup> storage in the servo. When creating E-CAM charts with not so many points (less than 800), you can download the E-CAM charts altogether at one time to save communication time. For example, if you use points 1-200 in chart A and 201-400 in chart B, the points in chart A plus the points in chart B are 400 (less than 800), you can download these two charts at one go.
8. Once executing this instruction, it clears the **Done** flag first and then sends the E-CAM chart. Once the transmission is complete, the **Done** flag is ON. If any error occurs from the slaves, the **Err** (error) flag is ON. If you need to resend the E-CAM chart, you need to wait for one scan time before executing this instruction again.
9. If the **Err** (error) flag is ON, refer to the definitions below.

ErrCode	Description
0001	This slave station number is NOT in the supported range.
0002	This E-CAM chart number is NOT in the supported range.
0003	This CAddr. Address or length is NOT in the supported range.
0004	No response from the slave.
0005	Error message sent from the slave while downloading or setting up.
0006	The PLC is NOT in the Delta Special Driver & AS Remote Mode nor in the Delta Special Driver & CANopen DS301 Mode.

API	Instruction			Operand								Description				
2814	D	ECAMS		Slave ~ ErrCode								E-CAM parameter setting and planning				

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
Slave								●					○	○		
Smode								●					○	○		
CAddr								●					○	○		
CLen								●					○	○		
Rpuu								●					○	○		
Cmode								●					○	○		
WbPuu								●					○	○		
OutT								●					○	○		
CaPuu								●					○	○		
CwPuu								●					○	○		
Orate								●					○	○		
Done		●	●	●												
Err		●	●	●												
ErrCode								●								

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
Slave		●				●							
Smode		●				●							
CAddr		●				●							
CLen		●				●							
RPuu			●				●						
Cmode		●				●							
WbPuu			●				●						
OutT		●				●							
CaPuu			●				●						
CwPuu			●				●						
ORate			●				●						
Done	●												
Err	●												
ErrCode		●				●							

Pulse Instruction	16-bit instruction	32-bit instruction
—	—	AS

**Symbol**

DECAMS	
En	
Slave	Done
Smode	Err
CAddr	ErrCode
CLen	
Rpuu	
Cmode	
WbPuu	
OutT	
CaPuu	
CwPuu	
Orate	

- Slave** : Servo slave station number
- Smode** : Command source for encoder of the master axis
- CAddr** : From which address to start storing E-CAM chart in the servo
- CLen** : Specified E-CAM chart length for executing
- RPuu** : Number of pulses for the master's E-CAM to rotate a full 360 cycle
- Cmode** : Engaging condition
- WbPuu** : Number of pulses for E-CAM to wait before engaging for the first time (32-bit value)
- OutT** : Disengaging condition
- CaPuu** : Number of pulses for E-CAM to wait before disengaging (32-bit value)
- CwPuu** : Number of pulses for E-CAM to wait before engaging again (32-bit value)
- ORate** : Output ratio for E-CAM chart (32-bit value)
- Done** : Downloading complete flag
- Err** : Error flag
- ErrCode** : Error code

**Explanation**

1. For execution of this instruction, you need to use PLC FW V1.06 or later and ISPSOft V3.07 or later.
2. This instruction is for setting up the E-CAM related parameters for the first time or setting up the E-CAM chart before the first engagement. If you need to modify the E-CAM chart during engaging, you need to use instruction ECAMC (API2816) instead.
3. **Slave** is the servo slave station, ranging from 1 to 8. If the slave station number you are using is out of the supported range, the instruction is NOT executed. And the **Err** (error) flag is ON. After modifying and the specified servo slave station responds correctly, the **DONE** flag is ON.
4. **Smode** is where you can set the command source for encoder of the master axis; the options are as shown below.

Command Source of Master Axis	Description
0	CAP axis (defined by CAP function)
1	Auxiliary encoder (P5-17)
2	Pulse command (A/B phase pulse) (P5-18)
3	PR command: the value of absolute coordinate from position command
4	Time axis (1ms)
5	Synchronous capture axis (P5-77)
6	Analog channel 1 (virtual axis; unit: 10 V corresponds to 1 M pulse/S)
12	Pulse command (CW/CCW pulse) (P5-18)
22	Pulse command (Pulse/Dir pulse) (P5-18)
Other numbers	Treated as option 2: Pulse command (A/B phase pulse) (P5-18)

- PLC sets up the servo parameter P5-88.Y according to the command source of the master axis. When the command source is Pulse Command, you need to set up the pulse type via the servo parameter P1-00 while the servo is OFF.
- CAddr** is the starting address where to store the E-CAM chart in the servo; the supported setting range is from 0 to 794. If the starting address you are using is out of the supported range, the instruction is NOT executed. And the **Err** (error) flag is ON. PLC sets the servo parameter P5-81 (start address of data array).
- CLen** is the specified E-CAM chart length for executing; its setting range is from 5 to 720. E-CAM chart is divided into **CLen** and the chart should include **CLen** +1 data. The servo supports 1<sup>st</sup> ~ 800<sup>th</sup> space; if the starting address is 501 and set the **CLen** to 400, this arrangement takes 902 (501+401) space which exceeds the 800<sup>th</sup> space, the instruction is NOT executed and the **Err** (error) flag is ON. PLC sets the servo parameter P5-82. Write this parameter when E-CAM stops (P5-88, X=0).
- RPuu** is where you set the number of pulses for the master's E-CAM to rotate a full 360 cycle; servo unit: PUU (per user unit). The value in **RPuu** should be 32-bit and ranges from 10 to 1073741823. When the value exceeds the upper or lower limit, it will be seen as the maximum value or the minimum value. PLC sets the servo parameter P5-83 and P5-84. Write the parameters when E-CAM stops (P5-88, X0=0).
- Cmode** is where you can set the engaging condition; the options are as shown below.

Mode	Description
0	Engage immediately
1	DI: CAM ON
2	Any one of the Capture
Other numbers	Treated as Mode 0, to engage immediately

- PLC sets the servo parameter P5-88.Z (engaging time).

11. **WbPuu** is where you set the number of pulses for E-CAM to wait before engaging for the first time. The value in **WbPuu** should be 32-bit and ranges from -1073741824 to +1073741823. When the value exceeds the upper or lower limit, it will be seen as the maximum vlaue or the minimum value. When the value is 0, it means no waiting before the first engagement. PLC sets the servo parameter P5-87.
12. **OutT** is where you can set the disengaging condition; the options are as shown below. Option 2, 4 and 6 cannot be selected at the same time.

Mode	Description	After disengaged
0	Never disengaged	-
1	DI: CAM OFF	In STOP status
2	Master axis receives the pulse number which is set by <b>CaPuu</b> (P5-89).	In STOP status
4	Master axis exceeds the setting value in <b>CaPuu</b> (P5-89).	Back to the pre-engaged status. The pre-engaged pulse is <b>CwPuu</b> (P5-92).
6	Same as 2; master axis receives the pulse number which is set by <b>CaPuu</b> (P5-89) but here E-CAM keeps its velocity while disengaging. Master axis exceeds the setting value in <b>CaPuu</b> (P5-89) a little bit. Suitable for the application of using the PR position command right after disengaged.	In STOP status
8	Work with option 1, 2 or 6; disable E-CAM after it is disengaged.	Set the servo parameter P5-88.X0 to 0.
	Work with option 4, to avoid jittering when it returns to pre-engaging status	-
Other numbers	Treated as Mode 0, to engage immediately	

13. PLC sets the servo parameter P5-88.U (disengaging time).
14. **CaPuu** is where you set the number of pulses for E-CAM to wait before disengaging. The value in **CaPuu** should be 32-bit and ranges from -1073741824 to +1073741823. When the value exceeds the upper or lower limit, it will be seen as the maximum vlaue or the minimum value. When the value is 0, it means no waiting before disengaging. PLC sets the servo parameter P5-89.
15. **CwPuu** is where you set the number of pulses for E-CAM to wait before engaging again. The value in **CwPuu** should be 32-bit and ranges from -2147483648 to +2147483647. When the value is 0, it means no waiting before engaging again. PLC sets the servo parameter P5-92.

16. **ORate** is where you set the output ratio for the E-CAM chart. The value in **ORate** should be a 32-bit integer and ranges from -2147000000 to +2147000000. When the value exceeds the upper or lower limit, it will be seen as the maximum value or the minimum value. PLC sets the servo parameter P5-19. For example, set **ORate** to 123000 and 123000 will be divided by 1000000 by the servo. And you will have 0.123 as the output ratio. Set **ORate** to 1500000 and 1500000 will be divided by 1000000 by the servo. And you will have 1.5 as the output ratio.
17. Once executing this instruction, it clears the **Done** flag first and then sends a request of setting E-CAM parameters. If the transmission works correctly, the **DONE** flag is ON. If any error occurs from the slaves, the **Err** (error) flag is ON. If you need to modify the E-CAM parameters, you need to wait for one scan time before executing this instruction again.
18. If the **Err** (error) flag is ON, refer to the definitions below.

ErrCode	Description
0001	This slave station number is NOT in the supported range.
0003	This downloading address (CAddr) or length (CLen) is NOT in the supported range.
0004	No response from the slave.
0005	Error message sent from the slave while downloading or setting up.
0006	The PLC is NOT in the Delta Special Driver & AS Remote Mode nor in the Delta Special Driver & CANopen DS301 Mode.


API	Instruction			Operand							Description			
2815	ECAMA			Slave ~ ErrCode							Activating E-CAM control and displaying the status			

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
Slave								●					○	○		
CAMEn	●	●	●	●												
CAMSt								●								
MIPuu								●								
SOPuu								●								
Err		●	●	●												
ErrCode								●								

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
Slave		●				●							
CAMEn	●												
CAMSt		●				●							
MIPuu			●				●						
SOPuu			●				●						
Err	●												
ErrCode		●				●							

Pulse Instruction	16-bit instruction	32-bit instruction
—	AS	—


Symbol



- Slave** : Servo slave station number
- CAMEn** : Activate E-CAM control
- CAMSt** : Display E-CAM status
- MIPuu** : Number of pulses inputted by the Master (unit: PUU)
- SOPuu** : Number of pulses outputted by the specified Slave (unit: PUU)
- Err** : Error flag
- ErrCode** : Error code

**Explanation**

1. For execution of this instruction, you need to use PLC FW V1.06 or later and ISPSOft V3.07 or later.
2. The INITC and ASDON (Servo-ON) instructions must be complete before this instruction is executed.
3. **Slave** is a servo slave station where you can specify to receive commands; the supported slave station ranges from 1 to 8. If the slave station number you are using is out of the supported range, the instruction is NOT executed. And the **Err** (error) flag is ON. If the specified servo slave station cannot communicate, the **Err** (error) flag is also ON.
4. **CAMEn** is where you can activate the E-CAM control. When the BOOL value in **CAMEn** is ON, it indicates E-CAM control is activated. When the BOOL value in **CAMEn** is OFF, it indicates E-CAM control is NOT activated. PLC sets the servo parameter P5-88, X=0 according to the status in **CAMEn**.
5. **CAMSt** is where you can find the E-CAM status in the servo according to the servo parameter P5-88.  
S: Shows the engage status (Read-only, the setting is invalid)  
0: Stop  
1: Engage status  
2: Pre-engage status



6. Status Description:
  - **Stop:** It is the initial status of the E-CAM. The E-CAM does not operate with the master pulse. When E-CAM function is disabled (P5-88, X=0), it returns to this status.
  - **Pre-engage:** When the engaged condition (path 1) is established, it enters this status. The E-CAM still does not operate with the master pulse.
  - **Engage:** When it reaches pre-engaged status (path 3), it enters this status. The E-CAM starts to operate with the master pulse.
7. Path Description:
  - **Path 1:** When the engaged condition is established (P5-88.Z), the status is Stop → Pre-engaged. The lead pulse is determined by P5-87.
  - **Path 2:** When the E-CAM function is disabled (P5-88.X=0), it returns to Stop status.

- **Path 3:** When it is in pre-engaged status, the status is Pre-engaged → Engaged.
  - **Path 4:** When the disengaged condition is established (P5-88, U=4), the status is Engaged → Pre-engaged. The lead pulse is determined by P5-92 (available for FM V1.006sub04 or later).
  - **Path 5:** When the disengaged condition is established (P5-88, U=1, 2, 6) or the E-CAM function is disabled (P5-88, X=0), the status is Engaged → Stop. °
8. **MIPuu** is wherer you can find the number of pulses received by the specified Slave from the Master. The unit is per user unit (PUU) of the servo. This value is shown accoridng to the servo parameter P5-86. When the instruction stops, this value does NOT refreshed either.
9. **SOPuu** is wherer you can find the number of pulses outputted by the specified Slave. The unit is per user unit (PUU) of the servo. This value is shown accoridng to the servo parameter CMD\_O. When the instruction stops, this value does NOT refreshed either.
10. If the **Err** (error) flag is ON, refer to the definitions below.

ErrCode	Description
<b>0001</b>	This slave station number is NOT in the supported range.
<b>0004</b>	No response from the slave.
<b>0005</b>	Error message sent from the slave while downloading or setting up.
<b>0006</b>	The PLC is NOT in the Delta Special Driver & AS Remote Mode nor in the Delta Special Driver & CANopen DS301 Mode.
<b>0007</b>	The slave is not initiated.


API	Instruction			Operand								Description				
2816	ECAMC			Slave ~ ErrCode								Modifying the starting address for E-CAM chart and the E-CAM chart length in the servo				

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
Slave								●					○	○		
CAddr								●					○	○		
CLen								●					○	○		
Done		●	●	●												
Err		●	●	●												
ErrCode								●								

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
Slave		●				●							
CAddr		●				●							
CLen		●				●							
Done	●												
Err	●												
ErrCode		●				●							

Pulse Instruction	16-bit instruction	32-bit instruction
—	AS	—

Symbol



- Slave** : Servo slave station number
- CAddr** : From which address to start storing E-CAM chart in the servo
- CLen** : Specified E-CAM chart length for executing
- Done** : Modification complete flag
- Err** : Error flag
- ErrCode** : Error code

Explanation

1. For execution of this instruction, you need to use PLC FW V1.06 or later and ISPSOft V3.07 or later.
2. This instruction is for modifying E-CAM chart settings. You need to download the E-CAM chart to the specified servo before using this instruction.
3. **Slave** is a servo slave station where you can specify to receive commands; the supported slave station ranges from 1 to 8. If the slave station number you are using is out of the supported range, the instruction is NOT executed. And the **Err** (error) flag is ON. If the specified servo slave station cannot communicate, the **Err** (error) flag is also ON.

After modifying the E-CAM parameters and the specified servo slave station responds correctly, the **DONE** flag is ON.

4. **CAddr** is the starting address where to store the E-CAM chart in the servo; the supported setting range is from 0 to 794. If the starting address you are using is out of the supported range, the instruction is NOT executed. And the **Err** (error) flag is ON. PLC sets the servo parameter P5-81 (start address of data array).
5. **CLen** is the specified E-CAM chart length for executing; its setting range is from 5 to 720. E-CAM chart is divided into **CLen** and the chart should include **CLen** +1 data. The servo supports 1<sup>st</sup> ~ 800<sup>th</sup> space; if the starting address is 501 and set the **CLen** to 400, this arrangement takes 902 (501+401) space which exceeds the 800<sup>th</sup> space, the instruction is NOT executed and the **Err** (error) flag is ON. PLC sets the servo parameter P5-82. Write this parameter when E-CAM stops (P5-88, X=0).
6. Once executing this instruction, it clears the **Done** flag first and then sends the modification request. After modifying the E-CAM parameters and the specified servo slave station responds correctly, the **DONE** flag is ON. If any error occurs from the slaves, the **Err** (error) flag is ON. If you need to modify the E-CAM starting address and length, you need to wait for one scan time before executing this instruction again.
7. If the **Err** (error) flag is ON, refer to the definitions below.

ErrCode	Description
0001	This slave station number is NOT in the supported range.
0002	This E-CAM chart number is NOT in the supported range.
0003	This downloading address (CAddr) or length (CLen) is NOT in the supported range.
0004	No response from the slave.
0005	Error message sent from the slave while downloading or setting up.
0006	The PLC is NOT in the Delta Special Driver & AS Remote Mode nor in the Delta Special Driver & CANopen DS301 Mode.


API	Instruction			Operand							Description						
2817	D	TQC		Node, TarTQ, ..., Err							Torque control						

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	“\$”	F
Node								●					○	○		
TarTQ								●					○	○		
LSpeed								●					○	○		
CurTQ								●								
Reach		●	●	●				●								
Err		●	●	●				●								

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
Node		●				●							
TarTQ		●				●							
LSpeed			●				●						
CurTQ		●				●							
Reach	●												
Err	●												

Pulse Instruction	16-bit instruction	32-bit instruction
-	-	AS

**Symbol**



- Node** : Node ID of Delta drives
- TarTQ** : Specified target torque
- LSpeed** : Maximum speed limit
- CurTQ** : Current torque value
- Reach** : Target torque is reached
- Err** : Communication error flag

**Explanation**

1. Make sure that all Delta drives have been initialized before executing this instruction.
2. For CAN communication, the PLC firmware of V1.06 and later and the ISPSOft software of V3.07 and later support the instruction. ECAT communication is available for the PLC with firmware V1.14.00 or later and ISPSOft V3.16 or later, and the AS-FECAT function card must be installed on the PLC.
3. For Delta Servo Drives: set the parameter P1-01 to 3 (T: Torque Control mode) and turn the power off and on again for the setting to be effective.  
For Delta Vector Control Drives: use ASDON instruction to set Torque Control mode and set the parameter P11-33 (Torque command source) to 3 (CANopen) on Delta AC Motor Drives that supports torque control mode.

4. **Node:** for CAN communication, the node ID of Delta Servos and Inverters range from 1 to 8 (Delta Servos) and 21 to 28 (Delta Inverters). If the setting is out of the range, Err flag will be ON. For ECAT communication, the node ID range from 1 to 16 and the device of the assigned ID should be a servo. If the setting is out of the range, Err flag will be ON.
5. **TarTQ:** specified target torque; it is suggested to check the manuals of Delta Servo Drives and AC Motor Drives before setting up. You can modify the settings during the execution of this instruction.

Drive Types	Node ID Range	TarTQ
Servo Drive	1~8 (CAN)	Setting the servo parameter P1-12 (internal torque limit 1), valid range: -300~+300, unit: 1%; value exceeding the upper/lower limit will be treated as the upper/lower limit value. For FW V1.08.40 or later, ASDA-A3/B3 high resolution torque mode is supported; valid range: -3000~+3000, unit: 0.1%, value exceeding the upper/lower limit will be treated as the upper/lower limit value.
	1-16 (ECAT)	The +/- sign indicates the forward / reverse direction. The servo runs according to torque control mode parameter P1-01 (torque output direction); set servo DI to TCM0 = ON and TCM1 = OFF in order to select internal torque command to 1; it is suggested to use COPRW instruction to clear the value in servo parameter P1-12 before Power-On. Since the default value of P1-12 is NOT 0%, it will start running once it is Servo ON.
AC Motor Drive	21~28 (CAN)	Setting the AC motor drive parameter P11-27 (maximum torque command); index 6071-00 (targeting torque) and index 6072-00 (largest output torque); valid range: -500~+500; unit: 1%; value exceeding the upper/lower limit will be treated as the upper/lower limit value.


6. **LSpeed:** maximum speed limit; this is used to prevent exceeding the speed limit, if the drives cannot complete the specified torque commands. You can modify the settings during the execution of this instruction.


Drive Types	Node ID Range	LSpeed
Servo Drive	1~8 (CAN) 1-16 (ECAT)	Setting the servo parameter P1-55 (maximum speed limit); valid range 10 to rated speed of each model; unit: 1 r/min (rotary).
AC Motor Drive	21~28 (CAN)	Setting the AC motor drive parameters 1. P01-00 = LSpeed (max. output frequency); valid range: 0~59900; unit: 0.01 Hz; value exceeding the upper/lower limit will be treated as the upper/lower limit 2. P11-37=100% (forward speed limit) 3. P11-38=100% (reverse speed limit) You need to set parameter P11-36 (speed limit selection) to 0 and when parameter P11-36 is set to 0, the speed limit is determined by the settings in P11-37 and P11-38.

7. **CurTQ**: current torque value; unit: 0.1%; the value here is the same as the value shown in its corresponding SR. Refer to API 2803 DRVIC instruction for more details on the corresponding SR.
8. **Reach** is the result of the comparison between **CurTQ** and **TarTQ**, shown in 0.1% as its unit. When **CurTQ**  $\geq$  **TarTQ**, the **Reach** flag is ON. When **CurTQ**  $<$  (**TarTQ** - 5), the **Reach** flag is OFF. The delay response value is 5.
9. If the nodes of the drives respond with error messages or do not respond, PLC will set **Err** flag to ON. For more details on error codes, refer to SR658 and SR659 from API 2803 DRVIC instruction.
10. Since the values in the command of torque and speed may vary. It is suggested to check the manuals of Delta Servo Drives and AC Motor Drives before setting up. This instruction does NOT examine or restrict if there is any invalid value.

### Example 1 (communication with Delta servo ASD-A2M)


1. Set up ASD-A2
  - A. Set the parameter P1-01 to 3 (T: Torque Control mode).
  - B. Set servo DI: TCM0 = ON and TCM1 = OFF in order to select internal torque command to 1.  
If the value in DI is default value, you can set DI3 to ON and then the torque command is set by DI3 and DI4.
  - C. Turn the power off and on again for the setting to be effective.
2. When M1 changes from OFF to ON, the INITC instruction starts to initialize the servos at node ID 1, until SM1681 is ON.
3. When M2 changes from OFF to ON, set the servo parameter P1-12 to 0. Use COPRW instruction to write the value in D100 into P1-12 (**S3=16#210B**). Remember use COPRW instruction to clear the value in servo parameter P1-12 before Power-On. Since the default value of P1-12 is NOT 0%, it will start running once it is Servo ON.
4. When M3 changes from OFF to ON, the ASDON instruction starts to enable the servo at node ID 1. When SM1651 is ON, it indicates Servo-ON.
5. When M4 changes from OFF to ON, servo parameter P1-12 = 12%, servo at node ID 2 moves at 1000 rpm until M4 is OFF.





### Example 2 (communication with Delta inverters)

1. Set up VFD-C2000 manually
  - A. Set the parameter P09-36 (CANopen slave address) to range 21~28 and P09-37 (CANopen speed) to 0 (1 MHz) and P09-40 (CANopen decoding method) to 1 (Enable CANopen DS402 standard protocol).
  - B. Set the parameter P00-20 (source of master frequency command (AUTO)) to 6 (CANopen communication card), P00-21 (operation command source) to 3 (CANopen communication card).
  - C. Set parameter P11-36 (speed limit selection) to 0 and when parameter P11-36 is set to 0, the speed limit is determined by the settings in P11-37 and P11-38.
2. When M1 changes from OFF to ON, the INITC instruction starts to initialize the AC motor drive at node ID 21, until SM1683 is ON.
3. When M2 changes from OFF to ON, start torque control on the AC motor drive at node ID 21.
4. When M3 changes from OFF to ON, the target torque of AC motor drive is set at 10% and AC motor drive at node ID 21 moves at the maximum output frequency of 60.00 Hz until M3 is OFF.



API	Instruction			Operand								Description				
2818	D	TQLC		Node \ TarSpd \ ... \ Err								Speed of torque control				


Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
Node								●					○	○		
TarSpd								●					○	○		
LimitTQ								●					○	○		
CurTQ								●								
Reach		●	●	●				●								
Err		●	●	●				●								

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
Node		●				●							
TarSpd			●				●						
LimitTQ		●				●							
CurTQ		●				●							
Reach	●												
Err	●												

Pulse Instruction	16-bit instruction	32-bit instruction
-	-	AS

Symbol :

6



- Node** : Node ID of Delta drives
- TarSpd** : Specified target speed
- LimitTQ** : Maximum torque
- CurTQ** : Target torque is reached
- Reach** : Communication error flag
- Err** : Target torque is reached

**Explanation**

1. Make sure that all Delta drives have been initialized before executing this instruction.
2. For CAN communication, the PLC firmware of V1.06 and later and the ISPSOFT software of V3.07 and later support the instruction. ECAT communication is available for the PLC with firmware V1.14.00 or later and ISPSOFT V3.16 or later, and the AS-FECAT function card must be installed on the PLC.
3. For Delta Servo Drives: set the parameter P1-01 to 3 (T: Torque Control mode) and turn the power off and on again for the setting to be effective.  
For Delta Vector Control Drives: use ASDON instruction to set Torque Control mode and set the parameter P00-20 (source of master frequency command (AUTO)) to 6 (CANopen communication card) on Delta AC Motor Drives that supports torque control mode.

4. **Node:** for CAN communication, the node ID of Delta Servos and Inverters range from 1 to 8 (Delta Servos) and 21 to 28 (Delta Inverters). If the setting is out of the range, Err flag will be ON. For ECAT communication, the node ID range from 1 to 16 and the device of the assigned ID should be a servo. If the setting is out of the range, Err flag will be ON.

5. **TarSpd:** specified target speed

Drive Types	Node ID Range	TarSpd Setting Range	TarSpd
Servo Drive	1~8 (CAN)	-60000 ~ 60000 (0.1rpm)	The +/- sign indicates the forward / reverse direction.
	1-16 (ECAT)	Example: input 6005 indicating 600.5rpm	
AC Motor Drive	21~28 (CAN)	-32768 ~ 32767 (1rpm) Example: input 605 indicating 605rpm	

6. **LimitTQ:** maximum torque value; once the instruction is started, the setting applies to the servo drive. You can NOT modify the settings during the execution of this instruction.

Setting the servo parameter P1-12 (internal torque limit 1), valid range: -300~+300, unit: 1%; value exceeding the upper/lower limit will be treated as the upper/lower limit value. For FW V1.08.40 or later, ASDA-A3/B3 high resolution torque mode is supported; valid range: -3000~+3000, unit: 0.1%, value exceeding the upper/lower limit will be treated as the upper/lower limit value. Setting P1-02 (speed and torque (force) limit setting); Set servo DI to TCM0 = ON and TCM1 = OFF in order to select internal torque command to 1. It is suggested to use COPRW instruction to clear the value in servo parameter P1-12 before Power-On. Since the default value of P1-12 is NOT 0%, it will start running once it is Servo ON. Supposing input a value of 30 in P1-12 and you will have the followings as shown in the table:

Allowable torque (force) range	Forward torque (force) limit	Reverse torque (force) limit
-30% ~ +30%	30%	-30%

Setting the AC motor drive parameter P11-17 (forward motor torque limit Quadrant I) and P11-19 (reverse motor torque limit Quadrant III), valid range: 0~+500, unit: 1%; value exceeding the upper/lower limit will be treated as the upper/lower limit value. Supposing input a value of 30 in P11-17 and P11-19 and you will have the followings as shown in the table:


Setting Item	P11-17	P11-19	Allowable torque (force) range	Forward torque (force) limit	Reverse torque (force) limit
Value	+30	+30	-30% ~ +30%	30%	-30%


7. **CurTQ:** current torque value; unit: 0.1%; the value here is the same as the value shown in its corresponding SR. Refer to API 2803 DRVIC instruction for more details on the corresponding SR.
8. **Reach** is the result of the comparison between **CurTQ** and **TarTQ**, shown in 0.1% as its unit. When **CurTQ** >= **TarTQ**, the **Reach** flag is ON. When **CurTQ** < (**TarTQ** - 5), the **Reach** flag is OFF. The delay response value is 5.
9. If the nodes of the drives respond with error messages or do not respond, PLC will set **Err** flag to ON. For more details on error codes, refer to SR658 and SR659 from API 2803 DRVIC instruction.

10. Since the values in the command of torque and speed may vary. It is suggested to check the manuals of Delta Servo Drives and AC Motor Drives before setting up. This instruction does NOT examine or make any restrictions if there is invalid setting or value.
11. The moment when the instruction is closed, all the restrictions on torque value will be lifted, so that the drive can execute other positioning commands.

**Example 1 (communication with Delta servo ASD-A2M)**


1. Set up ASD-A2
  - A. Set the parameter P1-01 (operation mode) to 0001 (position mode)
  - B. Set the parameter P1-02 (speed and torque (force) limit setting) to 0010 (enabled) or use COPRW instruction to set this parameter.
  - C. Set servo DI: TCM0 = ON and TCM1 = OFF in order to select internal torque command to 1.  
If the value in DI is default value, you can set DI3 to ON and then the torque command is set by DI3 and DI4.
2. When M0 changes from OFF to ON, the INITC instruction starts to initialize the servos at node ID 1, until SM1681 is ON.
3. When M1 changes from OFF to ON, use COPRW instruction to set the servo parameter P1-02 (speed and torque (force) limit setting) to 0010 (enabled).
4. When M2 changes from OFF to ON, the ASDON instruction starts to enable the servo at node ID 1. When SM1651 is ON, it indicates Servo-ON.
5. When M3 changes from OFF to ON, servo parameter P1-12 = 10%, servo at node ID 1 moves at 1000 rpm until M3 is OFF.






**Example 2 (communication with Delta inverters)**

1. Set up VFD-C2000 manually
  - A. Set the parameter P09-36 (CANopen slave address) to range 21~28 and P09-37 (CANopen speed) to 0 (1 MHz) and P09-40 (CANopen decoding method) to 1 (Enable CANopen DS402 standard protocol).
  - B. Set the parameter P00-20 (source of master frequency command) to 6 (CANopen communication card), P00-21 (operation command source) to 3 (CANopen communication card).
2. When M1 changes from OFF to ON, the INITC instruction starts to initialize the AC motor drive at node ID 21, until SM1683 is ON.
3. When M2 changes from OFF to ON, start torque control on the AC motor drive at node ID 21.
4. When M3 changes from OFF to ON, the torque limit of AC motor drive is set at 10% and AC motor drive at node ID 21 moves at 1000 rpm until M3 is OFF.






API	Instruction			Operand								Description			
2820		INITEC		<b>SlaveNo, SType, Done, Error, ErrCode</b>								Initializing the slaves for EtherCAT communication			

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	“\$”	F
SlaveNo								●					○	○		
SType								●	●							
Done		●	●	●				●								
Error		●	●	●				●								
ErrCode								●								

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
SlaveNo		●				●							
SType		●				●							
Done	●												
Error	●												
ErrCode		●											

Pulse Instruction	16-bit instruction	32-bit instruction
-	AS	-

**Symbol**



- SlaveNo** : Number of slaves to be initialized
- SType** : Slave type
- Done** : Completion flag
- Error** : Error flag
- ErrCode** : Error code

**Explanation**

- This instruction is available for AS PLC with firmware V1.14.00 or later and ISPSOft V3.16 or later and the AS-FECAT function card must be installed on the PLC.
- Before executing this instruction, make sure that the AS-FECAT communication card has been installed on the PLC.
- SlaveNo** should specify a value in the range of 1~16. (A maximum of 16 EtherCAT slaves are supported by AS-FECAT.) If the setting value exceeds this range, the PLC will consider it as an initialization error.

Note: The IDs of slaves must start from 1, and the way of setting a slave ID by skipping some station numbers is not allowed.

- SType** is the type of slaves and is an Array of Word variable, e.g. if **SlaveNo** is set to 8, this variable must also be set to an Array[8] variable. Type codes and corresponding Delta drives are listed in the following table.

Type code	1	2	3	Others
Drive Model	ASDA-A2-E	ASDA-A3-E ASDA-B3-E	C2000 CH2000	Reserved

Note: When the type code does not match the actual connected drive, the PLC will set the error flag to ON and report an error code.

5. **Done** is the initialization complete flag. It is suggested that you start the subsequent position control after the initialization is completed.
6. **Error** is the initialization error flag, and **ErrCode** is the error code.

See the error codes and causes in the following table.

Error Code	Cause
16#0000	No error
16#0001	The number of slaves is out of range.
16#0003	Slave type code setting error
16#0004	Timeout when communicating with AS-FECAT
16#0005	The slave SDO is being used by another instruction.
16#0006	AS-FECAT is not installed.
16#0007	Slave initialization error (AL STATUS UNKNOWN)
16#0008	Slave initialization error (AL STATUS ERROR)
16#0009	The number of slaves actually connected is less than the number of slaves set in INITEC.
16#000A	No physical connection between the AS-FECAT and the slave
16#000B	AS-FECAT initialization timeout

7. When the connection-loss problem (SR0 = 0x1901~0x1910, the last two codes represent the slave ID) occurs after the initialization is completed, SM1684 is OFF (default, indicating when one goes down, all slaves are OFF) and the relevant actions of other slaves will also be paused. After the trouble is cleared, you need to initialize all slaves to restart the operation. The PLC will automatically turn off the flashing error LED after confirming the initialization is completed, and the error will be recorded in the error log.
8. If slaves need to work independently without being affected by the failure of any slave else when the communication cable is properly connected, you need to set the SM1684 to ON after initialization is done to notify the PLC to record the error and set the corresponding error flag to ON, without needing to stop other slaves working.


API	Instruction		Operand									Description				
2821		ECATRW	Slave, RWCode, ... ErrCode									Reading and writing EtherCAT SDO data				

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	“\$”	F
Slave								●					○	○		
RWCode								●					○	○		
Index								●								
SubIndex								●								
Length								●					○	○		
Data								●								
Done		●	●	●												
Error		●	●	●												
ErrCode								●								

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
Slave		●				●							
RWCode		●				●							
Index		●				●							
SubIndex		●				●							
Length		●				●							
Data		●	●			●	●						
Done	●												
Error	●												
ErrCode		●											

Pulse Instruction	16-bit instruction	32-bit instruction
-	AS	-

Symbol



- Slave** : Slave ID
- RWCode** : Function code
- Index** : Index
- SubIndex** : Sub-index
- Length** : Size of data
- Data** : Destination register for the data to be read or  
Source register for the data to be written
- Done** : Completion flag
- Error** : Error flag
- ErrCode** : Error Code

**Explanation**

1. This instruction is available for the PLC with firmware V1.14.00 or later and ISPSOft V3.16 or later, and the AS-FECAT function card must be installed on the PLC.
2. This instruction is used to read and write parameter values of a slave on the EtherCAT network through SDO communication.
3. **Slave** specifies a value in the range of 1~16. (A maximum number of 16 EtherCAT slaves are supported by AS-FECAT.) If the value exceeds the setting range for initialization, the PLC will consider it as a setting error.
4. **RWCode** specifies the function code for reading or writing data. See the read/write function codes in the table as follows.

Function code	16#0000	16#0001	16#1000	16#1001
Description	Read one single EtherCAT parameter value	Read multiple EtherCAT parameter values	Write one single EtherCAT parameter value	Write multiple EtherCAT parameter values

Note: If you set **RWCode** to a function code which is not defined in the table above, the PLC will treat it as an error. When the function codes for reading and writing one single parameter value are used, the **Length** parameter of the instruction is invalid. When the function codes for reading and writing multiple parameter values are used, the instruction is executed according to **Length** parameter setting.

5. **Index** and **SubIndex** are the index and sub-index for the SDO communication. **Length** is the size of the multiple parameter values to be read or written and the setting range is 1 ~ 50. If the setting value exceeds the range, it will be automatically adjusted to the upper limit or lower limit. If you are to read and write multiple parameter values, the variables of **Index** and **SubIndex** must be declared as Array type.
6. **Data** is the destination device for storing the data to read or the source device where the data to write is. To read and write multiple parameter values, it should be noted that the data type of **Data** must be declared as Array. Each read or written parameter value occupies 2 words.
7. **Done** is the reading or writing completion flag. During performing the read operation, you should wait for the completion flag to be ON before using the read data.
8. **Error** is the communication error flag, and **ErrCode** is the error code.

See the error codes and causes in the following table.

Error Code	Cause
16#0000	No error
16#0001	The slave ID is out of range or the specified slave is not initialized.
16#0002	No response from the slave
16#0003	The read and write function code setting is incorrect.
16#0004	According to the set length of the data to read and write, the data in <b>Index</b> / <b>SubIndex</b> device is out of the range.

Error Code	Cause
16#0005	According to the set length of the data to read and write, the data in <b>Data</b> device is out of the range.
16#0006	AS-FECAT function card is not installed
16#0007	An error occurs in the message received by the slave. This error often occurs when the settings of the ECATRW instruction are invalid so that the slave fails to receive complete messages.

API	Instruction			Operand							Description			
2822		MOTST		<b>Slave, Reset, ... ErrCode</b>							Reading Motion state of an EtherCAT slave			


Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
Slave								●					○	○		
Reset			●													
Position								●								
State								●								
Done		●	●	●												
Error		●	●	●												
ErrCode								●								

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
Slave		●				●							
Reset	●												
Position			●				●						
State		●				●							
Done	●												
Error	●												
ErrCode		●											

Pulse Instruction	16-bit instruction	32-bit instruction
-	AS	-

6

Symbol



- Slave** : Slave ID
- Reset** : Reset the position control
- Position** : Slave position (32 bits)
- State** : Slave status
- Done** : Completion flag
- Error** : Error flag
- ErrCode** : Error code

Explanation

- This instruction is available for the PLC with firmware V1.14.00 or later and ISPSOft V3.16 or later, and the AS-FECAT function card must be installed on the PLC.
- Through PDO communication method, this instruction regularly refreshes the status and position of the specified slave. And the specified slave is scanned and its status and position are automatically updated to the variables of the instruction. It is suggested that you execute the instruction to refresh the latest status of the slave after the initialization is completed.

3. **Slave** specifies a value in the range of 1~16. (Up to 16 EtherCAT slaves are supported by AS-FECAT.) If the value exceeds the setting range for initialization, the PLC will consider it as a setting error.
4. When **Reset** is ON, the occupied position control over the specified slave is cleared so that other position instructions (including DDRVIC / DDRVAC / DPLSVC / ZRNC / DZRNC / DCSFOC / DTQC / DTQLC) can restart the slave to perform the position control. After the position control is released, **Reset** will automatically change to OFF.  
Note: In the normal position control, the original positioning will be stopped when this **Reset** action is performed.
5. If the device type of the specified slave is servo, **Position** is the current position (32 bits) of the specified slave. If the device type of the specified slave is the AC motor drive, the value of **Position** is the fixed value 0.
6. **State** is the current status of the specified slave.

See the definitions of bits when all bits of the status value are ON in the following table.

Bit No.	Bit 15 ~ Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
Definition	Reserved	Servo On	Pause	Position reached	Position in output

7. **Done** is the status update completion flag. In normal circumstances, the flag should be ON continuously. If it is OFF, the last updated data of the current state, position and speed of the slave will be maintained.
8. **Error** is the communication error flag, and **ErrCode** is the error code.

See the error codes and causes in the following table.

Error Code	Cause
16#0000	No error
16#0001	The slave ID is out of range or the specified slave is not initialized.
16#0003	AS-FECAT function card is not installed.

API	Instruction		Operand										Description			
2823		ECATST	Slave, State, Done, Error, ErrCode										Reading the state of an EtherCAT slave			

Device	X	Y	M	S	T	C	HC	D	FR	SM	SR	E	K	16#	"\$"	F
Slave								●					○	○		
State								●								
Done		●	●	●				●								
Error		●	●	●				●								
ErrCode								●								

Data type	BOOL	WORD	DWORD	LWORD	UINT	INT	DINT	LINT	REAL	LREAL	TMR	CNT	STRING
Slave		●				●							
State		●				●							
Done	●												
Error	●												
ErrCode		●											

Pulse Instruction	16-bit instruction	32-bit instruction
-	AS	-

Symbol



- Slave** : Slave ID
- State** : Status of the EtherCAT slave
- Done** : Completion flag
- Error** : Error flag
- ErrCode** : Error Code

Explanation

1. This instruction is available for the PLC with firmware V1.14.00 or later and ISPSOft V3.16 or later, and the AS-FECAT function card must be installed on the PLC.
2. The execution of the INITEC instruction should be completed before this instruction is executed.
3. There is no limit on the number of times the instruction can be used. However, for the same slave only one ECATST instruction is allowed to execute at the same time.
4. **Slave** specifies a value in the range of 1~16. (A maximum number of 16 EtherCAT slaves are supported by AS-FECAT.) If the value exceeds the setting range or the specified slave is not initialized, the instruction will not be executed.

5. **State** : Communication state of the **EtherCAT** slave

Bit No.	Description
<b>Bit 0~3</b>	1 : Initialization State 2 : Pre-Operational State 3 : Bootstrap State 4 : Safe-Operational State 8 : Operational State
<b>Bit 4</b>	0 : The device state is consistent with the required state or cleared by a command. 1 : The device state is inconsistent with the required state or changed by the slave.
<b>Bit 5</b>	0 : Device Identification is not effective. 1 : Device Identification is effective.
<b>Bit 6~15</b>	Reserved

6. **Done** is the status update completion flag. In normal circumstances, the flag should be ON all the time. If it is OFF, the last updated data of the EtherCAT slave state mentioned above will be maintained.

7. **Error** is the communication error flag, and **ErrCode** is the error code.

See the error codes and causes in the following table.

Error Code	Cause
16#0000	No error
16#0001	The slave ID is out of range or the specified slave is not initialized.
16#0002	No response from the slave
16#0003	AS-FECAT function card is not installed.
16#0004	Two or more ECATST instructions are started with the same slave ID.

### 6.27.3 Frequently asked questions in Delta special CANopen communication and Troubleshooting

Question 1: After the PLC starts the INITC instruction, the initialization completion flag SM1681 is not set to ON.

Steps:

- 1) Make sure that Card 2 is set to AS-FCOPM communication card in AS HWCONFIG and the communication mode is Delta special driver mode. Then check if the communication rate is the specified baud rate. After above settings are correct, re-download the hardware configuration table and then re-check if the initialization works. If the initialization still does not work, proceed with the next step.
- 2) Ensure that the servo initialization has been set by manual. Then re-power the servo on after power off. After doing so, continue with step 3.
- 3) Ensure that the servo node ID (P3-00), baud rate and mode (P3-01) have been set by manual and communication mode (P1-01) has been set to PR mode by manual. Then proceed with the step 4.
- 4) Ensure that the CAN communication cable connection is proper, the terminal resistor in AS-FCOPM card of the PLC is switched on and the last servo has been connected with a terminal resistor. Then move forward to the step 5.
- 5) Observe whether the word: **code** appears temporarily on the digital display of the servo when the PLC enables the initialization instruction. If there is no code appearing temporarily, return to step 1 or replace the servo. If there is the word **code** appearing temporarily, go to step 6.
- 6) Check if the actual states of DI0~DI7 (P2-10 ~ P2-17) of the servo are consistent with the function settings of servo parameters. E.g. DI0 is the negative limit input (contact A). Check if the actual input state has been OFF (Contact B). If DI function has been enabled, make the function disabled. If the function has not been enabled, go on with step7.
- 7) The communication mode of the communication card AS-FCOMP in HWCONFIG is switched back to DS301 mode. Use the CANopen Builder software to search the slave and observe which slave has not been scanned. Remove the one which has not been scanned and then make the initialization again by adjusting the servo node ID and the ID in INITC in the PLC.

# Chapter 7 Troubleshooting

## Table of Contents

<b>7.1</b>	<b>Troubleshooting</b> .....	<b>7-3</b>
7.1.1	Basic troubleshooting steps .....	7-3
7.1.2	Clear the Error States.....	7-3
7.1.3	Troubleshooting SOP .....	7-4
7.1.4	System Log and Positions of the Error Step .....	7-5
<b>7.2</b>	<b>Troubleshooting for CPU Modules</b> .....	<b>7-7</b>
7.2.1	ERROR LED Indicators Are ON .....	7-7
7.2.2	ERROR LED Indicators Blinking Every 0.5 Seconds.....	7-7
7.2.3	ERROR LED Indicators Blinking Rapidly Every 0.2 Seconds.....	7-9
7.2.4	ERROR LED Indicators Slow Blinking Every 3 Seconds and Lighting up for 1 Second .....	7-9
7.2.5	BAT. LOW LED Indicators Are ON .....	7-10
7.2.6	BAT. LOW LED Indicators Blinking Every 0.5 Seconds.....	7-10
7.2.7	The LED RUN and ERROR Indicators are Blinking Simultaneously Every 0.5 Seconds.....	7-11
7.2.8	The RUN and LED Indicators are Blinking One After Another Every 0.5 Seconds.....	7-11
7.2.9	Other Errors (Without LED Indicators).....	7-11
<b>7.3</b>	<b>Troubleshooting for Other I/O Modules</b> .....	<b>7-19</b>
7.3.1	Troubleshooting for Analog Modules (AD/DA/XA) and Temperature Modules (RTD/TC).....	7-19
7.3.2	Troubleshooting for the Positioning Module AS02/04PU .....	7-20
7.3.3	Troubleshooting for the High-Speed Counter Module AS02HC .....	7-20
7.3.4	Troubleshooting for the Load Cell Module AS02LC.....	7-21
7.3.5	Troubleshooting for the Module AS04SIL IO-Link as a Communication Module .....	7-22
7.3.6	Troubleshooting for the Module AS00SCM as a Communication Module.....	7-25
7.3.7	Troubleshooting for the Module AS00SCM as a Remote Module.....	7-26
7.3.8	Troubleshooting for AS01DNET Modules .....	7-27
<b>7.4</b>	<b>Error Codes and LED Indicators for Modules</b> .....	<b>7-28</b>
7.4.1	Error Codes and LED Indicators for CPU Modules .....	7-28
7.4.2	Error Codes and LED Indicators for Analog/Temperature Modules .....	7-35
7.4.3	Error Codes and LED Indicators for Positioning Module AS02 / 04PU ...	7-36
7.4.4	Error Codes and LED Indicators for High Speed Counter Module AS02HC.....	7-36
7.4.5	Error Codes and LED Indicators for Load Cell Module AS02LC .....	7-37
7.4.6	Error Codes and LED Indicators for Module AS04SIL IO-Link as a Communication Module .....	7-37
7.4.7	Error Codes and LED Indicators for Module AS00SCM as a Communication Module .....	7-38
7.4.8	Error Codes and LED Indicators for Module AS00SCM as a Remote	

	Module.....	7-38
7.4.9	Error Codes and LED Indicators for Module AS01DNET (Master/Slave Mode).....	7-39
7.4.10	Error Codes and LED Indicators for Module AS01DNET (RTU Mode) .....	7-40

## 7.1 Troubleshooting

### 7.1.1 Basic troubleshooting steps

This chapter includes the possible errors that can occur during operation, their causes, and corrective actions.

(1) Check the following:

- The PLC should be operated in a safe environment (consider environmental, electronic, and vibration safeties).
- Connect power supply correctly to the PLC.
- Secure the module, terminal, and cable installations.
- All LED indicators show correctly.
- Set all switches correctly.

(2) Check the following operational functions:

- Switch the RUN/STOP state
- Check the settings for the AS Series to RUN/STOP
- Check and eliminate errors from external devices
- Use the System Log function in ISPSOFT to check system operation and logs

(3) Identify possible causes:


- AS Series or external device
- CPU or extension modules
- Parameters or program settings

### 7.1.2 Clear the Error States

Use the following methods to clear the error states. If the error source is not corrected, the system continues to show errors.

- (1) Switch the CPU model state to STOP and then to RUN.
- (2) Turn off the CPU and turn it on again.
- (3) Use ISPSOFT to clear the error logs.
- (4) Reset the CPU to the default settings and download the program again.

### 7.1.3 Troubleshooting SOP




7


### 7.1.4 System Log and Positions of the Error Step

If ISPSOft is connected to an AS Series, you can view actions and errors in the AS Series by clicking **System Log** on the **PLC** menu. The CPU can store up to 20 error log sets. After the 20 sets are stored, the 1<sup>st</sup> log is replaced with the 21<sup>st</sup> if there are new logs coming in, and the old logs are replaced with the new ones sequentially. When the memory card is installed in the CPU module, 20 sets of the old logs are backed up in the memory card and up to 1000 logs can be recorded. If the stored logs exceed 1000, the oldest 20 logs are replaced with the newest 20 logs in the memory card.

- (1) On the **PLC** menu, click **System Log**.




- (2) The **System Log** window appears. Click **Clear Log** to clear the error log in the window and the error log in the CPU module, and reset the CPU module.



- **Group No.:** The number 1 indicates that the error occurred in the CPU module or the right-side module 1. The numbers 2–16 indicate the error occurred in the remote modules 1–15.
- **Module No.:** The number 0 indicates that the error occurred in the CPU module or the remote module. The numbers 1–32 indicate the error occurred in the right-side module of the CPU module / remote module. The number 1 represents the closest module to the CPU module or the remote module. This number increases from the closest to the furthest from the CPU module or the remote module. Note: up to eight extension modules can be connected to the right-side of the remote module.
- **PLC/Module name:** Model names of the CPU, remote, and extension modules.

- Error Code: Error codes in the error log.
  - Date & Time: The date and time the error occurred. The most recently occurring error is listed on the top.
  - The last column shows the descriptions for the error.
- (3) If the operation or operand exceeds the allowed range (SM0 = ON, stored in SR0) or an instruction inspection error (SM5 = ON, stored in SR4) occurs, you can use the following method to see where the problem is.
- When SM0 = ON, check the value in SR1 to see the error step. SR1: The address of the operation error (32-bit).
  - When SM5 = ON, check the value in SR5 to see the error step. SR5: The address of the grammar check error (32-bit).
  - Once you know the error step number, you can go to ISPSOft -> Edit -> Step positioning. Enter the error step number and click OK. The system takes you to the position where the step went wrong.



## 7.2 Troubleshooting for CPU Modules

Check the LED indicators and the error codes from the CPU module and refer to the following table for troubleshooting. V in the Log column indicates the error is recorded in the log. X in the Log column indicates the error is not recorded in the log. H in the Log column indicates whether or not you can set recording the error in the log in HWCONFIG.

Note: Error log is also stored in SR. Refer to Chapter 2 for more information on SR.

### 7.2.1 ERROR LED Indicators Are ON

Error Code (16#)	Description	Solution	Flag	Log
000A	Scan timeout	1. Check the setting of the watchdog timer in HWCONFIG. 2. Check if the program causes a long scan time	SM8	V

### 7.2.2 ERROR LED Indicators Blinking Every 0.5 Seconds

Error Code (16#)	Description	Solution	Flag	Log
000C	The program in the PLC is damaged.	Download the program again.	SM9	V
000D	The initial value of the device and the PLC program are not downloaded completely.	Download the program again.	SM9	V
0010	CPU memory is denied.	If the problem persists, contact the local authorized distributors.	SM9	V
0020	PLC scan time is longer than expected, due to abnormality of CPU operation speed.	If the problem persists, contact the local authorized distributors.	SM9	V
0021	Failed to restore Delta device parameters back to defaults	1. Check if the EDS file of the device is the same as the device that is to be restored to defaults. 2. Check if the network connection is normal for the PLC CPU and the device that is to be restored to defaults. 3. Check the compatibility of the device to be restored to defaults.	SM9	V
002E	CPU external memory access is denied.	If the problem persists, contact the local authorized distributors.	SM9	V
002F	PLC programs are not consistent with the system logs.	Download the program again.	SM34	V
0070	The arrangement of the function cards is not consistent with the settings.	Check if the settings in HWCONFIG are consistent with the arrangement of the function cards.	SM10	V
0102	The interrupt number exceeds the range.	Check the position where an error occurs and modify the program. Compile the program and download the program again.	SM5	X
0202	The MC instruction exceeds the range.		SM5	X
0302	The MCR instruction exceeds the range.		SM5	X

Error Code (16#)	Description	Solution	Flag	Log
0D03	The operands used in DHSCS are not used properly.		SM5	X
0E05	The operands HCXXX used in DCNT are not used properly.		SM5	X
1000 - 10FF	System error	If the problem persists, contact the local authorized distributors.	-	V
1300 - 130F	Errors occurred in the remote modules	Refer to Section 7.3.4 for more information on the error codes for the remote modules.	SM30	V
1402	The arrangement of the I/O modules is not consistent with the settings.	Check if the settings in HWCONFIG are consistent with the arrangement of the I/O modules.	SM10	V
140B	More than four communication modules.	Check the total number of communication modules (maximum is four).	SM10	V
140C	The number of connected positioning modules exceed the maximum number 8.	Check the total number of positioning modules.	SM10	V
140D	More than 32 extension modules.	Check the total number of extension modules (maximum is 32).	SM10	V
140E	More than eight remote modules on the right side of the CPU module.	Check the total number of remote modules on the right side of the CPU module (maximum is 8).	SM30	V
1600	The extension module ID exceeds the range.	1. Make sure the module is properly connected to the CPU module and turn the modules on again. 2. If the problem persists, contact the local authorized distributors.	SM10	V
1601	The extension module ID cannot be set.	1. Make sure the module is properly connected to the CPU module and turn the modules on again. 2. If the problem persists, contact the local authorized distributors.	SM10	V
1602	The extension module ID is duplicated.	1. Make sure the module is properly connected to the CPU module and turn the modules on again. 2. If the problem persists, contact the local authorized distributors.	SM10	V
1603	The extension module cannot be operated.	1. Make sure the module is properly connected to the CPU module and turn the modules on again. 2. If the problem persists, contact the local authorized distributors.	SM10	V
1604	Extension module communication timeout	1. Make sure the module is properly connected to the CPU module and turn the modules on again. 2. If the problem persists, contact the local authorized distributors.	SM10	V
1605	Hardware failure	If the problem persists, contact the local authorized distributors.	SM10	V
1606	Errors on the settings of the communication module function card	Make sure the function card is properly connected to the CPU module and turn the modules on again.	SM10	V

Error Code (16#)	Description	Solution	Flag	Log
1607	The external voltage is abnormal.	Check if the external 24 V power supply to the module is normal.	SM10	V
1608	The Internal factory calibration or the CJC is abnormal.	If the problem persists, contact the local authorized distributors.	SM10	V
1609 - 160F	Reserved (Error codes for the extension modules)			
200A	Invalid instruction	Check the position where an error occurs and modify the program. Compile the program and download the program again.	SM5	V
6010	The number of MODBUS TCP connections exceeds the range.	Check the number of superior devices (maximum is 32).	SM 1092	V
6011	The number of EtherNet/IP connections exceeds the range.	Check the number of connections (maximum is 16).	SM 1093	V
C000 - CFFF	The PLC program syntax is incorrect.	Save the PLC program and contact your distributor.	-	V

### 7.2.3 ERROR LED Indicators Blinking Rapidly Every 0.2 Seconds

This happens when the power supply 24 VDC of the CPU module is disconnected, or the power supply is not sufficient, not stable or abnormal.

Error Code (16#)	Description	Solution	Flag	Log
002A	The external voltage is abnormal.	Check if the external 24 V power supply to the module is normal.	SM7	V

### 7.2.4 ERROR LED Indicators Slow Blinking Every 3 Seconds and Lighting up for 1 Second

Error Code (16#)	Description	Solution	Flag	Log
0040	The converted value in the function card 1 (AS-F2AD) or in the built-in AD input channel 1 exceeds the setting range.	Check the actual input signal	SM27	H
0041	The converted value in the function card 1 (AS-F2AD) or in the built-in AD input channel 2 exceeds the setting range.	Check the actual input signal	SM27	H
0042	The converted value in the input channel 1 of the function card 2 (AS-F2AD) exceeds the setting range.	Check the actual input signal	SM27	H
0043	The converted value in the input channel 2 of the function card 2 (AS-F2AD) exceeds the setting	Check the actual input signal	SM27	H

	range.			
0044	Connection lost in the mode of current input 4 mA - 20 mA for the function card 1 (AS-F2AD) or for the built-in AD input channel 1.	Check the connection cable.	SM27	H
0045	Connection lost in the mode of current input 4 mA - 20 mA for the function card 1 (AS-F2AD) or for the built-in AD input channel 2.	Check the connection cable.	SM27	H
0046	Connection lost in the mode of current input 4 mA - 20 mA for the input channel 1 of the function card 2 (AS-F2AD).	Check the connection cable.	SM27	H
0047	Connection lost in the mode of current input 4 mA - 20 mA for the input channel 2 of the function card 2 (AS-F2AD).	Check the connection cable.	SM27	H
1500	Connection lost in the remote modules	Check the network connection cable.	SM30	V
1502 - 150F	Errors occurred in the remote modules	Refer to Section 7.3.4 for more information on the remote module error codes.	SM30	V
1800 - 180F	Errors occurred in the extension modules	Refer to Section 7.3 for more information on the extension module error codes.	SM10	V
1900 - 191C	Heartbeat / connection loss errors occurred in the slave of the CANopen / ECAT communication module.	1. Check the CANopen / ECAT connection cable. 2. Check if the specific slave is working properly. Note: The last 2 digits of the error code represent the ID number of the slave (convert hexadecimal to decimal).	-	V

### 7.2.5 BAT. LOW LED Indicators Are ON

This happens when there is no battery (CR1620) or the power is low. Turn this option off in the HWCONFIG > CPU > Device Setting > Show Battery Low Voltage Error CPU when you don't need the RTC function to keep track of the current time (default is enabled).

Error Code (16#)	Description	Solution	Flag	Log
0027	Battery Low	Change battery or turn this option off	SM219	X

### 7.2.6 BAT. LOW LED Indicators Blinking Every 0.5 Seconds

This happens when RTC cannot keep track of the current time.

Error Code (16#)	Description	Solution	Flag	Log
0026	RTC cannot keep track of the current time	If the problem persists, contact the local authorized distributors.	SM218	V
0028	No response from RTC	If the problem persists, contact the local authorized distributors.	SM217	V

### 7.2.7 The LED RUN and ERROR Indicators are Blinking Simultaneously Every 0.5 Seconds

This happens when the firmware of the CPU module is being upgraded. If this happens once the power is supplied to the CPU module, it means errors occurred during the previous firmware upgrade. Users need to upgrade the firmware again or contact your point of purchase.

### 7.2.8 The RUN and LED Indicators are Blinking One After Another Every 0.5 Seconds.

This happens when the CPU module memory card is backing up, restoring, or saving. If the CPU you are using is AS218 Series with no SD card installed, the RUN and LED indicators are blinking one after another every 0.5 seconds indicates the AIO firmware is updating. If this happens once the power is supplied to the CPU module, it indicates the AIO firmware updating has been failed and need to be updated again. If you did not update AIO firmware, the blinking indicates that AIO component is abnormal and you need to contact your point of purchase.

### 7.2.9 Other Errors (Without LED Indicators)

Error Code (16#)	Description	Solution	Flag	Log
0011	The PLC ID is incorrect.	Check the PLC ID.	SM34	V
0012	The PLC password is incorrect.	Check the PLC password.	SM34	V
002D	The PLC maximum password attempts exceeded.	Reset the CPU module or restore the CPU module to its factory settings.	SM34	V
0050	The memories in the latched special auxiliary relays are abnormal.	1. Reset the CPU module or restore the CPU module to its factory settings, and then download the program and the parameters again. 2. If the problem persists, contact the local authorized distributors.	SM6	V
0051	The latched special data registers are abnormal.	1. Reset the CPU module or restore the CPU module to its factory settings, and then download the program and the parameters again. 2. If the problem persists, contact the local authorized distributors.	SM6	V
0052	The memories in the latched auxiliary relays are abnormal.	1. Reset the CPU module or restore the CPU module to its factory settings, and then download the program and the parameters again. 2. If the problem persists, contact the local authorized distributors.	SM6	V
0054	The latched counters are abnormal.	1. Reset the CPU module or restore the CPU module to its factory settings, and then download the program and the parameters again. 2. If the error still occurs, please contact your distributor.	SM6	V
0055	The latched 32-bit counters are abnormal.	1. Reset the CPU module or restore the CPU module to its factory settings, and then download the program and the parameters again. 2. If the problem persists, contact the local authorized distributors.	SM6	V

0056	The latched special auxiliary relay is abnormal.	1. Reset the CPU module or restore the CPU module to its factory settings, and then download the program and the parameters again. 2. If the problem persists, contact the local authorized distributors.	SM6	V
0059	The latched data registers are abnormal.	1. Reset the CPU module or restore the CPU module to its factory settings, and then download the program and the parameters again. 2. If the problem persists, contact the local authorized distributors.	SM6	V
005D	The CPU module does not detect a memory card.	Check if the memory card is inserted correctly into the CPU module.	SM453	V
005E	The memory card is initialized incorrectly.	Check if the memory card is broken.	SM453	V
0063	An error occurs when data is written to the memory card.	Check if the file path is correct or if the memory card is malfunctioning.	SM453	V
0064	A file in the memory card cannot be read.	Check if the file path is correct, or if the file is damaged.	SM453	V
1950	The initialization of the CANopen communication module has not yet been completed, the CANopen instructions cannot be executed.	1. Check the CANopen connection cable. 2. Check if the specific slave is working properly. 3. If nothing is wrong, initialize the CANopen communication module again.	-	V
19B0	Heartbeat timeout occurred in the slave of the CANopen communication module.	Check if the CANopen connection cable is well-connected.	-	V
19B1	The data length of PDO (process data object) in the slave mode is not matched with the setting.	Revise the PDO data length setting in the slave mode and download the setting again.	-	V
Check the value in SR830~SR893 (refer to section 2.2.14 in this manual for more details) to see which slave (1~64) is experience an error and refer to the following error codes 19E1~19E8 to check the details.				
19E1	The data length of PDO (process data object) in the slave mode is not matched with the setting of the scan list. Refer to section 10.5 CANopen communication related descriptions in AS Series Hardware and Operation Manual for more details on the error codes 19E1 to 19E8.	Revise the PDO data length setting in the slave mode and download the setting again.	-	V
19E2	PDO in the slave mode is not received.	Check if the configurations are correctly set.	-	V
19E3	The function of auto downloading SDO fails at the first startup.	Check if the SDO contents for auto downloading are correct.	-	V
19E4	PDO configurations are set incorrectly.	Make sure to set the PDO configurations correctly.	-	V
19E5	The main settings are not consistent with the connected slave.	Make sure the connected slaves are the ones configured in ISPSOft.	-	V
19E6	The slave does NOT exist in the network.	Make sure the power supply of slave is normal and slave is correctly connected to the network.	-	V
19E7	Timeout on the slave error control	Make sure the power supply of slave is normal and slave is correctly connected to the network.	-	V
19E8	The node IDs of master and slave are duplicated.	Set the node ID of the master and slave again and make sure their node IDs are unique.	-	V
19F3	Error in the configuration	1. Download the parameter configuration again. 2. If the problem persists, contact the local	-	V

		authorized distributors.		
19F4	CANopen communication is in the BUS-OFF state.	<ol style="list-style-type: none"> <li>1. Check if the network cable is normal and the shielded cable is grounded.</li> <li>2. Check if the start and end of the network cable are both connected with a 121Ω terminal resistor.</li> <li>3. Check if all the node devices run at the same baud rate on the network.</li> </ol>	-	V
19FB	The sending registers exceed the range.	Revise the time to synchronize (suggested to use a longer time).	-	V
19FC	The receiving registers exceed the range.	Revise the time to synchronize (suggested to use a longer time).	-	V
2001	Not using the FCOMP card or not in the right mode for the ASDA-A2 while using the CANopen communication instruction.	<ol style="list-style-type: none"> <li>1. Use the FCOMP card in the function card 2 slot and make sure its work mode is CANopen communication.</li> <li>2. Check the position where an error occurs and modify the program. Compile the program and download the program again.</li> </ol>	SM0	V
2003	The device used in the program exceeds the device range or it is illegal.	Check the position where an error occurs and modify the program. Compile the program and download the program again.	SM0	V
200B	The operand n or the other constant operands K/H exceed the range.		SM0	V
200C	The operands overlap.		SM0	V
200D	The binary to binary-coded decimal conversion is incorrect.		SM0	V
200E	The string does not end with 00.		SM0	V
2012	Incorrect division operation		SM0	V
2013	The value exceeds the range of values that can be represented by the floating-point numbers.		SM0	V
2014	The task designated by the TKON or YKOFF instruction is incorrect or exceeds the range.		SM0	V
2017	The instruction BREAK is written outside of the FOR-NEXT loop.	SM0	V	
2027	No such position planning table number or the format is incorrect.	<ol style="list-style-type: none"> <li>1. Check the position where an error occurs and modify the program. Compile the program and download the program again.</li> <li>2. Check the settings in the position planning table.</li> </ol>	SM0	V
2028	High speed output instruction is being executed. Only one instruction can be executed at a time.	Refer to SR28 for the record of the axis number and rearrange the output control procedures.	-	V
2030	The output frequency executed by CSFO instruction exceeds the maximum output frequency.	Modify the ratio of input and output frequency or lower the input frequency.	-	V
2031	If the input pulse is 0 Hz and lasts for more than 2 seconds, PLC stops outputting automatically.	Modify the ratio of input and output frequency or lower the input frequency.	-	V
6004	The IP address filter is set incorrectly.	Set the Ethernet parameter for the CPU module in HWCONFIG again.	SM1108	X
600D	RJ45 port is not connected.	Check the connection.	SM1100	X

6012	There are devices using the same IP address.	<ol style="list-style-type: none"> <li>1. Check if there are devices using the same IP address.</li> <li>2. Check if there is more than 1 DHCP or BOOTP server on the network.</li> </ol>	SM1101	V
6100	The email connection is busy.	Retry the email connection later. This error does not cause the PLC to stop running. Solve the problem by means of the related flag in the program.	SM1113	X
6103	The trigger attachment mode in the email is set incorrectly.	Set up the trigger attachment mode in HWCONFIG > CPU Module > Device Setting > Options > Ethernet Port Advanced > Email > Trigger Setting > Trigger Attachment Mode.	SM1113	X
6104	The attachment in the email does not exist.	Check if the attachment exists in the memory card.	SM1113	X
6105	The attachment in the email is oversized.	Check the size of the attachment. If the size is over 2 MB, the file cannot be sent as an attachment.	SM1113	X
6106	There is an SMTP server response timeout.	Check for the correct address and set up the SMTP server in HWCONFIG > CPU Module > Device Setting > Options > Ethernet Port Advanced > Email again.	SM1113	X
6107	There is an SMTP server response timeout.	<ol style="list-style-type: none"> <li>1. Check if the status of the SMTP server is normal.</li> <li>2. Retry sending of the email later. This error does not cause the PLC to stop running. Solve the problem by means of the related flag in the program.</li> </ol>	SM1113	X
6108	SMTP verification failed	Check for the correct ID/Password and set up in HWCONFIG > CPU Module > Device Setting > Options > Ethernet Port Advanced > Email again.	SM1113	X
6200	The remote communication IP address set in the TCP socket function is illegal.	<ol style="list-style-type: none"> <li>1. Check the program and the related special data registers.</li> <li>2. Set the Ethernet parameter for the CPU module in HWCONFIG CPU Module &gt; Device Setting &gt; Options &gt; Ethernet Port Advanced &gt; TCP Socket.</li> </ol>	-	X
6201	The local communication port set in the TCP socket function is illegal.	<ol style="list-style-type: none"> <li>1. Check the program and the related special data registers.</li> <li>2. Set the Ethernet parameter for the CPU module in HWCONFIG CPU Module &gt; Device Setting &gt; Options &gt; Ethernet Port Advanced &gt; TCP Socket.</li> </ol>	-	X
6202	The remote communication port set in the TCP socket function is illegal.	<ol style="list-style-type: none"> <li>1. Check the program and the related special data registers.</li> <li>2. Set the Ethernet parameter for the CPU module in HWCONFIG CPU Module &gt; Device Setting &gt; Options &gt; Ethernet Port Advanced &gt; TCP Socket.</li> </ol>	-	X
6203	The device from which the data is sent in the TCP socket function is illegal.	<ol style="list-style-type: none"> <li>1. Check the program and the related special data registers.</li> <li>2. Set the Ethernet parameter for the CPU module in HWCONFIG CPU Module &gt; Device Setting &gt; Options &gt; Ethernet Port Advanced &gt; TCP Socket.</li> </ol>	-	X

6206	The device which receives the data in the TCP socket function is illegal.	<ol style="list-style-type: none"> <li>1. Check the program and the related special data registers.</li> <li>2. Set the Ethernet parameter for the CPU module in HWCONFIG CPU Module &gt; Device Setting &gt; Options &gt; Ethernet Port Advanced &gt; TCP Socket.</li> </ol>	-	X
6208	The data received through the TCP socket exceeds the device range.	<ol style="list-style-type: none"> <li>1. Check the program and the related special data registers.</li> <li>2. Set the Ethernet parameter for the CPU module in HWCONFIG CPU Module &gt; Device Setting &gt; Options &gt; Ethernet Port Advanced &gt; TCP Socket.</li> </ol>	-	X
6209	The remote communication IP address set in the UDP socket function is illegal.	<ol style="list-style-type: none"> <li>1. Check the program and the related special data registers.</li> <li>2. Set the Ethernet parameter for the CPU module in HWCONFIG CPU Module &gt; Device Setting &gt; Options &gt; Ethernet Port Advanced &gt; UDP Socket.</li> </ol>	-	X
620A	The local communication port set in the UDP socket function is illegal.	<ol style="list-style-type: none"> <li>1. Check the program and the related special data registers.</li> <li>2. Set the Ethernet parameter for the CPU module in HWCONFIG CPU Module &gt; Device Setting &gt; Options &gt; Ethernet Port Advanced &gt; UDP Socket.</li> </ol>	-	X
620C	The device from which the data is sent in the UDP socket function is illegal.	<ol style="list-style-type: none"> <li>1. Check the program and the related special data registers.</li> <li>2. Set the Ethernet parameter for the CPU module in HWCONFIG CPU Module &gt; Device Setting &gt; Options &gt; Ethernet Port Advanced &gt; UDP Socket.</li> </ol>	-	X
620F	The device which receives the data in the UDP socket function is illegal.	<ol style="list-style-type: none"> <li>1. Check the program and the related special data registers.</li> <li>2. Set the Ethernet parameter for the CPU module in HWCONFIG CPU Module &gt; Device Setting &gt; Options &gt; Ethernet Port Advanced &gt; UDP Socket.</li> </ol>	-	X
6210	The data received through the UDP socket exceeds the device range.	<ol style="list-style-type: none"> <li>1. Check the program and the related special data registers.</li> <li>2. Set the Ethernet parameter for the CPU module in HWCONFIG CPU Module &gt; Device Setting &gt; Options &gt; Ethernet Port Advanced &gt; UDP Socket.</li> </ol>	-	X
6212	There is no response from the remote device after the timeout period.	Make sure that the remote device is connected.	-	X
6213	The data received exceeds the limit.	<ol style="list-style-type: none"> <li>1. Check the program and the related special data registers.</li> <li>2. Set the Ethernet parameter for the CPU module in HWCONFIG CPU Module &gt; Device Setting &gt; Options &gt; Ethernet Port Advanced &gt; UDP Socket.</li> </ol>	-	X
6214	The remote device refuses the connection.	Make sure the remote device operates normally.	-	X
6215	The socket is not opened.	Check if operational sequence in the program is	-	X

		correct.		
6217	The socket is opened.	Check if operational sequence in the program is correct.	-	X
6218	The data has been sent through the socket.	Check if operational sequence in the program is correct.	-	X
6219	The data has been received through the socket.	Check if operational sequence in the program is correct.	-	X
621A	The socket is closed.	Check if operational sequence in the program is correct.	-	X
7011	The device communication function code in COM1 is incorrect.	1. Check the communication setting in the master and the slave. 2. Check the communication cable.	-	H
7012	The device communication address used in COM1 is incorrect.	1. Check the communication setting in the master and the slave. 2. Check the communication cable.	-	H
7013	The device used in COM1 exceeds the device range.	1. Check the communication setting in the master and the slave. 2. Check the communication cable.	-	H
7014	The device length of the communication data in COM1 exceeds the limit.	1. Check the communication setting in the master and the slave. 2. Check the communication cable.	-	H
7017	The device checksum for the communication serial port of COM1 is incorrect.	1. Check the communication setting in the master and the slave. 2. Check the communication cable.	-	H
7021	The device communication function code in COM2 is incorrect.	1. Check the communication setting in the master and the slave. 2. Check the communication cable.	-	H
7022	The device communication address used in COM2 is incorrect.	1. Check the communication setting in the master and the slave. 2. Check the communication cable.	-	H
7023	The device used in COM2 exceeds the device range.	1. Check the communication setting in the master and the slave. 2. Check the communication cable.	-	H
7024	The device length of the communication data in COM2 exceeds the limit.	1. Check the communication setting in the master and the slave. 2. Check the communication cable.	-	H
7027	The device checksum for the communication serial port of COM2 is incorrect.	1. Check the communication setting in the master and the slave. 2. Check the communication cable.	-	H
7031	The device communication function code in the Ethernet is incorrect.	1. Check the communication setting in the master and the slave. 2. Check the communication cable.	-	H
7032	The device communication address used in the Ethernet is incorrect.	1. Check the communication setting in the master and the slave. 2. Check the communication cable.	-	H
7033	The device used in the Ethernet exceeds the device range.	1. Check the communication setting in the master and the slave. 2. Check the communication cable.	-	H
7034	The device length of the communication data in the Ethernet exceeds the limit.	1. Check the communication setting in the master and the slave. 2. Check the communication cable.	-	H

7037	The device checksum for the communication serial port of the Ethernet is incorrect.	1. Check the communication setting in the master and the slave. 2. Check the communication cable.	-	H
7041	The device communication function code in the USB is incorrect.	1. Check the communication setting in the master and the slave. 2. Check the communication cable.	-	H
7042	The device communication address used in the USB is incorrect.	1. Check the communication setting in the master and the slave. 2. Check the communication cable.	-	H
7043	The device used in the USB exceeds the device range.	1. Check the communication setting in the master and the slave. 2. Check the communication cable.	-	H
7044	The device length of the communication data in the USB exceeds the limit.	1. Check the communication setting in the master and the slave. 2. Check the communication cable.	-	H
7047	The device checksum for the communication serial port of the USB is incorrect.	1. Check the communication setting in the master and the slave. 2. Check the communication cable.	-	H
70B1	The device communication function code in function card 1 is incorrect.	1. Check the communication setting in the master and the slave. 2. Check the communication cable.	-	H
70B2	The device communication address used in function card 1 is incorrect.	1. Check the communication setting in the master and the slave. 2. Check the communication cable.	-	H
70B3	The device used in the function card 1 exceeds the device range.	1. Check the communication setting in the master and the slave. 2. Check the communication cable.	-	H
70B4	The device length of the communication data in function card 1 exceeds the limit.	1. Check the communication setting in the master and the slave. 2. Check the communication cable.	-	H
70B7	The device checksum for the communication serial port of function card 1 is incorrect.	1. Check the communication setting in the master and the slave. 2. Check the communication cable.	-	H
70C1	The device communication function code in function card 2 is incorrect.	1. Check the communication setting in the master and the slave. 2. Check the communication cable.	-	H
70C2	The device communication address used in function card 2 is incorrect.	1. Check the communication setting in the master and the slave. 2. Check the communication cable.	-	H
70C3	The device used in function card 2 exceeds the device range.	1. Check the communication setting in the master and the slave. 2. Check the communication cable.	-	H
70C4	The device length of the communication data in function card 2 exceeds the limit.	1. Check the communication setting in the master and the slave. 2. Check the communication cable.	-	H
70C7	The device checksum for the communication serial port of function card 2 is incorrect.	1. Check the communication setting in the master and the slave. 2. Check the communication cable.	-	H
7203	Invalid communication function code	1. Refer to the function codes defined by the communication protocols 2. Check if the software and firmware you are using	-	H

		<p>is the latest versions.</p> <p>3. Note down the operation procedures and the error messages and then contact your distributor.</p>		
8105	<p>The contents of the program downloaded are incorrect.</p> <p>The program syntax is incorrect.</p>	<p>1. Re-editing the program and download the program and parameters again.</p> <p>2. Check if the communication cables are securely connected.</p> <p>3. Save and compress the project and then send it to your distributor.</p>	-	H
8106	<p>The contents of the program downloaded are incorrect.</p> <p>The length of the execution code exceeds the limit.</p>	<p>1. Re-editing the program and download the program and parameters again.</p> <p>2. Save and compress the project and then send it to your distributor.</p>	-	H
8107	<p>The contents of the program downloaded are incorrect.</p> <p>The length of the source code exceeds the limit.</p>	<p>1. Re-editing the program and download the program and parameters again.</p> <p>2. Save and compress the project and then send it to your distributor.</p>	-	H
8000 - 8FFF	<p>PLC editing errors in ISPSOft</p>	<p>1. Check if the software and firmware you are using is the latest versions.</p> <p>2. Note down the operation procedures and the error messages and then contact your distributor.</p>	-	H

## 7.3 Troubleshooting for Other I/O Modules

- **Introduction to troubleshooting modules**

Digital I/O, analog I/O, temperature measurement, positioning, high-speed counter, load cell, and network modules can be installed in an AS Series system. There are 2 types of error codes; error and warning. The CPU module and its modules stop operating when errors occur. The CPU modules and its modules do not stop operating when warnings are triggered.

### 7.3.1 Troubleshooting for Analog Modules (AD/DA/XA) and Temperature Modules (RTD/TC)

#### 7.3.1.1 ERROR LED Indicators Are ON

You can set up HWCONFIG to have the following errors appear as warnings when they occur. Otherwise, when an error occurs, only an error message appears.

Error Code	Description	Solution
16#1605	Hardware failure	If the problem persists, contact the local authorized distributors.
16#1607	The external voltage is abnormal.	Check the power supply.
16#1608	The factory calibration or the CJC is abnormal.	If the problem persists, contact the local authorized distributors.

#### 7.3.1.2 ERROR LED Indicators Blinking Every 0.2 Seconds

The following errors are specified as warnings to ensure that the CPU module can still run even when the warnings are triggered by its modules. The following first 4 error codes are set as warnings by default in HWCONFIG; CPU must STOP running immediately when the first 4 errors occur.

Error Code	Description	Solution
16#1801	The external voltage is abnormal.	Check the power supply.
16#1802	Hardware failure	If the problem persists, contact the local authorized distributors.
16#1804	The factory calibration is abnormal.	If the problem persists, contact the local authorized distributors.
16#1807	The CJC is abnormal.	If the problem persists, contact the local authorized distributors.
16#1808	The signal received by channel 1 exceeds the range of analog inputs (temperature).	Check the signal received by channel 1
16#1809	The signal received by channel 2 exceeds the range of analog inputs (temperature).	Check the signal received by channel 2
16#180A	The signal received by channel 3 exceeds the range of analog inputs (temperature).	Check the signal received by channel 3
16#180B	The signal received by channel 4 exceeds the range of analog inputs (temperature).	Check the signal received by channel 4

Error Code	Description	Solution
16#180C	The signal received by channel 5 exceeds the range of analog inputs (temperature).	Check the signal received by channel 5
16#180D	The signal received by channel 6 exceeds the range of analog inputs (temperature).	Check the signal received by channel 6
16#180E	The signal received by channel 7 exceeds the range of analog inputs (temperature).	Check the signal received by channel 7
16#180F	The signal received by channel 8 exceeds the range of analog inputs (temperature).	Check the signal received by channel 8
-	Upon power-on, the module does NOT receive any detecting request from the PLC CPU.	Check the connection between the CPU and the module or reconnect them again.

## 7.3.2 Troubleshooting for the Positioning Module AS02/04PU

### 7.3.2.1 ERROR LED Indicators Blinking Every 0.2 Seconds

Error Code	Description	Solution
16#1802	Hardware failure	If the problem persists, contact the local authorized distributors.

## 7.3.3 Troubleshooting for the High-Speed Counter Module AS02HC

### 7.3.3.1 ERROR LED Indicators Are ON

Error Code	Description	Solution
16#1605	Counted result in the latched area is not retainable (major error)	Counted data is lost. Switch the module power OFF and ON again. The error code is cleared by the system. If the problem persists, contact the local authorized distributors.
16#1606	Module settings in the latched area is not retainable. (major error)	Module setting data is lost. Switch the module power OFF and ON again. Download the HWCONFIG settings again to clear the error code. If the problem persists, contact the local authorized distributors.
16#1607	Module setting error (major error)	Check if the setting in HWCONFIG is consistent with the actual placement. If the problem persists, contact the local authorized distributors.

### 7.3.3.2 ERROR LED Indicators Blinking Every 0.5 Seconds

The following errors are specified as warnings to ensure that the CPU module can still run even when the warnings are triggered by its AIO modules.

Error Code	Description	Solution
16#1800	Counter overflow / underflow on CH1	Check the counter result. If the alarm is not required, disable the alarm output function in HWCONFIG. Use any of the followings to clear the error code: clear, reset, preset the counter, restart the module, or execute DHCCNT instruction again.
16#1801	Counter overflow / underflow on CH2	
16#1802	Linear count exceeding the set upper/lower limit on CH1	Check the signal received by channel 1 and 2. Hardware counter is still counting; when the number is accumulated to the maximum and go back to the minimum, the error code will be cleared.
16#1803	Linear count exceeding the set upper/lower limit on CH2	
16#1804	The variation in relation to a SSI encoder position exceeding the limit on CH1	Check if there is any interruption and check the device specification to see if the offset setting is matching with the actual placement. When the next reading is normal, the error code will be cleared.
16#1805	The variation in relation to a SSI encoder position exceeding the limit on CH2	
16#1806	Abnormal SSI communication on CH1	Check the execution of DHCCNT instruction. If it is parity check, check is there is any interruption and check if the data format is correct. Check if the device wiring is secure, and if the encoder power supply is normal.
16#1807	Abnormal SSI communication on CH2	
16#1808	SSI absolute position cross zero point on CH1	Check the SSI absolute encoder specification and modify the setting accordingly. If the alarm is not required, disable the alarm output function in HWCONFIG. Use any of the followings to clear the error code: clear, reset, preset the counter, restart the module, or execute DHCCNT instruction again.
16#1809	SSI absolute position cross zero point on CH2	

## 7.3.4 Troubleshooting for the Load Cell Module AS02LC

### 7.3.4.1 ERROR LED Indicators Are ON

You can set up HWCONFIG to have the following errors appear as warnings when they occur. Otherwise, when an error occurs, only an error message appears.

Error Code	Description	Solution
16#1605	Hardware failure (that is, the driver board)	If the problem persists, contact the local authorized distributors.
16#1607	The external voltage is abnormal.	Check the power supply.

### 7.3.4.2 ERROR LED Indicators Blinking Every 0.2 Seconds

The following errors are specified as warnings to ensure that the CPU module can still run even when the warnings are triggered by its modules. The following first 3 error codes are set as warnings by default in HWCONFIG; CPU must STOP running immediately when the first 3 errors occur.

Error Code	Description	Solution
16#1801	The external voltage is abnormal.	Check the power supply.
16#1802	Hardware failure	If the problem persists, contact the local authorized distributors.
16#1807	Diver board failure	Check if the terminals is affected by any interference or is short-circuit (check EXC+ and EXC-). If the problem persists, contact the local authorized distributors.
16#1808	The signal received by channel 1 exceeds the range of analog inputs or the SEN voltage is abnormal.	Check the signal received by channel 1 and the cable connections.
16#1809	The signal received by channel 1 exceeds the weight limit.	Check the value input to channel 1 and the maximum weight setting.
16#180A	The factory calibration in channel 1 is incorrect.	Check the weight calibration in channel 1.
16#180B	The signal received by channel 2 exceeds the range of analog inputs or the SEN voltage is abnormal.	Check the signal received by channel 2 and the cable connections.
16#180C	The signal received by channel 2 exceeds the weight limit.	Check the value input to channel 2 and the maximum weight setting.
16#180D	The factory calibration in channel 2 is incorrect.	Check the weight calibration in channel 1.
-	Upon power-on, the module does NOT receive any detecting request from the PLC CPU.	Check the connection between the CPU and the module or reconnect them again.

## 7.3.5 Troubleshooting for the Module AS04SIL IO-Link as a Communication Module

### 7.3.5.1 ERROR LED Indicators (Module Status) Blinking Every 0.2 Seconds

The following error codes identify possible errors when the AS04SIL module is installed on the right side of the CPU module or RTU and acts as a communication module.

Error Code	Description	Solution
16#1605	Hardware failure	<ol style="list-style-type: none"> <li>1. Check that the module is securely installed.</li> <li>2. Install a new AS04SIL or if the problem persists, contact the local authorized distributors.</li> </ol>
16#1606	24VDC power supply is not sufficient and then recovered from low-voltage for less than 10 ms.	Check whether the 24 V power supply to the module is normal.

### 7.3.5.2 ERROR LED Indicators (Network Status) Are ON

The following error codes identify possible errors when the AS-SIL module is installed on the right side of the CPU module or RTU and acts as a communication module.

Error Code	Description	Solution
16#1802	No external power supply	Check the external power supply

### 7.3.5.3 ERROR LED Indicators (Network Status) Blinking Every 1 Seconds

The following error codes identify possible errors when the AS-SIL module is installed on the right side of the CPU module or RTU and acts as a communication module.

Error Code	Description	Solution
16#1800	Error occurs in IO-Link Master	See the following IO-Link Event Code table for more information.
16#1801	Error occurs in IO-Link device	See the following IO-Link Event Code table for more information.
16#1803	Error in the download of IO-Link device mapping tables	Redownload the configuration by the software.
16#1804	Failure to switch the process data parameter set	Check if the configurations of the actual connected device are the same as the ones in the software.
16#1805	A connection error occurs in IO-Link via communication port 1	1. Cut the external power off for 3 seconds and then put the power back on. 2. Redownload the configuration by the software.
16#1806	A connection error occurs in IO-Link via communication port 2	
16#1807	A connection error occurs in IO-Link via communication port 3	
16#1808	A connection error occurs in IO-Link via communication port 4	
16#1809	Device scanning error and the scanning is forced to stop	1. Cut the external power off for 3 seconds and then put the power back on. 2. Scan all device again

#### IO-Link Event Code Table

You can find the IO-Link event codes in the module data exchange area where the device states of communication port 1~4 are stored. Check the IO-Link device operation manual if the event occurred is from IO-Link devices.

IO-Link Event Codes	Type			Event	Solution	Source	
	Warning	Error	Notification			IO-Link Master	IO-Link Device
16#4000		√		Device temperature over-load	Lower load		√
16#4210	√			Device temperature over-run	Clear source of heat		√
16#5101		√		Device fuse blown	Change fuse		√
16#5110	√			Power supply voltage over-run	Check tolerance		√
16#5111	√			Power supply voltage under-run	Check tolerance		√
16#6320		√		Parameter error	Check device specifications		√
16#6321		√		Parameter missing	Check device specifications		√
16#7710		√		Device short circuit	Check installation		√

IO-Link Event Codes	Type			Event	Solution	Source	
	Warning	Error	Notification			IO-Link Master	IO-Link Device
16#8C10	V			Process variable range over-run	Check process data		V
16#8C20		V		Measurement range over-run	Check application		V
16#8C30	V			Process variable range under-run	Check process data		V
16#8CA0	V			No connected IO-Link device	Check installation	V	
16#8CA1	V			The version of the IO-Link protocol is different from the one configured.	Use matching IODD file and configured again.	V	
16#8CA2	V			Connected device is different from the one configured in the software	Check configurations and installation	V	
16#8CA3				Reserved		V	
16#8CA4		V		IO-Link device process cable short circuit	Check installation	V	
16#8CA5	V			Master temperature exceeds 135°C	Clear source of heat	V	
16#8CA6		V		Master temperature exceeds 160°C	Clear source of heat and lower load	V	
16#8CA7	V			Device power supply voltage under-run L+ (<18V)	Check the external power supply	V	
16#8CA8		V		Device power supply voltage under-run L+ (<9V)	Check the external power supply	V	
16#8CA9	V			Illegal device ID	Check device specifications	V	
16#8CAA	V			IO-Link process data range over-run	Check device specifications	V	
16#8CAB	V			Process data range over-run	Scan the device and download the configuration again	V	
16#8CAC		V		Data storage error	If the problem persists, contact the local authorized distributors.	V	
0xFF21			V	New connected device		V	
0xFF22			V	Device disconnected	Check installation	V	
0xFF23			V	Data storage identification mismatch	Set the Data Storage access locked and set it to backup / restore and then backing up data according to actual placement.	V	
0xFF24			V	Data storage not sufficient	Check device specifications	V	
0xFF25			V	Data storage parameter access denied	Check device specifications	V	

## 7.3.6 Troubleshooting for the Module AS00SCM as a Communication Module

### 7.3.6.1 ERROR LED Indicator Are ON

The following error codes identify possible errors when the AS00SCM module is installed on the right side of the CPU module and acts as a communication module.

Error Code	Description	Solution
16#1605	Hardware failure	<ol style="list-style-type: none"> <li>3. Check that the module is securely installed.</li> <li>4. Install a new AS00SCM or contact your distributor.</li> </ol>
16#1606	Errors on the settings of the communication module function card	<ol style="list-style-type: none"> <li>1. Check if the function card is securely installed.</li> <li>2. Install a new function card or contact your distributor.</li> <li>3. Check if the setting in HWCONFIG is consistent with the function card setting.</li> <li>4. Install a new AS00SCM or contact your distributor.</li> </ol>

### 7.3.6.2 ERROR LED Indicators Blinking Every 0.5 Seconds

The following error codes identify possible errors when the AS00SCM module is installed on the right side of the CPU module and acts as a communication module.

Error Code	Description	Solution
16#1802	Incorrect parameters	Check the parameter in HWCONFIG. Download the parameter again.
16#1803	Communication timeout	<ol style="list-style-type: none"> <li>1. Check if the communication cable is properly connected.</li> <li>2. Check if the station number and the communication format are correctly set.</li> <li>3. Check if the connection with the function card is working correctly.</li> </ol>
16#1804	The UD Link setting is incorrect.	<ol style="list-style-type: none"> <li>1. Check the settings of the UD Link.</li> <li>2. Check the warning settings in the PLC.</li> </ol>

The following error codes can only be viewed with SCMSOFT; when the following errors occur, they are not shown on the LED indicators and the system does not send the error messages to the CPU module.

Error Code	Description	Solution
16#0107	The settings in HWCONFIG and manual settings are not consistent with function card 1.	Check the settings in HWCONFIG and manual settings for function card 1.
16#0108	The settings in HWCONFIG and manual settings are not consistent for function card 2.	Check the settings in HWCONFIG and manual settings for function card 2.
16#0201	Incorrect parameters	Check the parameter in HWCONFIG. Download the parameter again.
16#0301	Function card 1 communication timeout	<ol style="list-style-type: none"> <li>1. Check if the station number and the communication format are correctly set.</li> <li>2. Check if the connection with the function card is working correctly.</li> </ol>

Error Code	Description	Solution
16#0302	Function card 2 communication timeout	<ol style="list-style-type: none"> <li>1. Check if the station number and the communication format are correctly set.</li> <li>2. Check if the connection with the function card is working correctly.</li> </ol>
16#0400	Invalid UD Link Group ID for function card 1	<ol style="list-style-type: none"> <li>1. Check the UD Link settings.</li> <li>2. Check the warning settings in the PLC.</li> </ol>
16#0401	Invalid UD Link Group ID for function card 2	<ol style="list-style-type: none"> <li>1. Check the UD Link settings.</li> <li>2. Check the warning settings in the PLC.</li> </ol>
16#0402	Invalid UD Link Command for function card 1	<ol style="list-style-type: none"> <li>1. Check the UD Link settings.</li> <li>2. Check the warning settings in the PLC.</li> </ol>
16#0403	Invalid UD Link Command for function card 1	<ol style="list-style-type: none"> <li>1. Check the UD Link settings.</li> <li>2. Check the warning settings in the PLC.</li> </ol>

### 7.3.7 Troubleshooting for the Module AS00SCM as a Remote Module

Errors from the remote modules are regarded as warnings for AS Series CPU modules. The LED indicator of the CPU module blinks and the CPU module can still operate. Use flag SM30 to manage error presentation in the remote modules.

#### 7.3.7.1 ERROR LED Indicators Are ON

Error codes:

Error Code	Description	Solution
16#1301	Hardware failure	<ol style="list-style-type: none"> <li>1. Check if the module is securely installed.</li> <li>2. Change and install a new AS00SCM or contact your distributor.</li> </ol>
16#1302	Errors on the settings of the communication module function card	<ol style="list-style-type: none"> <li>1. Check if the function card is securely installed with the AS-FCOPM card.</li> <li>2. Change and install a new function card or contact your distributor.</li> <li>3. Check if the setting in HWCONFIG is consistent with the function card setting.</li> <li>4. Install a new AS00SCM or contact your distributor.</li> </ol>
16#1304	More than eight remote modules on the right side of the CPU module.	Check the total number of remote modules on the right side of the CPU module (maximum is 8).

#### 7.3.7.2 ERROR LED Indicators Blinking Every 1 Seconds

Warning type of error codes:

Error Code	Description	Solution
16#1506	Remote module had been stopped.	This error code should work with AS Series Remote Module Setting in ISPSoft. When this error code shows up, it indicates the remote module had been stopped: Master Disconnected, Master Reconnected, IO Module Alarm, or IO Module Timeout. Check and clear the problem and then power-off and then power-on the remote module to refresh its state. Refer to section 9.4.3 in AS Series Module Manual for more details.

### 7.3.7.3 ERROR LED Indicators Blinking Every 0.5 Seconds

Warning type error codes:

Error Code	Description	Solution
16#1500	Remote module communication timeout	Check the network connection cable of the remote modules.
16#1502	Incorrect parameters	Check the parameter in HWCONFIG. Download the parameter again.
16#1503	Extension module communication timeout	Make sure the module is properly connected to the CPU module and turn the modules on again.
16#1505	The actual arrangement of the extension module is not consistent with the configurations.	Check the actual arrangement and the configurations.
16#1604	Extension module communication timeout	<ol style="list-style-type: none"> <li>1. Make sure the module is properly connected to the CPU module and turn the modules on again.</li> <li>2. If the problem persists, contact the local authorized distributors.</li> </ol>

### 7.3.7.4 ERROR LED Indicators Blinking Every 0.2 Seconds

This happens when the 24 VDC power supply for the remote module is not sufficient. Check the power supply. If the power supply is normal, remove the extension module from the CPU module and then check if the SCM remote module is out of order.

Error codes:

Error Code	Description	Solution
16#1303	24VDC power supply is not sufficient and then recovered from low-voltage for less than 10 ms.	Check if the 24 V power supply to the module is normal.

## 7.3.8 Troubleshooting for AS01DNET Modules

Refer to sections 7.4.9 and 7.4.10 for more details.

## 7.4 Error Codes and LED Indicators for Modules

### 7.4.1 Error Codes and LED Indicators for CPU Modules

#### A. Columns

- a. Error code: If an error occurs in the system, an error code is generated.
- b. Description: The description of the error
- c. CPU status: If the error occurs, the CPU stops running, keeps running, or shows the status you defined for the error.
  - Stop: The CPU stops running when the error occurs.
  - Continue: The CPU keeps running when the error occurs.
- d. LED indicator status: If the error occurs, the LED indicator is ON, OFF, or blinks.
  - ERROR: System error

#### ● Descriptions

Module Type	LED indicator	Descriptions
<b>CPU</b>	Error LED	<p>There are five types of error indicator states for of the CPU module errors, including LED indicator ON, OFF, blinking fast, blinking normally, and blinking slowly. When the LED indicator is ON, blinking fast/normally, clear the problems first in order to run the CPU module. When the LED indicator is blinking slowly, indicating a warning type of error codes, it does not require immediate action. Clear the problems when the module is powered off.</p> <p>Error type:</p> <ul style="list-style-type: none"> <li>ON: A serious error occurs in the module.</li> <li>Blinking fast (every 0.2 seconds): unstable power supply or hardware Failure.</li> <li>Blinking normally (every 0.5 second): system program errors or system cannot run.</li> </ul> <p>Warning type:</p> <ul style="list-style-type: none"> <li>Blinking slowly (every one second and off for three seconds): a warning is triggered, but the system can still run.</li> <li>OFF: a warning is triggered, but the system can still run. You can modify the rules of how a warning is triggered, or use the SM/SR to show the warnings.</li> </ul>

Error code	Description	CPU status	ERROR LED indicator status				
			ON	Blinking fast	Blinking normally	Blinking slowly	OFF
000A	Scan timeout	Stop	V				
000C	The program in the PLC is damaged.	Stop			V		
000D	The initial value of the device and the PLC program are not completely downloaded.	Stop			V		
0010	The access to the memory in the CPU is denied.	Stop			V		
0011	The PLC ID is incorrect.	Continue					V
0012	The PLC password is incorrect.	Continue					V
0020	CPU operation speed is not at its highest.	Stop			V		
0021	Failed to restore Delta device parameters back to defaults	H			H		
<p>Note: You can set to have PLC CPU stop running or not in HWCONFIG if this error occurs. If the setting is to have PLC CPU stops running once 16#0021 occurs, the PLC CPU will stop running and the ERROR LED will go blinking. If the setting is to have PLC CPU keep running, the error will be stated in the Error Log but ERROR LED will not go blinking.</p>							
0026	RTC cannot keep track of the current time (the battery LED is blinking.)	Continue					
0027	Battery low (the battery LED is ON.)	Continue					
0028	No response from RTC	Continue					V
002A	24VDC power supply is not sufficient and then is recovered from low-voltage for less than 10 ms.	Continue		V			
002D	The PLC maximum password attempts exceeded.	Continue					V
002E	The access to the external memory of the CPU is denied.	Stop			V		
002F	PLC programs are not consistent with the system logs.	Stop			V		
0040	The converted value in the function card 1 (AS-F2AD) or in the built-in AD input channel 1 exceeds the setting range.	Continue				V	
0041	The converted value in the function card 1 (AS-F2AD) or in the built-in AD input channel 2 exceeds the setting range.	Continue				V	
0042	The converted value in the input channel 1 of the function card 2 (AS-F2AD) exceeds the setting range.	Continue				V	
0043	The converted value in the input channel 2 of the function card 2 (AS-F2AD) exceeds the setting range.	Continue				V	
0044	Connection lost in the mode of current input 4 mA - 20 mA for the function card 1 (AS-F2AD) or for the built-in AD input channel 1.	Continue				V	
0045	Connection lost in the mode of current input 4 mA - 20 mA for the function card 1 (AS-F2AD) or for the built-in AD input channel 2.	Continue				V	
0046	Connection lost in the mode of current input 4 mA - 20 mA for the input channel 1 of the function card 2 (AS-F2AD).	Continue				V	
0047	Connection lost in the mode of current input 4 mA - 20 mA for the input channel 2 of the function card 2 (AS-F2AD).	Continue				V	
0050	The memories in the latched special auxiliary relays are abnormal.	Continue					V
0051	The latched special data registers are abnormal.	Continue					V

Error code	Description	CPU status	ERROR LED indicator status				
			ON	Blinking fast	Blinking normally	Blinking slowly	OFF
0052	The memories in the latched auxiliary relays are abnormal.	Continue					V
0054	The latched counters are abnormal.	Continue					V
0055	The latched 32-bit counters are abnormal.	Continue					V
0056	The latched special auxiliary relay is abnormal.	Continue					V
0059	The latched data registers are abnormal.	Continue					V
005D	The CPU module does not detect a memory card.	Continue					V
005E	The memory card is initialized incorrectly.	Continue					V
0063	An error occurs when data is written to the memory card.	Continue					V
0064	A file in the memory card cannot be read.	Continue					V
0070	The actual arrangement of the function cards is not consistent with the settings.	Stop			V		
0102	The interrupt number exceeds the range.	Stop			V		
0202	The MC instruction exceeds the range.	Stop			V		
0302	The MCR instruction exceeds the range.	Stop			V		
0D03	The operands used in DHSCS are not used properly.	Stop			V		
0E05	The operands HCXXX used in DCNT are not used properly.	Stop			V		
1000 - 10FF	System error	Stop			V		
1300 - 130F	Errors occurred in the remote modules	Continue				V	
1402	The arrangement of the I/O modules is not consistent with the settings.	Stop			V		
140B	Number of communication modules exceeds the limit of four.	Stop			V		
140C	The number of connected positioning modules exceed the maximum number 8.	Stop			V		
140D	Number of extension modules exceeds the limit of 32.	Stop			V		
140E	Number of remote modules exceeds the limit of eight on the right side of the CPU module.	Stop			V		
1500	Connection lost in the remote modules	Continue				V	
1502 - 150F	Errors occurred in the remote modules	Continue				V	
1600	The ID of the extension module exceeds the range.	Stop			V		
1601	The ID of the extension module cannot be set.	Stop			V		
1602	The ID of the extension module is duplicated.	Stop			V		
1603	The extension module cannot be operated.	Stop			V		
1604	Extension module communication timeout	Stop			V		
1605	Hardware failure	Stop			V		
1606	Errors on the settings of the communication module function card	Stop			V		

Error code	Description	CPU status	ERROR LED indicator status				
			ON	Blinking fast	Blinking normally	Blinking slowly	OFF
1607	The external voltage is abnormal.	Stop			V		
1608	The Internal factory calibration or the CJC is abnormal.	Stop			V		
1609 - 160F	Reserved (Error codes for the extension modules)	Stop			V		
1800 - 180F	Errors occurred in the extension modules	Continue				V	
1900 - 191C	Heartbeat / connection loss errors occurred in the slave of the CANopen / ECAT communication module.	Continue				V	
1950	The initialization of CANopen communication module has not yet been completed, the CANopen instructions cannot be executed.	Continue					V
19B0	Heartbeat timeout occurred in the slave of the CANopen communication module.	Continue					V
19B1	The data length of PDO (process data object) in the slave mode is not matched with the setting.	Continue					V
19E1	The data length of PDO (process data object) in the slave mode is not matched with the setting of the scan list. Refer to section 10.5 CANopen communication related descriptions in AS Series Hardware and Operation Manual for more details on the error codes 19E1 to 19E8.	Continue					V
19E2	PDO in the slave mode is not received.	Continue					V
19E3	The function of auto downloading SDO fails at the first startup.	Continue					V
19E4	PDO configurations are set incorrectly.	Continue					V
19E5	The main settings are not consistent with the connected slave.	Continue					V
19E6	The slave does NOT exist in the network.	Continue					V
19E7	Timeout on the slave error control	Continue					V
19E8	The node IDs of master and slave are duplicated.	Continue					V
19F3	Error in the configuration	Continue					V
19F4	CANopen communication is in the BUS-OFF state.	Continue					V
19FB	The sending registers exceed the range.	Continue					V
19FC	The receiving registers exceed the range.	Continue					V
2001	Not using the FCOMP card or not in the right mode for the ASDA-A2 while using the CANopen communication instruction.	Continue					V
2003	The device used in the program exceeds the device range or it is illegal.	Continue					V
200A	Invalid instruction	Stop			V		
200B	The operand n or the other constant operands K/H exceed the range.	Continue					V
200C	The operands overlap.	Continue					V

Error code	Description	CPU status	ERROR LED indicator status				
			ON	Blinking fast	Blinking normally	Blinking slowly	OFF
200D	The binary to binary-coded decimal conversion is incorrect.	Continue					V
200E	The string does not end with 00.	Continue					V
2012	Incorrect division operation	Continue					V
2013	The value exceeds the range of values which can be represented by the floating-point numbers.	Continue					V
2014	The task designated by the TKON or YKOFF instruction is incorrect, or exceeds the range.	Continue					V
2017	The instruction BREAK is written outside of the FOR-NEXT loop.	Continue					V
2027	No such position planning table number or the format is incorrect.	Continue					V
2028	The high speed output instruction is being executed. Only one instruction can be executed at a time.	Continue					V
2030	The output frequency executed by CSFO instruction exceeds the maximum output frequency.	Continue					V
2031	If the input pulse is 0 Hz and lasts for more than 2 seconds, PLC stops outputting automatically.	Continue					V
6004	The IP address filter is set incorrectly.	Continue					V
600D	RJ45 port is not connected.	Continue					V
6010	The number of the MODBUS TCP connections exceeds the range.	Continue			V		
6011	The number of the EtherNet/IP connections exceeds the range.	Continue			V		
6012	There are devices using the same IP address.	Continue					V
6100	The email connection is busy.	Continue					V
6103	The trigger attachment mode in the email is set incorrectly.	Continue					V
6104	The attachment in the email does not exist.	Continue					V
6105	The attachment in the email is too big.	Continue					V
6106	There is an SMTP server response timeout.	Continue					V
6107	There is an SMTP server response timeout.	Continue					V
6108	SMTP verification failed	Continue					V
6200	The remote communication IP address set in the TCP socket function is illegal.	Continue					V
6201	The local communication port set in the TCP socket function is illegal.	Continue					V
6202	The remote communication port set in the TCP socket function is illegal.	Continue					V
6203	The device from which the data is sent in the TCP socket function is illegal.	Continue					V
6206	The device that receives the data in the TCP socket function is illegal.	Continue					V
6208	The data that is received through the TCP socket exceeds the device range.	Continue					V
6209	The remote communication IP address set in the UDP socket function is illegal.	Continue					V

Error code	Description	CPU status	ERROR LED indicator status				
			ON	Blinking fast	Blinking normally	Blinking slowly	OFF
620A	The local communication port set in the UDP socket function is illegal.	Continue					V
620C	The device from which the data is sent in the UDP socket function is illegal.	Continue					V
620F	The device that receives the data in the UDP socket function is illegal.	Continue					V
6210	The data that is received through the UDP socket exceeds the device range.	Continue					V
6212	There is no response from the remote device after the timeout period.	Continue					V
6213	The data received exceeds the limit.	Continue					V
6214	The remote device refuses the connection.	Continue					V
6215	The socket is not opened.	Continue					V
6217	The socket is opened.	Continue					V
6218	The data has been sent through the socket.	Continue					V
6219	The data has been received through the socket.	Continue					V
621A	The socket is closed.	Continue					V
7011	The device communication function code in COM1 is incorrect.	Continue					V
7012	The device communication address used in COM1 is incorrect.	Continue					V
7013	The device used in COM1 exceeds the device range.	Continue					V
7014	The device length of the communication data in COM1 exceeds the limit.	Continue					V
7017	The device checksum for the communication serial port of COM1 is incorrect.	Continue					V
7021	The device communication function code in COM2 is incorrect.	Continue					V
7022	The device communication address used in COM2 is incorrect.	Continue					V
7023	The device used in COM2 exceeds the device range.	Continue					V
7024	The device length of the communication data in COM2 exceeds the limit.	Continue					V
7027	The device checksum for the communication serial port of COM2 is incorrect.	Continue					V
7031	The device communication function code in Ethernet is incorrect.	Continue					V
7032	The device communication address used in Ethernet is incorrect.	Continue					V
7033	The device used in Ethernet exceeds the device range.	Continue					V
7034	The device length of the communication data in Ethernet exceeds the limit.	Continue					V
7037	The device checksum for the communication serial port of Ethernet is incorrect.	Continue					V
7041	The device communication function code in USB is incorrect.	Continue					V

Error code	Description	CPU status	ERROR LED indicator status				
			ON	Blinking fast	Blinking normally	Blinking slowly	OFF
7042	The device communication address used in USB is incorrect.	Continue					V
7043	The device used in USB exceeds the device range.	Continue					V
7044	The device length of the communication data in USB exceeds the limit.	Continue					V
7047	The device checksum for the communication serial port of USB is incorrect.	Continue					V
70B1	The device communication function code in function card 1 is incorrect.	Continue					V
70B2	The device communication address used in function card 1 is incorrect.	Continue					V
70B3	The device used in function card 1 exceeds the device range.	Continue					V
70B4	The device length of the communication data in function card 1 exceeds the limit.	Continue					V
70B7	The device checksum for the communication serial port of function card 1 is incorrect.	Continue					V
70C1	The device communication function code in function card 2 is incorrect.	Continue					V
70C2	The device communication address used in function card 2 is incorrect.	Continue					V
70C3	The device used in function card 2 exceeds the device range.	Continue					V
70C4	The device length of the communication data in function card 2 exceeds the limit.	Continue					V
70C7	The device checksum for the communication serial port of function card 2 is incorrect.	Continue					V
7203	Invalid communication function code	Continue					V
8105	The contents of the downloaded program are incorrect. The program syntax is incorrect.	Continue					V
8106	The contents of the downloaded program are incorrect. The length of the execution code exceeds the limit.	Continue					V
8107	The contents of the downloaded program are incorrect. The length of the source code exceeds the limit.	Continue					V
8000 - 8FFF	PLC editing errors in ISPSOft	Continue					V
C000 - CFFF	Syntax error in the PLC program	Stop			V		

## 7.4.2 Error Codes and LED Indicators for Analog/Temperature Modules

Error code	Description	ERROR LED indicator status	
		A → D / D → A / A ↔ D	ERROR
16#1605	Hardware failure	OFF	ON
16#1607	The external voltage is abnormal.	OFF	ON
16#1608	The factory calibration or the CJC is abnormal.	OFF	ON
16#1801*1	The external voltage is abnormal.	OFF	Blinking
16#1802*1	Hardware failure	OFF	Blinking
16#1804*1	The factory calibration is abnormal.	RUN: Blinking STOP: OFF	Blinking
16#1807*1	The CJC is abnormal.	OFF	Blinking
16#1808	The signal received by channel 1 exceeds the range of analog inputs (temperature).	RUN: Blinking STOP: OFF	Blinking
16#1809	The signal received by channel 2 exceeds the range of analog inputs (temperature).		
16#180A	The signal received by channel 3 exceeds the range of analog inputs (temperature).		
16#180B	The signal received by channel 4 exceeds the range of analog inputs (temperature).		
16#180C	The signal received by channel 5 exceeds the range of analog inputs (temperature).		
16#180D	The signal received by channel 6 exceeds the range of analog inputs (temperature).		
16#180E	The signal received by channel 7 exceeds the range of analog inputs (temperature).		
16#180F	The signal received by channel 8 exceeds the range of analog inputs (temperature).		
-	Upon power-on, the module does NOT receive any detecting request from the PLC CPU.	OFF	Blinking once or twice. After stops blinking for two seconds, starts the blinking pattern all over again.

\*1: The following errors are specified as warnings to ensure the CPU module can still run even when the warnings are triggered by its AIO modules. You can set up HWCONFIG to have the following first 4 error codes appear as errors when they occur.

### 7.4.3 Error Codes and LED Indicators for Positioning Module AS02 / O4PU

Error code	Description	ERROR LED indicator status	
		A → D	ERROR
16#1802	Hardware failure	OFF	Blinking

### 7.4.4 Error Codes and LED Indicators for High Speed Counter Module AS02HC

Error code	Description	ERROR LED indicator status	
		ON	Blinking
16#1605	Counted result in the latched area is not retainable (major error)	√	
16#1606	Module settings in the latched area is not retainable. (major error)	√	
16#1607	Module setting error (major error)	√	
16#1800	Counter overflow / underflow on CH1		√
16#1801	Counter overflow / underflow on CH2		√
16#1802	Linear count exceeding the set upper/lower limit on CH1		√
16#1803	Linear count exceeding the set upper/lower limit on CH2		√
16#1804	The variation in relation to a SSI encoder position exceeding the limit on CH1		√
16#1805	The variation in relation to a SSI encoder position exceeding the limit on CH2		√
16#1806	Abnormal SSI communication on CH1		√
16#1807	Abnormal SSI communication on CH2		√
16#1808	SSI absolute position cross zero point on CH1		√
16#1809	SSI absolute position cross zero point on CH2		√

### 7.4.5 Error Codes and LED Indicators for Load Cell Module AS02LC

Error code	Description	ERROR LED indicator status	
		A → D	ERROR
16#1605	Hardware failure (the diver board included)	OFF	ON
16#1607	The external voltage is abnormal.	OFF	ON
16#1801*1	The external voltage is abnormal.	OFF	Blinking
16#1802*1	Hardware failure	OFF	Blinking
16#1807*1	Diver board failure	OFF	Blinking
16#1808	The signal received by channel 1 exceeds the range of analog inputs or the SEN voltage is abnormal.	RUN: Blinking STOP: OFF	Blinking
16#1809	The signal received by channel 1 exceeds the weight limit.		
16#180A	The factory calibration in channel 1 is incorrect.		
16#180B	The signal received by channel 2 exceeds the range of analog inputs or the SEN voltage is abnormal.		
16#180C	The signal received by channel 2 exceeds the weight limit.		
16#180D	The factory calibration in channel 2 is incorrect.		
-	Upon power-on, the module does NOT receive any detecting request from the PLC CPU.	OFF	Blinking once or twice. After stops blinking for two seconds, starts the blinking pattern all over again.

\*1: The following errors are specified as warnings to ensure the CPU module can still run even when the warnings are triggered by its modules. You can set up HWCONFIG to have the following first 3 error codes appear as errors when they occur.

### 7.4.6 Error Codes and LED Indicators for Module AS04SIL IO-Link as a Communication Module

Error Code	Description	MS Status LED indicator	
		ON	Blinking
16#1605	Hardware failure		V
16#1606	24VDC power supply is not sufficient and then recovered from low-voltage for less than 10 ms.		V

Error Code	Description	NS LED indicator	
		ON	Blinking
16#1800	Error occurs in IO-Link Master		V
16#1801	Error occurs in IO-Link device		V
16#1802	No external power supply	V	
16#1803	Error in the download of IO-Link device mapping tables		V

Error Code	Description	NS LED indicator	
		ON	Blinking
16#1804	Failure to switch the process data parameter set		V
16#1805	A connection error occurs in IO-Link via communication port 1		V
16#1806	A connection error occurs in IO-Link via communication port 2		V
16#1807	A connection error occurs in IO-Link via communication port 3		V
16#1808	A connection error occurs in IO-Link via communication port 4		V
16#1809	Device scanning error and the scanning is forced to stop		V

#### 7.4.7 Error Codes and LED Indicators for Module AS00SCM as a Communication Module

Error Code	Description	ERROR LED indicator status	
		ON	Blinking
16#1605	Hardware failure	V	
16#1606	Errors on the settings of the communication module function card	V	
16#1802	Incorrect parameters		V
16#1803	Communication timeout		V
16#1804	The setting of the UD Link is incorrect.		V

#### 7.4.8 Error Codes and LED Indicators for Module AS00SCM as a Remote Module

Error Code	Description	ERROR LED indicator status			
		ON	Blinking	Blinking slow	Blinking fast
16#1301	Hardware failure	V			
16#1302	The setting of the function card is incorrect.	V			
16#1303	24 VDC power supply is not sufficient and then is recovered from a low-voltage less than 10ms situation.				V
16#1304	More than eight remote modules on the right side of the CPU module.	V			
16#1500	Remote module communication timeout		V		
16#1502	Incorrect parameters		V		
16#1503	Extension module communication timeout		V		
16#1505	The actual placement of the extension modules is NOT the same as it is set.		V		
16#1506	Remote module had been stopped.			V	
16#1604	Extension module communication timeout		V		

### 7.4.9 Error Codes and LED Indicators for Module AS01DNET (Master/Slave Mode)

Code	Explanation	Correction
0~63	Node address of AS01DNET-A (in normal operation)	--
80	AS01DNET-A is in STOP status.	Turn the PLC to RUN and start I/O data exchange
F0	The node ID of AS01DNET is the same as that of other node or exceeds the allowed range.	<ol style="list-style-type: none"> <li>1. Ensure that the node address of AS01DNET is unique.</li> <li>2. Re-power AS01DNET.</li> </ol>
F1	No configured slave in Scan List.	Configure the scan list and then download the configuration to AS01DNET.
F2	Too low voltage of the work power	Check if the power supply for AS01DNET and the PLC is normal.
F3	AS01DNET enters the test mode	Switch the function switch IN1 from On to Off and re-power AS01DNET-A.
F4	BUS-OFF	<ol style="list-style-type: none"> <li>1. Check if the network cable is normal and the shielded cable is grounded.</li> <li>2. Check if the baud rates of all nodes in the network are same.</li> <li>3. Check if the start and end of the network cable are both connected with a 121Ω terminal resistor.</li> <li>4. Re-power AS01DNET-A.</li> </ol>
F5	No network power	<ol style="list-style-type: none"> <li>1. Check if the network cable is normal.</li> <li>2. Ensure that the network power is normal.</li> </ol>
F6	Internal error; Flash or RAM check error	If the error still exists after re-power, send AS01DNET-A back for repair.
F8	Error produced in factory manufacturing	If the error still exists after re-power, send AS01DNET-A back for repair.
F9	Internal error; EEPROM access failure	If the error still exists after re-power, send AS01DNET-A back for repair.
FA	Invalid configuration data	<ol style="list-style-type: none"> <li>1. Configure the network correctly and re-download it to AS01DNET-A.</li> <li>2. Check if the node address of one slave in the scan list is the same as that of AS01DNET-A.</li> </ol>
E0	Identification parameters returned from the slave do not match the configuration data.	<ol style="list-style-type: none"> <li>1. Check if there is any change in node ID of the slave in the network.</li> <li>2. Check if some node device in the network is replaced.</li> <li>3. Re-configure the network.</li> </ol>
E1	I/O Data size returned does not match that in the scan list.	Re-configure I/O data size of the slave, download the configuration to AS01DNET-A and run the PLC.
E2	<p>The slave device in the scan list does not exist or is offline when AS01DNET-A is in master mode.</p> <p>The I/O connection between the slave AS01DNET-A and the master is broken when AS01DNET-A is in slave mode.</p>	<ol style="list-style-type: none"> <li>1. Check if there is a change in the node address of the slave.</li> <li>2. Check if the communication cable is disconnected or connected loosely.</li> <li>3. Check if the bus cable length exceeds the maximum transmission distance. If so, the system may not be stable.</li> </ol>
E3	AS01DNET-A fails to transmit data.	<ol style="list-style-type: none"> <li>1. Make sure that the connection between AS01DNET-A and the network is normal.</li> </ol>

Code	Explanation	Correction
		2. Check if the baud rate of AS01DNET-A is the same as that of other node in the network.
E4	Error detected in sequence of fragmented I/O data from the slave device.	Check if the slave is operating normally.
E5	The slave device returns error when AS01DNET-A attempts to communicate with it.	Check if the slave is operating normally.
E6	IO data size returned from the slave is bigger than that configured in Scan List.	Check that the IO data size of the slave should be the same as that configured in Scan List.
E7	AS01DNET-A is checking MAC ID.	<p>If the code is displayed long, do the troubleshooting according to the following steps.</p> <ol style="list-style-type: none"> <li>1. Make sure that at least two nodes work normally in the network.</li> <li>2. Check if either end of the network is connected with the terminal resistor of 121Ω.</li> <li>3. Check if the baud rates of the node devices in the network are same.</li> <li>4. Check if the communication cable is normal so as to avoid that the cable is disconnected or connected loosely.</li> <li>5. Check if the bus cable length exceeds the maximum transmission distance. If so, the system may not be stable.</li> <li>6. Check if the shielded wire of the network cable is grounded.</li> <li>7. Re-power AS01DNET-A scanner module.</li> </ol>

#### 7.4.10 Error Codes and LED Indicators for Module AS01DNET (RTU Mode)

Code	Indication	How to deal with
0~63	Node ID of the scanner module (When in RUN state)	No correction needed
F0	The node ID is repeated or exceeds allowed range.	<ol style="list-style-type: none"> <li>1. Ensure that the node ID of AS01DNET (RTU) is unique in the DeviceNet network within the range of 0~63.</li> <li>2. Repower it on after changing the node ID.</li> </ol>
F1	No I/O module is configured to AS01DNET (RTU) in the DeviceNet Builder software.	Add I/O modules in AS01DNET (RTU) in the DeviceNet Builder software and download the configuration data to AS01DNET (RTU) after the configuration is finished.
F2	The work voltage of AS01DNET (RTU) is too low.	Check if the power supply for AS01DNET (RTU) works normally.
F3	AS01DNET (RTU) enters the test mode.	Repower AS01DNET (RTU).
F4	AS01DNET (RTU) is the Bus-Off state.	<ol style="list-style-type: none"> <li>1. Check if the network communication cable is normal and the shielded cable is grounded.</li> <li>2. Ensure the baud rates of all network nodes are same.</li> <li>3. Check if the two ends of the network are both connected with a 120Ω terminal resistor.</li> <li>4. Repower the scanner module.</li> </ol>

Code	Indication	How to deal with
F5	No network power supply for AS01DNET(RTU)	<ol style="list-style-type: none"> <li>1. Check if the network cable is normal.</li> <li>2. Check if the network power supply is normal. (The external 24V DC network power supply is connected between red V+ and black V- of AS01DNET (RTU) .)</li> </ol>
F6	Internal error; An error in the internal storage units of AS01DNET (RTU)	Return the product for repair if the error still exists after re-power on.
F7	Internal error; An error in the data exchange units of AS01DNET (RTU)	Return the product for repair if the error still exists after re-power on.
F8	Manufacture error	Return the product for repair if the error still exists after re-power on.
F9	Internal error; An error in the access of the Flash of AS01DNET (RTU)	Return the product for repair if the error still exists after re-power on.
E4	Module error	<p>Check if an error occurs in the modules connected to the right side of AS01DNET (RTU);</p> <p>Check if the module exists;</p> <p>Check if current module matches that configured in the software;</p> <p>Check if the unconfigured module is added.</p>
E7	Repeated node ID detection	<p>If the code has emerged for a long time, please shoot troubles in the methods below.</p> <ol style="list-style-type: none"> <li>1. Ensure that there are at least two nodes working normally in the network.</li> <li>2. Check if the two ends of the network are both connected with a 121Ω terminal resistor.</li> <li>3. Ensure that the baud rates of all network nodes are same.</li> <li>4. Check if the network cable has a problem such as being disconnected and loosened.</li> <li>5. Check if the bus communication cable length exceeds maximum transmission distance. If the maximum transmission distance is exceeded, the stability of the system can not be ensured.</li> <li>6. Check if the shielded wire of the network communication cable is grounded.</li> <li>7. Turn on the power of AS01DNET (RTU) again.</li> </ol>
E9	The number of I/O modules connected to AS01DNET (RTU) exceeds the maximum 8.	Check if the number of I/O modules connected to AS01DNET (RTU) is more than 8.
80	AS01DNET (RTU) is in STOP state.	<ol style="list-style-type: none"> <li>1. Check if the RUN/STOP switch of the PLC connected to the DeviceNet master is turned to RUN.</li> <li>2. Check if the value of control word of AS01DNET (RTU) is 1. For details, refer to section 11.5.4.3.4.</li> </ol>
83	The AS01DNET (RTU) configuration in the software is being downloading.	Wait until the download of AS01DNET (RTU) configuration data is completed.

**MEMO**