



DIA Screen

Software User Manual

Copyright Notice

©Delta Electronics, Inc. All rights reserved.

All information contained in this user manual is the exclusive property of Delta Electronics Inc. (hereinafter referred to as "Delta") and is protected by copyright law and all other laws. Delta retains the exclusive rights of this user manual in accordance with the copyright law and all other laws. No parts in this manual may be reproduced, transmitted, transcribed, translated or used in any other ways without the prior consent of Delta.

Limitation of Liability

The contents of this user manual are only for the use of the DIASstudio manufactured by Delta. Except as defined in special mandatory laws, Delta provides this user manual "as is" and does not offer any kind of warranty through this user manual for using the product, either express or implied, including but not limited to the following:

- (i) this product will meet your needs or expectations;
- (ii) the information contained in the product is current and correct;
- (iii) the product does not infringe any rights of any other person. Use the product at your own risk.

In no event shall Delta, its subsidiaries, affiliates, managers, employees, agents, partners and licensors be liable for any direct, indirect, incidental, special, derivative or consequential damages (including but not limited to the damages for loss of profits, goodwill, use or other intangible losses) unless the laws contain special mandatory provisions to the contrary.

Delta reserves the right to make changes to the user manual and the products described in the user manual without prior notice and afterwards.

Related Documents

Document Name	Document ID
DIAInstaller User Manual	DIAS-Manual-0005-EN
DIADesigner Manual	DIAS-Manual-0003-EN

Revision History

Version	Issue Date	Revision
1.0	2020/12/08	The first version was published.
1.1.0	2021/09/30	Added Chapter 2 ~ Chapter 30: Added description of DOP series/AX series/IMP series/DXMC series.
1.1.1	2021/12/30	<ol style="list-style-type: none">1. Updated Section 2.2.2.1: Update the description of Clipboard.2. Updated Section 2.2.2.7: Update Select All instructions.3. Updated Section 24.3: Update the description of macro instructions.4. Updated Section 28.6: Add descriptions of new functions of the Text Bank.5. Added Section 29.2.3: Added OPC UA variable setting function.
1.1.2	2022/09/30	<ol style="list-style-type: none">1. Updated the overall manual structure in response to software UI adjustments.2. Update Section 2.1.1: Added description of DIAScreen startup screen.3. Added Section 2.1.1.1: Added Update Manager.
1.3.0	2022/12/22	Standalone TP series user manual.
1.3.1 1.3.2	2023/07/28	<ol style="list-style-type: none">1. Added Custom Confirmation window section.2. Updated Enhanced Recipe section.3. Added Font Template section.4. Added Installment section.5. Added DIADesigner-AX Tag Automatic Synchronization section.6. Added User Login Screen section.
1.4.0	2023/12/19	<ol style="list-style-type: none">1. Updated Address Setting section.2. Updated Alarm Setting section.3. Added Copy Multi-Language Font section.4. Updated Create Screen Data File section.5. Updated MODBUS TCP / COM Mapping Table section.6. Updated MQTT Settings section and added Retain Message and Will Message Function sections.7. Added Retain Permissions and Password Table Settings after Screen Download section.
1.5.0	2024/10/17	<ol style="list-style-type: none">1. Updated Report List section.

Version	Issue Date	Revision
		<ul style="list-style-type: none">2. Updated Data Display section.3. Updated IIoT section.4. Updated OPC UA section.5. Added EIP Exchange Table section.6. Updated MQTT Settings section.7. Updated Install and Uninstallation section.
1.5.2	2025/02/11	<ul style="list-style-type: none">1. Updated Communication section and renamed it to Device Communication.2. Updated History Buffer section.3. Updated Sampling section.4. Updated Setting Up History Buffer Example section.5. Added File Brower and Picture Viewer sections.6. Updated OPC UA section.7. Update MQTT Settings section.
1.6.0	2025/06/06	<ul style="list-style-type: none">1. Revised and restricted sections due to software UI updates.2. Updated Supported Devices section.3. Updated MQTT Settings section and supported Azure IoT Hub and Aliyun server functions.4. Added Circular Trend Properties section.5. Updated Alarm Moving Sign Properties section.6. Updated Report List function.7. Updated Configuration section.8. Added Sample Project section.9. Updated the instructions for address setting.10. Updated DOP-300 Series HMI Special Features section.

Table of Contents

DIAScreen Overview	1
DIAScreen Features.....	2
Supported Devices	2
Installation	4
System Requirements	5
Install DIAScreen	6
Uninstall DIAScreen.....	7
Update DIAScreen.....	8
Update Manager	9
Getting Started with DIAScreen	11
Sample Project	12
Create Screen Data File	17
Create Screen Data File / Create Auto Update Data File.....	17
Create Download Screen Executable	20
Create Screen Auto Execution File	22
Duplicate	24
Configuration.....	27
Main	27
Non-volatile	29
Security Level and Password	31
Global Keypad Settings.....	35
System Setting	39
Screensaver Setup.....	45
Others	47
Control Status Block	48
Control Block.....	49
Status Block	61
Real Time Clock.....	73

Print	78
Default	80
Element Default Value	82
Boot Logo	86
Boot Delay Screen	87
Network Settings	88
Remote Desktop and Data Collection	90
SMTP	94
FTP	98
MAC Settings	115
Multi-language	116
Industry Application	119
Device Communication	125
COM Port	125
Ethernet Port	128
Device	128
Localhost	130
Device	131
Common Properties	132
Custom Confirmation Window Screen	135
User Login Screen	136
Login/Logout Screen	136
Add/Delete User Account Screen	139
Change Password Screen	141
Compile	144
Compile	144
Compile All	144
Download All Data	145
Download Screen	146

Upload All Data	146
On-line Simulation	149
Off-line Simulation	152
Language Management	154
Multi-language Configuration	154
Export Multi-language Text	155
Export Multi-language Text (excluding element font settings)	155
Import Multi-language Text	156
Copy Multi-Language Font	157
Font Template	159
MODBUS TCP/COM Mapping Table	161
EIP Data Exchange Table	165
Installment	171
Keep Installment Data when Downloading	174
Enable Next Installment	174
The Remaining Time for the Current Installment	174
Installment Lock Status	175
System Time Setting Restriction	177
Project Protection	177
Element	179
Button	180
Template Output	181
Report List	185
Bar	186
Common Properties	187
Normal Bar Properties	189
Differential Bar Properties	191
Pie	192
Common Properties	192

Data Display	197
Timestamp	197
List	200
File Browser	201
Picture Viewer	205
Frame and Multimedia	209
VNC Viewer	210
Drawing	213
Rectangle Element	214
Alarm Setting	232
Alarm Settings Toolbar	237
Alarm Message Settings	239
Alarm Property Settings	241
Alarm Element	246
Common Properties	246
Alarm History Table Properties	252
Active Alarm List / Alarm Frequency Table Properties	255
Alarm Moving Sign Properties	256
Gantt Chart Properties	263
History Buffer	265
History Buffer Settings	265
Sampling Function	273
Common Properties	273
Historical Trend Graph Properties	275
Historical Data Table Properties	282
Historical Event Table Properties	286
Historical Overview Table Properties	287
Circular Trend Properties	288
History Buffer Setting Example	294

Enhanced Recipe	299
Enhanced Recipe Number Register (ENRCPNO)	299
Enhanced Recipe Register (ENRCP)	300
Enhanced Recipe Group Register (ENRCPG / ENRCPGNAME).....	301
Enhanced Recipe Quantity Limitation.....	302
Enhanced Recipe Example	302
Enhanced Recipe Attributes	310
OPC UA	315
OPC UA Client Settings	315
OPC UA Server Settings.....	320
OPC UA Security Policy and User Authentication.....	321
MQTT Settings	324
MQTT Broker	324
Will Message.....	325
Address Setting.....	328
MQTT Publisher & Subscriber	331
General Properties	332
Content Settings.....	336
Support Azure IoT Hub and Aliyun Server	343
IIoT	346
Address Conversion	350
All Tags	354
DIA Tag	354
Tag.....	355
User-defined Data Type.....	358
Structure	358
Array	359
Address Settings.....	361
Internal Memory.....	361

Internal Register (\$)	362
Non-volatile Internal Register (\$M)	363
Indirect Address Register (*\$ / *D\$)	363
Extended Memory	364
DXMC Series Internal Memory Address	366
Internal Parameter	369
System Setting	369
Account	372
Alarm	374
BACNETIP Server	376
Communication	376
Date&Time	377
Ethernet Setting	377
Ethernet Application	379
Extended Memory	381
Input Device	382
Installment	383
IoT	384
Keypad	386
Lua Program	386
MQTT	386
MQTT Broker	387
Storage	387
Touch	387
Handheld HMI	388
WiFi	389
External Controller Address	392
Variable Sharing	397
DIADesigner-AX Tag Automatic Synchronization	397

DIADesigner Tag Automatic Synchronization	401
DOP-300 Series HMI Special Features.....	403

DIAScreen Overview

The DIAScreen application is an intuitive visualization software, which can configure the Delta DOP series, TP series, and AX series controller soft-HMIs.

DIAScreen Features

DIAScreen has the following features:

- Tag sharing with the variables of DIADesigner and DIADesigner-AX
- Convenient User Interface, and rich 3D image library
- Smoother display for Meter and other elements
- Enhanced software download speed
- Clear output results
- Various control elements and functions, such as Recipe and Macros
- Support multi-language, such as English, Traditional Chinese and Simplified Chinese
- Provide passwords and permission levels to enhanced security.

Supported Devices

DIAScreen version 1.6.0 supports the following devices.

Type	Product Series
Controller soft-HMI	AX series
Touch type high color HMI	DOP-100 series
IoT type high color HMI	DOP-300 series
Handheld high color HMI	DOP-H Series (Handheld)
Motion Controller	DXMC series
Motion Control development platform	IMP series
Text Panel (TP) HMI	TP series

Note:

- Support AX / IMP series soft-HMI planning functions. Refer to AX series products manual and IMP manual for detail.

- Support DOP-100, DOP-300 and DOP-H series soft-HMI planning functions. Refer to HMI product manual for detail.
- Support DXMC series HMI planning functions. Refer to DXMC-P product manual.
- Supports TP series HMI planning functions. Refer to TP series operation manual.
- To avoid network attacks, the HMI must be connected and run within a firewall to slave devices or upper systems.
- If the environmental equipment uses flow control, it will affect the human-machine operating performance.

Installation

This section introduces how to download, install and uninstall DIAScreen in DIAInstaller.

System Requirements

To install and run DIAScreen, your computer should meet the following minimum hardware and software requirements.

Item	System Requirements
Operating System	Windows 10/11 (32-bit and 64-bit)
CPU	Intel Core i5 M520 2.4 GHz (min.)
Memory	Recommend to use 4 GB or above
Hard Disk Drive	15 GB free for DIAScreen
Monitor	Resolution: 1024 x 768 Pixels, 1920 x 1080 Pixels
Keyboard/Mouse	General keyboard mouse or Windows-compatible device
Printer	Printer that can be driven by Windows system (if you need to print project content)
PC Interface	Ethernet, USB, Serial port (depends on product interface)
Software	Need to install Microsoft .Net Framework 4.6.2 Need to install WinPcap V4.1.3* Need to install NDIS V5.0

***Note:** The upload and download function of the DOP-300 series HMI can transmit data through ZeroIP (zero address network) without network configuration and IP addresses. You must install and use the WinPcap package to realize this ZeroIP technology.

WinPcap download link: winpcap.org/install/bin/WinPcap_4_1_3.exe



Install DIAScreen


DIAScreen is used to easily download, install, uninstall, and update all DIAScreen software. You can download DIAScreen from diastudio.deltaww.com. For more information about DIAScreen, see *DIAScreen Download and Installation Manual*.

Prerequisites

- DIAScreen is installed.

To install DIAScreen

1. Open DIAScreen.
2. Click  at the upper-right corner to sign in.
3. Go to **All Apps** and find DIAScreen.
4. In **Available Versions**, select a version.
5. Click  and then select **Install**.
6. Select components to install. You can select the full components or customize the components to install.
7. In the **DIAScreen** dialog, follow the on-screen instructions to complete the installation.
8. Open DIAScreen and update the firmware version. For the firmware update method, see [Update Manager](#).




Uninstall DIAScreen

Use the following steps to uninstall DIAScreen in DIAInstaller.

Prerequisites


- Back up the picture bank or component library created by users.
 - Picture bank file path: C:\ProgramData\Delta Industrial Automation\HMI\Common\Pic
 - Element bank file path: C:\ProgramData\Delta Industrial Automation\HMI\DIAScreen 1.4\ScrEditApp\Library

Note: In the folder, click **View** and select the **Hidden Items** checkbox to view the ProgramData folder.



To uninstall DIAScreen

1. In DIAInstaller, go to **Installed**, and select **Uninstall**.
2. Follow the on-screen instructions to uninstall.
3. A message dialog appears, asking whether to delete the user configuration. Click **No** to keep the user configuration.





4. After uninstalling and reinstalling DIAScreen, overwrite the picture bank or element bank file to be restored to the above file path.

Update DIAScreen

Use the following steps to update DIAScreen.

To update DIAScreen


1. In DIAInstaller, go to **Updates**.
2. Find DIAScreen.
3. In **Available Versions**, select a version.
4. Do one of the following:
 - Select **Update** and then follow the on-screen instructions to complete the update.
 - Click  and select **Download** to download the installation file to the local path, and then select **Show in folder** to find the .exe file to install.








Update Manager

DIAScreen only has built-in firmware files for DOP-100 Series models, and you can **download, install, and update the firmware for each series through Update Manager to edit the HMI screen of other models.**


The following table lists the functions in the **Update Manager** dialog and their descriptions.




Function	Description
	Click to download the firmware or picture bank installation package.
	Click to Install the downloaded firmware or picture bank installation package.
	Click to uninstall the installed firmware or picture bank.
	Click to open the downloads folder.
	Click to check for updates.

Use the following steps to download and install the HMI firmware.

To download and install the HMI firmware

1. On the home page of DIAScreen, click **Update Manager**.
2. In the **Update Manager** dialog, select the desired HMI firmware installation package, and then click .

Once the download is complete, a message dialog appears, asking whether to install the installation package. Do one of the following:

- Click **Yes** to install automatically.
- Click **No** to install manually, and then click .


After the installation is complete, you can view the installed firmware version in **Installed version**.

Getting Started with DIAScreen

Sample Project

To help users quickly set up projects, DIAScreen provides the following four sample projects:



- Full-featured Application
- Industry Applications
- CODESYS Communication Application
- Small kit Application




The following table lists the functions demonstrated by each project and how they operate.

- **Full-featured Application**

Project	Description
Alarm Function	Configure discrete alarms , trigger alarms through value changes or button clicks on the screen, and display alarm information on the alarm element.
Full_Element_Demo	Configure various elements on the screen, and apply different styles. After loading the project into the HMI, switch between different pages to view the operating effects of each element.

Project	Description
Temperature_Control_Demo	<p>DOP series HMI connects AS controller to perform temperature control operations. Follow these steps to connect to the simulator.</p> <ol style="list-style-type: none"> 1. Open sample project in DIAScreen. 2. Open the controller project in DIADesigner. <p>Project Path: C:\ProgramData\Delta Industrial Automation\HMI\DIAScreen (version) \ScrEditApp\Example\1\ Example3_Temperature_Control_Demo\Temperature_Control_Demo.diade</p> <ol style="list-style-type: none"> 3. Create an AS300 simulator in COMMGR and start it.  <ol style="list-style-type: none"> 4. In DIADesigner, select AS PLC Simulator in Communication Setting, and click Connect.  <ol style="list-style-type: none"> 5. Perform Project Download and then perform Online. 6. Open the sample project in DIAScreen and go to General > Device Communication. In Ethernet1 page of the Device Communication dialog, select AS PLC in For COMMGR.


Project	Description
	 <p>7. Perform Off-line Simulation in DIAScreen.</p> <p>8. Perform temperature control operations through HMI simulator.</p>
History Function	<p>Presents historical data of various data types through the Historical Trend Graph element, and different styles of historical trend graphs are also configured to facilitate quick understanding of the functions provided by the history buffer.</p>

• Industry Applications

Project	Description
Labeling machine	<p>Demonstrates the operating interface used for HMI monitoring equipment status in different industries. You can refer to the page configuration, copy the screen and apply it to their own designed projects.</p>
Extrusion rubber plate machine	
Electrical industry	

• CODESYS Communication Application

Project	Description
CODESYS_Data_Exchange	<p>Demonstrates data exchange between AX-8's Soft-HMI and CODESYS controller. Follow these steps to configure the project.</p> <ol style="list-style-type: none"> 1. Use Update Manager to download and install AX-8 series package in DIAScreen.

Project	Description
	 <p>2. Open sample project in DIAScreen and then download the project directly to the AX-8 device.</p> <p>3. Open the controller project in DIADesigner-AX, and then download the controller project to the AX-8 device.</p> <p>Project Path: C:\ProgramData\Delta Industrial Automation\HMI\DIAScreen (version)\ScrEditApp\Example\3\Example1_CODESYS_Data_Exchange_Demo\CODESYS_Data_Exchange_Demo.project</p> <p>4. Open HMIManager on the AX-8 device to monitor the CODESYS controller through the HMI.</p>


• Small kit Application

This category of projects provides a variety of template styles. You can directly copy the template screens into the development project to achieve rapid project configuration.

Follow these steps to copy a template.

To copy a template

1. Open the sample project. Select the screen in **Screen Management Window** pane. Right-click the selected screen, and select **Copy** (or use the shortcut key Ctrl + C).



2. Open another DIAScreen project and paste the screen directly in **Screen Management Window** pane (or use the shortcut key Ctrl + V) to configure the template screen in the development project.



Project	Description
StartUp	This project provides a variety of Startup interface template styles.
Template	This project provides a variety of Operating Interface template styles.

Create Screen Data File

Create Screen Data File / Create Auto Update Data File

After storing the files compiled by the project in an external storage device (USB or SD card) and insert it into the HMI, you can update the HMI screen through **Screen Data file** and **Auto Update Data File**.

The following table lists the settings in the **Setting** dialog and their descriptions.


Setting	Description
Enable Protection	Enable password protection. When updating the screen on the HMI, you need to enter this copy password.
Output Folder	Select the folder path to save the download screen executable file.
MAC Settings	<p>Enter the MAC of the HMI to update screen data. In the Configuration dialog, click  and enter the MAC code of the HMI to be bound, the file can only perform screen updates on the specified HMI; if the MAC code is not set, the HMI model is not restricted.</p> <p>Note: You can obtain the MAC code from System Menu > System Setting > Network on the HMI.</p> 

Follow the steps to create the screen data file and auto update data file.

DIAScreen Operation

1. In the main menu, click **Create Screen Data File > Create Screen Data File / Create Auto Update Data File**.
2. In the **Setting** dialog, make the related settings, and then click **OK**.

The Screen Data File / Auto Update File are generated.



Note:

- If there are multiple data files in the HMI-000 folder, the software will number them sequentially from 000, for example, 000, 001, 002 and so on.
- After executing Create Auto Update Data File, the HMI only recognizes the folder name HMI_AutoUP. If you repeatedly execute this function, the contents of this folder will be overwritten.

If the project model is the DXMC series, after creating the project and setting the storage path and compiling, the software will automatically create a folder with the same name as the project under the project path and store the current screen data update file in the folder. You can directly import this update file into **DXMC Model Software-DMARS (DELTA Motion And Robot Software)** to update HMI screen.

Name	Date modified	Type	Size
DXMC_Test	11/17 8:05	File folder	
DXMC_Test.dpa	2023/11/17 8:05	DIAScreen project	71 KB

HMI Operation

- **Create Screen Data File**

After inserting the storage device into the HMI, go to **System Setting > File Manager > File Copy** on the HMI, and copy the screen data file in the storage device to the HMI.

- **Create Auto Update Data File**

1. Inserting the external storage device into the HMI.


When the HMI detects an external storage device with an auto update file (HMI_AutoUP), a message displays and ask you whether to execute the auto update.

2. Click **Yes**, the firmware and screen will be updated automatically.

Note: If the folder HMI_AutoUP is stored in both USB and SD card, when updating the firmware and screen files, the HMI will first update the USB.

Open Screen Data File



The generated **Screen Data File / Auto Update File** can also be edited in the software by **Open Screen Data File** function.



Create Download Screen Executable

You can update the HMI screen or firmware to the HMI through **Screen Download Executable File** without installing the DIAScreen software.

The following table lists the settings in the **Create Download Screen Exe. File** dialog and their descriptions.


Settings	Description
Executable file name	Set the name of the generated executable file.
Output folder	Select the folder path to save the download screen executable.
MAC settings	<p>Enter the MAC of the HMI to update screen data. In the Configuration dialog, click  and enter the MAC code of the HMI to be bound, the file can only perform screen download on the specified HMI; if the MAC code is not set, the HMI model is not restricted.</p> <p>Note: You can obtain the MAC code from System Menu > System Setting > Network on the HMI.</p> 

Follow the steps to create download screen executable.

To create download screen executable


1. In the main menu, click **Create Screen Data File > Create Download Screen Executable**.
2. In the **Create Download Screen Exe. File** dialog, make the related settings.

3. In the output folder, execute the executable file (the default file name is DownloadScreen.exe).
4. In the pup-up dialog, do one of the following:



- Selecting **All data** will automatically check the HMI firmware version. If the version matches the version that can be executed by the executable, the firmware update will be executed and the screen data will be downloaded to the HMI.
- Selecting **Only upgrade firmware** will update the HMI firmware update directly.

Note: Before executing **Create Download Screen Executable**, set the HMI screen upload / download mode first. Go to **General > Environment** on the toolbar to set.



Create Screen Auto Execution File

You can execute auto operation of the HMI screen on the computer through **Screen Auto Executable** without installing the DIAScreen software.


The following table lists the settings in the **Create screen executable file** dialog and their descriptions.

Settings	Description
Executable file name	Set the name of the generated executable file.
Output folder	Select the folder path to save the download screen executable.

Follow the steps to create screen auto executable.


To create screen auto executable

1. In the main menu, click **Create Screen Data File > Create Screen Auto Execution File**.
2. In the **Create screen executable file** dialog, make the related settings.
3. In the output folder, execute the executable file (the default file name is HMIEmulator.exe).
4. In the **COM Port Setting** dialog, set the communication port of the executable file.



Note: If communicating via network, you can ignore this dialog. Click **Cancel** to communicate with the IP set in the project.

The execution screen is as follows.



Duplicate


The duplicate feature allows you to perform duplication of an element, and then automatically increments or decrements the address according to your needs.

To duplicate

Do one of the following methods to perform duplication of an element:

- Right-click on the element and select **Duplicate**.
- Select the element and click **General > Duplicate** in the menu bar.

The following table lists the settings in the **Duplicate** dialog and their descriptions.





1 Copies

Setting	Description
Columns	Select or enter the number of horizontal (X) and vertical (Y) to get the total number of X*Y elements. You can also select / unselect the checkbox to single-select columns or rows according to your needs.
Rows	

2 Spacing (Pixels)



Setting	Description
Horizontal	Select or enter the spacing between each element. Once the duplication is complete, spacing generates automatically according to the settings.
Vertical	

3 Name Address Direction

Setting	Description	
Horizontal Direction	Set the duplicate direction of addresses. The duplicated element address increments (positive) or decrements (negative) according to the offset and gets duplicated horizontally or vertically.	
Vertical Direction	Horizontal	Vertical
		

4 Offset And Array index

Setting	Description
Offset	<p>Select or enter the amount that addresses increment or decrement automatically.</p> <ul style="list-style-type: none"> If elements are set as Word units, the increments or decrements are calculated in Word units. If elements are set as Bit units, the increments or decrements are calculated in bit units.

Setting	Description
Array Index	<p>Select the array index location. The default value is default.</p> <ul style="list-style-type: none"> Select Default, and the address is offset in the element unit.  <ul style="list-style-type: none"> Select 1–4 for the Tag address. The array indexes are arranged from right to left.  <p>Note: You can specify the offset of the array index. Currently available for CODESYS Tag only.</p>


5 Enable Automatic Text Numbering

Setting	Description
Starting number	Select or enter the starting value of the number displayed on the element.
Text format	Enter the text format of the number displayed on the element.

Configuration

Go to **General > Configuration** to configure the operation settings for the HMI screen.
The functions of each parameter are described as follows.

Main



Configuration

- Main
 - Non-volatile
 - Security Level and Password
 - Global Keypad Settings
 - System Setting
 - Screensaver Setup
 - Others
- Control Status Block
 - Control Block
 - Status Block
- Real Time Clock
- Print
- Default
 - Element Default Value
 - Boot Logo
 - Boot Delay Screen
 - Custom Scroll Button
- Network Settings
 - Remote Desktop and Data Collectio
 - SMTP
 - FTP
 - MAC Settings
- Multi-language
 - Multi-language Settings
- Industry Application
 - Electronic Record

Main

Project and Basic Settings 1

Name
NewHMI

HMI Type
DOP-107WV 65536 Colors

Clock Macro Delay Time 100 (ms)

Clock Macro Priority Low

Background macro update cycle 1 Lines

LUA Delay Time 10 (ms)


LUA priority Low

Print priority Low


Project Description 2

OK Cancel


1 Project and Basic Settings

Function	Description
Name	<p>Set the name of project. The project name on the Project tree will be changed synchronously.</p> 
HMI Type	Display the currently edited HMI model.
Clock Macro Delay Time	Set the interval time after each execution of Clock and Macro. The range value is 50–65535, and the default value is 100 .
Clock Macro Priority	Set the priority of the Clock macro execution. The higher the priority, the more accurate the Clock Macro Delay Time .
Background macro update cycle	Set the number of lines executed per cycle of the background macro. The range value is 1–512, and the default value is 1 .
LUA Delay Time	Set the interval time after each execution of LUA. The range value is 0–10, and the default value is 10 .
LUA priority	Set the priority of LUA execution. The higher the priority, the more accurate the LUA Delay Time .
Print priority	Set the priority of print execution.

2 Project Description

Function	Description
Project Description	<p>Set the purpose of the HMI screen. After running DIAScreen, you can see the description of the project in Recent opened file.</p> 


Non-volatile



Function	Description
Non-volatile data storage	Non-volatile data can be stored in Alarm, Recipe, and History Buffer .



Function	Description																														
	<p>Storage location depends on the devices supported by the model. The available options include HMI, USB Disk, USB Disk 2, and SD Card.</p> <p>The part of historical data will be determined if you have established a History Buffer.</p> <table><tr><th colspan="5">Non-volatile data storage</th></tr><tr><th>Name</th><th>Non-volatile</th><th>Storage Location</th><th>File Name</th><th></th></tr><tr><td>Alarm</td><td>No</td><td>HMI</td><td></td><td></td></tr><tr><td>Recipe</td><td>Yes</td><td>HMI</td><td></td><td></td></tr><tr><td>History Buffer ID-1</td><td>No</td><td>HMI</td><td>H0001</td><td></td></tr><tr><td>History Buffer ID-2</td><td>No</td><td>HMI</td><td>H0002</td><td></td></tr></table>	Non-volatile data storage					Name	Non-volatile	Storage Location	File Name		Alarm	No	HMI			Recipe	Yes	HMI			History Buffer ID-1	No	HMI	H0001		History Buffer ID-2	No	HMI	H0002	
Non-volatile data storage																															
Name	Non-volatile	Storage Location	File Name																												
Alarm	No	HMI																													
Recipe	Yes	HMI																													
History Buffer ID-1	No	HMI	H0001																												
History Buffer ID-2	No	HMI	H0002																												
Write the cache size of the external	<p>Select the external storage devices (USB Disk and SD Card).</p> <p>The data written by the HMI to the external storage device will be temporarily placed in the cache area. However, this setting value depends on the amount of data in the cache area. If the amount of data does not reach this setting value, the data will not be written to the external storage device. This method can prevent the external storage device from being damaged due to continuous writing.</p> <p>Assuming that the amount of data to be accessed is less than the capacity of the buffer or there is unexpected power failure, it may result in partial data loss. In order to avoid this situation, you can forcibly trigger the bit5 of the general control flag of the control area at regular intervals to write data to external storage device to ensure the existence of data.</p>																														

Security Level and Password



1 Security Management

Function	Description
Highest security password	<p>Set the password with the highest security level of HMI, which means level 10. The default value is 12345678.</p> <ul style="list-style-type: none"> This password is used to control upload screen data and recipes, download screen data and recipes (you need to select the Check password when downloading program checkbox), password protection, system formatting, system file encryption and copy file functions (you need to select Limit the times of updating screens via USB drive checkbox). The password text format is Hexadecimal unit from 0 to F. If you select the Complex password checkbox, the complex password must set more than (inclusive) 8 characters and contain an uppercase letter, a lowercase letter, a number, and a symbol (!, \$, #, %).
Default startup security level	<p>Set the default security level when the HMI is turned on. You can set the level from 0 to 10.</p> <p>Note: Level 10 is the highest security level.</p>

Function	Description
Check password when downloading program	<p>If selected, when executing Download All Data and Download Recipe, the software asks you to enter the highest security password.</p> <p>The screen can be downloaded to the HMI normally only after the password is entered successfully. If the password is failed, a warning message appears to notify you that the password is incorrect and cannot be downloaded.</p> <p>Note: You need to download the project to the HMI first and execute Download All Data again after selecting this option.</p>
Screen upload prohibited	<p>If selected, when executing Upload All Data, a warning message appears to notify you that the data cannot be uploaded. You need to download the project to the HMI first and execute Upload All Data again after selecting this option.</p> 
Prompt a reminder for insufficient security level	<p>If selected, if the user security level set in the element is higher than the default boot security level, the element on the HMI displays  that indicates that your current security level is not sufficient.</p>
Don't show password input window when the security level is insufficient	<p>If selected, if your current security level is not sufficient, the password input window does not display.</p>
Restrict high account function	<p>If selected, no operations can be performed on low-level accounts.</p>
Complex password	<p>If selected, all passwords must be set more than (inclusive) 8 characters and contain an uppercase letter, a lowercase letter, a number, and a symbol (!, \$, #, %).</p>
Limit the times of updating screens via USB drive	<p>If selected, you can encrypt the screen data files and limit the number of times of copying files.</p> <p>This function is mainly used with the function of file encryption and copying of files.</p>

2 Login / logout



Function	Description
Logout when time out	If selected, the system will return to the default boot security level according to the set Minutes before reset to default boot permission when the HMI is in idle status.
Account disabled after login failed	If selected, the account will be disabled according to the set Number of consecutive failed retries when login fails consecutively.
The first login of the component does not execute immediately	If selected, if the current executed security level is not sufficient, click the element to log in and then click it again to execute the element action.
Change password on first login	If selected, the HMI forces you to change the password after logging in for the first time.


3 Password Keypad

Function	Description
Password Keypad	Select the keypad according to your needs. The default is Default Keypad . Note: If you select Simple Keypad , the Complex password setting is not available.

4 Account and Password

Function	Description
Account and Password	Set the security level and the account and password of HMI. The security level is divided into 0–9, each level can add multiple accounts for users to log in at the same time. The following describes the setting rules for the account and password: <ul style="list-style-type: none"> • Password must not be blank. • Within the same security level, the account names cannot be the same, but the passwords can be the same. The account names of different security levels can be the same. • The length of the account and password is limited to 24 characters and is not case-sensitive. • User description can only be entered in English or numbers.

Function	Description
	<ul style="list-style-type: none"> Security levels are divided as follows: <ul style="list-style-type: none"> Level 0: No protection function, anyone can operate. Level 1–9: You need to enter the corresponding password or a higher security level to operate. Level 10: The highest security password and the protection password after project storage. This password is also the password to be entered when executing Check password when downloading program and formatting the system file. <p>Note: The account and password support 1,000 records, regardless of level.</p> <p>You can use the button element Password Table or select System Menu > System Settings > Password on the HMI to open the account and password table to change the password and account.</p> 
Enable RFID login	<p>Click to enable RFID login, you can login your account or add new account and password through external device on the HMI.</p> <p>Note: The RFID field in software is read-only. You need to add an RFID code through the HMI and upload all the data before the RFID code can be displayed.</p>
	<p>Click to export the account and password table as a CSV file, which can be imported into software after editing.</p> <p>The exported CSV file is named accounts.csv and saved in the storage device. The account and password table can be imported into the HMI through the Import/Export Account element.</p>
User Login Screen	<p>Set the login screen for each user level. When the User Security Level setting of the element is not 0 and no custom login user screen is specified, the login screen specified here will be displayed.</p>


Function	Description
	

Global Keypad Settings


You can set the keypad styles through **Global Keypad Settings** or element property dialog. The keypad types include Decimal, Hexadecimal, Binary and ASCII. **Global Keypad Settings** also provides multiple application methods to update the keypad styles of elements.

Follow the steps to set the global keypad style through element property dialog.



To set the global keypad style through element property dialog

1. Create **Numeric Entry** or **Character Entry** elements on the editing screen, double-click the elements.
2. In the element property dialog, click  in the **Detail** area in the Main tab.
3. In the **System Keypad Layout** dialog, set the keypad style according to your needs. Or you can edit through **General > Configuration > Global Keypad Settings**.

The following table lists the functions of the **Global Keypad Settings** page with their description.





1 Decimal Keypad



Function	Description
System Keypad	<p>This keypad is applied to the Numeric Keypad element when the place value is set to decimal.</p> 
Custom Keypad	<p>Click  to select the custom screen. Go to General > New Screen > Keypad Screen to customize screen.</p>

Function	Description
Apply Settings	Set the keypad style applied method. <ul style="list-style-type: none"> Not apply: Maintain the original style of the system keypad. Apply to all: Replace the old keypad style with the new style. Apply to new: Only applies to newly created keypads.


2 Binary Keypad


Function	Description
System Keypad	<p>This keypad is applied to the Numeric Keypad element when the place value is set to binary.</p> 
Custom Keypad	Click  to select the custom screen. Go to General > New Screen > Keypad Screen to customize screen.
Apply Settings	Set the keypad style applied method. <ul style="list-style-type: none"> Not apply: Maintain the original style of the system keypad. Apply to all: Replace the old keypad style with the new style.

3 Hexadecimal Keypad


Function	Description
System Keypad	<p>This keypad is applied to the Numeric Keypad element when the place value is set to hexadecimal.</p> 
Custom Keypad	<p>Click  to select the custom screen.</p> <p>Go to General > New Screen > Keypad Screen to customize screen.</p>
Apply Settings	<p>Set the keypad style applied method.</p> <ul style="list-style-type: none"> Not apply: Maintain the original style of the system keypad. Apply to all: Replace the old keypad style with the new style.

4 ASCII Keypad


Function	Description
System Keypad	<p>This keypad is applied to the Character Keypad element when the place value is set to ASCII.</p> 


Function	Description
Custom Keypad	Click  to select the custom screen. Go to General > New Screen > Keypad Screen to customize screen.
Apply Settings	Set the keypad style applied method. <ul style="list-style-type: none"> • Not apply: Maintain the original style of the system keypad. • Apply to all: Replace the old keypad style with the new style. • Apply to new: Only applies to newly created keypads.


System Setting





Function	Description
Enable Touch Cursor	If selected, when the HMI screen is pressed, the same mouse icon as the Windows operating system pointer appears. HMI supports wireless mouse with Unifying receiver.

Function	Description
Display initial screen at startup	<p>If selected, the HMI displays the initial screen every time it is powered on.</p> 
Auto detect baud rate	If selected, a message displays on the HMI and asks whether to detect procedure. When the baud rate of the HMI is different from that of the controller, it will be automatically adjusted to the same.
Keep user data	If selected, the files generated through LUA do not delete while downloading the screen. It will only be deleted while formatting or restoring to factory settings.
Pre-read invisible bit state value	If selected, when the invisible address is set to the controller address, switching the screen can avoid the transient state of the element display, but it affects the screen display speed.
Use terminator	If selected, character display/input, historical data display, and historical data CSV storage are applied the end character '\0'.
Watchdog	If selected, the HMI automatically restarts when it crashes.
Disable low battery message	If selected, the HMI does not display the low battery message when it is initializing.


Function	Description
Retain historical data after screen update	<p>If selected, the historical data on the HMI is retained when downloading the screen.</p> <p>In order to retain and continue to use the historical data, the historical data will be compared with the history buffer settings before updating the HMI screen. The following are the comparison principles.</p> <ul style="list-style-type: none"> The process of database saving and the export of CSV files are not affected. Historical elements may still display or behave normally. <p>After changing Read Length, Sample Number, Stamp Time and Date, Non-volatile, Export CSV File (including Field Name), and Save As Single File / Multiple File, the historical data will not be retained even if this setting is selected.</p> 
Keep the account and password table settings after the screen is downloaded	<p>If selected, the settings of the account and password table does not change while downloading the screen.</p>
Keep Installment payment settings after screen download	<p>If selected, the installment data on the HMI is retained while downloading the screen.</p>

Function	Description
Close Title Display	<p>If selected, the HMI screen does not display the title bar.</p>  <p>Note: This setting is only available for AX-8 Windows and IMP Series models.</p>
Minimize window to the system tray after startup	<p>If selected, the HMI screen minimizes to the system tray when it starts.</p> <p>Note: This setting is only available for AX-8 Windows and IMP Series models.</p>
Prompt before closing window	<p>If selected, a message displays when the HMI screen is closed, informing that the HMI application will be closed.</p> <p>Note: This setting is only available for AX-8 Windows and IMP Series models.</p>

Function	Description
USB Upload/Download	<p>Select the USB upload / download mode.</p> <ul style="list-style-type: none"> Auto <ul style="list-style-type: none"> If selected, after downloading the project, the HMI maintains the currently set mode to upload and download. The factory default value of other HMIs is Auto (except for B05S100, B05S101, B07S201, and B07S211 models). Disk <p>If selected, after downloading the project, the HMI uses this mode to upload and download (it is USBCommMode = 1.). You can view “DELTA” removable storage device in The PC.</p>  CDC <p>If selected, after downloading the project, the HMI uses this mode to upload and download (it is USBCommMode = 2). Right-click the blank space in The PC and go to Content > Device Manager. In the Device Manager dialog, check whether there is HMI device under Ports (COM & LPT).</p> 
HMI priority action	<p>Select the HMI priority action.</p> <ul style="list-style-type: none"> None—The HMI does not take any actions first. Touch—The HMI receives the touch action first, and then process the system operation.
Network Default Gateway	<p>Select network default gateway. The options are displayed according to the number of network ports of models. If extra network accessories are attached on the HMI, you can select Wi-Fi or 4G. The default value is Auto.</p>

Function	Description
Brightness	Set the brightness of the HMI backlight.
TP Delay	Set the delay time for the HMI to process pressing the move messages. Drag the delay to the right to decrease, the speed becomes faster; drag the delay to the left to increase the speed, and the speed becomes slower.
TP Force	Set the force for pressing the HMI screen. Drag the force to the left to decrease, the HMI screen becomes easier to press; drag the force to the right to increase, and the HMI screen becomes difficult to press.
Buzzer	Set the buzzer volume of the HMI. Drag to the left to increase the volume, and drag to the right to decrease the volume.
Boot Buzzer Volume	Set the boot buzzer volume of the HMI. Drag to the left to increase the volume, and drag to the right to decrease the volume.
Key sound	Set the sound when the HMI is pressed. Drag to the left to increase the volume, and drag to the right to decrease the volume.
Animation FPS	Set the update speed of the animation element setting frequency.

Screensaver Setup



Configuration

Screensaver Setup

☒ Enable Screensaver Wait 10 (Min)

☒ Enable backlight saving Wait 3 (Min)

Saving ratio 50 (%)

☐ Screensaver trigger address None


Screensaver Screen

Screensaver Status Off

After exiting the screensaver


- ☒ Return to original screen
- ☐ Choose screen

OK Cancel


Function	Description
Enable Screensaver	<p>If selected, you can set how long it takes to enter the screen saver screen without pressing the screen. The value range is 1–100, and the default value is 10.</p> <p>The screen saver can be configured by clicking  of Screensaver Screen or in General > Screen saver Screen.</p> <p>Note: If Enable Screensaver is not selected, but the screen saver is configured, the screen saver will not be activated.</p>
Enable backlight saving	<p>If selected, you can set how long it takes to enable the backlight saving function without pressing the screen.</p> <ul style="list-style-type: none"> The value range is 1–10, and the default value is 3. The saving ratio range is 1–99, and the default value is 50.
Screensaver trigger address	Set Word trigger address, 0 is to turn off the screen saver, and 1 is to turn on the screen saver.

Function	Description
After exiting the screensaver	<ul style="list-style-type: none"> • Return to original screen: If selected, after the screen saver is over, it jumps to the original screen before starting the screen saver. • Choose screen: If selected, you can specify the screen number, so that the designated screen will be displayed after the screen saver ends. <p>Note: If you want to use the specified screen, create a screen saver screen first.</p>

The following figure displays the flow chart of the screen saver screen.



Others



Configuration

- Main
 - Non-volatile
 - Security Level and Password
 - Global Keypad Settings
 - System Setting
 - Screensaver Setup
 - Others**
- Control Status Block
 - Control Block
 - Status Block
- Real Time Clock
- Print
- Default
 - Element Default Value
 - Boot Logo
 - Boot Delay Screen
 - Custom Scroll Button
- Network Settings
 - Remote Desktop and Data Collection
 - SMTP
 - FTP
 - MAC Settings
- Multi-language
 - Multi-language Settings
- Industry Application
 - Electronic Record

Others

Show disk accessing error message

☒ Alarm ☒ History Buffer ☒ Recipe

Insufficient storage hint screen ☐ Enable

	Remaining space	Jump to the specified screen
HMI	5 (5~10MB)	None
USB Disk	5	None
USB Disk 2	5	None
SD	5	None

Video

☐ VideoOverlay


OK Cancel

Function	Description
Show disk accessing error message	<p>Since alarms, history buffers and recipes can be set to save data as USB Disk or SD Card, if the external disk access fails, you can decide whether to display the warning message through this setting.</p> <p>The disk access failure means that when the non-volatile data location of history buffer is set to USB Disk, the HMI cannot detect the USB Disk after powering on, and cannot write data. If this option is not selected, when the above situation occurs, no error message appears.</p>
Insufficient storage hint screen	Set how many MB of storage space is left to jump to the specified screen. The storage spaces can be specified to HMI, USB Disk, USB Disk 2, and SD.
Video	<p>If Video Overlay is selected, the VGA or Camera element superimposes on the element, and the display can be triggered through the invisible address.</p> <p>This setting enables / disables according to different models.</p>

Control Status Block

The **Control Status Block** is used to execute or monitor the system operation and status. Select any of functions according to your needs, for example, in **Control Block**, you only need to select the **Screen No.** and **Recipe Number**, the **control status block** automatically configures the addresses continuously and only enables the **Goto Screen** and **Recipe Group Control** functions.


If an additional function is selected, such as **General Control**, the memory addresses are arranged continuously from top to bottom.



Function	Description
Auto Reset Flags	If selected, the HMI automatically resets the flags. To reactivate some functions in the Control Block , first turn the corresponding flags OFF, and then turn it ON again.
Data Format	Set the Data Format of the control status block. The default value is Unsigned Decimal .

Control Block


The **Control Block** is used to control the actions of the HMI, such as Goto screen, curve, recipe control, and user level.



Function	Description
Use discontinuous address in Control Block	If selected, the settings in the Control Block are available, and you can define the register addresses in the controller or the HMI internal memory.
Sampling Cycle	Set the interval time between the sampling actions. The value range is 100–1000, and the default value is 300 .


The following table lists the flags of screen no. register with its description.

Screen No. Register	
b0~b15 – Screen No.	<ul style="list-style-type: none"> Write the specified screen number into this register, and the HMI switches to the specified screen. If a Numeric Entry element is set to D0 and the input value is 1, the HMI switches to the first screen.



The following table lists the flags of general control register with their description.


General Control Register															
b15	b14	b13	b12	b11	b10	b9	b8	b7	b6	b5	b4	b3	b2	b1	b0
_____				_____				_____	_____	_____	_____	_____	_____	_____	_____
(10)				(9)				(8)	(7)	(6)	(5)	(4)	(3)	(2)	(1)
<p>(1) b0 Communication enable / disable flag</p> <p>(2) b1 Backlight enable / disable flag</p> <p>(3) b2 Buzzer enable / disable flag</p> <p>(4) b3 Alarm buffer clear flag</p> <p>(5) b4 Alarm counter clear flag</p> <p>(6) b5 External storage device cache write flag</p> <p>(7) b6 Remote control lock</p> <p>(8) b7 Reserved</p> <p>(9) b8~b11 Set User Security Level</p> <p>(10) b12~b15 Reserved</p>															

General Control Register	
<p>b0 – Communication enable / disable flag</p>	<p>Enable / disable the HMI communication.</p> <ul style="list-style-type: none"> To use this flag, click General > Communication Settings, and then select Disconnect after communication interrupt checkbox and set the Retry times after disconnection. When the HMI communicates with the controller, the HMI automatically stops the communication with the controller and turns the flag ON after the number of interruption times reaches the set retry times without the communication error message (this does not affect the communication between the HMI and other controllers). You can restore the communication by turning the flag OFF.  <p>Note:</p> <ul style="list-style-type: none"> This flag is only for restoring the communication when it is automatically stopped. It is not possible to directly stop the communication between the HMI and any controller by turning the flag ON. The Auto Reset Flags function is not applicable to this flag.
<p>b1 – Backlight enable / disable flag</p>	<p>Enable / disable the HMI backlight.</p> <ul style="list-style-type: none"> Set to ON, the HMI backlight is enabled. Set to OFF, the HMI backlight is disabled. <p>Note: The Auto Reset Flags function is not applicable to this flag.</p>


General Control Register	
<p>b2 – Buzzer enable / disable flag</p>	<p>Enable / disable the HMI buzzer.</p> <ul style="list-style-type: none"> Set to ON, the HMI buzzer is enabled. Set to OFF, the HMI buzzer is disabled. <p>Note: The Auto Reset Flags function is not applicable to this flag.</p>
<p>b3 – Alarm buffer clear flag</p>	<p>Clear the alarm buffer data of the HMI.</p> <p>Set to ON to clear the data in the alarm buffer. To reactivate this function, turn the flag OFF and then ON again.</p>
<p>b4 – Alarm counter clear flag</p>	<p>Clear the alarm frequency table data of the HMI. Set to ON to clear the data in the alarm frequency table. To reactivate this function, turn the flag OFF and then ON again.</p>
<p>b5 – External storage device cache write flag</p>	<p>Update the HMI cache data into an external storage device (USB Disk or SD Card) in real time.</p> <ul style="list-style-type: none"> If the alarm buffer, history buffer, or recipe function is activated, and the non-volatile storage location is set to USB Disk or SD, when the flag is set to ON, the HMI updates the data temporarily stored in the cache into an external storage device in real time. To reactivate this function, turn the flag OFF and then ON again. The data written into USB or SD Card by the HMI is temporarily stored in the cache first. Before the cache data size reaches the set limit (as shown in the following figure), the data is not written into an external storage device. This is to prevent the external storage device from being damaged by frequent overwriting. However, if the data volume accessed is less than the buffer capacity or the power is cut off unexpectedly, part of the data may be lost. To keep the data, turn ON the flag in a cyclic pattern to write the data into the external storage device.


General Control Register																																								
	<div><div>Configuration</div><div><div><div>Non-volatile</div><div>Non-volatile data storage</div><table><thead><tr><th>Name</th><th>Non-volatile</th><th>Storage Location</th><th>File Name</th></tr></thead><tbody><tr><td>Alarm</td><td>No</td><td>HMI</td><td></td></tr><tr><td>Recipe</td><td>Yes</td><td>HMI</td><td></td></tr></tbody></table></div><div>Write the cache size of the external</div><div><div>None</div><div>None</div><div>Default</div><div>64 KB</div><div>32 KB</div><div>16 KB</div><div>8 KB</div><div>2 KB</div><div>1 KB</div><div>512 B</div></div><div><div>OK</div><div>Cancel</div></div></div></div>	Name	Non-volatile	Storage Location	File Name	Alarm	No	HMI		Recipe	Yes	HMI																												
Name	Non-volatile	Storage Location	File Name																																					
Alarm	No	HMI																																						
Recipe	Yes	HMI																																						
b6 – Remote control lock	<div>Control whether the eRemote can be operated.</div> <div><div>Set to ON, eRemote can only be monitored and cannot be operated.</div><div>Set to OFF, eRemote can be operated normally.</div></div> <div><div>Note: The Auto Reset Flags function is not applicable to this flag.</div></div>																																							
b8~b11 – Set User Level	<div>You can set the current user level of the HMI. The HMI internal security levels are divided as follows:</div> <div><div>Security level 0–7: Controlled by Bit 8, Bit 9, and Bit 10 flags. Level 0 is the lowest security level</div><div>Highest security level: Controlled by Bit 11 flag.</div></div> <div>The following table lists the setting method or the security level.</div> <table><thead><tr><th rowspan="2">Security Level</th><th colspan="3">Flag Control</th></tr><tr><th>Bit 10</th><th>Bit 9</th><th>Bit 8</th></tr></thead><tbody><tr><td>0</td><td>0</td><td>0</td><td>0</td></tr><tr><td>1</td><td>0</td><td>0</td><td>1</td></tr><tr><td>2</td><td>0</td><td>1</td><td>0</td></tr><tr><td>3</td><td>0</td><td>1</td><td>1</td></tr><tr><td>4</td><td>1</td><td>0</td><td>0</td></tr><tr><td>5</td><td>1</td><td>0</td><td>1</td></tr><tr><td>6</td><td>1</td><td>1</td><td>0</td></tr><tr><td>7</td><td>1</td><td>1</td><td>1</td></tr></tbody></table> <div><div>Note: If enable Advanced Level Access Control, the user level control here will be invalid.</div></div>	Security Level	Flag Control			Bit 10	Bit 9	Bit 8	0	0	0	0	1	0	0	1	2	0	1	0	3	0	1	1	4	1	0	0	5	1	0	1	6	1	1	0	7	1	1	1
Security Level	Flag Control																																							
	Bit 10	Bit 9	Bit 8																																					
0	0	0	0																																					
1	0	0	1																																					
2	0	1	0																																					
3	0	1	1																																					
4	1	0	0																																					
5	1	0	1																																					
6	1	1	0																																					
7	1	1	1																																					

The following table lists the flags of curve control register with their description.

Curve Control Register															
b15	b14	b13	b12	b11	b10	b9	b8	b7	b6	b5	b4	b3	b2	b1	b0
(4)				(3)			(2)				(1)				
<p>(1) b0~b3 Curve sampling flags 1~4</p> <p>(2) b4~b7 Reserved</p> <p>(3) b8~b11 Curve clear flags 1~</p> <p>(4) b12~15 Reserved</p>															
b0~b3 – Curve sampling flags (1~4)				<p>Control the curve drawing action.</p> <ul style="list-style-type: none">The curves include the Trend Graph and X-Y Chart.If the flag is set to ON, the corresponding curve element samples and draws the curve. To reactivate this function, turn the flag OFF and then ON again.The sampling flag 1 of the Trend Graph element corresponds to the curve clear flag 1; the sampling flag 2 of the Trend Graph element corresponds to the curve clear flag 2, and so forth. <div><div>Trend Graph</div><div><div>Preview</div><div></div><div>State: 0</div><div>Language: Language1</div><div>Element description: Trend Graph_001</div></div><div><div>MainStyleCoord</div><div>Detail</div><div>Number of Curves: 1</div><div>Data</div><div>Address None</div><div>Sample Number 10</div><div>Max Sample 100</div><div>Data Format Unsigned Decimal</div><div>Sample Flag 1</div><div>Curve1</div><div>Minimum Maximum 100</div><div>Line Weight 1</div><div>Line Color Blue</div><div>Projection Axis No projection</div></div><div>OKCancel</div></div>											
				<p>b8~b11 – Curve clear flags (1~4)</p>											
b8~b11 – Curve clear flags (1~4)				<p>Control the curve clear action.</p> <p>If the flag is set to ON, the corresponding curve element clears the curve. To reactivate this function, turn the flag OFF and then ON again.</p>											

The following table lists the flags of recipe control register with their description.

Recipe Control Register															
b15	b14	b13	b12	b11	b10	b9	b8	b7	b6	b5	b4	b3	b2	b1	b0
(2)								(1)							
<div>(1) b0 Recipe number change flag</div> <div>(2) b1 Recipe read flag (PLC → HMI)</div> <div>(3) b2 Recipe write flag (HMI → PLC)</div> <div>(4) b3 Recipe group change flag</div> <div>(5) b4~b7 Reserved</div> <div>(6) b8~b15 Specify Recipe group number</div>															
b0 – Recipe number change flag				<div>Change the HMI recipe number. This is applicable to 16-Bit recipes. You must write the recipe number to be changed into the recipe number control register, and then trigger the recipe number change flag.</div> <div>Do one of the following to call or change the recipe number:</div> <div><div>• Use the HMI internal register RCPNO.</div><div></div><div>• Use this recipe number change flag.</div></div> <div>When the recipe number change flag is turned ON, the recipe number is changed according to the value defined in the recipe number control register, and the number of RCPNO internal register is changed automatically. To reactivate the function, turn the flag OFF and then ON again.</div>											
b1 – Recipe read flag (PLC → HMI)				<div>When the recipe read flag is turned ON, the HMI reads the controller recipe data and writes the data into the designated recipe data register. To reactivate the function, turn the flag OFF and then ON again.</div>											
b2 – Recipe write flag (HMI → PLC)				<div>When the recipe write flag is turned ON, the HMI writes the designated recipe data into the controller register. To reactivate the function, turn the flag OFF and then ON again.</div>											
b3 – Recipe group change flag				<div>Change the HMI recipe group number. This is applicable to 32-Bit recipes.</div> <div>Do one of the following to call and change the recipe group:</div>											

Recipe Control Register	
	<ul style="list-style-type: none"> Use the HMI internal register RCPG.  <ul style="list-style-type: none"> Use the recipe group change flag. <p>When the recipe group change flag is turned ON, the recipe group is changed according to the value defined in the recipe group change bits (b8~b15), and the number of the RCPG internal register is changed automatically. To reactivate the function, turn the flag OFF and then ON again.</p>
b8~b15 – Designate recipe group to be changed	Designate the recipe group to be changed with the high byte (Bits 8~15) from the recipe control register. By activating the recipe group change flag, the HMI changes the number of the RCPG internal register, it is changing the recipe group.

The following table lists the flags of recipe number register with their description.

Recipe Number Register															
b15	b14	b13	b12	b11	b10	b9	b8	b7	b6	b5	b4	b3	b2	b1	b0
								Recipe group designation							
b0~b15 – Recipe designation				Designate the group number of the recipe group to be changed through the recipe number register. By activating the recipe group change flag, the HMI automatically changes the number of the RCPG internal register, it is changing the recipe group.											

The following table lists the flags of system control register with their description.

System Control Register

b15	b14	b13	b12	b11	b10	b9	b8	b7	b6	b5	b4	b3	b2	b1	b0
-----	-----	-----	-----	-----	-----	----	----	----	----	----	----	----	----	----	----

(5)

(4)

(3)

(2)

(1)

(1) b0~b7 Multi-language setting values

(2) b8 Printer flag

(3) b9 Printer form feed flags

(4) b10~b11 Retrieve Ethernet address

(5) b12 Wi-Fi retrieve network address

(6) b13~b15 Reserved

b0~b7 –
Multi-language
setting values


Change the **multi-language setting values** to switch languages. You can set the multi-languages in **Multi-language setting page of Configuration** dialog.

Note: Supports adding up to maximum 32 languages.


b8 –
Printer flag

Set the printing mode, which is divided into general printing and screen layout printing.

- Set to ON, the printer runs according to the set mode.
- Set to OFF, the printer is idled.



Note: Only one mode is enabled at a time. The screen layout printing is prioritized.

System Control Register	
<p>b9 – Printer form feed flag</p>	<ul style="list-style-type: none"> Set to ON, the printer ejects the paper and flips the paper. Set to OFF, the printer is idled.  <pre> graph TD Start([Start]) --> ReadStatus{Read printer status} ReadStatus -- No --> Start ReadStatus -- Yes --> FormFeedFlag{Printer form feed flag} FormFeedFlag -- OFF --> ReadStatus FormFeedFlag -- ON --> PrintPage[The printer prints the next page automatically.] PrintPage --> End([End]) </pre>
<p>b10~b12 – Retrieve network address</p>	<p>When the HMI fails to obtain the IP address assigned by the DHCP server, trigger this bit to retrieve the IP address.</p> <ul style="list-style-type: none"> b10 is for obtaining the IP address with LAN1 b11 is for obtaining the IP address with LAN2. b12 is for obtaining the IP address with Wi-Fi.

The following table lists the flags of enhanced recipe control register with their description.

Enhanced Recipe Control Register

b15	b14	b13	b12	b11	b10	b9	b8	b7	b6	b5	b4	b3	b2	b1	b0
-----	-----	-----	-----	-----	-----	----	----	----	----	----	----	----	----	----	----

(6)

(5)

(4)

(3)

(2)

(1)


- (1) b0 Enhanced Recipe number change flag
- (2) b1 Enhanced Recipe read flag (PLC → HMI)
- (3) b2 Enhanced Recipe write flag (HMI → PLC)
- (4) b3 Enhanced Recipe group change flag
- (5) b4~b7 Reserved
- (6) b8~b15 Specify group number of Enhanced Recipe

b0 –
Enhanced Recipe
number change flag

Change HMI recipe group. This is applicable to enhanced recipes.

Do one of the following to call or change the enhanced recipe number:

- Use the HMI internal register **ENRCPNO**.



- Use enhanced recipe group change flag.

When the enhanced recipe group change flag is turned ON, the enhanced recipe group is changed according to the number defined in the enhanced recipe group control register, and the number in the internal register ENRCPNO is changed automatically. To reactivate the function, turn the flag OFF and then ON again.

b1 –
Enhanced Recipe
read flag
(PLC → HMI)

When the enhanced recipe read flag is turned ON, the HMI reads the controller enhanced recipe data and writes it into the designated enhanced recipe data register. To reactivate the function, turn the flag OFF and then ON again.


b2 –
Enhanced Recipe
write flag
(HMI → PLC)

When the enhanced recipe write flag is turned ON, the HMI writes the designated enhanced recipe data into the controller register. To reactivate the function, turn the flag OFF and then ON again.

b3 –
Enhanced Recipe
group number
change flag

Change the HMI recipe group number. This is applicable to enhanced recipes.

Do one of the following to call or change the enhanced recipe group number:

Enhanced Recipe Control Register	
	<ul style="list-style-type: none"> Use the HMI internal register ENRCPG.  <ul style="list-style-type: none"> Use enhanced recipe group number change flag. When the enhanced recipe group number change flag is turned ON, the enhanced recipe group number is changed according to the value defined in the enhanced recipe group number bits (b8~b15), and the number in the internal register ENRCPG is changed automatically. To reactivate the function, turn the flag OFF and then ON again.
b8~b15 – Designate enhanced recipe group number to be changed	Designate the enhanced recipe group number to be changed with the high byte (Bits 8~15) from the enhanced recipe control register. By activating the enhanced recipe group number change flag, the HMI changes the number in the internal register ENRCPG, it is changing the enhanced recipe group.

The following table lists the enhanced recipe control register with their description.

Enhanced Recipe Control Register															
b15	b14	b13	b12	b11	b10	b9	b8	b7	b6	b5	b4	b3	b2	b1	b0
								Enhanced recipe group designation							
b0~b15 – Enhanced Recipe designation				Designate the enhanced recipe group number to be changed from the enhanced recipe group control register. By activating the enhanced recipe group change flag, the HMI changes the number in the internal register ENRCPNO, it is changing the enhanced recipe group.											

The following table lists the advanced level access control register with their description.

Advanced Level Access Control					
b0~b3– Set User Level	Change the user level of the current HMI by triggering the Bit 0, Bit 1, Bit 2 and Bit 3 flags. The following table lists how to set security levels.				
	Security Level	Flag Control			
		Bit 3	Bit 2	Bit 1	Bit 0
	0	0	0	0	0
	1	0	0	0	1
	2	0	0	1	0
	3	0	0	1	1
	4	0	1	0	0
	5	0	1	0	1
	6	0	1	1	0
	7	0	1	1	1
	8	1	0	0	0
9	1	0	0	1	
b15 Set User Highest Level	Highest security level control.				

Note: If **Advanced Level Access Control** is enabled, user level of **General Control** becomes invalid.

Status Block

The **Status Block** is used to monitor the present HMI status, such as current screen number, curves, recipe control, and user level.

Note: If the **Control Block** is not set, the **Status Block** cannot monitor the status. Moreover, the addresses of the **Control Block** and **Status Block** cannot be the same.

Configuration

- Main
 - Non-volatile
 - Security Level and Password
 - Global Keypad Settings
 - System Setting
 - Screensaver Setup
 - Others
- Control Status Block
 - Control Block
 - Status Block**
- Real Time Clock
- Print
- Default
 - Element Default Value
 - Boot Logo
 - Boot Delay Screen
 - Custom Scroll Button
- Network Settings
 - Remote Desktop and Data Collectio
 - SMTP
 - FTP
 - MAC Settings
- Multi-language
 - Multi-language Settings
- Industry Application
 - Electronic Record

Status Block

☐ Use discontinuous address in Status Block
Start Address ...

☐ General Control ...
☐ Screen No. ...
☐ Curve Control ...
☐ Recipe Control ...
☐ Recipe Number ...
☐ System Control ...
☐ Enhanced Recipe Control ...
☐ Enhanced Recipe Number ...
☐ Advanced Level Access Control ...



OK

Cancel

Function	Description
Use discontinuous address in Status Block	If selected, the settings in the Status Block are available, and you can define the register addresses in the controller or the HMI internal memory.

The following table lists the flags of general control status register with their description.


General Control Status Register															
b15	b14	b13	b12	b11	b10	b9	b8	b7	b6	b5	b4	b3	b2	b1	b0
(9)				(8)				(7)	(6)	(5)	(4)	(3)	(2)	(1)	
(1) b0 Screen switch flag															
(2) b1~b2 Reserved															
(3) b3 Alarm buffer clear flag															
(4) b4 Alarm counter clear flag															

General Control Status Register	
<p>(5) b5 External storage device cache write flag</p> <p>(6) b6 Remote control lock flag</p> <p>(7) b7 Reserved</p> <p>(8) b8~b11 Set user level</p> <p>(9) b12~b15 Reserved</p>	
<p>b0 – Screen switch flag</p>	<ul style="list-style-type: none"> When the screen is switching, the flag is turned ON, When the screen switching is completed, the flag is turned OFF. 
<p>b3 – Alarm buffer clear flag</p>	<ul style="list-style-type: none"> When the HMI is clearing the alarm buffer, the flag is turned ON. When the alarm buffer clearing is completed, the flag is turned OFF. 

General Control Status Register


b4 – Alarm counter clear flag

- When the HMI is clearing the alarm counter, the flag is turned ON.
- When the alarm counter clearing is completed, the flag is turned OFF.



b5 – External storage device cache write flag

- When the HMI is updating the cache data into the USB or SD card, the flag is turned ON.
- When data updating is completed, the flag is turned OFF.



b8~b11 – Set user level

Reads the current user level operated by the HMI. The following table lists the bit state corresponding to the user level operated by the HMI.

Security Level	Flag Control			
	Bit 11	Bit 10	Bit 9	Bit 8
0	0	0	0	0
1	0	0	0	1
2	0	0	1	0
3	0	0	1	1
4	0	1	0	0
5	0	1	0	1
6	0	1	1	0
7	0	1	1	1
Highest security level	1	0	0	0

Note: If **Advanced Level Access Control** is enabled, the user level here will be invalid.

The following table lists the flags of screen No. status register with their description.

Screen No. Status Register															
b15	b14	b13	b12	b11	b10	b9	b8	b7	b6	b5	b4	b3	b2	b1	b0
								Screen number							
b0~b15 – Screen No. status				Check the last opened screen number with this status register.											

The following table lists the flags of the curve control status register with their description.

Curve Control Status Register															
b15	b14	b13	b12	b11	b10	b9	b8	b7	b6	b5	b4	b3	b2	b1	b0
_____				_____				_____				_____			
(4)				(3)				(2)				(1)			

(1) b0~b3 Curve sampling status flags 1~4 (b0 refers to flag 1, and so forth)


(2) b4~b7 Reserved

(3) b8~b11 Curve clear status flags 1~4 (b8 refers to flag 1, and so forth)

(4) b12~b15 Reserved


Curve Control Status Register

When the **Trend Graph** or **X-Y Chart** elements sample the data, the HMI turns the corresponding curve sampling status flag ON. When the sampling is completed, the curve sampling status flag is turned OFF.




The sampling flag 1 of the **Trend Graph** element corresponds to the curve sampling status flag 1; the sampling flag 2 of the **Trend Graph** element corresponds to the curve sampling status flag 2, and so forth.

b0~b3 –
Curve sampling
status flags
(1~4)




Curve Control Status Register

When the **Trend Graph** or **X-Y Chart** elements clear the data, the HMI turns the corresponding curve clear status flag ON. When the clearing is completed, the curve clear status flag is turned OFF.



The clear flag 1 of the **Trend Graph** element corresponds to the curve clear status flag 1; the clear flag 2 of the **Trend Graph** element corresponds to the curve clear flag 2, and so forth.

b8~b11 –
Curve clear
status flags
(1~4)



The following table lists the flags of recipe control status register with their description.

Recipe Control Status Register

b15	b14	b13	b12	b11	b10	b9	b8	b7	b6	b5	b4	b3	b2	b1	b0
-----	-----	-----	-----	-----	-----	----	----	----	----	----	----	----	----	----	----

(4)

(3)


(2)

(1)

- (1) b0 Recipe change status flag
- (2) b1 Recipe read status flag (PLC → HMI)
- (3) b2 Recipe write status flag (HMI → PLC)
- (4) b3~b15 Reserved


b0 –
Recipe change
status flag


When the control recipe group in the **control block** is changed, the recipe group change status flag is turned ON; when the HMI changes the recipe group and completes updating the RCPNO number, the recipe group change status flag is turned OFF.



b1 –
Recipe read
status flag

When the HMI reads back one set of recipe data from the control block, the recipe read status flag is turned ON; when the HMI completes reading and saving the recipe from the control block, the recipe read status flag is turned OFF.



Recipe Control Status Register	
b2 – Recipe write status flag	<p>When the HMI sends one set of designated recipe data to the control block, the recipe write status flag is turned ON; when the HMI completes writing the recipe into the control block, the recipe write status flag is turned OFF.</p> 

The following table lists the flags of recipe control status register with their description.


Recipe Control Status Register															
b15	b14	b13	b12	b11	b10	b9	b8	b7	b6	b5	b4	b3	b2	b1	b0
<div style="border-top: 1px solid black; margin-top: 10px; position: relative;"> Recipe group designation status </div>															
b0~b15 – Recipe number designation status				<ul style="list-style-type: none"> Whether you change the value of the recipe designation register RCPNO by the control block or HMI, the recipe group control status register updates its value so that the control block finds the current recipe number from this register. This recipe designation flag must work with the recipe change flag. 											

The following table lists the flags of system control status register with their description.

System Control Status Register															
b15	b14	b13	b12	b11	b10	b9	b8	b7	b6	b5	b4	b3	b2	b1	b0
(5)					(4)		(3)	(2)	(1)						
(1) b0~b7 Multi-language status value															
(2) b8 Printer status flag															
(3) b9 Printer form feed status flag															
(4) b10~b11 Retrieve Ethernet address status															
(5) b12 Wi-Fi retrieve network address status															
(6) b13~b15 Reserved															
b0~b7 – Multi-language status value				Display the corresponding status value of the language in use.											
b8 – Printer status flag				<ul style="list-style-type: none">Set to ON, the printer is printing the display screen or the edited screen of the HMI.Set to OFF, the printer is idled.											
b9 – Printer form feed status flag				<ul style="list-style-type: none">Set to ON, the printer is ejecting the paper and flipping the paper automatically.Set to OFF, the printer is idled.											
b10~b12 – Retrieve network address status value				Displays the status value of IP retrieve. When the Control Block is triggered to retrieve the network address, the status value is 1, and the status value is toggled to 0 after the address is obtained. <ul style="list-style-type: none">b10 is the LAN1 status.b11 is the LAN2 status.b12 is the Wi-Fi status.											

The following table lists the flags of enhanced recipe control status register with their description.

Enhanced Recipe Control Status Register															
b15	b14	b13	b12	b11	b10	b9	b8	b7	b6	b5	b4	b3	b2	b1	b0
(6)						(5)					(4)	(3)	(2)	(1)	
<div>(1) b0 Enhanced Recipe change status flag</div> <div>(2) b1 Enhanced passive read status flag (PLC → HMI)</div> <div>(3) b2 Enhanced Recipe write status flag (HMI → PLC)</div> <div>(4) b3 Enhanced Recipe group change status flag</div> <div>(5) b4~b7 Reserved</div> <div>(6) b8~b15 Designate the enhanced recipe group number to be changed.</div>															
b0 – Enhanced Recipe change status flag				When the control-enhanced recipe group in the control block is changed, the recipe group change status flag is turned ON; when the HMI group is changed and the RCPNO number is updated, the recipe group change status flag is turned OFF.											
				<div>Changing enhanced recipe group in progress</div> <div>Changing enhanced recipe group is done</div> <div>ON</div> <div>OFF</div>											
b1 – Enhanced Recipe read status flag				When the HMI reads one set of recipe data from the control block , the enhanced recipe read status flag is turned ON; when the reading and saving of the enhanced recipe via the control block is completed, the enhanced recipe read status flag is turned OFF.											
				<div>HMI is reading the data from PLC</div> <div>Reading the enhanced recipe data is done</div> <div>ON</div> <div>OFF</div>											

Enhanced Recipe Control Status Register	
b2 – Enhanced Recipe write status flag	<p>When the HMI sends one set of designated enhanced recipe data to the control block, the recipe write status flag is turned ON; after the enhanced recipe is written into the control block, the enhanced recipe write status flag is turned OFF.</p> 

The following table lists the flags of enhanced recipe control status register with their description.

Enhanced Recipe Control Status Register															
b15	b14	b13	b12	b11	b10	b9	b8	b7	b6	b5	b4	b3	b2	b1	b0
								Designation status of the enhanced recipe group							
b0~b15 – Enhanced Recipe designation status				<ul style="list-style-type: none">Whether you change the value of the enhanced recipe group designation register ENRCPNO by the control block or HMI, the enhanced recipe group status register updates its value so that the control block finds the recipe group number from this register.The enhanced recipe designation status flag must work with the enhanced recipe group change status flag.											

The following table lists the advanced level access control with their description.


Advanced Level Access Control					
b0~b3– Set User Level	Use Bit 0, Bit 1, Bit 2 and Bit 3 to read the current user authority level of the HMI. The following table lists how to set security levels.				
	Security Level	Flag Control			
		Bit 3	Bit 2	Bit 1	Bit 0
	0	0	0	0	0
	1	0	0	0	1
	2	0	0	1	0
	3	0	0	1	1
	4	0	1	0	0
	5	0	1	0	1
	6	0	1	1	0
	7	0	1	1	1
	8	1	0	0	0
	9	1	0	0	1
b15 Set User Highest Level	Highest authority level access.				

Note: If **Advanced Level Access** is enabled, user level of **General Control** becomes invalid.

Real Time Clock

Controller has a built-in real-time clock (RTC), allowing you to synchronize the HMI RTC time to the controller or the controller RTC time to the HMI. Some controllers do not have a built-in real-time clock, so this function cannot be used in operations related to time setting, for example, turn on and off the machine regularly every day, manage the access control, and so on.

Note: Some old Delta controller models (ES / SS / EC) do not support real time clock update.



Configuration

- Main
 - Non-volatile
 - Security Level and Password
 - Global Keypad Settings
 - System Setting
 - Screensaver Setup
 - Others
- Control Status Block
 - Control Block
 - Status Block
 - Real Time Clock**
- Print
- Default
 - Element Default Value
 - Boot Logo
 - Boot Delay Screen
 - Custom Scroll Button
- Network Settings
 - Remote Desktop and Data Collectio
 - SMTP
 - FTP
 - MAC Settings
- Multi-language
 - Multi-language Settings
- Industry Application
 - Electronic Record

Real Time Clock

1 ☐ Enable RTC Updates

2 **PLC Link Settings**

Link Name: Link2

Station No.: 1

Update: PLC RTC set to HMI

Trigger Mode: Timer 60 (Minutes)

None

3 **Time Field Setting**

Start Address: None

Length: 3

Address	Time Field
None	None
None	None
None	None

4 ☐ Sync time from PC

OK Cancel

1 Enable RTC Updates

Function	Description
Enable RTC Updates	Select to enable real-time clock update. Note: If the Delta controller is selected, the Time Field Setting area is disabled, and the address will be set to the special registers D1319 ~ D1313 of the real time clock of Delta controller.

2 PLC Link Settings

Function	Description
Link Name	Select the link name , even if the selected controller is COM1, COM2, COM3 or Ethernet. The default is Link2 .
Station No.	Set the station number of the controller for which you want to update the time. If the selected controller does not support station number setting, this setting is not available.

Function	Description
Update	Select the RTC update mode. The default is PLC RTC time set to HMI .
Trigger Mode	<p>Select the RTC trigger mode. The default is Timer.</p> <ul style="list-style-type: none"> If Timer is selected, you can set how often to perform automatic update. The range is 1 ~ 1440 minutes, and the default value is 60 minutes. If Bit On is selected, when the Bit is ON, it triggers to update the settings. If Bit Off is selected, when the Bit is OFF, it triggers to update the settings. <p>Note: If Bit On or Bit Off is selected, the trigger address must be set. The trigger address can be the internal memory or the register address of the controller.</p>




3 Time Field Setting




Function	Description
Start Address	<p>Set the register address of the controller for RTC time synchronization.</p> <p>Note: If Delta controller is selected, setting the Start Address is not required.</p>
Length	<p>Select the length according to the number of time field to synchronize. The value range is 1–7, and the default value is 3.</p> <p>Note: If Delta controller is selected, setting Length is not required.</p>

4 Sync time from PC

Function	Description
Sync time from PC	If selected, after downloading the project, the HMI time synchronizes with the PC.

The following table lists the setting steps with examples.

Setting Step	Example														
Real Time Clock Update	<ol style="list-style-type: none"> On the toolbar, go to General > Device Communication, and then configure the communication setting in the Device Communication dialog. <div data-bbox="598 432 1268 638" data-label="Form">  <p>Connection</p> <p>Link Name: Link3</p> <p>Manufacturers: Mitsubishi</p> <p>Series: FX3U/FX3GA</p> <p>Multi-Drop: Disable</p> </div> On the toolbar, go to General > Configuration. In the Real Time Clock setting page, select Enable RTC Updates checkbox. In the PLC Link Settings area, select Link3 (Mitsubishi – FX3U / FX3GA) for Link Name. Select PLC RTC time set to HMI for Update. Select Bit On for Trigger Mode. Click  to set the trigger address to \$I1.0. In the Time Field Setting area, set {Link3}1@D8013 for the start address and 6 for Length. In the address list, select Second for the Time Field corresponding to {Link3}1@D8013. Select Minute for the Time Field corresponding to {Link3}1@D8014. Select Hour for the Time Field corresponding to {Link3}1@D8015. Select Day for the Time Field corresponding to {Link3}1@D8016. Select Month for the Time Field corresponding to {Link3}1@D8017. Select Year for the Time Field corresponding to {Link3}1@D8018. <div data-bbox="598 1400 1364 1859" data-label="Form">  <p>Real Time Clock</p> <p>Enable RTC Updates</p> <p>PLC Link Settings</p> <p>Link Name: Link3</p> <p>Station No.: 1</p> <p>Update: PLC RTC set to HMI</p> <p>Trigger Mode: Timer 60 (Minutes)</p> <p>None</p> <p>Time Field Setting</p> <p>Start Address: {Link3}0@D8013</p> <p>Length: 6</p> <table border="1"> <thead> <tr> <th>Address</th> <th>Time Field</th> </tr> </thead> <tbody> <tr> <td>{Link3}0@D8013</td> <td>Second</td> </tr> <tr> <td>{Link3}0@D8014</td> <td>Minute</td> </tr> <tr> <td>{Link3}0@D8015</td> <td>Hour</td> </tr> <tr> <td>{Link3}0@D8016</td> <td>Day</td> </tr> <tr> <td>{Link3}0@D8017</td> <td>Month</td> </tr> <tr> <td>{Link3}0@D8018</td> <td>Year</td> </tr> </tbody> </table> </div> Click OK. 	Address	Time Field	{Link3}0@D8013	Second	{Link3}0@D8014	Minute	{Link3}0@D8015	Hour	{Link3}0@D8016	Day	{Link3}0@D8017	Month	{Link3}0@D8018	Year
Address	Time Field														
{Link3}0@D8013	Second														
{Link3}0@D8014	Minute														
{Link3}0@D8015	Hour														
{Link3}0@D8016	Day														
{Link3}0@D8017	Month														
{Link3}0@D8018	Year														

Setting Step	Example
Create button to trigger the real time clock	<ol style="list-style-type: none"> 1. Create a Maintained Button element and set its Write Address to \$11.0. 2. Edit the State 0 text as RTC BIT OFF, State 1 text as RTC BIT ON. 3. Set the Foreground Color as red, representing the state is triggered ON. 
Create Numeric Entry element	<ol style="list-style-type: none"> 1. Create 6 Numeric Entry elements, and set their addresses as {Link3}1@D8013 ~ {Link3}1@D8018 in order.  <ol style="list-style-type: none"> 2. Create 6 more Numeric Entry elements, and set their Internal parameter as TIME_YEAR, TIME_MONTH, TIME_DAY, TIME_HOUR, TIME_MINUTE, TIME_SECOND in order. 
Result	<p>After completing the creation of all elements, compile and download to the HMI. When the RTC Maintained Button (BITON) is triggered, the system will set the RTC time of the controller to the HMI. The HMI internal parameter TIME_YEAR, TIME_MONTH, TIME_DAY, TIME_HOUR, TIME_MINUTE, TIME_SECOND will be synchronized with the RTC of the controller.</p>

Setting Step	Example
	<div> <div>RTC BIT OFF</div> <div> D8013 D8014 D8015 D8016 D8017 D8018 2013 10 30 15 4 20 </div> <div> HMI_Year HMI_Month HMI_Day HMI_Hour HMI_Minute HMI_Second 2017 6 16 16 55 33 </div> </div>
	<div> <div>RTC BIT ON</div> <div> D8013 D8014 D8015 D8016 D8017 D8018 2013 10 30 15 4 20 </div> <div> HMI_Year HMI_Month HMI_Day HMI_Hour HMI_Minute HMI_Second 2013 10 30 15 4 20 </div> </div>

Print

Configuration

- Main
 - Non-volatile
 - Security Level and Password
 - Global Keypad Settings
 - System Setting
 - Screensaver Setup
 - Others
- Control Status Block
 - Control Block
 - Status Block
- Real Time Clock
- Print**
- Default
 - Element Default Value
 - Boot Logo
 - Boot Delay Screen
 - Custom Scroll Button
- Network Settings
 - Remote Desktop and Data Collection
 - SMTP
 - FTP
 - MAC Settings
- Multi-language
 - Multi-language Settings
- Industry Application
 - Electronic Record

Print

Standard 1

Printer: NULL

File read address: None

Save in: USB Disk String: 0

Paper:

Quality: DPI

Margin 2

Top: 0 mm

Bottom: 0 mm

Left: 0 mm

Right: 0 mm

Print Size 3

Width: mm

Ratio: 100 %

Height: mm

Ratio: 100 %

Interface 4

☒ USB Drive ☐ Ethernet

☐ COM Port

COM Port: COM1

Interface: RS232


Data Bits: 8 Bits

Parity Bits: None

Baud Rate: 9600

Direction 5

☒ Vertical ☐ Horizontal



☒ Auto Flip

OK Cancel

1 Standard

Function	Description
Printer	DOP-100 series models support Honeywell, HP, EPSON, ZEBRA, GoDEX, Micro Printer, PDF Writer, and ePrinter printers.
Paper	The paper size varies depending on the selected printer. The available options include A4, LETTER, CUSTOM, and so on.
Quality	Set the resolution of the printer. 72 and 203 DPI can be selected according to the selected printers.

2 Margin

Function	Description
Top / Bottom / Left / Right	Set the margins of the paper as the reserved area during printing, which means that it is displayed as blank and not printed. The value range is 0–550, and the default value is 0 .

3 Print Size

Function	Description
Width / Height	Set the width and height. This setting is available when Paper is set as CUSTOM.
Ratio	Set the ratio of the width and height. The value range is 10–400, and the default value is 100 .

4 Interface


Function	Description
Interface	USB, Ethernet, and COM Port can be selected according to the selected printer. If you choose ePrinter to print, you need to fill in the IP address and printer port (the default value is 85) of the PC you are using.


5 Direction

Function	Description
Direction	Set the printing direction as vertical or horizontal.

Function	Description
Auto Flip	<p>The printer provides an automatic paper ejection function, helping you to flip the paper to print.</p> <ul style="list-style-type: none"> If selected, the printer will automatically flip the paper and continue printing after the paper printing is completed. If not selected, the printer will forcibly eject the paper after the paper printing is completed and you need to flip the paper manually.

Default



Function	Description
Default Boot Screen	Set the initial screen when the HMI is turned on. You can choose another screen to set as the initial screen. The default is 1-Screen_1 .
Default Data Format	Set the default data format when creating an element. The default is Unsigned Decimal .
Default Screen Background	Set the default background color when editing the screen on the HMI. The default is  .

Function	Description						
System Error Display Time	<p>Set the time the message stays when an error message appears. The value range is 0–5, and the default value is 3.</p> <p>Note: When it is set to 0, if there is any error in the system, no message appears on the HMI.</p>						
System Key Mode	<p>Set the response the HMI should have when pressing the system key. The available options include Disabled, Enable the password check, and Uncheck Password. The default is Uncheck Password.</p> <table border="1"> <tr> <td>Disabled</td><td>If selected, pressing the system key cannot enter the system screen of the HMI.</td></tr> <tr> <td>Enable password check</td><td>If selected, after pressing the system key, the HMI asks you to enter the system key password.</td></tr> <tr> <td>Uncheck Password</td><td>If selected, after pressing the system key, you can enter the system screen of the HMI without entering the system key password.</td></tr> </table>	Disabled	If selected, pressing the system key cannot enter the system screen of the HMI.	Enable password check	If selected, after pressing the system key, the HMI asks you to enter the system key password.	Uncheck Password	If selected, after pressing the system key, you can enter the system screen of the HMI without entering the system key password.
Disabled	If selected, pressing the system key cannot enter the system screen of the HMI.						
Enable password check	If selected, after pressing the system key, the HMI asks you to enter the system key password.						
Uncheck Password	If selected, after pressing the system key, you can enter the system screen of the HMI without entering the system key password.						
System Key Password	<p>Set the system key password. This is the password that the HMI asks you to enter when the System Key Mode is set to Enable Password Check. The default value is 12345678.</p>						
System Default Font	<p>Set the system default font. The default is Verdana.</p>						
Use Fallback Font	<p>Currently, the DOP-100 series is to download the existing fonts to display on the HMI. When the operating system lacks fonts set in the elements, it makes the HMI unable to display the text normally after downloading, so the firmware loads a set of default fonts.</p> <ul style="list-style-type: none"> • If Use Fallback Font is selected, when the firmware default fonts fail, the software enables the backup font. • If Top Priority is selected, the priority of the backup fonts of the software will be higher than the default fonts of the firmware. 						
Faster HMI page changing	<p>If selected, when there are a lot of graphics and static text on the screen, the display speed can be speeded up when switching pages.</p>						
Reduce font size	<p>If selected, when the project is downloaded to the HMI, only the fonts used in the project will be downloaded.</p>						

Element Default Value

Configuration

- Main
 - Non-volatile
 - Security Level and Password
 - Global Keypad Settings
 - System Setting
 - Screensaver Setup
 - Others
- Control Status Block
 - Control Block
 - Status Block
- Real Time Clock
- Print
- Default
 - Element Default Value
 - Boot Logo
 - Boot Delay Screen
 - Custom Scroll Button
- Network Settings
 - Remote Desktop and Data Collection
 - SMTP
 - FTP
 - MAC Settings
- Multi-language
 - Multi-language Settings
- Industry Application
 - Electronic Record

Element Default Value

☒ Element text automatically wraps
☐ Contains alarm message

Font color

Default size of element scroll (if any)

20 pixels

Element flashing interval time

1000

(ms)

When changing the page, the element value update sequence

Display the value first, then communicate

Default fill style

Gradient

Font smoothing

Yes

☐ Apply to all elements



Elements are automatically resized according to text




Apply to new



Margin 0

OK


Cancel

Function	Description
Element text automatically wraps	<ul style="list-style-type: none"> If selected, the element text automatically wraps as long as it encounters the boundaries.  <ul style="list-style-type: none"> If not selected, when the text encounters the boundaries, the text does not wrap, but it gets extended. 
Font color	Set the font color . The default is <div></div> .
Default size of element scroll (if any)	Set the default size of the element scroll. The value range is 20–60 pixels, and the default value is 20 pixels . Note: This setting is applied to the elements with scrolls, such as historical data and alarm tables.


Function	Description																
Element flashing interval time	<p>Set the interval time for element flashing. The range value is 500–5000, and the default value is 1000.</p> <p>Note: This setting is available only when the Blink property of the element is set to Yes.</p> <table border="1"> <thead> <tr> <th colspan="2">Others</th></tr> </thead> <tbody> <tr> <td>Element Type</td><td>Maintained</td></tr> <tr> <td>Foreground Color</td><td> RGB(255, 0, 0)</td></tr> <tr> <td>Filled style</td><td>Gradient</td></tr> <tr> <td>Style</td><td>Standard</td></tr> <tr> <td>Blink</td><td>No</td></tr> <tr> <td>Min. Press Time (s)</td><td>0</td></tr> <tr> <td>User Security Level</td><td>0</td></tr> </tbody> </table>	Others		Element Type	Maintained	Foreground Color	 RGB(255, 0, 0)	Filled style	Gradient	Style	Standard	Blink	No	Min. Press Time (s)	0	User Security Level	0
Others																	
Element Type	Maintained																
Foreground Color	 RGB(255, 0, 0)																
Filled style	Gradient																
Style	Standard																
Blink	No																
Min. Press Time (s)	0																
User Security Level	0																


<p>When changing the page, the element value update sequence</p>	<p>Set the update order of the element value when the HMI changes the page. The default is Communicate first, then display the value.</p> <ul style="list-style-type: none"> Display the value first, then communicate: The value is read normally after switching the screen and is not affected by the communication.  <pre> graph TD A[Screen 1 D0=1] --> B[Goto Screen 2 D0=123] B --> C[Screen 2 [Numeric Entry] element show 123] C --> D[Get the value to complete the communication] D --> E["[Numeric Entry] address D0 value as 123"] </pre> <ul style="list-style-type: none"> Communication first, then display the value: The value display of the Numeric Entry elements pauses due to the switching of the screen.  <pre> graph TD A[Screen 1 D0=1] --> B[Goto Screen 2 D0=123] B --> C[Screen 2 [Numeric Entry] element show 123] C --> D[Get the value to complete the communication] D --> E["[Numeric Entry] address D0 value as 123"] </pre>
--	---

Function	Description																														
	<p>The following table lists the elements that currently support this feature.</p> <table> <tr> <td rowspan="5">Button element</td><td>Set to ON</td></tr> <tr> <td>Set to Off</td></tr> <tr> <td>Momentary</td></tr> <tr> <td>Maintained</td></tr> <tr> <td>Set value</td></tr> <tr> <td>Meter element</td><td>Meter(1) ~ (4)</td></tr> <tr> <td>Pipe Diagram element</td><td>Pipe Diagram (1), Pipe Diagram (2)</td></tr> <tr> <td rowspan="3">Indicator element</td><td>Multistate Indicator</td></tr> <tr> <td>Range Indicator</td></tr> <tr> <td>Simple Indicator</td></tr> <tr> <td rowspan="4">Data Display element</td><td>Numerical Display</td></tr> <tr> <td>Character Display</td></tr> <tr> <td>General Message display</td></tr> <tr> <td>Moving Sign</td></tr> <tr> <td rowspan="2">Graphic Display element</td><td>State Graphic</td></tr> <tr> <td>Animated Graphic</td></tr> <tr> <td rowspan="3">Input element</td><td>Numeric Entry</td></tr> <tr> <td>Character Entry</td></tr> <tr> <td>Barcode Input</td></tr> <tr> <td>Curve element</td><td>Curve Input</td></tr> <tr> <td>Analog element</td><td>Slider</td></tr> </table>	Button element	Set to ON	Set to Off	Momentary	Maintained	Set value	Meter element	Meter(1) ~ (4)	Pipe Diagram element	Pipe Diagram (1), Pipe Diagram (2)	Indicator element	Multistate Indicator	Range Indicator	Simple Indicator	Data Display element	Numerical Display	Character Display	General Message display	Moving Sign	Graphic Display element	State Graphic	Animated Graphic	Input element	Numeric Entry	Character Entry	Barcode Input	Curve element	Curve Input	Analog element	Slider
Button element	Set to ON																														
	Set to Off																														
	Momentary																														
	Maintained																														
	Set value																														
Meter element	Meter(1) ~ (4)																														
Pipe Diagram element	Pipe Diagram (1), Pipe Diagram (2)																														
Indicator element	Multistate Indicator																														
	Range Indicator																														
	Simple Indicator																														
Data Display element	Numerical Display																														
	Character Display																														
	General Message display																														
	Moving Sign																														
Graphic Display element	State Graphic																														
	Animated Graphic																														
Input element	Numeric Entry																														
	Character Entry																														
	Barcode Input																														
Curve element	Curve Input																														
Analog element	Slider																														
Default fill style	<p>Set the default filled style of the HMI. The default is Gradient. The settings of this page are global. After Filled Style is set, the filled style of the elements created later will be based on the setting here.</p>																														


Function	Description
Font smoothing	<p>Set whether the text font of the HMI is smooth. If set to Yes, the text is rendered anti-aliased.</p> <p>If Apply to all elements is selected, it will be applied to all elements and pops up a message. Otherwise, it will be applied to the Static Text elements.</p> 
Elements are automatically resized according to text	<ul style="list-style-type: none"> • Don't Apply: All elements are not automatically resized. • Apply to all: All elements in the project are automatically resized. • Apply to new: The added elements are automatically resized.


Boot Logo



Function	Description
Enable	<p>If selected, you can choose the boot screen from the picture bank. You can also:</p> <ul style="list-style-type: none"> Go to Project > Download the Boot Screen to replace the HMI boot screen. Go to Project > Download Screen to download the boot screen. <p>When a GIF file is selected, the gray circle at the bottom left corner displays as , you can preview the GIF action on the software.</p> <p>Note:</p> <ul style="list-style-type: none"> To use files not in the picture bank, import the picture to the picture bank first. After downloading the boot screen, power on the HMI again. Supported image file formats are BMP, JPG, GIF, ICO, and PNG. Only the boot screen after conversion by the software less than 3 Mbytes can be imported.

Boot Delay Screen



Function	Description
Enable	If selected, the boot delay time can be set.
Boot Delay Time	Set the boot delay time to wait for the controller to start. The value range is 0–255.
Default screen	<p>If the Boot Delay Time is set to 3 seconds, and the system default boot delay screen is used, then after downloading to the HMI, the HMI screen appears after counting down from 3 seconds to 0 seconds.</p> 
Custom Screen	Define the boot delay screen, and set the graphic display mode, background color, and whether to repeat.


Network Settings

Configuration

- Main
 - Non-volatile
 - Security Level and Password
 - Global Keypad Settings
 - System Setting
 - Screensaver Setup
 - Others
- Control Status Block
 - Control Block
 - Status Block
- Real Time Clock
- Print
- Default
 - Element Default Value
 - Boot Logo
 - Boot Delay Screen
 - Custom Scroll Button
- Network Settings**
 - Remote Desktop and Data Collectio
 - SMTP
 - FTP
 - MAC Settings
- Multi-language
 - Multi-language Settings
- Industry Application
 - Electronic Record

Network Settings

Localhost



HMI

Upload/Download port

12346

Modbus TCP Server Port

502

☒ Enable Modbus TCP Server

Time zone

(UTC+08:00) 台北

☐ Enable NTP

Server Name

tock.stdtime.gov.tw

☐ Calibration when startup

☐ Calibration at set intervals

180

Second

☐ Not prompt when NTP connection failed

Daylight saving time

Off

☒ Enable Lua Online Debugging

☒ Enable eComm Port

☒ Enable One Wire Service

OK


Cancel

Function	Description
HMI	Set the name of the HMI. When using network remote monitoring or data sampling, use the HMI name to quickly identify which HMI is being monitored or is accessing data.
Upload/Download port	Set the communication port. The default value is 12346 and is in the ON state. Note: There are a total of 65536 communication ports. Some specific communication ports are only used by specific programs.
MODBUS TCP Server Port	Set the communication port number. The default value is 502 . Note: <ul style="list-style-type: none"> This communication port must be the same as that of the MODBUS TCP/IP controller. If the HMI communicates with the MODBUS application on the PC side, change the communication port here.
Time	Select the time of the HMI to display according to the local time zone.
Enable NTP	If selected, the time of HMI can be calibrated through the network. Note: You must first check whether the network of HMI is smooth.
Server Name	Select the server provided in the software, or enter the local NTP server name.
Calibration when startup	If selected, the time of HMI is calibrated when the HMI is turned on.
Calibration at set intervals	If selected, set the number of seconds. The calibration timing is when the HMI is turned on and enters the screen. The value range is 10–99999, and the default value is 180 .
Daylight saving time	Select whether to enable the daylight-saving time. The default is off .
Enable Lua Online Debugging	If selected, you can set breakpoints in the Program page to perform the Online debug function.
Enable eComm Port	If selected, you can enable the HMI forward function to forward data to the terminal device through the HMI, and then establish the forward tunnel through eComm of the COMMGR software.
Enable One Wire Service	If selected, you can open the QIP function and scan the devices connected to the HMI communication port through the COMMGR software.

Remote Desktop and Data Collection

The following table lists the settings in the **Remote Desktop** and **Real-time Monitoring** tabs with their description.

Remote Desktop



1 eServer


Function	Description
Enable	Select to enable the eServer function.
Password	<p>Set the password to monitor or access data according to your needs. The default value is 12345678.</p> <ul style="list-style-type: none"> To comply with CyberSecurity specifications, the password must be set up to 8 characters and contain an uppercase letter, a lowercase letter, a number, and a symbol (!, \$, #, %). This is the password that must be entered to obtain the HMI project data and execute eServer and eRemote.
Sampling time	<p>Set how often eServer and eRemote take to perform sampling. The range value is 100–5000, and the default value is 100.</p>

Function	Description
Port	Set the connection ports of eServer and eRemote. The default value is 12348 . Note: The upload / download communication ports of the HMI are different from this communication port. The communication ports are different according to different programs.
Show warning when disconnected	This option is available only when Show warning when disconnected checkbox is selected. When the HMI is disconnected from the eServer or eRemote, the HMI displays a disconnection warning message.
Close warning window when the connection is restored	This option can only be enabled when Show warning when disconnected is checked. <ul style="list-style-type: none"> If selected, an error message keeps popping up on the HMI until the connection between the HMI and the eServer or eRemote is restored. If not selected, an error message only pops up once on the HMI.

2 VNC

Virtual Network Computing (VNC) function is an application that can remotely monitor and operate the HMI. This application can transmit keyboard and mouse actions and real-time screens through the network. When operating VNC using web pages, the browser must support JAVA installation, otherwise it cannot be opened.

Function	Description
Enable	If selected, you can remotely monitor to operate the HMI through VNC.
Password	Set the connection password according to your needs. The default value is 12345678 . To comply with CyberSecurity specifications, the password must be set up to 8 characters and contain an uppercase letter, a lowercase letter, a number, and a symbol (!, \$, #, %).
Multiple connection mode	Select to allow multiple HMIs to be connected. Up to 64 HMIs can be connected.
Monitor mode	If selected, you can only monitor the HMI when VNC is connecting remotely.
Port	Set the connection port. The default value is 5900 . VNC Viewer provides web page operation mode. In this mode, you only need to enter the IP Address of the HMI into the browser and set the port as 5800 (even if the communication

Function	Description
	<p>port is not set as default value 5900) to connect, such as <code>http://192.168.123.148:5800</code>.</p> <p>Note:</p> <ul style="list-style-type: none"> The connection port must be changed to 5902 when using VNC Viewer to connect. Do not use 5800 when setting the connection port on the software side. If it is set to 5800, after downloading the screen to the HMI, it asks you to change the port. 
Network Use	Select the port to open the VNC function. It applies to the HMI models with two Ethernet ports.

Real-time Monitoring


The real-time monitoring function allows you to write the value to the HMI on the web page, or monitor the change of the value by the web page after the HMI writes the value. The data formats supported by the monitoring address include BCD, Signed Decimal, Unsigned Decimal, Hexadecimal, Floating, and Char. You can set the reading length for each data format to decide whether to read Word or Double Word. When the number of reading is 1, the integer number of digits can be set up to 5, which means that the reading is Word; when the number of readings is 2, the integer number of digits can be set up to 10, which means that the reading is Double Word. Address input provides Word and Bit, which can support internal memory address and external controller address.

How to use network real-time monitoring?

1. In the **Real-time Monitoring** tab, select **Enable real-time monitoring** checkbox and set the address.
2. Enter **http: //[HMI IP]/RemoteMon/** on the browser.


Note: The two characters R and M must be capital letters.

- After the connection is successful, the login screen appears. Enter the password of the web application to log in.







The login screen for Delta HMI Remote Monitoring. It features the Delta logo and tagline 'Smarter. Greener. Together.' on the left. The title 'Delta HMI Remote Monitoring' is centered at the top. Below the title, there is a 'Password:' label followed by a text input field. A 'Submit' button is located below the input field.

The following table lists the settings in the **Real-time Monitoring** tab with their description.



The configuration window is titled 'Configuration' and has a tree view on the left. The 'Remote Desktop and Data Collection' option is selected. The main area shows the 'Real-time Monitoring' tab. It includes a checkbox for 'Enable real-time monitoring' with a password field set to '12345678'. Below this is a 'General Settings' section with 'Items per Page' set to 10 and 'Update' set to 30. A table with columns: NO, Name, Address, Data Format, Unit, Length, Integer Display, and Fractional Display is shown. The table is currently empty. At the bottom right are 'OK' and 'Cancel' buttons.

Function	Description
Enable real-time monitoring	If selected, the real-time monitoring settings are available.
	Click to add monitoring address. You can enter the name and address. The name can be entered up to 30 characters.
	Select the items you want to delete, and then click this icon to delete the monitoring address.


Function	Description
	Click to import a CSV file.
	Click to export the monitoring address content to a CSV file.
Password	Set the password that must be entered when entering the connection address using the web page. The default value is 12345678 . To comply with CyberSecurity specifications, the password must be set up to 8 characters and contain an uppercase letter, a lowercase letter, a number, and a symbol (!, \$, #, %).
Items per Page	Set the number of monitoring addresses to be displayed on one page. The value range is 1–20, and the default value is 10 .
Update	Set how often the screen updates after updating the value. The value range is 1–30, and the default value is 30 .

SMTP




SMTP (**Simple Mail Transfer Protocol**) is used to transmitting email and define the rules for sending email from a source address to a destination address to control how email is relayed. This function allows you to obtain the alarm message when an alarm occurs by receiving the email.





Note: Before using the SMTP function, set up a Mail Server environment or search for a free Mail Server on the Internet.

The following table lists the settings in the **SMTP** setting page with their description.




Function	Description
Enable Mail Host	If selected, the mail host settings are available.
Server Address	Set the server address. This IP address is the Mail Server IP created by users. Note: Before using the SMTP function, set up a Mail Server environment or search for a free Mail Server on the Internet.
Server Port	Set the server port. This is the general SMTP communication port. The default value is 25
Sender Address	Set the sender's email address.
SSL Encrypted Transmission	SSL (Secure Socket Layer) is an encryption-based Internet security protocol, which ensures the confidentiality and integrity of communication between two applications, as well as verifying the identity of the server. To use Gmail to send email, do the following: 1. After logging into your Gmail account, click Manage your Google Account .

Function	Description
	 <p>2. On the left navigation panel, select Security.</p> <p>3. Enable 2-Step Verification function under How you sign in to Google. For the detailed operation method, please see Sign in with app passwords.</p> <p>After the above setting is completed, you can use Gmail to receive alarm emails.</p> <p>Note: The e-mail must support SSL function.</p>
Enable Security Authentication	<p>If selected, the account and password can be set.</p> <p>If the SMTP server is set up with an account and password to verify the identity, this option must be selected.</p>
Account	<p>If the security authentication checkbox that requires an account and password is selected when setting up the SMTP Mail Server, first enter the account and password. This account and password are used to check whether the recipient is a legitimate user of the back-end mail system to prevent uncollected emails from occupying the system resources to cause hidden mail security problems.</p>
Password	<p>Note:</p> <ul style="list-style-type: none"> The account and password must be set according to the requirements of the SMTP server. The account format varies depending on the format of each SMTP Mail Server. You can look up the related rules of MIS.
Time	<p>Select the local time zone so the time to send the alarm email will be more accurate.</p>
Contact Management	<p>Set the contact address for the mail information of the alarm. Follow the steps to set the contact address and its mail information.</p> <ol style="list-style-type: none"> In the Contact list area, click  to add new contact. On the toolbar, click  to set the group name in the Group settings dialog.

Function	Description
	<p>3. In All contacts area, choose the contact and click  to add it to the Group contact. You can also click  to remove the contact from the Group contact.</p> <p>4. In the Contact Management dialog, choose the group name in the Address book, the contact in the group lists in the Contact list.</p>  <p>5. Set the mail recipient in the Mail field of the Alarm Settings page. The contacts or groups can be selected as Recipient.</p> 

After the SMTP settings are completed and downloaded to the HMI, go to **System Menu > System Setting > Network App > SMTP** to access the settings. You can also change the SMTP settings on the HMI and then upload the settings to DIAScreen.



FTP

FTP (File transfer protocol) is a standard communication protocol that is used for downloading alarms, historical data, recipes, and operation logs in a USB or SD card through the network to the PC for viewing. You can also upload files from your PC to a USB or SD card.

The following table lists the rules of FTP with their description.

FTP Rule	Description
Supported HMI	Network-based HMI
Network-based HMI	File transfer application
	Windows File Explorer
	DOS Command Line
Connection Limit	Up to 3 FTP Clients can be connected at the same time
	Automatically disconnect when idle for more than 90 seconds

FTP Rule	Description	
Login method	Anonymous login	Adding of directories is not allowed.
		Uploading of files is not allowed.
		Downloading of files is not allowed.
		Deletion of files is not allowed.
		Change of filename is allowed.
	Account login	Adding of directories is allowed.
		Uploading of files is allowed.
		Downloading of files is allowed.
		Deletion of files is allowed.
		Change of filename is allowed.
File transfer rules	Unlimited traffic	
	Support resume	
	Unlimited size of the file to be sent.	
	The maximum length of file name is 260 bytes.	
	Change of filename is allowed.	
	Support Chinese filename.	
	Encryption is not supported.	
	Support active / passive mode connection.	
	When FTP is transferring, you can enter and exit the system menu.	


The FTP Server supports connection through file transfer applications, Windows File Explorer, and DOS Command Line.

- **File transfer applications**

Upload / download files through file transfer applications.

Note: The FTP Server provided by HMI needs to be used with FTP Client application.

The following figure is an example using the file transfer application FileZilla, which is free and can be downloaded from filezilla-project.org/download.php.



The following table lists the functions in the FileZilla application with their description.


Legend	Function	Description
①	Host	Set the HMI IP address, the example is 192.168.123.114.
②	Username	Set the username as admin.
③	Password	Set the password as 1234.
④	Port	Set the port as 21.
⑤	Quick connect	Click to quickly connect to the FTP Server. Note: Before executing this function, complete the above settings.

• Windows File Explorer

Upload / download files by connecting to the FTP Server through Windows File Explorer.

1. Open the file manager and enter **ftp://192.168.1.7/** in the input box for the file path.
2. Enter the account and password to log in to FTP.


After logging in, all files in the USB will be displayed.



- **DOS Command Line**

Upload / download the files by connecting to the FTP Server through DOS Command Line.

1. Open the command prompt and enter **ftp 192.168.123.114**.
2. Enter users account **admin** and password **1234**.



According to the FTP command, use help to view the supported related commands.

```

系統管理員: C:\Windows\system32\cmd.exe - ftp 192.168.123.114
Microsoft Windows [版本 6.1.7601]
Copyright (c) 2009 Microsoft Corporation. All rights reserved.

C:\Users\Tina.Q.Lee>ftp 192.168.123.114
已連線到 192.168.123.114。
220 Welcome to Delta HMI FTP service.
使用者 (192.168.123.114:(none)): admin
331 Please specify the password.
密碼:
230 Login successful.
ftp> help
命令可能會被縮寫。命令為:

!          delete          literal          prompt          send
?          debug          ls              put             status
append     dir                  ndelete        pud            trace
ascii      disconnect        ndir           quit           type
bell       get                nget           quote          user
binary     glob              nkdir          recv           verbose
bye        hash              nls            remotehelp
cd         help              nput           rename
close     lcd              open           rmdir
ftp>

```

Enter the dir command to list all files currently in the USB.

```

系統管理員: C:\Windows\system32\cmd.exe - ftp 192.168.123.114
命令可能會被縮寫。命令為:


!          delete          literal          prompt          send
?          debug          ls              put             status
append     dir                  ndelete        pud            trace
ascii      disconnect        ndir           quit           type
bell       get                nget           quote          user
binary     glob              nkdir          recv           verbose
bye        hash              nls            remotehelp
cd         help              nput           rename
close     lcd              open           rmdir
ftp> dir
200 PORT command successful. Consider using PASV.
150 Here comes the directory listing.
-rwxrwxrwx 1 0 0 409294 Feb 09 13:35 5014031202-EN.pdf
-rwxrwxrwx 1 0 0 435 Dec 19 2016 Alarm_Initial-Macro.txt
-rwxrwxrwx 1 0 0 442699749 Apr 20 09:33 DELTA_Ia-HMI_DOPSoft-4-
00-01-00_SW_IC-SC-EN-SP_20170420.zip
drwxrwxrwx 3 0 0 4096 Jun 22 11:30 HMI
drwxrwxrwx 2 0 0 4096 Apr 24 20:15 PPT
drwxrwxrwx 3 0 0 4096 Apr 24 14:16 Screen
-rwxrwxrwx 1 0 0 64 Jun 22 11:31 interfaces
226 Directory send OK.
ftp: 528 位元組已接收，時間: 0.02秒數 33.00KB/sec。
ftp>

```

To download files from a USB or SD Card, use the get command. If you want to upload files from PC to USB or SD Card, use the put command.

The following table lists the functions of the **FTP Host** tab with their description.

FTP Host



Configuration

- Main
 - Non-volatile
 - Security Level and Password
 - Global Keypad Settings
 - System Setting
 - Screensaver Setup
 - Others
- Control Status Block
 - Control Block
 - Status Block
- Real Time Clock
- Print
- Default
 - Element Default Value
 - Boot Logo
 - Boot Delay Screen
 - Custom Scroll Button
- Network Settings
 - Remote Desktop and Data Collection
 - SMTP
 - FTP**
 - MAC Settings
- Multi-language
 - Multi-language Settings
- Industry Application
 - Electronic Record

FTP

FTP Host FTP File Setting

☐ Enable FTP host function

FTP Host Port: 21 (1~65535)

Account: hmi

Password: 12345678


Root Directory: USB Disk

☐ Anonymous

OK Cancel

Function	Description
Enable FTP host function	If selected, the FTP settings are available.
FTP Host Port	Set the FTP host port. The default value is 21 .
Account	Set the account name.
Password	Set the password. To comply with CyberSecurity specifications, the password must be set up to 8 characters and contain an uppercase letter, a lowercase letter, a number, and a symbol (!, \$, #, %).
Root Directory	Select the storage location of HMI files. The available options include USB Disk , USB Disk 2, SD, and HMI. The default is USB Disk .
Anonymous	If selected, you can log in to FTP without entering an account and password. Note: After using an anonymous connection to log into FTP, you cannot upload / download files, delete files or add new directories.

After the FTP settings are completed and loaded into the HMI, go to **System Menu > System Setting > Network App > FTP Server** to access the settings. You can also change the FTP settings on the HMI and then upload the settings to DIAScreen.



FTP File Setting

FTP file transfer provides functions such as account login / logout, file upload / download, file deletion, file management / rename, directory (folder) management, etc. File transfer can be carried out through DOP series HMI and FTP Server.

Note: FTP file transfer should be used with the **FTP File List** element.

Configuration

- Main
 - Non-volatile
 - Security Level and Password
 - Global Keypad Settings
 - System Setting
 - Screensaver Setup
 - Others
- Control Status Block
 - Control Block
 - Status Block
- Real Time Clock
- Print
- Default
 - Element Default Value
 - Boot Logo
 - Boot Delay Screen
 - Custom Scroll Button
- Network Settings
 - Remote Desktop and Data Collection
 - SMTP
 - FTP
 - MAC Settings
- Multi-language
 - Multi-language Settings
- Industry Application
 - Electronic Record

FTP

FTP Host

FTP File Setting

☐ Enable FTP file transfer

IP addr. (4 Words)

None

...

Port addr.

None

...

Login trigger addr.

None

...

Logout trigger addr.

None

...

Login account addr.

None

...

Max. length of

16

Word

Login password addr.

None

...

Max. length of password

16

Word

☐ Trigger addr. is set to a continuous addr.

Address Name	Address	Unit	Max. Length Of Name
Change working DIR trigger addr.	None	Bit	-----
Check duplicated DIR/File trigger	None	Bit	-----
Create DIR trigger addr.	None	Bit	-----
Change DIR/File trigger addr.	None	Bit	-----
Delete DIR/File trigger addr.	None	Bit	-----
Get DIR/File name trigger addr.	None	Bit	-----
Download DIR/File trigger addr.	None	Bit	-----
FileSlot operate saving trigger ac	None	Bit	-----
FileSlot operate rename trigger :	None	Bit	-----
FileSlot operate delete trigger a	None	Bit	-----
FileSlot operate save as trigger a	None	Bit	-----
FileSlot operate new trigger add	None	Bit	-----
Working DIR name addr.	None	Word	128


OK

Cancel


Function	Description	
Enable FTP file transfer function	Check to enable FTP Client function.	
Host Login	IP addr.	Set the FTP Server IP address to which to connect.
	Port addr.	Set the FTP Server connection port to which to connect.
	Login trigger addr.	The input value type is Bit. When this bit is turned On, it will be logged in.
	Logout trigger addr.	The input value type is Bit. When this bit is turned On, the system will log out.
	Login account addr.	Set the starting address of the account. The maximum length supports 16 words.
	Max. length of account	
	Login password addr.	Set the starting address of the password. The maximum length supports 16 words.
	Max. length of password	
Change working DIR / File	Change working DIR trigger addr.	When this bit is On, the working directory is changed and automatically cleared after completion.



Function	Description																													
	Example 1. Set the string content of Working DIR name addr. (\$500) to /lua. <div><div><input checked="" type="checkbox"/> Trigger addr. is set to a continuous addr.</div><table><tr><th>Address Name</th><th>Address</th><th>Unit</th><th>Max. Length Of Name</th></tr><tr><td>FileSlot operate rename trigger addr.</td><td>\$200.8</td><td>Bit</td><td>-----</td></tr><tr><td>FileSlot operate delete trigger addr.</td><td>\$200.9</td><td>Bit</td><td>-----</td></tr><tr><td>FileSlot operate save as trigger addr.</td><td>\$200.10</td><td>Bit</td><td>-----</td></tr><tr><td>FileSlot operate new trigger addr.</td><td>\$200.11</td><td>Bit</td><td>-----</td></tr><tr><td>Working DIR name addr.</td><td>\$500</td><td>Word</td><td>128</td></tr><tr><td>Selected DIR/File name addr.</td><td>\$700</td><td>Word</td><td>16</td></tr></table></div>		Address Name	Address	Unit	Max. Length Of Name	FileSlot operate rename trigger addr.	\$200.8	Bit	-----	FileSlot operate delete trigger addr.	\$200.9	Bit	-----	FileSlot operate save as trigger addr.	\$200.10	Bit	-----	FileSlot operate new trigger addr.	\$200.11	Bit	-----	Working DIR name addr.	\$500	Word	128	Selected DIR/File name addr.	\$700	Word	16
	Address Name	Address	Unit	Max. Length Of Name																										
	FileSlot operate rename trigger addr.	\$200.8	Bit	-----																										
	FileSlot operate delete trigger addr.	\$200.9	Bit	-----																										
FileSlot operate save as trigger addr.	\$200.10	Bit	-----																											
FileSlot operate new trigger addr.	\$200.11	Bit	-----																											
Working DIR name addr.	\$500	Word	128																											
Selected DIR/File name addr.	\$700	Word	16																											
2. Set Change working DIR trigger addr. (\$200.0) to On. <div><div><input checked="" type="checkbox"/> Trigger addr. is set to a continuous addr.</div><table><tr><th>Address Name</th><th>Address</th><th>Unit</th><th>Max. Length Of Name</th></tr><tr><td>Change working DIR trigger addr.</td><td>\$200.0</td><td>Bit</td><td>-----</td></tr></table></div>		Address Name	Address	Unit	Max. Length Of Name	Change working DIR trigger addr.	\$200.0	Bit	-----																					
Address Name	Address	Unit	Max. Length Of Name																											
Change working DIR trigger addr.	\$200.0	Bit	-----																											
3. The FTP File List element will be switched to the lua directory. If the directory does not exist, the operating state (\$1000) becomes 0x0022. <div><table><tr><td>Operating state</td><td>\$1000</td><td>Word</td></tr></table></div>		Operating state	\$1000	Word																										
Operating state	\$1000	Word																												
4. Once Change working DIR trigger addr. (\$200.0) operation is completed, it will be automatically cleared to Off.																														
Check duplicate DIR/File	Check duplicated DIR/File trigger addr.	When this bit is On, the duplicated directory / file is checked and automatically cleared after completion.																												
	Example 1. Set the string content of Change/Create/Check name addr. (\$750) to lua. <div><table><tr><td>Change/Create/Check name addr.</td><td>\$750</td><td>Word</td><td>16</td></tr></table></div>		Change/Create/Check name addr.	\$750	Word	16																								
	Change/Create/Check name addr.	\$750	Word	16																										
	2. Set Check duplicated DIR/File trigger addr. (\$200.1) to On. <div><table><tr><td>Check duplicated DIR/File trigger addr.</td><td>\$200.1</td><td>Bit</td></tr></table></div>		Check duplicated DIR/File trigger addr.	\$200.1	Bit																									
Check duplicated DIR/File trigger addr.	\$200.1	Bit																												
3. If the Lua folder already exists, the content of Check duplicated DIR/File result (\$900) becomes 1; otherwise, it becomes 0. <div><table><tr><td>Check duplicated DIR/File result</td><td>\$900</td><td>Word</td></tr></table></div>		Check duplicated DIR/File result	\$900	Word																										
Check duplicated DIR/File result	\$900	Word																												
Create DIR / Change DIR / Delete DIR / File	Create DIR trigger addr.	When this bit is On, a new directory is created and automatically cleared after completion.																												
	Example 1. Set the string content of Change/Create/Check name addr. (\$750) to TestHMI. <div><table><tr><td>Change/Create/Check name addr.</td><td>\$750</td><td>Word</td><td>16</td></tr></table></div>		Change/Create/Check name addr.	\$750	Word	16																								
Change/Create/Check name addr.	\$750	Word	16																											

Function	Description
	<p>2. Set Create DIR trigger addr. (\$200.2) to On.</p> <div>Create DIR trigger addr. \$200.2 Bit</div> <p>3. Add the TestHMI folder in the FTP Server and update the FTP File List element. If the TestHMI folder already exists, Operating state (\$1000) changes to 0x0042.</p> <div>Operating state \$1000 Word</div> <p>4. Once Create DIR trigger addr. (\$200.2) operation is completed, it will be automatically cleared to Off.</p>
Change DIR/File trigger addr.	When this bit is On, the directory / file name is changed and automatically cleared after completion.
<p>Example</p> <p>1. Use the FTP File List element to select the directory TestHMI to be changed.</p> <p>2. Set the string content of Change/Create/Check name addr. (\$750) to ChangeHMI.</p> <div>Change/Create/Check name addr. \$750 Word 16</div> <p>3. Set Change DIR/File trigger addr. (\$200.3) to On.</p> <div>Change DIR/File trigger addr. \$200.3 Bit</div> <p>4. Change the name of the TestHMI folder to ChangeHMI, and the HMI updates the FTP File List elements at the same time. If the ChangeHMI folder already exists, the Operating state (\$1000) changes to 0x0052.</p> <div>Operating state \$1000 Word</div> <p>5. Once Change DIR/File trigger addr. (\$200.3) operation is completed, it will be automatically cleared to Off.</p> <p>Note: This example operates on a directory. You can also use the trigger address to operate on files.</p>	
Delete DIR/File trigger addr.	When this bit is On, the directory / file name is deleted and automatically cleared after completion.
<p>Example</p> <p>1. Set the string content of Selected DIR/File name addr. (\$700) to ChangeHMI.</p> <div>Selected DIR/File name addr. \$700 Word 16</div> <p>2. Set Delete DIR/File trigger addr. (\$200.4) to On.</p> <div>Delete DIR/File trigger addr. \$200.4 Bit</div> <p>3. Delete the ChangeHMI folder of the FTP Server, and the HMI updates the FTP File List element at the same time.</p> <p>4. Once Delete DIR/File trigger addr. (\$200.4) operation is completed, it will be automatically cleared to Off.</p>	

Function	Description	
	Note: This example operates on a directory. You can also use the trigger address to operate on files.	
Get DIR / Filename	Get DIR/File name trigger addr.	When this bit is On, the directory / file name is obtained and automatically cleared after completion.
	<p>Example</p> <p>The following figure shows the FTP File List.</p>  <ol style="list-style-type: none"> Set Index of DIR/File name addr. (\$921) to 2. <div> Index of DIR/File name addr. \$921 Word </div> <p>If the index value is set to 0, the Operating state (\$1000) becomes 0x0027.</p> <div> Operating state \$1000 Word </div> Set Get DIR/File name trigger addr. (\$200.5) to On. <div> Get DIR/File name trigger addr. \$200.5 Bit </div> Get the folder name with FTP Server index value 2, Get DIR/File name result (\$770) content is lua. <div> Get DIR/File name result \$770 Word 16 </div> <p>Note:</p> <ul style="list-style-type: none"> This example operates on directory lines. You can also use this trigger address to operate on files. The index value is based on the FTP Server. The sorting displayed in the FTP File List of the HMI may not be the same as the sorting of the FTP Server. 	
Download DIR / File	Download directory/file trigger address	When this bit is On, the HMI starts downloading files from the FTP Server and automatically clear them after completion.
	<p>To use this function, first set up the FileSlot file function. In the menu bar, click Project > Other Settings > FileSlot Management to make related settings.</p>	

Function	Description	
	<p>3. The HMI downloads the file from the FTP Server to the Selected FileSlot addr. (\$920). If the directory contains multiple files, the Selected FileSlot addr. (\$920) represents the starting FileSlot position.</p> <div> <div>Selected FileSlot addr.</div> <div>\$920</div> <div>Word</div> </div> <p>After the action is completed, the Number of downloads (\$910) becomes 6.</p> <div> <div>Number of downloads</div> <div>\$910</div> <div>Word</div> </div> <p>4. After the file download is completed, the file will only be stored in the FileSlot address. To edit the downloaded file, you need to use the Text List element. To read out the file name of a downloaded file, use the FileSlotGetName macro command.</p> <p>Note:</p> <ul style="list-style-type: none"> This example operates on a directory, you can also use the trigger address to operate on files. If the name of the downloaded file is known, the HMI can obtain the location information (ID) of the file stored in FileSlot through the FileSlotGetID macro command. 	
FileSlot Operations	FileSlot operate saving trigger addr.	When this bit is On, the selected FileSlot file will be uploaded to the FTP Server and automatically cleared after completion.
	<p>To use this function, you need to set up the FileSlot file function and execute the download directory/file function.</p> <p>Example</p> <ol style="list-style-type: none"> Set Selected FileSlot addr. (\$920) to 4. <div> <div>Selected FileSlot addr.</div> <div>\$920</div> <div>Word</div> </div> <ol style="list-style-type: none"> Set FileSlot operate saving trigger addr. (\$200.7) to On. <div> <div>FileSlot operate saving trigger addr.</div> <div>\$200.7</div> <div>Bit</div> </div> <ol style="list-style-type: none"> The HMI uploads the file (main.lua) with FileSlotID 4 to the FTP Server. 	
	FileSlot operate rename trigger addr.	When this bit is On, the selected FileSlot file is renamed and uploaded to the FTP Server and automatically cleared after completion.
	<p>To use this function, first set up the FileSlot file function and execute the download directory/file function.</p> <p>Example</p> <ol style="list-style-type: none"> Set Selected FileSlot addr. (\$920) to 4. <div> <div>Selected FileSlot addr.</div> <div>\$920</div> <div>Word</div> </div>	

Function	Description	
	<p>2. Set Change/Create/Check name addr. (\$750) to main_new.lua.</p> <div>Change/Create/Check name addr. \$750 Word</div>	
	<p>3. Set FileSlot operate rename trigger addr. (\$200.8) to On.</p> <div>FileSlot operate rename trigger addr. \$200.8 Bit</div>	
	<p>4. The HMI changes the name of the main.lua file to main_new.lua, and simultaneously rename the FileSlot and updates the FTP File List.</p> 	
	FileSlot operate delete trigger addr.	When this bit is On, the selected FileSlot file is deleted from the FTP Server and automatically cleared after completion.
<p>To use this function, you need to set up the FileSlot file function and execute the download directory/file function.</p> <p>Example</p> <p>1. Set Selected FileSlot addr. (\$920) to 1.</p> <div>Selected FileSlot addr. \$920 Word</div> <p>2. Set FileSlot operate delete trigger addr. (\$200.9) to On.</p> <div>FileSlot operate delete trigger addr. \$200.9 Bit</div> <p>3. The HMI deletes the file LPT.bin on the FTP Server and updates the FTP File List simultaneously.</p>		
FileSlot Operations	FileSlot operate save as trigger addr.	When this bit is On, the selected FileSlot file is saved in the FTP Server and automatically cleared after completion.
	<p>To use this function, set up the FileSlot file function and execute the download directory / file function.</p> <p>Example</p> <p>1. Set Selected FileSlot addr. (\$920) to 3.</p> <div>Selected FileSlot addr. \$920 Word</div> <p>2. Set string content of the Change/Create/Check name addr. (\$750) to configNEW.ini.</p> <div>Change/Create/Check name addr. \$750 Word</div> <p>3. Set FileSlot operate save as trigger addr. (\$200.10) to On.</p> <div>FileSlot operate save as trigger addr. \$200.10 Bit</div>	

Function	Description	
	<p>4. The HMI adds a new file configNEW.ini on the FTP Server and updates the FTP file list simultaneously.</p> 	
	FileSlot operate new trigger addr.	When this bit is On, the selected FileSlot file is added to the FTP Server and automatically cleared after completion.
	<p>To use this function, set up the FileSlot file function first.</p> <p>Example</p> <ol style="list-style-type: none"> Set Selected FileSlot addr. (\$920) to 10. <input type="text" value="\$920"/> Word Set Change/Create/Check name addr. (\$750) to xyz.txt. <input type="text" value="\$750"/> Word Set FileSlot operate new trigger addr. (\$200.11) to On. <input type="text" value="\$200.11"/> Bit The HMI adds a file xyz.txt with a file size of 0 on the FTP Server, and updates the FTP File List simultaneously. 	
Operation directory/name address setting	Working DIR name addr.	Set the working directory name and Max. Length Of Name .
	Max. Length Of Name	Note: It should be used with Change working DIR trigger addr. Refer to the example operation of Change working DIR trigger addr.
	Selected DIR/File name addr.	Set the directory or file to be deleted and the maximum length.
	Max. Length Of Name	Note: It should be used with Delete DIR/File trigger addr. Refer to the example operation of Delete DIR/File trigger addr.

Function	Description	
	Change/Create/Check name addr.	Set the directory or file to be changed / created / checked and the maximum length. Note: It should be used with Check duplicated DIR/File trigger addr. or Create DIR trigger addr. Refer to the example operations for Check duplicated DIR/File trigger addr. or Create DIR trigger addr.
	Max. Length Of Name	
	Selected FileSlot addr.	Enter data type as Word and set the selected FileSlot. Note: It should be used with Download DIR/File trigger addr. Refer to the example operation of Download DIR/File trigger addr.
	Index of DIR/File name addr.	Enter data type as Word and set Index of DIR/File name addr. Note: It should be used with Get DIR/File name trigger addr. Refer to the example operation of Get DIR/File name trigger addr.
Execution result setting	Operating state	When the actions in the FTP transfer settings are completed, the operating state changes accordingly. If the operation is successful, 0 is displayed; otherwise, an error code is displayed.
	Check duplicated DIR/File result	Returns the result of Check duplicated DIR/File trigger addr.
	Number of downloads	Returns the number of downloaded files. Note: It should be used with Download DIR/File trigger addr.
	Get DIR/File name addr.	Returns the result of Get DIR/File name trigger addr.

The following table lists the FTP Client's return values with description.


Return Value		Description
Decimal	Hexadecimal	
0	0	Completed successfully
20	32	Login failed

Return Value		Description
Decimal	Hexadecimal	
21	33	Logout failed
22	34	Failed to switch working directory
23	35	Check for duplicate directory / file names failed
24	36	Unable to obtain directory / file information
25	37	Connection abnormality
26	38	Insufficient system memory space
27	39	Failed to query directory / file name
40	64	Failed to create directory / file
41	65	Unable to create file
42	66	Unable to create directory
50	80	Failed to rename directory / file
51	81	File cannot be renamed
52	82	Directory cannot be renamed
60	96	Failed to delete directory / file
61	97	Unable to delete file
62	98	Unable to delete directory
70	112	Fail to download directory / file
71	113	Unable to download file
72	114	Unable to download directory
73	115	FileSlot Insufficient storage space
80	128	Fail to save FileSlot
81	129	Unable to save FileSlot
82	130	Unable to save as FileSlot
A1	161	Unable to create FileSlot
A2	162	Unable to rename FileSlot
A3	163	Unable to delete FileSlot
A4	164	Unable to open FileSlot
A5	165	Unable to copy FileSlot
A6	166	Unable to obtain FileSlot ID
A7	167	Unrecognized FileSlot ID
A8	168	Unable to obtain FileSlot name


Return Value		Description
Decimal	Hexadecimal	
A9	169	Unable to set FileSlot name
AA	170	Unable to obtain the maximum number of FileSlots allowed
AB	171	Unable to add FileSlot, the maximum number of FileSlots allowed has been exceeded.
AC	172	Unable to obtain FileSlot space limit ed size
AD	173	FileSlot name duplicate



MAC Settings

In the **MAC Settings** page, set the MAC of the HMI to be loaded when creating screen data file, the file only can update the screen on the specified HMI. If the MAC is not set, the HMI model is not restricted. You can obtain the MAC from **System Menu > System Setting > Network** on the HMI.



The following table lists the functions in the **MAC Settings** page with their description.







Function	Description
	Click to add the MAC.
	Click to delete the MAC.


Multi-language

The following table lists the functions in the **Multi-language settings** tab with their description.

Multi-language settings




Function	Description
	Click to add a language. It supports adding up to 32 languages.
	<p>Select the item to be deleted and click the icon to delete, a warning message appears and asks whether to proceed.</p> <div data-bbox="416 1339 1348 1697"> <p>DIAScreen</p> <p> This action will remove the data related to this language and it is not recoverable. Proceed? (Y/N)</p> <p><input type="button" value="Yes"/> <input type="button" value="No"/></p> </div>
Language Name	Set the language name according to your needs.

Function	Description
Detail	<p>Detail column switches the language according to its value. To switch the language, you can:</p> <ul style="list-style-type: none"> Switch the language to the corresponding settings through the System Control in the Control Block page.  <ul style="list-style-type: none"> Click General on the toolbar and select the language to be switched in the Language field of the State/Language pane.
Enable	<p>The first row is the default language, the Enable checkbox cannot be unselected, or a warning message displays, informing that the language cannot be disabled.</p>
Default Font Style	<p>Apply the font name and font size according to the selected language.</p> <ul style="list-style-type: none"> If you only choose to apply the Font Name or Font Size, the font setting only applies to the newly created elements. If you choose both Font Name and Font Size to apply, the font setting applies to the existing and newly created elements. <p>Note: The font name and font size settings are applied to the elements that you can enter the text.</p>



System Language Settings

System languages include 6 languages, which can be applied to the system menu of the HMI and the pop-up message when operating the HMI.


Industry Application



Function	Description
Enable electronic record	If selected, the electronic record settings are available. Note: If enabled, Advanced Level Access Control of Control and Status Block becomes invalid.
Operation record	The Operation record function records all operations of the HMI, including numerical changes and user level. Checksum and Operation Log data will be added to the operation record file.


Function	Description
	
Alarm record	<p>If selected, the HMI alarm data will be recorded, and the Export CSV File field in the Alarm Settings page will be forced to be set to Yes.</p> <p>To cope with electronic signatures, the file name of the exported alarm data file will be created according to the year, month, day, hour, minute and second. Checksum data will be added.</p>  <p>Note: The timing of generating this file is based on the maximum number of records set by the alarm.</p>
History sampling record	<p>If selected, the HMI historical data will be recorded. In the Buffer Properties dialog of the History Buffer setting page,</p> <ul style="list-style-type: none"> Non-volatile will be forced to be set to HMI, SD, USB Disk or USB Disk 2 (based on the setting of Data storage), Export CSV File checkbox will be forced to be selected, The file storage method will also be forced to be set to Save As Multiple Files.

Function	Description																																																																																																																							
	<div> <div>Buffer Properties</div> <div> <div>Sampling</div> <div> <div>Address</div> <div>None</div> </div> <div> <div>Read Length (Word)</div> <div>1</div> </div> <div> <div>Sample Number</div> <div>10</div> </div> <div> <div>Enable active bit</div> <div>None</div> </div> </div> <div> <div>File Output</div> <div> <div> <input checked="" type="checkbox"/> Non-volatile <div>USB Disk</div> </div> <div> <input type="checkbox"/> Auto Stop </div> <div> <input checked="" type="checkbox"/> Export CSV File <div>Field Name</div> </div> </div> <div> <div>Save As Single File</div> <div> <div>File Name</div> <div>H0002</div> </div> </div> <div> <div>Save As Multiple Files</div> <div> <div>File Date</div> <div>%y %m %d</div> <div>File Time</div> <div>%H %M %S</div> <div>File Name</div> <div>H0002</div> <div>Archive trigger bit</div> <div>None</div> </div> </div> <div> <div>Trigger</div> <div> <div>Timer</div> <div> <input checked="" type="radio"/> Sampling Cycle (ms) <div>1000</div> </div> <div> <input type="radio"/> Custom Cycle (ms) <div>None</div> </div> </div> <div> <div>Stamp Time and Date</div> <div> <div>Time Format</div> <div>hh:mm:ss</div> <div>Date Format</div> <div>mm/dd/yy</div> </div> </div> </div> <div> <div>OK</div> <div>Cancel</div> </div> </div> </div>																																																																																																																							
	<p>The historical data of Save As Multiple Files will be stored according to year, month, day, hour, minute, and second. Checksum and HISTORY data will be added.</p> <p>H0001_Date-2017-07-12_Time-10-59-22.csv</p> <table border="1"> <thead> <tr> <th></th> <th>A</th> <th>B</th> <th>C</th> <th>D</th> <th>E</th> <th>F</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>HISTORY</td> <td></td> <td>6 mlfvfg</td> <td></td> <td></td> <td></td> </tr> <tr> <td>2</td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> </tr> <tr> <td>3</td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> </tr> <tr> <td>4</td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> </tr> <tr> <td>5</td> <td>Time</td> <td>Date</td> <td>Data 0</td> <td>Data 1</td> <td>Data 2</td> <td>Checksum</td> </tr> <tr> <td>6</td> <td>10:58:53</td> <td>07/12/2017</td> <td>0</td> <td>0</td> <td>0</td> <td>slM7WQ</td> </tr> <tr> <td>7</td> <td>10:58:53</td> <td>07/12/2017</td> <td>0</td> <td>0</td> <td>0</td> <td>q0gKGA</td> </tr> <tr> <td>8</td> <td>10:58:53</td> <td>07/12/2017</td> <td>0</td> <td>0</td> <td>0</td> <td>LNAWlw</td> </tr> <tr> <td>9</td> <td>10:58:53</td> <td>07/12/2017</td> <td>0</td> <td>0</td> <td>0</td> <td>Ncsnlq</td> </tr> <tr> <td>10</td> <td>10:58:53</td> <td>07/12/2017</td> <td>0</td> <td>0</td> <td>0</td> <td>GHqrLw</td> </tr> <tr> <td>11</td> <td>10:58:53</td> <td>07/12/2017</td> <td>0</td> <td>0</td> <td>0</td> <td>AWGAbg</td> </tr> <tr> <td>12</td> <td>10:58:53</td> <td>07/12/2017</td> <td>0</td> <td>0</td> <td>0</td> <td>KkzJrQ</td> </tr> <tr> <td>13</td> <td>10:58:54</td> <td>07/12/2017</td> <td>0</td> <td>0</td> <td>0</td> <td>Fbq98A</td> </tr> <tr> <td>14</td> <td>10:58:54</td> <td>07/12/2017</td> <td>0</td> <td>0</td> <td>0</td> <td>WvsnNw</td> </tr> <tr> <td>15</td> <td>10:58:54</td> <td>07/12/2017</td> <td>0</td> <td>0</td> <td>0</td> <td>Q+Aadg</td> </tr> <tr> <td>16</td> <td>10:58:54</td> <td>07/12/2017</td> <td>0</td> <td>0</td> <td>0</td> <td>aMlJtQ</td> </tr> </tbody> </table>		A	B	C	D	E	F	1	HISTORY		6 mlfvfg				2							3							4							5	Time	Date	Data 0	Data 1	Data 2	Checksum	6	10:58:53	07/12/2017	0	0	0	slM7WQ	7	10:58:53	07/12/2017	0	0	0	q0gKGA	8	10:58:53	07/12/2017	0	0	0	LNAWlw	9	10:58:53	07/12/2017	0	0	0	Ncsnlq	10	10:58:53	07/12/2017	0	0	0	GHqrLw	11	10:58:53	07/12/2017	0	0	0	AWGAbg	12	10:58:53	07/12/2017	0	0	0	KkzJrQ	13	10:58:54	07/12/2017	0	0	0	Fbq98A	14	10:58:54	07/12/2017	0	0	0	WvsnNw	15	10:58:54	07/12/2017	0	0	0	Q+Aadg	16	10:58:54	07/12/2017	0	0	0	aMlJtQ
	A	B	C	D	E	F																																																																																																																		
1	HISTORY		6 mlfvfg																																																																																																																					
2																																																																																																																								
3																																																																																																																								
4																																																																																																																								
5	Time	Date	Data 0	Data 1	Data 2	Checksum																																																																																																																		
6	10:58:53	07/12/2017	0	0	0	slM7WQ																																																																																																																		
7	10:58:53	07/12/2017	0	0	0	q0gKGA																																																																																																																		
8	10:58:53	07/12/2017	0	0	0	LNAWlw																																																																																																																		
9	10:58:53	07/12/2017	0	0	0	Ncsnlq																																																																																																																		
10	10:58:53	07/12/2017	0	0	0	GHqrLw																																																																																																																		
11	10:58:53	07/12/2017	0	0	0	AWGAbg																																																																																																																		
12	10:58:53	07/12/2017	0	0	0	KkzJrQ																																																																																																																		
13	10:58:54	07/12/2017	0	0	0	Fbq98A																																																																																																																		
14	10:58:54	07/12/2017	0	0	0	WvsnNw																																																																																																																		
15	10:58:54	07/12/2017	0	0	0	Q+Aadg																																																																																																																		
16	10:58:54	07/12/2017	0	0	0	aMlJtQ																																																																																																																		



Function	Description
Comm. error record	<p>If selected, the HMI will automatically store the communication error data in the HMI, USB, or SD card, and the storage location is HMI\HMI-000\CommEventLog. Checksum and Communication data will be added to the communication error record file.</p> 
Data storage	<p>Select the storage location of all stored data in electronic records. The available options include HMI, USB Disk, USB Disk 2, and SD.</p> <p>The default value is HMI.</p>

The electronic record function mainly ensures that the data are consistent and accurately generated and saved, and can be viewed at any time, which is different from the daily records. Therefore, the generated record data will be added with a checksum mechanism and exported to a CSV file.

Enable the **Enable electronic record** function will also enable the **Second confirmation of account** function for the **Confirmation Window** in the element dialog.



If the account is set to **Second confirmation of account**, you will be asked to enter the password twice.



The files generated by the electronic signature can be opened by Excel or the electronic record viewing tool eRecordViewer. The file storage location is C:\Program Files (x86)\Delta Industrial Automation\DIAScreen 1.6\Utility\eRecordViewer.

If the loaded data has not been tampered with, eRecordViewer will prompt "Verified OK".

Electronic Record Viewer

File Window

H0001_Date-2017-07-12_Time-10-59-22.csv

Verified OK.

	1	2	3	4	5	6
1	HISTORY V1.0	0006	mlhFvg			
2						
3						
4						
5	Time	Date	Data 0	Data 1	Data 2	Checksum
6	10:58:53	07/12/2017	00000	00000	00000	slM7WQ
7	10:58:53	07/12/2017	00000	00000	00000	q0gKGA
8	10:58:53	07/12/2017	00000	00000	00000	LNAW1w
9	10:58:53	07/12/2017	00000	00000	00000	Ncsnlg
10	10:58:53	07/12/2017	00000	00000	00000	GHqrLw
11	10:58:53	07/12/2017	00000	00000	00000	AWGabg
12	10:58:53	07/12/2017	00000	00000	00000	KkzJrQ
13	10:58:54	07/12/2017	00000	00000	00000	Fbq98A
14	10:58:54	07/12/2017	00000	00000	00000	VvsrNw
15	10:58:54	07/12/2017	00000	00000	00000	Q+Aadg
16	10:58:54	07/12/2017	00000	00000	00000	aM1JtQ
17	10:58:54	07/12/2017	00000	00000	00000	cdZ49A
18	10:58:54	07/12/2017	00000	00000	00000	9k5kOw
19	10:58:54	07/12/2017	00000	00000	00000	71VVeg
20	10:58:54	07/12/2017	00000	00000	00000	LCJB3Q
21	10:58:54	07/12/2017	00000	00000	00000	NTlwnA
22	10:58:54	07/12/2017	00000	00000	00000	HhQjXw
23	10:58:55	07/12/2017	00000	00000	00000	Tua/AQ

If the data has been tampered with, for example, eRecordViewer detects that the Checksum of the data in the 8th column of the file does not match, it will display **“Verified fail records: {1}”**. The number in the braces is the total number of error data.

Electronic Record Viewer

File Window

H0001_Date-2017-07-12_Time-10-59-22.csv.txt

Verified fail records: {1}

	1	2	3	4	5	6
1	HISTORY V1.0	6	mlhFvg			
2						
3						
4						
5	Time	Date	Data 0	Data 1	Data 2	Checksum
6	10:58:53	07/12/2017	0	0	0	slM7WQ
7	10:58:53	07/12/2017	0	0	0	q0gKGA
8	10:58:53	07/12/2017	5	0	0	LNAW1w
9	10:58:53	07/12/2017	0	0	0	Ncsnlg
10	10:58:53	07/12/2017	0	0	0	GHqrLw
11	10:58:53	07/12/2017	0	0	0	AWGabg
12	10:58:53	07/12/2017	0	0	0	KkzJrQ
13	10:58:54	07/12/2017	0	0	0	Fbq98A
14	10:58:54	07/12/2017	0	0	0	VvsrNw
15	10:58:54	07/12/2017	0	0	0	Q+Aadg
16	10:58:54	07/12/2017	0	0	0	aM1JtQ
17	10:58:54	07/12/2017	0	0	0	cdZ49A
18	10:58:54	07/12/2017	0	0	0	9k5kOw
19	10:58:54	07/12/2017	0	0	0	71VVeg
20	10:58:54	07/12/2017	0	0	0	LCJB3Q
21	10:58:54	07/12/2017	0	0	0	NTlwnA
22	10:58:54	07/12/2017	0	0	0	HhQjXw
23	10:58:55	07/12/2017	0	0	0	Tua/AQ

You can also save the electronic records as PDF files through eRecordViewer and print them.


Device Communication

The **Device Communication** function is used for configuring the related setting of communication between the HMI and devices, including COM Port, Ethernet, and other interfaces.

This section describes the parameter settings for each communication interface.

COM Port

The following table lists the functions in the COM Port setting page with the description.



Device Communication

1 ☒ Connection

Link Name

Manufacturers

Series

Multi-Drop

Main Extra

2 Communication Parameters

HMI Station

Interface

Data Bits

Stop Bits

Baud Rate

Parity Bits

Controller

PLC Station

Password

Comm. Delay Time(ms)

Connection Timeout(ms)

Connect Retries

For COMMGR Communication Simulation

☒ Optimize


☐ Disconnect after communication interrupt Retry times after disconnection

OK Cancel Apply

1 Connection

- The settings of COM Port are only available when **Connection** is selected.

- You can customize the **Link Name** and select the device to connect.
- If **Connection** is unselected, DIAScreen detects whether the current connection is being used. If so, a warning message appears, and the **Address List** dialog displays. In the **Address List** dialog, you can choose to change the address to another connection or **Clear Address**.



2 Communication Parameters


Function	Description			
HMI Station	Select or enter the HMI station ID. The range value is 1–255 and the default value is 0 .			
Interface	Select the communication interface (transmission method). The available options are RS232, RS422, and RS485. For COM1, only RS232 can be selected; for COM2 and COM3, RS232, RS422, and RS485 can be selected.			
		COM1	COM2	COM3
	RS232	V	V	V
	RS422	-	V	V
	RS485	-	V	V
Data Bits	Select the length of the received data packet.			

Function	Description
Stop Bits	Select the stop bits that inform the receiver of the end of the data signal.
Baud Rate	Select the data transmission speed.
Parity Bits	Select the parity bits. It is used to check for errors in the transmitted data. The available options are None, Odd, Even, Mark, and Space.

For other parameter settings, see [Common Properties](#).


Ethernet Port


The following table lists the functions in the Ethernet Port setting page with the description.



Device

1 Device

- Click  to add a link device named EtherLink1. The **Link Name** EtherLink1 can be changed according to your need.
- Up to 16 links are supported for each controller, and up to 4 types of controllers are supported for one network port.




2 Communication Parameters

Function	Description
HMI Station	Select or enter the HMI station ID. The range value is 1–255 and the default value is 0.
Controller IP	Set the IP address of controller. Note: The controller IP address must be set in the same network segment as the HMI IP address.
COM Port	Select or enter the communication port. You can also set it corresponding to the controller's port. Note: The COM Port varies depending on the selected controller.

For the descriptions of the **Main** tab, see [Common Properties](#).

Localhost



Device Communication

Device: Localhost

Localhost

☒ Overwrite IP

☐ Obtain an IP address automatically

HMI IP Address: 0 . 0 . 0 . 1

Subnet Mask: 255 . 255 . 255 . 0

Gateway IP: 0 . 0 . 0 . 0

DNS Server IP Address: 0 . 0 . 0 . 0

☐ Disconnect after communication interrupt

3 Retry times after disconnection


OK Cancel Apply

Function	Description
Overwrite IP	<ul style="list-style-type: none"> If selected, the network IP address of the HMI is written according to the screen file settings when DIAScreen downloads the project or updates the screen file. If not selected, the network IP address does not change due to project download and screen file updates. Go to System Menu > System Setting > Network on the HMI to change its IP address.
Obtain an IP address automatically	<ul style="list-style-type: none"> This setting is only available when Overwrite IP is selected. If Obtain an IP address automatically is selected, the HMI uses the DHCP mode to get the IP address.
HMI IP address	<p>Set the IP address of the HMI. If Obtain an IP address automatically is not selected, the fixed IP address can be set.</p> <p>Note: The HMI IP address must be set in the same network segment as the controller IP address.</p>

Function	Description												
Subnet Mask	Set the subnet mask. The subnet mask is used to segment the network and identify the destination address. It has the same format as the IP address, which is represented by four bytes separated by decimal points.												
	<table><tr><th>IP Class</th><th>Network Address</th><th>Subnet Mask</th></tr><tr><td>Class A</td><td>1.x.x.x~126.x.x.x</td><td>255.0.0.0</td></tr><tr><td>Class B</td><td>128.0.x.x~191.255.x.x</td><td>255.255.0.0</td></tr><tr><td>Class C</td><td>192.0.0.x~223.255.255.x</td><td>255.255.255.0</td></tr></table>	IP Class	Network Address	Subnet Mask	Class A	1.x.x.x~126.x.x.x	255.0.0.0	Class B	128.0.x.x~191.255.x.x	255.255.0.0	Class C	192.0.0.x~223.255.255.x	255.255.255.0
	IP Class	Network Address	Subnet Mask										
	Class A	1.x.x.x~126.x.x.x	255.0.0.0										
	Class B	128.0.x.x~191.255.x.x	255.255.0.0										
	Class C	192.0.0.x~223.255.255.x	255.255.255.0										
Subnet Mask must be set when the IP address is set on each computer. For Class C in the table above, the first 3 bytes of the IP address are Network ID. Therefore, the first 3 bytes of the Subnet Mask are all 255. The last byte is the Host ID, which is 0.													

Device

Set the connection parameters between HMI and external devices.



Device Communication

Device list

00-Barcode scanner

Detail

Device interface: USB

Read length: 512

Terminator:

- ☐ None
- ☒ CR/LF (0x0D or 0x0A)
- ☐ STX (0x02)
- ☐ ETX (0x03)
- ☐ STX/ETX (0x02 or 0x03)
- ☐ Other: 0x0 Hex (0~0xFF)


Timeout(s): 1.0 (0.1~30.0s)

☐ Disconnect after communication interrupt

3 Retry times after disconnection

OK Cancel Apply

1 Device list

- A USB device has been added by default and cannot be deleted.
- Click  to add a COM Port device. When all COM Ports are occupied, new devices cannot be added.

Note: The device name is defaulted as Barcode scanner and cannot be changed.

2 Detail

Function	Description
Device interface	<ul style="list-style-type: none"> • The default interface is USB. • After adding a device, select an unoccupied COM Port.
Communication Parameter	<ul style="list-style-type: none"> • This setting is only available when using a COM Port device. • This setting is the same as that of COM Port.
Read length	Select or enter the string length (not including the terminator) for reading data. The range value is 10–1024.
Terminator	Choose the terminator. The available options are None (No Terminator), CR/LF, STX, ETX, STX/ETX, and Other. Note: Other is custom hexadecimal encoding, and the range value is 0X00~0XFF.
Timeout	Enter the time interval between scanning and reading the first character and the terminator. The range value is 0.1–30.0.

Note: For the reading setting of the external devices, see the content of **Internal Parameter > Input Device** in the [Address Settings](#).

Common Properties

Controller Settings

Function	Description
PLC Station	PLC Station is the default station ID generated automatically after selecting the controller and can be changed. The range value is 0–255.
Password	Enter the password. If the set PLC requires a password check, you must set the corresponding password for communication in the software. The default value is 12345678 .

Function	Description
Comm. Delay Time	Select or enter the time interval between each communication. The range value is 0–255 and the default value is 0 .
Connection Timeout	Select or enter the connection timeout that HMI communicates with the device. The range value is 10–2000 and the default value is 1000 .
Connect Retries	Select or enter the retries. If the controller fails to respond to the communication, the HMI sends the communication command again. If reaching the set number of retries, the HMI displays a warning message of abnormal communication. The range value is 0–15 and the default value is 2 .
Optimize	<ul style="list-style-type: none"> If selected, the process of reading the address of all elements referring to this link gets optimized to facilitate communication. If unselected, the speed for reading the elements becomes slow.
For COMMGR Communication Simulation	Select the simulator driver configured in COMMGR to communicate with COMMGR simulator through the Off-line Simulation function. Note: Download and install COMMGR in DIAInstaller.

Disconnect after communication interrupt

- If **Disconnect after communication interrupt** is selected, **Connect Retries** can be set. When the communication is interrupted and the set **Connect Retries** is reached, the HMI will no longer connect with the controller. The range value of **Connect Retries** is 0–255 and the default value is **3**.
- When the communication between the HMI and controller stops due to reaching the **Connect Retries**, use Bit 0 in the **Control Block** to enable / disable the communication to restore the connection.

Configuration

- Main
 - Non-volatile
 - Security Level and Password
 - Global Keypad Settings
 - System Setting
 - Screensaver Setup
 - Others
- Control Status Block
 - Control Block
 - Status Block
- Real Time Clock
- Print
- Default
 - Element Default Value
 - Boot Logo
 - Boot Delay Screen
 - Custom Scroll Button
- Network Settings
 - Remote Desktop and Data Collection
 - SMTP
 - FTP
 - MAC Settings
- Multi-language
 - Multi-language Settings
- Industry Application
 - Electronic Record

Control Block

☒ Use discontinuous address in Control Block

Start Address None

☐ Screen No. ...

☒ General Control \$0

☐ Curve Control

☐ History Buffer Sampling

☐ History Buffer Cleaning

☐ Recipe Control

☐ Recipe Group Number

☐ System Control ...

☐ Enhanced Recipe Control ...

☐ Enhanced Recipe Group Number ...

Sampling Cycle 300 (ms)

Bit 0	Enable/disable communication
Bit 1	Enable/disable backlight
Bit 2	Enable/disable buzzer
Bit 3	Clear alarm buffer
Bit 4	Clear alarm counter
Bit 5	Write to external storage immediately
Bit 6	Lock remote monitoring operation
Bit 8-11	Set user level

OK


Cancel

Custom Confirmation Window Screen

DIAScreen supports the Confirmation Window Screen function. You can customize the confirmation window according to your needs.

Follow the steps to customize the confirmation window.


1. Do one of the following:
 - On the toolbar, click **General > New Screen > Confirmation Window Screen**.
 - Right-click the blank space of the **Screen Management Window** and select **New Screen**, select **Confirmation Window Screen** for **Screen Type**.



The confirmation window screen is created.

2. Create a **Goto Screen** element and double-click the element.
3. In the property window of the element, select **Custom** for **Confirmation Window** in the **Operating conds.** tab.

After downloading the screen to the HMI, the custom **Confirm Window** displays when you click the element on the HMI.




User Login Screen


This section describes different types of user login screen which includes **Login/Logout Screen**, **Add/Delete User Account Screen**, and **Change Password Screen**.

Login/Logout Screen


You can use this screen to log in / log out the user account.

To log in / log out the user account

1. Create a Login/Logout Screen. Do one of the following:
 - On the toolbar, click **General > New Screen > User Login Screen > Login/Logout Screen**.
 - Right-click the blank space on the **Screen Management Window** and select **New Screen**, and then select **Login/Logout Screen** for **Screen Type**.
2. Trigger the Login/Logout Screen. You can:
 - Set the **User Security Level** in the **User Security Level** tab of the element property dialog and click  to select the created Login/Logout Screen.
 - In the **Security Level and Password** setting page of the **Configuration** dialog, set the security level and the **Login/Logout Screen** to be triggered by this level.




If **User Security Level** of the element is set as 2 and **Custom User Login Screen** is set as None, the **Screen2** login screen is triggered after pressing the element on the HMI.



Note:

- The **Configuration** setting is Global setting, and the **Element** setting is Local setting. When different login screens are triggered if they have the same level, the login screen set in the element will take priority.



Configuration

- Main
 - Non-volatile
 - Security Level and Password**
 - Global Keypad Settings
 - System Setting
 - Screensaver Setup
 - Others
 - Control Status Block
 - Control Block
 - Status Block
 - Real Time Clock
 - Print
 - Default
 - Element Default Value
 - Boot Logo
 - Boot Delay Screen
 - Custom Scroll Button
 - Network Settings
 - Remote Desktop and Data Collection
 - SMTTP
 - FTP
 - MAC Settings
 - Multi-language
 - Multi-language Settings
 - Industry Application
 - Electronic Record

Security Level and Password

Security Management

Highest security password: 12345678

☐ Complex password

Default startup security level: 0

☐ Check password when downloading program

☐ Screen upload prohibited

☐ Prompt a reminder for insufficient security level

☐ Don't show password input window when the security level is insufficient.

☐ Restrict high account function ☐ Hide password only

☐ Complex password (must include one uppercase letter, one lowercase letter, number, symbol !, \$, #, %, >=8 letters)

☐ Limit the times of updating screens via USB drive

Login / logout

☐ Logout when time out

Minutes before reset to default boot permissions: 10

☐ Account disabled after login failed

Number of consecutive failed retries: 5

☐ The first login of the component does not execute in

☐ Change password on first login

Password Keypad

Default Keypad: [Dropdown]


Account and Password

0 [Dropdown] [Dropdown] [Dropdown]

User Login Screen: Screen_2

Number	Account	Password	User duration(0~9999 Day)	Password duration(0~9999)
1	00	00000000	0	0

OK Cancel



Set to On

Preview

State: 0

Language: Language1

Element Description: Set to On_002

Automatically resized based: Yes

Margin: 0

Main **Style** **Text** **Picture** **Operating conds.** **User Security Level** **Macro**

User Security Level


User Security Level: 2

Set Low Security: No

Custom User Login Screen: Screen_3

OK Cancel

- Since the highest security does not require an account setup, if the **Security Login** checkbox is selected, the **User Account** and **User Account Status** are disabled and not available for selection.




Add/Delete User Account Screen

You can use this screen to quickly add / delete the user account.

To add / delete the user account

1. Create an Add/Delete User Account Screen. Do one of the following:
 - On the toolbar, click **General > New Screen > User Login Screen > Add/Delete User Account Screen**.
 - Right-click the blank space on the **Screen Management Window** and select **New Screen**, and then select **Login/Logout Screen** for **Screen Type**.
2. Create a **Goto Screen** element on the screen.
3. In the element property dialog, set **Add/Delete User Account Screen** for **Goto Screen** in the **Main** tab.
4. After downloading the screen to the HMI, press the **Goto Screen** element on the HMI, and then log in the security level account.




5. Enter the **User Account**, **User Password**, and **User Level**, and then you can:

- Press **Add** to add the account.

The user account is successfully added.



Note: Only the accounts below the login level can be added. If accounts of the same level are added, the **Add Status** displays **Fail**.



Add User Account / Delete User Account

User Account: PP

User Password: **

User Level: 7


Current User Level: 7

Add Status / Delete Status: Fail /

Add Delete

- Press **Delete** to delete the account.

The user account is successfully deleted.



Add User Account / Delete User Account

User Account: 33

User Password:

User Level: 7

Current User Level: 7

Add Status / Delete Status: Fail / Success


Add Delete

Change Password Screen

You can use this screen to change the user password.

To change the user password

1. Create a Change Password Screen. Do one of the following:
 - On the toolbar, click **General > New Screen > User Login Screen > Change Password Screen**.
 - Right-click the blank space on the **Screen Management Window** and select **New Screen**, and then select **Change Password Screen** for **Screen Type**.
2. Create a **Goto Screen** element on the screen.
3. In the element property dialog, set **Add/Delete User Account Screen** for **Goto Screen** in the **Main** tab.
4. After downloading the screen to the HMI, press the **Goto Screen** element on the HMI, and then log in the security level account.



5. Select the **User Account** and enter the new password, and then press **Change Password**.

Note: Only the passwords for accounts below or equal to the login level can be changed.

Change Password

User Account:

33 (Level 3)

Set New Password:

Change Password Status:

Success

Current User Level:

3

User Account Status:

Unexpired


Change Password

Compile

DIAScreen provides the compiling function for convenient operation and use.

Compile

If only one screen among several screens is edited, you can use the **Compile** function to compile only that screen to save compilation time.



How to use the **Compile** function?


- Click **Project > Compile** on the menu bar.

Or

- Press **Ctrl + F7**.

Compile All

Use the **Compile All** function to compile all screens. If an error occurs during compilation, an error messages will be displayed in the **Output** pane to remind users. Click the message to link to the element with the error.



Download All Data

Use the **Download All Data** function to download the screen data and recipe to the HMI.


How to use the **Download All Data** function?



- Click **Project > Download All** on the menu bar.

Or

- Press **Ctrl + F8**.

When downloading all data, the software will detect the connection between the HMI and the computer. If the transmission interface between the HMI and the computer is not turned on, an error message will appear. The following table lists the check items with their description.

Check Item	Description
USB Tunnel	USB is turned on incorrectly. 

Check Item	Description
	<p>During the download process, the transmission line is unplugged, or the communication is interrupted.</p> 
Model Setting	<p>The HMI model is set incorrectly.</p> 

Note: Perform the DIAScreen uploading and downloading on an authorized HMI.

Download Screen

The **Download Screen** function downloads only screen data. Refer to [Download All Data](#) for the download method.

How to use the **Download Screen** function?


- Click **Project > Download All** on the menu bar.

Or


- Press **Ctrl + F9**.

Upload All Data


When uploading all data, the software asks you to enter a password. The password entered here is the system default password **12345678**. To set a password, go to **General > Configuration > Security Level and Password**.




After entering the password, save the screen file to upload.



After saving the file, the screen data starts to upload. You can click **Stop** to stop uploading the screen data.




Besides uploading screen data, you can also go to **General > Environment** to set whether to include picture data.



On-line Simulation

Use the **On-line Simulation** function to simulate the computer as an HMI and communicate with the controller through the computer's COM port. If the communication is normal, the computer can be used as an HMI for actual operation.




How to use the **On-line Simulation** function?

- Click **Project > On-line Simulation**.


Or

- Press **Ctrl + F4** °

When performing an online simulation, the software will first compile and check whether the screen for errors. Then set the COM port number of the compute. The HMI will communicate with the controller if the setting is correct.




In the **COM Port Setting** dialog, if the **Ask me every time** checkbox is selected, this dialog displays every time you perform an online simulation. If unselected, the dialog will not display. You can right-click the blank space on the online mode screen and select **COM Setting** to open this dialog again.



Online simulation also provides a monitoring function. Right-click the blank space on the screen and select **Monitor IO**. After setting the monitoring address, you can monitor the content value of the IO device.


The following table lists the setting in the **IO Monitor** dialog with their description.




Setting	Description
New item	Click to add the address to monitor in the Input dialog.
New blank	Click to add a new item row, and you can directly enter the monitor address in the Device Addr. field.
Delete item	Click to delete the selected monitor address.
Start Monitor	Click to start monitoring the device.
Stop Monitor	Click to stop monitoring the device.
Device Addr.	Set the internal memory or controller register address.
Device Value	Enter the content value of the internal address or controller register. You can also change the content value of the device in real-time. Note: The Length setting is not required if you are using a Delta controller.
Value Format	Select the value format.

The following describes the operation example of **Monitor IO**.

1. Create 2 **Numeric Entry** elements on the screen, and then set the **Write Address** to **\$500** and **{Link2}2@D100** respectively.
2. Click **Project > On-line Simulation** on the menu bar.
3. On the online simulation screen, right-click the bank space and select **Monitor IO**.
4. Click **New Item** to add a monitor address in the **IO Monitor** dialog.
5. Set the monitor address to **{Link2}2@D100** in the **Input** dialog.




6. Repeat steps 1~2 to set another monitor address to **\$500**.



The **Input** dialog box is used to configure device parameters. It includes a **Link** dropdown menu set to **Internal Memory**. The **Type** section has four radio buttons: **PLC Device (Word)**, **PLC Device (Bit)**, **Internal Memory (Word)** (selected), and **Internal Memory (Bit)**. The **PLC Station Number** section has a numeric input set to **0** and a **Default** checkbox. The **Detail** section includes a **Device Type** dropdown set to **\$** and an **Address** input set to **500**. A numeric keypad is also present with buttons for digits 0-9, **Back**, **Clear**, **Enter**, and **None**.

7. Click **Start Monitor** to start monitoring the values of **{Link2}2@D100** and **\$500** in the **Device Value** field. You can also manually change device values.



The **DOP-100 Series IO Monitor** window displays a table of device values. On the left, two large digital displays show the values **123** and **55**. Callout boxes indicate that **123** corresponds to **D100** and **55** corresponds to **\$500**. The table in the window is as follows:

Device Addr.	Device Value	Value Format
{Link2}1@D100	123	Unsigned Decimal
\$500	55	Unsigned Decimal

On the right side of the window, there are three buttons: **New item**, **New blank**, and **Delete item**.

Off-line Simulation

Use the **Off-line Simulation** function to check whether the edited screen, the read and write memory address, and the Marco are correct. No communication with the controller is required.


How to use the **Off-line Simulation** function?

- Click **Project > On-line Simulation**.

Or

- Press **Ctrl + F5**.

When performing an offline simulation, the software will first compile the screen and then enter the offline mode screen.




Language Management

Language Management provides **Import / Export Multi-language Text** and **Copy Multi-language Text** functions, allowing you to quickly edit multi-language text in the project with multiple languages and states.


Multi-language Configuration

Follow these steps to configure multi-language.

To configure multi-language

1. In the **Project** pane, double-click **Multi-language**.
2. In the **Multi-language** setting page, click  to add a language.
3. Configure languages according to your needs.

In the **Text** tab in the property dialog of the element, you can view the language configuration of each state.



State	Chinese	English
0		
1		

Export Multi-language Text

With the **Export Multi-language Text** function, you can export the element that multiple-language can be configured in the project as a file and edit.

Follow these steps to export multi-language text.

To export multi-language text

1. Create an element on the screen and configure its multi-language.
2. Click **Project > Language Management > Export Multi-language Text** on the toolbar.

The multi-language content of all elements in the current project is exported as a file.

	F	G	H
1	English	繁中	简中
2	Manual	手動	手动
3	28	40	16
4	Arial	Arial	Arial
5	Auto Range	自動量程	自动量程
6	28	16	16
7	Arial	Arial	Arial
8	Time to heat	加熱時間	加热时间
9	28	16	16
10	Arial	Arial	Arial
11	Time to cool	冷卻時間	冷却时间
12	28	16	16
13	Arial	Arial	Arial
14	Auto	自動	自动
15	28	16	16
16	Arial	Arial	Arial
17	Multistate_015	Multistate_015	Multistate_015

Export Multi-language Text (excluding element font settings)

With the **Export Multi-language Text (excluding element font settings)** function, the file size can be reduced when exporting / importing multiple-language text. The exported file only contains element description and multi-language content.

Follow these steps to export multi-language text excluding element font settings.

To export multi-language text excluding element font settings

1. Create an element on the screen and configure its multi-language.
2. Click **Project > Language Management > Export Multi-language Text (excluding element font settings)** on the toolbar.

The multi-language content (excluding font settings) for all elements in the current project is exported.

	F	G	H
1	English	繁中	简中
2	Manual	手動	手动
3	Auto Range	自動量程	自动量程
4	Time to heat	加熱時間	加热时间
5	Time to cool	冷卻時間	冷却时间
6	Auto	自動	自动
7	Multistate_015	Multistate_015	Multistate_015

Import Multi-language Text

After importing the multi-language text file, check whether the edited data has been imported completely.

To import multi-language text file

- Click **Project > Language Management > Import Multi-language Text** on the toolbar.

The following table lists the state before import and after import.


State	Chinese	English
Before Import	\$0.0	
After Import	設ON按鈕	ON Button


Copy Multi-Language Font

The **Copy Multi-Language Font** function helps you quickly apply the font settings of the existing language to the imported language.

Follow these steps to copy multi-language font.

To copy multi-language font

1. In the **Project** pane, double-click **Multi-language**.
2. In the **Multi-language** setting page, click  to add a language.



3. Edit the screen in the first language and click **Project > Language Management > Export Multi-language Text** on the toolbar to export the language settings as an Excel file.
4. Edit the text content of each language in the Excel file and save,
5. Click **Project > Language Management > Import Multi-language Text** on the toolbar to update the edited content to the project.
6. Click **Project > Language Management > Copy Multi-Language Font** on the toolbar.
7. In the **Copy Language Font Setting** dialog, select the **Source Language** and **Target Language**, and then click **OK**.





The font settings of the source language are applied to the target language.

Note:

- If there is only one language in the project, the **Copy Multi-Language Font** function is not available.

- If a text bank is applied in the element, the font settings will not be applied to the element after executing the **Copy Multi-Language Font** function.

The following table lists the execution result.



State	Result	
Before Execution		
After Execution		

Font Template

DIAScreen provides a wide range of fonts. To save users' time in selecting fonts, DIAScreen provides font templates to help users to customize frequently used font settings that improve the efficiency of screen design.

Follow the steps to set the font templates.


To set the font templates

1. On the toolbar, click **General > Font > Import font template** .
2. In the **Font Template** dialog, click  to add a new font template in **Font Template List**, and set the font, size, style, and color in **Font Template Settings**.
3. Click **Change** to save the font template.
4. Create an element and double-click it.
5. In the property dialog of the element, click **Import Font Template** in the **Text** tab.
6. In the **Font Template** dialog, select the desired font template, and then click **Import Template (all settings)** or **Only Import Font and Size** according to your needs.






The font settings are imported to the text of the selected status.

Note: Font template settings are stored in the computer with DIAScreen installed. The same set of font template settings can be used when opening different projects on the same computer.

The following table lists the settings in the **Font Template** dialog and their descriptions.



1 Font Template List

Setting	Description																																																						
	Click to add the font template. You can configure up to 100 templates.																																																						
	Select the template and click this icon to delete.																																																						
	Click to import the font template.																																																						
	Click to export the template as a .xlsx file. The following displays the format content of the font template. <table border="1"><thead><tr><th></th><th>A</th><th>B</th><th>C</th><th>D</th><th>E</th><th>F</th><th>G</th><th>H</th></tr></thead><tbody><tr><td>1</td><td>Description</td><td>UseBMPTText</td><td>FontName</td><td>FontSize</td><td>Blod</td><td>Italic</td><td>Underline</td><td>FontColor</td></tr><tr><td>2</td><td>字型1</td><td>1</td><td>Kristen ITC</td><td>24</td><td>1</td><td>1</td><td>1</td><td>RGB(255, 0, 0)</td></tr><tr><td>3</td><td>FontA</td><td>0</td><td>Arial Black</td><td>22</td><td>0</td><td>1</td><td>0</td><td>RGB(0, 128, 255)</td></tr><tr><td>4</td><td>字型B</td><td>0</td><td>Wide Latin</td><td>28</td><td>1</td><td>0</td><td>0</td><td>RGB(0, 255, 64)</td></tr><tr><td>5</td><td>Template_Test</td><td>0</td><td>微軟正黑體</td><td>20</td><td>1</td><td>1</td><td>1</td><td>RGB(255, 0, 255)</td></tr></tbody></table>		A	B	C	D	E	F	G	H	1	Description	UseBMPTText	FontName	FontSize	Blod	Italic	Underline	FontColor	2	字型1	1	Kristen ITC	24	1	1	1	RGB(255, 0, 0)	3	FontA	0	Arial Black	22	0	1	0	RGB(0, 128, 255)	4	字型B	0	Wide Latin	28	1	0	0	RGB(0, 255, 64)	5	Template_Test	0	微軟正黑體	20	1	1	1	RGB(255, 0, 255)
	A	B	C	D	E	F	G	H																																															
1	Description	UseBMPTText	FontName	FontSize	Blod	Italic	Underline	FontColor																																															
2	字型1	1	Kristen ITC	24	1	1	1	RGB(255, 0, 0)																																															
3	FontA	0	Arial Black	22	0	1	0	RGB(0, 128, 255)																																															
4	字型B	0	Wide Latin	28	1	0	0	RGB(0, 255, 64)																																															
5	Template_Test	0	微軟正黑體	20	1	1	1	RGB(255, 0, 255)																																															
	Click to clear all font templates.																																																						

2 Font Template Settings

Setting	Description
Description	Set the description of the font template.
Text Bitmap / Font	Choose to display a text in bitmap or font.
Font setting	Set the font, size, style, and color of a text.
Preview	Preview the effect of font template settings.

MODBUS TCP/COM Mapping Table

Delta HMI can be used as a Modbus Slave for external Modbus Server devices to transmit data. Modbus communication supports TCP/IP and Serial Port connections. You can configure the HMI address to the corresponding Modbus address through **Modbus TCP/COM mapping table** function.

How to open **Modbus TCP/COM mapping table**?

- On the toolbar, click **Project > Other Settings > Modbus TCP/COM mapping table**.

The following table lists the Modbus range limitation of TCP/IP and COM connection.

Connection	Data Type	Maximum Length	Modbus Range
TCP/IP	Coils	65536	00001(0x0000) ~ 65536(0xFFFF)
	Registers	65536	00001(0x0000) ~ 65536(0xFFFF)
COM	Coils	2048	00001(0x0000) ~ 02048(0x07FF)
	Registers	20000	40001(0xA410) ~ 60000(0xEA5F)

The following describes the setting methods of Modbus Slave (TCP/IP) and Modbus Slave (COM).

- Modbus Slave (TCP/IP)**


HMI with Ethernet ports will have the Modbus Slave function enabled by default. You can configure the Modbus address corresponding to the HMI address through the **Modbus TCP/COM mapping table**.

Example Settings


- In the **Modbus TCP/COM mapping table**, configure the mapping table.
 - Set the HMI address to \$4000.0, corresponding to the Modbus address of **Coils** function code 0x00000.
 - Set the HMI address to \$5000, corresponding to the Modbus address of **Registers** function code 0x00000.

2. Create elements on the screen and set the HMI address corresponding to Modbus, and then download the project to the HMI.

The Modbus Master device is connected with TCP/IP and set connected HMI IP. Change values of elements on the HMI, and the HMI transmits data through Modbus.



The following figure shows the result that **Modbus Poll** is used as the Modbus Master and communicated with the HMI.




- **Modbus Slave (COM)**

Follow the steps to set the **Modbus Slave (COM)** mapping.

1. In the **Communication Settings** dialog, select **COM2**.

2. Select **Modbus** for **Manufacturers** and **RTU (Slave)** for **Series** to perform the Modbus communication of Serial Port.
3. In the **Modbus TCP/COM mapping table**, click **Modbus Slave (COM)** to configure the corresponding relationship between the HMI address and Modbus address.

Example Settings



1. In the **Modbus TCP/COM mapping table**, configure the mapping table.
 - Set the HMI address to \$2000.0, corresponding to the Modbus address of **Coils** function code 00001.
 - Set the HMI address to \$0, corresponding to the Modbus address of **Registers** function code 40001.
2. Create elements on the screen and set the HMI address corresponding to Modbus, and then download the project to the HMI.

The Modbus Master device is connected through the Serial Port. Change values of elements on the HMI, and the HMI transmits data through Modbus.


The following figure shows the result that **Modbus Poll** is used as the Modbus Master and communicated with the HMI.

COM

\$2000.0

\$0

11	22	33	44
55	66	77	88



Mbpoll1

Tx = 4404: Err = 7: ID = 1: F = 01: SR = 1000ms
Function = Coils

	Name	00000
0		0
1		1
2		0
3		1
4		0
5		1
6		0
7		1
8		
9		

Mbpoll2

Tx = 4413: Err = 7: ID = 1: F = 03: SR = 1000ms
Function = Registers

	Name	00000
0		11
1		22
2		33
3		44
4		55
5		66
6		77
7		88
8		
9		

DIAScreen V1.6.0

164

EIP Data Exchange Table

The HMI supports Ethernet / IP connection. You can import EDS (Electronic Datasheet) files or manually enter CIP parameters to establish connection data, and configure the data exchange between the HMI internal memory and network devices through the data exchange table.









Note:

- Only available for DOP-300 series HMI.
- A maximum of 6 data exchange tables are supported and the same device supports up to 4 data exchange tables.


How to open the **EIP Data Exchange Table** configuration page?

- In the **Project** pane, double-click the EIP Data Exchange Table.

The following table lists the settings on the toolbar in the **EIP Data Exchange Table** configuration page and their descriptions.

Setting	Description
	Import the EDS file of the connected device and set the connection parameters.
	Manually add an EIP device. Establish a device for connection by entering CIP parameters.
	After adding an EIP device, click this icon to add a data exchange table.
	After selecting one row of the data exchange table, click this icon to edit the connection parameters.
	After selecting one row of the data exchange table, click this icon to copy the selected row.
	After selecting one row of the data exchange table, click this icon to delete the selected row.
	Click to delete all data exchange tables.
	Click to open the Device List dialog. In the Device List dialog, select the newly added or imported EIP devices to delete. Note: When a device is deleted, its corresponding data exchange table is also deleted.

The following table lists each field setting in the **EIP Data Exchange Table** configuration page and their descriptions.



No.	Enable	Device Name	IP Address	Internal Memory	HMI Read/Write	Size(Bytes)
1	<input checked="" type="checkbox"/>	AS300N	192.168.1.1	\$0	Read	200
				\$100	Write	200

Setting	Description
No.	Displays the line numbers of the data exchange table.
Enable	Select to enable the data exchange of the row. If not selected, the data exchange configuration will not be loaded to the HMI.
Device Name	Select the name of the connected device. This name is defined in an EDS file or when you manually add an EIP device.
IP Address	Displays the IP address of the connected device. It can be configured in the Connection Setup dialog. Note: The same IP cannot be set for different devices.
Internal Memory	Set the internal memory address of the HMI for data exchange. Note: The read / write addresses of the same data exchange table cannot be the same.
HMI Read / Write	Displays the read / write mark for the HMI.
Size (Bytes)	Displays the size of data exchange. It can be configured in the Connection Setup dialog.

The following table lists the settings in the **Connection Setup** dialog of the device imported through EDS and their descriptions.

AS300 Series - Connection Setup

1 Connection Name: IP Address: Port: (1-65535)

2 General Parameter

Connection Path: Trigger Type: RPI (ms): (5-1000 ms) Transport type: Timeout:

3 HMI Load(T->O)

Load Size: (0-200 Bytes) HMI Write(O->T)

Write Size: (0-200 Bytes) Target Data Config: Data Config Setup:

Connection Type: Connected Type: Connect Priority: Transform Type:

4 Electronic Key

Enable: Prod Type: Major Version: Vendor ID: Electronic Code: Minor Version:


1 Connection settings

Setting	Description
Connection Name	Select the name of the connected device for data exchange. Note: When the same IP address is set for the same device, the same connection name cannot be selected.
IP Address	Enter the IP address of the device.
Port	Enter the device port. The range value is 1–65525, and the default value is 44818.

2 General Parameters

Setting	Description
Connection Path	Displays the connection path.
Trigger Type	Select the trigger type of the connection.
Transport Type	This setting is available only when you manually add an EIP.
RPI (ms)	Enter the RPI of the connection. The range value is 5–1000, and the default value is 20.
Timeout	Select a timeout for the connection. The default value is 4.


3 HMI Read / Write

Setting	Description
Load Size	Enter the read size. The range value is 0–200 (bytes), and the default value is 200 (bytes).
Write Size	Enter the write size. The range value is 0–200 (bytes), and the default value is 200 (bytes).
Tar Configuration Size	The setting is not available.
Configuration Setup	<p>Click Setup to configure the connection data of the target device. In the Data Configuration dialog, set the data parameters in the Value field.</p> 
Connection Type	The setting is not available.
Connection Priority	The setting is not available.
Transform Type	The setting is not available.

4 Electronic Key

Setting	Description
Enable	<p>Select the items to match.</p> <p>Note: The parameter setting of the electronic key is available when you select the Enable checkbox in the Enable field.</p>

The following table lists the settings in the **Connection Setup** dialog by manually establishing an EIP device and their descriptions.



The screenshot shows the 'Connection Setup' dialog box with the following sections and annotations:

- 1 Connection settings:** Device Name (General Device), IP Address (192.168.1.1), Port (44818).
- 2 Path Setup:** Auto Gen Path (selected), Path Combin (checked), Assem Consume (checked), Assem Product (checked), User Define Path (unselected).
- 3 General Parameter:** Connection Path (20 04 24 00 2C 00 2C 00), Trigger Type (Cycle), RPI (10), Transportation Type (Rack Connector), Timeout (4).
- 4 HMI Read/Write:** HMI Read (Load Size: 200), HMI Write (Write Size: 200, Tar Configuration Size: 16), Connection Type (Point to Point), Connection Priority (Reserve), Transportation Type (Pure Data).
- 5 Electronic Key:** Enable (Enable), Product Type (1), Major Version (1), Vendor ID (1), Vendor Code (1), Minor Version (1).

1 Connection settings

Setting	Description
Device Name	Enter the name of the device.
IP Address	Enter the IP address of the device.
Port	Enter the device port. The range value is 1–65525, and the default value is 44818.

2 Path Setup

Setting	Description
Auto Gen Path	Enter the CIP parameters, and the Connection Path will be automatically generated according to the set parameters.
User Define Path	Define the Connection Path in the General Parameter area.

3 General Parameter

Setting	Description
Connection Path	This setting is available only when the User Define Path is selected.
Trigger Type	Select the trigger type of the connection.
Transportation Type	Select the transportation type of the connection.
RPI (ms)	Enter the RPI of the connection. The range value is 1–10000, and the default value is 10.
Timeout	Select a timeout for the connection. The default value is 4.

4 HMI Read / Write

Setting	Description
Load Size	Enter the read size. The range value is 0–200 (bytes), and the default value is 200 (bytes).
Write Size	Enter the write size. The range value is 0–200 (bytes), and the default value is 200 (bytes).
Tar Configuration Size	Enter the size of the target configuration. The range value is 0–400 (bytes), and the default value is 16 (bytes).
Configuration Setup	Click Setup to configure the connection data of the target device. In the Data Configuration dialog, set the data parameters in the Value field.
Connection Type	Select the connection type.
Connection Priority	Select a connection priority.
Transportation Type	Select the transportation format.

5 Electronic Key

Setting	Description
Enable	Select the items to match and enter the parameters. Note: The parameter setting of the electronic key is available when the Enable is selected in the Enable field.

Installment

The installment function allows customers to configure the device in stages by paying in installments to solve trial use and funding issues. A trial is also provided for customers. When the trial expires, it will lock the HMI screen to prevent further use.

Note:


- If external memory addresses, such as controller addresses, are used for the installment settings, it is important to ensure that the device is communicating properly and functioning correctly to avoid errors occurring when executing the installment function.
- The installment function does not support online simulation and offline simulation.

Follow these steps to set the installment.

To set the installment

1. Click **Project > Other Setting > Installment** on the toolbar.
2. Set the installment in the **Installment** dialog.

The following table lists the settings in the **Installment** dialog with the descriptions.



Installment

☐ Enable

Settings 1

☐ Customized Unlock Screen

Password Input Address: None

Installment Expiration Time: None

Installment Name Address: None

Unlock Trigger Address: None

Customer List 2

No.	Name
1	Customer1

Installment Settings 3

Administrator Password: •

☐ Enable installment time reminder

In advance: 0 (day)


Password mode: Use static password

Language: Language1



No.	Name	Time	Password
-----	------	------	----------

OK Cancel



1 Settings



Settings	Description
Customized Unlock Screen	If selected, the existing sub-screen is available for you to select which can be used as the unlock screen. You can also click  to add the example unlock screen.
Password Input Address	Set the password input address. Corresponding to the address set for the Character Entry element on the unlock screen.
Installment Name Address	Set the installment name address. <ul style="list-style-type: none"> Character Display element can be configured on the screen to show the name of the current unlocked installment. Corresponding to the address set for the Character Display elements on the unlock screen.
Installment Expiration Time	Set the installment expiration time address. <ul style="list-style-type: none"> Date Display, Time Display, and Weekday Display elements can be configured on the screen to show the time of the next installment. Corresponding to the address set for the Date Display, Time Display, and Weekday Display elements on the unlock screen.
Unlock Trigger Address	Set the unlock trigger address. Corresponding to the unlock button configured on the unlock screen.

2 Customer List

Settings	Description
	Click to add new customer. Up to 10 customers can be added and the names must not be the same. Select the customer number, the customer installment information will be applied when downloading the project.
	After selecting the customer number, click this icon to delete.

3 Installment Settings

Settings	Description
Administrator Password	Set the administrator password. Enter this password on the HMI to unlock all installments.
Enable installment time reminder	If selected, you can configure the number of days to set expiration reminders. The range value is 0–15 and the default value is 1 .
Password mode	<p>Select the password mode.</p> <ul style="list-style-type: none"> Select Use static password, the software will use a fixed password for each installment. Select Use variable password, you can set an internal memory address and customize the Password Length, making it easy to set the password through macros or LUA.
Installment HMI change trigger	<p>Set the HMI change trigger address to change the installment content on the HMI.</p> <ul style="list-style-type: none"> Trigger this address on the HMI and enter the installment setting manager password in the pop-up Password dialog.  <ul style="list-style-type: none"> Displays the Installment Settings dialog. Add / delete the installment setting in this dialog. 

Settings	Description
	Click to add a new installment, up to 32 installments can be added. Note: <ul style="list-style-type: none"> The installment name can only be entered in English. The installment password supports the characters 09, !, \$, #, %, a~z, and A~Z. For the same customer, the installment password cannot be the same (including the administrator password).
	Click to delete the selected installment(s).
Language	The installment name can be set to different languages with the Multi-language function.

Keep Installment Data when Downloading

With this function, the installment information will not be updated after downloading the screen and the installment unlock record on the HMI will not be cleared.

1. On the toolbar, click **General > Configuration**.
2. In the **Configuration** dialog, select **General > System Setting**, and then select **Keep Installment payment settings after screen download** checkbox.

Enable Next Installment

To unlock the installment before the set installment time arrives, click **Element > Button > Enable Next Installment**, on the toolbar and create the **Enable Next Installment** button to cancel the current installment settings.


The Remaining Time for the Current Installment

Follow these steps to set the remaining time for the current installment.


To set the remaining time for the current installment

1. Add a **Character Display** element on the screen.
2. Set the **Read Address** to "NEXT_INST_REMAIN_TIME" of Internal Parameter.

The HMI displays the remaining time until the next payment.




The following figure shows the effect of displaying the remaining time for the current installment by the HMI.



Note: The **String Length** of the **Character Display** element must be set to at least 23 characters to display the time completely.

Installment Lock Status


DIAScreen provides the Internal Parameter “INST_LOCK_STATUS” to facilitate you in identifying the installment status. Status 0 indicates that the installment is unlocked, while Status 1 indicates the installment is waiting to be unlocked. Once you have locked an installment, you can unlock it again.



How to unlock installment?


1. When the installment time is up or pressing the **Enable Next Installment** button on the HMI screen.

The **Unlock Installments** screen displays.




Note: The unlocking installment screen must be configured with a **Drop-down menu** element, and select **Installment Period** for **Project Data Source**, so that when unlocking the installment, you can select the installment to perform unlocking.

2. In the **Unlock Installments** screen, choose the period to be unlocked, and then enter the password of the period.
3. After entering the password, click the **Unlock** button.
 - If the password is entered correctly, a message displays and prompts you that the unlock is successfully.



- If the password is entered incorrectly, a message displays and prompts you that the unlock is failed.



System Time Setting Restriction

When the **Installment** function is enabled, the related functions of system time setting will be disabled, including LUA instructions, macros, NTP, system parameters, etc to prevent the device time setting from tampering during installment, causing the installment to fail to execute as scheduled. If system time calibration is required, you can use a project without installment settings or perform a factory reset, and then download the project with installment settings.

Note: If there is an abnormality with the device battery, the system time may be restored to the default value of 1970/01/01, and the HMI will be locked and cannot be used.

Project Protection

The **Installment** function involves the financial transactions, the projects must be well-protected and set the protection mechanism, such as **Check password when downloading program, Screen upload prohibited**. Project files, download executables, auto update data files, etc. must not be easily provided to outsiders.

Go to **General > Configuration > Security Level and Password** to set the protection mechanism.

Configuration

- Main
 - Non-volatile
 - Security Level and Password**
 - Global Keypad Settings
 - System Setting
 - Screensaver Setup
 - Others
- Control Status Block
 - Control Block
 - Status Block
- Real Time Clock
- Print
- Default
 - Element Default Value
 - Boot Logo
 - Boot Delay Screen
 - Custom Scroll Button
- Network Settings
 - Remote Desktop and Data Collectio
 - SMTP
 - FTP
 - MAC Settings
- Multi-language
 - Multi-language Settings
- Industry Application
 - Electronic Record

Security Level and Password

Security Management

Highest security password

12345678

☐ Complex password

Default startup security level

0

☒ Check password when downloading program

☒ Screen upload prohibited

☐ Prompt a reminder for insufficient security level

☐ Don't show password input window when the security level is insufficient.

☐ Restrict high account function
☐ Hide password only

☐ Complex password (must include one uppercase letter, one lowercase letter, number, symbol !, \$, #, %, >=8 letters)

☐ Limit the times of updating screens via USB drive

Login / logout

☐ Logout when time out

Minutes before reset to default boot permissions

10

☐ Account disabled after login failed

Number of consecutive failed retries

5

☐ The first login of the component does not execute in

☐ Change password on first login

Password Keypad

Default Keypad

...

Account and Password

0

...

0

...

User Login Screen

None

...

Number	Account	Password	User duration(0~9999 Day)	Password duration(0~9999)
1	00	00000000	0	0

OK

Cancel

Element

Button

Template Output

Alarm records, operational records, recipe data and data history records can be exported as PDF files and stored in external storage devices through the **Template Output** element.

Follow these steps to set the template screen.

To set the template screen

1. Create a template screen. Do one of the following:
 - In the menu bar, click **General > New Screen > Template Screen**.
 - Right-click the blank space on the **Screen Management Window** and select **New Screen**. Select **Template Screen** for **Screen Type** and click **OK**.
2. In the template screen, you can customize the content displayed at the header and footer of the page. The blank space between two red dotted lines is the content of the report.


Machine serial no:	ABCD	Machine type:	ABCD
	Report	Product name:	ABCD
		Batch number:	ABCD
		Recipe name:	ABCD

CopyRight 2019, Delta Electronics. All Rights Reserved.

Page 1


3. In the **Screen property setting** dialog, set the display style of the page number in the **Template setting** area.
4. Create a **Template Output** element on the screen.
5. In the **Template Output** property dialog, select the **Report Device**.

The following table lists the settings in the **Template setting** dialog with their descriptions.




1 Report (separate)

After creating report output of each type, PDF files will be generated respectively.

Setting	Description
Select template	Select the template you want to apply.
File name address	<p>Set the profile name address. If not set, the report file gets exported with the default file name.</p> <p>Note: The report file storage path is \HMI\HMI-000\@HMI0000.</p> 
String length	Select or enter the string length for the file name.
File date	<p>Select the date display format for the file. You can also set it to None to not to export the file date.</p> <p>Note: This setting is only available for historical reports.</p>





Setting	Description
File time	Select the time display format for the file. You can also set it to None to not to export the file time. Note: This setting is only available for historical reports.



2 Reports (Batch)

After customizing the display order of each type of report and exporting the reports, they will be consolidated as a single PDF file.

Setting	Description
Select template	Select the template to apply.
File name address	Set the file name address. If not set, the report file will be output with the default file name. Note: The default report file storage path is \HMI\HMI-000\@HMI0000\batch.pdf.

Setting	Description	
String length	Select or enter the string length for the file name.	
Sort	Sort (Fixed)	Select the output type of report and click   to sort the order in which the report is displayed.
	Dynamic sorting (HMI)	<p>Select to sort the display order of reports on the HMI screen.</p> 
Time	All time	Select to output reports of all recorded data.
	Interval setting (HMI)	<p>Select to specify the time interval for the output data on the HMI screen.</p> 


Report List

The alarm data can be exported as CSV file and stored in external devices through the **Report List** element.

Follow these steps to set the report list.

To set the report list

1. Create an alarm.
2. In the **Alarm** settings page, select the storage location of non-volatile, and then select **Yes** for **Export CSV File**.
3. Configure the **CSV Field Setting**. In the **CSV Field Setting** dialog, configure the content and order of the field to display.




4. Create a **Report List** element on the screen.
5. Click the element on the HMI, then export the alarm information as a CSV file and store it to the set report device.

Note: The report file storage path is \HMI\HMI-000\@HMI0000\HistoryOp\CSV.

Bar


- **Normal**

The **Normal Bar** element displays the values corresponding to the read addresses in the form of a bar from the minimum value to the maximum value on the HMI. You can also set the colors for the lower limit, upper limit, and target values to identify them.



- **Differential**

The **Differential Bar** element displays the deviation between the value of the **Read Address** and the set target value on the HMI.



The bar element of DIAScreen provides memory addresses with customizable target values and lower and upper limit values, making the application more flexible and meeting users' requirements.

Common Properties

- **Main**


- **Memory**


























Select the **Internal Memory** or the controller register address. The **Input** memory **Type** must be Word.

Detail


- **Data Type:** The available options are Word and Double Word.
- **Data Format:** The available options are BCD, Signed BCD, Signed Decimal, Unsigned Decimal, and Hexadecimal.
- **Minimum / Maximum:** Enter the valid range value according to the set **Data Type** and **Data Format**.
- **Variable minimum / maximum limits:** If selected, you can define the minimum and maximum value through the corresponding value of the memory address.

- **Style**



Legend	Setting	Description												
①	Style	<div>Select the appearance of the element. The available options are Standard, Raised, and Sunken. The default value is Standard.</div> <table><tr><td></td><td>Standard</td><td>Raised</td><td>Sunken</td></tr><tr><td>Normal Bar</td><td></td><td></td><td></td></tr><tr><td>Differential Bar</td><td></td><td></td><td></td></tr></table>		Standard	Raised	Sunken	Normal Bar				Differential Bar			
	Standard	Raised	Sunken											
Normal Bar														
Differential Bar														
②	Foreground Color / Background Color / Border Color	<div>Select the foreground color, background color, and border color of the element.</div> <div></div>												
③	Filled style	<div>Select the filled style of the element.</div> <div>Note: Since the default style of DOP-100 series models is Gradient, if the DOP-B project is opened, the elements are displayed in Fixed, and the effect is similar to that of DOP-B.</div> <table><tr><td>Gradient</td><td></td></tr><tr><td>Fixed</td><td></td></tr></table>	Gradient		Fixed									
Gradient														
Fixed														
④	Transparency	<div>Select or enter the transparency value of the element. The range value is 50—255 and the default value is 255.</div> <div>The lower the value is, the higher the transparency is.</div>												
⑤	Smooth animation	<div>Select whether to enable the Smooth animation function.</div> <div>When this function is enabled, the element display becomes smoother.</div>												

- Style – Scale Settings



The image shows a 'Scale Settings' dialog box with a close button (X) in the top right corner. It contains three main sections: 'Scale Display Position' with a dropdown menu set to 'Not Display'; 'Scale Settings' with four controls: 'Scale Mark Number' (spinner set to 5), 'Subscale Mark Number' (spinner set to 1), 'Mark Color' (color picker set to black), and 'Scale Width' (spinner set to 88); and 'Text Setting' with three controls: a checked 'Display mark' checkbox, 'Font size' (dropdown set to 16), and 'Text Color' (color picker set to blue). At the bottom are 'OK' and 'Cancel' buttons.

Setting	Description
Scale Display Position	<p>Select the position to display scale on the element according to Direction.</p> <ul style="list-style-type: none"> Scale can be displayed on the top or bottom when Direction is Left or Right. Scale can be displayed on the left or right when Direction is Top or Bottom.
Scale Settings	<p>Set the mark number, color, width of the scale. The range value of Scale Mark Number is 1–99.</p>
Text Setting	<p>Select the Display mark checkbox to display the mark and set the text size and color.</p>

Normal Bar Properties

- Main
 - Detail

☐ Target

☐ Range

Low Limit

High Limit

☐ Variable target/range limits

Setting	Description
Target	Select and enter the target value. You can also specify the display color. If the Variable target / range limits checkbox is not selected, enter only a constant value.
Range	Select and enter the Low Limit and High Limit . If the Variable target / range limits checkbox is not selected, enter only a constant value.
Variable target / range limits	If selected, set the memory addresses to dynamically change the displaying target value, and the low and high limit values.

○ Style

■ Numeric Display

Numeric Display:

No display

▼

Marlett

▼

12

▼

☐ **B**
☐ *I*
☐ U

▼

Horiz. alignment:

Horiz. Center

▼

Vert. alignment:


Vert. Centerin

▼

The available options are No display, Value, and Percentage. The default value is **No display**. If you select **Value** or **Percentage**, you can set the display style and alignment type.

Differential Bar Properties

- Main
 - Detail





The screenshot shows a dialog box titled "Differential Bar Properties" with a "Detail" tab selected. It contains the following elements:

- ☐ Display Deviation
- Deviation: A text input field containing the value "25".
- Color: A color selection dropdown menu showing a dark red color.
- ☐ Variable Standard Value/Deviation

Select and enter the **Deviation**. You can also set the display color for deviation values within the range. If the **Variable target / range limits** checkbox is not selected, enter only a constant value to define the deviation value of the **Differential Bar** element.

Pie

The **Pie** element displays the values corresponding to the read addresses in different pie styles on the HMI. You can also set the colors for the lower limit, upper limit, and target values to identify them.



Common Properties

Main	Style	Text	Operating conds.	Coord.
<div> <div> Memory </div> <div> Detail </div> </div>				
<div> <div> 1 Read Address: None </div> <div> Read Offset Address: None </div> </div>				
<div> <div> 2 Data Type: Word Data Format: Unsigned Decimal Minimum: 0 Maximum: 100 <input type="checkbox"/> Variable minimum/maximum limits </div> <div> 3 <input type="checkbox"/> Target 0 </div> <div> 4 <input type="checkbox"/> Range Low Limit: 0 High Limit: 100 </div> <div> 5 <input type="checkbox"/> Variable target/range limits </div> <div> 6 Interval display: 1 </div> </div>				

Legend	Function	Description
①	Memory	Select the Internal Memory or the controller register address. The Input memory Type must be Word.
②	Data Settings	<ul style="list-style-type: none"> • Data Type: The available options are Word and Double Word. • Data Format: The available options are BCD, Signed BCD, Signed Decimal, Unsigned Decimal, and Hexadecimal. • Minimum / Maximum: Enter the valid range value according to the set Data Type and Data Format. • Variable minimum / maximum limits: If selected, you can define the minimum and maximum value through the corresponding value of the memory address.
③	Target	Select and enter the target value. You can also specify the display color. If the Variable target / range limits checkbox is not selected, enter only a constant value.
④	Range	Select and enter the Low Limit and High Limit . If the Variable target / range limits checkbox is not selected, enter only a constant value.
⑤	Variable target / range limits	If selected, set the memory addresses to dynamically change the displaying target value, and the low and high limit values.
⑥	Interval display	Select or enter the interval display value. The range value is 0—100. To have an effect, the value displayed in the interval needs to be divided by the difference between the maximum value and the minimum value. For example, if the minimum value is 0, the maximum value is 100, the interval display value is 20, no scale is displayed when the value is 0~19; the scale is 20 when the value is 20~39; the scale is 40 when the value is 40~59, and so on.

- Style

Style

1 Border Color:

2 Low Range Color:

High Range Color:

3 Style: Standard

Foreground Color:

Background Color:

4 Display the colors of each No














5 Transparency: 255








6 Smooth animation: No







7 Anti-aliasing: Yes

8 Target Value Style: Default

9 Scale Setting

Legend	Function	Description								
1	Border Color Foreground Color Background Color	<p>Select the foreground color, background color, and border color of the element.</p> 								
2	Low Range Color High Range Color	<p>Select the element's low and high range color to display on the HMI.</p>								
3	Style	<p>Select the appearance of the element. The available options are Standard, Raised, Sunken, and Transparent. The default value is Standard.</p> <table><tr><th>Standard</th><th>Raised</th><th>Sunken</th><th>Transparent</th></tr><tr><td></td><td></td><td></td><td></td></tr></table>	Standard	Raised	Sunken	Transparent				
Standard	Raised	Sunken	Transparent							
										
4	Display the colors of each	<ul style="list-style-type: none">• If select No, no matter what the value is, only the Foreground Color will be displayed.• If select Yes, with the Low Range Color and Range functions, it can represent different colors of each stage.								

Legend	Function	Description				
		<div><div>Style</div><div>Border Color: <div></div></div><div>Low Range Color: <div></div></div><div>High Range Color: <div></div></div><div>Style: <div>Standard</div></div><div>Foreground Color: <div></div></div><div>Background Color: <div></div></div><div>Display the colors of each <div>No</div></div></div> <div><div><input type="checkbox"/> Range</div><div>Low Limit <div>0</div></div><div>High Limit <div>100</div></div></div> <p>The following is an example of setting Display the colors of each for Pie(1) element.</p> 				
5	Transparency	<p>Select or enter the transparency value of the element. The range value is 50—255 and the default value is 255.</p> <p>The lower the value is, the higher the transparency is.</p>				
6	Smooth animation	<p>Select whether to enable the Smooth Animation function.</p> <p>When this function is enabled, the element display becomes smoother.</p>				
7	Anti-aliasing	<p>Select whether to enable the Anti-aliasing function.</p> <p>When this function is enabled, the display of the elements will be more delicate, and there will be no aliasing.</p> <table><tr><th>Yes</th><th>No</th></tr><tr><td></td><td></td></tr></table>	Yes	No		
Yes	No					
						

Legend	Function	Description								
8	Target Value Style	Select the style of the target value. The available options are Default and Style 1, and the default value is Default .								
		<table><tr><td>Default</td><td></td></tr><tr><td>Style 1</td><td></td></tr></table>	Default		Style 1					
Default										
Style 1										
9	Scale Settings	<div><div>Scale Settings</div><div><div>Scale Display Position</div><div>Not Display</div></div><div><div>Scale Settings</div><div><div>Scale Mark Number</div><div>5</div></div><div><div>Subscale Mark Number</div><div>1</div></div><div><div>Mark Color</div><div></div></div><div><div>Scale Width</div><div>88</div></div></div><div><div>Text Setting</div><div><div><input checked="" type="checkbox"/> Display mark</div><div><div>Font size</div><div>16</div></div><div><div>Text Color</div><div></div></div></div><div><div>OK</div><div>Cancel</div></div></div></div>								
		<table><tr><th>Setting</th><th>Description</th></tr><tr><td>Scale Display Position</td><td>Select the position to display scale on the element according to Direction.</td></tr><tr><td>Scale Settings</td><td>Set the mark number, color, width of the scale. The range value of Scale Mark Number is 1–99.</td></tr><tr><td>Text Setting</td><td>Select the Display mark checkbox to display the mark and set the text size and color.</td></tr></table>	Setting	Description	Scale Display Position	Select the position to display scale on the element according to Direction .	Scale Settings	Set the mark number, color, width of the scale. The range value of Scale Mark Number is 1–99.	Text Setting	Select the Display mark checkbox to display the mark and set the text size and color.
		Setting	Description							
		Scale Display Position	Select the position to display scale on the element according to Direction .							
Scale Settings	Set the mark number, color, width of the scale. The range value of Scale Mark Number is 1–99.									
Text Setting	Select the Display mark checkbox to display the mark and set the text size and color.									

Data Display

The **Date Display**, **Time Display**, and **Week Display** elements display the date, time, and week of the HMI system. The date and time can also be displayed by setting the timestamp through **Read Address**, and the **Week Display** element can be edited using the **Multi-language** function.

Data Display																											
Date Display	The available Date Format options include mm/dd/yy, dd/mm/yy, dd.mm.yy, yy.mm.dd, yy/mm/dd, mm.dd, and mm/dd. The default value is mm/dd/yy .																										
Time Display	The available Time Format options include HH:MM:SS and HH:MM. The default value is HH:MM:SS .																										
Week Display	<p>If multi-language has been set, edit the Week display in the Text tab of the element properties dialog to present the multi-language effect.</p> <table><tr><th>State</th><th>Chinese</th><th>English</th></tr><tr><td>0</td><td>日</td><td>SUN</td></tr><tr><td>1</td><td>一</td><td>MON</td></tr><tr><td>2</td><td>二</td><td>TUE</td></tr><tr><td>3</td><td>三</td><td>WED</td></tr><tr><td>4</td><td>四</td><td>THR</td></tr><tr><td>5</td><td>五</td><td>FRI</td></tr><tr><td>6</td><td>六</td><td>SAT</td></tr></table>			State	Chinese	English	0	日	SUN	1	一	MON	2	二	TUE	3	三	WED	4	四	THR	5	五	FRI	6	六	SAT
State	Chinese	English																									
0	日	SUN																									
1	一	MON																									
2	二	TUE																									
3	三	WED																									
4	四	THR																									
5	五	FRI																									
6	六	SAT																									
Illustration	<p>After compiling the screen and downloading it to the HMI, the HMI screen appears as follows:</p> <table><tr><th>Date Display</th><th>Time Display</th><th colspan="2">Week Display</th></tr><tr><td><div>06/15/2016</div></td><td><div>13:31:14</div></td><td>Chinese</td><td>English</td></tr><tr><td></td><td></td><td><div>三</div></td><td><div>WED</div></td></tr></table>			Date Display	Time Display	Week Display		<div>06/15/2016</div>	<div>13:31:14</div>	Chinese	English			<div>三</div>	<div>WED</div>												
Date Display	Time Display	Week Display																									
<div>06/15/2016</div>	<div>13:31:14</div>	Chinese	English																								
		<div>三</div>	<div>WED</div>																								


Timestamp

Set the displayed date and time through **Read Address**.

Timestamp rules


- Start time: 1970/01/01
- Standard type: in **seconds**

- Time zone setting: Go to **General > Configuration > Network Settings > Time zone** to set the time zone of the HMI time.



Example

- Create **Date Display**, **Time Display**, and **Week Display** elements, and set **Read Address** to \$10.
- Create a **Numeric Entry** element and set **Write Address** to \$10.
- Compile the screen and download it to the HMI. Enter 0 to the **Numeric Entry** element on the HMI, and the time displays as 01/01/1970 00:00 (GTM +00:00).



- Enter 86400 to the **Numeric Entry** element and the time displays as 01/02/1970 00:00 (GTM +00:00).

Note:

- The timestamp is in seconds. It is suggested to set an address that supports **Quad Word** data type.
- For timestamp conversion, see epochconverter.com/.
- Setting **None** for **Read Address** displays the HMI system time.

CODESYS time variable read

The **Date Display** and **Time Display** elements support reading CODESYS time-type Tags, including TIME, LTIME, DATE, TIME_OF_DAY, and DATE_AND_TIME.

Note: Except **Date Display**, **Time Display**, and **Week Display** elements, other elements do not support reading time-type Tags.


List

File Browser

You can browse the stored device files on HMI, and rename and delete files through the **File Browser** element.


The following table lists the properties of the **File Browser** element with their descriptions.

- **Main**



- **Memory**

Setting	Description																												
Control Address	Set the address to trigger actions. The following table lists the corresponding actions of the state value.																												
	<table><tr><th>State Value</th><th>Action</th></tr><tr><td>1</td><td>File deletion</td></tr><tr><td>2</td><td>File rename</td></tr><tr><td>3</td><td>Path write</td></tr><tr><td>4</td><td>Switch to the previous page</td></tr></table>	State Value	Action	1	File deletion	2	File rename	3	Path write	4	Switch to the previous page																		
	State Value	Action																											
	1	File deletion																											
	2	File rename																											
3	Path write																												
4	Switch to the previous page																												
Control Return Address	Set the return address after the action is completed, the status code and description of the return are as follows:																												
	<table><tr><th>Action</th><th>Status</th><th>Description</th></tr><tr><td>No action</td><td>0</td><td>-</td></tr><tr><td>Succeed</td><td>1</td><td>-</td></tr><tr><td>File deletion</td><td>-1</td><td>Failed to delete the file</td></tr><tr><td rowspan="5">File rename</td><td>-2</td><td>File name is too long Note: The maximum length of the file name is 255 characters.</td></tr><tr><td>-3</td><td>File does not exist</td></tr><tr><td>-4</td><td>The file name cannot contain the following characters: \:*?\"<> </td></tr><tr><td>-5</td><td>The name of the file has not been changed</td></tr><tr><td>-6</td><td>The same file name exists</td></tr><tr><td rowspan="2">Path write</td><td>-7</td><td>The path does not exist</td></tr><tr><td>-8</td><td>The path write address is not set</td></tr></table>	Action	Status	Description	No action	0	-	Succeed	1	-	File deletion	-1	Failed to delete the file	File rename	-2	File name is too long Note: The maximum length of the file name is 255 characters.	-3	File does not exist	-4	The file name cannot contain the following characters: \:*?\"<>	-5	The name of the file has not been changed	-6	The same file name exists	Path write	-7	The path does not exist	-8	The path write address is not set
	Action	Status	Description																										
	No action	0	-																										
	Succeed	1	-																										
	File deletion	-1	Failed to delete the file																										
	File rename	-2	File name is too long Note: The maximum length of the file name is 255 characters.																										
		-3	File does not exist																										
		-4	The file name cannot contain the following characters: \:*?\"<>																										
		-5	The name of the file has not been changed																										
		-6	The same file name exists																										
Path write	-7	The path does not exist																											
	-8	The path write address is not set																											
Result Describes Address	Note:																												
	<ul style="list-style-type: none">The data type of Control Return Address is signed decimal.If the HMI language is non-English, the result description should be displayed using a Multi-language Input element.																												

Setting	Description
Write Path address	<p>Do one of the following to write path address:</p> <ul style="list-style-type: none"> Select the file on the HMI and click  on the toolbar of the element to write the path. Write value 3 for Control Address, and then write the current file path for Write Path Address. Write the file path to this address, and the file browser redirects to the specified file. <p>Note:</p> <ul style="list-style-type: none"> The file path does not contain the root directory, but the path after the address is written to the file location. Set this parameter using the Character Display or the Multi-language Input element.


Detail









Function	Description
File Types	Select the type of file to display.
Invisible Address	Set the invisible address. When the invisible bit is On, the element is not visible to the HMI.

File Location

Function	Description
Dynamic File Location	Choose whether to set the file location dynamically. Select Yes to select by the root directory of the address file.
File Location	Choose the root directory to which the path is written.

The following table lists the functions on the toolbar of the **File Browser** element with their description.

Icon	Function	Description
	Previous	Click to switch to the previous level of directory.


Icon	Function	Description
	File deletion	Click to delete the currently selected file.
	File rename	<p>After selecting a file, click this icon to enter the file name to change the name of the selected file.</p> <p>Note: If you want to input words other than English or numbers, check the languages in the Configuration dialog.</p> 
	Path write	<p>After selecting the file, click this icon to display the full path of the file at the Write Path Address.</p> <p>Note: If you don't select a file, clicking this button has no effect.</p>
	Display toggle	Click to display files as icons or manifests.
	Folder switching	Click to display or not display the folder.
	File sorting	<p>Click to set how the files are sorted.</p> 

Picture Viewer


You can select files and view pictures on the HMI through the **Picture Viewer** element.

The following lists the properties of the **Picture Viewer** element and their descriptions.


- **Main**



Legend	Function	Description
1	File Location	<p>Select the location to store the files.</p> <ul style="list-style-type: none"> • If Dynamic File Location is set to No, the storage device can be specified for reading. • If Dynamic File Location is set to Yes, the storage device can be dynamically specified on the HMI. The value 2 is USB disk, 6 is USB disk 2, 3 is SD card.

Legend	Function	Description
②	Folder	<p>Set the folders to display in the File Browser.</p> <ul style="list-style-type: none"> Root: The root directory of the specified File Location. Capture Picture: The screen_capture folder under the specified File Location. Define By User: The specified folder under the specified File Location. <p>If Dynamic Folder Path is set to Yes, the folder to display can be dynamically specified on the HMI.</p> <p>Note: You can only specify internal memory address of the HMI for Dynamic Folder Path.</p>
③	File Selection	<ul style="list-style-type: none"> Choose whether to automatically display the latest pictures. Select Yes to select whether to send a notification when the picture is updated, and specify the memory address of the notification.  <ul style="list-style-type: none"> Choose whether to specify the file by the address. Select Yes to specify the file name of the picture by the address on the HMI to display the picture on the element.

- Style












Setting	Description
Toolbar Location	Select the location to which the toolbar is displayed on the element.
Background Color	Select the background color of the element.
Hide Delete Button	Select whether to hide the delete button.
Invisible Address	Set the invisible address. When the invisible bit is On, the element is not visible to the HMI.

Note:

- Only one **Picture Viewer** element can be configured for a screen, and only for a general screen.

- The picture will not be loaded by default when the HMI starts, and the picture will only be displayed if you enter the **File Browser** element and click on the picture file, or specify the file name by the file address.

The following table lists the functions on the toolbar of the **Picture Viewer** element with their descriptions.

Icon	Function	Description
	File browsing	Click to toggle to File Browser . The directory under the set File Location is displayed by default. For the functions on the toolbar of the File Browser , refer to File Browser .
	Refresh	Click to reload the currently displayed picture.
	Delete	Click to delete the currently displayed picture.
	The first picture	Displays the pictures in alphabetical order by file name.
	Previous picture	
	The next picture	
	The last picture	
	Maintain proportions	Click to maintain the picture's aspect ratio. The ratio scales according to the size of the element.
	Actual size	Click to display the original size of the picture.


Frame and Multimedia

VNC Viewer

VNC (Virtual Network Computing) uses the RFB protocol to achieve screen sharing and remote operation. It can transmit keyboard and mouse movements and real-time images through the network. The **VNC Viewer** element of the HMI receives and controls the display device operated by the server.

Note: This function is only available for DOP-300 series models.

The following table lists the settings in the property dialog of the VNC Viewer element with the description.



VNC Viewer

Preview

VNC Viewer

State: 0

Language: Language1

Element Description: VNC Viewer_001

Main Operating conds. Coord.

Memory

1 State Address: None

2 Action Address: None

3 IP Address: 192.168.0.1

4 Port: 5900

5 Password: 12345678

6 Color Level: High

7 Enable virtual keypad: No

8 Number of: 10

Set IP as variable: No

Set password as variable: No

Password Max Length: 16 Word

OK Cancel

Legend	Function	Description																				
①	State Address	<p>Set the State Address in Word type.</p> <ul style="list-style-type: none">Obtain the current connection state through the State Address values. The following table lists the state values with the corresponding description. <table><tr><th>State</th><th>Description</th></tr><tr><td>0</td><td>Stopped</td></tr><tr><td>1</td><td>Connecting</td></tr><tr><td>2</td><td>Connect failed</td></tr><tr><td>3</td><td>Authentication error</td></tr><tr><td>4</td><td>Server disconnect</td></tr><tr><td>5</td><td>Security error</td></tr><tr><td>6</td><td>Attempting to reconnect</td></tr><tr><td>7</td><td>Reconnect failed</td></tr><tr><td>8</td><td>Reconnect successful</td></tr></table>	State	Description	0	Stopped	1	Connecting	2	Connect failed	3	Authentication error	4	Server disconnect	5	Security error	6	Attempting to reconnect	7	Reconnect failed	8	Reconnect successful
State	Description																					
0	Stopped																					
1	Connecting																					
2	Connect failed																					
3	Authentication error																					
4	Server disconnect																					
5	Security error																					
6	Attempting to reconnect																					
7	Reconnect failed																					
8	Reconnect successful																					
②	Action Address	<p>Set the Action Address in Word type.</p> <ul style="list-style-type: none">Send the action to the VNC device through the Action Address. The following table lists the state values with the corresponding description. <table><tr><th>State</th><th>Description</th></tr><tr><td>0</td><td>None</td></tr><tr><td>1</td><td>Start</td></tr><tr><td>2</td><td>Stop</td></tr><tr><td>3</td><td>Update</td></tr></table>	State	Description	0	None	1	Start	2	Stop	3	Update										
State	Description																					
0	None																					
1	Start																					
2	Stop																					
3	Update																					
③	IP Address	<p>Set the IP address for the VNC server.</p> <ul style="list-style-type: none">When selecting Yes for Set IP as variable, you can dynamically change the IP address on the HMI. Use the 4 Word addresses read by the IP starting address continuously as the set IP address.																				
④	Port	<p>Set the Port for the VNC server. The default value is 5900.</p>																				
⑤	Password	<p>When selecting Yes for Set password as variable, you can dynamically change the VNC connection password on the HMI. Use the set Password Max Length, read by the set starting address, as the password. Password can consist of numbers and letters.</p>																				
⑥	Color Level	<p>Set the display color for different bits. The available options are High (32 Bit), Middle (16 Bit), and Low (8 Bit). The default value is High.</p>																				

Legend	Function	Description
7	Enable virtual keypad	If select Yes , the Keyboard button appears at the bottom right corner of the element after clicking the VNC Viewer element on the HMI. Click the Keypad button to call out the ASCII keypad.
8	Number of	<ul style="list-style-type: none"> If the connection to the server is disconnected, a message "Attempting to reconnect to VNC server" appears. When the connection is not restored after the set retries are reached, it will be automatically aborted and a message "Disconnected from VNC server" will appear. If set to 0, it means the number of retries is unlimited. The maximum number is 65535, and the interval between each retry is 3 seconds.


Drawing


Rectangle Element

The **Rectangle** element provides various filled styles and border configurations and supports importing pictures from the picture bank. Use the set read address to control the moving position, color, size, and blinking of the rectangle element.

The following table lists the functions in the Rectangle element property dialog with their description.


Main









Legend	Function	Description
1	Read Address	<p>Select the internal address or controller register address.</p> <ul style="list-style-type: none"> When Variable Position is set to Yes, the value of the Read Address is regarded as the X coordinate of the horizontal axis for the upper left corner of the dynamic Rectangle element. When Variable Position is set to Yes, the value of Read Address+1 is regarded as the Y coordinate of the vertical axis for the upper left corner of the dynamic Rectangle element. When Variable Size is set to Yes, the value of Read Address+2 is regarded as the width for the dynamic Rectangle element. When Variable Size is set to Yes, the value of Read Address+3 is regarded as the height for the dynamic Rectangle element. When Variable Color is set to Yes, the value of Read Address+4 is regarded as the color for the dynamic Rectangle element. Its value range is 0–65535. When Blink is set to Yes, the value of Read Address+5 determines whether the dynamic Rectangle element blinks or not. When its value is greater than 1, the dynamic Rectangle element is displayed as blinking; when the value is 0, it does not blink. When Variable Position is set to No, the corresponding memory addresses are automatically filled in. <div>  </div>
2	Data Format	<p>Select the data format. The default value is Unsigned Decimal.</p>



Legend	Function	Description
③	Variable Position	<p>Select whether the position can be moved. The default value is No.</p> <ul style="list-style-type: none"> If select Yes, the position of the dynamic Rectangle element can be moved. If select No, the dynamic rectangle element cannot be moved, but the size can be changed.
④	Variable Color	<p>Select whether the color can be changed. The default value is No.</p> <ul style="list-style-type: none"> If select Yes, the color of the dynamic Rectangle element can be changed. Its value range is 0–65535. <p>Note: This setting has no effect when the Filled style is set to more than one color such as Gradient or Fill Pattern Style.</p>
⑤	Variable Size	<p>Select whether the size can be changed. The default value is No.</p> <ul style="list-style-type: none"> If select Yes, the size of the dynamic Rectangle element can be changed by changing its coordinates at the lower right corner. If select No, the size of the rectangle element cannot be changed.
⑥	Image File Name Address	<p>Specify the selected item through this setting, and then set Load Image Trigger Address to On, the element displays the selected item.</p> <ul style="list-style-type: none"> Image File Name Address supports selecting the controller address (Word) and internal register address (Word). Load Image Trigger Address supports selecting the controller address (Bit) and internal register address (Bit).
⑦	Load Image Trigger Address	
⑧	Save in	<p>Select the stored type. The default value is USB Disk. By storing the image file in a USB Disk, USB Disk 2 or SD Card, the image file can be read on the HMI. Currently supports BMP, JPEG, PNG, and TIFF file formats.</p>
⑨	String Length	<p>Select or enter the file name to read. The default value is 16.</p>
⑩	Extended mode	<p>Select the extended mode. The default value is All areas.</p>



Style



Legend	Function	Description
①	Foreground Color	Set the foreground color of the element. Note: This setting has no effect when the Filled style is set more than two gradients.
②	Round Corner Radius	Select or enter the round corner radius. The size of this round corner radius is determined by the width and height of the Rectangle element. Take the smaller value among width/2 and height/2 of the Rectangle element. This is the maximum value that can be set for the radius.
③	Blink	Select whether to blink or not. The default value is No . <ul style="list-style-type: none"> If select Yes, the dynamic Rectangle element displays as blinking. When the value of the corresponding read address is great than 1, the dynamic Rectangle element displays as blinking; when the value is 0, it does not blink. If select No, the dynamic Rectangle element does not blink.

Legend	Function	Description						
4	Transparent	<p>Select whether to display in transparent. The default value is No.</p> <ul style="list-style-type: none">If select Yes, the Foreground Color setting has no effect.If select No, the dynamic Rectangle element displays only the rectangle border line with the middle shown in transparent						
5	Penetrate	<p>Select whether the element that overlaps with the Rectangle element can be clicked. The default value is ON.</p> <p>Example Operation</p> <ol style="list-style-type: none">Create a Numeric Entry element.Create one more Numeric Entry element and make it overlaps on top of the Numeric Entry element. <table><thead><tr><th>Function</th><th>Illustration</th></tr></thead><tbody><tr><td>Penetrate ON</td><td><p>The Numeric Entry element under Rectangle element can be clicked.</p></td></tr><tr><td>Penetrate OFF</td><td><p>The Numeric Entry element under Rectangle element cannot be clicked.</p></td></tr></tbody></table>	Function	Illustration	Penetrate ON	<p>The Numeric Entry element under Rectangle element can be clicked.</p> 	Penetrate OFF	<p>The Numeric Entry element under Rectangle element cannot be clicked.</p> 
Function	Illustration							
Penetrate ON	<p>The Numeric Entry element under Rectangle element can be clicked.</p> 							
Penetrate OFF	<p>The Numeric Entry element under Rectangle element cannot be clicked.</p> 							
6	Filled style	<p>Select the fill style of the element. The default value is Gradient. The following table lists the functions in the Gradient Fill view with their description.</p> <table><thead><tr><th>Function</th><th>Illustration</th></tr></thead></table>	Function	Illustration				
Function	Illustration							

Legend	Function	Description
	Gradient Style	<p>Set the Gradient Style by setting the Current Angle or Center Point. Set the Current Angle or Center Point by dragging the mouse on the preview image, or set the memory address for dynamic configuration on the HMI. Supports adding gradient stop points and setting stop point colors to present the effect of multi-color gradients.</p> <p>Note: Up to 5 stop points can be set.</p> <ul style="list-style-type: none"> Mono Gradient The gradient color automatically configured by the software does not provide stop point configuration and is compatible with the behavior of DOPSoft software.  <ul style="list-style-type: none"> Linear Style  Radiation Gradient

Legend	Function	Description
		<div>  </div> <ul style="list-style-type: none"> Conical Style <div>  </div>
	Solid Color	<p>Set a single color fill, the same as the Foreground Color setting.</p> <div>  </div>
	Fill Pattern Style	<p>Provides a variety of Fill Pattern styles and two color combinations to present pattern fill effects.</p> <div>  </div>


Legend	Function	Description
		Note: This feature is supported in software version 1.4.0 and above.
7	Transparency	Select or enter the transparency value. The range value is 50–255 and the default value is 255 .
8	Anti-aliasing	Select whether to enable anti-aliasing effect. <ul style="list-style-type: none"> If select Yes, the element border displays smooth. If select No, the element border displays in aliasing. Note: This setting only has effect when the Round Corner Radius is set.
9	Customize each fillet radius	Set each fillet radius. Note: The fillet radius settings are available when this setting is selected.

Border

Note: This feature is supported in software version 1.3.1 and above.

- **Border Style**

- **Fixed**




Function	Description
Width	Select the border width. The range value is 1 ~ 8, and the default value is 1 .
Color	Set the border color to display.

- Linear Gradient

Rectangle

Preview



State:

0

Language:

Chinese

Element Description:

矩形_002

Main

Style

Border

Picture

Operating conds.

Border

Border Style:

Linear Gradient

Show Borders:

Yes

Width:

5

Linear Degree:

From 45 degree













Variable Border Color:



No

Begin Color:

Mid Color:

End Color:


Function	Description										
Linear Degree	Select the angle of transition from Begin Color to End Color .										
	<table><tr><th>Angle</th><th>Result</th></tr><tr><td>From 0 degree</td><td><div><div>Preview</div></div></td></tr><tr><td>From 45 degree</td><td><div><div>Preview</div></div></td></tr><tr><td>From 90 degree</td><td><div><div>Preview</div></div></td></tr><tr><td>From 180 degree</td><td><div><div>Preview</div></div></td></tr></table>	Angle	Result	From 0 degree	<div><div>Preview</div></div>	From 45 degree	<div><div>Preview</div></div>	From 90 degree	<div><div>Preview</div></div>	From 180 degree	<div><div>Preview</div></div>
	Angle	Result									
	From 0 degree	<div><div>Preview</div></div>									
	From 45 degree	<div><div>Preview</div></div>									
From 90 degree	<div><div>Preview</div></div>										
From 180 degree	<div><div>Preview</div></div>										
Variable Border Color	<p>Select whether the border color is variable.</p> <ul style="list-style-type: none">• If select No, the Begin Color and End Color are fixed.• If select Yes, the Begin Color and End Color dynamically change on the HMI according to the set address.										

Function	Description
	<div> <div> <div>Rectangle</div> <div> <div>Preview</div>  </div> <div> <div>State:</div> <div>0</div> </div> <div> <div>Language:</div> <div>Chinese</div> </div> <div> <div>Element Description:</div> <div>矩形_003</div> </div> </div> <div> <div> <div>Main</div> <div>Style</div> <div>Border</div> <div>Picture</div> <div>Operating conds.</div> </div> <div> <div>Border</div> <div> <div>Border Style:</div> <div>Linear Gradient</div> </div> <div> <div>Show Borders:</div> <div>Yes</div> </div> <div> <div>Width:</div> <div>5</div> </div> <div> <div>Linear Degree:</div> <div>From 0 degree</div> </div> <div> <div>Variable Border Color:</div> <div>Yes</div> </div> <div> <div>Begin Color:</div> <div>\$10</div> </div> <div> <div>End Color:</div> <div>None</div> </div> <div> <div>Mid Color:</div> <div>\$20</div> </div> </div> </div> </div> <p>The value entered in the address corresponds to the color as shown in the following figure.</p> <div> <div>Color</div> <div> <div>Basic colors(B):</div>  </div> <div> <div>Custom colors(C):</div> <div> <div>HMI Colors(H)</div> <div> <div>Decimal</div> <div>Hexadecimal</div> <div>63488</div> </div> </div> <div> <div>Color(Solid(O))</div> <div> <div>Hue(E): 0</div> <div>Sat(S): 240</div> <div>Lum(L): 120</div> </div> <div> <div>Red(R): 255</div> <div>Green(G): 0</div> <div>Blue(U): 0</div> </div> </div> <div> <div>Add Custom Colors(A)</div> <div> <div>OK</div> <div>Cancel</div> </div> </div> </div> </div>

- Radiation Gradient

Rectangle

Preview



State:

0

Language:

Chinese

Element Description:

矩形_005

Main

Style

Border

Picture

Operating conds.

Border

Border Style:

Radiation Gradient

Show Borders:

Yes

Width:

3

Radiation Gradient

From Mid point



Variable Border Color:




No

Begin Color:


Mid Color:

End Color:


Function	Description	
Radiation Gradient	Begin Color radiates from the mid point of the gradient to the End Color .	
	Angle	Result
	From Mid point	<div> <div>Preview</div>  </div>
	From Top-Left cor.	<div> <div>Preview</div>  </div>

Function	Description	
	From Top-Right cor.	
	From Bot-Right cor.	
	From Bot-Left cor.	

- **Transition Gradient**




Select **Transition Gradient**, and HMI will dynamically cycle according to **Begin Color**, **Mid Color**, and **End Color**.



- Figure-Filled

Rectangle

Preview



State:

0

Language:

Chinese

Element Description:

矩形_007

Main

Style

Border

Picture

Operating conds.

Border

Border Style:

Figure-Filled

Show Borders:

Yes

Width:

8

Figure Style:


Variable Border Color:

No

Begin Color:

Mid Color:

End Color:


Function	Description	
Figure Style	Select Figure Style . The dotted line type uses Begin Color as the line background color and End Color as the dotted line color.	
	<div>Style</div> <div>Style 1</div>	<div>Result</div> <div> <div>Rectangle</div> <div> <div>Preview</div>  <div> <div>State:</div> <div>0</div> </div> <div> <div>Language:</div> <div>Chinese</div> </div> <div> <div>Element Description:</div> <div>矩形_008</div> </div> </div> <div> <div> <div>Main</div> <div>Style</div> <div>Border</div> <div>Picture</div> <div>Operating conds.</div> </div> <div> <div>Border</div> <div> <div>Border Style:</div> <div>Figure-Filled</div> </div> <div> <div>Show Borders:</div> <div>Yes</div> </div> <div> <div>Width:</div> <div>5</div> </div> <div> <div>Figure Style:</div> <div>---</div> </div> <div> <div>Variable Border Color:</div> <div>No</div> </div> <div> <div>Begin Color:</div> <div></div> </div> <div> <div>Mid Color:</div> <div></div> </div> <div> <div>End Color:</div> <div></div> </div> </div> </div> </div>

Function	Description	
	Style 2	<div> <div>Rectangle</div> <div> <div>Preview</div>  </div> <div> <div>State:</div> <div>0</div> </div> <div> <div>Language:</div> <div>Chinese</div> </div> <div> <div>Element Description:</div> <div>矩形_008</div> </div> </div> <div> <div>MainStyleBorderPictureOperating conds.</div> <div>Border</div> <div> <div>Border Style:</div> <div>Figure-Filled</div> </div> <div> <div>Show Borders:</div> <div>Yes</div> </div> <div> <div>Width:</div> <div>5</div> </div> <div> <div>Figure Style:</div> <div>.....</div> </div> <div> <div>Variable Border Color:</div> <div>No</div> </div> <div> <div>Begin Color:</div> <div></div> </div> <div> <div>Mid Color:</div> <div></div> </div> <div> <div>End Color:</div> <div></div> </div> </div>

- **Flashing-Outline**

Rectangle

Preview



State:

0

Language:

Chinese

Element Description:

矩形_009

Main

Style

Border

Picture

Operating conds.

Border

Border Style:

Flashing-Outline

Show Borders:

Yes

Width:

8

Flashing Speed:

100ms

Twinkle Control Bit:

None

Variable Border Color:

No

Begin Color:

End Color:


Function	Description
Flashing Speed	Select Flashing Speed . Begin Color and End Color flash alternately according to Flashing Speed .
Twinkle Control Bit	Select Twinkle Control Bit and set it to \$1.1 as an example. When \$1.1 is OFF, the border color is Begin Color ; when \$1.1 is ON, the border color is End Color . Note: This function is only available when the Flashing Speed is set to Custom .

Coord.

You can set **Rotation angle** as a variable or a constant, which is a value for clockwise rotation.

Rectangle

Preview



State:

0

Language:

Chinese

Element Description:

矩形_010

Main

Style

Border

Picture

Operating conds.

Coord.

Coordinates

X:

98

Y:

66

Width:

183

Height:

115

Rotations

Rotation angle:

30

OK

Cancel

Alarm Setting

You can set the properties to be used by the alarm elements, such as read address, sampling cycle, maximum records, non-volatile data storage, and alarm moving sign, and can also edit the alarm message contents to be displayed. The Bit or Word addresses can also be configured to trigger alarms through the continuous alarm address and non-continuous alarm address functions.

The content of the alarm message also supports dynamic changes. You can add %d1 and %f1 to the alarm message, and then enter the value through the monitoring address function. When the alarm is triggered, the alarm message with the current value can be displayed immediately.

The formula provided by the software calculates all the alarm relevant data edited. Then, the set non-volatile memory (HMI, USB Disk, and SD) saves these calculation results. For data saved in the HMI, the alarm data size is subject to change based on the HMI model, you can see the specifications for non-volatile memory in the HMI installation manual. For data saved in the external storage devices (USB Disk or SD Card), the alarm data size is determined by the external storage devices.

The alarm formulas are applicable to the **Alarm History Table** and **Alarm Frequency Table**. The CSV file size is determined by the message (length) entered, there is no formula for the CSV file.

The following describes the formulas for the **Alarm History Table** and **Alarm Frequency Table**.

1. Alarm History Table

$$\{[6 \text{ Bytes}(a) + 2 \text{ Bytes}(b)] \times N(c)\} + 6 \text{ Bytes}(d) = \text{Actual file size Bytes}$$

a	Time and Date Data
b	Alarm Data
c	Scan Points
d	Data File Header

2. Alarm Frequency Table

$$2 \text{ Bytes}(a) \times N(b) = \text{Actual file size Bytes}$$


a	Alarm Frequency Data
b	Alarm Records

How to open the **Alarm** setting page?

- In the **Project** pane, double click **Alarm**.
- On the toolbar, click **Data Management > Alarm Settings**.


Use the following the steps to set an alarm.

1. Click **Data Management > Alarm Settings** on the toolbar.
 2. In the **Alarm** setting page, set the alarm for continuous alarm address and non-continuous alarm address.
- **Continuous Alarm address:** Add 3 alarms.




No.	Enable	Message Content	Category	Trigger Condition	Monitor Address	Text Color	Alarm Screen	Mail	Notification
1*	<input checked="" type="checkbox"/>	Alarm1	0	On	...	RGB(0, 0, 0)	None		
2*	<input checked="" type="checkbox"/>	Alarm2	0	On	...	RGB(0, 0, 0)	None		
3*	<input checked="" type="checkbox"/>	Alarm3	0	On	...	RGB(0, 0, 0)	None		

Set the alarm Address in the Properties tab, as shown below.




Address	
Address	\$0
Acknowledge all alarms	None

- **Non-continuous Alarm address:** Click  on the toolbar and set the **Type**, **Address**, and **Trigger Condition**.




No.	Enable	Message Content	Category	Type	Address	Trigger Condition	Monitor Address	Text Color	Alarm Screen	Mail	Notification
1*	<input checked="" type="checkbox"/>	Alarm1	0	Word	\$10	0 <= \$10 <= 9999	...	RGB(255, 0, 0)	2 - Screen_2		
2*	<input checked="" type="checkbox"/>	Alarm2	0	Word	\$11	\$11 > 10000	...	RGB(0, 0, 0)	None		
3*	<input checked="" type="checkbox"/>	Alarm3	0	Bit	\$0.0	On	...	RGB(0, 0, 0)	None		

- In the **Alarm** setting page, set the **Scan Time (seconds)** and **Alarm Moving Sign** in the **Properties** tab.



Address	
Address	\$0
Acknowledge all alarms	None
Detail	
Scan Time (seconds)	1
Max Records	500
Non-volatile Data Storage	None
Export CSV File	No
CSV Field Setting	...
Exit Screensaver when alarm occurs	Yes
Time to enter screen saver again	No alarm is triggered
Display alarm screen	Auto
Alarm Moving Sign	
Enable	Yes
Position	Top
Direction	Right
Points per time	20
Interval (ms)	400
Background color	ff0000
Translucent	255

- Click **Data Management > Alarm** on the toolbar and select **Alarm History Table**, and add it to the screen.
- In the **Alarm History Table** element, select the items to display in the **Field attributes** tab.




Main		Style		Operating conds.		Field attributes		Function Buttons		Coord.	
<input checked="" type="checkbox"/>	No.	30	No								
<input type="checkbox"/>	Group	50	Group								
<input checked="" type="checkbox"/>	Trigger Time	120	Trigger								
<input checked="" type="checkbox"/>	Alarm Message	250	Message								
<input checked="" type="checkbox"/>	Alarm Counts	50	Frequency								
<input checked="" type="checkbox"/>	Recovery Time	120	Recovery								
<input checked="" type="checkbox"/>	Confirmation Time	120	Ack								

Column order:

- Alarm Message
- No.
- Trigger Time
- Alarm Counts
- Recovery Time
- Confirmation Time

6. Create elements on the screen to trigger alarms.

- **Continuous Alarm address:** Create 3 **Maintained Button** elements with addresses set to \$0.0, \$0.1, and \$0.2.



- **Non-continuous Alarm address:** Create 2 **Numeric Entry** elements to trigger Word type alarms and a **Button** element to trigger Bit type alarms.



7. Click **General > New Screen > Subscreen** on the toolbar.

8. In the **Alarm** setting page, set the **Alarm Screen** of the number 1 item to the subscreen you have created.

Detail		Properties							
No.	<input type="checkbox"/> Enable	Message Content	Category	Trigger Condition	Monitor Ac	Text Color	Alarm Screen	Mail	Notification
1*	<input checked="" type="checkbox"/>	TEST1	0	On	...	RGB(0, 0, 0)	2 - Screen_2		
2*	<input checked="" type="checkbox"/>	TEST2	0	On	...	RGB(0, 0, 0)	None		
3*	<input checked="" type="checkbox"/>	TEST3	0	On	...	RGB(0, 0, 0)	None		

9. Click **Project > Compile All** on the toolbar and download the screen to the HMI.

The following example shows the behavior of continuous alarm address on the HMI.

Since Alarm 1 has an alarm screen set up, when clicking the button with the address \$0.0 will trigger Alarm 1 and pop up an alarm dialog.

Delta DOP-110WS Emulator, V1.0130, Offline Mode

Alarm1 Alarm1 Alarm1 Alarm1 Alarm1 Alarm1 Alarm1 Alarm1

Alarm1 Alarm

Alarm Historical

No	Message	Trigger	Recovery
0001	Alarm1	14:06:10 11/16/202	

Active Alarm

Group	Message	Trigger
1	Alarm1	14:06:10 11/16/202

Alarm Frequency

Message	Frequency
Alarm1	1
Alarm2	0
Alarm3	0

Warning

addresses are continuous

arm1 Alarm2 Alarm3

addresses are uncontinuous

0 0 Alarm3

Switch Language

繁中 English 簡中

When the alarm is recovered, the **Recovery** field of the **Alarm History Table** displays the recovery time.

Delta DOP-110WS Emulator, V1.0130, Offline Mode

Alarm2 Alarm1 Alarm2 Alarm1 Alarm2 Alarm1 Alarm2 Alarm1 Alarm2 Alarm1 Alarm2 Alarm1 Alarm2 Alarm1 Alarm

Alarm1 Alarm2 Alarm1 Alarm2 Alarm1

Alarm Historical

No	Message	Trigger	Recovery
0001	Alarm1	14:06:10 11/16/202	
0002	Alarm2	14:06:34 11/16/202	
0003	Alarm3	14:06:38 11/16/202	14:06:41 11/16/2023

Active Alarm

Group	Message	Trigger
2	Alarm2	14:06:34 11/16/2023
1	Alarm1	14:06:10 11/16/2023

Alarm Frequency

Message	Frequency
Alarm1	1
Alarm2	1
Alarm3	1

Alarm addresses are continuous

Alarm1 Alarm2 Alarm3

Alarm addresses are uncontinuous














0 0 Alarm3






Switch Language

繁中 English 簡中

Alarm Settings Toolbar


The following table lists the settings on the toolbar in the **Alarm** setting page and their descriptions.

Setting	Description						
	Click to copy the selected alarm items. <ul style="list-style-type: none"> Support single and multiple copy functions. Press Ctrl to select the alarm item to copy, and press Shift to select a range of alarm items to copy. 						
	Click to paste the selected alarm items. <ul style="list-style-type: none"> Supports single and multiple paste functions. Note: You must first copy the alarm items.						
	After selecting the alarm items, click this icon to delete. The settings of the item will return to default settings.						
	Click to display the next 2048 entries.						
	Click to display the previous 2048 entries.						
Alarm Font Size	Set the text size for displaying alarm message on the screen.						
Alarm Font	Set the font for displaying alarm message on the screen.						
Alarm Font Ratio	<p>Set the scaling ratio for display alarm message on the screen. The value range is 33% – 200%, and the default value is 100%.</p> <table border="1"> <thead> <tr> <th>Ratio</th><th>Result</th></tr> </thead> <tbody> <tr> <td>100%</td><td>  </td></tr> <tr> <td>150%</td><td>  </td></tr> </tbody> </table>	Ratio	Result	100%		150%	
Ratio	Result						
100%							
150%							
	<p>Click to switch between Continuous Alarm Address and Non-continuous Alarm Address.</p> <p>Set the alarm address in the Alarm setting page, and the alarm can be triggered using Bit or Word addresses.</p> 						


Setting	Description																																																																																																																																																	
	<p>Click to quickly set alarm categories in batches.</p> <p>In the Alarm Category Settings dialog, set the Starting Alarm Number, Ending Alarm Number and Category ID, click Batch Setting. The alarms and categories from the start number to the end number will be set to the specified numbers.</p> <ul style="list-style-type: none">The category number range is 0 ~ 4095.																																																																																																																																																	
	<p>Click to import the alarm data file. Supports .xlsx, .alm, and .ini formats.</p> <p>Note: .alm and .ini are alarm configuration files exported by the old software.</p>																																																																																																																																																	
	<p>Click to export the edited alarm data file. Supports .xlsx format.</p> <p>The exported .xlsx file contains AlarmContent and AlarmSetting. You can edit the contents of each field and alarm properties of the alarm in the alarm data file.</p> <div><table><thead><tr><th></th><th>A</th><th>B</th><th>C</th><th>D</th></tr></thead><tbody><tr><td>1</td><td>[Language]</td><td>[Font]</td><td>[Size]</td><td>[Ratio]</td></tr><tr><td>2</td><td></td><td>Font</td><td>Size</td><td>Ratio</td></tr><tr><td>3</td><td>中文</td><td>Delius</td><td>20</td><td>100</td></tr><tr><td>4</td><td>English</td><td>Elephant</td><td>24</td><td>100</td></tr><tr><td>5</td><td>簡中</td><td>Comic Sans MS</td><td>28</td><td>100</td></tr><tr><td>6</td><td></td><td></td><td></td><td></td></tr><tr><td>7</td><td>Alarm Setting</td><td>Address</td><td></td><td></td></tr><tr><td>8</td><td>Address</td><td>Address</td><td>\$0</td><td></td></tr><tr><td>9</td><td>Scan Time</td><td>Scan Time (seconds)</td><td>3.000000</td><td></td></tr><tr><td>10</td><td>Max Records</td><td>Max Records</td><td></td><td>500</td></tr><tr><td>11</td><td>Hold</td><td>Enable non-volatile mem</td><td></td><td>1</td></tr><tr><td>12</td><td>Hold Place</td><td>Non-volatile Data Stora</td><td></td><td>0</td></tr><tr><td>13</td><td>CSV</td><td>Export CSV File</td><td></td><td>1</td></tr><tr><td>14</td><td>CSV Column Setting</td><td>CSV Field Setting</td><td>0 1 3 4 2 </td><td></td></tr><tr><td>15</td><td>Exit Screen Saver</td><td>Exit Screensaver when a</td><td></td><td>1</td></tr><tr><td>16</td><td>Time To Enter Screen Sa</td><td>Time to enter screen sav</td><td></td><td>0</td></tr><tr><td>17</td><td>Screen Display Mode</td><td>Display alarm screen</td><td></td><td>0</td></tr><tr><td>18</td><td>Continue Address</td><td>Continuous alarm addre</td><td></td><td>1</td></tr><tr><td>19</td><td></td><td></td><td></td><td></td></tr><tr><td>20</td><td>Alarm Moving Sign</td><td>Alarm Moving Sign</td><td></td><td></td></tr><tr><td>21</td><td>Enable</td><td>Enable</td><td></td><td>1</td></tr><tr><td>22</td><td>Position</td><td>Position</td><td></td><td>0</td></tr><tr><td>23</td><td>Direction</td><td>Direction</td><td></td><td>1</td></tr><tr><td>24</td><td>Moving Points</td><td>Points per time</td><td></td><td>20</td></tr><tr><td>25</td><td>Interval</td><td>Interval (ms)</td><td></td><td>400</td></tr><tr><td>26</td><td>BackgroundColor</td><td>Background color</td><td>RGB(213,213,213)</td><td></td></tr><tr><td>27</td><td>Opacity</td><td>Translucent</td><td></td><td>255</td></tr><tr><td>28</td><td>AckAllAddress</td><td>Acknowledge all alarms</td><td>None</td><td></td></tr></tbody></table></div>		A	B	C	D	1	[Language]	[Font]	[Size]	[Ratio]	2		Font	Size	Ratio	3	中文	Delius	20	100	4	English	Elephant	24	100	5	簡中	Comic Sans MS	28	100	6					7	Alarm Setting	Address			8	Address	Address	\$0		9	Scan Time	Scan Time (seconds)	3.000000		10	Max Records	Max Records		500	11	Hold	Enable non-volatile mem		1	12	Hold Place	Non-volatile Data Stora		0	13	CSV	Export CSV File		1	14	CSV Column Setting	CSV Field Setting	0 1 3 4 2		15	Exit Screen Saver	Exit Screensaver when a		1	16	Time To Enter Screen Sa	Time to enter screen sav		0	17	Screen Display Mode	Display alarm screen		0	18	Continue Address	Continuous alarm addre		1	19					20	Alarm Moving Sign	Alarm Moving Sign			21	Enable	Enable		1	22	Position	Position		0	23	Direction	Direction		1	24	Moving Points	Points per time		20	25	Interval	Interval (ms)		400	26	BackgroundColor	Background color	RGB(213,213,213)		27	Opacity	Translucent		255	28	AckAllAddress	Acknowledge all alarms	None	
	A	B	C	D																																																																																																																																														
1	[Language]	[Font]	[Size]	[Ratio]																																																																																																																																														
2		Font	Size	Ratio																																																																																																																																														
3	中文	Delius	20	100																																																																																																																																														
4	English	Elephant	24	100																																																																																																																																														
5	簡中	Comic Sans MS	28	100																																																																																																																																														
6																																																																																																																																																		
7	Alarm Setting	Address																																																																																																																																																
8	Address	Address	\$0																																																																																																																																															
9	Scan Time	Scan Time (seconds)	3.000000																																																																																																																																															
10	Max Records	Max Records		500																																																																																																																																														
11	Hold	Enable non-volatile mem		1																																																																																																																																														
12	Hold Place	Non-volatile Data Stora		0																																																																																																																																														
13	CSV	Export CSV File		1																																																																																																																																														
14	CSV Column Setting	CSV Field Setting	0 1 3 4 2																																																																																																																																															
15	Exit Screen Saver	Exit Screensaver when a		1																																																																																																																																														
16	Time To Enter Screen Sa	Time to enter screen sav		0																																																																																																																																														
17	Screen Display Mode	Display alarm screen		0																																																																																																																																														
18	Continue Address	Continuous alarm addre		1																																																																																																																																														
19																																																																																																																																																		
20	Alarm Moving Sign	Alarm Moving Sign																																																																																																																																																
21	Enable	Enable		1																																																																																																																																														
22	Position	Position		0																																																																																																																																														
23	Direction	Direction		1																																																																																																																																														
24	Moving Points	Points per time		20																																																																																																																																														
25	Interval	Interval (ms)		400																																																																																																																																														
26	BackgroundColor	Background color	RGB(213,213,213)																																																																																																																																															
27	Opacity	Translucent		255																																																																																																																																														
28	AckAllAddress	Acknowledge all alarms	None																																																																																																																																															
	<p>Click to optimize the reading of non-continuous alarm addresses and speed up the alarm reading and writing.</p>																																																																																																																																																	

Alarm Message Settings

The following table lists the setting in the **Detail** tab in the **Alarm** setting page.

Setting	Description
No.	The number of alarm messages, and supports up to 20480 alarms.
Enable	<p>Enable / disable the alarm.</p> <ul style="list-style-type: none"> If selected, run according to the set alarm rules after downloading. When you change any alarm setting field, the alarm is automatically enabled. If not selected, the alarm content will not be checked when compiling the rule, and the alarm rule will not be executed when downloading to the HMI.
Message Content	<p>Set the content of the alarm message to be displayed.</p> <ul style="list-style-type: none"> If you want to dynamically display message content, you can use it with the Monitor Address field. If you want to set the message content displayed in different languages, you can go to Project pane > Multi-language to add a new language, and then go to General > Language drop-down menu to switch.
Category	<p>Set the category of the alarm number.</p> <p>On the toolbar, click  to quickly set the category numbers. After the setting is complete, you can set the display order in the alarm elements or display the alarm category according to the set range. The value range is 0–4095.</p>
Type	<p>Set the trigger type of the alarm as Word or Bit.</p> <p>Note: You must switch the alarm address to non-continuous.</p>
Address	<p>Set the trigger address of the alarm.</p> <p>Note: You must switch the alarm address to non-continuous.</p>
Trigger Condition	<ul style="list-style-type: none"> Continuous Alarm Address: Set the Trigger Condition as On or Off. <ul style="list-style-type: none"> Select On to trigger an alarm when the Bit is On. Select Off to trigger an alarm when the Bit is Off. Non-continuous Alarm Address: Establish the Trigger conditions according to the set trigger type. <ul style="list-style-type: none"> Select Bit for Trigger Type, the Trigger Condition can be configured as On or Off. Select Word for Trigger Type, you can configure the trigger condition range in the Trigger Condition field.

Setting	Description				
Monitor Address	<div><div>Configure the settings for dynamic display of alarm message. The alarm message can display the current value of the monitor address.</div><div><div><div><div><div></div><div>No.</div></div><div><div></div><div>Enable</div></div><div><div></div><div>Message Content</div></div></div><div><div>3*</div><div><div></div><div></div></div><div><div></div><div>A:%d1,B:%d2,C:%d3,D:%s4,E,%f5</div></div></div></div><div><div>Result</div><div><div>A:65535,B:-32767,C:4D2,D:ABC,E,123.123</div></div></div></div><div><div>Text Color</div><div>Set the text color of the alarm message displayed by the alarm element or the alarm moving sign when the alarm is triggered.</div></div><tr><td>Alarm Screen</td><td>Set whether to show the specified alarm screen when the alarm is triggered. The default value is None.</td></tr><tr><td>Mail</td><td><div><div>Set the mail information. When an alarm occurs, the Mail function sends an e-mail to relevant recipients.</div><div>Click Recipient, Copy or Bcc in the Select Name dialog and select Select contact to select the recipient's email address in the contact list.</div><div><div><div>Select name</div><div><div><div><div><div></div><div>Select contact</div></div><div><div></div><div>Select group</div></div><div><div>Contact person...</div></div></div><div><div><div><div><div></div><div>Name</div></div><div><div></div><div>Email address</div></div></div><div><div>New contact person1</div><div>Contact1@domain.com</div></div></div><div><div><div>Recipient</div><div>New contact person1</div></div><div><div>Copy</div><div></div></div><div><div>Bcc</div><div></div></div></div><div><div>OK</div><div>Cancel</div></div></div></div></div></div></div></div></td></tr></div>	Alarm Screen	Set whether to show the specified alarm screen when the alarm is triggered. The default value is None .	Mail	<div><div>Set the mail information. When an alarm occurs, the Mail function sends an e-mail to relevant recipients.</div><div>Click Recipient, Copy or Bcc in the Select Name dialog and select Select contact to select the recipient's email address in the contact list.</div><div><div><div>Select name</div><div><div><div><div><div></div><div>Select contact</div></div><div><div></div><div>Select group</div></div><div><div>Contact person...</div></div></div><div><div><div><div><div></div><div>Name</div></div><div><div></div><div>Email address</div></div></div><div><div>New contact person1</div><div>Contact1@domain.com</div></div></div><div><div><div>Recipient</div><div>New contact person1</div></div><div><div>Copy</div><div></div></div><div><div>Bcc</div><div></div></div></div><div><div>OK</div><div>Cancel</div></div></div></div></div></div></div></div>
Alarm Screen	Set whether to show the specified alarm screen when the alarm is triggered. The default value is None .				
Mail	<div><div>Set the mail information. When an alarm occurs, the Mail function sends an e-mail to relevant recipients.</div><div>Click Recipient, Copy or Bcc in the Select Name dialog and select Select contact to select the recipient's email address in the contact list.</div><div><div><div>Select name</div><div><div><div><div><div></div><div>Select contact</div></div><div><div></div><div>Select group</div></div><div><div>Contact person...</div></div></div><div><div><div><div><div></div><div>Name</div></div><div><div></div><div>Email address</div></div></div><div><div>New contact person1</div><div>Contact1@domain.com</div></div></div><div><div><div>Recipient</div><div>New contact person1</div></div><div><div>Copy</div><div></div></div><div><div>Bcc</div><div></div></div></div><div><div>OK</div><div>Cancel</div></div></div></div></div></div></div></div>				

Setting	Description
	<p>Note: E-mail sending requires SMTP settings. Go to General > Configuration > SMTP to configure the mail address.</p> 

Alarm Property Settings

The following table lists the settings in the **Properties** tab in the **Alarm** setting page.

The screenshot shows the 'Elephant' application window. The title bar includes standard window controls and a zoom level of 100%. The interface has two tabs: 'Detail' (selected) and 'Properties'. The 'Detail' tab displays a list of properties for the 'Alarm Moving Sign' (indicated by a blue circle with the number 3). The properties are listed in a table-like format with two columns: the property name and its value.

Alarm Moving Sign	
Enable	Yes
Position	Top
Direction	Right
Points per time	20
Interval (ms)	400
Background color	■ ff0000
Translucent	255

① Address

Setting	Description
Address	Set the Internal Memory or the controller register address to read addresses. Note: Address field is available only the alarm address is switched to continuous.
Acknowledge all alarms	Set the Internal Memory address to acknowledge all alarms. When the alarm is triggered, the Alarm History Table will record the alarm acknowledge time.













② Detail

Setting	Description
Scan Time (seconds)	Set the time when the alarm is updated. The value range is 0.5–10, and the default value is 3.
Max Records	Set the max records for scan point. When the recorded scan point reaches the maximum, the record starts from 1 and overwrites the previous data. The value range is 1–9,999, and the default value is 500.
Non-volatile Data Storage	Set the storage location when the power is off. The storage location varies depending on the HMI model, including None, HMI, USB Disk, USB Disk 2, and SD. <ul style="list-style-type: none"> If select HMI, when the HMI is powered off, the data is saved in the HMI SRAM. If Export CSV File is set to Yes, set Non-volatile Data Storage to USB Disk or SD.
Export CSV File	Set as Yes to save the alarm data as CSV files in the external storage devices (USB Disk or SD Card).
CSV Field Setting	Select the column items for the exported CSV file, and you can adjust the column order. Use the Print Output button element to print the historical alarm content into a CSV file according to the CSV Field Setting and store it in the external storage devices. Note: This setting is available only the Export CSV File is set to Yes .
Exit Screensaver when alarm occurs / Time to enter screen saver	<ul style="list-style-type: none"> These functions are used with the screen saver. Set Exit Screensaver when alarm occurs to Yes: When an alarm occurs, the screensaver screen will stop immediately. if the screensaver screen is not set, the HMI will not enter backlight mode.

Setting	Description						
again	<p>The following table lists the timing to enter the screensaver screen again.</p> <table> <tr> <th>Timing</th><th>Description</th></tr> <tr> <td>No alarm is triggered on the HMI</td><td>As long as no alarm is triggered, the HMI can enter the screensaver mode.</td></tr> <tr> <td>No alarm is triggered during the screen saver waiting time</td><td> <ul style="list-style-type: none"> As long as no alarm is triggered during the screen saver waiting time, the HMI can enter the screensaver mode. The screen saver waiting time can be set in Configuration > Screensaver Setup. </td></tr> </table> <ul style="list-style-type: none"> Set Exit Screensaver when alarm occurs to No: The HMI exits the screen saver when the alarm is triggered for the first time. After that, whether the alarm is cleared or not, the HMI enters the screensaver mode according to the set time. Screensaver screen creation: Create a normal screen and go to General > Screensaver Setup. In the Screensaver Setup dialog, drag the screen from All Screens to Screensaver Screen. 	Timing	Description	No alarm is triggered on the HMI	As long as no alarm is triggered, the HMI can enter the screensaver mode.	No alarm is triggered during the screen saver waiting time	<ul style="list-style-type: none"> As long as no alarm is triggered during the screen saver waiting time, the HMI can enter the screensaver mode. The screen saver waiting time can be set in Configuration > Screensaver Setup.
Timing	Description						
No alarm is triggered on the HMI	As long as no alarm is triggered, the HMI can enter the screensaver mode.						
No alarm is triggered during the screen saver waiting time	<ul style="list-style-type: none"> As long as no alarm is triggered during the screen saver waiting time, the HMI can enter the screensaver mode. The screen saver waiting time can be set in Configuration > Screensaver Setup. 						
Display alarm screen	<p>Set to display the alarm screen automatically or manually.</p> <ul style="list-style-type: none"> Set to Auto: The HMI displays the alarm screen as soon as the alarm with a set alarm screen is triggered. Set to Manual: It must be controlled with the Alarm History Table element. The triggering methods are as follows: <ul style="list-style-type: none"> In the element property dialog, set Action Control Addr. in the Operating conds. tab. When the value is set to 2, the alarm screen displays. In the element property dialog, select the Trigger alarm screen checkbox in the Function Buttons tab to display the alarm screen. 						

③ Alarm Moving Sign

Setting	Description
Enable	<p>Set whether to display the alarm moving sign. The default is No.</p> <ul style="list-style-type: none"> Set to Yes: When the alarm is triggered, no matter which page you operate on the HMI, an alarm moving sign shows at the specified position on the screen. Set to No: When the alarm is triggered, alarm messages are not displayed.

Setting	Description										
Position	<p>Set the display position. The default is Top.</p> <ul style="list-style-type: none"> Set to Top: When the alarm is triggered, the alarm message is displayed at the top of the HMI screen. Set to Bottom: When the alarm is triggered, the alarm message is displayed at the bottom of the HMI screen. 										
Direction	<table> <tr> <th>Direction</th><th>Result</th></tr> <tr> <td>Left</td><td>  </td></tr> <tr> <td>Right</td><td>  </td></tr> <tr> <td>Up</td><td>  </td></tr> <tr> <td>Down</td><td>  </td></tr> </table>	Direction	Result	Left		Right		Up		Down	
Direction	Result										
Left											
Right											
Up											
Down											
Points per time	Set the points per time. The greater the number, the greater the distance each time the text moves. The value range is 1–50 (pixel).										
Interval (ms)	<p>Set how often the alarm moving sign moves. The value range is 1–50.</p> <p>Note: The moving distance is determined by the setting of Points per time.</p>										
Background color	Set the background color of the alarm moving sign.										

Setting	Description																																																																																
Translucent	Set the transparency level of the alarm moving sign. The value range is 0–255, and the default value is 255.																																																																																
	<table><tr><th>Value</th><th>Result</th></tr><tr><td rowspan="7">255</td><td>alarm 6 alarm 7</td></tr><tr><td><table><tr><th>No</th><th>Message</th><th>Frequency</th><th>Trigger</th><th>Ack</th><th>Recovery</th></tr><tr><td>0001</td><td>alarm 6</td><td>1</td><td>15:29:12 11/16/2023</td><td></td><td></td></tr><tr><td>0002</td><td>alarm 7</td><td>1</td><td>15:29:12 11/16/2023</td><td></td><td></td></tr><tr><td>0003</td><td>alarm 8</td><td>1</td><td>15:29:12 11/16/2023</td><td></td><td></td></tr><tr><td>0004</td><td>alarm 9</td><td>1</td><td>15:29:13 11/16/2023</td><td></td><td></td></tr><tr><td>0005</td><td>alarm 10</td><td>1</td><td>15:29:13 11/16/2023</td><td></td><td></td></tr></table></td></tr><tr><td rowspan="7">100</td><td>alarm / alarm 8</td></tr><tr><td><table><tr><th>No</th><th>Message</th><th>Frequency</th><th>Trigger</th><th>Ack</th><th>Recovery</th></tr><tr><td>0001</td><td>alarm 6</td><td>1</td><td>15:29:12 11/16/2023</td><td></td><td></td></tr><tr><td>0002</td><td>alarm 7</td><td>1</td><td>15:29:12 11/16/2023</td><td></td><td></td></tr><tr><td>0003</td><td>alarm 8</td><td>1</td><td>15:29:12 11/16/2023</td><td></td><td></td></tr><tr><td>0004</td><td>alarm 9</td><td>1</td><td>15:29:13 11/16/2023</td><td></td><td></td></tr><tr><td>0005</td><td>alarm 10</td><td>1</td><td>15:29:13 11/16/2023</td><td></td><td></td></tr></table></td></tr></table>	Value	Result	255	alarm 6 alarm 7	<table><tr><th>No</th><th>Message</th><th>Frequency</th><th>Trigger</th><th>Ack</th><th>Recovery</th></tr><tr><td>0001</td><td>alarm 6</td><td>1</td><td>15:29:12 11/16/2023</td><td></td><td></td></tr><tr><td>0002</td><td>alarm 7</td><td>1</td><td>15:29:12 11/16/2023</td><td></td><td></td></tr><tr><td>0003</td><td>alarm 8</td><td>1</td><td>15:29:12 11/16/2023</td><td></td><td></td></tr><tr><td>0004</td><td>alarm 9</td><td>1</td><td>15:29:13 11/16/2023</td><td></td><td></td></tr><tr><td>0005</td><td>alarm 10</td><td>1</td><td>15:29:13 11/16/2023</td><td></td><td></td></tr></table>	No	Message	Frequency	Trigger	Ack	Recovery	0001	alarm 6	1	15:29:12 11/16/2023			0002	alarm 7	1	15:29:12 11/16/2023			0003	alarm 8	1	15:29:12 11/16/2023			0004	alarm 9	1	15:29:13 11/16/2023			0005	alarm 10	1	15:29:13 11/16/2023			100	alarm / alarm 8	<table><tr><th>No</th><th>Message</th><th>Frequency</th><th>Trigger</th><th>Ack</th><th>Recovery</th></tr><tr><td>0001</td><td>alarm 6</td><td>1</td><td>15:29:12 11/16/2023</td><td></td><td></td></tr><tr><td>0002</td><td>alarm 7</td><td>1</td><td>15:29:12 11/16/2023</td><td></td><td></td></tr><tr><td>0003</td><td>alarm 8</td><td>1</td><td>15:29:12 11/16/2023</td><td></td><td></td></tr><tr><td>0004</td><td>alarm 9</td><td>1</td><td>15:29:13 11/16/2023</td><td></td><td></td></tr><tr><td>0005</td><td>alarm 10</td><td>1</td><td>15:29:13 11/16/2023</td><td></td><td></td></tr></table>	No	Message	Frequency	Trigger	Ack	Recovery	0001	alarm 6	1	15:29:12 11/16/2023			0002	alarm 7	1	15:29:12 11/16/2023			0003	alarm 8	1	15:29:12 11/16/2023			0004	alarm 9	1	15:29:13 11/16/2023			0005	alarm 10	1	15:29:13 11/16/2023		
	Value	Result																																																																															
	255	alarm 6 alarm 7																																																																															
<table><tr><th>No</th><th>Message</th><th>Frequency</th><th>Trigger</th><th>Ack</th><th>Recovery</th></tr><tr><td>0001</td><td>alarm 6</td><td>1</td><td>15:29:12 11/16/2023</td><td></td><td></td></tr><tr><td>0002</td><td>alarm 7</td><td>1</td><td>15:29:12 11/16/2023</td><td></td><td></td></tr><tr><td>0003</td><td>alarm 8</td><td>1</td><td>15:29:12 11/16/2023</td><td></td><td></td></tr><tr><td>0004</td><td>alarm 9</td><td>1</td><td>15:29:13 11/16/2023</td><td></td><td></td></tr><tr><td>0005</td><td>alarm 10</td><td>1</td><td>15:29:13 11/16/2023</td><td></td><td></td></tr></table>		No	Message		Frequency	Trigger	Ack	Recovery	0001	alarm 6	1	15:29:12 11/16/2023			0002	alarm 7	1	15:29:12 11/16/2023			0003	alarm 8	1	15:29:12 11/16/2023			0004	alarm 9	1	15:29:13 11/16/2023			0005	alarm 10	1	15:29:13 11/16/2023																																													
No		Message	Frequency		Trigger	Ack	Recovery																																																																										
0001		alarm 6	1		15:29:12 11/16/2023																																																																												
0002		alarm 7	1		15:29:12 11/16/2023																																																																												
0003		alarm 8	1	15:29:12 11/16/2023																																																																													
0004		alarm 9	1	15:29:13 11/16/2023																																																																													
0005	alarm 10	1	15:29:13 11/16/2023																																																																														
100	alarm / alarm 8																																																																																
	<table><tr><th>No</th><th>Message</th><th>Frequency</th><th>Trigger</th><th>Ack</th><th>Recovery</th></tr><tr><td>0001</td><td>alarm 6</td><td>1</td><td>15:29:12 11/16/2023</td><td></td><td></td></tr><tr><td>0002</td><td>alarm 7</td><td>1</td><td>15:29:12 11/16/2023</td><td></td><td></td></tr><tr><td>0003</td><td>alarm 8</td><td>1</td><td>15:29:12 11/16/2023</td><td></td><td></td></tr><tr><td>0004</td><td>alarm 9</td><td>1</td><td>15:29:13 11/16/2023</td><td></td><td></td></tr><tr><td>0005</td><td>alarm 10</td><td>1</td><td>15:29:13 11/16/2023</td><td></td><td></td></tr></table>	No	Message	Frequency	Trigger	Ack	Recovery	0001	alarm 6	1	15:29:12 11/16/2023			0002	alarm 7	1	15:29:12 11/16/2023			0003	alarm 8	1	15:29:12 11/16/2023			0004	alarm 9	1	15:29:13 11/16/2023			0005	alarm 10	1	15:29:13 11/16/2023																																														
	No	Message	Frequency	Trigger	Ack	Recovery																																																																											
	0001	alarm 6	1	15:29:12 11/16/2023																																																																													
	0002	alarm 7	1	15:29:12 11/16/2023																																																																													
	0003	alarm 8	1	15:29:12 11/16/2023																																																																													
	0004	alarm 9	1	15:29:13 11/16/2023																																																																													
0005	alarm 10	1	15:29:13 11/16/2023																																																																														

Alarm Element

You can create alarm element to display alarm status. Alarm elements including Alarm History Table, Active Alarm List, Alarm Frequency Table, Alarm Moving Sign, and Gantt Chart. This section introduces the properties of each alarm element.

Common Properties

- **Main – Enable group number filtering**

You can select the group number for **Category** in the **Detail** in the alarm setting page.

In the alarm element property dialog, select the **Enable group number filtering** checkbox in the **Main** tab. On the HMI, the element will display the alarm group according to the specified number. The value of the group number can be a variable or constant.

Note: When **the Group** is 0, all alarms are displayed.

- **Operating conds. – Filter**

In the alarm element property dialog, you can use the filter function to configure the items displayed on the alarm element in the **Operating conds.** tab.

The following table lists the settings in the **Filter** area in the Operating conds. tab and their descriptions.

Setting	Description	
Filter control address	Set the filter control address to filter the specified items.	
	Value	Action description
	0	Default status, displays all triggered alarms.
	1	Hides the alarms with both Recovery Time and Acknowledge Time .
	2	Hides the alarms with Recovery Time .
	3	Hides the alarms with Recovery Time or Acknowledgement Time .
	4	Hides the alarms with Acknowledgement Time .
	5	<ul style="list-style-type: none">This setting must be used with Alarm counter display.The alarm display count refers to the value of Alarm counter display. When the alarm display count is smaller than this value, the alarm is hidden.
6	<ul style="list-style-type: none">This setting must be used with Alarm category start addr. and Alarm category end addr.When the alarm category number is not within the range set by Alarm category start addr. and Alarm category end addr., the alarm is hidden.	
Alarm counter display	<ul style="list-style-type: none">This setting is applicable to the Alarm History Table element and the must be used with Filter control address.When Filter control address is set to 5, enter the value of the alarm count.	
	Example	Description
	Alarm element has alarms with alarm counts 1, 2, and 3 times	<ul style="list-style-type: none">Set to 1 for Alarm counter display, the Alarm History Table element displays the alarms with 1 or more alarm counts.Set to 2 for Alarm counter display, the Alarm History Table element displays the alarms with 2 or more alarm counts.Set to 3 for Alarm counter display, the Alarm History Table element displays the alarms with 3 or more alarm counts.


Alarm category start addr./ Alarm category end addr.	<ul style="list-style-type: none"> This setting must be used with Filter control address. When Filter control address is set to 6, enter the alarm category number. 	
	Example	Description
	Alarm element has alarms with alarm category numbers 1 and 5	<ul style="list-style-type: none"> Set to 1 for Alarm category start addr. and 3 for Alarm category end addr., only the alarms with alarm category number 1 are displayed on the alarm element. Set to 1 for Alarm category start addr. and 5 for Alarm category end addr., the alarms with alarm category numbers 1 and 5 are displayed on the alarm element.




• Operating conds. – Control



In the alarm element property dialog, you can set the scroll control address in the **Operating conds.** tab and switch the alarm table display page on the HMI through the memory address. The scroll control supports 16-bit Unsigned, 16-bit signed, 32-bit Unsigned, and 32-bit signed data formats.

• Style

The display style of Alarm elements on the HMI can be set.


Setting	Description
Background Color	<p>Set the background color of the element. The default is white. When set to red, it displays as follows.</p> 



Setting	Description
Border Color	<p>Set the border color of the element. The default is gray. When set to red, it displays as follows.</p> 
Gridline Color / Show Gridlines	<p>Set the gridline color of the element. The default is white. When set to red, it displays as follows. Note: The Gridline Color setting is valid only when you select Yes for Show Gridlines.</p> 
Select Row Color	<p>Set the color of the selected row of data when operating the element on the HMI. The default is blue. When set to red, it displays as follows.</p> 

Setting	Description
Row Color	<p>Set the color to display for each row of the alarm. The default is light blue. When set to red, it displays as follows.</p> 
Alternating Row Color	<p>Set the color for the alternating row of the alarm. The default is blue. When set to red, it displays as follows.</p> 
Transparency	<p>Set the transparency of the element. The range value is 50–255, and the default value is 255. The smaller the value, the more transparent the element is.</p>

- Field attributes**

In the alarm element property dialog, set the field items to be displayed in the alarm table in the **Field attributes** tab.



Legend	Setting	Description	
①	Column display	Select the columns to be displayed in the element.	
②	Column width	Select or enter the width for each column.	
③	Column title	Enter the titles for each column.	
④	Column order	After selecting the columns to be displayed, click   to adjust the column displaying order.	
⑤	Allow to change the field width	Select to drag the field on the HMI to change the displaying width.	
⑥	Title bar	Title Text Alignment	Select the title bar text as left, center or right.
		Title Background	Select the background color of the title bar.
		Title Text Color	Set the text color of the title bar.
⑦	Date and time	Date Format	Set the display date format.
		Time Format	Select the display time format.
		Color	Select the display color of date and time. The default is black.

- **Function Buttons**

You can add function buttons in the **Function Buttons** tab of the alarm element properties dialog to control the display of the alarm table.

Setting	Description
Function Description	Select to add function buttons.
Default Description	Set the description of the function button. Click Set As Default Description to insert the default strings to the input fields. You can switch between the different languages to define the default text.
Default Button Width	Set the width of the function buttons. The value range is 25–100, and the default value is 60. After adjusting the width, right-click the element on the screen and select Rearrange Function Buttons , all function buttons display according to the settings.
Default Button Height	Set the width of the function buttons. The value range is 25–100, and the default value is 40. After adjusting the height, right-click the element on the screen and select Rearrange Function Buttons , all function buttons display according to the settings.

Alarm History Table Properties


- **Style**

You can set **Trigger Column Color**, **Confirm Column Color**, and **Recovery Column Color** after selecting **Color Mode** as **Alarm Status**. When an alarm is triggered on the HMI, colors display according to different statuses.

Example Setting


1. Select the **Color Mode**.
2. Trigger an alarm on the HMI.

The trigger column is displayed in red.




3. Click the **Acknowledge Alarm** or **Acknowledge All Alarm** button on the Alarm History Table.

The confirm column is displayed in green.



When an alarm is recovered, the recovery column is displayed in blue.



- Operating conds.

Alarm History Table

Preview

Message: ####

State: 0

Language: Language1

Element Description: 歷史警報表_001

Main Style **Operating conds.** Field attributes Function Buttons Coord.

1 Event

Action Control Addr.: None

2 Sort

☐ Use header controls to sort

Sorting Control Addr.: None

Sorting Order Address: None

Filter

Filter control address: None

Alarm counter display: None

Alarm category start addr.: None

Alarm category end addr.: None

OK Cancel

1 Event

Setting	Description	
Action Control Addr.	Set the action control address to change screens or acknowledge the alarms for specified alarms.	
	Value	Description
	0	Default status, no action.
	1	Acknowledge for selected alarms in the Alarm History Table element .
	2	If the selected alarm in the Alarm History Table element has a set alarm screen which is set to display manually, the alarm screen displays when the value is 2.

2 Sort

Setting	Description														
Use header controls to sort	<p>If selected, click the header of the Alarm History Table element to sort the alarms in ascending or descending order. The Sorting Control Addr. and Sorting Order Address settings are not available.</p> <p>Note: The sorting of the Message column is not supported.</p>														
Sorting Control Addr.	<p>Set Sort Control Addr. for the specified item.</p> <table> <tr> <th>Value</th><th>Description</th></tr> <tr> <td>0</td><td>Default status, no action.</td></tr> <tr> <td>1</td><td>Sort by Trigger Time.</td></tr> <tr> <td>2</td><td>Sort by Acknowledge Time.</td></tr> <tr> <td>3</td><td>Sort by Recovery Time.</td></tr> <tr> <td>4</td><td>Sort by alarm count.</td></tr> <tr> <td>5</td><td>Sort by alarm category.</td></tr> </table>	Value	Description	0	Default status, no action.	1	Sort by Trigger Time .	2	Sort by Acknowledge Time .	3	Sort by Recovery Time .	4	Sort by alarm count.	5	Sort by alarm category.
Value	Description														
0	Default status, no action.														
1	Sort by Trigger Time .														
2	Sort by Acknowledge Time .														
3	Sort by Recovery Time .														
4	Sort by alarm count.														
5	Sort by alarm category.														
Sorting Order Address	<p>Set the sorting order address with the Sorting Control Addr. value to determine the ascending or descending order. For example, if the Sorting Control Addr. is set to 1 and the Sorting Order Address is set to 0, the Trigger Time is sorted in ascending order.</p> <table> <tr> <th>Value</th><th>Description</th></tr> <tr> <td>0</td><td>Sort in ascending order.</td></tr> <tr> <td>1</td><td>Sort in descending order.</td></tr> </table>	Value	Description	0	Sort in ascending order.	1	Sort in descending order.								
Value	Description														
0	Sort in ascending order.														
1	Sort in descending order.														

Active Alarm List / Alarm Frequency Table Properties

- Operating conds.


Select the fields you want to display in the **Field attributes** tab, and then select **Use header controls to sort** checkbox in the **Operating conds.** tab, the **Default sort field** can be selected.

Alarm Moving Sign Properties

The **Alarm Moving Sign** element records the alarm number, time and date when an alarm is triggered. You can also set the time interval and moving distance according to your needs.

In the **Main** tab, you can set the content of the Alarm Moving Sign.

The following table lists the properties in the **Main** tab in the **Alarm Moving Sign** element and their descriptions.



Alarm Moving Sign

Preview

State: 0

Language: Language1

Element Description: 警報訊息走馬燈_004

Main Style Operating conds. Coord.

Memory

Invisible Address: None

Invisible State: On

Detail

1 Direction: Left

2 Interval(ms): 100

3 Points per time: 1

4 Status Display

☐ Time Format hh:mm:ss

☐ Date Format mm/dd/yy

Color

5 Others

☐ Alarm No.

☐ Alarm Group

☐ Enable group number filtering





☐ Group number is variable

Group 0

(0 : Show all)

OK Cancel

1 Direction

Setting	Description
Direction	Select the display direction. The default value is Left.
	<div>Left</div> 
	<div>Right</div> 
	<div>Up</div> 
	<div>Down</div> 

2 Interval

Setting	Description
Interval (ms)	Set how often the message moves. The default value is 100.



3 Points per time

Setting	Description
Points per time	Set the distance each time text moves. The greater the number, the greater the distance each time the text moves. The value range is 1–50, and the default value is 1.

4 Status Display

Setting	Description
Time format	Select the time format. The default value is hh:mm:ss.
Date format	Select the date format. The default value is mm/dd/yy.
Display Color	Select the display color of the time and date.

5 Other displays

Item	Description
Alarm No.	<p>If selected, the Alarm Moving Sign element displays the alarm number when an alarm is triggered.</p> 
Alarm Group	<p>If selected, the Alarm Moving Sign element displays the alarm category when an alarm is triggered.</p> 

In the **Style** tab of the property dialog, you can set the display style of the **Alarm Moving Sign** element.

Alarm Moving Sign

Preview

####

State: 0

Language: Language1

Element Description: 警報訊息走馬燈_004

Main

Style

Operating conds.

Coord.

Style

1 Style: Sunken

2 Border Color:

3 Background Color:

4 Size: 16














5 Font: Arial



6 Ratio: 100%

7 Transparency: 255


OK

Cancel


Legend	Setting	Description								
①	Style	Set the appearance of the element. The options include Standard, Raised, Sunken, and Transparent.								
		<table><tr><th>Standard</th><th>Raised</th><th>Sunken</th><th>Transparent</th></tr><tr><td></td><td></td><td></td><td></td></tr></table>	Standard	Raised	Sunken	Transparent				
		Standard	Raised	Sunken	Transparent					
										
②	Border Color	Set the border color of the element. The default is gray. When set to red, it displays as follows.								
										

Legend	Setting	Description				
3	Filled style	Select the fill style of the element. The default value is Gradient . The following table lists the functions in the Gradient Fill view with their description.				
		<table><tr><th>Setting</th><th>Description</th></tr><tr><td>Gradient Style</td><td><p>Set the Gradient Style by setting the Current Angle or Center Point. Set the Current Angle or Center Point by dragging the mouse on the preview image, or set the memory address for dynamic configuration on the HMI. Supports adding gradient stop points and setting stop point colors to present the effect of multi-color gradients.</p><p>Note: Up to 5 stop points can be set.</p><ul style="list-style-type: none">Mono Gradient The gradient color automatically configured by the software does not provide stop point configuration and is compatible with the behavior of DOPSoft software.Linear StyleRadiation Gradient</td></tr></table>	Setting	Description	Gradient Style	<p>Set the Gradient Style by setting the Current Angle or Center Point. Set the Current Angle or Center Point by dragging the mouse on the preview image, or set the memory address for dynamic configuration on the HMI. Supports adding gradient stop points and setting stop point colors to present the effect of multi-color gradients.</p> <p>Note: Up to 5 stop points can be set.</p> <ul style="list-style-type: none">Mono Gradient The gradient color automatically configured by the software does not provide stop point configuration and is compatible with the behavior of DOPSoft software.Linear StyleRadiation Gradient
		Setting	Description			
Gradient Style	<p>Set the Gradient Style by setting the Current Angle or Center Point. Set the Current Angle or Center Point by dragging the mouse on the preview image, or set the memory address for dynamic configuration on the HMI. Supports adding gradient stop points and setting stop point colors to present the effect of multi-color gradients.</p> <p>Note: Up to 5 stop points can be set.</p> <ul style="list-style-type: none">Mono Gradient The gradient color automatically configured by the software does not provide stop point configuration and is compatible with the behavior of DOPSoft software.Linear StyleRadiation Gradient					
<div><div>Gradient Style</div><div><div>Gradient Style</div><div><div>Style</div><div>Mono Gradient</div></div><div><div>Color</div><div></div></div></div><div><div>Preview</div><div></div></div><div><div>Ok</div><div>Cancel</div></div></div>						
<div><div>Pattern Style</div><div><div>Pattern Style</div><div><div>Style</div><div>Linear Style</div></div><div><div>Current Angle</div><div>0</div></div></div><div><div>Preview</div><div><div>Please drag picture for more effect</div><div></div></div></div><div><div>Ok</div><div>Cancel</div></div></div>						

Legend	Setting	Description
		<div>  </div> <ul style="list-style-type: none"> Conical Style <div>  </div>
	Solid Color	<p>Set a single color fill, the same as the Foreground Color setting.</p> <div>  </div>
	Fill Pattern Style	Provides a variety of Fill Pattern styles and two-color combinations to present pattern fill effects.

Legend	Setting	Description
		 <p>Note: If select Transparent for Style, the set Filled style will not be applied.</p>
④	Size	Set the text size of the alarm message to be displayed.
⑤	Font	Set the font of the alarm message to be displayed. You can switch between different languages to set the font settings corresponding to the language.
⑥	Ratio	Set the scaling ratio of the alarm message to be displayed.
⑦	Transparency	Set or enter the transparency value. The smaller the value, the higher the transparency of the element. The value range is 50–255, and the default value is 255 .

Note: When an alarm element is created and the alarm reading address is not set, the error message will be displayed in the **Output** pane after compilation.




Gantt Chart Properties

The **Gantt Chart** element displays the alarm trigger time to restore time. You can filter the alarm information to view using

Note: This element is only available for DOP-300 series model, and one screen can only have one Gantt Chart element.


- **Style**

The following table lists the settings in the **Appearance Settings** dialog with their description.



The **Appearance Settings** dialog box for the Gantt Chart element contains the following sections and settings:

- Preview:** A visual representation of the Gantt chart showing a timeline with a blue bar labeled 'Category' and a red bar labeled 'Event'. The timeline is divided into segments with time labels like 'hh:mm:ss'.
- Display time span:** A dropdown menu set to '4' and 'Hour'.
- Title:**
 - Background Color: [White]
 - Text Color: [Black]
 - Format: [Date + Time]
- Title Axis:**
 - Background Color: [Blue]
 - Category Text Color: [Dark Blue]
 - Event Record Text Color: [Red]
- Grid:**
 - Background Color: [White]
 - Line Color: [Gray]
 - Number of: [4]
 - The actual number of grid lines drawn will vary depending on the "Display Time Span" setting.
- Current Segment:**
 - Line Color: [Orange]
 - Text Color: [Black]
- Inspection Line:**
 - ☒ Inspection Line
 - Line Color: [Blue]
 - Text Color: [Black]
- Footer:**
 - Background Color: [White]
 - Text Color: [Black]
 - Date: [Do not display]
 - Time: [HH:MM:SS]
- Buttons:** OK, Cancel



Setting	Description
Display time span	Set the time range to display on the Gantt chart.
Title	Set the background color, text color, and date / time format of the title. Note: The format setting synchronously applies to Current Segment and Inspection Line .
Title Axis	Set the background color, category text color, and event record text color of the title axis.
Grid	Set the background, line color, and number of grids.
Current segment	Set the line color and text color.
Inspection Line	
Footer	Set the background color, text color, and date and time format.

History Buffer

The history buffer records specific data in HMI or external storage device, through the buffer attribute to set the sampling data, trigger mode, and file output content, after the buffer data is established. The sampling data can be displayed on the HMI through the sampling element.


History Buffer Settings

How to open the **History Buffer** settings page?

- In **Project** pane, double-click **History Buffer**.

Or

- On the toolbar, click **Data Management > History Buffer**.

On the **History Buffer** settings page, click the  to open **Buffer Properties** dialog.

The following table lists the settings in the **Buffer Properties** dialog with their description.

Buffer Properties

Sampling

Address

None

Read Length (Word)

1

Sample Number

10

☐ Enable active bit

None

☐ Stamp Time and Date

Time Format: hh:mm:ss

Date Format: mm/dd/yy

Control Status Block

Control Block

Data sampling

Trigger

Timer

☒ Sampling Cycle (ms)

1000

☐ Custom Cycle (ms)
☐ Use DWORD

None

Data Clearing

None

Status Block

Data Sampling Status

None

Data Clear Status

None

File Output

☐ Non-volatile

HMI

☐ Auto Stop

☐ Export CSV File

Field Name

☒ Save As Single File

File Name: H0001

☐ Save As Multiple Files

File Date: %y %m %d

File Time: %H %M %S

File Name: H0001

☒ Archive trigger bit

None

When continuous addresses disabled, HMI performance may be affected.

OK


Cancel

Settings	Description
Address	Select either the internal memory or the controller register address.
Read Length (Word)	Select or enter the number of words that can be sampled. The maximum value is 256.
Sample Number	Enter the number of historical data to be recorded. Up to 9,999,999 sampling points can be This function needs to be used with the Auto Stop function. If the Auto Stop checkbox is selected, the recording stops automatically when it reaches the set sample number. If the Auto Stop checkbox is not selected, the recording does not stop when it reaches the set sample number; instead, the recording restarts from the first record and overwrites the previous data.
Enable active bit	Select to set the active bit. If the Trigger is set to Timer for Data sampling , the HMI immediately records the sampling data as soon as it starts up. The Enable active bit function allows you to determine when to start sampling. When the active bit is On, it starts to sample; when the active bit is Off, it stops sampling.


Settings	Description
Stamp Time and Date	Select to set the time format and date format.
Trigger	<p>Select the trigger source.</p> <ul style="list-style-type: none"> With Timer as the trigger source, you can choose between Sampling Cycle and Custom Cycle. <ul style="list-style-type: none"> Sampling Cycle: The range value is 100~86400000. Custom Cycle: The cycle time of sampling can be dynamically set on HMI through the specified memory address. The maximum value can be set to 32767. If Use DWORD is selected, the maximum value can be set to 2147483647. With Memory Address as the trigger source, you can configure the bit address to trigger data capture. When the bit is On, it will be sampled.
Data Clearing	Set the address of data clearing as a bit address. When the trigger address is On, the buffer data is cleared.
Status Block	Set the status block address as a bit address to read the sampling / clearing status. When the address is On, data sampling / clearing is performed.
Non-volatile	<p>Check and select the storage location of data. The storage location varies depending on the external device supported by the model, including HMI, USB Disk, and SD.</p> <p>If HMI is selected, the data is recorded in the HMI SRAM when the power is cut off.</p>
Auto Stop	<p>If selected, the recording stops automatically when the set Sample Number is reached.</p> <p>Note: Refer to the instructions of Sample Number.</p>
Export CSV File	<p>Select to export historical data to a CSV file, and you can set the Field Name for a CSV file.</p> <p>Note: This setting is only available when Non-volatile is selected. The following table lists the settings in the CSV Fields dialog with their description.</p>







Settings	Description		
	<div><div>CSV Fields</div><div><div><div>Title Setting 1</div><div>Column0Detail</div><div></div><div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div></div></div></div></div>		


Settings	Description																																				
			<div>Set for the column item.</div> <div><ul style="list-style-type: none">The column items are displayed according to the Read Length (Word) setting. You can choose whether to Open the item or not, and set the data style to be presented on the CSV file, including the title name, data format, and integer digits/fractional digits.You can also set the Data Start Position and Length according to the read data. Different Length supports different data formats. The following table lists the valid range value corresponding to the data format.</div> <div><table><tr><th colspan="2">Length is 1</th></tr><tr><th>Data Format</th><th>Valid Range Value</th></tr><tr><td>BCD</td><td>0~9999</td></tr><tr><td>Signed BCD</td><td>–999~9999</td></tr><tr><td>Signed Decimal</td><td>–32768~32767</td></tr><tr><td>Unsigned Decimal</td><td>0~65535</td></tr><tr><td>Hex</td><td>0~0xFFFF</td></tr><tr><td>Char</td><td>2 words</td></tr><tr><th colspan="2">Length is 2</th></tr><tr><th>Data format</th><th>Valid Range Value</th></tr><tr><td>BCD</td><td>0~99999999</td></tr><tr><td>Signed BCD</td><td>–99999999~99999999</td></tr><tr><td>Signed Decimal</td><td>–2147483648~2147483647</td></tr><tr><td>Unsigned Decimal</td><td>0~4294967295</td></tr><tr><td>Hex</td><td>0~0xFFFFFFFF</td></tr><tr><td>Char</td><td>4 words</td></tr><tr><td>Floating</td><td>0~9999999</td></tr></table></div>	Length is 1		Data Format	Valid Range Value	BCD	0~9999	Signed BCD	–999~9999	Signed Decimal	–32768~32767	Unsigned Decimal	0~65535	Hex	0~0xFFFF	Char	2 words	Length is 2		Data format	Valid Range Value	BCD	0~99999999	Signed BCD	–99999999~99999999	Signed Decimal	–2147483648~2147483647	Unsigned Decimal	0~4294967295	Hex	0~0xFFFFFFFF	Char	4 words	Floating	0~9999999
Length is 1																																					
Data Format	Valid Range Value																																				
BCD	0~9999																																				
Signed BCD	–999~9999																																				
Signed Decimal	–32768~32767																																				
Unsigned Decimal	0~65535																																				
Hex	0~0xFFFF																																				
Char	2 words																																				
Length is 2																																					
Data format	Valid Range Value																																				
BCD	0~99999999																																				
Signed BCD	–99999999~99999999																																				
Signed Decimal	–2147483648~2147483647																																				
Unsigned Decimal	0~4294967295																																				
Hex	0~0xFFFFFFFF																																				
Char	4 words																																				
Floating	0~9999999																																				


Settings	Description
	<ul style="list-style-type: none"> Use Export / Import buttons on the right to export the data as an XLSX file. After editing, you can import it into the field settings. <p>The field name of the CSV file and the corresponding output result, as shown in the following figure.</p>  <p>Note: If Non-volatile is not enabled, it can be used with the LUA command <i>history.ExportCSV</i> to export a CSV file.</p>
File storage	<p>Select to save the history butter data as single file or multiple file.</p> <ul style="list-style-type: none"> Save As Single File: All data is saved in a single file. You can define the file name (including English and numeric), and the maximum length is 8 characters. Save As Multiple Files: When the Sample Number record of the historical buffer data is full, or the Archive trigger bit is triggered, the current data will be saved and the buffer data will be cleared. The file name format of the multiple files is File Name_Date_Time. <p>Note: Save As Multiple Files and Auto Stop cannot be used at the same time. To enable Auto Stop, select Save As Single File option.</p>

The following table lists the functions on the toolbar in the History Buffer settings page.

Function	Description
	Click to adds buffers. Up to 40 sets of buffers can be added.



Function	Description
	Click to delete the selected buffer data.
	Click to open the selected buffer properties dialog to modify the buffer properties.
	Click to export buffer data as an XLSX file.
	Click to import buffer data after modification.
	<p>Click to enable / disable the Continuous historical buffer control command address function.</p> <ul style="list-style-type: none"> Enabled: Use continuous address to control the sampling or clearing of data in each buffer. It is set on the Properties tab. Refer to the next paragraph. Disabled: Set the respective control command addresses in the Buffer Properties dialog. <p>Note: If continuous address function is not enabled, it may affect the performance of the HMI.</p>
	<p>Enabling optimization is recommended when the set addresses of multiple buffers are not continuous.</p> <p>If multiple buffer addresses are already continuous, enabling this function may result in the slow read speed.</p>

In the **Properties** tab, you can set the control bit of the data sampling or clearing of the history buffer. It controls the actions of each buffer with the set starting address. Take the **Data Sampling** as an example, set the starting address to \$10. You can click  to query the buffer number of each sampling bit control or view the actual control bits of that buffer in the properties dialog of each buffer.



Note: The **continuous historical buffer control command address** function needs to be enabled to set the Control Block / Status Block address.

The following table lists the settings in the **Properties** tab with their description.

Setting	Description
Data Sampling	Controls the buffer sampling flag. When the control bit is ON, a sampling is performed. Note: The Trigger of the buffer needs to be Memory Address .
Data Clearing	Clears the buffer data flags, including data for sampling elements and non-volatile records.
Data Sampling Status	<p>When the HMI samples the history buffer, it turns the corresponding history buffer sampling status flag ON. After the sampling is complete, the history buffer sampling status flag is turned OFF in real time.</p> 
Data Clear status	<p>When the HMI clears the history buffer, it turns the corresponding history buffer clear status flag ON. After the clearing is complete, the history buffer clear status flag is turned OFF in real time.</p> 
Auto Reset Flags	Set whether to automatically clear flags. When Auto Cleared Flag is set to Yes , all data sampling or data clearing addresses will be cleared to 0 after sampling or clearing any buffer.
Sampling Cycle (ms)	Set the interval at which the sampling is performed. The default value is 300, and the range value is 100~1000.

Sampling Function

Displays the sampling elements of historical buffer data. The following are sampling elements.


- **Historical Trend Graph:** Displays the sampled data over a period on the element in the form of a trend chart. A maximum of 60 curves can be displayed.
- **Historical Data Table:** Lists the values sampled from the history buffer on the element. A maximum of 60 fields can be displayed, corresponding to 60 curves in the historical trend chart.
- **Historical Event Table:** Converts the sampled values into information and presents them on the element in Word or LSB format.
- **Historical Overview Table:** Draws the historical data stored on an external storage device (USB disk or SD card) on the element in the form of a trend chart.
- **Circular Trend:** Draws the sampled data over a period as a circular trend chart using the polar coordinate system. A maximum of 60 curves can be displayed.




Note: There can be only one **Circular Trend** element per screen.

Common Properties

- **Style**

The following table lists the common style properties of **Historical Data Table** and **Historical Event Table**.

Setting	Description
Border Color	<p>Set the border color of the element. The default color is gray. When set to red, it displays as shown in the following figure.</p>  <p>The figure shows a screenshot of a data table with a red border. The table has a header row with the text '####' and a body row with a blue background. The table is displayed within a window with a scroll bar.</p>

Setting	Description
Background Color	<p>Set the background color of the element. The default color is white. When set to red, it displays as shown in the following figure.</p> 
Row Color	<p>Set the color of the odd number of rows. The default color is light blue. When set to red, it displays as shown in the following figure.</p> 
Alternating Row Color	<p>Set the color of the even number rows. The default color is blue. When set to red, it displays as shown in the following figure.</p> 
Select Row Color	<p>Set the color of the select row to be displayed after clicking the element when executing on the HMI.</p>
Transparency	<p>Select or enter the transparency value of the element. The range value is 50~255. The smaller the value, the higher the transparency of the element.</p>

• Function Buttons

The function buttons control the display of charts on the HMI.

Setting	Description
Zoom In	<p>Select to zoom in or out historical data on the X-axis on the trend chart.</p> <p>Note: This function is used for Historical Trend Graph.</p>
Zoom Out	
Zoom Reset	<p>Select to reset the X-axis to the default style.</p> <p>Note: This function is used for Historical Trend Graph.</p>

Setting	Description
Scroll	Configure the scroll direction and interval according to the characteristics of the element. The trend chart can be scrolled left and right, and the data table can be scrolled up and down.
Set the time display interval	Displays the corresponding data according to the set time interval.
Set as the default description	Click to fill in the function description as default strings.
Default button width / height	Select or enter the height and width of the function buttons. After changing the height or width, click Rearrange Function Buttons in the element context menu to update the button size.


Historical Trend Graph Properties

- **Main — Global curve setting**

The **Global range** checkbox needs to be selected to set the format of all curves on the trend chart uniformly.

Historical Trend Graph

Preview



State:

0

Language:

Language1

Element Description:

Historical Trend Graph_001

Main

Style

Historical data

Function Buttons

Coord.

Global curve setting

History Buffer

Buffer ID 1

☒ Global range

Scale Settings

Curve style

Curve

Length

1

Data Format

Unsigned Decimal

Integer Digits

4

Fractional

0

Min 0

Max 9999

Minimum/Maximum

0

/

100

☐ Display High Value

80

☐ Display Low Value

20

OK

Cancel


Setting	Description
Scale Settings	<p>Set the position of the scale, the size and color of the markers, and the scale mark number.</p> <div> <div>Scale Settings</div> <div> <div>Display scale</div> <div>Display on left</div> </div> <div> <div>Scale Settings</div> <div> <input checked="" type="checkbox"/> Display mark <div> <div>Font size</div> <div>16</div> </div> <div> <div>Text Color</div> <div></div> </div> <div> <div>Mark Color</div> <div></div> </div> <div> <div>Scale Mark Number</div> <div>5</div> </div> <div> <div>Subscale Mark Number</div> <div>1</div> </div> <div> <div>Scale Width</div> <div>69</div> </div> </div> </div> <div> <div>OK</div> <div>Cancel</div> </div> </div>

Setting	Description
Curve style	Select the curve style.
Length	Select the length. If the read length is 1, the length of the read data is 1 Word. If the read length is 2, the length of the read data is 2 Word.
Data Format	Select the data format. Note: Floating can only be selected when the read length is 2.
Integer Digits / Fractional Digits	Set integer digits and fractional digits to be displayed.
Minimum / Maximum	Set a valid range value according to the set Read Length and Data Format . You can enter a constant or a custom memory address to change the minimum / maximum value dynamically.
Display High Value / Display Low Value	Select to display high or low lines. You can enter a constant or custom memory address and set the color of the marking.

- **Style**

Historical Trend Graph

Preview



State:

0

Language:

Language1

Element Description:

Historical Trend Graph_001

Main

Style

Historical data

Function Buttons

Coord.

Style

Number of Curves:

1

Transparency:

255

Filling Curve:

No

Anti-aliasing:

Yes

Monitoring Line:

No

Margin:

No

Horiz. Grid Number:

1

Gridline Color:

Border Color:


Background Color:



Filled style:

Gradient

OK


Cancel

Setting	Description
Number of Curves	<p>Select the number of curves to display. Support up to 60 curves.</p> <p>This setting is synchronized with the number of Curve in the Historical data tab.</p>
Filling Curve	<p>Select whether to fill the curve. If set to Yes, the area below the curve will be filled with the curve color. The filling effect is shown in the following figure.</p> 

Setting	Description
Monitoring Line	Select whether to display the monitoring line. If set to Yes , the monitoring line will be displayed after clicking the sampling point on the HMI screen.
Horiz. Grid Number / Gridline Color	Set the horizontal grid number and the gridline color. The horizontal grid number divides the number of zones of the Historical Trend Graph element. If set to 2, there is one grid line and 2 zones; if set to 3, there are two grid lines and 3 zones, and so on. Support up to 50 zones.
Background Color	Sets the background color of the element. The default color is blue. When set to red, it displays as shown in the following figure. 
Filled style	Sets the fill effect of Background Color .
Transparency	Select or enter the transparency of the element. The range value is 50~255. The lower the number, the higher the transparency.
Anti-aliasing	Select whether to enable the anti-aliasing function. If select Yes , the element display becomes more delicate without jagged edges.
Margin	Select whether to enable the margining function. If select Yes , it leaves white space around the element, and the trend chart will be indented as shown in the following figure. 

- **Historical data – Individual curve setting**


Make the individual settings for all curves on the trend chart.



Follow these steps to configure the individual curve settings.

To configure the individual curve settings

1. Select the buffer data to be presented by this element, and the **Buffer ID** corresponds to the data number set in the **History Buffer Setup** dialog.



2. In the **Style** tab, set the **Number of Curves**, and then configure the individual curve settings table. The following table lists the settings of the individual curve settings table with their description.

Setting	Description
Enable	Set whether to enable the curve to read the data. <ul style="list-style-type: none"> A value of 1 is enabled, and a value of 0 is not enabled. The bit address can be set to enable curves dynamically on the HMI.
Length	Select the read length according to the data source. Note: If Global range is selected, it is not possible to set the read length for individual curves.
Start Position	Select the data start position, and it depends on the Read Length set in the History Buffer Setup dialog.
Data Format	Select the data format. Note: <ul style="list-style-type: none"> If Global range is selected, it is not possible to set the value format for individual curves. Floating can only be selected when the Read Length is 2.
Integer Digits / Fractional Digits	Select the integer digits and fractional digits to be displayed. Note: If Global range is selected, it is not possible to set the integer digits and fractional digits for individual curves.
Line Color	Set the line color of the curve.
Line Weight	Select the line width of the curve. The range value is 1–8.
Minimum / Maximum	Set the minimum and maximum values according to the Read Length and Data Format . Note: If Global range is selected, it is not possible to set the minimum and maximum values for individual curves.
Write Address	Set the write address of the curve value on the monitoring line.
Curve Style	Select the curve style.

○ **Time/Date**


- **Time / Date Format:** Select to display the sampling time and date, and select the format to be displayed.
- **Display time/date:** Select to display the timeline and set the time interval.

- **Time Interval:** Select or enter the interval between the sampling points displayed at the set time. If the interval is 3, the sampling time will be displayed on the timeline at the first and fourth sampling points.
- **Timeline scaling:** Select the zoom ratio of the timeline display. The scale is smaller, the more sample points can be seen.

Historical Data Table Properties

- **Style**

The following table lists the unique properties in the **Historical Data Table**. For other Style properties, refer to [Common Properties](#).



The screenshot shows the 'Historical Data Table' dialog box with the 'Style' tab selected. The dialog has a 'Preview' section on the left and a 'Style' section on the right. The 'Preview' section shows a table with three columns and one row, with the first column highlighted in blue. The 'Style' section contains various settings for the table's appearance, including border color, background color, column counts, gridline color, show gridlines, row color, alternating row color, and select row color. The 'OK' and 'Cancel' buttons are at the bottom right.


Property	Value
Border Color	Gray
Transparency	255
Background Color	White
Column Counts	1
Gridline Color	White
Show Gridlines	No
Row Color	White
Alternating Row Color	Blue
Select Row Color	Blue

State: 0

Language: Language1

Element Description: Historical Data Table_005

OK Cancel

Function	Description
Column Counts	Select the number of curves to be displayed. Support up to 60 columns. This setting is synchronized with the number of curve item in the Historical data tab.
Gridline Color / Show Gridlines	Select the gridline color of the element. The default color is white. When set to red, it displays as shown in the following figure. Note: Gridline Color only works when Show Gridlines is set to Yes . 

- Historical data – Individual field setting

Historical Data Table

Preview

####

State:
0

Language:
Language1

Element Description:
Historical Data Table_005

Style

Historical data

Order

Text

Function Buttons

Coord.

Individual field setting

History Buffer

Buffer ID
1

Item	Length	Start Position	Data Format	Integer D	Fractional	Color
1	1	0	Unsigned Decimal	4	0	RGB(0, 0, 0)

Time/Date

☐ Time Format

hh:mm:ss

Align

Align left

Field Width

72

☐ Date Format

mm/dd/yy

Align

Align left

Field

72

Color

Sort

Time Date

☐ Show Title

Time

TIME

Date

DATE

No.

No.

Background

Text Color

☐ Show No.

Align left


OK

Cancel

Follow these steps to configure the individual field settings.

To configure the individual field settings

1. Select the buffer data to be presented by this element, and the **Buffer ID** corresponds to the data number set in the **History Buffer Setup** dialog.



2. In the **Style** tab, set the **Column Counts**, and then configure the individual field settings table. The following table lists the settings of the individual field settings table with their description.

Setting	Description
Length	Select the range of length and start position, which depend on the Read Length set in the History Buffer Setup dialog.
Start Position	
Data Format	Select the data format. Note: <ul style="list-style-type: none"> • Floating can only be selected when Length is 2. • If Length is greater than 2, you can use only the Char format.
Integer Digits / Fractional Digits	Set the number of integer digits and fractional digits to be displayed. Note: There are no integers / fractional digits in the Char format.
Color	Set the text color of this field.
Column Width	Set the display width of this field. The range value is 0~9999.
Prefix Zero	Select to determine the number of digits to prefix according to the set Integer digits .
Title bar	Enter the title bar. Note: The title bar name is only displayed on the element when the Show title bar is selected.
Field alignment	Select to align the text in the field to the left, center, or right.

- **Time/Date**

- **Time / Date Format:** Select to display sampling time and date, and set the display format, alignment, and field width.
- **Color:** Select the display color of the text.

- **Show Title**

Select to display the title bar, and set the time, date, and the title of the index, as well as the background color and text color of the title bar.

Note: The text in the title row of the data field is configured in the **individual field settings**.

- **Show No.**

Select to display the index, and set the text color and alignment of the index row.


- **Order**

Select the data sorting method, which is sorted by the sampling time.

- **Text**

Select the display font size of the text.

Historical Event Table Properties



Historical Event Table

Preview

State: 0

Language: Language1

Element Description: Historical Event Table_006

Automatically resized based: Yes

Margin: 0

Main Style Text Function Buttons Coord.

Detail

Data Type: Word

Data Format: Unsigned Decimal

State Counts: 3

History Buffer

Buffer ID: 1

Data No.: 0

Time/Date

☐ Time Format: hh:mm:ss

☐ Date Format: mm/dd/yy

Color: [Black]


OK Cancel

- **Main – Detail**

- **Data Type:** If select **Word**, you can set 1 to 256 states; if select **LSB**, the sampling values of historical data are converted into binary display, and you can set 1 to 16 states.
- **Note:** To display State 0, select **LSB (Support State 0)**.

- **Main– Buffer setting**

- **Buffer Number:** Select the buffer data to be presented by this component, which corresponds to the data number set in the **History Buffer Setup** dialog.




- **Data No:** Select the data number, which depends on the **Read Length** set in the **History Buffer Setup** dialog. If the read length is 1, the data position is 0.
- **Time/Date: Time / Date Format:** Select to display the sampling time and date, and select the display format and text color.

Historical Overview Table Properties

The **Historical Overview Table** element has a file browsing area on the left and the trend chart on the right, which have different properties.

For the trend chart properties, refer to [Historical Trend Graph Properties](#). The following lists the properties of the **file browsing area** with their description.



Historical Overview Table

Preview

- Dir: 0
 - File: 0
 - File: 1
- Dir: 1
 - File: 0
 - File: 1

State: 0

Language: Language1

Element Description: Historical Overview Table_1

Main Style Function Buttons

Detail

File Extension Filter: dat

Text

Font: Arial

Size: 16

Color: [Black]

OK Cancel

- **Main – File Extension Filter**

Enter the extension of the file you want to browse. The default value is **dat**.

- **Main – Text**

Set the font, size, and color of the text in the file browsing area.

- **Style**


Set the border color, background color, and transparency of the file browsing area.

Circular Trend Properties

- **Main — Global curve setting**

Disk Curve

Preview



State:

0

Language:

Language1

Element Description:

Disk Curve_001

Main | Style | Historical data | Coord.

Global Curve Settings

History Buffer

Buffer ID

Distance (hours)

1

Starting Position

Move up

Zoom Factor

1

Current time output (seconds)

None

Select Historical Time Output





















None

☒ Function Button Display

OK

Cancel


Setting	Description
Distance (hours)	Set the length of time for a circle of the circular trend chart. The range value is 1–24. You can also set the memory address to dynamically change the length of time on the HMI.
Starting Position	Select the starting position of the curve.
Zoom Factor	Set the zoom factor. The range value is 1–10. You can also set a memory address to change the displayed zoom factor on the HMI dynamically.
Current time output (seconds)	Set the time gap between the loading time by HMI and the last historical data, which is recorded in seconds.
Select Historical Time Output	Set the time gap between the HMI loading time and monitoring line. Record in seconds.

Setting	Description																												
Function Button Display	<p>If selected, you can open the settings dialog and adjust the circle's display settings on the HMI.</p> <ul style="list-style-type: none">Click  to open the setting dialog to set the displayed time range of data and displayed channel. <div><div>Setting</div><div><div><div>Start Time</div><div><div><div></div></div><div>2025/05/12</div><div></div></div><div><div>15</div><div>:</div><div>51</div></div></div><div><div>End Time</div><div><div><div></div></div><div>2025/05/12</div><div></div></div><div><div>15</div><div>:</div><div>51</div></div></div><div><div>Channel Scale Control</div><div><div></div></div></div><div><div>Curve Display Control</div><table><thead><tr><th>Curve</th><th>ON / OFF</th></tr></thead><tbody><tr><td>Curve 1</td><td>ON</td></tr><tr><td>Curve 2</td><td>ON</td></tr><tr><td>Curve 3</td><td>ON</td></tr></tbody></table><div><div>Reset</div><div>Apply</div></div></div></div></div> <ul style="list-style-type: none">Click  to expand the function menu. The following table lists the functions in the function menu. <table><thead><tr><th>Icon</th><th>Function</th><th>Description</th></tr></thead><tbody><tr><td></td><td>Displays the previous data</td><td rowspan="2">Click to toggle the displayed time range. The time range in units of the set time distance.</td></tr><tr><td></td><td>Display the next data</td></tr><tr><td></td><td>Display the last data</td><td>Click to display the last data in units of the time distance.</td></tr><tr><td></td><td>Set the factor for zoom in to 1</td><td>Click to reset the factor for zoom in to 1.</td></tr><tr><td></td><td>Zoom in 1x</td><td>Click once to increase the factor for zoom in by 1 until the factor reaches 10 and no longer zooms in.</td></tr><tr><td></td><td>Zoom out 1x</td><td>Click once to reduce the factor for zoom out by 1 until the factor reaches 1 and no longer zooms out.</td></tr></tbody></table>	Curve	ON / OFF	Curve 1	ON	Curve 2	ON	Curve 3	ON	Icon	Function	Description		Displays the previous data	Click to toggle the displayed time range. The time range in units of the set time distance.		Display the next data		Display the last data	Click to display the last data in units of the time distance.		Set the factor for zoom in to 1	Click to reset the factor for zoom in to 1.		Zoom in 1x	Click once to increase the factor for zoom in by 1 until the factor reaches 10 and no longer zooms in.		Zoom out 1x	Click once to reduce the factor for zoom out by 1 until the factor reaches 1 and no longer zooms out.
	Curve	ON / OFF																											
	Curve 1	ON																											
	Curve 2	ON																											
	Curve 3	ON																											
	Icon	Function	Description																										
		Displays the previous data	Click to toggle the displayed time range. The time range in units of the set time distance.																										
		Display the next data																											
		Display the last data	Click to display the last data in units of the time distance.																										
		Set the factor for zoom in to 1	Click to reset the factor for zoom in to 1.																										
	Zoom in 1x	Click once to increase the factor for zoom in by 1 until the factor reaches 10 and no longer zooms in.																											
	Zoom out 1x	Click once to reduce the factor for zoom out by 1 until the factor reaches 1 and no longer zooms out.																											

- Style

Circular Trend

Preview



State:

0

Language:

Language1

Element Description:

Circular Trend_001

Main

Style

Historical data

Coord.

Style

Number of Curves:

1

Border Color:

Background Color:

Monitoring Line:

No

Anti-aliasing:

Yes

Show Grid

Number of Grid:

8

Time Scale Display

Font

Arial

14

Channel Scale Display

Font

Arial

14

Time/Date

HH:MM

MM/DD/YYYY


OK

Cancel

Setting	Description
Number of Curves	Select the number of curves to display. Support up to 8 curves. This setting is synchronized with the number of Curve in the Historical data tab.
Monitoring Line	Select whether to display the monitoring line. If set to Yes , the monitoring line is displayed after clicking the sampling point on the HMI screen, and the monitoring line time is displayed at the upper left.
Anti-aliasing	Select whether to enable the anti-aliasing function. If select Yes , the element display becomes more delicate without jagged edges.
Show Grid	Select to display the circular grid, and configure the number of grids and time scale settings.
Time Scale Display	Select to display the time scale on the circular trend chart, and set the scale font and color.

Setting	Description
Channel Scale Display	Select to display the channel scale on the circular trend chart, and set the scale font. Note: The scale color is displayed based on Line Color in the Historical data tab.
Time/Date	Select to display the current time at the upper left of the element, and set the format and color to display.


- **Historical data – Individual curve setting**



Follow these steps to configure the individual curve settings.

To configure the individual curve settings

1. Select the buffer data to be presented by this element, and the **Buffer ID** corresponds to the data number set in the **History Buffer Setup** dialog.





- In the **Style** tab, set the **Number of Curves**, and then configure the individual curve settings table. The following table lists the settings of the individual curve settings table with their description.

Setting	Description
Enable	Set whether to enable the curve to read the data. <ul style="list-style-type: none"> A value of 1 is enabled, and a value of 0 is not enabled. The bit address can be set to enable curves dynamically on the HMI.
Interlock State	This setting is only available when Enable is set as a bit address.
Length	Select the read length according to the data source.
Start Position	Select the data start position, and it depends on the Read Length set in the History Buffer Setup dialog.
Data Format	Select the data format. Note: Floating can only be selected when the Read Length is 2.
Integer Digits / Fractional Digits	Select the integer digits and fractional digits to be displayed.
Line Color	Set the line color of the curve.
Line Weight	Select the line width of the curve. The range value is 1–8.
Minimum / Maximum	Set the minimum and maximum values according to the Read Length and Data Format .
Write Address	Set the write address of the curve value on the monitoring line.

History Buffer Setting Example

Follow these steps to add a history buffer and view the history data through the sampling element.

1. In the **History Buffer** settings page. Click  on the toolbar to add **Buffer Properties** dialog.
2. In the **Buffer Properties** dialog, set the buffer properties as shown in the following figure.



The image shows the 'Buffer Properties' dialog box with the following settings:

- Sampling**
 - Address: \$1000
 - Read Length (Word): 3
 - Sample Number: 10
 - ☐ Enable active bit
 - ☒ Stamp Time and Date
 - Time Format: hh:mm:ss
 - Date Format: mm/dd/yy
- Control Status Block**
 - Control Block: Data sampling
 - Trigger: Memory Address
 - \$10.0
 - Data Clearing: \$20.0
 - Status Block
 - Data Sampling Status: None
 - Data Clear Status: None
- File Output**
 - ☒ Non-volatile: USB Disk
 - ☐ Auto Stop
 - ☒ Export CSV File: Field Name
 - ☒ Save As Single File
 - File Name: H0001
 - ☐ Save As Multiple Files
 - File Date: %y %m %d
 - File Time: %H %M %S
 - File Name: H0001
 - ☒ Archive trigger bit: None

When continuous addresses disabled, HMI performance may be affected.

OK Cancel

The example of setting the **Field Name** of **Export CSV File** is shown in the following figure.

CSV Fields

Title Setting

Column

2

Detail

	A	B
1	Region	TW
2	Location	TN02
3	Floor	7F

Column Settings

Time

Time

Date


Date

Item	Open	Name	Length	Data Start Position	Data Format
0	<input checked="" type="checkbox"/>	DATA1	1	0	Unsigned Decimal
1	<input checked="" type="checkbox"/>	DATA2	1	1	Unsigned Decimal
2	<input checked="" type="checkbox"/>	DATA3	1	2	Unsigned Decimal
3	<input checked="" type="checkbox"/>		1	3	Signed Decimal
4	<input checked="" type="checkbox"/>		1	4	Signed Decimal
5	<input checked="" type="checkbox"/>		1	5	Signed Decimal
6	<input checked="" type="checkbox"/>		1	6	Signed Decimal
7	<input checked="" type="checkbox"/>		1	7	Signed Decimal
8	<input checked="" type="checkbox"/>		1	8	Signed Decimal
9	<input checked="" type="checkbox"/>		1	9	Signed Decimal
10	<input checked="" type="checkbox"/>		1	10	Signed Decimal
11	<input checked="" type="checkbox"/>		1	11	Signed Decimal
12	<input checked="" type="checkbox"/>		1	12	Signed Decimal
13	<input checked="" type="checkbox"/>		1	13	Signed Decimal


OK

Cancel

3. Create a **Historical Trend Chart** element on the screen, and then double-click the element to open the properties dialog.
 - a. In the **Style** tab, select **3** for **Number of Curves**.
 - b. In the **Historical data** tab, set **Enable** in **Individual curve setting** table to **1**, and set the curve properties.
 - c. In the **Time/Date** area, set the display method of time and date.



4. Create a **Historical Data Table** element on the screen, and then double-click the element to open the properties dialog.
 - a. In the **Style** tab, set 3 for **Column Counts**.
 - b. In the **Historical data** tab, set each property of the **Individual curve setting** table.
 - c. Select the **Time Format**, **Date Format**, and **Show Title** checkboxes.



Historical Data Table

Style | **Historical data** | Order | Text | Function Buttons | Coord.

Individual field setting

History Buffer: [1] Buffer ID: [1]

Item	Length	Start Position	Data Format	Integer	Fractional	Color
1	1	0	Unsigned Decimal	4	0	RGB(0, 0, 0)
2	1	1	Unsigned Decimal	4	0	RGB(0, 0, 0)
3	1	2	Unsigned Decimal	4	0	RGB(0, 0, 0)

Time/Date

☒ Time Format: hh:mm:ss Align: Align left Field Width: 72

☒ Date Format: mm/dd/yy Align: Align left Field: 72

Color: [Orange] Sort: Time Date

☒ Show Title

Time: TIME Background: [Grey]


Date: DATE Text Color: [Black]

No.: No.

☐ Show No. [Black] Align left

OK Cancel


- Create 3 **Numeric Entry** elements on the screen, and then set the **Write Address** is the read address of the history buffer \$1000.
- Create 2 **Momentary** button elements on the screen, and then set the **Write Address** to \$10.0 and \$20.0 respectively, corresponding to the trigger bit and data clear bit.



W:\$1000 1234 W:\$1001 1234 W:\$1002 1234

W:\$10.0 Trigger W:\$20.0 Clean

- Download the screen to the HMI and enter the value within 100 to 3 **Numeric Entry** elements respectively. Click the button with the memory address of \$10.0, and the **Historical Data Table** records the current value. Click \$10.0 button again, and the historical trend chart draws the data curve. The following figure shows the execution result.



8. The historical data is synchronously written to the USB disk. The file path is HMI\HMI-000\History\CSV\H0001.csv, and the content of the CSV file is also written to the data content according to **Field Name**.

	A	B	C	D	E
1	Region	TW			
2	Location	TN02			
3	Floor	7F			
4	Time	Date	DATA1	DATA2	DATA3
5	14:55:14	12/23/2024	10	20	30
6	14:55:25	12/23/2024	55	66	77

Enhanced Recipe


Due to production needs, an enhanced recipe is provided that can record a mixture of alphanumeric (string) and numeric formats. The data type supported by the enhanced recipe is Word or Double Word and use the address of the control area different from the 16-Bit / 32-Bit Recipe to set the control area. When reading or writing recipes, you need to specify the recipe number and recipe group for reading and writing one of the recipes.

The following table lists the definition of each enhanced recipe special registers.

Register Name	Definition
ENRCP	Enhanced Recipe Register
ENRCPNO	Enhanced Recipe Number Register
ENRCPG	Enhanced Recipe Group Register
ENRCPGNAME	Enhanced Recipe Group Name Register

Enhanced Recipe Number Register (ENRCPNO)

The enhanced recipe number register is used to specify the enhanced recipe number. Read and write a group of recipes according to the recipe number recorded in the recipe number register. For example, when selecting the first group of recipes, ENRCPNO = 1; when selecting the fourth group of recipes, ENRCPNO = 4.




	RCPNO Name	1 Unsigned Decimal 1 Word	2 Floating 2 Word	3 Char 5 Word	4 BCD 2 Word
1	1	111	5.55	aaa	11111111
2		222	6.66	bbb	22222222
3	3	333	7.77	ccc	33333333
4	4	444	8.88	ddd	44444444
5	5	555	9.99	eee	55555555

Note: The enhanced recipe number registers do not have power-off retentive function. When the HMI is powered off, the data in the register cannot be retained.

Enhanced Recipe Register (ENRCP)

The recipe buffer is arranged in front of the recipe register. This area allows you to place a selected group of recipes. When the number of fields in the recipe buffer is the same as the number of fields in the selected recipe group, it means that the recipe buffer occupies L recipe registers. The number of recipe buffers occupied by a recipe table is $L * (G+1)$, where $G+1$ represents the number of registers with one more set of buffers.



	RCPNO Name	1 Unsigned Decimal 1 Word	2 Floating 2 Word	3 Char 5 Word	4 BCD 2 Word
1	1	111	5.55	aaa	11111111
2	2	222	6.66	bbb	22222222
3	3	333	7.77	ccc	33333333
4	4	444	8.88	ddd	44444444
5	5	555	9.99	eee	55555555

The main purpose of the recipe buffer is that you only need to switch the number of recipe groups to know the currently specified recipe parameters. If the selected recipe group (ENRCPNO) is 1, and then the recipe buffer displays the first group recipe value, that is, $ENRCPNO = 1$.

	ENRCPNO	ENRCPG	ENRCPGNAME
	1	1	Chocolate
Recipe Buffer	ENRCP0	ENRCP1	ENRCP2
	111	5.55	aaa
Recipe Start Address	ENRCP6	ENRCP7	ENRCP8
	111	5.55	aaa
	222	6.66	bbb
	333	7.77	ccc

Enhanced Recipe Group Register (ENRCPG / ENRCPGNAME)

The enhanced recipe set selection register is used to specify the enhanced recipe set. Up to 255 sets of enhanced recipe data can be created. To call the enhanced recipe data, users must use recipe set 1~255 (ENRCPG 1~255). If enhanced recipes are enabled, the default value for the recipe set is 1. Therefore, if the first group of recipes for the first set of enhanced recipes is selected, that means ENRCPG = 1, ENRCPGNAME = chocolate, and ENRCPNO = 1.

☒ Enable
 Enhanced Recipe Address 50

ENRCPG = 1
ENRCPGNAME = Chocolate

1:Chocolate (5X6) 2:Strawberry (3X6)

	RCPNO Name	1 Unsigned Decimal 1 Word	2 Floating 2 Word	3 Char 5 Word	4 BCD 2 Word
Title	ENRCPNO = 1				
1	1	111	5.55	aaa	11111111
2	2	222	6.66	bbb	22222222
3	3	333	7.77	ccc	33333333
4	4	444	8.88	ddd	44444444
5	5	555	9.99	eee	55555555

ENRCPGNAME extracts the recipe content by entering the recipe name while ENRCPG enters a value from 1 ~ 255.

ENRCPGNAME names the recipe group name in Unicode, you can enter the language of each country. With this register, you can enter the recipe name to call the recipe. It must be used with the **Multi-Language Input** element (available for DOP-100 series HMI) must be used with.

Note: The enhanced recipe group register does not have the power-off retention function. When the HMI is powered off, the data in the register cannot be retained.


Enhanced Recipe Quantity Limitation

If the non-volatile data storage area is set in the USB disk or SD card, the maximum number of enhanced recipe files cannot exceed 256 fields X 10000 groups. If the non-volatile data storage area is set in the HMI, the editable size of the enhanced recipe depends on the flash memory specifications of different models.


Enhanced Recipe Example

The following table lists the example of operating the enhanced recipe.

Set the enhanced recipe

1. Click **Data Management > Recipe > Advanced Recipe** on the toolbar.
2. Select the **Enable** checkbox in the enhanced recipe setting page, and then set **Enhanced Recipe Address** to \$0.
3. Click .
4. Set the **Name** as Chocolate, **Fields** as 6, and **Group** as 5 in the **Enhanced Recipe Setting** dialog, and then click **Next**.
5. Configure the data format. Do the following:
 - Set the 1st field as Unsigned Decimal and **Length** to 1.

- Set the 2nd field as Floating, and **Length** to 2, **Integer Digits** to 3, and **Fractional Digits** to 2.
- Set the 3rd field as Char and **Length** to 5.
- Set the 4th field as BCD and **Length** to 2.
- Set the 5th field as Signed Decimal and **Length** to 1.
- Set the 6th field as Hexadecimal and **Length** to 1.



Enhanced Recipe Setting


Batch processing

Data Format: Unsigned Decimal, Length: 1, Integer: , Fractional Digits:

Fields	Data Format	Length	Integer Digits	Fractional Digits	Title
1	Unsigned Decimal	1	0	0	
2	Floating	2	3	2	
3	Char	5	0	0	
4	BCD	2	0	0	
5	Signed Decimal	1	0	0	
6	Hexadecimal	1	0	0	

< Back Next > Finish

- Click **Finish**, and then enter recipe data.



HMI


Enable Enhanced Recipe Address: \$0

1 1 (Group, Field) Search RCPNO name index

1 Chocolate (5X6) 2 Strawberry (3X6)

	RCPNO Name	1 Unsigned Decimal 1 Word	2 Floating 2 Word	3 Char 5 Word	4 BCD 2 Word	5 Signed Decimal 1 Word	6 Hexadecimal 1 Word
Title							
1	1	111	5.55	aaa	11111111	-11	AA
2	2	222	6.66	bbb	22222222	-22	BB
3	3	333	7.77	ccc	33333333	-33	CC
4	4	444	8.88	ddd	44444444	-44	DD
5	5	555	9.99	eee	55555555	-55	EE

7. Add a new recipe, and then set **Name** to Strawberry, **Fields** to 6, and **Group** to 3.
8. Set the same data format and enter the recipe data.



	RCPNO Name	1 Unsigned Decimal 1 Word	2 Floating 2 Word	3 Char 5 Word	4 BCD 2 Word	5 Signed Decimal 1 Word	6 Hexadecimal 1 Word
Title							
1	測試	555	1.11	測試TEST	44444444	-123	AAAA
2	TEST	666	2.22	BBB	55555555	-456	BBBB
3	草莓	777	3.33	CCC	66666666	-789	CCCC


Create ENRCPG Numeric Entry element

1. Create a **Numeric Entry** element.
2. Set the **Write Address** to ENRCPG. This element is mainly used to select the enhanced recipe group.



Create ENRCPGNAME Multi-Language Input element

1. Create a **Multi-language Input** element.
2. Set the **String Length** to 10.
3. Set the **Write Address** to I ENRCPGNAME. This element is mainly used to select the enhanced recipe group by entering the recipe name.



Create ENRCPNO Numeric Entry element

1. Create a **Numeric Entry** element.
2. Set the **Write Address** to ENRCPNO. This element is mainly used to select the enhanced recipe number.



Create ENRCP Numeric Entry element

Before creating the **Numeric Entry** element to display the enhanced recipe register, the formula $[(L*(G+1)-1)]$ of the recipe register can be applied to calculate the number represented by n in ENRCPn. According to the configured recipe field length (L) is 3 X group number (G) is 3, substitute into the recipe, and the number ENRCPn is ENRCP0~ENRCP11.

1. Create a **Numeric Entry** element and set the **Write Address** to ENRCP0. Set its representation mode according to the first field of the recipe table, select the **Data Type** as Word and **Data Format** as Unsigned Decimal.
2. Create a **Numeric Entry** element and set the **Write Address** to ENRCP1. Set its representation mode according to the second field of the recipe table, select the **Data Type** as Double Word and **Data Format** as Floating, and then set the **Integer Digits** to 3 and **Fractional** to 2.
3. Create a **Multi-Language Input** element and set the **Write Address** to ENRCP2. Set its representation mode according to the third field of the recipe table, select or enter the **String Length** as 10

Note: One word length can store two characters.

4. Create a **Numeric Entry** element and set the **Write Address** to ENRCP3. Set its representation mode according to the fourth field of the recipe table, select the **Data Type** as Double Word and **Data Format** as BCD.
5. Create a **Numeric Entry** element and set the **Write Address** to ENRCP4. Set its representation mode according to the fifth field of the recipe table, select the **Data Type** as Word and **Data Format** as Signed Decimal, and then set its **Maximum** and **Minimum**.

6. Create a **Numeric Entry** element and set the **Write Address** to ENRCP5. Set its representation mode according to the sixth field of the recipe table, select the **Data Type** as Word and **Data Format** as Hexadecimal.
7. Repeat steps 1 ~ 6 to create ENRCP6 ~ ENRCP23 elements in order and set their data formats.

	ENRCPN0	ENRCPG	ENRCPNAME			
	W:ENRCPN0 1234	W:ENRCPG 123.45	W:ENRCPNAME ABCDEFGHIJ			
Recipe Buffer	ENRCP0 W:ENRCP0 1234	ENRCP1 W:ENRCP1 123.45	ENRCP2 W:ENRCP2 ABCDEFGHIJ	ENRCP3 W:ENRCP3 12345678	ENRCP4 W:ENRCP4 12345	ENRCP5 W:ENRCP5 1234
Recipe Start Address	ENRCP6 W:ENRCP6 1234	ENRCP7 W:ENRCP7 123.45	ENRCP8 W:ENRCP8 ABCDEFGHIJ	ENRCP9 W:ENRCP9 12345678	ENRCP10 W:ENRCP10 12345	ENRCP11 W:ENRCP11 1234
	W:ENRCP12 1234	W:ENRCP13 123.45	W:ENRCP14 ABCDEFGHIJ	W:ENRCP15 12345678	W:ENRCP16 12345	W:ENRCP17 1234
	W:ENRCP18 1234	W:ENRCP19 123.45	W:ENRCP20 ABCDEFGHIJ	W:ENRCP21 12345678	W:ENRCP22 12345	W:ENRCP23 1234

Note: ENRCP0~ENRCP5 is the recipe buffer, and the actual recipe data is ENRCP6~ENRCP23.


Create recipe read controller address element

Repeat steps 1~6 of the ENRCP address setting to create elements in order and set the **Write Address** to \$0~\$11 and set its **Data Format**.

PLC Address	W:\$0	W:\$1	W:\$3	W:\$8	W:\$10	W:\$11
	1234	123.45	ABCD	12345678	12345	1234


Set Enhanced Recipe Control

Click **General > Configuration** on the toolbar, select the **Enhanced Recipe Control** checkbox in the **Control Block** page, and then set the start address of the control block to decide the recipe control address.



Create Momentary button element


Create two **Momentary Buttons** elements, set the **Write Address** to \$50.1 and \$50.2 respectively, corresponding to Bit 1 and Bit 2 of the recipe control flag to read and write recipes.



Result

After completing the establishment and configuration of all elements, compile and download all data to HMI. You can select different enhanced recipe group according to your needs.

The recipe data will be displayed in ENRCP0 ~ ENRCP11 according to the selected recipe group, among which ENRCP0 ~ ENRCP5 is the recipe buffer data, and the start address of the first group of actual recipe data is ENRCP6.



ENRCPNO	ENRCPG	ENRCPGNAME
1	1	Chocolate

Recipe Buffer	ENRCP0	ENRCP1	ENRCP2	ENRCP3	ENRCP4	ENRCP5
	111	5.55	aaa	11111111	-11	AA

Recipe Start Address	ENRCP6	ENRCP7	ENRCP8	ENRCP9	ENRCP10	ENRCP11
	111	5.55	aaa	11111111	-11	AA
	222	6.66	bbb	22222222	-22	BB
	333	7.77	ccc	33333333	-33	CC

PLC Address	0	0.00		0	0	0
	0	0.00		0	0	0

RCPNO	RCPNO Name					
1	1	111	5.55	aaa	11111111	-11 AA
2	2	222	6.66	bbb	22222222	-22 BB
3	3	333	7.77	ccc	33333333	-33 CC


Recipe Read From PLC

Recipe Write To PLC

Trigger the **Recipe Write** button, which will refer to the selected enhanced recipe group, and write the recipe data of this group to the PLC. Triggering the **Recipe Read** button will also refer to the selected enhanced recipe group, write the PLC data, and read it back to the selected data content of the formula group by HMI.

- **Write Recipe**

1. Set the recipe number and group to be written to the controller.
2. Click **Recipe Write To PLC** to write the data in the recipe buffer to the controller address.



The screenshot shows the 'Enhanced Recipe' HMI screen. It features several input fields for recipe data, organized into sections: ENRCPNO, ENRCPG, ENRCPNAME, Recipe Buffer, Recipe Start Address, and PLC Address. A 'Recipe Viewer' table is also present, showing a list of recipes with their respective data. A 'Step 1' callout points to the ENRCPNAME field, and a 'Step 2' callout points to the 'Recipe Write To PLC' button. A yellow box highlights the 'Enhanced Recipe' title.

RCPNO	RCPNO Name	ENRCP0	ENRCP1	ENRCP2	ENRCP3	ENRCP4	ENRCP5
1	測試	111	5.55	aaa	11111111	-11	AA
2	TEST	666	2.22	BBB	55555555	-456	BBBB
3	台達	777	3.33	CCC	66666666	-789	CCCC


• Read Recipe

1. Set the recipe group name on the HMI screen.



This screenshot shows the 'ENRCPNAME' field with the value 'Chocolate'. A blue arrow points to the 'ASCII-KEY' input field, which contains the text 'Strawberry'. Below the input field is a virtual keyboard with letters, numbers, and symbols.

2. Click **Recipe Read From PLC** to read the controller address data back to the specified recipe number.



The interface shows the configuration for an Enhanced Recipe. It includes fields for ENRCPNO, ENRCPG, and ENRCPGNAME. Below these are sections for Recipe Buffer, Recipe Start Address, and PLC Address, each containing six input fields. A 'Recipe Viewer' table is also present, showing a list of recipes with their RCPNO, RCPNO Name, and associated data. The interface is divided into two steps: Step 1 (Configuration) and Step 2 (Data Transfer).

Step 1

ENRCPNO: 1, ENRCPG: 2, ENRCPGNAME: Strawberry

Enhanced Recipe

Recipe Buffer: ENRCP0: 111, ENRCP1: 5.55, ENRCP2: aaa, ENRCP3: 11111111, ENRCP4: -11, ENRCP5: AA

Recipe Start Address: ENRCP6: 111, ENRCP7: 5.55, ENRCP8: aaa, ENRCP9: 11111111, ENRCP10: -11, ENRCP11: AA

PLC Address: ENRCP0: 111, ENRCP1: 5.55, ENRCP2: aaa, ENRCP3: 11111111, ENRCP4: -11, ENRCP5: AA

Recipe Viewer

RCPNO	RCPNO Name	111	5.55	aaa	11111111	-11	AA
1	測試	111	5.55	aaa	11111111	-11	AA
2	TEST	666	2.22	BBB	55555555	-456	BBBB
3	台達	777	3.33	CCC	66666666	-789	CCCC





Step 2

Recipe Read From PLC, Recipe Write To PLC






Recipe data from PLC read back to HMI


Enhanced Recipe Attributes

The following table lists the settings in the enhanced recipe setting page and their descriptions.

Setting	Description
	Click to add a recipe. Up to 255 sets of recipes can be added.
	Click to delete a recipe. After the deletion, a message dialog displays, asking you whether to delete the enhanced recipe data.
	Click to import the recipe file. Support .csv and .xlsx file formats. Note: If the wrong file is opened, the recipe data will not be displayed normally, and an error message will be displayed after loading.
	Click to export the recipe files in .csv and .xlsx file formats. <ul style="list-style-type: none"> The .csv file only records the data format of the recipe field and the content of the recipe data.

Setting	Description						
<ul style="list-style-type: none"> The .xlsx file records detailed recipe address information, including data format, recipe title, recipe group address or field read address. 	ENRCP-4.0						
	巧克力	6	3				
	2	1	0	0			
	5	2	3	2			
	8	5	0	0			
	0	2	0	0			
	1	1	0	0			
	3	1	0	0			
	1	111	5.55	aaa	11111111	-11	AA
	2	222	6.66	bbb	22222222	-22	BB
	3	333	7.77	ccc	33333333	-33	CC
	草莓						
	2	1	0	0			
	5	2	3	2			
	8	5	0	0			
	0	2	0	0			
	1	1	0	0			
	3	1	0	0			
	測試	555	1.11	測試TEST	44444444	-123	AAAA
	TEST	666	2.22	BBB	55555555	-456	BBBB
	台達	777	3.33	CCC	66666666	-789	CCCC
	Enhanced Recipe						
	Enable Enhanced Recipe	1.0					
	Continuous Enhanced Recipe Address		1				
	Enhanced Recipe Address		0				
	Enhanced Recipe Storage Location		\$0				
	Recipe Name		HMI				
	Recipe Fields		巧克力				
	Recipe Group		6				
	Recipe Address Continued		3				
	Recipe Read Address		0				
	Recipe Fields Setting		None				
	Data Format	Length	Integer	Dig	Fractional	Title	Read Address
	Unsigned Decimal	1	0	0	0		\$0
	Floating	2	3	2	2		\$1
	Char	5	0	0	0		\$3
	BCD	2	0	0	0		\$8
	Signed Decimal	1	0	0	0		\$10
	Hexadecimal	1	0	0	0		\$11
	Recipe Data						
	RCPNO Name						
	1	111	5.55	aaa	11111111	-11	AA
	2	222	6.66	bbb	22222222	-22	BB
	3	333	7.77	ccc	33333333	-33	CC

Setting	Description
	<p>Click to clear all recipe contents.</p> <div> <div>Before</div>  </div> <div> <div>After</div>  </div>
	<p>Click to set the Name, Fields, Group, and Data Format.</p>
Recipe Storage	<p>Select the recipe storage location. The options vary from the model, including HMI, USB Disk, USB Disk 2, and SD.</p> <p>If select HMI, the data will be recorded in the ROM of HMI when powering off.</p>
	<p>Click to switch to Continuous recipe address or Non-continuous recipe address.</p> <p>Unclicking the Continuous Recipe Address icon, the Group addresses are consecutive checkbox displays on the recipe group page.</p> <ul style="list-style-type: none"> If select Group addresses are consecutive, you can set the group Read Address. Its address is the start address of the recipe group. If unselect Group addresses are consecutive, the read address will be displayed in the recipe table, and the read address of each recipe field can be set individually.
Enable	<p>Click to enable the enhanced recipe. If not selected, all enhanced recipe settings will be invalid.</p>

Setting	Description
Enhanced Recipe Address	Select internal memory or controller register address. If click  , the start address of all enhanced recipes is the set address.
(Groups, Fields) Search	After entering the number of groups and fields to be searched, click this button to search.
RCPNOname index	After entering the RCPNO name to be searched, click this button to search.

The following table lists the settings in the Enhanced Recipe Setting dialog and their descriptions.

Setting	Description														
Name	Enter the group name of the enhanced recipe. Support Unicode input, you can enter the languages of each country.														
Field	Select or enter the number of fields. Fields indicates the length and of the recipe. The value range is 1–2048.														
Group	Select or enter the number of groups. Group indicates the length of the enhanced recipe. The value range is 1–65535.														
Data Format	Select the data format. The options are BCD, Signed Decimal, Unsigned Decimal, Hex, Floating, and Char. Among them, the read length of the Char format supports up to 32 Word lengths (that is, 64 characters), and supports Unicode input. Note: If select Char, do not fill in the value with the same character as the delimiter, otherwise, it will cause data errors and the data will fail to import.														
Length	Select the read length. The read length varies from the data format. <table border="1"> <thead> <tr> <th>Data Format</th><th>Length</th></tr> </thead> <tbody> <tr> <td>BCD</td><td>1: Word</td></tr> <tr> <td>Signed Decimal</td><td>2: Double Word</td></tr> <tr> <td>Unsigned Decimal</td><td>4: Quad Word</td></tr> <tr> <td>Hexadecimal</td><td></td></tr> <tr> <td>Floating</td><td>2: Double Word 4: Quad Word</td></tr> <tr> <td>Char</td><td>Supports up to 32 Words (64 characters)</td></tr> </tbody> </table>	Data Format	Length	BCD	1: Word	Signed Decimal	2: Double Word	Unsigned Decimal	4: Quad Word	Hexadecimal		Floating	2: Double Word 4: Quad Word	Char	Supports up to 32 Words (64 characters)
Data Format	Length														
BCD	1: Word														
Signed Decimal	2: Double Word														
Unsigned Decimal	4: Quad Word														
Hexadecimal															
Floating	2: Double Word 4: Quad Word														
Char	Supports up to 32 Words (64 characters)														

Setting	Description
Integer Digits	This setting is available only when the Data Format is selected as Floating. Note: The sum of Integer Digits and Fractional Digits only supports 7 digits.
Fractional Digits	This setting is available only when the Data Format is selected as Floating. Note: The sum of Integer Digits and Fractional Digits only supports 7 digits.


OPC UA

Use the OPC UA Client function to import tags from files or use Ethernet to connect to the OPC UA Server. This section introduces the setting instructions for OPC UA Client and OPC UA Server.

OPC UA Client Settings


To set OPC UA Client

1. Create a project for a model that supports Ethernet.
2. On the menu bar, click **General > Device Communication**.
3. In the **Device Communication** dialog, click **Ethernet1**.
4. In the **Device** tab, click  to add a new network connection, and then select the controller as **OPC UA Client**.




To import OPC UA Tag

- **Import from file**

1. In the **Device Communication** dialog, set the controller as **OPC UA Client**, and click **Import**.
2. In the **Tag List** dialog, click  to import tag (XML or CSV file).

Note:


- The .xml file is a file exported by the OPC UA server.
- The .csv file is a file exported by ISPSOft software. Follow the steps to export a .csv file.
 - a. In ISPSOft software, in **Project** pane, double-click **Global Symbols** > **OPC UA Table**.
 - b. In the **OPC UA Table** dialog, right-click an empty space and select **Add a Symbol** to create the symbol.
 - c. Export the global symbol table. Do any of the following:
 - Right-click an empty space and select **Export Global Symbol**.
 - In **Project** pane, right-click **OPC UA Table** and select **Export Global Symbol**.



Note: The OPC UA Server function is currently only available for AS-300 series models. It requires an additional AS-FOP02 communication card and ISPSOft version 3.13 and above.

- **Import Tags from OPC UA Server**


1. In the **Device Communication** dialog, after setting **Controller** as **OPC UA Client**, enter IP address and communication port of the OPC UA server in **Controller IP** field.



2. Click **Import**.


3. In the **Tag List** dialog, click .



The Tag has been imported to the OPC UA Server through the set IP address. The tag list can be viewed.



Using OPC UA Tag

- Used for elements: In the **Read Address / Write Address** dialog, select **EtherLink1** for **Link**.



- Used for macro commands: In the macro editing dialog, click  and enter macro command. If the variable content selects OPC UA Tag, OPC UA Tag automatically adds single quotes after updating the macro; if you use  to input OPC UA Tag, you need to manually add single quotes before and after the OPC UA Tag.

```
{OPC-UA}@@Root.Objects.DemoUANodeSetXML.010_ComplianceTest.Static.All Profiles.Scalar.Double
```

The following table lists the supported OPC UA Tag NodeID types and OPC UA Tag data types.

OPC UA Tag NodeID Type Support List		
NodeID (Identifier Type)	Scalar	Array
I (Numeric)	V	V
B (Opaque)	V	-
S (String)	V	V
G (GUID)	V	-
Data Type	Scalar	Array
Boolean	V	V
Byte	V	V
Int32	V	V
Int16	V	V
Int64	V	V
Double	V	V
Float	V	V
SByte	V	V
String	V	V
UInt32	V	V
UInt16	V	V
UInt64	V	V

OPC UA Server Settings

Set the communication address as an OPC UA variable through the OPC UA Server.

Note: This function only supports DOP-107WV, DOP-103WQ, DOP-110WS, DOP-112MX, DOP-115MX, DOP-112WX, DOP-115WX, and DOP-300 series models.





How to open **OPC UA server**?

- In **Project pane**, double-click **OPC UA Server**.

Or

- Click **IIoT > OPC UA Server** on the menu bar.

The following table lists the functions in the **OPC UA Server** dialog with their description.

Function	Description
	Click to add a new group.
	Click to add a new tag. Note: Address is required. If not set, a message appears to inform you that the address input failed.
	Select the tag or group you want to delete, then click this icon to delete.
	Select the tag or group you want to edit, then click this icon to edit its properties. Note: You can double-click a tag or group to edit properties.


Follow these steps to apply the OPC UA server tag to the element.

To apply OPC UA server tag to element

1. Create an element.
2. In the address **Input** dialog of the element, select **OPCUA Server** for **Link**.

Tags display in the list below.

3. Select the tag you want to apply to the element, and click **OK**.



OPC UA Security Policy and User Authentication


In OPC UA (Open Platform Communications Unified Architecture), security can be ensured through account authentication and encrypted communication. The account authentication is the most basic and simple. Enter the user's account name and password and have the server verified the credentials and allow access if they match.

Note: This function is only available for DOP-300 series models.

Follow these steps for OPC UA authentication.

- **OPC UA Client**
 1. In the **Device Communication** dialog, click **Ethernet1**.
 2. In the **Device** tab, select **OPC UA Client** for **Controller**, and the **Certification** tab displays.

The following table lists the functions in the **Certification** tab with their description.




1 Security

Function	Description
Security Policy	Select a security policy. The available options include None, Basic128Rsa15, Basic256, Basic256Sha256, Aes128Sha256RsaOaep, and Aes256Sha256RsaPss.
Message Security Mode	Select a message security mode. The available options include None, Sign, and Sign & Encrypt.


2 Authentication

Function	Description
Anonymous	Choose anonymous login or user login.
Username/Password Login	

- **OPC UA Server**

In the **OPC UA Server** dialog, click  to open **OPC UA server settings** dialog.

The following table lists the functions in the **OPC UA server settings** dialog with their description.



Function		Description
General	Port Number	Select or enter the port number. The range value is 0–65535, and the default value is 4840 .
	Security Policies	<p>Check the security policy and select message security mode.</p> <ul style="list-style-type: none"> Security policy options include None, Basic128Rsa15, Basic256, Basic256Sha256, Aes128Sha256RsaOaep, and Aes256Sha256RsaPss. Message security mode options include None, Sign, and Sign & Encrypt
Verification	Allow anonymity	If selected, check at least one of the options - Browse, Read, or Write.
	Username & Password	If selected, Name and Password should not be vacant.


MQTT Settings


HMI sends messages through an object to the MQTT server or subscribes to a topic from the MQTT server. It can also be an MQTT server. When the HMI is an MQTT server, the messages will not be sent to other servers.

MQTT Broker

You need to add a Broker to enable MQTT functions.

To add a Broker

1. Click **IoT > MQTT Settings** on the toolbar.
2. In the **MQTT Settings** dialog, click  to add a Broker on the toolbar.
Note: Supports up to 5 MQTT Broker for one HMI.
3. In the **MQTT Broker Information** dialog, enter the information for the Broker in the **General** tab.



The image shows the 'MQTT Broker Information' dialog box with the 'General' tab selected. The dialog has two tabs: 'General' and 'Address'. The 'General' tab contains the following fields and controls:

- Server:** A dropdown menu set to 'General'.
- Communication:** A dropdown menu set to 'MQTT v3.1.1'.
- Description:** A text field containing 'Broker1'.
- IP / URL:** An empty text field.
- Port:** A spin box set to '1883'.
- Client ID:** An empty text field with a note below it: '(Word limit: 128) %0: HMIID, %2: Random Code'.
- Account:** An empty text field.
- Password:** An empty text field.
- QoS:** A dropdown menu set to '0'.
- Cert:** A button labeled 'Set certificate' with an ellipsis icon.
- Keep Alive (s):** A spin box set to '60'.

On the right side of the dialog, there are additional options:

- Will Message:** A checkbox that is currently unchecked.
- Last-Will Topic:** An empty text field.
- Last-Will Message:** A large text area for entering the message content.
- Last-Will QoS:** A dropdown menu set to '0'.
- Last-Will Retain:** A checkbox that is currently unchecked.

At the bottom right, there are 'OK' and 'Cancel' buttons.

Note: In the MQTT specification, each client will have a Client ID, allowing the broker to determine where the data is sent, but if the Client ID is duplicated, the client that connects later will fail to connect. In order to avoid duplicate client IDs, HMI provides two variables, %0 (HWID) and %2 (Random Code) settings, where HWID is an internal parameter and is a unique identification code in the HMI, and different machines will have their own HWID.


Will Message

The Will Message is a simplified version of the PUBLISH message. It is specified through the CONNECT packet when the device is connected to the server. The server publishes Will Message to the Will Topic specified when the device is unexpectedly disconnected, the server must complete the storage of the Will Message before responding CONNACK to ensure that the message is published.

Follow these steps to set up Will Message.

To set up will message

1. In the **MQTT Broker Information** dialog, set up **Will Message**.




The image shows the 'MQTT Broker Information' dialog box with the 'General' tab selected. The 'Will Message' section is highlighted with a blue border. The 'Will Message' checkbox is checked. The 'Last-Will Topic' is set to 'WILL'. The 'Last-Will Message' text area contains 'WILL_MESSAGE'. The 'Last-Will QoS' is set to '0'. The 'Last-Will Retain' checkbox is checked. The 'OK' button is highlighted with a blue border.

Field	Value
Server:	General
Communication	MQTT v3.1.1
Description:	Broker1
IP / URL:	
Port:	1883
Client ID:	
(Word limit: 128)	%0: HMIID, %2: Random Code
Account:	
Password:	
QoS:	0
Cert:	Set certificate
Keep Alive (s):	60
Will Message	Checked
Last-Will Topic:	WILL
Last-Will Message:	WILL_MESSAGE
Last-Will QoS:	0
Last-Will Retain	Checked

- Open MQTTX software and set up the Will Message Subscriber of the MQTT connection.

Note: You can go to mqttx.app/zh to download the MQTTX software.




The screenshot shows the 'MQTTX' software interface for editing an MQTT connection. The left sidebar shows a list of connections, with 'MQTT@192.168.0.55:...' selected. The main panel is titled '编辑' (Edit) and contains two sections: '基础' (Basic) and '高级' (Advanced).

基础 (Basic) Settings:

- 名称 (Name):** MQTT
- Client ID:** mqttx_e68e8cf4
- 服务器地址 (Server Address):** mqtt:// 192.168.0.55
- 端口 (Port):** 5678
- 用户名 (Username):** (empty)
- 密码 (Password):** (empty)
- SSL/TLS:** (disabled)

高级 (Advanced) Settings:

- MQTT 版本 (MQTT Version):** 5.0
- 连接超时时长 (Connection Timeout):** 10 (秒)
- Keep Alive:** 60 (秒)
- 自动重连 (Auto Reconnect):** (disabled)





The screenshot shows the 'Edit Subscription' dialog box in the MQTTX software. It contains the following fields and options:


- Topic:** WILL
- QoS:** 0 (At most once)
- Color:** #C13125
- Alias:** (empty)
- Subscription Identifier:** (empty)
- No Local flag:** true (selected), false
- Retain as Published flag:** true (selected), false
- Retain Handling:** 0

At the bottom right, there are 'Cancel' and 'Confirm' buttons.

When the HMI is disconnected, MQTTX receives the WILL Message.



3. In the MQTTX tool, click  and reconnect to receive the WILL retained message.



Address Setting


The **States Address** function displays the current connection status and error codes of the Client and Server. The connection state helps you check whether the device is disconnected. If disconnected, you can check the type of the current communication error through the error codes and set the Control Address on the HMI to change the connection message, such as Broker IP, Port, account, password, and so on.

To set states address and control address

- In the **MQTT Broker information** dialog, set the current **States Address** and **Control Address** in the **Address** tab to automatically configure all controls through the continuous address function.

Note: The **States Address** and **Control Address** limit setting the internal memory address.

The following table lists the internal addresses limited by **States Address** with their description of error codes. Set the **States Address** to \$180 as an example.




The screenshot shows the 'MQTT Broker Information' dialog box with the 'Address' tab selected. The 'Status Address' field is set to '\$180'. Below it, a table lists the internal addresses and their descriptions:

Control Address	Description
\$180	Status (0: Stopped, 1: Disconnected, 2: Connected)
\$181	Error (0: None, non-0: Error)

At the bottom of the dialog, there are 'OK' and 'Cancel' buttons.

Address	Error Code Description
\$180 (Status address)	<ul style="list-style-type: none"> 0: Stopped 1: Disconnected 2: Connected
\$181 (Error address)	<ul style="list-style-type: none"> 0: No errors 3: Invalid parameter 4: Client is not connected to Broker 7: Disconnected 14: Underlying system calls failed <p>Note: Look over and judge from the system log or other relevant messages for detailed error messages.</p> <ul style="list-style-type: none"> 15: Network address analysis error or not use the external network to connect 99: JSON data type is not yet supported


The following table lists the internal address limited by **Control Address** with their description of error codes. Set the **Control Address** to \$200 as an example.



The image shows a screenshot of the 'MQTT Broker Information' dialog box. It has two tabs: 'General' and 'Address'. The 'Address' tab is selected. In this tab, there are two input fields: 'Status Address' with the value '\$180' and 'Control Address' with the value '\$200'. Below the 'Control Address' field, there is a list of internal addresses and their descriptions:

Address	Description
\$200	Command (0:None, 1:Start, 2:Stop, 3:Update)
\$201	IP (4 characters)
\$205	Connection port number
\$206	Client ID (20 characters)
\$226	Authentication (0: Disabled, 1: Enabled)
\$227	Username (16 characters)
\$243	Password (16 characters)

At the bottom right of the dialog box, there are 'OK' and 'Cancel' buttons.

Address	Error Code Description
\$200 (Command address)	<ul style="list-style-type: none"> 0: None 1: Start 2: Stop 3: Update
\$201~204 (Broker IP address)	Used to set the IP address for which the Data Type is Word.
\$206 (Client ID)	A maximum of 20 bits are supported.
\$226 (Authentication address)	<ul style="list-style-type: none"> 0: Disabled 1: Enabled <p>Note: This address is based on whether the Certification Information is enabled.</p> 
\$227~242 (Username address)	Used to configure the user account address. Set the Character Input element for which the string length is 16.
\$243~259 (Password address)	Used to configure the password address. Set the Character Input element for which the string length is 16.

The following figure is an example of the screen configuration.

Status	W:\$180	Error Code	W:\$181
Command	W:\$200		
IP	W:\$201	W:\$202	W:\$203
Connection port number	W:\$205		
Authentication	W:\$226		
Username	W:\$227	W:\$243	
Password			

\$180	Status (0: Stopped, 1: Disconnected, 2: Connected)
\$181	Error (0: None, non-0: Error)
\$200	Command (0:None, 1:Start, 2:Stop, 3:Update)
\$201	IP (4 characters)
\$205	Connection port number
\$206	Reserved (20 characters)
\$226	Authentication (0: Disabled, 1: Enabled)
\$227	Username (16 characters)
\$243	Password (16 characters)

After downloading the screen to the HMI, the addresses are shown in the figure below.

V2 192.168.0.5 (x11vnc) - VNC Viewer

Status	2	Error Code	0
Command	0		
IP	192	168	0
Connection port number	5678		
Authentication	0		
Username	1111		
Password	1111		


\$180	Status (0: Stopped, 1: Disconnected, 2: Connected)
\$181	Error (0: None, non-0: Error)
\$200	Command (0:None, 1:Start, 2:Stop, 3:Update)
\$201	IP (4 characters)
\$205	Connection port number
\$206	Reserved (20 characters)
\$226	Authentication (0: Disabled, 1: Enabled)
\$227	Username (16 characters)
\$243	Password (16 characters)

MQTT Publisher & Subscriber


This section describes the properties content of Publisher and Subscriber.



Note: Publisher and Subscriber can add up to 100 topics each.


General Properties



The image shows the 'MQTT Publisher Property' dialog box with the 'General Properties' tab selected. The 'Topic' field is empty, with a placeholder text '%0: HMIIID, %1: Client ID' and a button to open the topic selector. The 'Sampling method' section has two options: 'Value change' (checked) and 'Timed execution' (unchecked). The 'Sampling time(s)' is set to 3. The 'Retain Message' checkbox is unchecked. The 'Content format' is set to 'JSON (General)'. The 'Timestamp' and 'Use "d" for the top level' checkboxes are both checked. The 'OK' and 'Cancel' buttons are at the bottom right.

Function	Description
Topic	<ul style="list-style-type: none"> In order to reduce the possibility of duplicate topics and make it easier for users to distinguish where data is being sent and received from, you can set the topic as a variable, providing %0 as HWID and %1 as the Client ID. DOP-300 series HMI can dynamically set the topic. After configuring the address variable for the topic content, the topic content can be dynamically changed through the address variable on the HMI to obtain different topic messages. <p>Follow these steps to set the topic.</p> <ol style="list-style-type: none"> Click  in the Topic field on the General Properties tab or in the Topic field on the Publisher or Subscriber list.

Function	Description
	<div data-bbox="539 271 1378 714">  </div> <p>2. In the Address Settings dialog, set Variable definition and Topic address and click OK.</p> <p>Note:</p> <ul style="list-style-type: none"> The setting formats are %s: String, %f: Floating, %d: Decimal, and Hexadecimal. <div data-bbox="553 927 1378 1391">  </div> <ul style="list-style-type: none"> The maximum number is 8. <p>3. Enter the variable definition in the Topic field in the General Properties tab, for example, %s1%d2%f3.</p> <p>4. Execute on the HMI. When the topics of Publisher and Subscriber are the same, the HMI sends the corresponding data.</p>


Function	Description
	
Sampling method	<p>Select the sampling method during execution.</p> <ul style="list-style-type: none"> Value Change: Sampling when the value changes. Timed Execution: Sampling according to the set sampling time. <p>Note: This function is only available in the Publisher properties.</p>
Retain Message	<p>When Publisher publishes a message, if the Retained mark in the MQTTX software is set as True, the message is a Retain Message in MQTT. The MQTT server stores the latest retain message for each topic so that clients that come online after the message is published can still receive the message when subscribing to the topic.</p> <p>Note: This function is only available in the Publisher properties.</p>
Content format	<p>Select the content format.</p> <ul style="list-style-type: none"> JSON (General): Basic JSON format. JSON (Advanced): You can customize the JSON format of the nested structure. <p>Note: JSON (Advanced) is only supported in the DOP-300 series HMI.</p>
Timestamp / Use "d" for the top level	<ul style="list-style-type: none"> Timestamp and d message format may not exist in different application scenarios. However, the default MQTT Message function of Delta HMI displays these two pieces of information. In case the messages received when receiving data do not contain these two pieces of information, the communication fails. It is suggested to enable Time stamp and Use "d" for the top level functions. Confirm whether the timestamp and "d" mark appear in the JSON format of the HMI topic through the MQTTX software. <p>Note: Go to mqttx.app/zh to download the MQTTX software.</p> <p>Timestamp:</p>

Function	Description
	<div><div><div><div>+ New Subscription</div><div><div>WILLQoS 0</div><div>HMIQoS 0</div><div>ArrayQoS 0</div><div>AAQoS 0</div></div></div><div><div>JSON</div><div><pre>"B4": [0], "C1": [0], "Q1": [0], "Q2": [0], "Q3": [0], "Q4": [0] }, "ts": "2024-06-13 15:20:47" }</pre></div><div>2024-06-13 15:20:48:392</div><div><div>Plaintext</div><div>QoS 0</div><div><input checked="" type="radio"/> Retain</div><div>Meta</div><div>▲</div></div><div>WILL</div><div>123456</div></div></div></div>
	<div><div>Use “d” for the top level:</div><div><div>Topic: HMIQoS: 0</div><div><pre>{ "d": { "A1": [0], "A2": [0], "A3": [0], "B1": [1], "B2": [0], }, }</pre></div></div></div>

Content Settings

JSON (General)

DIAScreen provides Unsigned Decimal, Signed Decimal, Floating, Hexadecimal, and Char numeric formats with different numerical units for users to set according to the data size to transfer.








JSON (Advanced)






Note:



- This function is only supported in the DOP-300 series HMI.
- Advanced JSON format can set up to 8 layers of nodes.
- A maximum of 512 nodes can be set for a topic.

The following lists the toolbar settings in the **Content Settings** tab for JSON (Advance) with their description.









Function	Description
	<p>Click to add an object. The JSON format is represented by {}.</p> <div data-bbox="408 1285 1374 1494">  </div> <p>Note: The maximum name input length is 256 characters.</p>
	<p>Click to add a general array. The JSON format is represented by [].</p> <div data-bbox="408 1597 1374 1805">  </div> <p>Note:</p> <ul style="list-style-type: none"> The maximum name input length is 256 characters The names of child nodes under general arrays cannot be edited, and the software will automatically name them with [0] ~ [n].




Function	Description
	
	<p>Click to add a Numeric array. In the Numeric Array dialog, set Name, Type, Address, and Size for a numeric array.</p>  <p>Note: The maximum name input length is 256 characters.</p> <p>The following figure shows the JSON format of a numeric array.</p> 
	<p>Click to add a value. In the Numerical Value dialog, set Name, Type, Timestamp, and so on for a numerical value.</p>

Function	Description
	
Function	Description
Name	Enter a value name. Note: The maximum input length is 256 characters.
Type	Select the numerical type. The default is String .
Numerical	<p>Select the numerical format. The default is Address. Note:</p> <ul style="list-style-type: none"> When String is selected as Type, a maximum of 256 characters can be entered for a Fixed Value. When Quantity is selected as Type, up to 20 characters can be entered for a Fixed Value. When setting Subscriber topic content, the Fixed Value option is not available and the Timestamp option is limited to one topic selection. 
The corresponding JSON format of each numerical type is shown in the following figure.	

Function	Description																																																																																																						
	<div><div>MQTT Publisher Property</div><div><div>General Properties</div><div>Content Settings</div></div><div><div><div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div></div><div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div></div></div><table><thead><tr><th>Name</th><th>Type</th><th>Numerical Value</th><th>Address</th><th>Address Type</th><th>Length</th></tr></thead><tbody><tr><td>Payload</td><td>Object</td><td></td><td></td><td></td><td></td></tr><tr><td>Value</td><td>String</td><td>Hello</td><td></td><td></td><td></td></tr><tr><td>Value(2)</td><td>String</td><td></td><td>\$10</td><td>String</td><td>10</td></tr><tr><td>Value(3)</td><td>String</td><td>Timestamp</td><td></td><td></td><td></td></tr><tr><td>Value(4)</td><td>Quantity</td><td>123</td><td></td><td></td><td></td></tr><tr><td>Value(5)</td><td>Quantity</td><td></td><td>\$100</td><td>UInt16</td><td>1</td></tr><tr><td>Value(6)</td><td>Quantity</td><td>Timestamp</td><td></td><td></td><td></td></tr><tr><td>Value(7)</td><td>Boolean</td><td>false</td><td></td><td></td><td></td></tr><tr><td>Value(8)</td><td>Boolean</td><td></td><td>\$0.0</td><td>Boolean</td><td>1</td></tr></tbody></table></div></div> <div><div>JSON Text</div><div><pre>{ "Value": "Hello", "Value(2)": "abcd", "Value(3)": "2024-08-14 16:03:54", "Value(4)": 123, "Value(5)": 65535, "Value(6)": 1723622634675, "Value(7)": false, "Value(8)": false}</pre></div></div>	Name	Type	Numerical Value	Address	Address Type	Length	Payload	Object					Value	String	Hello				Value(2)	String		\$10	String	10	Value(3)	String	Timestamp				Value(4)	Quantity	123				Value(5)	Quantity		\$100	UInt16	1	Value(6)	Quantity	Timestamp				Value(7)	Boolean	false				Value(8)	Boolean		\$0.0	Boolean	1																																										
Name	Type	Numerical Value	Address	Address Type	Length																																																																																																		
Payload	Object																																																																																																						
Value	String	Hello																																																																																																					
Value(2)	String		\$10	String	10																																																																																																		
Value(3)	String	Timestamp																																																																																																					
Value(4)	Quantity	123																																																																																																					
Value(5)	Quantity		\$100	UInt16	1																																																																																																		
Value(6)	Quantity	Timestamp																																																																																																					
Value(7)	Boolean	false																																																																																																					
Value(8)	Boolean		\$0.0	Boolean	1																																																																																																		
<div><div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div></div></div>	<div><div>Select the node to be deleted and click this icon to delete.</div><div>Note: Its child nodes will be deleted together.</div></div> <div><div><div>Before delete</div><div><div>MQTT Publisher Property</div><div><div>General Properties</div><div>Content Settings</div></div><div><div><div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div></div><div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div></div></div><table><thead><tr><th>Name</th><th>Type</th><th>Numerical Value</th><th>Address</th><th>Address Type</th><th>Length</th></tr></thead><tbody><tr><td>Payload</td><td>Object</td><td></td><td></td><td></td><td></td></tr><tr><td>Object</td><td>Object</td><td></td><td></td><td></td><td></td></tr><tr><td>Array</td><td>Array</td><td></td><td>\$10</td><td>UInt16</td><td>1</td></tr><tr><td>[0]</td><td>Quantity</td><td></td><td></td><td></td><td></td></tr><tr><td>[1]</td><td>String</td><td>Hello</td><td></td><td></td><td></td></tr><tr><td>[2]</td><td>Boolean</td><td>true</td><td></td><td></td><td></td></tr><tr><td>[3]</td><td>Quantity</td><td>1000</td><td></td><td></td><td></td></tr><tr><td>Value</td><td>String</td><td></td><td>{Link2}1@D0</td><td>String</td><td>20</td></tr><tr><td>Object(2)</td><td>Object</td><td></td><td></td><td></td><td></td></tr><tr><td>Value</td><td>String</td><td>Timestamp</td><td></td><td></td><td></td></tr><tr><td>Array[5]</td><td>Array (Quantity)</td><td></td><td>{Link2}1@D50</td><td>UInt16</td><td>5</td></tr></tbody></table></div></div><div><div>After delete</div><div><div>MQTT Publisher Property</div><div><div>General Properties</div><div>Content Settings</div></div><div><div><div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div></div><div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div></div></div><table><thead><tr><th>Name</th><th>Type</th><th>Numerical Value</th><th>Address</th><th>Address Type</th><th>Length</th></tr></thead><tbody><tr><td>Payload</td><td>Object</td><td></td><td></td><td></td><td></td></tr><tr><td>Object(2)</td><td>Object</td><td></td><td></td><td></td><td></td></tr><tr><td>Value</td><td>String</td><td>Timestamp</td><td></td><td></td><td></td></tr><tr><td>Array[5]</td><td>Array (Quantity)</td><td></td><td>{Link2}1@D50</td><td>UInt16</td><td>5</td></tr></tbody></table></div></div></div></div></div>	Name	Type	Numerical Value	Address	Address Type	Length	Payload	Object					Object	Object					Array	Array		\$10	UInt16	1	[0]	Quantity					[1]	String	Hello				[2]	Boolean	true				[3]	Quantity	1000				Value	String		{Link2}1@D0	String	20	Object(2)	Object					Value	String	Timestamp				Array[5]	Array (Quantity)		{Link2}1@D50	UInt16	5	Name	Type	Numerical Value	Address	Address Type	Length	Payload	Object					Object(2)	Object					Value	String	Timestamp				Array[5]	Array (Quantity)		{Link2}1@D50	UInt16	5
Name	Type	Numerical Value	Address	Address Type	Length																																																																																																		
Payload	Object																																																																																																						
Object	Object																																																																																																						
Array	Array		\$10	UInt16	1																																																																																																		
[0]	Quantity																																																																																																						
[1]	String	Hello																																																																																																					
[2]	Boolean	true																																																																																																					
[3]	Quantity	1000																																																																																																					
Value	String		{Link2}1@D0	String	20																																																																																																		
Object(2)	Object																																																																																																						
Value	String	Timestamp																																																																																																					
Array[5]	Array (Quantity)		{Link2}1@D50	UInt16	5																																																																																																		
Name	Type	Numerical Value	Address	Address Type	Length																																																																																																		
Payload	Object																																																																																																						
Object(2)	Object																																																																																																						
Value	String	Timestamp																																																																																																					
Array[5]	Array (Quantity)		{Link2}1@D50	UInt16	5																																																																																																		
<div><div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div></div></div>	<div><div>Select the node to be edited and click this icon to edit.</div></div>																																																																																																						

Function	Description
	<p>Select the node to be copied and click this icon to copy and paste. Note: Its child nodes will be copied together.</p>
	<div> <div>Copy</div>  </div> <div> <div>Paste</div>  </div>


Function	Description
	<p>Click to use a template. In the JSON Text dialog, fill in the JSON format, the corresponding tree structure will be automatically converted.</p>
	<div> <div> <p>JSON text content</p> </div> <div>  </div> </div> <div> <div> <p>Tree structure after conversion</p> </div> <div>  </div> </div> <p>Note:</p> <ul style="list-style-type: none"> The Value node in the Publisher topic settings is converted to a Fixed Value. The Value node in the Subscriber topic settings is converted to an Address Value.

Function	Description
	<p>Click to preview the JSON format. The tree structure content will be converted to the corresponding JSON format.</p>
	<div> <div>Tree structure content</div> <div>  </div> </div> <div> <div>JSON text content after conversion</div> <div>  </div> </div>

Support Azure IoT Hub and Aliyun Server

MQTT supports Azure IoT Hub and Aliyun server. The applicable models are as follows.

- Azure IoT Hub server: All series models
- Aliyun server: DOP-300 series models



The comparisons between Azure IoT Hub and Aliyun server are as follows.

	Azure IoT Hub	Aliyun
Cert certificate version	TLS 1.2 and above	TLS 1.2 and above
QoS	0, 1	0, 1,2
Communication	MQTT v3.1.1	MQTT v3.1.1
Default port	8883	8883

MQTT Broker Information Settings Limit

- When selecting **Azure IoT Hub** or **Aliyun** for **Server**, **Communication** can only be selected as **MQTT v3.1.1**.
- When selecting **Azure IoT Hub** for **Server**, **QoS** can only be set to **0** or **1**.
- When selecting **Azure IoT Hub** and **Aliyun** for **Server**, **Version** can only be set to **TLS1.2** in the **Certificate** file dialog of the **Cert** field.

- When selecting **Aliyun** for **Server**, **Content format** can only be set to **JSON (Advanced)** in the property dialog of the **Publisher** and **Subscriber** tabs.
- When selecting **Azure IoT Hub** for **Server**, in the **MQTT Subscriber Property** dialog of the **Subscriber** tab, the **Topic** field requires two special open symbols, such as # and #, and # can only be placed in the end of the final level.

Example:

- **# symbol**

Enter devices/Delta_HMI/messages/events/#, other characters must not be entered after the # symbol.

- **+ symbol**

Only /single-level message can be entered after the + symbol, for example, devices/+/temperature. If you enter two levels of message, you will not be able to receive the information.

- When selecting **Amazon AWS** for **Server**, you need to verify its credentials. Without a credential, you cannot use the Amazon AWS server.

IIoT

IIoT integrates the cloud platform for DIAScreen, which can upload DIAScreen projects to the cloud or download projects from the cloud to DIAScreen for editing. At the same time, the HMI can also transmit data to the cloud and monitor the device through the configuration screen of the cloud platform.

Note: This function is only applicable to DOP-300 series models.

To create a template and upload it to the cloud

1. On the menu bar, click **IIoT > DIACloud > Cloud Template**.
2. In the **Cloud Template** dialog, check **Enable cloud templates**.

Note: The VNC function will be enabled at the same time to monitor the HMI screen from the cloud.
3. In the **Upload Template** area, click **Create New Template**.
4. In the **Template Information** area, click **Edit Template** to edit template.
5. In the **Cloud Template Information** dialog, enter the template information and click **OK**.

The template is created.

6. Click **Login** in the upper right corner to open **Login to DIACloud** dialog.
7. In the **Login to DIACloud** dialog, enter your DIACloud Account and Password, and then click **Login**.

Note: If you have not registered a DIACloud account, go to hms.diacloudsolutions.com to register.

8. Click **Transmission starts** to start to upload the DIAScreen project to the cloud.

☒ Enable cloud templates

Upload Template

Template:

Create New Template

Transmission starts

Template Information

Template Name:

Model: DOP-3S07S3E2

Edit Template

Not logged in

Login

*[When this function is enabled, the HMI time mechanism will be based on the cloud]

*[Therefore, the time will not be changed through other methods, such as perpetual calendar, NTP, system directory or macro functions]

OK

Close

You can also create cloud data in DIAScreen so the configuration screen can reference the corresponding variables to monitor the device.

To create Cloud Tag

1. On the menu bar, click **IIoT > DIACloud > Cloud Tag**.
2. In the **Cloud Tag** dialog, click  to add a new tag.
3. Make relevant settings and click **OK**.

Cloud Tag


No. /	Name	Description	Type	Default	Address	Store Data in Cloud	Access Status	Minimum	Maximum	Fractional Digits	Length	Upload cycle (seconds)
1	BOOL_Tag		BOOL		\$0.0	No	Readable/Writable					300
2	INT_Tag		UINT16		\$100	No	Readable/Writable	-32768	32767			300

OK

Cancel

Note:

- Cloud tag supports BOOL, UINT16, UINT32, UINT64, INT16, INT32, INT64, REAL, LREAL and STRING data types. The corresponding data type can be selected based on the actual data value.
- If the currently edited project has been bound to a template, you need to log in to DIACloud before opening the **Cloud Tag** dialog to ensure that the tag content is synchronized with the cloud.
- If the cloud tag is used in the configuration screen, some fields in the **Cloud Tag** will be grayed out and cannot be edited.



No.	Name	Description	Type	Default	Address	Store Data in Cloud	Access Status	Minimum	Maximum	Fractional Digits	Length	Upload cycle (seconds)
1	A0		INT16		\$1001	Yes	Readable/Writable	-32768	32767			300
2	A1		INT16		\$1002	Yes	Readable/Writable	-32768	32767			300
3	A2		INT16		\$1003	Yes	Readable/Writable	-32768	32767			300
4	B0		INT16		\$1004	Yes	Readable/Writable	-32768	32767			300
5	B1		INT16		\$1005	Yes	Readable/Writable	-32768	32767			300
6	B2		INT16		\$1006	Yes	Readable/Writable	-32768	32767			300
7	C0		INT16		\$1007	Yes	Readable/Writable	-32768	32767			300
8	C1		INT16		\$1008	Yes	Readable/Writable	-32768	32767			300
9	C2		INT16		\$1009	Yes	Readable/Writable	-32768	32767			300
10	int16	int16	INT16		\$20	No	Readable/Writable	-32768	32767			300
11	mint32		INT32		\$1100	No	Readable/Writable	-2147483648	2147483647			300
12	A1000		UINT32		\$2000	Yes	Readable/Writable	0	4294967295			300
13	mUint64	DDD	UINT64	123	\$400	Yes	Readable/Writable	0	18446744073709551615			300
14	mUint16	888	UINT16		\$200	Yes	Readable/Writable	100	10000			300
15	mUint32	CCC	UINT32	123	\$300	Yes	Readable/Writable	0	4294967295			300
16	mint16	EEE	INT16	123	\$500	No	Readable/Writable	-32768	32767			300
17	mReal		REAL	123.123	\$800	Yes	Readable/Writable	0	3.40282e+38	0		300

You can also download projects to DIAScreen from the cloud.

How to enable cloud templates?

- In the main menu, click **Open Cloud Template**.

Follow these steps to download a project from the cloud to a template.

To download projects to templates from the cloud

1. Click **Login** to log in to DIACloud.
2. Select the template you want to download.
3. Click **OK** to start the transfer.

Load Cloud Template

@deltavv.com

1 Logout

Please select a template to download

Template

Select	Template Name	Model	Creation date	Modification date	Customer Name	Comment
2 <input type="checkbox"/>	Auto Test	DOP-3S07S3E2	2024-07-10 13:35:15	2024-07-10 13:35:19	Delta	TEST1234567890
<input type="checkbox"/>	Test1	DOP-3S07S3E2	2024-07-10 13:34:13	2024-07-10 13:34:17	Delta	TEST
<input type="checkbox"/>	Test	DOP-3S07S3E2	2024-07-10 13:34:43	2024-07-10 13:34:47	Delta	TEST

3

Refresh

OK

Close

Address Conversion

After selecting an element on the screen, modify all the addresses of the selected element directly in the list through the address conversion function. You can also replace the address for a specific element.


How to open **Address Conversion**?

- On the menu bar, click **Tools > Address Conversion**.

Or

- Right-click the element and select **Address Conversion**.

The following table lists the settings in the **Address Conversion** dialog with their description.



Address Conversion

☒ Hide unaddressed items
☒ Hide constant items
☐ Hide unchanged items
☐ Automatically adjust all addresses

Display type: All addresses

Address Search and Replace




Find What:

Replace With:

Replace All

Select	Element Name	Address	The Converted Address	Address Name	Memory Types
<input checked="" type="checkbox"/>	Pie(1)_001 { }	{EtherLink1}1@RW-6	{EtherLink1}1@RW-6	Element read address	Word
<input checked="" type="checkbox"/>	Password Table Sett	{EtherLink1}1@RWB-0	{EtherLink1}1@RWB-0	Interlock Address	Bit
<input checked="" type="checkbox"/>	Password Table Sett	{EtherLink1}1@RWB-0	{EtherLink1}1@RWB-0	Visible Address	Bit
<input checked="" type="checkbox"/>	Numeric Display_006	{EtherLink1}1@RW-6	{EtherLink1}1@RW-6	Element read address	Word
<input checked="" type="checkbox"/>	Numeric Display_006	{EtherLink1}1@RWB-0	{EtherLink1}1@RWB-0	Visible Address	Bit
<input checked="" type="checkbox"/>	Numeric Entry_011 { }	{EtherLink1}1@RW-0	{EtherLink1}1@RW-0	Element read address	Word
<input checked="" type="checkbox"/>	Numeric Entry_011 { }	{EtherLink1}1@RWB-0	{EtherLink1}1@RWB-0	Interlock Address	Bit
<input checked="" type="checkbox"/>	Numeric Entry_011 { }	{EtherLink1}1@RWB-0	{EtherLink1}1@RWB-0	Visible Address	Bit
<input checked="" type="checkbox"/>	Numeric Entry_011 { }	{EtherLink1}1@RW-6	{EtherLink1}1@RW-6	Element write address	Word
<input checked="" type="checkbox"/>	Numeric Entry_011 { }	{EtherLink1}1@RWB-0	{EtherLink1}1@RWB-0	Element write address	Bit
<input checked="" type="checkbox"/>	Pie chart_003 { }	\$0	\$0	Element read address	Word
<input checked="" type="checkbox"/>	GridBox_012 { }	{EtherLink1}1@RW-6	{EtherLink1}1@RW-6	Start Address	Word

OK Cancel

Legend	Function	Description
1		Select to hide items whose addresses are not set.
	Function	Illustration
	Unselected	Display addresses with None. 
	Selected	Hide addresses set to None. 
2		Select to hide addresses set to constant, such as element position and upper/lower limit value.
	Function	Illustration
	Unselected	Display constant addresses. 
	Selected	Hide constant addresses.

Legend	Function	Description																																																																																																												
		<div><div>Address Conversion</div><div><div><div><div><div><input checked="" type="checkbox"/> Hide unaddressed items</div><div><input checked="" type="checkbox"/> Hide constant items</div><div><input type="checkbox"/> Hide unchanged items</div><div><input type="checkbox"/> Automatically adjust all addresses</div></div><div>Display type</div><div>All addresses</div></div><div><div>Address Search and Replace</div><div><div>Find What:</div><div>Replace With:</div><div>Replace All</div></div></div></div><div><table><thead><tr><th>Select</th><th>Element Name</th><th>Address</th><th>The Converted Address</th><th>Address Name</th><th>Memory Types</th></tr></thead><tbody><tr><td><input checked="" type="checkbox"/></td><td>Pic1_001 {}</td><td>{EtherLink1}0RW-6</td><td>{EtherLink1}0RW-6</td><td>Element read address</td><td>Word</td></tr><tr><td><input checked="" type="checkbox"/></td><td>Range Indicator_003 {}</td><td>{EtherLink1}0RW-6</td><td>{EtherLink1}0RW-6</td><td>Element read address</td><td>Word</td></tr><tr><td><input checked="" type="checkbox"/></td><td>Range Indicator_003 {}</td><td>{EtherLink1}0RWB-0</td><td>{EtherLink1}0RWB-0</td><td>Visible Address</td><td>Bit</td></tr><tr><td><input checked="" type="checkbox"/></td><td>Numeric Entry_011 {}</td><td>{EtherLink1}0RW-0</td><td>{EtherLink1}0RW-0</td><td>Element read address</td><td>Word</td></tr><tr><td><input checked="" type="checkbox"/></td><td>Numeric Entry_011 {}</td><td>{EtherLink1}0RWB-0</td><td>{EtherLink1}0RWB-0</td><td>Interlock Address</td><td>Bit</td></tr><tr><td><input checked="" type="checkbox"/></td><td>Numeric Entry_011 {}</td><td>{EtherLink1}0RWB-0</td><td>{EtherLink1}0RWB-0</td><td>Visible Address</td><td>Bit</td></tr><tr><td><input checked="" type="checkbox"/></td><td>Numeric Entry_011 {}</td><td>{EtherLink1}0RW-6</td><td>{EtherLink1}0RW-6</td><td>Element write address</td><td>Word</td></tr><tr><td><input checked="" type="checkbox"/></td><td>Numeric Entry_011 {}</td><td>{EtherLink1}0RWB-0</td><td>{EtherLink1}0RWB-0</td><td>Element write address</td><td>Bit</td></tr><tr><td><input checked="" type="checkbox"/></td><td>Gridbox_012 {}</td><td>{EtherLink1}0RW-6</td><td>{EtherLink1}0RW-6</td><td>Start Address</td><td>Word</td></tr><tr><td><input checked="" type="checkbox"/></td><td>Gridbox_012 {}</td><td>{EtherLink1}0RWB-0</td><td>{EtherLink1}0RWB-0</td><td>Visible Address</td><td>Bit</td></tr><tr><td><input checked="" type="checkbox"/></td><td>Numeric Display_006 {}</td><td>{EtherLink1}0RW-6</td><td>{EtherLink1}0RW-6</td><td>Element read address</td><td>Word</td></tr><tr><td><input checked="" type="checkbox"/></td><td>Numeric Display_006 {}</td><td>{EtherLink1}0RWB-0</td><td>{EtherLink1}0RWB-0</td><td>Visible Address</td><td>Bit</td></tr></tbody></table></div><div>OKCancel</div></div></div>	Select	Element Name	Address	The Converted Address	Address Name	Memory Types	<input checked="" type="checkbox"/>	Pic1_001 {}	{EtherLink1}0RW-6	{EtherLink1}0RW-6	Element read address	Word	<input checked="" type="checkbox"/>	Range Indicator_003 {}	{EtherLink1}0RW-6	{EtherLink1}0RW-6	Element read address	Word	<input checked="" type="checkbox"/>	Range Indicator_003 {}	{EtherLink1}0RWB-0	{EtherLink1}0RWB-0	Visible Address	Bit	<input checked="" type="checkbox"/>	Numeric Entry_011 {}	{EtherLink1}0RW-0	{EtherLink1}0RW-0	Element read address	Word	<input checked="" type="checkbox"/>	Numeric Entry_011 {}	{EtherLink1}0RWB-0	{EtherLink1}0RWB-0	Interlock Address	Bit	<input checked="" type="checkbox"/>	Numeric Entry_011 {}	{EtherLink1}0RWB-0	{EtherLink1}0RWB-0	Visible Address	Bit	<input checked="" type="checkbox"/>	Numeric Entry_011 {}	{EtherLink1}0RW-6	{EtherLink1}0RW-6	Element write address	Word	<input checked="" type="checkbox"/>	Numeric Entry_011 {}	{EtherLink1}0RWB-0	{EtherLink1}0RWB-0	Element write address	Bit	<input checked="" type="checkbox"/>	Gridbox_012 {}	{EtherLink1}0RW-6	{EtherLink1}0RW-6	Start Address	Word	<input checked="" type="checkbox"/>	Gridbox_012 {}	{EtherLink1}0RWB-0	{EtherLink1}0RWB-0	Visible Address	Bit	<input checked="" type="checkbox"/>	Numeric Display_006 {}	{EtherLink1}0RW-6	{EtherLink1}0RW-6	Element read address	Word	<input checked="" type="checkbox"/>	Numeric Display_006 {}	{EtherLink1}0RWB-0	{EtherLink1}0RWB-0	Visible Address	Bit																														
Select	Element Name	Address	The Converted Address	Address Name	Memory Types																																																																																																									
<input checked="" type="checkbox"/>	Pic1_001 {}	{EtherLink1}0RW-6	{EtherLink1}0RW-6	Element read address	Word																																																																																																									
<input checked="" type="checkbox"/>	Range Indicator_003 {}	{EtherLink1}0RW-6	{EtherLink1}0RW-6	Element read address	Word																																																																																																									
<input checked="" type="checkbox"/>	Range Indicator_003 {}	{EtherLink1}0RWB-0	{EtherLink1}0RWB-0	Visible Address	Bit																																																																																																									
<input checked="" type="checkbox"/>	Numeric Entry_011 {}	{EtherLink1}0RW-0	{EtherLink1}0RW-0	Element read address	Word																																																																																																									
<input checked="" type="checkbox"/>	Numeric Entry_011 {}	{EtherLink1}0RWB-0	{EtherLink1}0RWB-0	Interlock Address	Bit																																																																																																									
<input checked="" type="checkbox"/>	Numeric Entry_011 {}	{EtherLink1}0RWB-0	{EtherLink1}0RWB-0	Visible Address	Bit																																																																																																									
<input checked="" type="checkbox"/>	Numeric Entry_011 {}	{EtherLink1}0RW-6	{EtherLink1}0RW-6	Element write address	Word																																																																																																									
<input checked="" type="checkbox"/>	Numeric Entry_011 {}	{EtherLink1}0RWB-0	{EtherLink1}0RWB-0	Element write address	Bit																																																																																																									
<input checked="" type="checkbox"/>	Gridbox_012 {}	{EtherLink1}0RW-6	{EtherLink1}0RW-6	Start Address	Word																																																																																																									
<input checked="" type="checkbox"/>	Gridbox_012 {}	{EtherLink1}0RWB-0	{EtherLink1}0RWB-0	Visible Address	Bit																																																																																																									
<input checked="" type="checkbox"/>	Numeric Display_006 {}	{EtherLink1}0RW-6	{EtherLink1}0RW-6	Element read address	Word																																																																																																									
<input checked="" type="checkbox"/>	Numeric Display_006 {}	{EtherLink1}0RWB-0	{EtherLink1}0RWB-0	Visible Address	Bit																																																																																																									
		<div><div>If selected, only items with changes to The Converted Address field will be displayed.</div><div><div>Function</div><div>Illustration</div></div><div><div>Unselected</div><div>Display all element addresses.</div><div><div>Address Conversion</div><div><div><div><div><div><input checked="" type="checkbox"/> Hide unaddressed items</div><div><input checked="" type="checkbox"/> Hide constant items</div><div><input type="checkbox"/> Hide unchanged items</div><div><input type="checkbox"/> Automatically adjust all addresses</div></div><div>Display type</div><div>All addresses</div></div><div><div>Address Search and Replace</div><div><div>Find What: S</div><div>Replace With: D</div><div>Replace All</div></div></div></div><div><table><thead><tr><th>Select</th><th>Element Name</th><th>Address</th><th>The Converted Address</th><th>Address Name</th><th>Memory Types</th></tr></thead><tbody><tr><td><input type="checkbox"/></td><td>Numeric Entry_001 {} \$1</td><td>D1</td><td>D1</td><td>Element write address</td><td>Word</td></tr><tr><td><input type="checkbox"/></td><td>Numeric Entry_002 {} \$2</td><td>D2</td><td>D2</td><td>Element write address</td><td>Word</td></tr><tr><td><input type="checkbox"/></td><td>Numeric Entry_003 {} \$3</td><td>D3</td><td>D3</td><td>Element write address</td><td>Word</td></tr><tr><td><input type="checkbox"/></td><td>Numeric Entry_004 {} \$4</td><td>D4</td><td>D4</td><td>Element write address</td><td>Word</td></tr><tr><td><input type="checkbox"/></td><td>Numeric Entry_005 {} \$5</td><td>D5</td><td>D5</td><td>Element write address</td><td>Word</td></tr><tr><td><input type="checkbox"/></td><td>Numeric Entry_006 {} \$6</td><td>\$6</td><td></td><td>Element write address</td><td>Word</td></tr><tr><td><input type="checkbox"/></td><td>Numeric Entry_007 {} \$7</td><td>\$7</td><td></td><td>Element write address</td><td>Word</td></tr><tr><td><input type="checkbox"/></td><td>Numeric Entry_008 {} \$8</td><td>\$8</td><td></td><td>Element write address</td><td>Word</td></tr><tr><td><input type="checkbox"/></td><td>Numeric Entry_009 {} \$9</td><td>\$9</td><td></td><td>Element write address</td><td>Word</td></tr><tr><td><input type="checkbox"/></td><td>Numeric Entry_010 {} \$10</td><td>\$10</td><td></td><td>Element write address</td><td>Word</td></tr><tr><td><input type="checkbox"/></td><td>Numeric Entry_011 {} \$11</td><td>\$11</td><td></td><td>Element write address</td><td>Word</td></tr><tr><td><input type="checkbox"/></td><td>Numeric Entry_012 {} \$12</td><td>\$12</td><td></td><td>Element write address</td><td>Word</td></tr><tr><td><input type="checkbox"/></td><td>Numeric Entry_013 {} \$13</td><td>\$13</td><td></td><td>Element write address</td><td>Word</td></tr><tr><td><input type="checkbox"/></td><td>Numeric Entry_014 {} \$14</td><td>\$14</td><td></td><td>Element write address</td><td>Word</td></tr><tr><td><input type="checkbox"/></td><td>Numeric Entry_015 {} \$15</td><td>\$15</td><td></td><td>Element write address</td><td>Word</td></tr><tr><td><input type="checkbox"/></td><td>Numeric Entry_016 {} \$16</td><td>\$16</td><td></td><td>Element write address</td><td>Word</td></tr><tr><td><input type="checkbox"/></td><td>Numeric Entry_017 {} \$17</td><td>\$17</td><td></td><td>Element write address</td><td>Word</td></tr></tbody></table></div><div>OKCancel</div></div></div></div></div>	Select	Element Name	Address	The Converted Address	Address Name	Memory Types	<input type="checkbox"/>	Numeric Entry_001 {} \$1	D1	D1	Element write address	Word	<input type="checkbox"/>	Numeric Entry_002 {} \$2	D2	D2	Element write address	Word	<input type="checkbox"/>	Numeric Entry_003 {} \$3	D3	D3	Element write address	Word	<input type="checkbox"/>	Numeric Entry_004 {} \$4	D4	D4	Element write address	Word	<input type="checkbox"/>	Numeric Entry_005 {} \$5	D5	D5	Element write address	Word	<input type="checkbox"/>	Numeric Entry_006 {} \$6	\$6		Element write address	Word	<input type="checkbox"/>	Numeric Entry_007 {} \$7	\$7		Element write address	Word	<input type="checkbox"/>	Numeric Entry_008 {} \$8	\$8		Element write address	Word	<input type="checkbox"/>	Numeric Entry_009 {} \$9	\$9		Element write address	Word	<input type="checkbox"/>	Numeric Entry_010 {} \$10	\$10		Element write address	Word	<input type="checkbox"/>	Numeric Entry_011 {} \$11	\$11		Element write address	Word	<input type="checkbox"/>	Numeric Entry_012 {} \$12	\$12		Element write address	Word	<input type="checkbox"/>	Numeric Entry_013 {} \$13	\$13		Element write address	Word	<input type="checkbox"/>	Numeric Entry_014 {} \$14	\$14		Element write address	Word	<input type="checkbox"/>	Numeric Entry_015 {} \$15	\$15		Element write address	Word	<input type="checkbox"/>	Numeric Entry_016 {} \$16	\$16		Element write address	Word	<input type="checkbox"/>	Numeric Entry_017 {} \$17	\$17		Element write address	Word
Select	Element Name	Address	The Converted Address	Address Name	Memory Types																																																																																																									
<input type="checkbox"/>	Numeric Entry_001 {} \$1	D1	D1	Element write address	Word																																																																																																									
<input type="checkbox"/>	Numeric Entry_002 {} \$2	D2	D2	Element write address	Word																																																																																																									
<input type="checkbox"/>	Numeric Entry_003 {} \$3	D3	D3	Element write address	Word																																																																																																									
<input type="checkbox"/>	Numeric Entry_004 {} \$4	D4	D4	Element write address	Word																																																																																																									
<input type="checkbox"/>	Numeric Entry_005 {} \$5	D5	D5	Element write address	Word																																																																																																									
<input type="checkbox"/>	Numeric Entry_006 {} \$6	\$6		Element write address	Word																																																																																																									
<input type="checkbox"/>	Numeric Entry_007 {} \$7	\$7		Element write address	Word																																																																																																									
<input type="checkbox"/>	Numeric Entry_008 {} \$8	\$8		Element write address	Word																																																																																																									
<input type="checkbox"/>	Numeric Entry_009 {} \$9	\$9		Element write address	Word																																																																																																									
<input type="checkbox"/>	Numeric Entry_010 {} \$10	\$10		Element write address	Word																																																																																																									
<input type="checkbox"/>	Numeric Entry_011 {} \$11	\$11		Element write address	Word																																																																																																									
<input type="checkbox"/>	Numeric Entry_012 {} \$12	\$12		Element write address	Word																																																																																																									
<input type="checkbox"/>	Numeric Entry_013 {} \$13	\$13		Element write address	Word																																																																																																									
<input type="checkbox"/>	Numeric Entry_014 {} \$14	\$14		Element write address	Word																																																																																																									
<input type="checkbox"/>	Numeric Entry_015 {} \$15	\$15		Element write address	Word																																																																																																									
<input type="checkbox"/>	Numeric Entry_016 {} \$16	\$16		Element write address	Word																																																																																																									
<input type="checkbox"/>	Numeric Entry_017 {} \$17	\$17		Element write address	Word																																																																																																									
		<div><div>Hide unchanged items.</div><div><div>Address Conversion</div><div><div><div><div><div><input checked="" type="checkbox"/> Hide unaddressed items</div><div><input checked="" type="checkbox"/> Hide constant items</div><div><input checked="" type="checkbox"/> Hide unchanged items</div><div><input type="checkbox"/> Automatically adjust all addresses</div></div><div>Display type</div><div>All addresses</div></div><div><div>Address Search and Replace</div><div><div>Find What: S</div><div>Replace With: D</div><div>Replace All</div></div></div></div><div><table><thead><tr><th>Select</th><th>Element Name</th><th>Address</th><th>The Converted Address</th><th>Address Name</th><th>Memory Types</th></tr></thead><tbody><tr><td><input type="checkbox"/></td><td>Numeric Entry_001 {} \$1</td><td>D1</td><td></td><td>Element write address</td><td>Word</td></tr><tr><td><input type="checkbox"/></td><td>Numeric Entry_002 {} \$2</td><td>D2</td><td></td><td>Element write address</td><td>Word</td></tr><tr><td><input type="checkbox"/></td><td>Numeric Entry_003 {} \$3</td><td>D3</td><td></td><td>Element write address</td><td>Word</td></tr><tr><td><input type="checkbox"/></td><td>Numeric Entry_004 {} \$4</td><td>D4</td><td></td><td>Element write address</td><td>Word</td></tr><tr><td><input checked="" type="checkbox"/></td><td>Numeric Entry_005 {} \$5</td><td>D5</td><td>D5</td><td>Element write address</td><td>Word</td></tr></tbody></table></div><div>OKCancel</div></div></div></div>	Select	Element Name	Address	The Converted Address	Address Name	Memory Types	<input type="checkbox"/>	Numeric Entry_001 {} \$1	D1		Element write address	Word	<input type="checkbox"/>	Numeric Entry_002 {} \$2	D2		Element write address	Word	<input type="checkbox"/>	Numeric Entry_003 {} \$3	D3		Element write address	Word	<input type="checkbox"/>	Numeric Entry_004 {} \$4	D4		Element write address	Word	<input checked="" type="checkbox"/>	Numeric Entry_005 {} \$5	D5	D5	Element write address	Word																																																																								
Select	Element Name	Address	The Converted Address	Address Name	Memory Types																																																																																																									
<input type="checkbox"/>	Numeric Entry_001 {} \$1	D1		Element write address	Word																																																																																																									
<input type="checkbox"/>	Numeric Entry_002 {} \$2	D2		Element write address	Word																																																																																																									
<input type="checkbox"/>	Numeric Entry_003 {} \$3	D3		Element write address	Word																																																																																																									
<input type="checkbox"/>	Numeric Entry_004 {} \$4	D4		Element write address	Word																																																																																																									
<input checked="" type="checkbox"/>	Numeric Entry_005 {} \$5	D5	D5	Element write address	Word																																																																																																									
		<div><div>Select to adjust all addresses automatically. Changing the address of the first item in The Converted Address column and then selecting the item will automatically offset The converted address according to the original address offset.</div></div>																																																																																																												

Legend	Function	Description																																				
		<div><div>Address Conversion</div><div><div><div><div><div><input checked="" type="checkbox"/> Hide unaddressed items</div><div><input checked="" type="checkbox"/> Hide constant items</div><div><input checked="" type="checkbox"/> Hide unchanged items</div><div><input checked="" type="checkbox"/> Automatically adjust all addresses</div></div></div><div><div>Display type</div><div>All addresses</div></div></div><div><div>Address Search and Replace</div><div><div>Find What:</div><div>Replace With:</div></div><div>Replace All</div></div><table><thead><tr><th><input checked="" type="checkbox"/> Select</th><th>Element Name</th><th>Address</th><th>The Converted Address</th><th>Address Name</th><th>Memory Types</th></tr></thead><tbody><tr><td><input checked="" type="checkbox"/></td><td>Numeric Entry_001 { \$1</td><td></td><td>\$100</td><td>Element write address</td><td>Word</td></tr><tr><td><input checked="" type="checkbox"/></td><td>Numeric Entry_002 { \$2</td><td></td><td>\$101</td><td>Element write address</td><td>Word</td></tr><tr><td><input checked="" type="checkbox"/></td><td>Numeric Entry_003 { \$3</td><td></td><td>\$102</td><td>Element write address</td><td>Word</td></tr><tr><td><input checked="" type="checkbox"/></td><td>Numeric Entry_004 { \$4</td><td></td><td>\$103</td><td>Element write address</td><td>Word</td></tr><tr><td><input checked="" type="checkbox"/></td><td>Numeric Entry_005 { \$5</td><td></td><td>\$104</td><td>Element write address</td><td>Word</td></tr></tbody></table><div><div>OK</div><div>Cancel</div></div></div></div>	<input checked="" type="checkbox"/> Select	Element Name	Address	The Converted Address	Address Name	Memory Types	<input checked="" type="checkbox"/>	Numeric Entry_001 { \$1		\$100	Element write address	Word	<input checked="" type="checkbox"/>	Numeric Entry_002 { \$2		\$101	Element write address	Word	<input checked="" type="checkbox"/>	Numeric Entry_003 { \$3		\$102	Element write address	Word	<input checked="" type="checkbox"/>	Numeric Entry_004 { \$4		\$103	Element write address	Word	<input checked="" type="checkbox"/>	Numeric Entry_005 { \$5		\$104	Element write address	Word
<input checked="" type="checkbox"/> Select	Element Name	Address	The Converted Address	Address Name	Memory Types																																	
<input checked="" type="checkbox"/>	Numeric Entry_001 { \$1		\$100	Element write address	Word																																	
<input checked="" type="checkbox"/>	Numeric Entry_002 { \$2		\$101	Element write address	Word																																	
<input checked="" type="checkbox"/>	Numeric Entry_003 { \$3		\$102	Element write address	Word																																	
<input checked="" type="checkbox"/>	Numeric Entry_004 { \$4		\$103	Element write address	Word																																	
<input checked="" type="checkbox"/>	Numeric Entry_005 { \$5		\$104	Element write address	Word																																	
5	Display type	Select the type of address to display in the address list. The default is All addresses .																																				
6	Address Search and Replace	Enter Find What and Replace With to find and replace the string with a new string. <div><div>Address Conversion</div><div><div><div><div><div><input checked="" type="checkbox"/> Hide unaddressed items</div><div><input checked="" type="checkbox"/> Hide constant items</div><div><input checked="" type="checkbox"/> Hide unchanged items</div><div><input type="checkbox"/> Automatically adjust all addresses</div></div></div><div><div>Display type</div><div>All addresses</div></div></div><div><div>Address Search and Replace</div><div><div>Find What: \$</div><div>Replace With: D</div></div><div>Replace All</div></div><table><thead><tr><th><input checked="" type="checkbox"/> Select</th><th>Element Name</th><th>Address</th><th>The Converted Address</th><th>Address Name</th><th>Memory Types</th></tr></thead><tbody><tr><td><input checked="" type="checkbox"/></td><td>Numeric Entry_001 { \$1</td><td></td><td>01</td><td>Element write address</td><td>Word</td></tr><tr><td><input checked="" type="checkbox"/></td><td>Numeric Entry_002 { \$2</td><td></td><td>02</td><td>Element write address</td><td>Word</td></tr><tr><td><input checked="" type="checkbox"/></td><td>Numeric Entry_003 { \$3</td><td></td><td>03</td><td>Element write address</td><td>Word</td></tr><tr><td><input checked="" type="checkbox"/></td><td>Numeric Entry_004 { \$4</td><td></td><td>04</td><td>Element write address</td><td>Word</td></tr><tr><td><input checked="" type="checkbox"/></td><td>Numeric Entry_005 { \$5</td><td></td><td>05</td><td>Element write address</td><td>Word</td></tr></tbody></table><div><div>OK</div><div>Cancel</div></div></div></div>	<input checked="" type="checkbox"/> Select	Element Name	Address	The Converted Address	Address Name	Memory Types	<input checked="" type="checkbox"/>	Numeric Entry_001 { \$1		01	Element write address	Word	<input checked="" type="checkbox"/>	Numeric Entry_002 { \$2		02	Element write address	Word	<input checked="" type="checkbox"/>	Numeric Entry_003 { \$3		03	Element write address	Word	<input checked="" type="checkbox"/>	Numeric Entry_004 { \$4		04	Element write address	Word	<input checked="" type="checkbox"/>	Numeric Entry_005 { \$5		05	Element write address	Word
<input checked="" type="checkbox"/> Select	Element Name	Address	The Converted Address	Address Name	Memory Types																																	
<input checked="" type="checkbox"/>	Numeric Entry_001 { \$1		01	Element write address	Word																																	
<input checked="" type="checkbox"/>	Numeric Entry_002 { \$2		02	Element write address	Word																																	
<input checked="" type="checkbox"/>	Numeric Entry_003 { \$3		03	Element write address	Word																																	
<input checked="" type="checkbox"/>	Numeric Entry_004 { \$4		04	Element write address	Word																																	
<input checked="" type="checkbox"/>	Numeric Entry_005 { \$5		05	Element write address	Word																																	

All Tags

You can convert a memory address to tag through the DIAScreen Tag configuring function for use as well as use the import function of different files to import the variables declared in the programming software to DIAScreen.

DIA Tag

Synchronize the global variables declared in DIADesigner through DIA Tag function to DIAScreen and use. The following describes the setting method of DIA Tag.

DIADesigner operation

1. Create a project.
2. In **Project Explorer**, add a controller device.
3. Double-click **Programming**, right-click **Global Variable**, and then select **Add Global Variable Table**.
4. In the **Add Global Variable Table** dialog, enter the **Name** and **Comment**, and then click **OK**.
5. In the Global Variable table, add variables.

Note: The variable address must be configured. If not configured, DIAScreen will not be able to use the Tag.


6. Click **Compile** on the toolbar.

DIAScreen operation

1. Create a project.
2. In the **Device Communication** dialog, select Delta controller.

Note: The controller type must be the same as the controller type created in DIADesigner.


3. In the **Project** pane, double-click **DIA Tag**.

4. In the **DIA Tag** settings page, click .
5. In the **DIA Tag Import Settings** dialog, select a DIADesigner project file (.diade).
6. Select a **Link Name**. The communication parameters of the connection are listed in the dialog.
7. Set the **Station No.**

Note:

- The **Don't specify station number** checkbox is selected by default. The **Station No.** field is available only when the DIA Tag is used on the element.
- If unselect the **Don't specify station number** checkbox, the specified station number can be entered in the **Station No.** field.

8. Click **OK**.


9. In the **DIA Tag** setting page, click  to enable DIA Tag automatic synchronization.
10. In the **DIA Tag Synchronization Settings** dialog, select **Enable automatic sync** checkbox and set **Automatic check cycle**.
11. Create an element on the screen, and then double-click it.
12. In the address **Input** dialog of the element, select **DIA Tag** for **Link**. The variables are listed in the dialog.

Note: You can also export .diatag files from ISPSOft or DIADesigner software, and select DIATag File (.diatag) in the **DIA Tag Import Settings** dialog to import the files, but tags of this file type do not support **Synchronization** function.

Tag

You can add tags of different types in the tag page or declare structures and arrays of user-defined data types as tags.

The following table lists the functions of **Tag Property Setup** dialog with their description.



The image shows a 'Tag Property Setup' dialog box. It contains fields for Name, Address, Description, and Length. The Length field is set to 1 and has a unit of '(bytes)'. Below these fields are two radio buttons: 'Basic Type' (selected) and 'User-defined Data Type'. A list of data types is shown below the radio buttons, with 'WORD' selected. The list includes: BOOL, DINT, DWORD, INT, LINT, LREAL, LWORD, REAL, STRING, UDINT, UINT, ULINT, WORD, and WSTRING. At the bottom are 'OK' and 'Cancel' buttons.

Function	Description
Name	<p>Enter a tag name. The naming convention is as follows:</p> <ul style="list-style-type: none"> The name cannot exceed 220 bytes, and one Chinese character occupies 2 bytes. The name cannot start with a number. System reserved keywords, such as recipe register address RCP, cannot be used. Decimal points, square brackets, and @ symbol are not allowed in names. The name should be in the same language as the operating system (except English and number). Using a language different from the system language will result in garbled characters.
Address	<p>Set the address corresponding to the tag.</p> <p>Note: Configure an address of sufficient length according to the selected Type.</p>
Description	Enter a description for the tag.
Length	<p>Select or enter a length.</p> <p>Note: This function is only available when Basic Type is STRING or WSTRING.</p>
Type	<ul style="list-style-type: none"> Basic Type The following table lists the format and description of each Basic Type.

Type	Description
BOOL	1-Bit value format, which can only be used for bit control addresses, such as bit-type button elements.
INT	Word unit and signed integer format
DINT	Double Word unit and signed integer format
LINT	Quad Word unit and signed integer format
WORD	Word unit value format
DWORD	Double Word unit value format
LWORD	Quad Word unit numerical format
REAL	Floating point value format of Double Word unit
LREAL	Floating point value format of Quad Word unit
UINT	Word unit and unsigned integer format
UDINT	Double Word unit and unsigned integer format
ULINT	Quad Word unit and unsigned integer format
STRING	String format, 1 ASCII character is 1 byte, up to 128 bytes.
WSTRING	String format, 1 ASCII character is 1 byte, up to 256 bytes.

- User-defined Data Type**
Create a user-defined type on the **structure** or **array** page. You can create a tag for the user-defined type in the tab page.

Tag Import

The set tags can be exported as XLSX files and imported into Excel after editing. CSV files of variable tables edited by external software can also be imported into DIAScreen for programming.

Note: You need to clear the current tag content before importing the tag.

Tags usage

In the element address **Input** dialog, select **Tag** for **Link** name, and then select the tag. The element address will be presented as a tag name.

Input

Link: Tag

Find Aa

Name	Type	Address	Descri
Variable			
Internal Memory			
{Link2}			

User-defined Data Type

A user-defined data type (also called DUT (Data Type Unit) or UDT (User-defined Data Type)) is a data type that is combined by users using existing basic data types.


Structure

A structure consists of a fixed number of elements of various data types, and a structure or array element can also serve as an element of another structure. Structures can be used to define grouped data and to transmit parameters as a data unit.

Follow these steps to build a structure.

To build a structure

1. In **User-defined Data Type** page, click **+Structure** to add a structure. You can edit the structure name in the **Name** field.
2. Select the data type.



3. Select **Structure** and click **+WORD**. A new element will be added under the structure, and the element name can be edited in the **Name** field.

The naming rules for structure names and element names are as follows:

- Structure names must not be repeated.
- It is not allowed to add new elements with duplicate names in the same structure.
- The maximum length of the structure name and element name is 32 characters.
- Structure names and element names cannot have spaces, and cannot use special characters such as * # ? \ % @ [] () . , etc.
- Structure names should be in the same language as the operating system (except English and number). Using a language different from the system will result in garbled characters.


Array

An array consists of fixed length and the same data type.

Follow these steps to create an array.

To create an Array

1. In **User-defined Data Type** page, select a data type.



2. Click **+WORD** to add a new array. In the **Name** field, edit the array name.

The naming rules of array names are as follows:

- Array names must not be repeated.
- The maximum length of the array names is 32 characters.
- Array names cannot have spaces, and cannot use special characters such as * # ? \ % @ [] () . , etc.
- Array names should be in the same language as the operating system (except English and number). Using a language different from the system will result in garbled characters.

Address Settings

Each HMI function needs to be executed through address concatenation, you can set the address in the element property dialog. The address settings include Internal Memory Address and External Controller Address. This section describes various address definitions and their setting methods.

Internal Memory

Delta HMI has a total of 13 types of registers with different functions.

1. Internal register \$
2. Non-volatile internal register \$M
3. Indirect address register *\$
4. Extended memory EM0~15
5. Recipe register RCP
6. Recipe number register RCPNO
7. Recipe group register RCPG
8. Recipe indirect addressing register *RCP
9. Enhanced recipe register ENRCP
10. Enhanced recipe number register ENRCPNO
11. Enhanced recipe group register ENRCPG
12. Enhanced recipe group name register ENRCPGNAME
13. Enhanced recipe indirect addressing register *ENRCP

Types 5~13 belong to recipe addresses. For detailed description, see the manual of the recipe.

Link:

Internal Memory

Type

☐ Device (Word)
☐ Device (Bit)
☒ Internal Memory (Word)
☐ Internal Memory (Bit)
☐ Constant

Constant Types

☐ Signed Decimal
☐ Unsigned Decimal
☐ Hexadecimal

Station No.

1

☒ Default

Content

Device Type

\$

Address/Value

\$M

Tag

B

C

6

7

1

2

0

:

.

EM0

EM1

EM2

EM3

EM4

EM5

EM6

EM7

EM8

EM9

EM10

EM11

EM12

EM13

EM14

EM15

RCP

RCPNO

RCPG

*RCP

ENRCP

ENRCPNO

ENRCPNONAME

ENRCPG

ENRCPGNAME

*ENRCP

Internal Register (\$)

The Internal Register is the HMI internal memory that freely reads data and supports all kinds of configurations, such as the communication address of the element.

The HMI can access 200,000 sets of 16-bit internal registers.

Note: The internal register does not have a power-off retention function, so the data in the register is not retained when the power is off.

Access Type	Element Type	Access Range
Word	\$n	\$0~\$199999
Bit	\$n.b	\$0.0~\$199999.15

Note: n is Word (0~199999); b is Bit (0~15).

Non-volatile Internal Register (\$M)

The Non-volatile Internal Register provides a power-off retention function. The data in the register is retained when the power is off so that you can record important data in this register. The HMI can access 5000 sets of 16-bit non-volatile internal registers (\$M0.0~\$M4999.15).

Access Type	Element Type	Access Range
Word	\$Mn	\$0~\$4999
Bit	\$Mn.b	\$0.0~\$4999.15


Note: n is Word (0~4999); b is Bit (0~15).

Indirect Address Register (*\$ / *D\$)

The Indirect Address Register uses the value of the internal memory as the address, and assigns the address value to the corresponding **Indirect Address Register** of the internal memory.

Access Type	Element Type	Access Range
Word	*\$0~*\$199999	\$0~\$199999
Double Word	*D\$0~*D\$199998	\$0~\$199998

Indirect address register *\$n or *D\$n, obtains the value from the internal memory \$n, sets the value as a new address, and then accesses the value from the new address. For example, \$10 = 101, \$101 = 55, then *\$10 = 55.



If the address assigned by the internal memory exceeds the value of one Word (65535), the indirect address register must use ***D\$** and obtain the value in Double Word format.

Note: The indirect address register does not have a power-off retention function, so the data in the register is not retained when the power is off.

Extended Memory


The Extended Memory (EM) can store data on an external storage device so that the data can be retained even after the HMI is powered off. The elements on the HMI screen are also read and written through the extended memory.

- The extended memory has 16 groups (EM0~EM15).
- Supports file storage in external storage devices (USB, USB 2 disk and SD card).
- Each EM is a file, supporting a maximum of 512MB.
- Values can be read and written into the file.
- The maximum Word address is 268435455, and the last Word of the 512MB file can be read.
- The address of the last Bit is EM0_268435455.15.
- EM addresses can be used in elements and macro functions, and can also be used to create data codes.

Follow the steps to set the extended memory.

1. On the toolbar, click **Project > Other Settings > Extended Memory Settings**.
2. In the **Extended memory settings** dialog, set the file name corresponding to each EM area.


The file name supports multiple languages, and the maximum file name length is (32*4) bytes. The file extension stored on the external storage device is .emi.



ID	File name (.emi)	File is stored in
EM0	em0	USB
EM1	em1	USB
EM2	em2	USB
EM3	em3	USB
EM4	em4	USB
EM5	em5	USB
EM6	em6	USB
EM7	em7	USB
EM8	em8	USB
EM9	em9	USB

OK Cancel

- In the address **Input** dialog of the element, select **Internal Memory** for **Link**, select **EM0~EM15** for **Device Type**, and then enter the read and write address.



Link: Internal Memory

Type

☐ Device (Word)
☐ Device (Bit)
☒ Internal Memory (Word)
☐ Internal Memory (Bit)
☐ Constant

Constant Types

☐ Signed Decimal
☐ Unsigned Decimal
☐ Hexadecimal

Station No.

1 ☒ Default

Content

Device Type: EM0

Address/Value: \$, \$M, *\$, *D\$, EM0, EM1, EM2, EM3, EM4, EM5, EM6, EM7, EM8, EM9, EM10, EM11, EM12, EM13, EM14, EM15

Tag: B, C, 6, 7, 1, 2, 0, :

None

The following table lists the API for LUA applications to read and write extended memory.

Command	Description
mem.em.Read (EMID, addr, [FORMAT])	Read 1 WORD from the addr address of EMID
mem.em.Write (EMID, addr, value)	Write 1 WORD from the addr address of EMID
mem.em.ReadDW (EMID, addr, [FORMAT])	Read 1 DWORD from the addr address of EMID
mem.em.WriteDW (EMID, addr, value)	Write 1 DWORD from the addr address of EMID
mem.em.ReadQW (EMID, addr, [FORMAT])	Read 1 QWORD from the addr address of EMID
mem.em.WriteQW (EMID, addr, value)	Write 1 QWORD from the addr address of EMID
mem.em.ReadBit (EMID, addr, bit_index)	Read the bit_index value from the addr address of EMID
mem.em.WriteBit (EMID, addr, bit_index, value)	Write the value from the addr address bit_index of EMID
mem.em.ReadFloat (EMID, addr)	Read 1 Float from the addr address of EMID
mem.em.WriteFloat (EMID, addr, value)	Write 1 Float from the addr address of EMID
mem.em.ReadDouble (EMID, addr)	Read 1 Double from the addr address of EMID
mem.em.WriteDouble (EMID, addr, value)	Write 1 Double from the addr address of EMID
mem.em.ReadASCII (EMID, addr, length)	Read length characters from the addr address of EMID
mem.em.WriteASCII (EMID, addr, string, length)	Write length characters from the addr address of EMID

DXMC Series Internal Memory Address

The following table lists the internal memory address range of Word elements.


Register Type	Symbol Format	Read and Write Address Range	Data Length	Remark
	Word No.(n)			
X_Register	X_n	X0~X1FFFFFF	Word	Hexadecimal
Y_Register	Y_n	Y0~Y1FFFFFF	Word	Hexadecimal
DV_Register	DV_n	DV0~DV262143	Word	Even addressing
DH_Register	DH_n	<ul style="list-style-type: none"> DXMC-1H08AD-70, DXMC-1H08CD-7S, DXMC-1H08ED-7S: DH1000000~DH1061439 DXMC-1P08NE-4S/70/7S, DXMC-1P04NE-7S, DXMC-1FA1RN-70F: DH1000000~DH1024575 DXMC-1FA2RN-70F: DH1000000~DH1049151 	Word	Even addressing
SDV_Register	SDV_n	SDV3000000~SDV3065535	Word	Even addressing
SDH_Register	SDH_n	<ul style="list-style-type: none"> DXMC-1H08AD-70, DXMC-1H08CD-7S, DXMC-1H08ED-7S: SDH6000000~SDH6065535 DXMC-1P08NE-4S/70/7S, DXMC-1P04NE-7S, DXMC-1FA1RN-70F: SDH6000000~SDH6004095 DXMC-1FA2RN-70F: SDH6000000~SDH6008191 	Word	Even addressing
RP_Register	RP_n	RP0~RP7FFFFFF	Word	Hexadecimal
Controller	CR_n	CR0~CR14FFFFFF	Word	Hexadecimal
MW_Register	MW_n	MW0~MW67108863	Word	Even addressing
MD_Register	MD_n	MD0~MD67108863	Word	Even addressing
ML_Register	ML_n	ML0~ML67108863	Word	Even addressing

The following table lists the internal memory address range of Bit elements.

Contact Type	Symbol Format	Read and Write Address Range	Remark
	Byte No.(n); Bit No.(b)		
X_Coil	X n.b	X0.0~X1FFFFFF.15	Hexadecimal
Y_Coil	Y n.b	Y0.0~Y1FFFFFF.15	Hexadecimal
DV_Coil	DV n.b	DV0.0~DV262143.7	-
DH_Coil	DH n.b	<ul style="list-style-type: none"> DXMC-1H08AD-70, DXMC-1H08CD-7S, DXMC-1H08ED-7S: DH1000000.0~DH1061439.7 DXMC-1P08NE-4S/70/7S, DXMC-1P04NE-7S, DXMC-1FA1RN-70F: DH1000000.0~DH1024575.7 DXMC-1FA2RN-70F: DH1000000.0~DH1049151.7 	-
SDV_Coil	SDV n.b	SDV3000000.0~SDV3065535.7	-
SDH_Coil	SDH n.b	<ul style="list-style-type: none"> DXMC-1H08AD-70, DXMC-1H08CD-7S, DXMC-1H08ED-7S: SDH6000000.0~SDH6065535.7 DXMC-1P08NE-4S/70/7S, DXMC-1P04NE-7S, DXMC-1FA1RN-70F: SDH6000000.0~SDH6004095.7 DXMC-1FA2RN-70F: SDH6000000.0~SDH6008191.7 	-
SM_Coil	SM n.b	SM0.0~SM8191.15	-
MX_Coil	MX n.b	MX0.0~MX67108863.7	-
MW_Coil	MW n.b	MW0.0~MW67108863.7	-

Internal Parameter

The **Internal Parameter** can access the HMI internal state values, including system time value, external storage device status, X / Y coordinates when touching, touch status, remaining battery voltage in percentage, network parameters, firmware version, extended memory status, and so on.








Note: Internal Parameter is available only for Word elements. You are unable to use this function if you create Bit elements.

The following table lists each internal parameter with their descriptions.

System Setting

Parameter	Definition	Description
BATTER_VOLTAGE	Remaining HMI battery	The display unit is percentage.

Parameter	Definition	Description	
LANG_OF_SYMSG	Display language of the HMI directory	State Value	Language
		0	English
		1	Tradition Chinese
		2	Simple Chinese
		3	Spanish
		4	French
		5	Russian
		6	Turkish
		<p>Follow these steps to set the system menu language.</p> <ol style="list-style-type: none"> 1. Create an element such as Numeric Entry element. 2. In the address input dialog of the element, select Link name as Internal Parameter, and the Device Type as LANG_OF_SYMSG. 	
			
		<ol style="list-style-type: none"> 3. Download the screen to the HMI and change the value of the element on the HMI. 4. Press and hold the screen for 2 seconds, and the system menu button appears on the top left of the screen. 	
			
		<p>After entering the system menu, you can see the display language changes.</p>	

Parameter	Definition	Description
		
SP_BRIGHT	Backlight brightness of HMI	The display unit is percentage.
SYS_BUZZER_VOLUME	Buzzer volume	The display unit is percentage. The value range is 0–100.
BTN_BUZZER_VOLUME	Touch-tone	The display unit is percentage. The value range is 0–100.
FW_VERSION1	Major version number of HMI firmware version	 <ul style="list-style-type: none"> When setting this parameter, set the Data Format to Hexadecimal. 
FW_VERSION2	Minor version number of HMI firmware version	
Loaded CODESYS Tags	Total number of loaded CODESYS Tag	Display the number of current loaded tags. HMI displays the progress bar when preloading the tags. After all tags are loaded, the total number of preloaded CODESYS tags can be known.

Parameter	Definition	Description
BOOT_BUZZER_VOLUME	Boot buzzer volume of HMI	The display unit is percentage. The value range is 0–100.
HardwareID	HMI hardware code	Read the HMI hardware code. This parameter is set using the Character Display element, and the string length is 32 to ensure that the complete hardware code is read.

Account

Note: This parameter only applies if the account is set to a **non-simple password**.




Parameter	Definition	Description						
ACCOUNT	Currently logged-in account	<ul style="list-style-type: none">Account contains English letters and numbers, use the Character Display element.Account contains non-ASCII characters, use the Multi-language Input element.						
SetUserAccount	User account	<ul style="list-style-type: none">It is used for user login / logout, adding / deleting an account, and changing a password.Use the Character Entry element to set this parameter.						
AdminLogin	Highest authority account number	<table><tr><th>State Value</th><th>Result</th></tr><tr><td>0</td><td>Log in using a non-highest authority account.</td></tr><tr><td>1</td><td>Log in with the highest authority account.</td></tr></table>	State Value	Result	0	Log in using a non-highest authority account.	1	Log in with the highest authority account.
State Value	Result							
0	Log in using a non-highest authority account.							
1	Log in with the highest authority account.							
SetUser Password	User password	<ul style="list-style-type: none">The password is displayed in ***.It is used for user login / logout, adding / deleting an account, and changing a password.Use the Character Entry element to set this parameter.						
SetUserLevel	User level	<ul style="list-style-type: none">It is used for user login / logout, adding / deleting an account, and changing a password.The level range is 0–10.						

Parameter	Definition	Description	
AccountStatus	Account status	Read the login status of the current account. The status includes the following: <ul style="list-style-type: none">UnexpiredUnlockedExpiredLocked Use the Character Entry element to set this parameter.	
CurrentUser Level	Currently logged in level	Read the level (0~10) of the current login account.	
LoginResult	Login status	Read whether the last login / logout of the current account was successful. The status includes the following: <ul style="list-style-type: none">SuccessFail Use the Character Entry element to set this parameter.	
LogoutResult	Logout status		
Login	Login settings	State Value	Result
Logout	Logout settings	0	The action is completed.
		1	Trigger login / logout
DeleteUser Account	Delete account	State Value	Result
		0	The action of deleting an account is completed.
		1	Trigger account deletion
DeleteUser AccountResult	Delete account result	Read whether the deletion of the account is successful. The status includes the following: <ul style="list-style-type: none">SuccessFail Use the Character Entry element to set this parameter.	
AddUser Account	Add account	State Value	Result
		0	The action of adding an account is completed.
		1	Trigger account adding
AddUser AccountResult	Add account result	Read whether the adding of the account is successfully read. The status includes the following:	

Parameter	Definition	Description	
		<ul style="list-style-type: none">• Success• Fail. Use the Character Entry element to set this parameter.	
ChangeUser Password	Change password	State Value	Result
		0	The password change action is completed.
		1	Trigger password change
Change PasswordResult	Change password result	Read whether the change of the password is successful. The status includes the following: <ul style="list-style-type: none">• Success• Fail Use Character Entry element to read this parameter.	
UserDescription	Get a description of the user who is currently logged in to the account	The user description only supports English and numbers. Use the Character Display element to read this parameter.	
RFIDSerialNum ber	Get the RFID serial number of the current login account	The RFID serial number uses the Character Display element to read this parameter.	
SetRFIDSerialN umber	Set the RFID serial number	If is used for Add/Delete User Account Screen , only English and numbers are supported. Use the Character Entry element to set this parameter.	
SetUserDescript ion	Set a user description		

Alarm




Parameter	Definition	Description
ALARM_COUNT	Alarm triggered The total number of transactions	<ul style="list-style-type: none"> • Display the total number of alarms that are triggered and de-triggered. • The DOP-B, DOP-H, and HMC series models record the triggered and de-triggered alarms separately. As a result, Alarm_Count displays 20 when there are ten alarms.

Parameter	Definition	Description
		 <ul style="list-style-type: none"> The DOP-W and DOP-100 series models record the triggered and de-triggered alarms within one row of data. As a result, Alarm_Count displays 10 when there are ten alarms.  <ul style="list-style-type: none"> This function reminds you to export the alarm data in case the initial alarm data contents are removed when the data reach the set maximum. 

BACNETIP Server

Parameter	Definition	Description
DEVICEID	Device ID of BACnet	The device ID can be changed dynamically on the HMI.

Communication

Parameter	Definition	Description					
NET_STATUS1	Network connection status	<ul style="list-style-type: none">NET_STATUS1 represents the 16 connections of the first controller; NET_STATUS2 is the 16 connections of the second controller, and so forth for NET_STATUS2 and NET_STATUS4.Set the Data Format as Binary when setting these internal parameters. 					
NET_STATUS2		<ul style="list-style-type: none">Sort according to the EtherLink device number added by the software. 					
NET_STATUS3							
NET_STATUS4		 <table><thead><tr><th>State Value</th><th>Result</th></tr></thead><tbody><tr><td>0</td><td>Not connected</td></tr><tr><td>1</td><td>Connected</td></tr></tbody></table>	State Value	Result	0	Not connected	1
State Value	Result						
0	Not connected						
1	Connected						

Date&Time





Parameter	Definition	Description	
TIME_YEAR	HMI time value	Time Value	Result
TIME_MONTH		TIME_YEAR (yyyy)	<input type="text" value="2016"/>
TIME_DAY		TIME_MONTH (mm)	<input type="text" value="4"/>
TIME_HOUR		TIME_DAY (dd)	<input type="text" value="28"/>
TIME_MINUTE		TIME_HOUR (hr)	<input type="text" value="14"/>
TIME_SECOND		TIME_MINUTE (min)	<input type="text" value="53"/>
		TIME_SECOND (sec)	<input type="text" value="12"/>

Ethernet Setting

Some DOP-100 series HMI models have two Ethernet ports, so the network parameters are named as: NET1_IP1~NET1_IP4, SUBMASK1_IP1~SUBMASK1_IP4, GWAY1_IP1~GWAY1_IP4 and NET2_IP1~NET2_IP4, SUBMASK2_IP1~SUBMASK2_IP4, GWAY2_IP1~GWAY2_IP4.


For the DOP-100 models to be compatible with the DOP-B projects, the network parameters NET_IP1 to NET_IP4, SUBMASK_IP1 to SUBMASK_IP4, and GWAY_IP1 to GWAY_IP4 are added.

Parameter	Definition	Description
NET1_IP1 NET2_IP1	IP address of the HMI	Take 192.168.1.88 as an example.
NET1_IP2 NET2_IP2		<input type="text" value="R:NET1_IP1"/> <input type="text" value="192"/> <input type="text" value="R:NET1_IP2"/> <input type="text" value="168"/> <input type="text" value="R:NET1_IP3"/> <input type="text" value="1"/> <input type="text" value="R:NET1_IP4"/> <input type="text" value="88"/>
NET1_IP3 NET2_IP3		
NET1_IP4 NET2_IP4		

Parameter	Definition	Description
SUBMASK_IP1 SUBMASK1_IP1 SUBMASK_IP2 SUBMASK1_IP2 SUBMASK_IP3 SUBMASK1_IP3 SUBMASK_IP4 SUBMASK1_IP4	Submask IP address of the HMI	Take 255.255.255.0 as an example. 
GWAY1_IP1 GWAY2_IP1 GWAY1_IP2 GWAY2_IP2 GWAY1_IP3 GWAY2_IP3 GWAY1_IP4 GWAY2_IP4	Gateway IP address of the HMI	Take 192.168.1.254 as an example. 
DNS1_IP1 DNS2_IP1 DNS1_IP2 DNS2_IP2 DNS1_IP3 DNS2_IP3 DNS1_IP4 DNS2_IP4	IP address of the HMI DNS Server	Take 192.168.1.5 as an example. 
NET_MAC1 NET2_MAC1 NET_MAC2 NET2_MAC2 NET_MAC3 NET2_MAC3	MAC number of the HMI network port	<ul style="list-style-type: none"> When setting this parameter, set the Data Format to Hexadecimal.  <ul style="list-style-type: none"> The value is displayed with the high and low bits swapped. If the value is 1800, it is displayed as 00:18.


Ethernet Application

Parameter	Definition	Description		
SMTP_STATUS	SMTP connection status	State Value	State Description	Corresponding Message in SMTP_INFO
		0	Status unknown	Unknown
		1	Connection success	Message Sent
		-100	Connection failed	Unable to connect to Host
		-101	System disconnected	The displayed message changes according to the system.
SMTP_INFO	SMTP messages	-102	Authentication required	530 SMTP Authentication is required.
		-103	Authentication failed	Fail to send message due to Authentication Fail
		-999	SMTP error	Fail to send message
REMO_COUNT	Number of remote devices connected to the HMI	Remote devices include eServer, VNC, and LUA online debugging programs.		
VNC_ENABLE	VNC start	State Value	Result	
		0	Disable VNC	
		1	Enable VNC	

Parameter	Definition	Description	
VNC_STATUS_ENABLE	VNC status display	State Value	Result
		0	Turn off the VNC status display.
		1	Turn on the VNC status display. 
VNC_NOPASSWORD	VNC Password Setting	State Value	Result
		0	No password is required for VNC connection.
		1	Password is required for VNC connection.
VNC_VIEWONLY	VNC Read-only Setting	State Value	Result
		0	After connecting to HMI, you can only view the screen and cannot operate it.
		1	Operation is possible after connecting to HMI.
VNC_MULTI_CONNECT	VNC Multi-connection Mode	State Value	Result
		0	Multiple VNC connections are allowed by HMI.
		1	Only one VNC connection is allowed by HMI.
VNC_PASSWORD	VNC Password Setting	Set the VNC connection password (up to 8 characters) through the Character Input element.	
VNC_PORT	VNC Connection Port	Set the VNC connection port.	


Parameter	Definition	Description	
InternetConn Status	Internet Connection status	State Value	Result
		0	No Internet connection
		1	Internet connection exists
		2	Detecting

Extended Memory

Parameter	Definition	Description												
StatusEM0~15	Extended memory status	Displays the current processing status of each extended memory.												
														
		<table><thead><tr><th>State Value</th><th>Result</th></tr></thead><tbody><tr><td>0</td><td>Writing is complete</td></tr><tr><td>1</td><td>Writing</td></tr><tr><td>2</td><td>The corresponding disk does not exist</td></tr><tr><td>3</td><td>File write error</td></tr><tr><td>4</td><td>File read error</td></tr></tbody></table>	State Value	Result	0	Writing is complete	1	Writing	2	The corresponding disk does not exist	3	File write error	4	File read error
		State Value	Result											
		0	Writing is complete											
		1	Writing											
		2	The corresponding disk does not exist											
		3	File write error											
4	File read error													

Input Device

HMI supports reading data from external input devices. The following parameters control external input devices and read the data.

Parameter	Definition	Description												
InputDevID	The interface of input device	<table><tr><th>State Value</th><th>Result</th></tr><tr><td>1</td><td>COM1</td></tr><tr><td>2</td><td>COM2</td></tr><tr><td>3</td><td>COM3</td></tr><tr><td>4</td><td>COM4</td></tr><tr><td>10</td><td>USB (Default)</td></tr></table>	State Value	Result	1	COM1	2	COM2	3	COM3	4	COM4	10	USB (Default)
		State Value	Result											
		1	COM1											
		2	COM2											
		3	COM3											
		4	COM4											
10	USB (Default)													
InputDevConnStatus	The connection status of input device	<table><tr><th>State Value</th><th>Result</th></tr><tr><td>0</td><td>No keypad device detected</td></tr><tr><td>1</td><td>Keypad device detected</td></tr></table>	State Value	Result	0	No keypad device detected	1	Keypad device detected						
		State Value	Result											
		0	No keypad device detected											
1	Keypad device detected													
InputDevData	Read data content	<ul style="list-style-type: none">Displays the data in InputDevData and reads the data length in InputDevDataLen.The read data displays the character before the Terminator. If the Terminator is not received, the reading stops when the timeout period expires.												
		<div><p>Note: Set the Terminator and Timeout in the Device page on the Device Communication dialog.</p></div>												
InputDevDataLen	Read data length													

Parameter	Definition	Description	
InputDevClear	Clear data and data length	State Value	Result
		0	Idle
		1	Clear the data and data length. After clearing, the device status returns to 0.
InputDevInProgress	Progress of input device	State Value	Result
		0	Idle
		1	Receiving data
InputDevStatus	Status of input device	<ul style="list-style-type: none"> After clearing the read data, the device status returns to 0. 	
		State Value	Result
		0	Idle
		1	Reading successful
		2	Reading failed
		3	The read data size exceeds the specified size.
		4	Open the port failed

Installment

Parameter	Definition	Description	
NEXT_INST_REMAIN_TIME	Current installment time left	<ul style="list-style-type: none"> Displays the remaining time until the next installment. It is recommended to use Character Display elements. <p>Note: The String Length must be set to 23 to display the complete time.</p> <div>2 days 23 hours 40 min</div>	
INST_LOCK_STATUS	Installment locked status	State Value	Result
		0	Connection failed
		1	Connection successful

IoT

This parameter is only available for DOP-300 series HMI.

Note: Tunnel related parameters are read-only.

Parameter	Definition	Description	
IoTNotify	Cloud notification	State Value	Result
		0	Cloud has no new version.
		2	New firmware updates on the cloud.
		3	Cloud has new template updates, but the template ID remains unchanged and the data will not stop updating.
		5	Cloud has new template updates and the template ID changes, and the data will stop updating.
IoTDeviceStatus	Connection state of HMI and Cloud	State Value	Result
		0	The device is turning on.
		1	The device account is unbinding.
		2	The device account is binding.
		3	Device online
		4	Device offline
IoTEnable	Enable Cloud service	State Value	Result
		0	Not enabled
		1	Enabled
IoTPairingKey	Cloud template binding verification code	<ul style="list-style-type: none"> Verification code (6 digits) entered when the HMI is bound to the cloud template. Use the Numeric Input element to set this parameter. 	
IoTBindingQRCode	Bind HMI to DIACloud	Set to 1, bind the HMI and DIACloud.	
IoTUnBindingQRCode	Unbinding DIACloud	Set to 1, unbinding the HMI and DIACloud.	

Parameter	Definition	Description	
IoTShowQRCode	Cloud template QR code	Use the QR Code Display element to set this parameter.	
IoTTunnelStatus	State value and description of the HMI connected to FUDA Tunnel	State value	Description
IoTTunnelStatusDesc		0	Tunnel is not connected
		1	Tunnel is connected
		2	The tunnel data has reached the limit.
		4	Fail to load Tunnel configuration file
		9	Fail to open Tunnel interface
		-1	Connection timed out
99		Establish a connection	
IoTTunnelID	The ID of the HMI connected to FUDA Tunnel	<ul style="list-style-type: none">When not connected, display 0.When connected, display the allocated value (1~65535) by the server. The ID is still displayed after disconnection.	
IoTTunnelIP	The Tunnel IP set in the virtual network adapter of HMI	<ul style="list-style-type: none">IP format is 0.0.0.0~255.255.255.255.Use the Character Read element to set this parameter.	
IoTTunnelServer	Tunnel server address	Displays the server name when connected. The server name is still displayed after disconnection.	
IoTTunnelLatency	Tunnel connection delay time	<ul style="list-style-type: none">When not connected, display -1.When connected, display the delay time.	
IOTDataSyncStatus	Cloud Template Sync status	Displays whether the current template is downloaded from DIACloud. The status includes the following: <ul style="list-style-type: none">Sync.Not sync. Use the Character Entry element to set this parameter.	


Keypad

Parameter	Definition	Description
KEY_CHAR	Show keyboard text	<ul style="list-style-type: none"> When the HMI is connected to an external keypad, the characters can be directly input through the keypad and displayed through this parameter. It is recommended to use Character Entry or Character Display elements.

Lua Program

Parameter	Definition	Description	
PROGRAM_STATUS	Current LUA running status	State Value	Description
		0	Stop
		1	Run
		2	Breakpoint
		3	Pause
PROGRAM_INFO	LUA execution information	If an error occurs during LUA operation, the current error message can be displayed through this parameter.	

MQTT

Parameter	Definition	Description
MQTTClientID	Read Broker ClientID	<p>Set the Broker ID to read the corresponding Client ID.</p> 
BrokerNumber	Assign Broker Number	<p>Note:</p> <ul style="list-style-type: none"> MQTTClientID is read-only, and this parameter is read by the Character Display element. BrokerNumber corresponds to the Broker List in MQTT Setting.

MQTT Broker




Parameter	Definition	Description
BrokerInfo	Read the execution status of Broker	<p>Displays the current execution status of MQTT Broker. The status includes the following:</p> <ul style="list-style-type: none"> • Executing • Memory is full and rejects all published messages. • Stopped <p>Use the Character Entry element to set this parameter.</p>

Storage

Parameter	Definition	Description	
SD_STATUS	State value of external storage device (SD card)	State Value	Result
		0	SD card is not inserted
		1	SD card is inserted
USB_STATUS	State value of external storage (USB disk)	State Value	Result
		0	USB disk is not inserted
		1	USB disk is inserted
USB2_STATUS	State value of external storage (USB disk)	State Value	Result
		0	USB disk is not inserted
		1	USB disk is inserted
		Note: This parameter is only available for DOP-300 series HMI.	

Touch

Parameter	Definition	Description	
TP_STATUS	State value of HMI panel	State Value	Result
		0	Panel is not touched
		1	Panel is touched

Parameter	Definition	Description					
TP_X	Touch the X coordinate of HMI panel	<table><tr><th>Coordinate</th><th>Result</th></tr><tr><td>X</td><td rowspan="2"></td></tr><tr><td>Y</td></tr></table>	Coordinate	Result	X		Y
Coordinate	Result						
X							
Y							
TP_Y	Touch the Y coordinate of HMI panel						
TP_FORCE	Pressing force applied to the HMI	The display unit is percentage.					
TP_DELAY	Delay time of pressing the HMI screen	The display unit is percentage.					

Handheld HMI

This parameter is only available for DOP-Handheld series HMI.

Parameter	Definition	Description	
EMS_STATUS	Current status of emergency stop switch	State Value	Result
		0	Emergency stop switch is not pressed
		1	Emergency stop switch is pressed
LSWITCH_STATUS	Current status of enabling switch	State Value	Result
		0	Enabling switch is not pressed
		1	Enabling switch is pressed
HANDWHEEL_COUNTER	Accumulated number of rotations of handwheel	Rotate to the right, the value increases by 1; rotate to the left, the value decreases by 1.	
AUXKEY_PRESSED1	Auxiliary key press status	<ul style="list-style-type: none">Displayed in power of 2, the leftmost button is the first row, and the value is displayed from top to bottom, with the value increasing by 1, 2, 4, and 8, as shown below.If there are more than 24 auxiliary keys, it will be displayed with parameter AUXKEY_PRESSED2.	
AUXKEY_PRESSED2			

Parameter	Definition	Description
		

WiFi

Parameter	Definition	Description										
WiFi.Country	Wi-Fi country codes	Use the Character Input element to set this parameter.										
WiFi.DongleStatus	Wi-Fi Dongle configuration status	<div>This parameter is read-only.</div> <table><tr><th>State Value</th><th>Result</th></tr><tr><td>0</td><td>The Dongle is not inserted</td></tr><tr><td>1</td><td>The Dongle is inserted</td></tr></table>	State Value	Result	0	The Dongle is not inserted	1	The Dongle is inserted				
State Value	Result											
0	The Dongle is not inserted											
1	The Dongle is inserted											
WiFi.Connect Command	Wi-Fi connection configuration	<div>When set to 1 or 2, this parameter will be automatically reset to 0.</div> <table><tr><th>State Value</th><th>Result</th></tr><tr><td>0</td><td>No commands in progress</td></tr><tr><td>1</td><td>Disconnected</td></tr><tr><td>2</td><td>Connected</td></tr></table>	State Value	Result	0	No commands in progress	1	Disconnected	2	Connected		
State Value	Result											
0	No commands in progress											
1	Disconnected											
2	Connected											
WiFi.ErrorMessage	Wi-Fi connection error message	<div>This parameter is read-only.</div> <div>Use the Character Display element to read this parameter.</div>										
WiFi.ConnectStatus	Wi-Fi connection status	<div>This parameter is read-only.</div> <table><tr><th>State Value</th><th>Result</th></tr><tr><td>0</td><td>Not connected</td></tr><tr><td>1</td><td>Connecting</td></tr><tr><td>2</td><td>Connected</td></tr><tr><td>3</td><td>Fail to connect</td></tr></table>	State Value	Result	0	Not connected	1	Connecting	2	Connected	3	Fail to connect
State Value	Result											
0	Not connected											
1	Connecting											
2	Connected											
3	Fail to connect											

Parameter	Definition	Description																						
WiFi.SignalLevel	Wi-Fi signal level	<div>This parameter is read-only, the level 4 has the highest signal.</div> <table><tr><th>Level</th><th>Signal Strength</th></tr><tr><td>0</td><td>-100 < signal < -88</td></tr><tr><td>1</td><td>-88 <= signal < -78</td></tr><tr><td>2</td><td>-78 <= signal < -67</td></tr><tr><td>3</td><td>-67 <= signal < -55</td></tr><tr><td>4</td><td>-55 <= signal < 0</td></tr></table>	Level	Signal Strength	0	-100 < signal < -88	1	-88 <= signal < -78	2	-78 <= signal < -67	3	-67 <= signal < -55	4	-55 <= signal < 0										
Level	Signal Strength																							
0	-100 < signal < -88																							
1	-88 <= signal < -78																							
2	-78 <= signal < -67																							
3	-67 <= signal < -55																							
4	-55 <= signal < 0																							
WiFi.SignalStrength	Wi-Fi signal strength	<div>This parameter is read-only, the unit is dBm.</div>																						
WiFi.IPSetting	Wi-Fi network mode	<table><tr><th>State Value</th><th>Result</th></tr><tr><td>0</td><td>DHCP</td></tr><tr><td>1</td><td>Static</td></tr></table>	State Value	Result	0	DHCP	1	Static																
State Value	Result																							
0	DHCP																							
1	Static																							
WiFi.IP1	Wi-Fi IP address	<div><div>Status</div><table><tr><td>State</td><td>COMPLETED</td></tr><tr><td>Network Name</td><td>HMI_WiFi</td></tr><tr><td>MAC</td><td>40:9b:cd:a6:b2:f6</td></tr><tr><td>Signal Strength</td><td>-40</td></tr><tr><td>Frequency</td><td>2462</td></tr><tr><td>Security</td><td>WPA2-PSK</td></tr><tr><td>Auto Connect</td><td>ON</td></tr><tr><td>IP Address</td><td>192.168.122.170</td></tr><tr><td>Gateway</td><td>192.168.123.1</td></tr><tr><td>Mask</td><td>255.255.254.0</td></tr><tr><td>DNS</td><td>192.168.123.1</td></tr></table><div><div>Forget</div><div>Disconnect</div></div></div>	State	COMPLETED	Network Name	HMI_WiFi	MAC	40:9b:cd:a6:b2:f6	Signal Strength	-40	Frequency	2462	Security	WPA2-PSK	Auto Connect	ON	IP Address	192.168.122.170	Gateway	192.168.123.1	Mask	255.255.254.0	DNS	192.168.123.1
State			COMPLETED																					
Network Name			HMI_WiFi																					
MAC			40:9b:cd:a6:b2:f6																					
Signal Strength	-40																							
Frequency	2462																							
Security	WPA2-PSK																							
Auto Connect	ON																							
IP Address	192.168.122.170																							
Gateway	192.168.123.1																							
Mask	255.255.254.0																							
DNS	192.168.123.1																							
WiFi.IP2																								
WiFi.IP3																								
WiFi.IP4																								
WiFi.Mask1	Wi-Fi subnet mask	<div><div>Status</div><table><tr><td>State</td><td>COMPLETED</td></tr><tr><td>Network Name</td><td>HMI_WiFi</td></tr><tr><td>MAC</td><td>40:9b:cd:a6:b2:f6</td></tr><tr><td>Signal Strength</td><td>-40</td></tr><tr><td>Frequency</td><td>2462</td></tr><tr><td>Security</td><td>WPA2-PSK</td></tr><tr><td>Auto Connect</td><td>ON</td></tr><tr><td>IP Address</td><td>192.168.122.170</td></tr><tr><td>Gateway</td><td>192.168.123.1</td></tr><tr><td>Mask</td><td>255.255.254.0</td></tr><tr><td>DNS</td><td>192.168.123.1</td></tr></table><div><div>Forget</div><div>Disconnect</div></div></div>	State	COMPLETED	Network Name	HMI_WiFi	MAC	40:9b:cd:a6:b2:f6	Signal Strength	-40	Frequency	2462	Security	WPA2-PSK	Auto Connect	ON	IP Address	192.168.122.170	Gateway	192.168.123.1	Mask	255.255.254.0	DNS	192.168.123.1
State			COMPLETED																					
Network Name			HMI_WiFi																					
MAC			40:9b:cd:a6:b2:f6																					
Signal Strength	-40																							
Frequency	2462																							
Security	WPA2-PSK																							
Auto Connect	ON																							
IP Address	192.168.122.170																							
Gateway	192.168.123.1																							
Mask	255.255.254.0																							
DNS	192.168.123.1																							
WiFi.Mask2																								
WiFi.Mask3																								
WiFi.Mask4																								

Parameter	Definition	Description																						
WiFi.DNS1	Wi-Fi DNS	<div><div>Status</div><table><tr><td>State</td><td>COMPLETED</td></tr><tr><td>Network Name</td><td>HMI_WiFi</td></tr><tr><td>MAC</td><td>40:9b:cd:a6:b2:f6</td></tr><tr><td>Signal Strength</td><td>-40</td></tr><tr><td>Frequency</td><td>2462</td></tr><tr><td>Security</td><td>WPA2-PSK</td></tr><tr><td>Auto Connect</td><td>ON</td></tr><tr><td>IP Address</td><td>192.168.122.170</td></tr><tr><td>Gateway</td><td>192.168.123.1</td></tr><tr><td>Mask</td><td>255.255.254.0</td></tr><tr><td>DNS</td><td>192.168.123.1</td></tr></table><div><div></div><div>Forget</div><div>Disonnect</div></div></div>	State	COMPLETED	Network Name	HMI_WiFi	MAC	40:9b:cd:a6:b2:f6	Signal Strength	-40	Frequency	2462	Security	WPA2-PSK	Auto Connect	ON	IP Address	192.168.122.170	Gateway	192.168.123.1	Mask	255.255.254.0	DNS	192.168.123.1
State			COMPLETED																					
Network Name			HMI_WiFi																					
MAC			40:9b:cd:a6:b2:f6																					
Signal Strength	-40																							
Frequency	2462																							
Security	WPA2-PSK																							
Auto Connect	ON																							
IP Address	192.168.122.170																							
Gateway	192.168.123.1																							
Mask	255.255.254.0																							
DNS	192.168.123.1																							
WiFi.DNS2																								
WiFi.DNS3																								
WiFi.DNS4																								
WiFi.MAC1	Wi-Fi Dongle MAC	<div><div>Status</div><table><tr><td>State</td><td>COMPLETED</td></tr><tr><td>Network Name</td><td>HMI_WiFi</td></tr><tr><td>MAC</td><td>40:9b:cd:a6:b2:f6</td></tr><tr><td>Signal Strength</td><td>-40</td></tr><tr><td>Frequency</td><td>2462</td></tr><tr><td>Security</td><td>WPA2-PSK</td></tr><tr><td>Auto Connect</td><td>ON</td></tr><tr><td>IP Address</td><td>192.168.122.170</td></tr><tr><td>Gateway</td><td>192.168.123.1</td></tr><tr><td>Mask</td><td>255.255.254.0</td></tr><tr><td>DNS</td><td>192.168.123.1</td></tr></table><div><div></div><div>Forget</div><div>Disonnect</div></div></div>	State	COMPLETED	Network Name	HMI_WiFi	MAC	40:9b:cd:a6:b2:f6	Signal Strength	-40	Frequency	2462	Security	WPA2-PSK	Auto Connect	ON	IP Address	192.168.122.170	Gateway	192.168.123.1	Mask	255.255.254.0	DNS	192.168.123.1
State			COMPLETED																					
Network Name			HMI_WiFi																					
MAC			40:9b:cd:a6:b2:f6																					
Signal Strength			-40																					
Frequency			2462																					
Security	WPA2-PSK																							
Auto Connect	ON																							
IP Address	192.168.122.170																							
Gateway	192.168.123.1																							
Mask	255.255.254.0																							
DNS	192.168.123.1																							
WiFi.MAC2																								
WiFi.MAC3																								
WiFi.MAC4																								
WiFi.MAC5																								
WiFi.MAC6																								
WiFi.NetworkName	Name / password of connected AP	<div><div>Status</div><table><tr><td>State</td><td>COMPLETED</td></tr><tr><td>Network Name</td><td>HMI_WiFi</td></tr><tr><td>MAC</td><td>40:9b:cd:a6:b2:f6</td></tr><tr><td>Signal Strength</td><td>-40</td></tr><tr><td>Frequency</td><td>2462</td></tr><tr><td>Security</td><td>WPA2-PSK</td></tr><tr><td>Auto Connect</td><td>ON</td></tr><tr><td>IP Address</td><td>192.168.122.170</td></tr><tr><td>Gateway</td><td>192.168.123.1</td></tr><tr><td>Mask</td><td>255.255.254.0</td></tr><tr><td>DNS</td><td>192.168.123.1</td></tr></table><div><div></div><div>Forget</div><div>Disonnect</div></div></div>	State	COMPLETED	Network Name	HMI_WiFi	MAC	40:9b:cd:a6:b2:f6	Signal Strength	-40	Frequency	2462	Security	WPA2-PSK	Auto Connect	ON	IP Address	192.168.122.170	Gateway	192.168.123.1	Mask	255.255.254.0	DNS	192.168.123.1
State			COMPLETED																					
Network Name	HMI_WiFi																							
MAC	40:9b:cd:a6:b2:f6																							
Signal Strength	-40																							
Frequency	2462																							
Security	WPA2-PSK																							
Auto Connect	ON																							
IP Address	192.168.122.170																							
Gateway	192.168.123.1																							
Mask	255.255.254.0																							
DNS	192.168.123.1																							
WiFi.Password																								

Parameter	Definition	Description	
WiFi.Security	Encryption method	State Value	Result
		0	WPA2
		1	WEP
		2	NONE
WiFi.AutoConnect	Whether to automatically connect Wi-Fi	State Value	Result
		0	Manual
		1	Auto
WiFi.Enable	Whether to enable Wi-Fi Dongle	State Value	Result
		0	Not enabled
		1	Enabled

External Controller Address

HMI monitors the parameters of the device after it is connected to the controller through COM Port or Ethernet.


Follow these steps to set the external controller address.

To set the external controller address


1. Click **General > Device Communication** in the menu bar.
2. In the **Device Communication** dialog, set the **Link Name**.

The following shows an example of setting the COM Port and Ethernet link names.

The screenshot shows the 'Device Communication' configuration window. On the left, a list of communication ports includes COM1, COM2 (selected with a red checkmark), COM3, Ethernet1, and a Device icon. The main area is titled 'Device Communication' and contains a 'Connection' section with a checked checkbox. Below this, the 'Link Name' is set to 'Link2', 'Manufacturers' is 'Delta', 'Series' is 'Delta DVP PLC', and 'Multi-Drop' is 'Disable'. There are two tabs: 'Main' and 'Extra'. The 'Main' tab is active and contains two sub-sections: 'Communication Parameters' and 'Controller'. 'Communication Parameters' includes 'HMI Station' (0), 'Interface' (RS232), 'Data Bits' (7 Bits), 'Stop Bits' (1 Bits), 'Baud Rate' (9600), and 'Parity Bits' (Even). The 'Controller' section includes 'PLC Station' (1), 'Password' (12345678), 'Comm. Delay Time(ms)' (0), 'Connection Timeout(ms)' (1000), 'Connect Retries' (2), and 'For COMMGR Communication Simulation' (None). At the bottom of the 'Main' tab, the 'Optimize' checkbox is checked. The bottom of the window has a 'Disconnect after communication interrupt' checkbox (unchecked) and a 'Retry times after disconnection' spinner set to 3. At the very bottom are 'OK', 'Cancel', and 'Apply' buttons.



3. In the address **Input** dialog of the element, select the **Link** name, and then set the controller address.




- Unselect the **Default** checkbox, and then set the **Station No.**

Some Ethernet controllers support variable import function, such as Allen Bradley, Beckoff, Simens, Omron, CODESYS, and so on. After importing the corresponding variable file in the **Device Communication** dialog, the HMI can communicate with the controller through variables (Tag).

How to use Tag?

- In the **Device Communication** dialog, select **Ethernet1**.
- In the **Device** tab, click .
- Select **EthernetIP (Micro820/850)(Use Tags)** for **Controller**.





- Click **Import**.
- In the address **Input** dialog of the element, select the **Link** name with the imported variable file.

The variables are listed in the dialog.

6. After selecting the variable, click **OK**.

In the variable selection dialog, you can:

- Use keywords to search for variables.


In the **Find** field, enter a keyword and click . You can also click  to set whether the keyword is case-sensitive.

The variables containing the keyword are listed in the dialog.

- Use spaces to search for variables under a specific level.


Enter the upper level keyword followed by a space, and then enter the lower level keyword.

The matching variables are listed in the dialog.



7. If array variables are imported, select the number of arrays in the drop-down menu of the **Array** after selecting the array variable.

Note: If you need to read and write the Bit of a specific variable in the Bit element, select it through the drop-down menu of the **Bit**.



Variable Sharing


The variables declared by DIADesigner and DIADesigner-AX can be synchronized through the DIA Tag function of DIAScreen, and can be assigned to the elements on the HMI for use.

DIADesigner-AX Tag Automatic Synchronization


Follow these steps to synchronize variables declared by DIADesigner-AX to DIAScreen.


DIADesigner-AX operation (software version 1.6.0)


1. Create global variables or POU variables.



2. Create a symbol table and select the variables to use.



3. Select the device and click  to compile.



4. Click **Build > Generate Code** on the toolbar.

DIAScreen operation

1. Create a project, select the model that includes a network, and then open the variable import dialog.


- If select **DOP-100 series** for **series**, select the **CODESYS** controller in the **Ethernet** setting page of the **Device Communication** dialog, and then click **Import**.

The **Tag List** dialog displays.


- If select **AX-8 series** for **series**, double-click **Built-In PLC** in the **Project** pane.

2. Click  to select .xml or .project file.

Note: To enable the tag automatic synchronization function, select .project file.

3. After selecting .project file, click **Open**.
4. In the **Select device to import** dialog, select the **Device Name**, and then click **OK**.
5. Click .
6. Perform the settings in the **Tag synchronization settings** dialog.

The following table lists the settings in the **Tag synchronization settings** dialog with their descriptions.



The dialog box titled "Tag synchronization settings" contains the following elements:

- 1** ☐ Enable Tag automatic synchronization
- 2** **Source Settings**
 - Imported File: C:\Users\KERRYFANG\Desktop\TEST.project
 - Device Name: AX8
 - Active Application: Application
- 3** **Synchronization Settings**
 - Automatic Check Cycle: 3 (s)
 - ☐ When a change is detected, pop up a window to confirm whether it is synchronized

Buttons: OK, Cancel

1 Enable Tag automatic synchronization

Setting	Description
Enable Tag automatic synchronization	Select Enable Tag automatic synchronization . Once the code is generated in DIADesigner-AX, DIAScreen automatically checks whether the symbol table has been updated according to the set Check Cycle.

2 Source Settings

Setting	Description
Imported File	Displays the synchronized project file path, and you can also change the file path here.
Device Name	You can select the device in the project file.
Active Application	Automatically imports the program name of the device after selecting the device.

3 Synchronization Settings

Setting	Description
Automatic Check Cycle	Set the automatic check cycle. The value range is 3 – 60, and the default value is 3.
When a change is detected, pop up a window to confirm whether it is synchronized	If selected, a message dialog displays when a change is detected and asks you whether to synchronize automatically. <ul style="list-style-type: none"> Select Yes to perform automatic synchronization and update the Tag List in DIAScreen. Select No to not to update the Tag List in DIAScreen and turn off the automatic synchronization function.

Note: If automatic synchronization is enabled and the project file path exists, when the dpa project file is opened, Tag automatic synchronization will be executed first.

DIADesigner Tag Automatic Synchronization

Follow these steps to synchronize variables declared by DIADesigner to DIAScreen.

DIADesigner operation (software version 1.4.2)

1. Create a project.
2. In **Project Explorer**, add a controller device.
3. Double-click **Programming**, right-click **Global Variable**, and then select **Add Global Variable Table**.
4. In the **Add Global Variable Table** dialog, enter the **Name** and **Comment**, and then click **OK**.
5. In the Global Variable table, add variables.

Note: The variable address must be configured. If not configured, DIAScreen will not be able to use the Tag.

6. Click **Compile** on the toolbar.

DIAScreen operation

1. Create a project.

2. In the **COM** setting page of the **Device Communication** dialog, select **Delta** for **Manufacturers** and select the type of controller created in DIADesigner for **Series**.

3. In the **Project** pane, double-click **DIA Tag**.

4. In the **DIA Tag** setting page, click .

5. In the **DIA Tag Import Settings** dialog, select a DIADesigner project file (.diade).

6. Select a **Link Name**.

The communication parameters of the connection are listed in the dialog.

7. Set the **Station No.**

Note:

- The **Don't specify station number** checkbox is selected by default. The **Station No.** field is available only when the DIA Tag is used on the element.
- If unselect the **Don't specify station number** checkbox, the specified station number can be entered in the **Station No.** field.

8. Click **OK**.

9. In the **DIA Tag** setting page, click .

10. In the **DIA Tag Synchronization Settings** dialog, select **Enable automatic sync** checkbox and set **Automatic check cycle**.

11. Create an element on the screen, and then double-click it.

12. In the address **Input** dialog of the element, select **DIA Tag** for **Link**.

The variables are listed in the dialog.

DOP-300 Series HMI Special Features

The following table lists the special features for DOP-300 series HMI.

Category	Function
Element	VNC Viewer
	Gantt Chart
Protocol	EIP Data Exchange Table
IIoT	OPC UA Server Safety Verification
	OPC UA Client Safety Verification
	MQTT JASON Custom
	Aliyun Server
Internal Parameter	IoT
	Storage - USB2_STATUS



Industrial Automation Headquarters

Delta Electronics, Inc.

Taoyuan Technology Center
No.18, Xinglong Rd., Taoyuan District,
Taoyuan City 33068, Taiwan
TEL: 886-3-362-6301 / FAX: 886-3-371-6301

Asia

Delta Electronics (Shanghai) Co., Ltd.

No.182 Minyu Rd., Pudong Shanghai, P.R.C.
Post code : 201209
TEL: 86-21-6872-3988 / FAX: 86-21-6872-3996
Customer Service: 400-820-9595

Delta Electronics (Japan), Inc.

Tokyo Office
Industrial Automation Sales Department
2-1-14 Shibadaimon, Minato-ku
Tokyo, Japan 105-0012
TEL: 81-3-5733-1155 / FAX: 81-3-5733-1255

Delta Electronics (Korea), Inc.

Seoul Office
1511, 219, Gasan Digital 1-Ro., Geumcheon-gu,
Seoul, 08501 South Korea
TEL: 82-2-515-5305 / FAX: 82-2-515-5302

Delta Energy Systems (Singapore) Pte Ltd.

4 Kaki Bukit Avenue 1, #05-04, Singapore 417939
TEL: 65-6747-5155 / FAX: 65-6744-9228

Delta Electronics (India) Pvt. Ltd.

Plot No.43, Sector 35, HSIIDC Gurgaon,
PIN 122001, Haryana, India
TEL: 91-124-4874900 / FAX: 91-124-4874945

Delta Electronics (Thailand) PCL.

909 Soi 9, Moo 4, Bangpoo Industrial Estate (E.P.Z),
Pattana 1 Rd., T.Phraksa, A.Muang,
Samutprakarn 10280, Thailand
TEL: 66-2709-2800 / FAX: 662-709-2827

Delta Electronics (Australia) Pty Ltd.

Unit 20-21/45 Normanby Rd., Notting Hill Vic 3168, Australia
TEL: 61-3-9543-3720

Americas

Delta Electronics (Americas) Ltd.

Raleigh Office
P.O. Box 12173, 5101 Davis Drive,
Research Triangle Park, NC 27709, U.S.A.
TEL: 1-919-767-3813 / FAX: 1-919-767-3969

Delta Greentech (Brasil) S/A

São Paulo Office
Rua Itapeva, 26 – 3º Andar - Bela Vista
CEP: 01332-000 – São Paulo – SP - Brasil
TEL: 55-11-3530-8643 / 55-11-3530-8640

Delta Electronics International Mexico S.A. de C.V.

Mexico Office
Gustavo Baz No. 309 Edificio E PB 103
Colonia La Loma, CP 54060
Tlalnepantla, Estado de México
TEL: 52-55-3603-9200

EMEA

Headquarters: Delta Electronics (Netherlands) B.V.

Sales: Sales.IA.EMEA@deltaww.com
Marketing: Marketing.IA.EMEA@deltaww.com
Technical Support: iatechnicalsupport@deltaww.com
Customer Support: Customer-Support@deltaww.com
Service: Service.IA.emea@deltaww.com
TEL: +31(0)40 800 3900

BENELUX: Delta Electronics (Netherlands) B.V.

De Witbogt 20, 5652 AG Eindhoven, The Netherlands
Mail: Sales.IA.Benelux@deltaww.com
TEL: +31(0)40 800 3900

DACH: Delta Electronics (Netherlands) B.V.

Coesterweg 45, D-59494 Soest, Germany
Mail: Sales.IA.DACH@deltaww.com TEL:
+49(0)2921 987 0

France: Delta Electronics (France) S.A.

ZI du bois Challand 2, 15 rue des Pyrénées,
Lisses, 91090 Evry Cedex, France
Mail: Sales.IA.FR@deltaww.com
TEL: +33(0)1 69 77 82 60

Iberia: Delta Electronics Solutions (Spain) S.L.U

Ctra. De Villaverde a Vallecas, 265 1º Dcha Ed.
Hormigueras – P.I. de Vallecas 28031 Madrid
TEL: +34(0)91 223 74 20
Carrer Llacuna 166, 08018 Barcelona, Spain
Mail: Sales.IA.Iberia@deltaww.com

Italy: Delta Electronics (Italy) S.r.l.

Via Meda 2-22060 Novedrate(CO)
Piazza Grazioli 18 00186 Roma Italy Mail:
Sales.IA.Italy@deltaww.com
TEL: +39 039 8900365

Russia: Delta Energy System LLC

Vereyskaya Plaza II, office 112 Vereyskaya str.
17 121357 Moscow Russia
Mail: Sales.IA.RU@deltaww.com
TEL: +7 495 644 3240

Turkey: Delta Greentech Elektronik San. Ltd. Sti. (Turkey)

Şerifali Mah. Hendem Cad. Kule Sok. No:16-A
34775 Ümraniye – İstanbul
Mail: Sales.IA.Turkey@deltaww.com
TEL: + 90 216 499 9910

GCC: Delta Energy Systems AG (Dubai BR)

P.O. Box 185668, Gate 7, 3rd Floor, Hamarain Centre
Dubai, United Arab Emirates
Mail: Sales.IA.MEA@deltaww.com
TEL: +971(0)4 2690148

Egypt + North Africa: Delta Electronics

Unit 318, 3rd Floor, Trivium Business Complex, North 90 street,
New Cairo, Cairo, Egypt
Mail: Sales.IA.MEA@deltaww.com