


**Warning**

ENGLISH

- This instruction sheet only provides introductory information on electrical specification, installation and wiring.
- Switch off the power before wiring. DO NOT touch any terminal when the power is switched on.
- RTU-EN01 is an OPEN-TYPE device and therefore should be installed in an enclosure free of airborne dust, humidity, electric shock and vibration. The enclosure should prevent non-maintenance staff from operating the device (e.g. key or specific tools are required to open the enclosure) in case danger and damage on the device may occur.
- DO NOT touch the internal circuit within one minute after the power supply is cut off.
- DO NOT connect AC power supply to any of the I/O terminals; otherwise serious damage may occur. Check all the wiring again before switching on the power and DO NOT touch any terminal when the power is switched on. Make sure the ground terminal is correctly grounded in order to prevent electromagnetic interference.

Introduction**Features**

- The smart PLC functions support counter, timer and RTC and are able to operate independently through easy setup without control of PLC MPU or programming.
- Able to auto-detect 10/100 Mbps transmission speed; MDI/MDI-X auto-detect.
- Supporting 16 digital I/O modules (max. 256 I/O points) and 8 analog I/O modules.
- Supporting maximum 16 Modbus TCP connections.
- Supporting Modbus TCP/Modbus gateway (supporting Master mode, able to connect to max. 32 devices).
- Parameters can be set up on webpage.

Product Profile & Outline**Specifications****Ethernet Port**

Interface	RJ-45 with Auto MDI/MDIX
Transmission method	802.3, 802.3u
Transmission cable	Category 5e, 100m (Max)
Transmission speed	10/100 Mbps Auto-Detection
Network protocol	ICMP, IP, TCP, UDP, DHCP, NTP, Modbus TCP, HTTP

RS-485 Port

Interface	3 PIN feed-through terminal
Transmission method	RS-485
Transmission distance	1,200m
Transmission speed	110, 150, 300, 600, 1,200, 2,400, 4,800, 9,600, 19,200, 38,400, 57,600, 115,200 bps
Communication format	Stop bit: 1; Parity bit: None, Odd, Even; Data bit: 7,8
Communication protocol	Modbus ASCII - Modbus RTU

RS-232 Port


Interface	Mini Dim
Transmission method	RS-232
Transmission speed	19,200 bps
Communication format	Stop bit: 1; Parity bit: None; Data bit: 8
Communication protocol	Delta Configuration
Transmission cable	DVPACAB215 / DVPACAB230 / DVPACAB2A30

Electrical Specification

Power supply voltage	24VDC (-15% ~ 20%) (with DC input polarity reverse protection)
Power supply capacity	1.85A/30VDC, Polyswitch
Power consumption	2W
Insulation voltage	500VDC
Weight	116g

Environment

Noise immunity	ESD (IEC 61131-2, IEC 61000-4-2); 2kV Air Discharge EFT (IEC 61131-2, IEC 61000-4-4); Power Line: 2kV, Digital Input: ±2kV, Communication I/O: ±2kV RS (IEC 61131-2, IEC 61000-4-3); 80MHz ~ 100MHz, 10V/m, 1.4GHz ~ 2.0GHz, 10V/m Conducted Susceptibility Test (EN61000-4-6, IEC61131-2 9.10); 150kHz ~ 80MHz, 3V/m Surge Test (Bwave IEC61132-2, IEC61000-4-5); Power line 0.5kV DM, Ethernet 0.5kV CM, RS-485 0.5kV CM
Operation/storage	Operation: 0°C ~ 55°C (temperature), 5 ~ 95% (humidity), pollution degree 2 Storage: -25°C ~ 70°C (temperature), 5 ~ 95% (humidity)
Shock/vibration immunity	International standards: IEC61131-2, IEC68-2-6 (TEST Fc)/IEC61131-2 & IEC 68-2-27 (TEST Ea)
Certificates	

Installation**Dimension****RUN / STOP Switch**


Status	Explanation
RUN	1. RUN Indicator on RTU-EN01 is ON. 2. Analog I/O module in RUN status. 3. Smart PLC function running
RUN → STOP	1. Analog I/O module switches from RUN to STOP status. 2. Y points on digital output module are all OFF.
STOP	1. RUN Indicator on RTU-EN01 is OFF. 2. Analog I/O module in STOP status. 3. Smart PLC function stops.
STOP → RUN	1. RTU-EN01 re-detected the number of points in right-side module. 2. Analog I/O module switches from STOP to RUN status.

RS-45 PIN Definition

PIN	Signal	Definition
1	Tx+	Positive pole for data transmission
2	Tx-	Negative pole for data transmission
3	Rx+	Positive pole for data receiving
4	-	N/C
5	-	N/C
6	Rx-	Negative pole for data receiving
7	-	N/C
8	-	N/C

Feed-through Terminal PIN Definition

PIN	Signal	Definition
1	SG	Ground of data
2	D-	Negative pole for data
3	D+	Positive pole for data

**LED Indicators & Trouble-Shooting**

There are 7 LED indicators and a digital display on RTU-EN01. POWER LED displays the status of the power supply. RS-232 LED, RS-485 LED, LINK/ACT LED and SPEED LED display the connection status of the communication. The digital display shows the address of RTU-EN01, error messages and errors from the slave.

POWER LED

LED status	Indication	Solution
OFF	Power supply is abnormal.	Check if the power supply of RTU-EN01 is normal.
Green light ON	Power supply is normal.	--

RUN LED

LED status	Indication	Solution
OFF	RTU-EN01 in STOP status	1. Check if the RUN/STOP switch is switched to RUN. 2. Check if an error is displayed on the digital display
Green light ON	RTU-EN01 in RUN status	--

BATLOW LED

LED status	Indication	Solution
OFF	No communication or abnormal RS-232 connection.	If occurring during communication, check if the RS-232 port on RTU-EN01 is normally connected.
Yellow light steady ON	Abnormal RS-232 connection	Check if the RS-232 port on RTU-EN01 is normally connected.

RS-232 LED

LED status	Indication	Solution
OFF	No communication or abnormal RS-485 connection	1. If occurring during communication, check if the RS-485 port on RTU-EN01 is normally connected. 2. Make sure at least 1 node on network can communicate normally.
Yellow light steady ON	Abnormal RS-485 connection	Switch D+ and D-.

RS-485 LED

LED status	Indication	Solution
OFF	No communication or abnormal RS-485 connection	1. If occurring during communication, check if the RS-485 port on RTU-EN01 is normally connected. 2. Re-power RTU-EN01. If the error still exists, return your RTU-EN01 to the manufacturer for further solutions.
Yellow light flashes	Data transmission is normal.	--

LINK / ACT LED

LED status	Indication	Solution
OFF	No power supply or network connection	1. Check the power of RTU-EN01 and make sure the network connection is normal. 2. Re-power RTU-EN01. If the error still exists, return your RTU-EN01 to the manufacturer for further solutions.
Green light ON	The connection is normal, but no data transmission	--

SPEED LED

LED status	Indication	Solution
OFF	Ethernet communication speed = 10Mbps	1. Check if RTU-EN01 is connected to 100Mbps Ethernet. 2. Check if the network is connected and connected by Category 5e cable.
Yellow light ON	Ethernet communication speed = 100Mbps	3. Re-power RTU-EN01. If the error still exists, return it to the manufacturer for further solutions.

Codes in Digital Display


Code	Status	Indication	Solution
0~FF	ON	Node address of RTU-EN01 under normal operation	--
F0	Flash	Returning to default setting	--
F1	Flash	RTU-EN01 is booting.	--
F2	Flash	Power supply in low voltage	Check if the power supply is normal.
F3	Flash	Internal memory error	1. Check if the settings of Smart PLC are incorrect. 2. Re-power RTU-EN01. If the error still exists, try step 3. 3. Re-set RTU-EN01. If the error still exists, return it to the manufacturer for further solutions.
F4	Flash	Internal error caused by manufacturing in the factory	Check if RTU-EN01 is normally connected to the network.
F5	Flash	Network connection error	Check if the number of connections exceeds the maximum.
F6	Flash	Insufficient TCP connection	Check if the RS-485 communication format is correct.
F7	Flash	RS-485 setting error	1. DTR request failure 2. Setting error 3. MASK setting error 4. Gateway does not exist in the same subnet. 5. Returning to default setting
F8	Flash	IP setting error	Check if the configuration of the right-side module has been modified. If the error still exists, check if the number of I/O points exceeds the allowed range and if the number of analog I/O points exceeds 8.
F9	Flash	Right-side module error	Check if the configuration of the right-side module has been modified. If the error still exists, check if the number of I/O points exceeds the allowed range and if the number of analog I/O points exceeds 8.
FA	Flash	Syntax check error	1. Check if errors occur in TS, CS, AL, RT registers. 2. Read the RS-485 where the error occurs.
04	Flash	Slave error from the station	1. Check if RTU-EN01 and RS-485 is connected normally. 2. Check if the other nodes on the network.
0b	Flash	No response from station	Check if the transmission speed is consistent with that of other nodes on the network.

注意事項

- 此安装手册只提供電氣規格、一般規格、安裝及配線等。
- 配線時請勿關電源，請勿在電源接線時觸摸任何端子。
- 本機為開放式 (OPEN TYPE) 機體，因此使用者使用本機時，必須將其安置於具防塵、防腐蝕等級的環境內。
- 輸入電源切斷後，一分鐘之內，請勿觸摸內部線路。
- 交流輸入電源不可直接接於輸入 / 輸出端子號；否則可能造成嚴重損壞。請在上電前再次確認電源接線，且請勿在上電時觸摸任何端子。本機上的接地端子請務必正確的接地，以提高產品抗雜訊能力。


產品簡介**功能特色**

- Smart PLC 功能，支援計數器、計時器、RTC，不需 PLC 主機控制或編程，經由簡單設定即能獨立運作。
- 自動偵測 10/100 Mbps 傳輸速率：MDI/MDI-X 自動偵測。
- 最大支援 16 台數位輸入/輸出模組（最多可達 256 點）與 8 台類比輸入/輸出模組。
- 最大支援 16 組 Modbus TCP 連接器。
- 支援 Modbus TCP/Modbus 通訊埠（支援 Master 模式，最多可以連接 32 台裝置）。
- 可透過網頁設定參數。

產品外觀**功能規格****Ethernet 連接器**

接頭	RJ-45 with Auto MDI/MDIX

<tbl_r cells="2" ix="4" maxcspan="1" maxrspan="1" usedcols="2



尺寸单位: mm

■ RUN / STOP 開關



狀態	說明
RUN	1. RTU-EN01內部的RUN燈亮 2. 比較輸入/輸出模組處於RUN狀態 3. Smart PLC功能啓動
RUN → STOP	1. 比較輸入/輸出模組由RUN切換到STOP狀態 2. 數位輸出模組的Y點全都要OFF狀態
STOP	1. RTU-EN01內部的STOP燈亮 2. 比較輸入/輸出模組處於STOP狀態 3. Smart PLC功能停止
STOP → RUN	1. RTU-EN01根據重新上電右側模組資訊 2. 比較輸入/輸出模組由STOP切換到RUN狀態

■ RJ-45 連接器的腳位定義

腳位	訊號	敘述
1	Tx+	傳輸資料正極
2	Tx-	傳輸資料負極
3	Rx+	接收資料正極
4	-	N/C
5	-	N/C
6	Rx-	接收資料負極
7	-	N/C
8	GND	參考地



■ RS-232 連接器的腳位定義

腳位	訊號	敘述
1	-	N/C
2	-	N/C
3	-	N/C
4	Rx	接收資料
5	Tx	傳輸資料
6	-	N/C
7	-	N/C
8	GND	參考地



■ 歐式端子台的腳位定義

腳位	訊號	敘述
1	SG	資料傳輸參考地
2	D-	資料負極
3	D+	資料正極



■ LED 燈指示說明及故障排除

RTU-EN01有七個LED指示燈和一個數位顯示器。POWER LED用來顯示RTU-EN01的工作電源是否正常；RS-232 LED、RS-485 LED、LINK/ACT LED和SPEED LED用來顯示RTU-EN01的通訊連接狀態；數位顯示器用來顯示RTU-EN01各模組的站號、錯誤資訊以及從站的錯誤訊息。

■ POWER 燈顯示說明

LED 燈狀態	顯示說明	處理方法
燈滅	工作電源不正常	檢查RTU-EN01工作電源是否正常
綠燈亮	工作電源正常	無需處理

■ RUN 燈顯示說明

LED 燈狀態	顯示說明	處理方法
燈滅	STOP 狀態	1. 檢查 RUN/STOP 開關是否在 RUN 狀態 2. 數位顯示器顯示是否有錯誤發生
綠燈亮	RUN 狀態	無需處理

■ BAT.LOW 燈顯示說明

LED 燈狀態	顯示說明	處理方法
燈滅	電池正常	無需處理
紅燈閃爍	電池低電量	1. 請更換電池 2. 重新上電，如果錯誤依然存在，請退回工廠進行修復。

■ RS-232 燈顯示說明

LED 燈狀態	顯示說明	處理方法
燈滅	無訊號或 RS-232 連接不正常	如訊號中斷，檢查RTU-EN01的RS-232確認連接正常。
黃燈復亮	RS-232 連接不正常	檢查RTU-EN01的RS-232，確認連接正常。

■ RS-485 燈顯示說明

LED 燈狀態	顯示說明	處理方法
燈滅	無訊號或 RS-485 連接不正常	1. 如訊號中斷，檢查RTU-EN01的RS-485確認連接正常 2. 檢查網絡上至少有一個節點可以正常通訊。
黃燈復亮	RS-485 連接不正常	D+ - D- 調試

■ LINK / ACT 燈顯示說明

LED 燈狀態	顯示說明	處理方法
燈滅	無電源或者網路無連接	1. 檢查RTU-EN01電源並確認網路線連接正常 2. 重新上電，如果錯誤依然存在，請退回工廠進行修復。
綠燈亮	連線正常、無資料傳送	無需處理

■ SPEED 燈顯示說明

LED 燈狀態	顯示說明	處理方法
綠燈亮	傳送、接收資料正常	無需處理

LED 燈狀態	顯示說明	處理方法
燈滅	Ethernet 連線為 10Mbps	1. 檢查是否連接 10Mbps Ethernet 設備 2. 檢查網路線是否正確，並為 Category 5e 線路。 3. 重新上電，如果錯誤依然存在，請退回工廠進行修復。
黃燈亮	Ethernet 連線為 100Mbps	無需處理

■ 數位顯示器顯示說明

代碼	狀態	顯示說明	處理方法
0 ~ FF	常亮	模組的節點位址 (正常工作時)	無需處理
F0	閃爍	回歸出厂設定值	無需處理
F1	閃爍	開機中	無需處理
F2	閃爍	工作電壓過高過低	檢查通訊模組的工作電壓是否正確
F3	閃爍	內部錯誤	1. 檢查 Smart PLC 設定是否發生錯誤。 2. 將 RTU-EN01 重新上電，如果錯誤依然存在，進行步驟 3。 3. 將 RTU-EN01 回復原廠設定值，如果錯誤依然存在，請退回工廠進行修復。
F4	閃爍	內部錯誤、工業製造流程出錯	檢查通訊模組與網路連接正常
F5	閃爍	網路連接錯誤	確認錯誤數目是否超過最大值
F6	閃爍	TCP 連接不足	請確認連接數目是否超過最大值
F7	閃爍	RS-485 設定錯誤	檢查 RS-485 通訊格式是否設定正確
F8	閃爍	IP 設定錯誤	1. DHCP請求失敗 2. IP設定錯誤 3. MASK設定錯誤 4. Gateway不在相同的子網路中 5. 回歸原廠設定值
F9	閃爍	右側模組錯誤	檢查右側模組是否正常，若錯誤持續顯示時，檢查輸出人點數是否超過，模組輸出模塊總數是否超過 8 個。
FA	閃爍	文法檢查錯誤	1. 檢查 TS, CS, AL, RT 訊息是否產生錯誤 2. 請取 BR58 為錯誤發生的地址
F0	閃爍	從站錯誤	1. 檢查 RS-485 連接是否正常 2. 檢查通訊模組串列埠速率與網絡上其他節點的串列埠速率設定一致
0b	閃爍	站台無回應	檢查站台無回應

■ 功能規格

■ Ethernet 連接器

埠頭	RJ-45 with Auto MDI/MDIX
传输方式	802.3, 802.3y
传输距离	Category 5e, 100m (Max)
传输速率	10/100 Mbps Auto-Detection
网络协议	ICMP, IP, TCP, UDP, DHCP, NTP, Modbus TCP, HTTP

■ RS-485 連接器

埠頭	欧式端子行 3 PIN
传输方式	RS-485
传输距离	1.200m
传输速率	11...150, 300, 600, 1,200, 2,400, 4,800, 9,600, 19,200, 38,400, 57,600, 115,200 bps
通讯格式	Stop bit: 1; Parity bit: None, Odd, Even; Data bit: 7,8
通讯协议	Modbus ASCII, Modbus RTU

■ RS-232 連接器

埠頭	Mini Dim
传输方式	RS-232
传输速率	19,200 bps
通讯格式	Stop bit: 1; Parity bit: None, Data bit: 8
通讯协议	Delta Configuration
传输缆线	DVPACAB215 / DVPACAB230 / DVPACAB2A30

■ 电气规格

电源电压	24VDC (-15% ~ 20%) (具直流入地极性反接保护)
电源输入容许	1.85A/30V DC, 可恢复式 (Polyswitch)
消耗电力	2W
绝缘电压	500V DC
重量	116g

■ 环境规格

干扰免疫力	ESD (IEC 61131-2, IEC 61000-4-2): 8kV Air Discharge EFT (IEC 61131-2, IEC 61000-4-4): Power Line ±2kV, Digital Input: ±2kV, Communication I/O: ±2kV RS (IEC 61131-2, IEC 61000-4-3): 80MHz ~ 100MHz, 10V/m, 1.4GHz ~ 2.0GHz, 10V/m Commutation Frequency Test (IEC61000-4-6, IEC61131-2.9.10): 150kHz ~ 80MHz, 3V/m Surge Test (Biased IEC61131-2.9, IEC61000-4-5): Power line 0.5kV DM, Ethernet 0.5kV CM, RS-485 0.5kV CM
操作 / 储存环境	操作: 0°C ~ 55°C (湿度), 5 ~ 95% (湿度), 污染等级 2 储存: -25°C ~ 70°C (湿度), 5 ~ 95% (湿度)
耐震动 / 冲击	国际标准规范 IEC61131-2, IEC60068-2-6 (TEST Fc) / IEC61131-2 & IEC 68-2-27 (TEST Ea)
标准	CE, RoHS

■ 欧式端子台的接脚定义

脚位	信号	叙述
1	Tx+	传输资料正极
2	Tx-	传输资料负极
3	Rx+	接收资料正极
4	-	N/C
5	-	N/C
6	Rx-	接收资料负极
7	-	N/C
8	GND	参考地



■ LED 灯指示说明及故障排除

LED 灯状态	显示说明	处理方法
灯灭	工作电源不正常	检查 RTU-EN01 工作电源是否正常
绿灯亮	工作电源正常	无需处理
黄灯亮	RS-485 未连接	1. 检查 RS-485 连接线是否连接正常 2. 检查数据线是否损坏

■ POWER 灯显示说明

LED 灯状态	显示说明	处理方法
灯灭	工作电源不正常	检查 RTU-EN01 工作电源是否正常
绿灯亮	工作电源正常	无需处理
黄灯闪烁	RS-485 未连接	1. 检查 RS-485 连接线是否连接正常 2. 检查数据线是否损坏

■ RUN 灯顯示说明

LED 灯状态	显示说明	处理方法
灯灭	无电源或者网络无连接	如讯号中断，检查 RTU-EN01 的 RS-232 确认连接正常。
绿灯亮	连接正常	检查 RTU-EN01 的 RS-232，确认连接正常。
黄灯闪烁	连接不正常	1. 请更换电池 2. 重新上电，如果错误依然存在，请退回工厂进行修复。

■ RS-232 灯显示说明