



Industrial Automation Headquarters

Delta Electronics, Inc.

Taoyuan Technology Center
No.18, Xinglong Rd., Taoyuan District,
Taoyuan City 33068, Taiwan
TEL: 886-3-362-6301 / FAX: 886-3-371-6301

Asia

Delta Electronics (Shanghai) Co., Ltd.

No.182 Minyu Rd., Pudong Shanghai, P.R.C.
Post code : 201209
TEL: 86-21-6872-3988 / FAX: 86-21-6872-3996
Customer Service: 400-820-9595

Delta Electronics (Japan), Inc.

Tokyo Office
Industrial Automation Sales Department
2-1-14 Shibadaimon, Minato-ku
Tokyo, Japan 105-0012
TEL: 81-3-5733-1155 / FAX: 81-3-5733-1255

Delta Electronics (Korea), Inc.

Seoul Office
1511, 219, Gasan Digital 1-Ro., Geumcheon-gu,
Seoul, 08501 South Korea
TEL: 82-2-515-5305 / FAX: 82-2-515-5302

Delta Energy Systems (Singapore) Pte Ltd.

4 Kaki Bukit Avenue 1, #05-04, Singapore 417939
TEL: 65-6747-5155 / FAX: 65-6744-9228

Delta Electronics (India) Pvt. Ltd.

Plot No.43, Sector 35, HSIDC Gurgaon,
PIN 122001, Haryana, India
TEL: 91-124-4874900 / FAX : 91-124-4874945

Delta Electronics (Thailand) PCL.

909 Soi 9, Moo 4, Bangpoo Industrial Estate (E.P.Z),
Pattana 1 Rd., T.Phraksa, A.Muang,
Samutprakarn 10280, Thailand
TEL: 66-2709-2800 / FAX : 662-709-2827

Delta Energy Systems (Australia) Pty Ltd.

Unit 20-21/45 Normanby Rd., Notting Hill Vic 3168, Australia
TEL: 61-3-9543-3720

Americas

Delta Electronics (Americas) Ltd.

Raleigh Office
P.O. Box 12173, 5101 Davis Drive,
Research Triangle Park, NC 27709, U.S.A.
TEL: 1-919-767-3813 / FAX: 1-919-767-3969

Delta Greentech (Brasil) S/A

São Paulo Office
Rua Itapeva, 26 – 3º Andar - Bela Vista
CEP: 01332-000 – São Paulo – SP - Brasil
TEL: 55-11-3530-8642 / 55-11-3530-8640

Delta Electronics International Mexico S.A. de C.V.

Mexico Office
Vía Dr. Gustavo Baz No. 2160, Colonia La Loma,
54060 Tlalnepantla Estado de Mexico
TEL: 52-55-2628-3015 #3050/3052

EMEA

Headquarters: Delta Electronics (Netherlands) B.V.

Sales: Sales.IA.EMEA@deltaww.com
Marketing: Marketing.IA.EMEA@deltaww.com
Technical Support: iatechnicalsupport@deltaww.com
Customer Support: Customer-Support@deltaww.com
Service: Service.IA.emea@deltaww.com
TEL: +31(0)40 800 3800

BENELUX: Delta Electronics (Netherlands) B.V.

De Witbogt 20, 5652 AG Eindhoven, The Netherlands
Mail: Sales.IA.Benelux@deltaww.com
TEL: +31(0)40 800 3800

DACH: Delta Electronics (Netherlands) B.V.

Coesterweg 45, D-59494 Soest, Germany
Mail: Sales.IA.DACH@deltaww.com
TEL: +49(0)2921 987 0

France: Delta Electronics (France) S.A.

ZI du bois Challand 2, 15 rue des Pyrénées,
Lisses, 91090 Evry Cedex, France
Mail: Sales.IA.FR@deltaww.com
TEL: +33(0)1 69 77 82 60

Iberia: Delta Electronics Solutions (Spain) S.L.U

Ctra. De Villaverde a Vallecas, 265 1º Dcha Ed.
Hormigueras – P.I. de Vallecas 28031 Madrid
TEL: +34(0)91 223 74 20

Carrer Llacuna 166, 08018 Barcelona, Spain
Mail: Sales.IA.Iberia@deltaww.com

Italy: Delta Electronics (Italy) S.r.l.

Ufficio di Milano Via Senigallia 18/2 20161 Milano (MI)
Piazza Grazioli 18 00186 Roma Italy
Mail: Sales.IA.Italy@deltaww.com
TEL: +39 02 64672538

Russia: Delta Energy System LLC

Vereyskaya Plaza II, office 112 Vereyskaya str.
17 121357 Moscow Russia
Mail: Sales.IA.RU@deltaww.com
TEL: +7 495 644 3240

Turkey: Delta Greentech Elektronik San. Ltd. Sti. (Turkey)

Şerifali Mah. Hendem Cad. Kule Sok. No:16-A
34775 Ümraniye – İstanbul
Mail: Sales.IA.Turkey@deltaww.com
TEL: + 90 216 499 9910

GCC: Delta Energy Systems AG (Dubai BR)

P.O. Box 185668, Gate 7, 3rd Floor, Hamarain Centre
Dubai, United Arab Emirates
Mail: Sales.IA.MEA@deltaww.com
TEL: +971(0)4 2690148

Egypt + North Africa: Delta Electronics

511 Cairo Business Plaza, North 90 street,
New Cairo, Cairo, Egypt
Mail: Sales.IA.MEA@deltaww.com



Slim Industrial IEEE 802.11 a/b/g/n/ac Wireless AP/Client/Gateway

DVW-W01I2-E1 Series User Manual

DVW 2.4 GHz/5 GHz

Delta Industrial Wireless DVW-W01I2-E1 Series User Manual

Revision History

| Version | Revision | Date |
|-----------------|----------------------------------|------------|
| 1 st | The first version was published. | 2020/01/22 |

Delta Industrial Wireless DVW-W01I2-E1 Series User Manual

Contents

Chapter 1 Product Introduction

| | |
|--|-------------|
| 1.1 Overview | 1-3 |
| 1.1.1 High performance wireless technology | 1-3 |
| 1.1.2 Good reliability and design optimization | 1-4 |
| 1.1.3 Robust design for industrial hardware | 1-4 |
| 1.1.4 Product profile and dimensions | 1-4 |
| 1.2 LED indicator | 1-5 |
| 1.3 Installation | 1-6 |
| 1.3.1 DIN-rail mounting | 1-6 |
| 1.3.2 Wall mounting | 1-7 |
| 1.3.3 Wiring the redundant power input | 1-7 |
| 1.3.4 Wiring the Alarm Contact | 1-8 |
| 1.3.5 Wiring the Digital Input | 1-9 |
| 1.3.6 Pin definition | 1-9 |
| 1.3.7 Wiring | 1-10 |
| 1.4 Package checklist | 1-10 |

Chapter 2 User Interface and Application

| | |
|---|------------|
| 2.1 Configuration | 2-2 |
| 2.2 Connection and access settings | 2-2 |
| 2.3 IEXplorer | 2-4 |
| 2.3.1 Device connection and detection | 2-4 |
| 2.4 General configurations | 2-4 |
| 2.4.1 AP mode setup | 2-4 |
| 2.4.2 Client mode setup | 2-6 |
| 2.4.3 MODBUS Slave Gateway | 2-8 |
| 2.4.4 MODBUS Master Gateway | 2-10 |
| 2.4.5 Serial Server (TCP/UDP Client) | 2-11 |
| 2.4.6 Transparent (TCP Server) | 2-12 |

| | | |
|-------|---|------|
| 2.4.7 | Serial server (TCP client) + Transparent (TCP server) | 2-14 |
| 2.4.8 | Virtual COM | 2-15 |
| 2.4.9 | Wi-Fi Roaming (One Roaming)..... | 2-17 |

Chapter 3 Function Guide

| | | |
|------------|------------------------------------|-------------|
| 3.1 | System | 3-3 |
| 3.1.1 | System configuration | 3-3 |
| 3.1.2 | System CPU status | 3-3 |
| 3.2 | Basic configuration | 3-4 |
| 3.2.1 | System information | 3-4 |
| 3.2.2 | Network configuration | 3-5 |
| 3.3 | Serial configuration | 3-6 |
| 3.3.1 | MODBUS gateway..... | 3-6 |
| 3.3.2 | Serial server | 3-14 |
| 3.3.3 | Transparent server..... | 3-19 |
| 3.3.4 | MODBUS cache table | 3-22 |
| 3.4 | WLAN management - 2.4G..... | 3-26 |
| 3.4.1 | Operation mode | 3-26 |
| 3.4.2 | WLAN 2.4G..... | 3-27 |
| 3.5 | WLAN management - 5G..... | 3-31 |
| 3.5.1 | Operation mode | 3-31 |
| 3.5.2 | WLAN 5G | 3-32 |
| 3.6 | Advance..... | 3-36 |
| 3.6.1 | SNMP Configuration | 3-36 |
| 3.6.2 | Packet Control | 3-38 |
| 3.7 | Auto Warning Setting | 3-40 |
| 3.7.1 | SysLog..... | 3-40 |
| 3.7.2 | E-mail Alarm..... | 3-42 |
| 3.7.3 | SNMP Trap..... | 3-43 |
| 3.7.4 | Relay Alarm | 3-44 |

| | | |
|-------------|-------------------------------------|-------------|
| 3.8 | Management Access | 3-45 |
| 3.8.1 | SSH Configuration..... | 3-45 |
| 3.8.2 | Telnet Configuration | 3-45 |
| 3.9 | Monitoring | 3-46 |
| 3.9.1 | Email Alarm Table | 3-46 |
| 3.9.2 | Relay Alarm Table | 3-46 |
| 3.9.3 | Trap Alarm Table..... | 3-46 |
| 3.9.4 | Network Connection Status | 3-46 |
| 3.9.5 | AP Client List..... | 3-47 |
| 3.9.6 | DHCP Client List | 3-47 |
| 3.9.7 | Serial Port Status..... | 3-47 |
| 3.9.8 | Serial Port Statistics | 3-48 |
| 3.9.9 | Serial Port Error..... | 3-48 |
| 3.9.10 | Serial Port Log..... | 3-48 |
| 3.10 | Maintenance | 3-48 |
| 3.10.1 | Session timeout..... | 3-48 |
| 3.10.2 | Password | 3-49 |
| 3.10.3 | System log backup..... | 3-49 |
| 3.10.4 | Roaming log..... | 3-49 |
| 3.10.5 | Serial log | 3-50 |
| 3.10.6 | Ping | 3-51 |
| 3.10.7 | Ping detection | 3-51 |
| 3.10.8 | Firmware upgrade..... | 3-51 |
| 3.10.9 | Configuration Import & Export | 3-51 |
| 3.10.10 | Load factory default | 3-52 |
| 3.10.11 | Log off | 3-52 |

Chapter 1 Product introduction

Table of Contents

| | |
|---|-------------|
| 1.1 Overview..... | 1-3 |
| 1.1.1 High performance wireless technology..... | 1-3 |
| 1.1.2 Good reliability and design optimization..... | 1-3 |
| 1.1.3 Robust design for industrial hardware..... | 1-4 |
| 1.1.4 Product profile and dimensions..... | 1-4 |
| 1.2 LED indicator..... | 1-5 |
| 1.3 Installation | 1-5 |
| 1.3.1 DIN-rail mounting | 1-5 |
| 1.3.2 Wall mounting | 1-6 |
| 1.3.3 Wiring the redundant power input..... | 1-7 |
| 1.3.4 Wiring the Alarm Contact | 1-7 |
| 1.3.5 Wiring the Digital Input..... | 1-8 |
| 1.3.6 Pin definition | 1-9 |
| 1.3.7 Wiring | 1-10 |
| 1.4 Package checklist..... | 1-10 |

About this Manual

This manual contains information about **DVW-W01I2-E1** series. When using Delta DVW series product in China, please refer to Delta official website with model name **DVW-W01I2-E1** or contact our nearest branch offices or distributors for further information.

FCC Interference Statement

This equipment has been tested and found to comply with the limits for a class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates radio frequency signal and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

---Reorient or relocate the receiving antenna.

---Increase the separation between the equipment and receiver.

---Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

---Consult the dealer or an experienced radio/TV technician for help.

CE Declaration of Conformity

In accordance with the Directives 2004/108/EC*, 2014/30/EU, 2006/95/EC*, 2014/35/EU and 1999/5/EC. The test record, data evaluation and DX-2100RW-WWW configurations represented herein are true and accurate under the standards herein specified.

EN 301 511 V9.0.2 (2003-3)

Test Items:

Radiated spurious emissions – MS allocated channel (Clause 4.2.16)

Radiated spurious emissions – MS in idle mode (Clause 4.2.17)

EN 301 908-1 V7.1.1 (2015-03)

EN 301 489-1 V1.9.2 (2011-09)

EN 301 489-7 V1.3.1 (2005-11)

EN 301 489-24 V1.5.1 (2010-10)

Disclaimers and Limitation of Liabilities

To the maximum extent permitted by law and regardless DELTA be aware or has been advised of the possibility of these damages, DELTA is not liable to any user or anyone else for: (a) any loss of use, data, reputation, goodwill, credit, opportunity, economy or profits, whether or not foreseeable; (b) any special, incidental, indirect, consequential, or punitive damages whatsoever; (c) any losses or damages based on any theory of liability, including breach of contract or warranty, negligence or other tortious action; (d) any losses or damages resulting from use or unable to use the systems or devices to which the Software or Services are incorporated or co-operated; and (e) any losses or damages arising from any other claim or in connection with the use of or access to the Software or Services.

1.1 Overview

Delta's industrial wireless DVW-W01I2-E1 series features Ethernet port, RS-232 and RS-485, supports standard MODBUS protocol for executing and controlling data transmission with operating devices. DVW-W01I2-E1 supports fast-roaming solution especially suitable for clients in wireless environment to quickly switch connection from one AP to another for continuous roaming experience and applications, such as automatic storage system or autonomous carriers.

1

1.1.1 High performance wireless technology

- 10/100/1000/Base-T
- Auto detects transmission speed
- Auto-MDI/MDI-X
- 802.11 a/b/g/n/ac, up to 866 Mbps
- Supports fast roaming (personal network)

1.1.2 Good reliability and design optimization


- Redundant dual DC power input
- One set of digital input (DI)
- One set of alarm output (DO)

1.1.3 Robust design for industrial hardware

- Operating temperature: -10~60°C
- Storage temperature: -40~85°C
- Humidity: 5%~95% (non-condensing)
- Metal case: IP40

1

1.1.4 Product profile and dimensions



| No | Description |
|----|-----------------|
| 1 | LED indicator |
| 2 | Antenna socket |
| 3 | Signal strength |
| 4 | Ethernet port |
| 5 | RS-485 port |
| 6 | RS-232 port |
| 7 | Power terminal |
| 8 | Reset button |

1.2 LED indicator


| LED | Color | Status | Description |
|---------------------|-------|----------|--|
| PWR1/PWR2 | Green | On | The device is powered up |
| | | Off | The device is not powered up |
| RS-232 | Green | Blinking | Data transmission |
| | | Off | No data transmission |
| RS-485 | Green | Blinking | Data transmission |
| | | Off | No data transmission |
| DI/ALARM | Red | On | Closed relay |
| | | Off | Disconnect relay |
| | Green | On | Valid digital input (DI) |
| | | Off | No digital input (DI) |
| | | Blinking | Relay closed and DI occurs simultaneously |
| Signal light | Green | On | Lighting 1-3 lights based on signal strength |
| | | Off | No network signal |

1.3 Installation


1.3.1 DIN-rail mounting

Attach the back trench of the device to the mounting rail in arrow ① direction and push the device against the rail in arrow ② direction. To disassemble, first push down the device in arrow ① direction and follow arrow ③ direction to push out the device.

1



1.3.2 Wall mounting




1.3.3 Wiring the redundant power input


The DVW-W01I2-E1 is equipped with one to two sets of DC input (PWR1 / PWR2). Both sets of DC input can be connected to a wide range of power sources (12 to 48VDC). When one power source fails, the other source can work as a backup to ensure that the machine operates normally.

Step 1: Detach the terminal block from DVW-W01I2-E1 and insert the negative and positive DC wires into the terminal block. Make sure that the positive DC wire is connected to V1+ or V2+, and that the negative DC wire is connected to 0V.

Step 2: To prevent the loose DC wires, tighten the wire clamp screws on the terminal block with the flat-blade screwdriver.




Note: Please use copper wire 60/75°C, AWG 28-14; screw torque is 2.2kgf-cm (1.91 in-lbs)



1.3.4 Wiring the alarm contact


The DVW-W01I2-E1 is equipped with one to two sets of alarm output. The alarm contact is a dry relay. Under normal mode of operation, the contact is in “OPEN” circuit; when one of the two power sources fails or communication is interrupted, the contact will change to a “CLOSED” circuit. The relay can be connected up to 1A/24VDC power source.

1





1.3.5 Wiring the digital input

The DVW-W01I2-E1 is equipped with one to two sets of digital input. When input voltage is between 0 to 5V, the state of DI is OFF; input voltage between 11 to 30V, the state of DI is ON. The maximum input current is 6mA.





1.3.6 Pin definition








RS-232 & RS485

| Pin no. | RS-232 | | Pin no. | RS-485 | |
|---------|--------|---|---------|--------|---|
| 1 | RX |  | 1 | D+ |  |
| 2 | TX | | 2 | D- | |
| 3 | SG | | 3 | SG | |
| 4 | RTS | | | | |
| 5 | CTS | | | | |


Ethernet port (RJ45) & power input

| Ethernet port (RJ45) | | | | | | | | Power input | |
|----------------------|-----|---|-----|---|-----|---|-----|--|---|
| 1 | TX+ | 2 | TX- | 3 | RX+ | 4 | N/C |  |  |
| 5 | N/C | 6 | RX- | 7 | N/C | 8 | N/C | | |

Interface

| Category | Terminal | Explanation | |
|----------|--|--|--|
| Power |  | Power ground where two grounds interconnect | |
| |  PWR1 | Power 1 | <ul style="list-style-type: none"> Input voltage: DC 12V~24V, +/- 20%; Power consumption in normal operation: 2.5W; Reverse voltage protect; |
| |  PWR2 | Power 2 | <ul style="list-style-type: none"> Dual redundant power supply, the device will automatically match to the higher voltage side and disconnect from the lower voltage side |
| I/O |  DI | DI: <ul style="list-style-type: none"> Input type: DC (sourcing or sinking) Input current: 24V : 5ma Max. input frequency: 1KHZ Input impedance: 5.6K | |
| |  ALARM | DO: Contact rating: DC24V: 2A, AC125V: 0.5A, AC220V: 0.2A | |
| ANT1 |  ANT1 | Wi-Fi antenna, external thread connector (male) Internal diameter: 4.45mm External diameter (thread excluded): 5.32mm External diameter: 6.26mm | |
| RST |  RST | Press less than 3 seconds: restart the device Press longer than 6 seconds: restore to default | |

1.3.7 Wiring



1.4 Package checklist

The package contains the following accessories:

- Delta industrial wireless DVW-W01I2-E1 series x1
- Instruction sheet x1
- SMA antenna x 2
- Wall mount metal accessory x1
- Screws x4



Attention

Each released DVW-W01I2-E1 contains accessories that are listed above. When you receive the product, please open the package and check for any missing or broken accessories. For any enquiries, do contact our local distributors.

MEMO

1

Chapter 2 User Interface and Application

Table of Contents

| | | |
|------------|---|------------|
| 2.1 | Configuration | 2-2 |
| 2.2 | Connection and access settings..... | 2-2 |
| 2.3 | IExplorer..... | 2-4 |
| 2.3.1 | Device connection and detection | 2-4 |
| 2.4 | General configurations | 2-4 |
| 2.4.1 | AP mode setup | 2-4 |
| 2.4.2 | Client mode setup | 2-6 |
| 2.4.3 | MODBUS Slave Gateway | 2-8 |
| 2.4.4 | MODBUS Master Gateway | 2-10 |
| 2.4.5 | Serial Server (TCP/UDP Client) | 2-11 |
| 2.4.6 | Transparent (TCP Server) | 2-12 |
| 2.4.7 | Serial server (TCP client) + Transparent (TCP server) | 2-14 |
| 2.4.8 | Virtual COM | 2-15 |
| 2.4.9 | Wi-Fi Roaming (One Roaming) | 2-17 |

2.1 Configuration



Before using DVW-W01I02-E1 series, please pay attention to the following item preparation.

| No | Item | Description |
|----|--------------|--|
| 1 | PC | Contains Windows operating system and web browsers. |
| 2 | Power supply | Supports 12-48V with output power larger than 2.5W. |
| 3 | Cable | Includes 5 types of twisted pair as communication cables of DVW-W01I02-E1. |

2.2 Connection and access settings


1. The DVW-W01I02-E1 series and PC connects to RJ45 port through using web-based Ethernet for parameter settings.



2. When PC and DVW device connection is complete, continue configuring the PC's IP address.
 - 1) Click the start button , then click the control panel to open network connection.
 - 2) In Network and Sharing Center, check the network connections.
 - 3) Right-click the connection for modification, then click Attribute. When the UAC  appears as a reminder, please type in the user password for confirmation.
 - 4) Click Network. Under this option, select Internet Protocol Version 4 (TCP / IPv4) or Internet Protocol Version 6 (TCP / IPv6), then click Attribute.



- 5) Manually configure the local IP address. Since the default IP address is 192.168.1.5 for router settings, the subnet mask is 255.255.255.0, therefore, the local IP on PC can be set anywhere between 192.168.1.1 to 254 excluding 192.168.1.5 and with no repeating IPs. We setup the IP address as 192.168.1.10, the default gateway is 192.168.1.5, select an available DNS address or configuring to 192.168.1.5.



- 6) Open browser (e.g. IE) then type in default IP address **192.168.1.5** and click enter. The following log-in page appears for users to enter the correct username and password (Default setting: admin/password).

- ☐ **Username:** admin
☐ **Password:** password



2.3 IEXplorer

IEXplorer can search for DVW-W01I2-E1 products to help you understand the basics of your device.

2.3.1 Device connection and detection

After starting IEXplorer, it will automatically search the list of supported IEXplorer devices on the network. The device name, model, IP address,


MAC address, firmware version, serial number, users can easily and quickly know the information of those devices and devices on the network. Also use the mouse to connect

Tap the device name on the list to open the device's settings webpage (only DVS, DVW devices are supported).

2.4 General configurations

2.4.1 AP mode setup

In AP mode, the access point serves as intermediate point between devices for wired or wireless connection and data transmission.



Configuration procedures

1. Set all IP addresses in the same segment.

- Log in the DVW wireless device page on the PC, the default IP is 192.168.1.5. Username and password by default is admin/password.




Please Login

User Name

Password

- From WLAN2.4G listed on the menu, select Operation Mode, choose AP mode and click Apply.



Operation Mode

RF ☒ Enabled ☐ Disabled

Operation Mode

Region

- Select Basic Configuration and setup SSID name as well as WPA2-PSK for security mode (recommended), then click Apply.



Basic Configuration

Operation Mode

RF Type

Channel

Bandwidth

SSID

SSID Broadcast ☒ Enabled ☐ Disabled

Security Mode

- For wireless client, search for DVW SSID (SlimWiFi_B4F8) in the AP list and click to complete on-line data transmission via wireless connection.



2.4.2 Client mode setup

When users have two DVW devices, one uses AP mode and the other as client mode, both are combined via wireless connection. However, only LAN connection can be used in client mode but not wireless devices or connections.



Configuration procedures

1. Set all IP addresses in the same segment.
2. AP mode: please refer to section 2.3.1.
3. Client mode: Log in the wireless client device page on PC through default IP setting 192.168.1.6. Username and password by default is admin/password.

Please Login

User Name

Password

4. From WLAN2.4G listed on the menu, select Operation Mode, choose Client mode and click Apply.

- System
- Basic Configuration
- Serial Configuration
- WLAN 2.4G
 - Operation Mode
 - WLAN 2.4G
- WLAN 5G
- Auto Warning Settings
- Maintenance

Operation Mode

Cancel
Apply

RF ☒ Enabled ☐ Disabled

Operation Mode

Region

5. Select Basic Configuration and click “Site Survey”.

- System
- Basic Configuration
- Serial Configuration
- WLAN 2.4G
 - Operation Mode
 - WLAN 2.4G
- WLAN 5G
- Auto Warning Settings
- Maintenance

Basic Configuration

Cancel
Apply

Operation Mode

RF Type

Channel

Bandwidth

SSID

EXTAP ☐ Enabled ☒ Disabled


Security Mode

Client Mode


6. Select the configured AP SSID (e.g. SlimWiFi_4456). When SSID cannot be found, please click “Refresh”.

| Refresh | | Back | | | | | |
|---------|---------------|-------------------|---------|---------------|--------|-----------|--|
| No. | SSID | MAC Address | Channel | Security Mode | Signal | RSSI(dBm) | |
| 1 | SlimWiFi_4456 | 00:33:22:33:44:56 | 1 | WPA2-PSK | 91/94 | -18 | |
| 2 | DELTA_11NG | 00:18:23:12:C8:20 | 6 | OPEN | 94/94 | -25 | |
| 3 | Delta-612C | A0:AB:18:85:61:2C | 1 | WPA/WPA2-PSK | 94/94 | -40 | |
| 4 | Delta-IoT | 6C:FA:89:08:48:86 | 11 | OPEN | 93/94 | -70 | |
| 5 | Delta-Quest | 6C:FA:89:08:48:82 | 11 | OPEN | 92/94 | -76 | |

7. Type in the password for AP setting and click APPLY to complete Client and AP connection.




8. When connection is complete, select Ping under Maintenance. Then, type in destination IP to test the connection. For successful connection, the AP Ping response time appears. (See below)



2.4.3 MODBUS Slave Gateway

This function is that the MODBUS protocol on the serial port can be converted into MODBUS TCP protocol through the DVW gateway function, and data exchange can be performed with the MODBUS TCP Client device through wireless transmission. The following is a setting example.



Configuration procedures

● WiFi wireless configuration

- 1. Set all IP addresses in the same segment.
- 2. Configure the DVW to be in AP+Client mode. For details, see [2.3.1 AP Mode Configuration](#). [2.3.2 Client Mode Configuration](#).


● Device Configuration

- 1. Set the RS485 of the PLC to MODBUS Slave mode, 9600/7/E/1/ASCII, Slave ID: 1, and connect to the DVW serial port.
- 2. Set the HMI to MODBUS TCP Client, IP: 192.168.1.10

● MODBUS Slave gateway configuration

- 1. The PC logs into the DVW IP 192.168.1.5 device web interface.
- 2. Click Serial Configuration > MODBUS Gateway in the menu.

- MODBUS gateway function: Select MODBUS ASCII Slave.


**Note:**


The DVW gateway configuration is determined by the serial port. For example, if the PLC is Slave, the DVW gateway must be set to MODBUS Slave.

- RS485 : 9600/7/E/1
- Slave ID mapping: Slave ID range 1-20, Map ID range 1-20, external Slave ID: 1 can be mapped to the serial port Slave ID: 1



- 3. The HMI is set to MODBUS TCP Client, the MODBUS TCP Server IP address is specified as DVW IP 192.168.1.6, and the Slave ID is set to 1. The Map ID of the gateway is directed to the mapped Slave ID 1, which can complete the connection for data exchange.




**Slave ID mapping description**

This function works when DVW uses RS232/RS485 at the same time and ID is 1-20. You can use Slave ID mapping and set the following Slave ID mapping table to map from the external Master's MODBUS TCP ID to all Slave devices under the serial port

For example:

- 1. The Master needs to exchange data with the RS232 Slave ID20, and must use 40 in the MODBUS TCP ID.

2. The Master needs to exchange data with RS485 Slave ID1, and must use 1 in MODBUS TCP ID.




3. The Slave ID mapping table is set as follows

| | Slave ID Range | | Map ID Range | |
|-------|--|----|--|----|
| | DVW serial port Slave ID range setting | | Slave ID range of external MODBUS TCP Client connection, corresponding to Slave ID range | |
| RS485 | 1 | 20 | 1 | 20 |
| RS232 | 1 | 20 | 20 | 40 |

2.4.4 MODBUS Master Gateway

This function is that the MODBUS protocol on the serial port can be converted into MODBUS TCP protocol through the DVW gateway function, and data exchange can be performed with the MODBUS TCP Server device through wireless transmission. The following is a setting example.



Configuration procedures

● WiFi wireless configuration

1. Set all IP addresses in the same segment.
2. Configure the DVW to be in AP+Client mode. For details, see [2.3.1 AP Mode Configuration](#). [2.3.2 Client Mode Configuration](#).

● Device Configuration

1. Set the RS485 of the HMI to MODBUS Master Mode, 9600/7/E/1/ASCII, Slave ID: 1, and connect to the DVW serial port.
2. Set the PLC to MODBUS TCP Server, IP address 192.168.1.10, port 502.

● MODBUS Master Gateway Configuration

1. PC login DVW IP: 192.168.1.5 device web interface.
2. Click Serial Configuration > MODBUS Gateway in the menu.
 - MODBUS gateway function: Select MODBUS ASCII Master.

■ RS485 configuration: 9600/7/E/1

■ Forwarding table settings:


1. Station ID: 10 (Slave ID of Master)
2. Map destination slave ID: 1 (Slave device Slave ID)
3. Destination IP: 192.168.1.10 (IP address of the slave device)
4. Destination TCP port: 502

| No. | Enabled | Station ID | Map destination station ID | Destination IP | Destination Port |
|-----|-------------------------------------|------------|----------------------------|----------------|------------------|
| 1 | <input checked="" type="checkbox"/> | 10 | 1 | 192.168.1.10 | 502 |
| 2 | <input type="checkbox"/> | | | | 502 |
| 3 | <input type="checkbox"/> | | | | 502 |
| 4 | <input type="checkbox"/> | | | | 502 |
| 5 | <input type="checkbox"/> | | | | 502 |

3. Enable data exchange on the HMI side, and you can start data exchange with the remote PLC through the WiFi wireless network.

2.4.5 Serial Server (TCP/UDP Client)

The function is that when DVW is used as the TCP/UDP Client, the DVW serial port data can be wrapped into TCP/UDP packets and forwarded to the remote TCP server device, which can be used for any serial port custom protocol. The following example shows that the TCP client uses the RS485 serial port to perform data exchange with the remote TCP server.



Configuration procedures

- **WiFi wireless configuration**
 1. Set all IP addresses in the same segment.
 2. Configure the DVW to be in AP+Client mode. For details, see [2.3.1 AP Mode Configuration](#). [2.3.2 Client Mode Configuration](#).
- **Device Configuration**
 1. Set the RS485 port of the TCP client device to 9600/8/N/1/ASCII and connect the DVW serial port.
 2. Connect the TCP server device to another DVW by using the network route and configure the IP network segment to be in the same network segment as the TCP client.

● Serial server configuration


1. PC login DVW IP: 192.168.1.5 device web interface.
2. Click Serial Configuration > Serial Server > RS485 on the menu
 - Mode : TCP client
 - RS485 setting: 9600/8/N/1/ASCII, which needs to be the same as the serial port device
 - Destination IP address/port: 192.168.1.11/8000



3. The serial port device sends data to the RS-485, and the TCP server receives the data.

2.4.6 Transparent (TCP Server)

The function is that when DVW is used as the TCP/UDP server, the DVW serial data can be wrapped into TCP/UDP packets and forwarded to the remote TCP client device, which can be used for any serial port custom protocol. The following example shows an example of how the TCP server uses the RS485 serial port and the remote TCP client for data exchange.



Configuration procedures

● WiFi wireless configuration

1. Set all IP addresses in the same segment.
2. Configure the DVW to be in AP+Client mode. For details, see [2.3.1 AP Mode Configuration](#). [2.3.2 Client Mode Configuration](#).

● Device Configuration

1. Set the TCP client device IP to 192.168.1.11 and the port to 8000 and connect to DVW with Ethernet port.
2. Connect the TCP server device to the other DVW with a serial port and configure it to 9600/8/N/1, and set the DVW IP to 192.168.1.5.

● Transparent configuration

1. PC login DVW IP: 192.168.1.5 device web interface.
2. Click Serial Configuration > Serial Server > RS485 on the menu
 - Mode : TCP server
 - TCP port : 8000


- RS485 communication format: 9600/8/N/1



3. The TCP client device needs to set the TCP server IP address 192.168.1.5 and port: 8000 to transfer the data to the DVW to connect to the serial device.

2.4.7 Serial server (TCP client) + Transparent (TCP server)

Two DVWs can be used to set the serial port server (TCP client) and transparent transmission (TCP server) for data exchange and can be used for any serial port custom protocol. The following describes an example of how the TCP server uses the RS485 serial port to encapsulate the TCP packet and the remote TCP client connection.



Configuration procedures

● WiFi wireless configuration

1. Set all IP addresses in the same segment.
2. Configure the DVW to be in AP+Client mode. For details, see [2.3.1 AP Mode Configuration](#). [2.3.2 Client Mode Configuration](#).

● Device Configuration

1. Connect the TCP client device's serial port to the DVW and configure it as 9600/7 / E / 1 / ASCII
2. Connect the serial port of the TCP server device to the DVW and configure it as 9600/7 / E / 1 / ASCII

● TCP client (serial server) configuration

1. PC login DVW IP: 192.168.1.6 device web interface.
2. Click Serial Configuration > Serial Server > RS485 on the menu
 - Mode: TCP client mode
 - RS485 communication format: 9600/7 / E / 1
 - Destination IP address: 192.168.1.6, port: 8000

● Transparent configuration


1. PC login DVW IP: 192.168.1.5 device web interface.
2. Click Serial Configuration > Serial Server > RS485 on the menu
 - Mode : TCP server
 - TCP port : 8000

- RS485 communication format: 9600/8/N/1



2.4.8 Virtual COM

In Virtual COM mode, DVW series can establish a network connection between the host computer and serial device. When the application on host computer doesn't provide serial interface to connect with serial device, then Virtual COM mode can solve this problem and establish a Virtual COM connection on Ethernet interface.



Configuration procedures

● WiFi wireless configuration

1. Set all IP addresses in the same segment.
2. Configure the DVW to be in AP+Client mode. For details, see [2.3.1 AP Mode Configuration](#). [2.3.2 Client Mode Configuration](#).

● Device Configuration

1. Connect the TCP Server device's serial port to the DVW and configure it as 9600/7 / E / 1 / ASCII


● TCP client (serial server) configuration

1. PC login DVW IP: 192.168.1.6 device web interface.
2. Click Serial Configuration > Serial Server > RS485 on the menu
 - Mode: TCP Server mode
 - RS485 communication format: 9600 / 7 / E / 1
 - TCP port: 8888


+ VirtualCOM configuration

1. Use IEXplorer to establish a virtual COM port on the PC
 - COM Port: COM22 (Select a COM port that has not been used)
 - IP Address: 192.168.1.6
 - Listen Port: 8888


- Module Name:1234 (Any name)



2. Press O33K, you can successfully establish the virtual serial port COM22




3. Use Delta PLC tool ISPSOft to set the created virtual serial port ELTIMA Virtual Serial Port (COM22) in the communication port, and upload and download from this communication port.



2

2.4.9 Wi-Fi Roaming (One Roaming)

The DVW Client supports roaming between multiple APs. It uses Delta One Roaming technology to quickly switch wireless networks between different APs to maintain uninterrupted communication between devices. This function is mainly used in AGV scenes. The following is a setting example.



Configuration procedures

● WiFi wireless configuration

■ AP Mode:

1. PC login DVW IP: 192.168.1.1 ~ 192.168.1.5 device web interface.
2. Click WLAN 5G Manager> Operation Mode on the menu
 - ☐ RF: enabled
 - ☐ Operation mode: AP
 - ☐ Region: Location of selected equipment

3. Click WLAN 5G Manager> WLAN 5G> Basic Wireless Configuration in the menu, and set the basic wireless configuration of all APs to the same.

Note



- + If each AP uses the same channel setting, it can achieve the best roaming switching speed of about 150ms, but if each AP uses different channels (up to three different channels are set), the roaming switching speed is about 320ms, but it can achieve AP signals without interference purpose.
- + When the AP is set up in the factory, if the original standard antenna is used, the recommended distance between the AP and the AP should be less than 50m to achieve the best wireless coverage.

■ Client mode:

1. PC login DVW IP: 192.168.1.6
2. Click WLAN 5G Manager in the menu> Operation Mode
 - ☐ RF: Enable
 - ☐ Operation mode: Client mode
 - ☐ Region: Location of selected equipment

The screenshot shows the 'WLAN 5G' configuration menu on the left. The 'Operation Mode' sub-menu is selected. The main panel displays the 'Operation Mode' configuration with the following settings:

- RF: ☒ Enabled ☐ Disabled
- Operation Mode: Client
- Region: Europe

3. Click WLAN 5G Manager in the menu> WLAN 5G> Basic Wireless Configuration, and click "Site survey"

The screenshot shows the 'Basic Configuration' sub-menu selected. The 'Site Survey' button is visible. The configuration settings are as follows:

- Operation Mode: Client
- RF Type: ACN Model
- Channel: 36
- Bandwidth: 80M
- SSID: 54878
- EXTAP: ☒ Enabled ☐ Disabled
- WMM: ☒ (Please enable wmm when AP is in N only mode, or the connection will be failure)
- Security Mode: WPA2-PSK(AES)
- Security Policy (WPA2-PSK): Password: 12345678 (8-63 characters or 64 hex digits)

4. Click the SSID(54878) to be connected

| No. | SSID | MAC Address | Channel | Security Mode | Signal | RSSI(dBm) |
|-----|-------|-------------------|---------|---------------|--------|-----------|
| 1 | 54878 | 00:33:22:33:44:55 | 36 | WPA2-PSK | 945H | -33 |
| 2 | 54878 | 00:18:23:32:84:F9 | 36 | WPA2-PSK | 945H | -33 |
| 3 | GGG | 00:18:23:12:C5:8A | 48 | WPA2-PSK | 085H | -70 |

5. Set the key and enable the roaming mode and roaming configuration. The recommended configuration is as follows. Finally, click Apply. The DVW LED signal light is on to complete the connection.

The screenshot shows the 'Scan Policy' configuration interface. The settings are as follows:

- Scan Policy: Period Scanning or Signal Change Scanning
- Scan Channels(The channels with * are DFS channels): 36
- Scan Time(10~200ms): Not Scanning
- Scan Period(1000~300000ms): Not Scanning
- Scan Threshold(-95~0 dBm): 50
- Roaming Signal Difference(5~20 dBm): 2000
- Roaming Threshold(-95~0 dBm): -20
- Roaming Detect Period(50~300000ms): 5
- Roaming Threshold(-95~0 dBm): -55
- Roaming Detect Period(50~300000ms): 1000

Notes: Client will begin scanning when the signal of current AP is lower than "Scan Threshold", when it get new AP and the signal of current AP is lower than "Roaming Threshold", roaming start.

Note

- The system automatically sets the scanning channel to the channel of the AP you selected. If other APs are on the same channel, you do not need to set other scanning channels. If the channel of the AP is between 2-3 different channels, please select the working channel in the two drop-down boxes below. If there are more than 3 channels, directly change the first setting to automatic.
- The "roaming threshold" is set according to the method of step 2. The "scanning threshold" must be greater than the "roaming threshold", and the difference between the two is generally greater than or equal to the "roaming signal difference" value.
- Using a wireless network scanning tool, test the signal strength of each path near the midpoint between two APs. After recording the signal strength values of all the center points, you can calculate the average value. The value is the roaming threshold; if the value of each center point is very large, you may consider adjusting the location of the AP deployment, or removing factors that interfere with signal transmission, or replanning the path. The scanning tool can use wirelessmon.



Chapter 3 Function Guide

Table of Contents

| | | |
|------------|------------------------------------|-------------|
| 3.1 | System | 3-3 |
| 3.1.1 | System configuration | 3-3 |
| 3.1.2 | System CPU status | 3-3 |
| 3.2 | Basic configuration..... | 3-4 |
| 3.2.1 | System information | 3-4 |
| 3.2.2 | Network configuration | 3-5 |
| 3.3 | Serial configuration | 3-6 |
| 3.3.1 | MODBUS gateway..... | 3-6 |
| 3.3.2 | Serial server | 3-14 |
| 3.3.3 | Transparent server | 3-19 |
| 3.3.4 | MODBUS cache table..... | 3-22 |
| 3.4 | WLAN management - 2.4G..... | 3-26 |
| 3.4.1 | Operation mode | 3-26 |
| 3.4.2 | WLAN 2.4G..... | 3-27 |
| 3.5 | WLAN management - 5G..... | 3-31 |
| 3.5.1 | Operation mode | 3-31 |
| 3.5.2 | WLAN 5G..... | 3-32 |
| 3.6 | Advance..... | 3-36 |
| 3.6.1 | SNMP Configuration | 3-36 |
| 3.6.2 | Packet Control..... | 3-38 |
| 3.7 | Auto Warning Setting | 3-40 |
| 3.7.1 | SysLog..... | 3-40 |
| 3.7.2 | E-mail Alarm..... | 3-42 |
| 3.7.3 | SNMP Trap | 3-43 |
| 3.7.4 | Relay Alarm | 3-44 |
| 3.8 | Management Access | 3-45 |
| 3.8.1 | SSH Configuration | 3-45 |

| | | |
|-------------|-------------------------------------|-------------|
| 3.8.2 | Telnet Configuration | 3-45 |
| 3.9 | Monitoring | 3-46 |
| 3.9.1 | Email Alarm Table | 3-46 |
| 3.9.2 | Relay Alarm Table | 3-46 |
| 3.9.3 | Trap Alarm Table | 3-46 |
| 3.9.4 | Network Connection Status | 3-46 |
| 3.9.5 | AP Client List | 3-47 |
| 3.9.6 | DHCP Client List | 3-47 |
| 3.9.7 | Serial Port Status | 3-47 |
| 3.9.8 | Serial Port Statistics | 3-48 |
| 3.9.9 | Serial Port Error | 3-48 |
| 3.9.10 | Serial Port Log | 3-48 |
| 3.10 | Maintenance | 3-48 |
| 3.10.1 | Session timeout | 3-48 |
| 3.10.2 | Password | 3-49 |
| 3.10.3 | System log backup | 3-49 |
| 3.10.4 | Roaming log | 3-49 |
| 3.10.5 | Serial log | 3-50 |
| 3.10.6 | Ping | 3-51 |
| 3.10.7 | Ping detection | 3-51 |
| 3.10.8 | Firmware upgrade | 3-51 |
| 3.10.9 | Configuration Import & Export | 3-51 |
| 3.10.10 | Load factory default | 3-52 |
| 3.10.11 | Log off | 3-52 |

3.1 System

The main display focuses on DVW-W01I2-E1 series present system information and CPU status.

3.1.1 System configuration

Displays information which can be categorized into three parts: System Configuration, Device Info and 802.11 Info.

| System Configuration | |
|----------------------|--------------------------------------|
| System Configuration | |
| Model Name | DVW-W01I2-E1 |
| Device Name | 1111111 |
| SN | DVWW100119027777 |
| System Uptime | Thu Aug 15 06:40:57 UTC 2019 |
| Firmware Version | 1.02-20190814 |
| Device Info | |
| MAC Address | 00:33:22:33:44:55 |
| IP Address | 192.168.1.5 |
| IP Subnet Mask | 255.255.255.0 |
| Gateway | |
| 802.11 2.4G Info | |
| Status | Enabled |
| Country | Europe |
| Operation Mode | AP |
| Channel | 1 |
| RF Type | G/N Mixed |
| SSID | SlimWiFi_4456 |
| 802.11 5G Info | |
| Status | Enabled |
| Country | Europe |
| Operation Mode | Client - Connected 00:18:23:32:B4:F9 |
| Channel | 36 |
| RF Type | AC/N Mixed |
| SSID | SlimWiFi_B4F9_5G |
| Serial Information | |
| RS232 RX | 0 |
| RS232 TX | 0 |
| RS485 RX | 0 |
| RS485 TX | 0 |

3.1.2 System CPU status

Displays system's present CPU status which includes running time, total power-on time, CPU usage, total RAM and RAM available. These status values are displayed in grey color and cannot be edited.

System CPU Status

| | |
|---------------------|------------|
| Running Time | 81472.10 s |
| Total Power-on Time | 81472.10 s |
| CPU Usage | 16% |
| Total RAM | 235152 KB |
| RAM Available | 92812 KB |

3.2 Basic configuration

The basic configuration allows users to perform maintenance and setup for DVW-W01I2-E1 series including system information and network.

3.2.1 System information

The configuration contains user-defined device name, location, description and contact information. Through this setup, users can easily and clearly identify each DVW-W01I2-E1 used on the network.

System Information

Cancel

Apply

| | |
|----------------------------|-----------------------------|
| Device Name | DVW-W01I2-E1 |
| Device Location | Europe |
| Device Description | Delta Dual-Band WiFi Router |
| Device Contact Information | |

| Description | Default value |
|---|-----------------------------|
| Device name | |
| Users can define the device name | DVW-W01I2-E1 |
| Device location | |
| Users can define the device location | Europe |
| Device description | |
| Users can provide detailed device description | Delta Dual-Band WiFi Router |
| Device contact information | |
| Users can input contact information of maintenance personnel. | NONE |

3.2.2 Network configuration

Network configuration allows users to setup IP, IP address, IP subnet mask, gateway IP and primary DNS. There are several IP modes available for network configuration. Users can select modes from DHCP-Client, Static and DHCP-Server.

DHCP-Client:

Configure the network as DHCP-Client in DVW-W01I2-E1 series:

- When DHCP server is added for installment, DVW-W01I2-E1 will use the IP address assigned by DHCP server.
- When DHCP server is not added for installment, DVW-W01I2-E1 will auto-configure the IP address to 192.168.1.5 and the IP subnet mask to 255.255.255.0.

Static:

Users can define the device regarding IP, IP address, IP subnet mask, gateway IP and primary DNS.

DHCP-Server:

- When DHCP-Server is installed in DVW-W01I2-E1, DHCP-Server and BOOTP-Server are both enabled and exist in this mode. The IP address is auto-configured to 192.168.1.5 and the IP subnet mask to 255.255.255.0. When end user devices and clients request for IP address, DVW-W01I2-E1 will assign a set of dynamic IP address.
- The gateway IP address provided by DHCP server address pool is from 192.168.1.100 to 192.168.1.250, users are allowed to configure the starting and ending of the IP address pool.

Network Configuration

Cancel
Apply

| | |
|---------------------|--|
| IP | DHCP-Server ▼ |
| IP Address | 192.168.1.5 |
| IP Subnet Mask | 255.255.255.0 |
| Gateway IP | |
| Primary DNS | |
| Starting IP Address | <div style="display: flex; align-items: center; gap: 5px;"> <div style="border: 1px solid #ccc; padding: 2px 10px;">192</div> <div style="border: 1px solid #ccc; padding: 2px 10px;">168</div> <div style="border: 1px solid #ccc; padding: 2px 10px;">1</div> <div style="border: 1px solid #ccc; padding: 2px 10px;">100</div> </div> |
| Ending IP Address | <div style="display: flex; align-items: center; gap: 5px;"> <div style="border: 1px solid #ccc; padding: 2px 10px;">192</div> <div style="border: 1px solid #ccc; padding: 2px 10px;">168</div> <div style="border: 1px solid #ccc; padding: 2px 10px;">1</div> <div style="border: 1px solid #ccc; padding: 2px 10px;">250</div> </div> |

| Description | Default value |
|--|---------------|
| IP Allows different mode configuration, options include DHCP-Client, Static and DHCP-Server DHCP-Client: DVW-W01I2-E1 will use the IP setting from the DHCP-Server. Static: Manually setup the IP address DHCP-Server: DHCP-Server and BOOTP-Server are both enabled and exist in this mode, the DVW-W01I2-E1 will assign a set of dynamic IP address to the end-user device. | Static |

| Description | Default value |
|--|---------------|
| IP address | |
| Configure IP address and identify DVW-W01I2-E1 series in TCP/IP network. | 192.168.1.5 |
| IP subnet mask | |
| Set the IP subnet mask of router LAN ports. (Example: 255.0.0.0 is Type A address; 255.255.0.0 is Type B address; 255.255.255.0 is Type C address) | 255.255.255.0 |
| Gateway IP | |
| Connect DVW-W01I2-E1 to WAN IP gateway. | |
| Primary DNS | |
| Connect DVW-W01I2-E1 to primary DNS in WAN configuration that translates domain names into IP addresses. | 1 day |
| Starting IP address | |
| The starting IP address provided by DHCP server address pool. | 192.168.1.100 |
| Ending IP address | |
| The ending IP address provided by DHCP server address pool. | 192.168.1.250 |

3.3 Serial configuration

DVW-W01I2-E1 contains MODBUS gateway, serial server and transparent transmission functions. The MODBUS gateway function allows data to be transferred from MODBUS to Ethernet and vice versa. While serial server and serial port transparent transmission modules can provide real-time networking to access serial devices at any time or locations.

3.3.1 MODBUS gateway

MODBUS gateway allows DVW device to perform format conversion and data transfer. (Convert Modbus RTU/ASCII to Modbus TCP).

3.3.1.1 RS-485 gateway

● MODBUS ASCII / RTU Slave

In this mode, the DVW series serve as MODBUS TCP server. When the device receives client's MODBUS request, it is packed into MODBUS ASCII/RTU protocol and corresponding serial ports can be confirmed base on the map ID. Also, MODBUS ASCII/RTU master can forward request to slave through DVW series.



For instance, RS-232 serial port slave ID setting range is 1-20, map ID setting range 1-20; while RS-485 serial port slave ID setting range is 1-20 and map ID setting range is 21-40. When users request reading PLC station number 6 data connected via RS-232 through MODBUS network port, the map ID needs to be configured to 6; when reading PLC station number 6 data connected via RS-485 through MODBUS network port, the map ID needs to be configured to 26.

**Attention**

For RS-232 and RS-485, the configured map ID range cannot have repeated regions, because the system forwards the request to serial ports base on the network port of the map ID in the request data.

RS485 MODBUS Gateway

| Cancel | | Apply | |
|---|--|--|--|
| MODBUS Gateway Function <input checked="" type="radio"/> MODBUS ASCII Slave <input type="radio"/> MODBUS RTU Slave <input type="radio"/> MODBUS ASCII Master <input type="radio"/> MODBUS RTU Master <input type="radio"/> Disabled | | RS485 Configuration Data Bit: 7 + Parity Bit: None ▾ Stop Bit: 1 + Baud Rate: 9600 ▾ | |
| | | Others Station ID: 247 (1-247) TCP Keepalive Time: 30 (0-32767 s) Response Timeout: 3000 (0-65535 ms) Retry: 3 (0-10) Modbus Exception: <input checked="" type="radio"/> Enabled <input type="radio"/> Dropped Slave ID Map: Slave ID Range 1 20 (1-247) Map ID Range 21 40 (1-247) | |

| | | | |
|---|--|--|--|
| MODBUS Gateway Function <input type="radio"/> MODBUS ASCII Slave <input checked="" type="radio"/> MODBUS RTU Slave <input type="radio"/> MODBUS ASCII Master <input type="radio"/> MODBUS RTU Master <input type="radio"/> Disabled | | RS485 Configuration Data Bit: 8 + Parity Bit: None ▾ Stop Bit: 1 + Baud Rate: 9600 ▾ | |
| | | Others Station ID: 247 (1-247) TCP Keepalive Time: 30 (0-32767 s) Response Timeout: 3000 (0-65535 ms) Retry: 3 (0-10) Modbus Exception: <input checked="" type="radio"/> Enabled <input type="radio"/> Dropped Slave ID Map: Slave ID Range 1 20 (1-247) Map ID Range 21 40 (1-247) | |

- **MODBUS ASCII / RTU Master**

In this mode, the DVW series serve as MODBUS ASCII/RTU Slave. When the device receives master's MODBUS request, it is packed into MODBUS TCP protocol base on the station ID and the corresponding relationship from the forward table. Also, MODBUS TCP client can forward request to the server through DVW series.



RS485 MODBUS Gateway

| Cancel | | Apply | | | |
|--|--|--|--|---|--|
| MODBUS Gateway Function | | RS485 Configuration | | Others | |
| <input type="radio"/> MODBUS ASCII Slave | | Data Bit <input type="text" value="7"/> | | Station ID <input type="text" value="247"/> (1-247) | |
| <input type="radio"/> MODBUS RTU Slave | | Parity Bit <input type="text" value="None"/> | | TCP Keepalive Time <input type="text" value="30"/> (0-32767 s) | |
| <input checked="" type="radio"/> MODBUS ASCII Master | | Stop Bit <input type="text" value="1"/> | | Response Timeout <input type="text" value="3000"/> (0-65535 ms) | |
| <input type="radio"/> MODBUS RTU Master | | Baud Rate <input type="text" value="9600"/> | | Retry <input type="text" value="3"/> (0-10) | |
| <input type="radio"/> Disabled | | | | Modbus Exception <input checked="" type="radio"/> Enabled <input type="radio"/> Dropped | |

| | | | | | |
|--|--|--|--|---|--|
| MODBUS Gateway Function | | RS485 Configuration | | Others | |
| <input type="radio"/> MODBUS ASCII Slave | | Data Bit <input type="text" value="8"/> | | Station ID <input type="text" value="247"/> (1-247) | |
| <input type="radio"/> MODBUS RTU Slave | | Parity Bit <input type="text" value="None"/> | | TCP Keepalive Time <input type="text" value="30"/> (0-32767 s) | |
| <input type="radio"/> MODBUS ASCII Master | | Stop Bit <input type="text" value="1"/> | | Response Timeout <input type="text" value="3000"/> (0-65535 ms) | |
| <input checked="" type="radio"/> MODBUS RTU Master | | Baud Rate <input type="text" value="9600"/> | | Retry <input type="text" value="3"/> (0-10) | |
| <input type="radio"/> Disabled | | | | Modbus Exception <input checked="" type="radio"/> Enabled <input type="radio"/> Dropped | |

Forward Table

| No. | Enabled | Station ID | Map destination station ID | Destination IP | Destination Port |
|-----|--------------------------|------------|----------------------------|----------------|------------------|
| 1 | <input type="checkbox"/> | | | | 502 |
| 2 | <input type="checkbox"/> | | | | 502 |
| 3 | <input type="checkbox"/> | | | | 502 |
| 4 | <input type="checkbox"/> | | | | 502 |
| 5 | <input type="checkbox"/> | | | | 502 |
| 6 | <input type="checkbox"/> | | | | 502 |
| 7 | <input type="checkbox"/> | | | | 502 |
| 8 | <input type="checkbox"/> | | | | 502 |
| 9 | <input type="checkbox"/> | | | | 502 |
| 10 | <input type="checkbox"/> | | | | 502 |
| 11 | <input type="checkbox"/> | | | | 502 |
| 12 | <input type="checkbox"/> | | | | 502 |
| 13 | <input type="checkbox"/> | | | | 502 |

| Description | | Default value |
|--|--|---------------|
| Operation mode | | |
| Select the roles and operating agreement for present network and serial ports via following options: 1. MODBUS ASCII Slave: The network port for DVW device operates in MODBUS TCP Server mode, the RS-485 serial port operates in MODBUS ASCII master mode. 2. MODBUS RTU Slave: The network port for DVW device operates in MODBUS TCP Server mode, the RS-485 serial port operates in MODBUS RTU master mode. 3. MODBUS ASCII Master: The network port for DVW device operates in MODBUS TCP client mode, the RS-485 serial port operates in MODBUS ASCII slave mode. 4. MODBUS RTU Master: The network port for DVW device operates in MODBUS TCP client mode, the RS-485 serial port operates in MODBUS RTU slave mode. | | Close |
| Configuring RS485 | Data bit | |
| | Displays serial port data bit; the value is fixed to 7 in ASCII protocol, the value is fixed to 8 in RTU protocol. | N/A |
| | Parity bit | |
| | Configuring parity for serial port. Optional values include “none”, “odd” or “even”. | None |
| | Stop bit | |

| Description | | Default value |
|---------------------------|---|---------------|
| | Configuring stop bit for serial port. Optional values include 1 or 2. | 1 |
| | Baud rate Configuring baud rate for serial port. Optional values include 2400, 4800, 9600, 19200, 38400, 57600, 115200. | 9600 |
| Others | Station ID Displays the station ID of the device. The station ID of RS-485 is 247. | N/A |
| | TCP keepalive time Configure DVW device in idle TCP connection to setup TCP keep-alive time. When the time is "0", the connection will stay open. | 30 |
| | Response timeout DVW device waits for serial port response timeout. | 3000 |
| | Retry Setup the number of retry when response time reaches timeout. | 3 |
| | MODBUS exception When device reaches response timeout, exception code may be sent to client. | Enabled |
| | Mapping slave ID Setup slave ID mapping table. -- Slave ID range: Input actual station ID range. -- Map ID range: Input virtual ID range that can be identified by DVW device. Since MODBUS TCP does not contain actual serial port messages, therefore, we use different map ID section to determine each port. Requests need to be set within the map ID range in order to forward to the corresponding serial ports, the station ID will also be converted. | |
| | Enabled Set forward message to enable or not enable. | None |
| Slave mode | Station ID Assign the station ID received from the serial port. | None |
| | Map destination station ID Set the corresponding destination station ID. | None |
| | Destination IP Set the IP address of MODBUS TCP server. | None |
| | Destination TCP port Set the interface for MODBUS TCP server. | 502 |
| | Enabled Set forward message to enable or not enable. | None |
| | Station ID Assign the station ID received from the serial port. | None |
| | Map destination station ID Set the corresponding destination station ID. | None |
| Master mode-Forward table | Destination IP Set the IP address of MODBUS TCP server. | None |
| | Destination TCP port Set the interface for MODBUS TCP server. | 502 |
| | Enabled Set forward message to enable or not enable. | None |
| | Station ID Assign the station ID received from the serial port. | None |
| | Map destination station ID Set the corresponding destination station ID. | None |
| | Destination IP Set the IP address of MODBUS TCP server. | None |
| | Destination TCP port Set the interface for MODBUS TCP server. | 502 |

3.3.1.2 RS-232 gateway

● MODBUS ASCII / RTU Slave

In this mode, the DVW series serve as MODBUS TCP server. When the device receives client's MODBUS request, it is packed into MODBUS ASCII/RTU protocol and corresponding serial ports can be confirmed base on the map ID. Also, MODBUS ASCII/RTU master can forward request to slave through DVW series.



For instance, RS-232 serial port slave ID setting range is 1-20, map ID setting range 1-20; while RS-485 serial port slave ID setting range is 1-20 and map ID setting range is 21-40. When users request reading PLC station number 6 data connected via RS-232 through MODBUS network, the map ID needs to be configured to 6; when reading PLC station number 6 data connected via RS-485 through MODBUS network, the map ID needs to be configured to 26.



Attention

For RS-232 and RS-485, the configured map ID range cannot have repeated regions, because the system forwards the request to serial ports base on the network port of the map ID in the request data.

RS232 MODBUS Gateway

Cancel Apply

| MODBUS Gateway Function | RS232 Configuration | Others |
|---|---|--|
| <input checked="" type="radio"/> MODBUS ASCII Slave <input type="radio"/> MODBUS RTU Slave <input type="radio"/> MODBUS ASCII Master <input type="radio"/> MODBUS RTU Master <input type="radio"/> Disabled | Data Bit: 8 Parity Bit: None Stop Bit: 1 Baud Rate: 9600 | Station ID: 246 (1-247) TCP Keepalive Time: 30 (0-32767 s) Response Timeout: 3000 (0-65535 ms) Retry: 3 (0-10) Modbus Exception: <input checked="" type="radio"/> Enabled <input type="radio"/> Dropped Slave ID Map: Slave ID Range 1-20 (1-247) Map ID Range 1-20 (1-247) |

| MODBUS Gateway Function | RS232 Configuration | Others |
|---|---|--|
| <input type="radio"/> MODBUS ASCII Slave <input checked="" type="radio"/> MODBUS RTU Slave <input type="radio"/> MODBUS ASCII Master <input type="radio"/> MODBUS RTU Master <input type="radio"/> Disabled | Data Bit: 8 Parity Bit: None Stop Bit: 1 Baud Rate: 9600 | Station ID: 246 (1-247) TCP Keepalive Time: 30 (0-32767 s) Response Timeout: 3000 (0-65535 ms) Retry: 3 (0-10) Modbus Exception: <input checked="" type="radio"/> Enabled <input type="radio"/> Dropped Slave ID Map: Slave ID Range 1-20 (1-247) Map ID Range 1-20 (1-247) |

● MODBUS ASCII / RTU Master

In this mode, the DVW series serve as MODBUS ASCII/RTU Slave. When the device receives master's MODBUS request, it is packed into MODBUS TCP protocol base on the station ID and the corresponding relationship from the forward table. Also, MODBUS TCP client can forward request to the server through DVW series.



RS232 MODBUS Gateway

Cancel

Apply

| | | |
|--|---|--|
| <div>MODBUS Gateway Function</div> <div><div><input type="radio"/> MODBUS ASCII Slave</div><div><input type="radio"/> MODBUS RTU Slave</div><div><input checked="" type="radio"/> MODBUS ASCII Master</div><div><input type="radio"/> MODBUS RTU Master</div><div><input type="radio"/> Disabled</div></div> | <div>RS232 Configuration</div> <div><div>Data Bit<div>7 ▾</div></div><div>Parity Bit<div>None ▾</div></div><div>Stop Bit<div>1 ▾</div></div><div>Baud Rate<div>9600 ▾</div></div></div> | <div>Others</div> <div><div>Station ID<div>246 (1~247)</div></div><div>TCP Keepalive Time<div>30 (0~32767 s)</div></div><div>Response Timeout<div>3000 (0~65535 ms)</div></div><div>Retry<div>3 (0~10)</div></div><div>Modbus Exception<div><input checked="" type="radio"/> Enabled <input type="radio"/> Dropped</div></div></div> |
|--|---|--|

| | | |
|--|---|--|
| <div>MODBUS Gateway Function</div> <div><div><input type="radio"/> MODBUS ASCII Slave</div><div><input type="radio"/> MODBUS RTU Slave</div><div><input type="radio"/> MODBUS ASCII Master</div><div><input checked="" type="radio"/> MODBUS RTU Master</div><div><input type="radio"/> Disabled</div></div> | <div>RS232 Configuration</div> <div><div>Data Bit<div>8 ▾</div></div><div>Parity Bit<div>None ▾</div></div><div>Stop Bit<div>1 ▾</div></div><div>Baud Rate<div>9600 ▾</div></div></div> | <div>Others</div> <div><div>Station ID<div>246 (1~247)</div></div><div>TCP Keepalive Time<div>30 (0~32767 s)</div></div><div>Response Timeout<div>3000 (0~65535 ms)</div></div><div>Retry<div>3 (0~10)</div></div><div>Modbus Exception<div><input checked="" type="radio"/> Enabled <input type="radio"/> Dropped</div></div></div> |
|--|---|--|

Forward Table

| No. | Enabled | Station ID | Map destination station ID | Destination IP | Destination Port |
|-----|--------------------------|------------|----------------------------|----------------|------------------|
| 1 | <input type="checkbox"/> | | | | 502 |
| 2 | <input type="checkbox"/> | | | | 502 |
| 3 | <input type="checkbox"/> | | | | 502 |
| 4 | <input type="checkbox"/> | | | | 502 |
| 5 | <input type="checkbox"/> | | | | 502 |
| 6 | <input type="checkbox"/> | | | | 502 |
| 7 | <input type="checkbox"/> | | | | 502 |

| Description | Default value |
|---|---------------|
| <div>Operation mode</div> <div>Select the roles and operating agreement for present network and serial ports via following options:</div> <div>1. MODBUS ASCII Slave: The network port for DVW device operates in MODBUS TCP Server mode, the RS-485 serial port operates in MODBUS ASCII master mode.</div> | Close |

| Description | | Default value |
|--|--|---------------|
| 2. MODBUS RTU Slave: The network port for DVW device operates in MODBUS TCP Server mode, the RS-485 serial port operates in MODBUS RTU master mode. 3. MODBUS ASCII Master: The network port for DVW device operates in MODBUS TCP client mode, the RS-485 serial port operates in MODBUS ASCII slave mode. 4. MODBUS RTU Master: The network port for DVW device operates in MODBUS TCP client mode, the RS-485 serial port operates in MODBUS RTU slave mode. | | |
| | Data bit | |
| | Displays serial port data bit; the value is fixed to 7 in ASCII protocol, the value is fixed to 8 in RTU protocol. | N/A |
| | Parity bit | |
| Configuring RS485 | Set parity bits for serial ports. Optional values include “none”, “odd” or “even”. | None |
| | Stop bit | |
| | Set stop bits for serial ports. Optional values include 1 or 2. | 1 |
| | Baud rate | |
| | Set baud rates for serial ports. Optional values include 2400, 4800, 9600, 19200, 38400, 57600, 115200. | 9600 |
| | | |
| Others | Station ID | |
| | Displays the station ID of the device. The station ID of RS-485 is 247. | N/A |
| | TCP keepalive time | |
| | Configure DVW device in idle TCP connection to setup TCP keep-alive time. When the time is “0”, the connection will stay open. | 30 |
| | Response timeout | |
| | DVW device waits for serial port response timeout. | 3000 |
| | Retry | |
| | Set the number of retry when response time reaches timeout. | 3 |
| | MODBUS exception | |
| | When device reaches response timeout, exception code may be sent to client. | Enabled |
| Slave mode | Mapping slave ID | |
| | Set slave ID mapping table. -- Slave ID range: Input actual station ID range. -- Map ID range: Input virtual ID range that can be identified by DVW device. Since MODBUS TCP does not contain actual serial port messages, therefore, we use different map ID section to determine each port. Requests need to be set within the map ID range in order to forward to the corresponding serial ports, the station ID will also be converted. | |
| Master mode-Forward table | Enabled | |
| | Set forward message to enable or not enable. | None |
| | Station ID | |
| | Assign the station ID received from the serial port. | None |
| | Map destination station ID | |
| | Set the corresponding destination station ID. | None |
| | Destination IP | |
| | Set the IP address of MODBUS TCP server. | None |
| | Destination TCP port | |
| | Set the interface for MODBUS TCP server. | 502 |

3.3.2 Serial server

The function allows DVW series to connect with the assigned server, while also pack serial port data into TCP/UDP and send it to the server for TCP or UDP client.

3.3.2.1 RS-485

In this mode, the DVW series is used as client's serial server of communication via TCP/UDP protocol which can transmit RS-485 data to the serial server.

RS485 Server

| | | | |
|-------------------------|----------------------|--------------|----------------------|
| Mode | TCP Client Mode ▼ | | |
| Baud Rate | 9600 ▼ | | |
| Data Bit | 8 ▼ | | |
| Parity Bit | None ▼ | | |
| Stop Bit | 1 ▼ | | |
| TCP Keepalive Time | 7 | (0-99min) | |
| Destination IP 1 | <input type="text"/> | Port | <input type="text"/> |
| Destination IP 2 | <input type="text"/> | Port | <input type="text"/> |
| Destination IP 3 | <input type="text"/> | Port | <input type="text"/> |
| Destination IP 4 | <input type="text"/> | Port | <input type="text"/> |
| Max Payload Length | 0 | (0-1024) | |
| Minimal Packet Interval | 0 | (0-65535 ms) | |

RS485 Server

Cancel
Apply

| | | | |
|------------|-----------------------|--|--|
| Mode | <div>UDP Mode ▾</div> | | |
| Baud Rate | <div>9600 ▾</div> | | |
| Data Bit | <div>8 ▾</div> | | |
| Parity Bit | <div>None ▾</div> | | |
| Stop Bit | <div>1 ▾</div> | | |

| | Begin Address | End Address | Port |
|------------------|----------------------|----------------------|----------------------|
| Destination IP 1 | <input type="text"/> | <input type="text"/> | <input type="text"/> |
| Destination IP 2 | <input type="text"/> | <input type="text"/> | <input type="text"/> |
| Destination IP 3 | <input type="text"/> | <input type="text"/> | <input type="text"/> |
| Destination IP 4 | <input type="text"/> | <input type="text"/> | <input type="text"/> |

| | |
|-------------------------|-------------------------------|
| Source Port | <div>15000 (1025-65535)</div> |
| Max Payload Length | <div>0 (0-1024)</div> |
| Minimal Packet Interval | <div>0 (0-65535 ms)</div> |

| Description | | Default value |
|---|--|---------------|
| Operation mode | | |
| Select the current operating serial port default to “Close”, other options include: 1. TCP mode: serve as client’s serial server of communication via TCP protocol. 2. UDP mode: serve as client’s serial server of communication via UDP protocol. | | Close |
| Serial communication parameters | Baud rate | |
| | Set baud rates for serial ports. Optional values include 2400, 4800, 9600, 19200, 38400, 57600, 115200. | 9600 |
| | Data bit | |
| | Set data bits for serial ports. Optional values include 7 or 8. | 8 |
| | Parity bit | |
| | Set parity bits for serial ports. Optional values include “none”, “odd” or “even”. | None |
| | Stop bit | |
| | Set stop bits for serial ports. Optional values include 1 or 2. | 1 |
| TCP mode | TCP keepalive time | |
| | Configure idle time of TCP to auto-close TCP connection. Optional values from 0 to 99 minutes. 0: TCP connection will not be closed due to idle (always open) | 7 |

| Description | | Default value |
|-------------|--|---------------|
| | 1~99: When idle time reaches setting value, TCP connection is closed. | |
| | Destination IP and port | |
| | Set connected serial server IP range and port, the IP and port cannot have the same configuration. Max. 4 serial servers for simultaneous connection. | None |
| | Max. payload length | |
| | Set the waiting length of cumulative data for data packet transmission, the range is 0 to 1024 byte; set 0 for immediate data transmission. | 0 |
| | Minimal packet interval | |
| | Set the waiting time to forcing data packet transmission, the range is 0 to 65535 ms; set 0 to permanently avoid forcing of transmission; For data transmission, set range is between 1 to 65535 when the time reaches setting value or cumulative data length reaches the setting length. | 0 |
| UDP mode | Destination IP and port | |
| | Set the connected serial server IP and ports. Maximum of 4 serial servers for simultaneous connection in UDP. Each server IP range supports up to 99 IP address, meaning the max. number of IP between starting and ending IP is 99. The IP and ports cannot have the same configuration. | None |
| | Source port | |
| | Set monitoring source port. | 15000 |
| | Max. payload length | |
| | Set the waiting length of cumulative data for data packet transmission, the range is 0 to 1024 byte; set 0 for immediate data transmission. | 0 |
| | Minimal packet interval | |
| | Set the waiting time to forcing data packet transmission, the range is 0 to 65535 ms; set 0 to permanently avoid forcing of transmission; For data transmission, set range is between 1 to 65535 when the time reaches setting value or cumulative data length reaches the setting length. | 0 |

3.3.2.2 RS-232

In this mode, the DVW series is used as client's serial server of communication via TCP/UDP protocol which can transmit RS-232 data to the serial server.

RS232 Server

Cancel

Apply

| | | | |
|-------------------------|----------------------|--------------|----------------------|
| Mode | TCP Client Mode ▼ | | |
| Baud Rate | 9600 ▼ | | |
| Data Bit | 8 ▼ | | |
| Parity Bit | None ▼ | | |
| Stop Bit | 1 ▼ | | |
| Flow Control | None ▼ | | |
| TCP Keepalive Time | 7 | (0-99min) | |
| Destination IP 1 | <input type="text"/> | Port | <input type="text"/> |
| Destination IP 2 | <input type="text"/> | Port | <input type="text"/> |
| Destination IP 3 | <input type="text"/> | Port | <input type="text"/> |
| Destination IP 4 | <input type="text"/> | Port | <input type="text"/> |
| Max Payload Length | 0 | (0-1024) | |
| Minimal Packet Interval | 0 | (0-65535 ms) | |

RS232 Server

Cancel

Apply

| | |
|--------------|------------|
| Mode | UDP Mode ▼ |
| Baud Rate | 9600 ▼ |
| Data Bit | 8 ▼ |
| Parity Bit | None ▼ |
| Stop Bit | 1 ▼ |
| Flow Control | None ▼ |

| | Begin Address | End Address | Port |
|-------------------------|----------------------|----------------------|----------------------|
| Destination IP 1 | <input type="text"/> | <input type="text"/> | <input type="text"/> |
| Destination IP 2 | <input type="text"/> | <input type="text"/> | <input type="text"/> |
| Destination IP 3 | <input type="text"/> | <input type="text"/> | <input type="text"/> |
| Destination IP 4 | <input type="text"/> | <input type="text"/> | <input type="text"/> |
| Source Port | 16000 (1025-65535) | | |
| Max Payload Length | 0 (0-1024) | | |
| Minimal Packet Interval | 0 (0-65535 ms) | | |

| Description | | Default value |
|---|---|---------------|
| Operation mode | | |
| Select the present operating serial port default to "Close", other options include: 1. TCP mode: serve as client's serial server of communication via TCP protocol. 2. UDP mode: serve as client's serial server of communication via UDP protocol. | | Close |
| Serial communication parameters | Baud rate | |
| | Set baud rates for serial ports. Selected values include 2400, 4800, 9600, 19200, 38400, 57600, 115200. | 9600 |
| | Data bit | |
| | Set data bits for serial ports. Optional values include 7 or 8. | 8 |
| | Parity bit | |
| | Set parity bits for serial ports. Optional values include "none", "odd" or "even". | None |
| | Stop bit | |
| | Set stop bits for serial ports. Optional values include 1 or 2. | 1 |

| Description | | Default value |
|-------------|--|---------------|
| TCP mode | Flow Control | |
| | Set types of flow control. Optional values include "XON/XOFF", "RTS/CTS". | None |
| | TCP keepalive time | |
| | Configure idle time of TCP to auto-close TCP connection. Optional values from 0 to 99 minutes. 0: TCP connection will not be closed due to idle (always open) 1~99: When idle time reaches setting value, TCP connection is closed. | 7 |
| | Destination IP and port | |
| | Set connected serial server IP range and port, the IP and port cannot have the same configuration. Max. 4 serial servers for simultaneous connection. | None |
| | Max. payload length | |
| | Set the waiting length of cumulative data for data packet transmission, the range is 0 to 1024 byte; set 0 for immediate data transmission. | 0 |
| | Minimal packet interval | |
| | Set the waiting time to forcing data packet transmission, the range is 0 to 65535 ms; set 0 to permanently avoid forcing of transmission; For data transmission, set range is between 1 to 65535 when the time reaches setting value or cumulative data length reaches the setting length. | 0 |
| UDP mode | Destination IP and port | |
| | Set the connected serial server IP and ports. Maximum of 4 serial servers for simultaneous connection in UDP. Each server IP range supports up to 99 IP address, meaning the max. number of IP between starting and ending IP is 99. The IP and ports cannot have the same configuration. | None |
| | Source port | |
| | Set monitoring source port. | 16000 |
| | Max. payload length | |
| | Set the waiting length of cumulative data for data packet transmission, the range is 0 to 1024 byte; set 0 for immediate data transmission. | 0 |
| | Minimal packet interval | |
| | Set the waiting time to forcing data packet transmission, the range is 0 to 65535 ms; set 0 to permanently avoid forcing of transmission; For data transmission, set range is between 1 to 65535 when the time reaches setting value or cumulative data length reaches the setting length. | 0 |

3.3.3 Transparent server

In this mode, the DVW device serves as TCP servers that receives data packet from assigned ports and transmits to RS-485 or RS-232 serial ports without any processing.

3.3.3.1 RS-485 transparent server

RS485 Transparent Server

Cancel
Apply

| | | |
|------------|--------------|--------------|
| Mode | TCP Server ▼ | |
| TCP Port | 12580 | (1025~65535) |
| Baud Rate | 9600 ▼ | |
| Data Bit | 8 ▼ | |
| Parity Bit | None ▼ | |
| Stop Bit | 1 ▼ | |

| Description | Default value |
|--|---------------|
| Operation mode | |
| Select present operating serial port mode from the following options: 1. TCP server: as TCP server, create connection once receive client host request then client host and DVW device can start data transmission. 2. Close: close transparent server function. | Close |
| TCP port | |
| Set the port for TCP Server monitoring data packet. | 12580 |
| Baud rate | |
| Set baud rates for serial ports. Optional values include 2400, 4800, 9600, 19200, 38400, 57600, 115200. | 9600 |
| Data bit | |
| Set data bits for serial ports. Optional values include 7 or 8. | 8 |
| Parity bit | |
| Set parity bits for serial ports. Optional values include “none”, “odd”or “even”. | None |
| Stop bit | |
| Set stop bits for serial ports. Optional values include 1or 2. | 1 |

3.3.3.2 RS-232 transparent server

RS232 Transparent Server

Cancel Apply

Mode TCP Server ▼

TCP Port 12581 (1025~65535)

Baud Rate 9600 ▼

Data Bit 8 ▼

Parity Bit None ▼

Stop Bit 1 ▼

Flow Control None ▼

| Description | Default value |
|--|---------------|
| Operation mode | |
| Select present operating serial port mode from the following options: 1. TCP server: as TCP server, create connection once receive client host request then client host and DVW device can start data transmission. 2. Close: close transparent server function. | Close |
| TCP port | |
| Set the port for TCP Server monitoring data packet. | 12581 |
| Baud rate | |
| Set baud rates for serial ports. Optional values include 2400, 4800, 9600, 19200, 38400, 57600, 115200. | 9600 |
| Data bit | |
| Set data bits for serial ports. Optional values include 7 or 8. | 8 |
| Parity bit | |
| Set parity bits for serial ports. Optional values include "None", "odd" or "even". | None |
| Stop bit | |
| Set stop bits for serial ports. Optional values include 1 or 2. | 1 |
| Flow control | |
| Set types of flow control. Optional values include "XON/XOFF", "RTS/CTS". | None |

3.3.4 MODBUS cache table

Since the transmission speed of Ethernet interface is faster than that of serial ports, therefore, when Ethernet devices send requests to serial devices, more time is required for waiting serial port data. MODBUS cache table provides PLCs with relevant configuration information (e.g. station ID, MODBUS IP). The DVW device can send request to receive serial port device data based on prior MODBUS cache table. When Ethernet devices requests for transmission to DVW device, DVW can immediately respond to data. Because DVW has already receive the data in advance, so it does not need to transfer the requests to serial devices and the function can also be used in MODBUS ASCII/RTU slave mode.

3.3.4.1 RS-485 cache table

On the left part of the cache table page displays information regarding configuration; click **Online** and data read based on configuration messages are shown on the right.

RS485 Cache Table

Cancel Apply

☐ Enabled (Only MODBUS ASCII/RTU Slave)

Cycle Time: 1000 ms Available Size: 0 Bytes Timeout Calibration: ms Detect

Coil Device Word Device

| # | Station Address | MODBUS (Hex) | MODBUS (Dec) | Count | Format | Online | Station Address | MODBUS (Hex) | MODBUS (Dec) | Present Value | Format |
|---|-----------------|--------------|--------------|-------|--------|--------|-----------------|--------------|--------------|---------------|--------|
| | | | | | | All | | | | | |

Add Edit Delete Online

Coil Device Word Device

| # | Station Address | MODBUS (Hex) | MODBUS (Dec) | Count | Online | Station Address | MODBUS (Hex) | MODBUS (Dec) | Status |
|---|-----------------|--------------|--------------|-------|--------|-----------------|--------------|--------------|--------|
| | | | | | All | | | | |

Add Edit Delete Online

| Explanation | Default value |
|--|---------------|
| Enabled | |
| Set MODBUS cache function to enable or not enable. | Not checked |
| Cycle time | |
| Set the time for sending requests to serial devices. | 1000 |
| Available size | |
| Displays the available data size for monitoing. | |
| Timeout calibration | |

| Explanation | Default value |
|--|---------------|
| Calibrate the response timeout. When users click Detect , the DVW device will use the MODBUS cache table for communication. | |
| Add | |
| Add a configuration message (up to 100 messages). | |
| Edit | |
| Edit selected configuration messages. | |
| Delete | |
| Delete assigned configuration messages. | |
| Online | |
| When clicked, real-time values gathered for relevant addresses are shown on the right section of the page. | |

| Word device | |
|-----------------|--------------------------------|
| Item | Explanation |
| Station address | The device station ID. |
| MODBUS (Hex) | MODBUS in hexadecimal values |
| MODBUS (Dec) | MODBUS in decimal values |
| Present value | MODBUS present value. |
| Format | Hexadecimal or decimal format. |

| Coil device | |
|-----------------|------------------------------|
| Item | Explanation |
| Station address | The device station ID. |
| MODBUS (Hex) | MODBUS in hexadecimal values |
| MODBUS (Dec) | MODBUS in decimal values |
| Status | Values of MODBUS. |

To add/ edit a configuration (see below):

MODBUS Cache Function

Station Address

(1~247)

MODBUS (Hex)

MODBUS (Dec)

Count

(1~100)

☐ Online

| Explanation | Default value |
|---|---------------|
| Station address | |
| The device station ID. | None |
| MODBUS (Hex) | |
| MODBUS in hexadecimal values. | None |
| MODBUS (Dec) | |
| MODBUS in decimal values | None |
| Count | |
| Starting from MODBUS address and connecting to monitored data size. | None |

| Explanation | Default value |
|--|---------------|
| Format | |
| Set format to Hex, Dec, Bin (hexadecimal, decimal, binary). When add or edit coil device types, format is not required. | Hex |
| Online | |
| Set or not to set data display on MODBUS monitoring table. | Not checked |

3.3.4.2 RS-232 cache table

On the left part of the cache table page displays information regarding configuration; click **Online** and data read based on configuration messages are shown on the right.

RS232 Cache Table

RS232 Cache Table

| Explanation | Default value |
|--|---------------|
| Enabled | |
| Set MODBUS cache function to enable or not enable. | Not checked |
| Cycle time | |
| Set the time for sending requests to serial devices. | 1000 |

| Explanation | Default value |
|--|---------------|
| Available size | |
| Displays the available data size for monitoring. | |
| Timeout calibration | |
| Calibrate the response timeout. When users click Detect , the DVW device will use the MODBUS cache table for communication. | |
| Add | |
| Add a configuration message (up to 100 messages). | None |
| Edit | |
| Edit selected configuration messages. | None |
| Delete | |
| Delete assigned configuration messages. | None |
| Online | |
| When clicked, real-time values gathered for relevant addresses are shown on the right section of the page. | None |

| Word device | |
|-----------------|--------------------------------|
| Item | Explanation |
| Station address | The device station ID. |
| MODBUS (Hex) | MODBUS in hexadecimal values |
| MODBUS (Dec) | MODBUS in decimal values |
| Present value | MODBUS present value. |
| Format | Hexadecimal or decimal format. |

| Coil device | |
|-----------------|------------------------------|
| Item | Explanation |
| Station address | The device station ID. |
| MODBUS (Hex) | MODBUS in hexadecimal values |
| MODBUS (Dec) | MODBUS in decimal values |
| Status | Values of MODBUS. |

To add/ edit a configuration (see below):

MODBUS Cache Function

Station Address

MODBUS (Hex)

MODBUS (Dec)

Count

☐ Online

(1~247)

(1~100)

| Explanation | Default value |
|-------------------------------|---------------|
| Station address | |
| The device station ID. | None |
| MODBUS (Hex) | |
| MODBUS in hexadecimal values. | None |
| MODBUS (Dec) | |
| MODBUS in decimal values | None |

| Explanation | Default value |
|--|---------------|
| Count | |
| Starting from MODBUS address and connecting to monitored data size. | None |
| Format | |
| Set format to Hex, Dec, Bin (hexadecimal, decimal, binary). When add or edit coil device types, format is not required. | Hex |
| Online | |
| Set or not to set data display on MODBUS monitoring table. | Not checked |

3.4 WLAN management - 2.4G

The WLAN management focuses on configuring 2.4G WIFI operation mode and its corresponding parameters. Please refer to the manual for accurate configuration before setup.

3.4.1 Operation mode

DVW-W01I2-E1 provides 2 different WIFI operation modes including AP and client mode that allow users to easily configure wireless network environment. Please first set DVW-W01I2-E1 operation mode, then configure WLAN.

Operation Mode

RF

☒ Enabled
 ☐ Disabled

Operation Mode

AP ▼

Region

Europe ▼

| Description | Default value |
|---|---------------|
| RF | |
| To enable or disable wireless function. | Enabled |
| Operation mode | |
| Set wireless operation mode: <ul style="list-style-type: none"> AP mode: used as an intermediate point for wired and wireless devices connection, data transmission and more. Client mode: DVW-W02W2-E2 operating in client mode can perform wireless data transmission via AP. | AP |
| Region | |
| Show the country or region for the device | U.S |



Attention

2.4G and 5G WIFI cannot operate in client mode simultaneously.

3.4.2 WLAN 2.4G

The setting page focuses on the basic and advanced configuration of 2.4G network in AP or client mode.

3.4.2.1 Basic configuration

The setting corresponds to operation mode. Different operation mode will have different basic configurations.

- **AP mode:**

In AP mode, users can add or edit WLAN basic configurations. For example, RF type, channel, SSID, SSID broadcast and security mode. Click **Apply** once configurations are completed.

Basic Configuration

Cancel Apply

Operation Mode AP

RF Type G/N Mixed ▼

Channel Auto ▼

Bandwidth 20M ▼

SSID SlimWiFi_4456

SSID Broadcast ☒ Enabled ☐ Disabled

Security Mode None ▼

| Description | Default value |
|--|---------------------------------|
| Operation mode | |
| Display present operation mode | |
| RF type | |
| Select from the following types: <ul style="list-style-type: none"> ● G: only supports IEEE 802.11g standard ● B/G Mixed: supports mixed mode IEEE 802.11b/g ● G/N Mixed: supports mixed mode IEEE 802.11g/n, but does not support 802.11b ● B/G/N Mixed: supports mixed mode IEEE 802.11b/g/n ● N Only: only supports 2.4GHz IEEE 802.11n standard | G/N Mixed |
| Channel | |
| Set AP operating channels from the following options: <ul style="list-style-type: none"> ● Auto ● 1-11 | Auto |
| Bandwidth | |
| Set WIFI 2.4G with the following bandwidth options: <ul style="list-style-type: none"> ● 20MHz ● 40MHz 20MHz penetrability is better and contains long transmission distance but is slower in speed. | 20MHz |
| SSID | |
| Type the wireless device name that consists of 1-32 characters | "SlimWiFi_"+"MAC last 4 digits" |
| SSID broadcast | |
| Set enable or disable SSID broadcast | Enabled |

- **Client mode**

Basic Configuration

| Refresh | | Back | | | | | | | |
|---------|---------------|-------------------|---------|-----------------|--------|-----------|--|--|--|
| No. | SSID | MAC Address | Channel | Security Mode | Signal | RSSI(dBm) | | | |
| 1 | SimWP_54FS_5G | 00:18:23:12:54:F8 | 36 | OPEN | 34.54 | -72 | | | |
| 2 | Delta-IT | 9C:FA:99:08:48:8F | 56 | OPEN | 30.94 | -76 | | | |
| 3 | Delta-Guest | 9C:FA:99:08:48:8D | 56 | OPEN | 30.94 | -76 | | | |
| 4 | iss-office | 9C:FA:99:08:48:8C | 56 | WPA/WPA2-802.1X | 30.94 | -76 | | | |
| 5 | Delta-Office | 9C:FA:99:08:48:8E | 56 | WPA2-802.1X | 30.94 | -76 | | | |
| 6 | 0000 | 00:18:23:12:C5:8A | 48 | WPA2-PSK | 38.94 | -60 | | | |
| 7 | Delta-IT | CC:45:D6:7C:50:4F | 54 | OPEN | 27.94 | -80 | | | |
| 8 | Delta-Guest | CC:45:D6:7C:50:4D | 54 | OPEN | 27.94 | -80 | | | |
| 9 | Delta-Office | CC:45:D6:7C:50:4E | 54 | WPA2-802.1X | 27.94 | -80 | | | |
| 10 | iss-office | 80:2F:A8:E1:83:EC | 54 | WPA/WPA2-802.1X | 34.94 | -64 | | | |
| 11 | Delta-Guest | 80:2F:A8:E1:83:ED | 54 | OPEN | 21.94 | -91 | | | |
| 12 | Delta-IT | 80:2F:A8:E1:83:EF | 54 | OPEN | 27.94 | -80 | | | |
| 13 | Delta-Office | 80:2F:A8:E1:83:EE | 54 | WPA2-802.1X | 27.94 | -81 | | | |
| 14 | Delta-Guest | F0:29:29:27:C2:3D | 54 | OPEN | 21.94 | -85 | | | |
| 15 | Delta-IT | F0:29:29:27:C2:3F | 54 | OPEN | 21.94 | -85 | | | |
| 16 | Delta-Office | F0:29:29:27:C2:3E | 54 | WPA2-802.1X | 18.94 | -89 | | | |
| 17 | iss-office | F0:29:29:27:C2:3C | 54 | WPA/WPA2-802.1X | 18.94 | -89 | | | |

| Description | Default value |
|--|---------------|
| EXTAP | |
| <ul style="list-style-type: none"> Enabled: When EXTAP is enabled, client compatibility increases along with more compatible AP. Disabled: When EXTAP is disabled, recommend using the AP of DVW-W0112-E1 for enhanced connection. | Disabled |
| Client mode | |
| <ul style="list-style-type: none"> Disabled: Operation under normal WiFi client mode. Roaming: client support fast roaming protocol of personal level. | Disabled |

**Attention**

In client mode, RF type and channel in gray background cannot be configured; while in AP mode, simultaneous configuration for RF type, channel and security mode begins once matching is successful.

Start roaming mode, the DVW devices support fast roaming protocol of personal level and can fulfill the need for fast switching APs in maintaining the operation under wireless application environment.

Client Mode Roaming ▾

Scan Policy : Signal Change Scanning ▾

Scan channels(The channels with * are DFS channels) 36 ▾

Not scanning ▾

Not scanning ▾

Scan Time(10~200ms) 50

Scan Period(1000~300000ms) 1000

Scan Threshold(-95~0 dBm) -50

Roaming Signal Difference(5~20 dBm) 5

Roaming Threshold(-95~0 dBm) -55

Roaming Detect Period(50~300000ms) 1000

Notes: Client will begin scanning when the signal of current AP is lower than "Scan Threshold", when it get new AP and the signal of current AP is lower than "Roaming Threshold", roaming start.

| Description | Default value |
|--|--------------------|
| Client Mode | |
| To enable or not enable fast roaming function. | Disabled |
| Scan channel | |
| <p>To set fast roaming, DVW scans the assigned AP channels; when there are more channels that need to be determined, roaming speed is also more easily affected.</p> <ul style="list-style-type: none"> Below are options in the first drop-down list: <ul style="list-style-type: none"> -- Auto: Scan all the channels and select an option without selecting the second and third drop-down lists. --The present AP channels in connection with DVW. Below are options in the second and third drop-down list: <ul style="list-style-type: none"> -- Not scanning: Scanning channels only from the previous drop-down list. -- Channel value: Select desired channels for scanning. | Present AP channel |
| Scan time | |
| When DVW scans for available APs, set the scan time for each channel.Setting range: 10~200ms. | 50 |
| Scan period | |
| Set the AP interval period for DVW scan. Setting range: 1000~300000ms ° | 1000 |

| Description | Default value |
|--|---------------|
| Scan threshold | |
| Set the AP threshold once DVW is triggered for scanning, but only when the AP's transmission power connected to the present DVW is lower than the threshold value, the DVW will scan the available AP based on the scan period. Setting range: -95~0 dBm. | -50 |
| Roaming signal difference | |
| Set DVW roaming signal difference which is a condition to execute DVW switching action. When the signal difference between present AP's transmission power in connection with DVW and the new AP is larger than the setting value, the DVW will switch to the new AP. Setting range: 5~20 dBm. | 5 |
| Roaming threshold | |
| Set DVW roaming threshold which is a condition for DVW to execute switch action. When the present AP's transmission power in connection with DVW is lower than the setting value, the DVW can switch to new AP. Setting range: -95~0 dBm. | -55 |
| Roaming detect period | |
| Set DVW to detect whether the interval period of the two roaming conditions are satisfied; When both conditions are satisfied, the DVW can execute switching. Setting range: 50~300000ms. | 50 |

3.4.2.2 Security mode

The device provides 5 standard security modes including none, WEP, WPA-PSK[TKIP], WPA2-PSK[AES] and WPA-PSK[TKIP] + WPA2-PSK[AES]. Users can set the security mode base on your own needs.

- **Security mode: None**

No security mode. When selecting this option, any client can connect to DVW-W02W2-E2 device without security mode.

- **Security mode: WPA/WPA2 Personal**

The WIFI alliance developed Wi-Fi Protected Access (WPA) and Wi-Fi Protected Access 2 (WPA2) to protect two security protocols and security identifications in wireless network. The WPA/WPA2-Personal or so-called WPA / WPA-PSK (Pre-Shared Key) has two encryption methods including TKIP (Temporal Key Integrity Protocol) and AES (Advance Encryption System). TKIP can automatically create a new network password every few minutes which can prevent attackers from continuously collecting sufficient data in accessing your network. AES represents Advance Encryption System that encrypts 128-bit, 192-bit or 256-bit block and is considered the safest option for WIFI encryption.

Security Options (WPA2-PSK)

Password (8-63 characters or 64 hex digits)

| Description | Default value |
|---|---------------|
| Security options | |
| <ul style="list-style-type: none"> ● WPA2-PSK[AES]: Enable AES encryption method. ● WPA-PSK[TKIP]+ WPA2-PSK[AES]: Supports WPA-PSK and WPA2-PSK. Broadcast packets uses TKIP. For point-to-point transmission, WPA-PSK client uses TKIP and WPA2-PSK client uses AES. | None |
| Password | |
| Password phrase requires 8 to 63 ASCII characters or 64 hexadecimal digit. | None |

3.4.2.3 Advanced configuration

The configuration provides users to execute advanced parameter settings based on different on-site wireless environment.

Advanced Configuration

Cancel Apply

Transmission Power(dBm) 20 ▾

Beacon Interval(40-1000ms) 150

| Description | Default value |
|--|---------------|
| Transmission power | |
| Set the transmission power. The transmission power gets stronger as setting value becomes higher and the influence range widens. Range option 1 to 20. | 20 |
| Beacon interval | |
| The beacon interval of a wireless broadcast, the unit is ms. When roaming is required, users can adjust to lower value for faster connection; adjust to higher value for power saving. Input range: 40-1000. | 150 |

3.5 WLAN management - 5G

The WLAN management focuses on configuring 5G WIFI operation mode and its corresponding parameters. Please refer to the manual for accurate configuration before setup.

3.5.1 Operation mode

DVW-W0112-E1 provides 2 different WIFI operation modes including AP and client mode that allow users to easily configure wireless network environment. Please first set DVW-W0112-E1 operation mode, then configure WLAN.

Operation Mode

Cancel Apply


RF ☒ Enabled ☐ Disabled

Operation Mode AP ▾

Region Europe ▾

| Description | Default value |
|-------------|---------------|
|-------------|---------------|

| | |
|---|---------|
| RF | |
| To enable or disable wireless function. | Enabled |
| Operation mode | |
| Set wireless operation mode: <ul style="list-style-type: none">● AP mode: used as an intermediate point for wired and wireless devices connection, data transmission and more.● Client mode: DVW-W02W2-E2 operating in client mode can perform wireless data transmission via AP. | AP |
| Region | |
| Set the country or region for the device. The setting follows the different WLAN channels established by each country. Many countries have their own regulations on these channels, e.g. maximum power levels within these frequency ranges, countries or regions supported in total: China, Taiwan, U.S. and Europe. | Europe |

**Attention**
2.4G and 5G WIFI cannot operate in client mode simultaneously.

3.5.2 WLAN 5G

The setting page focuses on the basic and adanced configuration of 5G network in AP or client mode.

3.5.2.1 Basic configuration

The setting corresponds to operation mode. Different operation mode will have different basic configurations.

● AP mode:

In AP mode, users can add or edit WLAN basic configurations. For example, RF type, channel, SSID, SSID broadcast and security mode. Click **Apply** once configurations are completed.

Basic Configuration

Cancel

Apply

| | |
|----------------|---|
| Operation Mode | AP |
| RF Type | AC/N Mixed |
| Channel | 36 |
| Bandwidth | 80M |
| SSID | SlimWiFi_B4F9_5G |
| SSID Broadcast | <input checked="" type="radio"/> Enabled <input type="radio"/> Disabled |
| Security Mode | None |

| Description | Default value |
|-------------|---------------|
|-------------|---------------|

| Description | Default value |
|---|--------------------------------------|
| Operation mode | |
| Display present operation mode | |
| RF type | |
| Select from the following types: <ul style="list-style-type: none"> ● AC/N Mixed: only supports mixed mode IEEE 802.11ac/n ● A/N Mixed: supports mixed mode IEEE 802.11a/n ● N Only: only supports 5GHz IEEE 802.11n standard ● A: only supports 5GHz IEEE 802.11n standard | AC/N Mixed |
| Channel | |
| Set AP operating channels from the following options: <ul style="list-style-type: none"> ● 36/40/44/48/52/60/64/100/104/108/112/116/120/124/128/132/136/140 | 36 |
| Bandwidth | |
| Set WIFI 5G with the following bandwidth options: <ul style="list-style-type: none"> ● 20MHz ● 40MHz ● 80MHz 20MHz penetrability is better and contains long transmission distance but is slower in speed. | 80MHz |
| SSID | |
| Type the wireless device name that consists of 1-32 characters | "SlimWiFi_"+"MAC last 4 digits"+"5G" |
| SSID broadcast | |
| Set enable or disable SSID broadcast | Enabled |
| Security mode | |
| Set AP operation security mode from the following options: <ul style="list-style-type: none"> ● None ● WPA2-PSK[AES] ● WPA-PSK[TKIP]+ WPA2-PSK[AES] For more security mode information, refer to section 3.4.2.2 | None |

● Client mode

In client mode, click **Site Survey** and the existed network SSID will appear, then choose the matching SSID. For example, the matching SSID is configured to WEP or WPA/WPA2-PSK. Please enter the correct password then click **Apply** to connect with AP.

Basic Configuration

Cancel

Apply

Operation Mode

Client

RF Type

AC/N Mixed

Channel

36

Bandwidth

80M

SSID

SlimWiFi_B4F9_5G

Site Survey

EXTAP

Enabled

Disabled

Security Mode

WPA2-PSK[AES]

Security Options (WPA2-PSK)


Password

(8-63 characters or 64 hex digits)

Client Mode

Disabled

| Description | Default value |
|---|---------------|
| EXTAP | |
| <ul style="list-style-type: none">Enabled: When EXTAP is enabled, client compatibility increases along with more compatible AP.Disabled: When EXTAP is disabled, recommend using the AP of DVW-W01I2-E1 for enhanced connection. | Disabled |
| Client mode | |
| <ul style="list-style-type: none">Disabled: Operation under normal WiFi client mode.Roaming: client support fast roaming protocol of personal level | Disabled |



Attention

In client mode, RF type and channel in gray background cannot be configured; while in AP mode, simultaneous configuration for RF type, channel and security mode begins once matching is successful.

Start roaming mode, the DVW devices support fast roaming protocol of personal level and can fulfill the need for fast switching APs in maintaining the operation under wireless application environment.

Client Mode Roaming ▾

Scan Policy : Signal Change Scanning ▾

Scan channels(The channels with * are DFS channels) Auto ▾

Scan Time(10~200ms) Not scanning ▾

Scan Period(1000~300000ms) Not scanning ▾

Scan Threshold(-95~0 dBm) 50

Roaming Signal Difference(5~20 dBm) 1000

Roaming Threshold(-95~0 dBm) -50

Roaming Detect Period(50~300000ms) 5

1000

Notes: Client will begin scanning when the signal of current AP is lower than "Scan Threshold", when it get new AP and the signal of current AP is lower than "Roaming Threshold", roaming start.

| Description | Default value |
|---|-----------------------|
| Client Mode | |
| To enable or not enable fast roaming function. | Disabled |
| Scan channel | |
| Set DVW scan strategy, the system offers two options. <ul style="list-style-type: none"> Scan changing signals: When the signal of AP in connection with DVW is lower than scan threshold, once signal value changes and triggers DVW to scan for available AP; the AP signal information received provides DVW to determine in switching or not; the parameter of scan period is invalid under this mode. Periodic scanning or scan changing signals: When the signal of AP in connection with DVW is lower than scan threshold, the DVW is triggered according to scan period or changing signal values for available AP; the AP signal information received provides DVW to determine in switching or not | Scan changing signals |
| To set fast roaming, DVW scans the assigned AP channels; when there are more channels that need to be determined, roaming speed is also more easily affected. <ul style="list-style-type: none"> Below are options in the first drop-down list: -- Auto: Scan all the channels and select an option without selecting the second and third drop-down lists. --The present AP channels in connection with DVW. Below are options in the second and third drop-down list: -- Not scanning: Scanning channels only from the previous drop-down list. -- Channel value: Select desired channels for scanning. | Auto |
| Scan time | |
| When DVW scans for available APs, set the scan time for each channel.Setting range: 10~200ms. | 50 |
| Scan period | |
| Set the AP interval period for DVW scan. Setting range: 1000~300000ms ° | 1000 |
| Scan threshold | |
| Set the AP threshold once DVW is triggered for scanning, but only when the AP's transmission power connected to the present DVW is lower than the threshold value, the DVW will scan the available AP based on the scan period. Setting range: -95~0 dBm. | -50 |
| Roaming signal difference | |
| Set DVW roaming signal difference which is a condition for DVW to execute switch action. When the signal difference between present AP's transmission power in connection with DVW and the new AP is larger than the setting value, the DVW will switch to the new AP. Setting range: 5~20 dBm. | 5 |

| Description | Default value |
|--|---------------|
| Roaming threshold | |
| Set DVW roaming threshold which is a condition for DVW to execute switch action. When the present AP's transmission power in connection with DVW is lower than the setting value, the DVW can switch to new AP. Setting range: -95~0 dBm. | -55 |
| Roaming detect period | |
| Set DVW to detect whether the interval period of the two roaming conditions are satisfied; when both conditions are satisfied, the DVW can execute switching. Setting range: 50~300000ms. | 50 |

3.5.2.2 Advanced configuration

The configuration provides users to execute advanced parameter settings based on different on-site wireless environment.

Advanced Configuration

Transmission Power(dBm)

20 ▾

Beacon Interval(40-1000ms)

150

| Description | Default value |
|--|---------------|
| Transmission power | |
| Set the transmission power. The transmission power gets stronger as setting value becomes higher and the influence range widens. Range option 1 to 20. | 20 |
| Beacon interval | |
| The beacon interval of a wireless broadcast, the unit is ms. When roaming is required, users can adjust to lower value for faster connection; adjust to higher value for power saving. Input range: 40-1000. | 150 |

3.6 Advance

3.6.1 SNMP Configuration

Simple Network Management Protocol (SNMP) is an application protocol used for exchanging management information between network devices. SNMP is a member of the TCP/IP protocol suite. SNMP V1, V2 and V3 are supported on the Delta DVW series. When the SNMP protocol version is V1, V2c, the authentication type use a community string. When the SNMP protocol version is V3, then you need to specify the authentication type. If you have data encryption requirement, you can specify the privacy type.

SNMP Configuration

| | |
|---------------------------|-------------------------|
| Enabled | Disabled ▾ |
| Read Community | public |
| Write Community | private |
| SNMP Agent Version | V1, V2c ▾ |
| Admin Authentication Type | No Auth ▾ |
| Admin Privacy Type | Disabled ▾ |
| Privacy Key | |
| Device object ID | enterprise.6785.501.8.1 |

| Description | Factory Default |
|--|-----------------|
| Enable | |
| Specify whether the SNMP agent is enabled. | None |
| Remote Management | |
| Specify whether remote user can manage DVW series by SNMP. | None |
| Read Community | |
| Input a community name for the device to be accessed with read-only permission. | Public |
| Write Community | |
| Input a community name for the device to be accessed with read/write permission. | Private |
| SNMP Agent Version | |
| Specify the SNMP version of the device. | V1, V2c |
| Admin Authentication Type | |
| Specify the admin authentication type to verify that the message is from a valid source. It works when SNMP agent version is "V1, V2c, V3" or "V3". <ul style="list-style-type: none"> No Auth: No Authentication. Only use admin account to access objects. MD5: Use MD5 algorithms for authentication. SHA: Use SHA algorithms for authentication. | No Auth |
| Admin Privacy Type | |
| Specify the data encryption type. It works when SNMP agent version is "V1, V2c, V3" or "V3". <ul style="list-style-type: none"> Disable: No data encryption. AES: Use AES-based data encryption. DES: Use DES-based data encryption. | Disabled |
| Privacy Key | |
| Input a data key for data encryption. | None |
| Device Object ID | |
| This field displays the Delta DVW series's OID. | Fixed |

3.6.2 Packet Control

DVW-W01I2-E1 has three built-in filters (MAC address filtering, IP protocol filtering, TCP / UDP port filtering). These are filters that can enhance the security and performance of the network.

3.6.2.1 Filter configuration

Settings of 3 filters, MAC filters, IP Protocol filters, and TCP/UDP port filters as well as the packet acceptance.

Filter Configuration

Cancel

Apply


Enabled

Disabled ▾

Policy

Drop ▾

| Description | Factory Default |
|--|-----------------|
| Enable | |
| Specify whether the filter configuration is enabled. <ul style="list-style-type: none">Enable: Packet filter function is enabled.Disable: Packet filter function is disabled. The filter priority: MAC filters > IP Protocol filters > TCP/UDP port filters | Disabled |
| Policy | |
| <ul style="list-style-type: none">Drop: All packets correspond with the list will be dropped.Accept: Only the packets correspond with the list can be accepted. | Drop |

**Notice:**
Before you enable the filter function, please notice the **Policy**:
Drop: If there is no data in the filter list, all packets are **accepted**.
Accept: If there is no data in the filter list, all packets are **dropped**.

3.6.2.2 MAC Filter

The MAC filter can accept or drop packets with specified MAC addresses. The MAC address can be configured up to 8 entries.

MAC filters

Cancel Apply

| No | Active | Name | MAC address |
|----|--------------------------|------|-------------|
| 1 | <input type="checkbox"/> | | |
| 2 | <input type="checkbox"/> | | |
| 3 | <input type="checkbox"/> | | |
| 4 | <input type="checkbox"/> | | |
| 5 | <input type="checkbox"/> | | |
| 6 | <input type="checkbox"/> | | |
| 7 | <input type="checkbox"/> | | |
| 8 | <input type="checkbox"/> | | |

**Notice:**

Please check the Active check box for the entries which you want to specify and please remember to configure the policy in **Filter Configuration** page.

3


3.6.2.3 IP Protocol Filter

The IP Protocol filter can accept or drop packets with specified IP protocol and source/destination addresses. The policy can be configured up to 8 entries. DVW provides 3 IP protocols items: All, TCP, UDP and ICMP. The Source IP and Destination IP must be specified. You can specify an IP address or a range of IP addresses.

IP Protocol Filters


Cancel Apply

| No | Active | Protocol | Source IP | Source netmask | Destination IP | Destination netmask |
|----|--------------------------|----------|-----------|----------------|----------------|---------------------|
| 1 | <input type="checkbox"/> | All | | | | |
| 2 | <input type="checkbox"/> | All | | | | |
| 3 | <input type="checkbox"/> | All | | | | |
| 4 | <input type="checkbox"/> | All | | | | |
| 5 | <input type="checkbox"/> | All | | | | |
| 6 | <input type="checkbox"/> | All | | | | |
| 7 | <input type="checkbox"/> | All | | | | |
| 8 | <input type="checkbox"/> | All | | | | |

Example:

If the IP protocol filtering settings are as follows, and the policy configured by the filter is [Drop], all IP packets sent from 192.168.1.20 to 192.168.1.10 will be filtered and cannot be delivered.

| No | Active | Protocol | Source IP | Source Netmask | Destination IP | Destination Netmask |
|----|-------------------------------------|----------|--------------|-----------------|----------------|---------------------|
| 1 | <input checked="" type="checkbox"/> | All | 192.168.1.20 | 255.255.255.255 | 192.168.1.10 | 255.255.255.255 |



Notice:
Please check the Active check box for the entries which you want to specify and please remember to configure the policy in **Filter Configuration** page.

3.6.2.4 TCP/UDP Port Filter

The TCP/UDP port filter can accept or drop packets with specified port and protocol. The policy can be configured up to 8 entries.


You can specify TCP or UDP protocol, and specify a single port or a range of port. If you want to specify a single port, you can leave blank in end port field; if you want to specify a range of port, the end port can't be larger than the start port.

TCP/UDP Port Filters

Cancel

Apply

| No | Active | Source port | Destination port | Protocol | Application name |
|----|--------------------------|----------------------|----------------------|----------|----------------------|
| 1 | <input type="checkbox"/> | <input type="text"/> | <input type="text"/> | TCP | <input type="text"/> |
| 2 | <input type="checkbox"/> | <input type="text"/> | <input type="text"/> | TCP | <input type="text"/> |
| 3 | <input type="checkbox"/> | <input type="text"/> | <input type="text"/> | TCP | <input type="text"/> |
| 4 | <input type="checkbox"/> | <input type="text"/> | <input type="text"/> | TCP | <input type="text"/> |
| 5 | <input type="checkbox"/> | <input type="text"/> | <input type="text"/> | TCP | <input type="text"/> |
| 6 | <input type="checkbox"/> | <input type="text"/> | <input type="text"/> | TCP | <input type="text"/> |
| 7 | <input type="checkbox"/> | <input type="text"/> | <input type="text"/> | TCP | <input type="text"/> |
| 8 | <input type="checkbox"/> | <input type="text"/> | <input type="text"/> | TCP | <input type="text"/> |



Notice:
Please check the Active check box for the entries which you want to specify and please remember to configure the policy in **Filter Configuration** page.

3.7 Auto Warning Setting

Industrial Ethernet devices in an industrial environment are very important. These devices usually need to work for a long time and are usually located at the end of the system. So if the Delta DVW series need to be maintained, it must provide some messages to the maintainer. Even when the maintainers or engineers do not stay in the control room, they still need to be informed the status of the devices. Delta DVW series provides different approaches to warn engineers automatically, such as log, E-mail, relay output and SNMP trap.

3.7.1 SysLog

Syslog function provides you to monitor the device. When faults, errors, configuration changes or specified events happen, this function can generate messages and forward the messages to a specified syslog server.

3.7.1.1 Syslog Event Types

Please check the box to enable the event items. The default settings are disabled (unticked).

Syslog Event Types

Cancel Apply

| Event | Active |
|---|--------------------------|
| Cold Start | <input type="checkbox"/> |
| Warm Start | <input type="checkbox"/> |
| Authentication Failure | <input type="checkbox"/> |
| IP Change | <input type="checkbox"/> |
| Password Changed | <input type="checkbox"/> |
| Configuration Changed | <input type="checkbox"/> |
| WLAN Connection or Disconnection | <input type="checkbox"/> |
| WLAN Role Change | <input type="checkbox"/> |
| WLAN Client Joined&Left | <input type="checkbox"/> |
| Firmware Update | <input type="checkbox"/> |
| Disabled <input type="checkbox"/> DI | <input type="checkbox"/> |
| Disabled <input type="checkbox"/> Port Link | <input type="checkbox"/> |

| Description | Factory Default |
|--|-----------------|
| Cold Start | |
| Power off and then power on to start the system. | Uncheck |
| Warm Start | |
| When the power is still on, restart the system. | Uncheck |
| Authentication Failure | |
| Log in failure (wrong ID / Password) | Uncheck |
| IP Changed | |
| Change the IP address of the DVW series. | Uncheck |
| Password Changed | |
| Change the login password. | Uncheck |
| Configuration Changed | |
| Any configuration of the DVW series changed. | Uncheck |
| WLAN Connection or Disconnection | |
| When in the Client mode, any wireless device joined or left. | Uncheck |
| WLAN Role Change | |
| Operation mode or configuration changed | Uncheck |
| WLAN Client Joined / Left | |
| When in the Client mode, any client end joined or left. | Uncheck |
| Firmware Update | |
| When updating firmware | Uncheck |
| DI (ON→OFF) or (OFF→ON) | |
| Trigger DI to (ON→OFF) or (OFF→ON) | Uncheck |

3.7.1.2 Syslog Server Configuration

This function allows users to have the system log sent to the syslog server once there is any event occurs. DVW series can configure 1 syslog server and its transport layer protocol is UDP.

Syslog Server Configuration

Cancel

Apply

Remote Syslog Enable

☐ Enable ☒ Disable

Syslog server

Syslog port

514

| Description | Factory Default |
|---|-----------------|
| Remote Syslog Enable | |
| Enable or disable the remote syslog function | Disabled |
| Syslog Server | |
| The IP address of the syslog server | None |
| Syslog Port | |
| Set up the local UDP port (the setups should be the same as the UDP port of the syslog server , ranging from 1-65535) | 514 |

3.7.2 E-mail Alarm

When malfunctions, errors, configuration changed, or other appointed events occurred, the system can create a warning and send the warning to the appointed email address.

3.7.2.1 Syslog Server Configuration

Please check the box to enable the event items you'd like to be notified. The default settings are disabled (unticked).

Email Event Types

Cancel

Apply

| Event | Active |
|----------------------------------|--------------------------|
| Cold Start | <input type="checkbox"/> |
| Warm Start | <input type="checkbox"/> |
| Authentication Failure | <input type="checkbox"/> |
| IP Change | <input type="checkbox"/> |
| Password Changed | <input type="checkbox"/> |
| Configuration Changed | <input type="checkbox"/> |
| WLAN Connection or Disconnection | <input type="checkbox"/> |
| WLAN Role Change | <input type="checkbox"/> |
| WLAN Client Joined/Left | <input type="checkbox"/> |
| Firmware Update | <input type="checkbox"/> |
| Disabled ▼ Di | <input type="checkbox"/> |
| Disabled ▼ Port Link | <input type="checkbox"/> |

3.7.2.2 E-mail Server Configuration

The E-mail server parameters can be configured in this page. The maximum e-mail addresses which you can specify are 4. You can also send Test Mail to see if the email server configuration is complete.

E-mail Server Configuration

| | |
|---------------------|---|
| Mail server(SMTP) | <input type="text" value="192.168.1.100"/> |
| User name | <input type="text" value="mailadmin"/> |
| Password | <input type="password" value="••••••••"/> |
| From e-mail address | <input type="text" value="DWW@delta.com.tw"/> |
| To e-mail address 1 | <input type="text" value="david@delta.com.tw"/> |
| To e-mail address 2 | <input type="text"/> |
| To e-mail address 3 | <input type="text"/> |
| To e-mail address 4 | <input type="text"/> |

| Description | Factory Default |
|--|-----------------|
| Mail Server (SMTP) | |
| Set up the IP address or domain address of the syslog server (SMTP) | None |
| User Name / Password | |
| Set up the user name and the password for the syslog server | None |
| From Email Address | |
| Set up the administrator's email address; once the warning email is sent, this email address will be shown on the sender's section. Up to 63 characters can be inputted. | None |
| To Email Address 1 / 2 / 3 / 4 | |
| Set up the receipt's email address; up to 63 characters can be inputted. | None |

3.7.3 SNMP Trap

NMS (Network Management Station) usually manage and monitor many SNMP agents. If manager pre-configure the event, then the SNMP agents will send a message as a trap when the event has been triggered.

3.7.3.1 Trap Event Types

Please check the box to enable the event items you'd like to be notified. The default settings are disabled (unticked).

Trap Event Types

Cancel

Apply

| Event | Active |
|----------------------------------|--------------------------|
| Cold Start | <input type="checkbox"/> |
| Warm Start | <input type="checkbox"/> |
| Authentication Failure | <input type="checkbox"/> |
| IP Change | <input type="checkbox"/> |
| Password Changed | <input type="checkbox"/> |
| Configuration Changed | <input type="checkbox"/> |
| WLAN Connection or Disconnection | <input type="checkbox"/> |
| WLAN Role Change | <input type="checkbox"/> |
| WLAN Client Joined&Left | <input type="checkbox"/> |
| Firmware Update | <input type="checkbox"/> |
| Disabled ▼ Di | <input type="checkbox"/> |
| Disabled ▼ Port Link | <input type="checkbox"/> |

3.7.3.2 SNMP Trap Receiver Configuration

Users can set up the SNMP Trap receiver; SMIv1 MIBs (SNMPv1) and SMIv2 MIBs (SNMPv2c) are supported.

SNMP Trap Receiver Configuration

Cancel

Apply

1st Trap version

V1 ▼

1st Trap server IP/name

192.168.1.11

1st Trap community

public

2nd Trap version

V2 ▼

2nd Trap server IP/name

192.168.1.11

2nd Trap community

private

| Description | Factory Default |
|---|-----------------|
| 1st/ 2nd Trap version | |
| Specify the SNMP trap version in SNMPv1 or SNMPv2. | V1 |
| 1st/ 2nd Trap server IP/name | |
| Enter the IP address or the name of SNMP Trap server in your network. | None |
| 1st/ 2nd Trap community | |
| Input the community string for authentication. | None |

3.7.4 Relay Alarm

The relay alarm is mainly used to monitor the specified event. When the event is triggered, the relay alarm (DO closed) is triggered, and at the same time, the indicator light is on.

Relay Event Types

| <input type="button" value="Cancel"/> <input type="button" value="Apply"/> | |
|--|-------------------------------------|
| Event | Active |
| ▼ DI | <input checked="" type="checkbox"/> |
| ▼ Port Link | <input checked="" type="checkbox"/> |

3.7.4.1 Relay Event Types

DVW defines two types of trigger events: DI and Port Link.

| <input type="button" value="Cancel"/> <input type="button" value="Apply"/> | |
|--|--------------------------|
| Event | Active |
| Disabled ▼ DI | <input type="checkbox"/> |
| Disabled ▼ Port Link | <input type="checkbox"/> |

3**3.8 Management Access**

Delta DVW series supports not only web interface to manage the device. You also can use CLI (Command Line Interface) to configure the DVW series by Secure Shell (SSH) and Telnet. For system security, we recommend that you set all access management settings to disabled if there is no need

3.8.1 SSH Configuration

You can set whether to allow users to log in to the device using SSH.

SSH Configuration

| | |
|--|---|
| <input type="button" value="Cancel"/> <input type="button" value="Apply"/> | |
| SSH | <input type="radio"/> Enable <input checked="" type="radio"/> Disable |

3.8.2 Telnet Configuration

You can configure Telnet configuration in this page.

Telnet Configuration

| | |
|--|---|
| <input type="button" value="Cancel"/> <input type="button" value="Apply"/> | |
| Telnet | <input type="radio"/> Enable <input checked="" type="radio"/> Disable |

3.9 Monitoring

After the user sets the automatic alarm function, the monitoring function provides a detailed record of all occurrences. These include email, relay alarm table, trap alarm table, system log, network connection status, AP client list, DHCP client, serial port status, serial port statistics, serial port error, serial port log.

3.9.1 Email Alarm Table

When Email event has been triggered, this page displays the event and status.

E-mail alarm table

| Index | Event | Status |
|-------|------------------|--------|
| 1 | Port 2 Link down | Fail |
| 2 | Power2(On-->Off) | Fail |

| Item | Description |
|--------|-------------------------------------|
| Index | The index of the event. |
| Event | The event which has been triggered. |
| Status | The status of the event. |

3.9.2 Relay Alarm Table

When relay event has been triggered, this page displays the event and status.

Relay alarm table

| Index | Event | Relay |
|-------|------------------|-------|
| 1 | Power2 Off | V |
| 2 | Port 2 Link down | V |

| Item | Description |
|--------|-------------------------------------|
| Index | The index of the event. |
| Event | The event which has been triggered. |
| Status | The status of the event. |

3.9.3 Trap Alarm Table

When relay event has been triggered, this page displays the event and status.

Trap alarm table

| Index | Event | Status |
|-------|------------------|---------|
| 1 | Port 2 Link down | Success |
| 2 | Power2(On-->Off) | Success |

| Item | Description |
|--------|-------------------------------------|
| Index | The index of the event. |
| Event | The event which has been triggered. |
| Status | The status of the event. |

3.9.4 Network Connection Status

Network connection status page provides user to monitor the physical LAN port connection status.

Network Connection Status

LAN

On

3.9.5 AP Client List

AP Client List displays all wireless which associates with DVW series currently. The information includes IP Address, MAC Address and Device Name.

AP Client List

| # | IP Address | MAC Address | Device Name |
|---|---------------|-------------------|--------------|
| 1 | 192.168.1.128 | 00:03:7F:EF:11:22 | DWW-W52WQ-E2 |
| 2 | 192.168.1.50 | 60:67:28:D6:B4:80 | TWYTY3M0359 |

3.9.6 DHCP Client List

When the device starts DHCP-Server in [Network Configuration], this page displays a list of DHCP clients currently connected to the device. Click the refresh button to refresh the list.

DHCP Client List

| Select all | refresh | | | | |
|---|---------------|-----|----|---------------------|---------------|
| <table> <tr> <th>MAC</th><th>IP</th></tr> <tr> <td>1 00:03:7f:ef:11:22</td><td>192.168.1.128</td></tr> </table> | | MAC | IP | 1 00:03:7f:ef:11:22 | 192.168.1.128 |
| MAC | IP | | | | |
| 1 00:03:7f:ef:11:22 | 192.168.1.128 | | | | |

| Item | Description |
|------------|---|
| Select All | Select all clients on the DHCP Client List. |
| Refresh | Refresh the DHCP Client List |

3.9.7 Serial Port Status

Display serial port status Provide port, interface, operation function, baud rate, format, flow control, buffer size.

| Port | Operation Function | Baud Rate | Format | Flow Control | Buffer Size |
|-------|--------------------|-----------|--------|--------------|-------------|
| RS232 | Disabled | 9600 | 8,N,1 | None | Not Support |
| RS485 | Disabled | 9600 | 8,N,1 | None | Not Support |

Serial Port Statistics page displays the number of serial Tx and Rx packet number and data transmission status for each serial port.

| Port | TX Byte Count | RX Byte Count | RTS | CTS |
|-------|---------------|---------------|---|---|
| RS232 | 0 | 0 | | |
| RS485 | 0 | 0 | | |

Serial Port Error page displays the current number of frame, parity, overrun and break errors for each port.

| Port | Frame Error | Parity Error | Overrun Error | Break Error |
|------|-------------|--------------|---------------|-------------|
| 1 | 0 | 0 | 0 | 0 |
| 2 | 0 | 0 | 0 | 0 |

Serial Port Log page displays the logs of serial port. Users can choose to see contents of one single port or contents of the sent and received data.

RS232

RS485

Send

All Clear

Clear

```
[2019-10-19 34:55:11]1 3 14 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 a3 67
[2019-10-19 34:55:12]1 3 14 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 a2 67
[2019-10-19 34:55:13]1 3 14 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 a3 67
[2019-10-19 34:55:14]1 3 14 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 a3 67
[2019-10-19 34:55:15]1 3 14 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 a3 67
[2019-10-19 34:55:16]1 3 14 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 a3 67
```

Receive

Clear

```
[2019-10-19 34:55:11]1 3 0 0 0 a c5 cd
[2019-10-19 34:55:12]1 3 0 0 0 a c5 cd
[2019-10-19 34:55:13]1 3 0 0 0 a c5 cd
[2019-10-19 34:55:14]1 3 0 0 0 a c5 cd
[2019-10-19 34:55:15]1 3 0 0 0 a c5 cd
[2019-10-19 34:55:16]1 3 0 0 0 a c5 cd
```

3.10.1 Session timeout

3-48

Session Timeout

| | |
|--|--|
| <input type="button" value="Cancel"/> <input type="button" value="Apply"/> | |
| Session Timeout (minutes) | <input type="text" value="30"/> (0~60) |

| Description | Default value |
|---|---------------|
| Session timeout | |
| Set the time for session timeout. | 30 |
| <ul style="list-style-type: none"> Timeout setting range is 0 to 60 min. Set to 0 and session timeout will never occur. | |
| | |

3.10.2 Password

Users can change the password of DVW-W01I2-E1 log in page. To successfully configure a new set of password, users need to type in the old password.

New Password

| | |
|--|--------------------------|
| <input type="button" value="Cancel"/> <input type="button" value="Apply"/> | |
| Old Password | <input type="password"/> |
| New Password | <input type="password"/> |
| Repeat New Password | <input type="password"/> |

| Description | Default value |
|-----------------------------|---------------|
| Old password | |
| The current admin. password | |
| New password | |
| Set new admin. password | |
| Repeat new password | |
| Repeat the new password | |

3.10.3 System log backup

The function allows documents derived from the logs to be stored in PCs or storage devices.

3.10.4 Roaming log

Roaming log function can record the device as WIFI station that quickly switch from one AP message to another including SSID in AP's source and transmission power as well as SSID in destination AP and transmission power.



| Description | Default value |
|--|---------------|
| BSSID | |
| MAC in AP's source destination AP | N/A |
| Power | |
| RF power of AP | N/A |
| Threshold | |
| Switch threshold setting by users | N/A |
| Connect | |
| Previous AP connection time | N/A |
| Handoff | |
| The handoff time for switching to AP roaming | N/A |
| ID | |
| The number of times for roaming | N/A |

3.10.5 Serial log

From selecting a serial, users can determine the assigned log level and serial logs.

Serial Log

Set Log Level Error ▼ Configuration

Save A Copy Of Log

Select A Serial RS232 ▼ Backup

The image above shows the system can derive all log level as "Error" from RS232 serial logger. Users can click **Backup** button and download the logs in PCs.

3.10.6 Ping

Ping function can help admin to analyze network status. Type in the IP address to search for connection status.

Ping

Destination

3.10.7 Ping detection

When users enable Ping detection for AP connection, the AP's IP address is usually configured so that when the number of Ping failure reaches the setting number, the system is bound to start WIFI reset.

Detect AP Connection

Enable Ping Detection For AP Connection

3.10.8 Firmware upgrade

DVW-W01I2-E1 releases new upgraded firmware regularly to enhance product performance and include more functions. We strongly recommend users to do regular checkup and proceed firmware upgrade for your DVW-W01I2-E1 device. Please download the latest firmware document for our website.

Firmware Upgrade

Select The Upgrade File

3.10.9 Configuration Import & Export

The “**Backup**” button allows the documents derived from current configuration messages to store in your PCs or storage devices.

The “**Restore**” button can import the assigned document by users into the device.

Conifg Import & Export

[Save a copy of current configurations](#)

Backup

[Restore saved configurations from a file](#)

瀏覽...

Restore

3.10.10 Load factory default

When “Load” is clicked, the DVW-W01I2-E1 device restores the default values. In addition, the panel hardware contains RST button for devices to restore default settings.

Load Factory Default

[Load Factory Default](#)

Load

3.10.11 Log off

Users can click **Log off** to exist the configuration page. When configuration and operating on the DVW-W01I2-E1 device is complete, we recommend to log off from your current account for security consideration. When Log off is clicked, the log-in page appears.