

DIInstaller Version 2.6.1 Release Notes

Released: June 20, 2025

These release notes apply to DIInstaller version 2.6.1. The release notes summarize corrected anomalies in this release.

New Features

DIInstaller version 2.6.1 has no new features.

Anomalies

Corrected Anomalies

- *[523058]* After launching the software in DIInstaller, some features might not work as expected. First identified in DIInstaller version 2.6.0.
[523040] DIADesigner version 1.10.0 and COMMGR version 2.10.0 cannot be found in DIInstaller. First identified in DIInstaller version 2.6.0.

Known Anomalies

DIInstaller version 2.6.1 has no known anomalies.

Legal Notices

End User License Agreement (EULA)

You can view the Delta Electronics End User License Agreement (EULA) by opening the.rtf file located in your product's installation folder on your hard drive.

The default location of this file is:

C:\Program Files (x86)\Delta Industrial Automation\DIASudio\DIATools\DIInstaller 2\Licenses.

Open-Source Software Licenses

The software included in this product contains copyrighted software that is licensed under one or more open-source licenses.

You can view all open-source software used in this product and their corresponding licenses by opening the FOSS components in DIInstaller.html file located in your product's Licenses folder on your hard drive.

You can view the following sections in this file.

- Components

Includes the name of the open-source component, its version number, and the type of license.

- Copyright text

- Licenses

Includes the name of the license and the terms of the license.

- Website of the component

The default location of the file is:

C:\Program Files (x86)\Delta Industrial Automation\DIASudio\DIATools\DIInstaller
2\Licenses\FOSS components in DIInstaller.

You may obtain Corresponding Source code for open-source components included in this product from their respective project websites.

Commercial Software Licenses

DIInstaller doesn't use any commercial software components.